Embedded Linux





Various Layers within Linux


				1.335		
Various layers within Linux, also showing separation between the userland and kernel space						
User mode	User applications	bash, LibreOffice, GIMP, Blender, 0 A.D., Mozilla Firefox,				
	System components	init daemon: OpenRC, runit, systemd	System daemons: polkitd, smbd, sshd, udevd	Window manager: X11, Wayland, SurfaceFlinger (Android)	Graphics: Mesa, AMD Catalyst,	Other libraries: GTK, Qt, EFL, SDL, SFML, FLTK, GNUstep,
	C standard library	fopen, execv, malloc, memcpy, localtime, pthread_create (up to 2000 subroutines) glibc aims to be fast, musl aims to be lightweight, uClibc targets embedded systems, bionic was written for Android, etc. All aim to be POSIX/SUS-compatible.				
Kernel mode	Linux kernel	stat, splice, dup, read, open, ioctl, write, mmap, close, exit, etc. (about 380 system calls) The Linux kernel System Call Interface (SCI), aims to be POSIX/SUS-compatible [2]				
		Process scheduling subsystem	IPC subsystem	Memory management subsystem	Virtual files subsystem	Network subsystem
		Other components: ALSA, DRI, evdev, klibc, LVM, device mapper, Linux Network Scheduler, Netfilter Linux Security Modules: SELinux, TOMOYO, AppArmor, Smack				
Hardware (CPU, main memory, data storage devices, etc.)						

https://en.wikipedia.org/wiki/User_space_and_kernel_space





Embedded Linux System







Linux kernel key features

- >> Portability and hardware support
- Scalability
- > Exhaustive networking support
- Stability and reliability
- Modularity
- Easy to program.




System Start Up



Linux Start Up











SOC RK3399







Embedded Linux System Booting







RK3399 System Boot

Reference:


Page 30 of Rockchip_RK3399TRM_V1.3_Part1.pdf





RK3399 System Boot (1)






Cortex-A53 get first instruction from address **0xffff0000 romcode** start to run



RK3399 System Boot (2)






Check ID BLOCK from external SPI Nor Flash



RK3399 System Boot (3)




eMMC SDMMC SPI SPI NOFlash NandFlash

Check ID BLOCK from external SPI Nand Flash



RK3399 System Boot (4)






Check ID BLOCK from external eMMC



RK3399 System Boot (5)

BL1 work in cache IDB_Loader




Check ID BLOCK from external **SDMMC**



RK3399 System Boot (6)






- 5. Check ID BLOCK from external **SDMMC**
- 6. Read 2nK SDRAM initialization image code to internal SRAM



RK3399 System Boot (7)






- 5. Check ID BLOCK from external **SDMMC**
- 6. Read 2nK SDRAM initialization image code to internal SRAM
- 7. Run boot code to do DDR initialization



RK3399 System Boot (8)






- 5. Check ID BLOCK from external **SDMMC**
- 6. Read 2nK SDRAM initialization image code to internal SRAM
- 7. Run boot code to do DDR initialization
- 8. Transfer boot code to DDR then Run boot code



RK3399 System Boot (9)



BL3 work in DDR RAM UBoot



NOFlash NandFlash


Run UBoot



RK3399 System Boot (10)



work in DDR RAM Linux



eMMC

SDMMC

SPI NOFlash NandFlash

SPI

Run Linux





Boot

- >> Power On BootROM code (work in cache)
 - Load BL1
- BL1 (work in cache IDB_Loader)
 - Initial simple exception vectors, PLL (clock)
 - Initial Multi-CPU
 - Load BL2
- BL2 (work in cache)
 - Initial DDR memory
 - Initial C environment (stack, heap,)
 - Load BL31





Boot

- > BL31 (work in DDR)
 - Initial exception vectors
 - Load BL32 (u-boot)
 - BL32 U-boot (work in DDR)
 - Initial storage device
 - Load Linux Kernel
 - Kernel (work in DDR)
 - kernel/Documentation/arm64/booting.txt
 - Load RootFS





Embedded Linux System

User land

