Tas	k Description	Shortened Name			
1.	Place all necessary clamps onto the PA structure (repeat for all clamps)				
	Robot picks up a clamp from where the clamps are stored.	PickClampFromStorage			
	Robot places the clamp onto the PA structure and releases it.	PlaceClampToStructure			
2.	Bring the next beam to be assembled				
	Robot picks up a gripper from where the gripper is stored.	PickGripperFromStorage			
	Robot picks up the next beam from the operator at the loading station	PickBeamFromStorage			
	a. <u>If this is a beam with no clamps</u>				
	Robot places the beam on the ground. The operator fixes it.	PlaceBeamInClamp			
	b. <u>If this beam used clamps</u>				
	Robots and clamps move in synchronisation to clamp the joints.	AssembleBeamWithClamps			
	Robot places the gripper back to its storage location.	PlaceGripperToStorage			
3.	Retrieve all clamps from the PA structure (repeat for all clamps)				
	Robot picks up a used clamp from the PA structure.	PickClampFromStructure			
	Robot places the clamp back in its storage location.	PlaceClampToStorage			

Assembly Model Parameters	Process Model Parameters
Fixed from the previous Assembly Design Phase	Computed or chosen later in the next steps
Assembly Sequence:	Tool Choice:
<pre>bid = beam_id = assembly_sequence[i] where: i = integer iterator beam = assembly.beams[bid] where: type(assembly) = Assembly where: type(beam) = Beam</pre>	<pre>cid = clamp_id = beam.clamp_on_joint[jid] gid = gripper_id = beam.gripper_choice</pre>
Joints and Neighbours:	
<pre>jid = joint_id = beam.joints_to_assemble[j] where: j = integer iterator decomposing: jid = (bid, nid) where: nid = neighbour_beam_id</pre>	

Task Agents	Controller	Low-Level Task Available	
RFL Robot	L2 ROS RRC Driver for RFL Robot	 Linear Motion (LM) Free Motion (FM) 	
Clamp	L2 Clamp Controller	Clamp Jaw Motion	
RFL Robots and Clamp(s)	L3 Process Controller	Clamp and Robot Sync Linear Motion (SM)	
Clamp	L2 ROS RRC Driver for	 Open attachment gripper Close attachment gripper 	
Parallel Gripper	RFL Robot (Digital IO)	Open GripperClose Gripper	
Docking Adapter		Lock Tool Unlock Tool	
Operator	Operator	Place Beams from Storage in Robot Gripper	

Relation Level	Design Phase	Designer	Description	Data Type
Process	TD	TE	Robot Model	Robot Model
	PD	PE	Environment Models	3D Geometry
	PD	PE	Position of Assembly Model relative to the Robot	T [World Frame]
Assembly AD ASD / PE Assembly		Assembly Sequence	List of Beam ID	
,	AD	Auto	Beam Connectivity	Graph of Beams and Joints
Beam AD ASD D		ASD	Designed Location	T [World Frame]
	AD	ASD	Assembly Direction	T [Beam Frame]
	PD	PE / Auto	Gripper Choice	Gripper ID
	PD	PE / Auto	Grasp Face	Face ID
	PD	PE / Auto	Grasp Position	Length along beam
	PD	Auto	Grasp Pose	Inverse T [Beam Frame]
	PD	Auto	Beam Pickup Location	T [World Frame]
	PD	Auto	Clamp Jaw Approach Direction (only for beams that require clamps)	T [World Frame]
Joint	AD	Auto	Joint Position	T [Beam Frame]
•	TD	TE	Allowable Clamp Choices	
	PD	PE / Auto	Clamp Choice	Clamp Type
	PD	Auto	Assigned Clamp Device	Clamp ID
	TD	TE	Allowable Clamp Attach Poses	T [Joint Frame]
	PD	PE / Auto	Clamp Attach Pose	T [Joint Frame]
	AD	Auto	Allowable Assembly Direction	T [Joint Frame]
All DiRT	PD	PE	Storage Location (Tool Storage Station)	T [World Frame]
Tools	TM	TE	Storage Retract Direction	T [Tool Base Frame]
(Gripper and Clamps)	ТМ	TE	Kinematic Chain Link FK	T [Tool Base Frame]
Clamp	TM	TE	Beam-Approach-Jaw Direction	T [Tool Base Frame]
	TM	TE	Clamp-Attach-To-Beam Direction (x2 steps)	T [Tool Base Frame]
Gripper	TM	TE	Gripper-Approach-Beam Direction	T [Tool Base Frame]
1.1	PD	PE	Gripper Location for Beam Pickup	T [World Frame]
	PD	PE / Auto	Beam Pickup Retract Direction	T [World Frame]
Docking	TM	TE	Dock Approach Direction	T [Adapter Base Frame]
Adapter	TM Data	TE	Tool Link FK	T [Adapter Base Frame]

^{*} T = Transformation Data Type, value in the bracket is the transformation's base frame.

Object Type	Parameters	Parameter Type	
RFL Robot	 Joint Configuration Target Frame	List of Joint ValuesRigid Transformation / Frame	
Docking Adapter	Base FrameKinematic Attachment	Rigid Transformation / FrameParent Object, Rigid Transformation	
Tools (Clamps and Grippers)	Tool FrameJoint ConfigurationKinematic Attachment	 Rigid Transformation / Frame List of Joint Values Parent Object, Rigid Transformation 	
Beams	Beam FrameKinematic Attachment	Rigid Transformation / FrameParent Object, Rigid Transformation	
Environment Model	Object Frame	Rigid Transformation / Frame	

Task Agents	Low Level Task	AffectedParameters in UpdateState()	
RFL Robot	Linear Motion Free Motion	Robot/TargetFrame = <u>TargetFrame</u> DockingAdapter/BaseFrame = <u>TargetFrame</u> Tool/ToolFrame = <u>TargetToolFrame</u> * Beam/BeamFrame = <u>TargetBeamFrame</u> *	
RFL Robots and Clamp(s)	Clamp and Robot Sync Linear Motion	Robot/TargetFrame = <u>TargetFrame</u> DockingAdapter/BaseFrame = <u>TargetFrame</u> Tool/ToolFrame = <u>TargetToolFrame</u> Beam/BeamFrame = <u>TargetBeamFrame</u> Clamp/JointConfig = <u>TargetJawPosition</u>	
Clamp	Clamp Jaw Motion	Clamp/JointConfig/JawPosition = <u>TargetJawPosition</u>	
	Open Hanging Gripper	Clamp/JointConfig/Gripper= Open	
	Close Hanging Gripper	Clamp/JointConfig/Gripper = Close	
Parallel Gripper	Open Gripper (Beam)	Gripper/JointConfig/Gripper = Open Beam/KinematicAttachment = None, None	
	Close Gripper (Beam, Grasp)	Gripper/JointConfig/Gripper = Close Beam/KinematicAttachment = Gripper, Grasp	
Docking	Lock Tool (Tool)	Tool/KinematicAttachment = None, None	
Adapter	Unlock Tool (Tool)	Tool/KinematicAttachment = DockingAdapter, DockingAdapter.[Base]T[Child]	
Operator	Place Beam in Robot Gripper	Beam/BeamFrame = <u>TargetBeamFrame</u>	

^{*} Whether Tool and Beam Frame are updated depends on the kinematic chain configuration of that Robot Motion Task

Level 3 Controller	Com	Level 2 Controller (e.g. ABB Robot)	
Long Command 1 (e.g. Movement)	\rightarrow	Move to execution queue	
Long Command 2 (e.g. Movement)	\rightarrow	Move to execution queue	
After Command 1 is completed			
Update Command 1 status (e.g. Completed)	←	Status Update for Command 1	
Emergency Stop during the execution of Command 2			
		Status Update is not initiated	
Controller is not informed about the stop, e.g. the clamps are still running			

Level 3 Controller	Com	Level 2 Controller (e.g. ABB Robot)		
Long Command 1 (e.g. Movement)	\rightarrow	Move to execution queue		
Long Command 2 (e.g. Movement)	\rightarrow	Move to execution queue		
After Command 1 is completed	After Command 1 is completed			
Update Command 1 status (e.g. Completed)	←	Status Update for Command 1		
Emergency Stop during the execution of Command 2				
		Status Update is not initiated		
Controller realised the ABB Robot Controller is not running using the second channel				
Controller can propagate stop signal to other Level 2 controllers, e.g. stop the clamps				

States	Meaning	
Queued	Command is queued for execution because other commands are still running.	
Queue Full Cancelled	Command cannot be queued because the buffer is full.	
Running	Command is currently running	
Paused	Command is paused by the L3 controller after it has started running. It can be unpaused by the L3 controller and continue.	
Completed	Command is completed successfully	
Error	Command failed and cannot be continued. L2 Controller is likely to enter an error state and will not execute further until L3 cancels the error.	
Cancelled	The command is cancelled by the request of L3.	

Level 3 Controller	Com	Level 2 Controller (e.g. ABB Robot)	
Long Command 1 (e.g. Movement)	\rightarrow	Move to execution queue	
Update Command 1 status (e.g. Running)	←	Non-blocking acknowledge / Status Update	
Long Command 2 (e.g. Movement)	\rightarrow	Move to execution queue	
Update Command 2 status (e.g. Queued)	←	Non-blocking acknowledge / Status Update	
After Command 1 is completed			
Update Command 1 status (e.g. Completed)	←	Status Update for Command 1	
Update Command 2 status (e.g. Running)	←	Status Update for Command 2	
Emergency Stop during the execution of Command 2			
Update Command 2 status (e.g. Error)	←	Status Update for Command 2	
Controller can propagate stop signal to other Level 2 controllers, e.g. stop the clamps			
Operator decides to clear the error			
Cancel Command 2	\rightarrow	Acknowledge / Remove command 2 from buffer	