
Part 0xD

CHAPTER 3

Architecture and Organization



Alan Clements


These slides are being provided with permission from the copyright for in-class (CS2208B) use only. The slides must not be reproduced or provided to anyone outside of the class.

All download copies of the slides and/or lecture recordings are for personal use only. Students must destroy these copies within 30 days after receipt of final course evaluations.



Music: "Corporate Success" by Scott Holmes, used under <u>Attribution-NonCommercial License</u>

Block Move Instructions Encoding/Decoding



0 = post operation: use pointer then adjust

1 = pre operation: adjust pointer then use pointer

Block Move Instructions Encoding Example

```
ARM Instruction: STMFD
                                               r13!, {r0-r4, r10}
Condition = 1110 (always - unconditional)
      P = 1 (DB: adjust pointer then use pointer)
      U = 0 (DB: decrement)
      S = 0 (user mode)
      W = 1 (write-back adjusted pointer)
      L = 0 (store)
      r_{\text{base}} = 1101 (r13)
      Register list (r15, r14, ..., r2, r1, r0) = 0000 0100 0001 1111
      1110 1001 0010 1101 0000 0100 0001 1111
                                               FIGURE 3.58
                                                           Encoding ARM's block move instructions
0xE92D041F
                                                   28 27 26 25
                                                              23 22 21 20 19 16 15
                                                              U
                                               Condition 1 0 0
                                                                 S
                                                                                          Register list
           Stack full descending
                                    Free | n - 12
                                                                                  Base register
                Occupied

    Data direction (Load/store)

                                   Item 3 n - 8
                                                                                   0 = store in memory
                 memorv
                                                                                  1 = load into register
                                   Item 2 \mid n-4
                                                                                  Pointer update (Write-back)
                                                                                   0 = don't write back adjusted pointer
                                   Item 1 | n
                                                                                  1 = write back adjusted pointer
                        SP
 Grows up
                                                                                  Restore PSR
                                                                                   0 = don't load PRS or force user mode
                                                                                  1 = load PSR or force user mode
                      Stack grows towards low memory
                                                                                  Pointer direction (Up/down)
                      Stack pointer points at top of stack
                                                                                  0 = decrement pointer
                                                                                  1 = increment pointer
                                                                                  Pointer adjust (Pre-post-increment)
```

This slide is modified from the original slide by the author A. Clements

Pointer adjust (Pre-post-increment)
 0 = post operation: use pointer then adjust

1 = pre operation: adjust pointer then use pointer

Block Move Instructions Encoding Example


```
r13!, {r0-r4,r10}
ARM Instruction: LDMFD
Condition = 1110 (always - unconditional)
      P = 0 (IA: use pointer then adjust)
      U = 1 (IA: increment)
      S = 0 (user mode)
      W = 1 (write-back adjusted pointer)
      L = 1 (load)
     r_{\text{base}} = 1101 (r13)
     Register list (r15, r14, ..., r2, r1, r0) = 0000 0100 0001 1111
      1110 1000 1011 1101 0000 0100 0001 1111
                                               FIGURE 3.58
                                                          Encoding ARM's block move instructions
0xE8BD041F
                                                  28 27 26 25
                                                             23 22 21 20 19 16 15
                                                             U
                                              Condition 1 0 0
                                                                S
                                                                                        Register list
           Stack full descending
                                   Free | n - 12
                                                                                Base register
                Occupied
                                                                                Data direction (Load/store)
                                   Item 3 n - 8
                                                                                 0 = store in memory
                memorv
                                                                                 1 = load into register
                                  Item 2 \mid n-4
                                                                                Pointer update (Write-back)
                                                                                 0 = don't write back adjusted pointer
                                  Item 1 | n
                                                                                 1 = write back adjusted pointer
                       SP
 Grows up
                                                                                Restore PSR
                                                                                 0 = don't load PRS or force user mode
                                                                                 1 = load PSR or force user mode
                     Stack grows towards low memory
                                                                                Pointer direction (Up/down)
                     Stack pointer points at top of stack
                                                                                 0 = decrement pointer
                                                                                 1 = increment pointer
```

This slide is modified from the original slide by the author A. Clements

Block Move Instructions Decoding Example

Decode the ARM machine language 0x08855555

ARM Instruction: STMEQIA **r5**, {r0, r2, r4, r6, r8, r10, r12, r14}



Block Move Instructions Decoding Example

Decode the ARM machine language 0x99922222

```
1001 1001 1001 0010 0010 0010 0010
Condition = 1001 (LS)
   P = 1 (IB: adjust pointer then use pointer)
   U = 1 (IB: increment)
   S = 0 (user mode)
   W = 0 (do not write-back adjusted pointer)
   L = 1 (load)
   r_{\text{base}} = 0010 \ (r2)
   Register list (r15, r14, ..., r2, r1, r0) = 0010 0010 0010 0010
```

ARM Instruction: LDMLSIB r2, {r1, r5, r9, r13}

