

- Powering options:
 1) Provide 5V to J2 and close the solder jumper (NO DC/DC converter)
 2) Add the DC/DC converter and provide the input voltage to J2 (e.g. 12V car battery voltage)

