Chapter 6

Bandwidth Utilization: Multiplexing and Spreading



Bandwidth utilization is the wise use of available bandwidth to achieve specific goals.

Efficiency can be achieved by multiplexing; privacy and anti-jamming can be achieved by spreading.

6-1 MULTIPLEXING

Whenever the bandwidth of a medium linking two devices is greater than the bandwidth needs of the devices, the link can be shared. Multiplexing is the set of techniques that allows the simultaneous transmission of multiple signals across a single data link. As data and telecommunications use increases, so does traffic.

Topics discussed in this section:

Frequency-Division Multiplexing
Wavelength-Division Multiplexing
Synchronous Time-Division Multiplexing
Statistical Time-Division Multiplexing

Figure 6.1 Dividing a link into channels




Figure 6.2 Categories of multiplexing





Figure 6.3 Frequency-division multiplexing





FDM is an analog multiplexing technique that combines analog signals.

Figure 6.4 FDM process




Figure 6.5 FDM demultiplexing example





Figure 6.10 Wavelength-division multiplexing



WDM is an analog multiplexing technique to combine optical signals.

Figure 6.11 Prisms in wavelength-division multiplexing and demultiplexing






Figure 6.12 TDM





TDM is a digital multiplexing technique for combining several low-rate channels into one high-rate one.

Figure 6.13 Synchronous time-division multiplexing



In synchronous TDM, the data rate of the link is *n* times faster, and the unit duration is *n* times shorter.

Figure 6.15 Interleaving




Figure 6.18 Empty slots




Figure 6.22 Framing bits






Figure 6.26 TDM slot comparison



a. Synchronous TDM



b. Statistical TDM