


ARDUINO


# How 433MHz RF Tx-Rx Modules Work & Interface with Arduino



Want to add wireless capabilities to your next Arduino project, for less than the price of a cup of coffee? Well, then 433MHz RF Transmitter and Receiver Modules are just for you! They can often be obtained online for less than two dollars for a pair, making them one of the most inexpensive data communication options that you can get. And best of all, these modules are super tiny, allowing you to incorporate a wireless interface into almost any project.


X

Let's have a closer look at the 433MHz RF Transmitter and Receiver Modules.



This little module is a transmitter among two. It is really simple as it looks. The heart of the module is the SAW resonator which is tuned for 433.xx MHz operation. There is a switching transistor and a few passive components, that's it.


When a logic HIGH is applied to the DATA input, the oscillator runs producing a constant RF output carrier wave at 433.xx MHz and when the DATA input is taken to logic LOW, the oscillator stops. This technique is known as Amplitude Shift Keying, which we will discuss in detail shortly.



This one is a receiver module. Though it looks complex, it is as simple as the transmitter module. It consists of a RF tuned circuit and a couple of OP Amps to amplify the received carrier wave from the transmitter. The amplified signal is further fed to a PLL (Phase Lock Loop) which enables the decoder to "lock" onto a stream of digital bits which gives better decoded output and noise immunity.

ASK – Amplitude Shift Keying
As discussed above, for sending the digital data over radio, these modules use a technique called Amplitude Shift Keying or ASK. In Amplitude Shift Keying the amplitude (i.e. the evel) of the carrier wave (in our case it's a 433MHz signal) is changed in response to the ncoming data signal.
This is very similar to the analog technique of amplitude modulation which you might be familiar with if you're familiar with AM radio. It's sometimes called binary amplitude shift keying because there are only two levels we are concerned with. You can think of it as an ON/OFF switch.
• For Digital 1 – This drives the carrier at full strength.
• For Digital 0 – This cuts the carrier off completely.

This is how the Amplitude modulation looks like:




Amplitude Shift keying has the advantage of being very simple to implement. It is quite simple to design the decoder circuitry. Also ASK needs less bandwidth than other modulation techniques like FSK (Frequency Shift Keying). This is one of the reasons for being inexpensive.

The disadvantage however is that ASK is susceptible to interference from other radio devices and background noise. But as long as you keep your data transmission to a relatively slow speed it can work reliably in most environments.

### 433MHz RF Transmitter & Receiver Pinout

Let's have a look at the pinout of 433MHz RF Transmitter and Receiver Modules.




DATA pin accepts digital data to be transmitted.

supplies power for the transmitter. This can be any positive DC voltage between 3.5V to 12V. Note that the RF output is proportional to the supply voltage i.e. the higher the Voltage, the greater the range will be.

GND is a ground pin.

Antenna is a pin for external antenna. As discussed earlier, you will want to solder a 17.3 cm piece of solid wire to this pin for the improved range.



vcc supplies power for the receiver. Unlike the transmitter, supply voltage for receiver needs to be 5V.

DATA pins output the digital data received. The two center pins are internally tied together, so you can use either one for data out.

GND is a ground pin.

Antenna is a pin for external antenna which is often unmarked. It is the pad in the lower left of the module, right next to the small coil. Again, you will want to solder a 17.3 cm piece of solid wire to this pin for the improved range.


### Wiring – Connecting 433MHz RF Transmitter and Receiver to Arduino UNO


Now that we know everything about the modules it is time to put them to use!

As we will be sending data between two Arduino boards, we will of course need two Arduino boards, two breadboards and a couple of jumper wires.

The wiring for the transmitter is fairly simple. It has only three connections. Connect the VCC pin to 5V pin and GND to ground on the Arduino. The Data-In pin should be connected to Arduino's digital pin #12. You should try and use pin 12 as by default the library we'll be using in our sketch uses this pin for data input.

The following illustration shows the wiring.






Once you have the transmitter wired you can move on to the receiver. The wiring for the receiver is just as easy as the transmitter was.

Once again there are only three connections to make. Connect the VCC pin to 5V pin and GND to ground on the Arduino. Any of the middle two Data-Out pins should be connected to digital pin #11 on the Arduino.

This is how wiring for the receiver should look like.




Now that both the transmitter and receiver are wired up we will need to write some code and send it to the respective Arduino boards. Since you probably have only one PC, we will start with the transmitter. Once the code has been loaded there, we'll move on to the receiver. The Arduino to which transmitter is connected can then be powered using a power supply or battery.

RadioHead Library – a Swiss Army Knife for wireless modules


Before we start coding, there is a library called <b>RadioHead</b> we will need to install into our Arduino IDE that will make writing the code a lot simpler.
RadioHead is a library that allows simple data transfer between Arduino boards. It's so versatile that it can be used to drive all sorts of radio communications devices, including our 433MHz modules.
What RadioHead library does is to take our data, encapsulate it into a packet of data which includes a CRC (Cyclic Redundancy Check) and then send it with the necessary preamble and header to another Arduino. If the data is received correctly, the receiving Arduino is informed that there is data available and proceeds to decode and action it.
The <b>RadioHead Packet</b> is made up as follows: A 36 bit stream of "1" and "0" bit pairs, called a "Training Preamble", is sent at the start of every transmission. These bits are necessary for the receiver to adjust its gain prior to getting the actual data. Followed by this, a 12 bit "Start Symbol" and then the actual data (payload) is added.

A Frame Check Sequence or CRC is added at the end of the packet which is recalculated by RadioHead at the receiver end and if the CRC check is correct, the receiving device is alerted. If the CRC check fails, the packet is discarded.

The whole packet looks something like this:



You can download the library, by visiting the airspayce.com or, just click this button to download the zip:



To install it, open the Arduino IDE, go to Sketch > Include Library > Add .ZIP Library, and then select the RadioHead file that you just downloaded. If you need more details on installing a library, visit this Installing an Arduino Library tutorial.

#### Arduino Code – For 433MHz RF Transmitter

In our experiment we will just send a simple text message from the transmitter to the receiver. It will be helpful to understand how to use the modules and can serve as the

basis for more practical experiments and projects.

Here is the sketch we will be using for our transmitter:

```
// Include RadioHead Amplitude Shift Keying Library
#include <RH_ASK.h>
// Include dependant SPI Library
#include <SPI.h>
// Create Amplitude Shift Keying Object
RH_ASK rf_driver;
void setup()
{
   // Initialize ASK Object
   rf_driver.init();
}
void loop()
{
   const char *msg = "Hello World";
    rf_driver.send((uint8_t *)msg, strlen(msg));
    rf_driver.waitPacketSent();
    delay(1000);
}
```

It's a pretty short sketch but it's all you need to get a signal transmitted.

The sketch starts by including RadioHead ASK library. We also need to include the Arduino SPI Library as the RadioHead library is dependent on it.

```
#include <RH_ASK.h>
#include <SPI.h>
```

Next, we need to create an ASK object in order to access special functions related to RadioHead ASK library.

```
// Create Amplitude Shift Keying Object
RH_ASK rf_driver;
```

In setup function, we need to initialize the ASK object.

```
// Initialize ASK Object
rf_driver.init();
```

In loop function, we start by preparing a message. It's a simple text string and stored in a character pointer named **msg**. Keep in mind that, your message can be anything but should not exceed 27 characters for better performance. And be sure to count the number of characters in it, as you will need that count in the receiver code. In our case, we have 11 characters.

```
// Preparing a message
const char *msg = "Hello World";
```

The message is then transmitted using a <code>send()</code> function. It has two parameters: first is array of data and second is number of bytes (length of the data) to be sent. The <code>send()</code> function is usually followed by <code>waitPacketSent()</code> function which waits until any previous transmit packet is finished being transmitted. After that the sketch waits for a second to give our receiver time to take in everything.

```
rf_driver.send((uint8_t *)msg, strlen(msg));
rf_driver.waitPacketSent();
delay(1000);
```

#### Arduino Code – For 433MHz RF Receiver

Connect the receiver Arduino to the computer and load the following code:

```
// Include RadioHead Amplitude Shift Keying Library
#include <RH ASK.h>
// Include dependant SPI Library
#include <SPI.h>
// Create Amplitude Shift Keying Object
RH_ASK rf_driver;
void setup()
    // Initialize ASK Object
    rf_driver.init();
    // Setup Serial Monitor
    Serial.begin(9600);
}
void loop()
{
    // Set buffer to size of expected message
    uint8_t buf[11];
    uint8_t buflen = sizeof(buf);
    // Check if received packet is correct size
    if (rf_driver.recv(buf, &buflen))
```

```
{
```

Just like the transmitter cade, receiver code starts by loading both the RadioHead and SPI libraries and creating an ASK object.

```
#include <RH_ASK.h>
#include <SPI.h>
RH_ASK rf_driver;
```

In the setup function: we initialize the ASK object and also set up the serial monitor as this is how we will view our received message.

```
rf_driver.init();
Serial.begin(9600);
```

In loop function: we create a buffer of size same as the transmitted message. In our case, it's 11, remember? You will need to adjust this to match your message length. Be sure to include any spaces and punctuation as they all count as characters.

```
uint8_t buf[11];
uint8_t buflen = sizeof(buf);
```


Next, we call a recv() function. This turns the receiver on if it not already on. If there is a valid message available, it copies the message to its first parameter buffer and return true else return false. If the function returns **true**, the sketch enters into **if** statement and prints the received message on the serial monitor.

```
if (rf_driver.recv(buf, &buflen))
{
    Serial.print("Message Received: ");
```

```
Serial.println((char*)buf);
}
```

Then we go back to the start of the loop and do it all over again.

After loading the sketch open your serial monitor. If all is OK you should see your message.



433MHz Wireless RF Module Output on Serial Monitor - Receiver

# Improving range of 433MHz RF modules

The antenna that you use for both the transmitter and receiver can really affect the range you'll be able to obtain with these RF modules. In fact without an antenna you'd be lucky to communicate over a distance of more than a meter.

With a proper antenna design, you'll be able to communicate over a distance of 50 meters.

Of course that is outdoors in an open space. Your range indoors, especially through walls, will be slightly weakened.

The antenna need not be complicated. A simple piece of single core wire can make an excellent antenna for both the transmitter and receiver. The antenna diameter hardly has any importance, as long as the length of the antenna is maintained.

The most effective antenna has the same length as the length of the wave it is used for. For practical purposes, half or a quarter of that length will suffice.

The wavelength of a frequency is calculated as:

Wavelength of frequency =  $\frac{\text{Speed of the transmission (v)}}{\text{Transmission frequency (f)}}$ 

In air, speed of transmission is equal to the speed of light, which is 299,792,458 m/s to be precise. So, For the 433 MHz band the wavelength is:

Wavelength of frequency =  $\frac{299,792,458 \text{ m/s}}{433,000,000 \text{ Hz}}$ = 0.6924 meters = 69.24 cm

As full wave 69.24 cm antenna is a pretty long antenna, it is not very practical to use. That's why we'll opt for a quarter wave antenna which works out to about 17.3 cm or 6.8 inches.

Just in case, if you are experimenting with other radio transmitters that use different frequencies, you can use the same formula to calculate the required antenna length. Pretty easy, Right?



Even a 17.3 cm antenna can seem inconvenient in your tiny Arduino project. But Do NOT be tempted to coil the antenna to make it more compact as this will seriously impact range. A straight antenna is always best!



Disclaimer Privacy Policy Contact Us

Copyright @ 2022 LastMinuteEngineers.com. All rights reserved.