Example BLE AWS 1

With Amazon AWS Greengrass

This application example shows how to connect Bluetooth Low Energy (BLE) devices implementing the "BlueST" protocol to a Linux gateway, and to make them communicate to the Amazon AWS IoT Cloud through the AWS Greengrass edge computing service.

The Greengrass edge computing service allows to perform local computation of Lambda functions with the same logic available on the cloud even when the connection to the cloud is missing; moreover, as soon as the connection becomes available the shadow devices on the cloud get automatically synchronized to the local virtual devices.

This application example involves two BLE devices exporting the "Switch" feature as specified by the "BlueST" protocol; pressing the user button on a device makes the LED of the other device toggle its status. In particular, whenever the user button is pressed on a device, the sending device publishes a JSON message on a "sense" topic with its device identifier and the status of the button, a simple lambda function swaps the device identifier and publishes the new message on an "act" topic, and the recipient device toggles the status of its LED.

Davide Aliprandi - SW Platforms and Cloud - Central Labs - STMicroelectronics S.r.l.

Table of Contents

Requirements	3
Amazon AWS Greengrass (Edge Computing)	
Accessing Greengrass Edge-Computing Service	4
Creating a Group	4
Creating a Greengrass Lambda Function	4
Creating Devices	7
Creating Subscriptions	8
Raspberry PI3	g
Setting up the Raspberry PI3	S
Setting up BlueST and EdgeST SDKs	9
Setting up Amazon AWS Greengrass SDK	10
Bluetooth Low Energy Nodes	11
Deploying Greengrass on the core device	12
Starting the Greengrass daemon	12
Performing a Greengrass deployment	12
Running the demo	12
Setup	12
Running the main Python script	12

Requirements

- Amazon Developer account.
- Raspberry PI3 with an 8GB SD card and:
 - o "Stretch" Raspbian OS
 - o "Linux RaspberryPi 4.9.59-v7+ #1047" kernel
- Two Bluetooth Low Energy IoT nodes made up of:
 - o NUCLEO-F401RE MCU board
 - o X-NUCLEO-IDB05A1 Bluetooth Low Energy expansion board

Amazon AWS Greengrass (Edge Computing)

Accessing Greengrass Edge-Computing Service

- Sign in to your Amazon AWS account at the following webpage:
 - o https://aws.amazon.com/
- Click the "Sign In To the Console" button.
- From the "Services" page, look for the "AWS Greengrass" service.
- Select "Oregon" / "West-2" region (top right page corner).
- Select the "Greengrass" item from the left menu.
- Enter into the "Groups" section and click the "Get Started" button.

Creating a Group

- Click on "Create Group", then "Use easy creation".
- Name your group, for example as "GG_Group_1".
- Click "Next", then "Create Group and Core".
- Download your security certificates and keys by clicking on "Download these resources as a tar.gz". They will have to be copied on your core device later.
- Download the Greengrass SDK by selecting the desired target platform (e.g. "ARMv7l" if you are using, for example, a Raspberry PI3) and clicking on "Download Greengrass version X.Y.Z"; it will be installed later.
- Click "Finish".


Creating a Greengrass Lambda Function

- In the AWS IoT console, choose "Software", download the Python AWS Greengrass core SDK to your computer ("greengrass-core-python-sdk-1.1.0.tar"), and decompress it.
- Enter the "aws_greengrass_core_sdk\examples\HelloWorld" folder and decompress the "greengrassHelloWorld.zip" file into a "greengrassHelloWorld" folder.
- Rename the "GG_Switch_Lambda.py" file to "greengrassHelloWorld.py" and copy it into the "greengrassHelloWorld" folder.
- Compress the following content into a "hello_world_python_lambda.zip" file:




• From the "GG_Group_1" management page, select "Lambdas" from the left menu, "Add lambda", and "Create new lambda".


- Within the "Author from scratch" panel create a lambda function named "GG_Switch_Lambda" that use the "Python 2.7" runtime.
- Under "Role" select "Create a role from template", put "Edge_Role" under "Role name", then select "AWS IoT Button permissions" under "Policy templates", and "Create function" to confirm.
- You should see a control page like the following:



You will end up with an editing page like the following:



- On the "Configuration" tab, in the "Function code" region, under the "Code entry type" drop-down menu, choose "Upload a .ZIP file". For Runtime, choose Python 2.7. Type "greengrassHelloWorld.function_handler" into the "Handler" field. Upload the "hello_world_python_lambda.zip" file you created earlier by clicking on "Upload", then on "Save".
- You should see an editing page like the following:



- Then under "Actions" click on "Publish new version", with a new version, e.g. "V1".
- Return on the AWS IoT console and enter the "GG_Group_1" Greengrass group, select "Lambdas", "Add Lambda", then "Use existing Lambda". Select the "GG_Switch_Lambda" lambda previously created, click "Next", select the desired version, and click on "Finish".

Creating Devices

- Enter the "GG_Group_1" group, select "Devices", then "Add Device", "Create New Device", and create the two devices "IoT_Device_1" and "IoT_Device_2"; then select "Use Defaults".
- Download certificates and keys of the devices by clicking on "Download these resources as a tar.gz", and the Certification Authority as "root.ca.pem" by clicking "Download a root CA". They will have to be copied on your core device later.
- Enter the "GG_Group_1" group, select "Devices", and for each device switch from "Local Shadow Only" to "Sync to the Cloud" capability.
- You should see a list of devices like the following:



Creating Subscriptions

• Enter the "GG_Group_1" Greengrass group, select "Subscriptions" from the left menu, click on "Add Subscription", and create the following custom subscriptions:

FROM	то	ТОРІС
IoT_Device_1	GG_Switch_Lambda:1	iot_device/switch_sense
IoT_Device_2	GG_Switch_Lambda:1	iot_device/switch_sense
GG_Switch_Lambda:1	IoT_Device_1	iot_device/switch_act
GG_Switch_Lambda:1	IoT_Device_2	iot_device/switch_act

• Then, for each device, create the following system subscriptions, related to shadow-devices:

FROM	то	ТОРІС
<device></device>	Local Shadow Service	\$aws/things/ <device>/shadow/update</device>
<device></device>	Local Shadow Service	\$aws/things/ <device>/shadow/get</device>
<device></device>	Local Shadow Service	\$aws/things/ <device>/shadow/delete</device>
Local Shadow Service	<device></device>	\$aws/things/ <device>/shadow/update/accepted</device>
Local Shadow Service	<device></device>	\$aws/things/ <device>/shadow/update/rejected</device>
Local Shadow Service	<device></device>	\$aws/things/ <device>/shadow/update/delta</device>
Local Shadow Service	<device></device>	\$aws/things/ <device>/shadow/get/accepted</device>
Local Shadow Service	<device></device>	\$aws/things/ <device>/shadow/get/rejected</device>
Local Shadow Service	<device></device>	\$aws/things/ <device>/shadow/delete/accepted</device>
Local Shadow Service	<device></device>	\$aws/things/ <device>/shadow/delete/rejected</device>

• At the end you should have 24 subscriptions in your "GG_Group_1" Greengrass group.

Raspberry PI3

Setting up the Raspberry PI3

- Please see the official documentation to set up your Raspberry PI3.
- From a PC/MAC flash the latest "Raspbian OS" release on a fresh SD card. At the time of writing the following release has been used:
 - "Stretch" Raspbian OS
 - o "Linux raspberrypi 4.9.59-v7+ #1047" kernel
- Enable the SSH service temporarily:
 - o touch /<volume>/boot/ssh
- Insert the SD card into your Raspberry PI3.
- Login:
 - o ssh pi@raspberrypi.local
- Run "raspi-config" and:
 - Enable the SSH service permanently.
 - Set the correct timezone.
- Update the system by running the following instructions:
 - o sudo rpi-update
 - o sudo apt-get install --reinstall raspberrypi-bootloader raspberrypi-kernel sqlite3
 - o sudo apt-get update && sudo apt-get upgrade
- Install the required packages:
 - o sudo apt-get install python-pip libglib2.0-dev vim git

Setting up BlueST and EdgeST SDKs

- Please see the official documentation of the SDKs:
 - o https://qithub.com/STMicroelectronics-CentralLabs/BlueSTSDK Python
 - o https://github.com/STMicroelectronics-CentralLabs/EdgeSTSDK Python
- Clone the Git repository of the SDKs onto the PI3 "/home/pi" home folder:
 - o git clone https://github.com/SIMicroelectronics-CentralLabs/BlueSTSDK Python.git
 - o git clone https://github.com/SIMicroelectronics-CentralLabs/EdgeSTSDK Python.git
- Install the bluepy Python library, required by the BlueST SDK:
 - o sudo pip install bluepy
- Install the concurrent.futures Python module, required by the BlueST SDK:
 - o sudo pip install futures

Setting up Amazon AWS Greengrass SDK

- Please see the official documentation to install the Amazon AWS Greengrass SDK. At the time of writing the instructions are as follows.
 - o https://docs.aws.amazon.com/greengrass/latest/developerguide/what
 -is-gg.html
- Install the Amazon AWS IoT Python SDK, required by the EdgeST SDK:
 - o sudo pip install AWSIoTPythonSDK
- Add user and group to the system:

```
o sudo adduser --system ggc_user
o sudo addgroup --system ggc group
```

• Enable hardlink and softlink protection at operating system start-up by adding the following two lines to the end of the "/etc/sysctl.d/98-rpi.conf" file:

```
o fs.protected_hardlinks = 1
o fs.protected symlinks = 1
```

• Reboot the PI, connect to it through SSH, and then run the following commands to confirm the hardlink/symlink change:

```
o sudo sysctl -a 2> /dev/null | grep fs.protected
```

- You should see "fs.protected hardlinks = 1" and "fs.protected symlinks = 1".
- Append the following configuration parameter to the command line within the "/boot/cmdline.txt" file, and then reboot the PI3:

```
o cgroup memory=1
```

- Copy the "Greengrass-linux-armv7l-1.3.0.tar.gz" file downloaded when creating a group into the root of the PI3.
- Install Amazon AWS IoT Greengrass SDK:

```
o sudo tar -xzvf greengrass-platform-version.tar.gz -C /
```

 Install the Symantec VeriSign root Certification Authority "CA.pem" downloaded when creating the devices. This certificate enables your device to communicate with AWS IoT using the MQTT messaging protocol over TLS. Copy it onto the PI3 at the folder:

```
o /greengrass/certs
```

• Configure Amazon AWS IoT Greengrass SDK by editing the following file and filling in with the correct parameters:

```
o /greengrass/config/config.json
```

- Please note that you are required to put your "eeeeeeeeeeeeeeiot.us-west-2.amazonaws.com" AWS IoT endpoint, which you can find in the AWS IoT console under "Settings".
- Further information can be found here:
 - o https://docs.aws.amazon.com/greengrass/latest/developerguide/ggdevice-start.html#config.json-params

Example "config.json" file:

• Copy and rename the core's certificate and keys downloaded when creating the group into the "/greengrass/certs/" folder:

```
o core.cert.pem
o core.private.key
o core.public.key
```

• Create a "devices_ble_aws_1" folder into the PI3 "/home/pi/" folder, and copy and rename all certificates and keys downloaded when creating the devices into it:

```
o root.ca.pem
o iot_device_1.cert.pem
o iot_device_1.private.key
o iot_device_1.public.key
o iot_device_2.cert.pem
o iot_device_2.private.key
o iot device 2.public.key
```

• Copy the "example_ble_aws_1.py" Python application into the PI3 "/home/pi" home folder.

Bluetooth Low Energy Nodes

- Import the "Node_BLE_Switch_Device" mbed OS application to your ARM mbed account, compile, and flash it onto the two switch enabled BLE devices:
 - o https://os.mbed.com/teams/ST/code/Node BLE Switch Device/
- Edit the "example_ble_aws_1.py" example application in the "/home/pi/EdgeSTSDK_Python/edge_st_example/aws/" folder and set the "IOT_DEVICE_1_MAC" and "IOT_DEVICE_2_MAC" global variables to the proper MAC address of your switch enabled BLE devices (which you can retrieve for example through a smartphone application).

Deploying Greengrass on the core device

Starting the Greengrass daemon

- Login to the Raspberry PI.
- Enter the PI3 "/home/pi" home folder:
 - o cd /home/pi
- Restart the Greengrass daemon:
 - o sudo /greengrass/ggc/core/greengrassd restart

Performing a Greengrass deployment

- Sign in to your Amazon AWS account at the following webpage:
 - o https://aws.amazon.com/
- Deploy the system by clicking on "Deployments" from the left panel, then "Deploy".
- Select "Automatic", then "Grant permission".
- Wait for the green status of the deployment.

Running the demo

Setup

Connect and power on all the devices.

Running the main Python script

- Login to the Raspberry PI.
- Enter the PI3 "/home/pi" home folder:
 - o cd /home/pi
- Become super user (to use the Bluetooth peripheral), restart the Greengrass daemon, and set the Python path environmental variable:
 - o sudo su
 - o sudo /greengrass/ggc/core/greengrassd restart
 - o export PYTHONPATH=/home/pi/BlueSTSDK_Python/:/home/pi/EdgeSTSDK_Python/
- Run the application example by passing the endpoint and the path to the root certification authority certificate:
- Press the user button on a BLE device to toggle the LED status on the other device.
- Press CTRL+C to stop the application.