



Contents

1	Lega	al Notic	ee		1
2	Mod	lule Ind	lex		3
	2.1	Modu	les		3
3	Data	a Struct	ture Index		5
	3.1	Data S	Structures		5
4	Mod	lule Do	cumentati	on .	7
	4.1	NvEnd	codeAPI D	ata structures	7
		4.1.1	Define D	ocumentation	12
			4.1.1.1	NV_ENC_CAPS_PARAM_VER	12
			4.1.1.2	NV_ENC_CONFIG_VER	12
			4.1.1.3	NV_ENC_CREATE_BITSTREAM_BUFFER_VER	12
			4.1.1.4	NV_ENC_CREATE_INPUT_BUFFER_VER	12
			4.1.1.5	NV_ENC_CREATE_MV_BUFFER_VER	12
			4.1.1.6	NV_ENC_EVENT_PARAMS_VER	13
			4.1.1.7	NV_ENC_INITIALIZE_PARAMS_VER	13
			4.1.1.8	NV_ENC_LOCK_BITSTREAM_VER	13
			4.1.1.9	NV_ENC_LOCK_INPUT_BUFFER_VER	13
			4.1.1.10	NV_ENC_MAP_INPUT_RESOURCE_VER	13
			4.1.1.11	NV_ENC_MEONLY_PARAMS_VER	13
			4.1.1.12	NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS_VER	13
			4.1.1.13	NV_ENC_PARAMS_RC_2_PASS_FRAMESIZE_CAP	13
			4.1.1.14	NV_ENC_PARAMS_RC_2_PASS_QUALITY	13
			4.1.1.15	NV_ENC_PARAMS_RC_2_PASS_VBR	13
			4.1.1.16	NV_ENC_PARAMS_RC_CBR2	13
			4.1.1.17	NV_ENC_PARAMS_RC_VBR_MINQP	14
			4.1.1.18	NV ENC PIC PARAMS VER	14

ii CONTENTS

		4.1.1.19	NV_ENC_PRESET_CONFIG_VER	14
		4.1.1.20	NV_ENC_RC_PARAMS_VER	14
		4.1.1.21	NV_ENC_RECONFIGURE_PARAMS_VER	14
		4.1.1.22	NV_ENC_REGISTER_RESOURCE_VER	14
		4.1.1.23	NV_ENC_SEQUENCE_PARAM_PAYLOAD_VER	14
		4.1.1.24	NV_ENC_STAT_VER	14
	4.1.2	Enumera	tion Type Documentation	14
		4.1.2.1	NV_ENC_BUFFER_FORMAT	14
		4.1.2.2	NV_ENC_CAPS	15
		4.1.2.3	NV_ENC_DEVICE_TYPE	18
		4.1.2.4	NV_ENC_H264_ADAPTIVE_TRANSFORM_MODE	18
		4.1.2.5	NV_ENC_H264_BDIRECT_MODE	18
		4.1.2.6	NV_ENC_H264_ENTROPY_CODING_MODE	18
		4.1.2.7	NV_ENC_H264_FMO_MODE	18
		4.1.2.8	NV_ENC_HEVC_CUSIZE	19
		4.1.2.9	NV_ENC_INPUT_RESOURCE_TYPE	19
		4.1.2.10	NV_ENC_LEVEL	19
		4.1.2.11	NV_ENC_MEMORY_HEAP	19
		4.1.2.12	NV_ENC_MV_PRECISION	19
		4.1.2.13	NV_ENC_PARAMS_FRAME_FIELD_MODE	19
		4.1.2.14	NV_ENC_PARAMS_RC_MODE	20
		4.1.2.15	NV_ENC_PIC_FLAGS	20
		4.1.2.16	NV_ENC_PIC_STRUCT	20
		4.1.2.17	NV_ENC_PIC_TYPE	20
		4.1.2.18	NV_ENC_STEREO_PACKING_MODE	21
		4.1.2.19	NVENCSTATUS	21
4.2	NvEnc	odeAPI Fu	unctions	23
	4.2.1	Function	Documentation	26
		4.2.1.1	NvEncCreateBitstreamBuffer	26
		4.2.1.2	NvEncCreateInputBuffer	26
		4.2.1.3	NvEncCreateMVBuffer	27
		4.2.1.4	NvEncDestroyBitstreamBuffer	27
		4.2.1.5	NvEncDestroyEncoder	27
		4.2.1.6	NvEncDestroyInputBuffer	28
		4.2.1.7	NvEncDestroyMVBuffer	28
		4.2.1.8	NvEncEncodePicture	29
		4.2.1.9	NvEncGetEncodeCaps	32

			4.2.1.10	NvEncGetEncodeGUIDCount	32
			4.2.1.11	NvEncGetEncodeGUIDs	32
			4.2.1.12	NvEncGetEncodePresetConfig	33
			4.2.1.13	NvEncGetEncodePresetCount	33
			4.2.1.14	NvEncGetEncodePresetGUIDs	34
			4.2.1.15	NvEncGetEncodeProfileGUIDCount	34
			4.2.1.16	NvEncGetEncodeProfileGUIDs	35
			4.2.1.17	NvEncGetEncodeStats	35
			4.2.1.18	NvEncGetInputFormatCount	36
			4.2.1.19	NvEncGetInputFormats	36
			4.2.1.20	NvEncGetSequenceParams	37
			4.2.1.21	NvEncInitializeEncoder	37
			4.2.1.22	NvEncInvalidateRefFrames	39
			4.2.1.23	NvEncLockBitstream	39
			4.2.1.24	NvEncLockInputBuffer	40
			4.2.1.25	NvEncMapInputResource	41
			4.2.1.26	NvEncodeAPICreateInstance	41
			4.2.1.27	NvEncodeAPIGetMaxSupportedVersion	41
			4.2.1.28	NvEncOpenEncodeSession	42
			4.2.1.29	NvEncOpenEncodeSessionEx	42
			4.2.1.30	NvEncReconfigureEncoder	42
			4.2.1.31	NvEncRegisterAsyncEvent	43
				NvEncRegisterResource	43
			4.2.1.33	NvEncRunMotionEstimationOnly	44
			4.2.1.34	NvEncUnlockBitstream	44
			4.2.1.35	NvEncUnlockInputBuffer	45
			4.2.1.36	NvEncUnmapInputResource	45
			4.2.1.37	NvEncUnregisterAsyncEvent	46
			4.2.1.38	NvEncUnregisterResource	46
5	Data	a Struct	ure Docur	mentation	49
	5.1			erence	49
		5.1.1		Description	49
		5.1.2		cumentation	49
			5.1.2.1	Data1	49
			5.1.2.2	Data2	49
			5.1.2.3	Data3	49
			· ·		-

iv CONTENTS

		5.1.2.4	Data4	49
5.2	NV_E	NC_CAPS	S_PARAM Struct Reference	50
	5.2.1	Detailed	Description	50
	5.2.2	Field Do	cumentation	50
		5.2.2.1	capsToQuery	50
		5.2.2.2	reserved	50
		5.2.2.3	version	50
5.3	NV_E	NC_CODI	EC_CONFIG Union Reference	51
	5.3.1	Detailed	Description	51
	5.3.2	Field Do	cumentation	51
		5.3.2.1	h264Config	51
		5.3.2.2	h264MeOnlyConfig	51
		5.3.2.3	hevcConfig	51
		5.3.2.4	hevcMeOnlyConfig	51
		5.3.2.5	reserved	51
5.4	NV_E	NC_CODI	EC_PIC_PARAMS Union Reference	52
	5.4.1	Detailed	Description	52
	5.4.2	Field Do	cumentation	52
		5.4.2.1	h264PicParams	52
		5.4.2.2	hevcPicParams	52
		5.4.2.3	reserved	52
5.5	NV_E	NC_CONI	FIG Struct Reference	53
	5.5.1	Detailed	Description	53
	5.5.2	Field Do	cumentation	53
		5.5.2.1	encodeCodecConfig	53
		5.5.2.2	frameFieldMode	53
		5.5.2.3	frameIntervalP	53
		5.5.2.4	gopLength	53
		5.5.2.5	monoChromeEncoding	53
		5.5.2.6	mvPrecision	54
		5.5.2.7	profileGUID	54
		5.5.2.8	rcParams	54
		5.5.2.9	reserved	54
		5.5.2.10	reserved2	54
		5.5.2.11	version	54
5.6	NV_E	NC_CONI	FIG_H264 Struct Reference	55
	5.6.1	Detailed	Description	56

5.6.2	Field Do	cumentation	56
	5.6.2.1	adaptiveTransformMode	56
	5.6.2.2	bdirectMode	56
	5.6.2.3	chromaFormatIDC	56
	5.6.2.4	disableDeblockingFilterIDC	56
	5.6.2.5	disableSPSPPS	56
	5.6.2.6	enableConstrainedEncoding	56
	5.6.2.7	enableIntraRefresh	56
	5.6.2.8	enableLTR	56
	5.6.2.9	enableStereoMVC	57
	5.6.2.10	enableTemporalSVC	57
	5.6.2.11	enableVFR	57
	5.6.2.12	entropyCodingMode	57
	5.6.2.13	fmoMode	57
	5.6.2.14	h264VUIParameters	57
	5.6.2.15	hierarchicalBFrames	57
	5.6.2.16	hierarchicalPFrames	57
	5.6.2.17	idrPeriod	57
	5.6.2.18	intraRefreshCnt	57
	5.6.2.19	intraRefreshPeriod	58
	5.6.2.20	level	58
	5.6.2.21	ltrNumFrames	58
	5.6.2.22	ltrTrustMode	58
	5.6.2.23	maxNumRefFrames	58
	5.6.2.24	maxTemporalLayers	58
	5.6.2.25	numTemporalLayers	58
	5.6.2.26	outputAUD	58
	5.6.2.27	outputBufferingPeriodSEI	58
	5.6.2.28	outputFramePackingSEI	58
	5.6.2.29	outputPictureTimingSEI	59
	5.6.2.30	outputRecoveryPointSEI	59
	5.6.2.31	ppsId	59
	5.6.2.32	qpPrimeYZeroTransformBypassFlag	59
	5.6.2.33	repeatSPSPPS	59
	5.6.2.34	reserved1	59
	5.6.2.35	reserved2	59
	5.6.2.36	reservedBitFields	59

vi CONTENTS

		5.6.2.37	separateColourPlaneFlag	59
		5.6.2.38	sliceMode	59
		5.6.2.39	sliceModeData	60
		5.6.2.40	spsId	60
		5.6.2.41	stereoMode	60
		5.6.2.42	useConstrainedIntraPred	60
5.7	NV_E	NC_CONI	FIG_H264_MEONLY Struct Reference	61
	5.7.1	Detailed	Description	61
	5.7.2	Field Do	cumentation	61
		5.7.2.1	bStereoEnable	61
		5.7.2.2	disableIntraSearch	61
		5.7.2.3	disablePartition16x16	61
		5.7.2.4	disablePartition16x8	61
		5.7.2.5	disablePartition8x16	61
		5.7.2.6	disablePartition8x8	61
		5.7.2.7	reserved	62
		5.7.2.8	reserved1	62
		5.7.2.9	reserved2	62
5.8	NV_E	NC_CONI	FIG_H264_VUI_PARAMETERS Struct Reference	63
	5.8.1	Detailed	Description	63
	5.8.2	Field Do	cumentation	63
		5.8.2.1	bitstreamRestrictionFlag	63
		5.8.2.2	chromaSampleLocationBot	63
		5.8.2.3	chromaSampleLocationFlag	63
		5.8.2.4	chromaSampleLocationTop	63
		5.8.2.5	colourDescriptionPresentFlag	63
		5.8.2.6	colourMatrix	64
		5.8.2.7	colourPrimaries	64
		5.8.2.8	overscanInfo	64
		5.8.2.9	overscanInfoPresentFlag	64
		5.8.2.10	transferCharacteristics	64
		5.8.2.11	videoFormat	64
		5.8.2.12	videoFullRangeFlag	64
		5.8.2.13	videoSignalTypePresentFlag	64
5.9	NV_E	NC_CONI	FIG_HEVC Struct Reference	65
	5.9.1	Detailed	Description	65
	5.9.2	Field Do	cumentation	65

5.9.2.1	chromaFormatIDC	65
5.9.2.2	disableDeblockAcrossSliceBoundary	66
5.9.2.3	disableSPSPPS	66
5.9.2.4	enableIntraRefresh	66
5.9.2.5	enableLTR	66
5.9.2.6	hevcVUIParameters	66
5.9.2.7	idrPeriod	66
5.9.2.8	intraRefreshCnt	66
5.9.2.9	intraRefreshPeriod	66
5.9.2.1	0 level	66
5.9.2.1	1 ltrNumFrames	66
5.9.2.1	2 ltrTrustMode	67
5.9.2.1	3 maxCUSize	67
5.9.2.1	4 maxNumRefFramesInDPB	67
5.9.2.1	5 maxTemporalLayersMinus1	67
5.9.2.1	6 minCUSize	67
5.9.2.1	7 outputAUD	67
5.9.2.1	8 outputBufferingPeriodSEI	67
5.9.2.1	9 outputPictureTimingSEI	67
5.9.2.2	pixelBitDepthMinus8	67
5.9.2.2	1 ppsId	67
5.9.2.2	2 repeatSPSPPS	67
5.9.2.2	3 reserved	68
5.9.2.2	4 reserved1	68
5.9.2.2	5 reserved2	68
5.9.2.2	6 sliceMode	68
5.9.2.2	7 sliceModeData	68
5.9.2.2	8 spsId	68
5.9.2.2	9 tier	68
5.9.2.3	0 useConstrainedIntraPred	68
5.9.2.3	vpsId	68
NV_ENC_CO	NFIG_HEVC_MEONLY Struct Reference	69
5.10.1 Details	ed Description	69
5.10.2 Field I	Documentation	69
5.10.2	1 reserved	69
5.10.2	2 reserved1	69
NV_ENC_CR	EATE_BITSTREAM_BUFFER Struct Reference	70
	5.9.2.2 5.9.2.3 5.9.2.4 5.9.2.5 5.9.2.6 5.9.2.7 5.9.2.1 5.9.2.1 5.9.2.1 5.9.2.1 5.9.2.1 5.9.2.1 5.9.2.1 5.9.2.1 5.9.2.2	5.9.2.2 disableDeblockAcrossSliceBoundary 5.9.2.3 disableSPSPPS 5.9.2.4 enableIntraRefresh 5.9.2.5 enableLTR 5.9.2.6 hevcVUIParameters 5.9.2.7 idrPeriod 5.9.2.8 intraRefreshCnt 5.9.2.9 intraRefreshPeriod 5.9.2.10 level 5.9.2.11 ltrNumFrames 5.9.2.12 ltrTrustMode 5.9.2.13 maxCUSize 5.9.2.14 maxNumRefFramesInDPB 5.9.2.15 maxTemporalLayersMinus1 5.9.2.16 minCUSize 5.9.2.17 outputAUD 5.9.2.18 outputBufferingPeriodSEI 5.9.2.19 outputPictureTimingSEI 5.9.2.20 pixelBitDepthMinus8 5.9.2.21 repeatSPSPPS 5.9.2.22 repeatSPSPPS 5.9.2.23 reserved 5.9.2.24 reserved1 5.9.2.25 sliceMode 5.9.2.27 sliceMode 5.9.2.28 spsld 5.9.2.29 tier 5.9.2.20 uscConstrainedIntraPred

viii CONTENTS

5.11.1	Detailed Description	70
5.11.2	Field Documentation	70
	5.11.2.1 bitstreamBuffer	70
	5.11.2.2 bitstreamBufferPtr	70
	5.11.2.3 memoryHeap	70
	5.11.2.4 reserved	70
	5.11.2.5 reserved1	70
	5.11.2.6 reserved2	70
	5.11.2.7 size	71
	5.11.2.8 version	71
5.12 NV_E	NC_CREATE_INPUT_BUFFER Struct Reference	72
5.12.1	Detailed Description	72
5.12.2	Field Documentation	72
	5.12.2.1 bufferFmt	72
	5.12.2.2 height	72
	5.12.2.3 inputBuffer	72
	5.12.2.4 memoryHeap	72
	5.12.2.5 pSysMemBuffer	72
	5.12.2.6 reserved	72
	5.12.2.7 reserved1	73
	5.12.2.8 reserved2	73
	5.12.2.9 version	73
	5.12.2.10 width	73
5.13 NV_E	NC_CREATE_MV_BUFFER Struct Reference	74
5.13.1	Detailed Description	74
5.13.2	Field Documentation	74
	5.13.2.1 mvBuffer	74
	5.13.2.2 reserved1	74
	5.13.2.3 reserved2	74
	5.13.2.4 version	74
5.14 NV_E	NC_EVENT_PARAMS Struct Reference	75
5.14.1	Detailed Description	75
5.14.2	Field Documentation	75
	5.14.2.1 completionEvent	75
	5.14.2.2 reserved	75
	5.14.2.3 reserved1	75
	5.14.2.4 reserved2	75

5.14.2.5 version	7:
5.15 NV_ENC_H264_MV_DATA Struct Reference	70
5.15.1 Detailed Description	70
5.15.2 Field Documentation	70
5.15.2.1 mbType	70
5.15.2.2 mv	70
5.15.2.3 partitionType	70
5.15.2.4 reserved	70
5.16 NV_ENC_HEVC_MV_DATA Struct Reference	7'
5.16.1 Detailed Description	7
5.16.2 Field Documentation	7
5.16.2.1 cuSize	7
5.16.2.2 cuType	7
5.16.2.3 lastCUInCTB	7
5.16.2.4 mv	7
5.16.2.5 partitionMode	7
5.17 NV_ENC_INITIALIZE_PARAMS Struct Reference	78
5.17.1 Detailed Description	78
5.17.2 Field Documentation	78
5.17.2.1 darHeight	78
5.17.2.2 darWidth	78
5.17.2.3 enableEncodeAsync	78
5.17.2.4 enableExternalMEHints	79
5.17.2.5 enableMEOnlyMode	79
5.17.2.6 enablePTD	79
5.17.2.7 enableSubFrameWrite	79
5.17.2.8 encodeConfig	79
5.17.2.9 encodeGUID	79
5.17.2.10 encodeHeight	79
5.17.2.11 encodeWidth	79
5.17.2.12 frameRateDen	79
5.17.2.13 frameRateNum	80
5.17.2.14 maxEncodeHeight	80
5.17.2.15 maxEncodeWidth	80
5.17.2.16 maxMEHintCountsPerBlock	80
5.17.2.17 presetGUID	80
5.17.2.18 privData	80

X CONTENTS

	5.17.2.19 privDataSize	80
	5.17.2.20 reportSliceOffsets	80
	5.17.2.21 reserved	80
	5.17.2.22 reserved2	81
	5.17.2.23 reservedBitFields	81
	5.17.2.24 version	81
5.18 NV_EN	NC_LOCK_BITSTREAM Struct Reference	82
5.18.1	Detailed Description	82
5.18.2	Field Documentation	82
	5.18.2.1 bitstreamBufferPtr	82
	5.18.2.2 bitstreamSizeInBytes	82
	5.18.2.3 doNotWait	82
	5.18.2.4 frameAvgQP	83
	5.18.2.5 frameIdx	83
	5.18.2.6 frameSatd	83
	5.18.2.7 hwEncodeStatus	83
	5.18.2.8 ltrFrame	83
	5.18.2.9 ltrFrameBitmap	83
	5.18.2.10 ltrFrameIdx	83
	5.18.2.11 numSlices	83
	5.18.2.12 outputBitstream	83
	5.18.2.13 outputDuration	83
	5.18.2.14 outputTimeStamp	83
	5.18.2.15 pictureStruct	84
	5.18.2.16 pictureType	84
	5.18.2.17 reserved	84
	5.18.2.18 reserved2	84
	5.18.2.19 reservedBitFields	84
	5.18.2.20 sliceOffsets	84
	5.18.2.21 version	84
5.19 NV_EN	NC_LOCK_INPUT_BUFFER Struct Reference	85
5.19.1	Detailed Description	85
5.19.2	Field Documentation	85
	5.19.2.1 bufferDataPtr	85
	5.19.2.2 doNotWait	85
	5.19.2.3 inputBuffer	85
	5.19.2.4 pitch	85

5.19.2.5	reserved1	85
5.19.2.6	reserved2	85
5.19.2.7	reservedBitFields	86
5.19.2.8	version	86
5.20 NV_ENC_MAP	P_INPUT_RESOURCE Struct Reference	87
5.20.1 Detailed	Description	87
5.20.2 Field Do	ocumentation	87
5.20.2.1	inputResource	87
5.20.2.2	mappedBufferFmt	87
5.20.2.3	mappedResource	87
5.20.2.4	registeredResource	87
5.20.2.5	reserved1	87
5.20.2.6	reserved2	87
5.20.2.7	subResourceIndex	88
5.20.2.8	version	88
5.21 NV_ENC_MEO	NLY_PARAMS Struct Reference	89
5.21.1 Detailed	Description	89
5.21.2 Field Do	ocumentation	89
5.21.2.1	bufferFmt	89
5.21.2.2	completionEvent	89
5.21.2.3	inputBuffer	89
5.21.2.4	inputHeight	89
5.21.2.5	inputWidth	89
5.21.2.6	mvBuffer	90
5.21.2.7	referenceFrame	90
5.21.2.8	reserved1	90
5.21.2.9	reserved2	90
5.21.2.10	0 version	90
5.21.2.11	1 viewID	90
5.22 NV_ENC_MVE	SCTOR Struct Reference	91
5.22.1 Detailed	Description	91
5.22.2 Field Do	ocumentation	91
5.22.2.1	mvx	91
5.22.2.2	mvy	91
	N_ENCODE_SESSION_EX_PARAMS Struct Reference	
5.23.1 Detailed	Description	92
5.23.2 Field Do	ocumentation	92

xii CONTENTS

	5.23.2.1	apiVersion	92
	5.23.2.2	device	92
	5.23.2.3	deviceType	92
	5.23.2.4	reserved	92
	5.23.2.5	reserved1	92
	5.23.2.6	reserved2	92
	5.23.2.7	version	93
5.24 NV_E	NC_PIC_F	PARAMS Struct Reference	94
5.24.1	Detailed	Description	94
5.24.2	Field Do	cumentation	94
	5.24.2.1	bufferFmt	94
	5.24.2.2	codecPicParams	94
	5.24.2.3	completionEvent	95
	5.24.2.4	encodePicFlags	95
	5.24.2.5	frameIdx	95
	5.24.2.6	inputBuffer	95
	5.24.2.7	inputDuration	95
	5.24.2.8	inputHeight	95
	5.24.2.9	inputPitch	95
	5.24.2.10	inputTimeStamp	95
	5.24.2.11	inputWidth	95
	5.24.2.12	2 meExternalHints	95
	5.24.2.13	meHintCountsPerBlock	96
	5.24.2.14	meHintRefPicDist	96
	5.24.2.15	outputBitstream	96
	5.24.2.16	pictureStruct	96
	5.24.2.17	pictureType	96
	5.24.2.18	gpDeltaMap	96
	5.24.2.19	qpDeltaMapSize	96
	5.24.2.20	reserved1	96
	5.24.2.21	reserved2	96
	5.24.2.22	2 reserved3	97
	5.24.2.23	reserved4	97
	5.24.2.24	reservedBitFields	97
	5.24.2.25	version	97
5.25 NV_E	NC_PIC_F	PARAMS_H264 Struct Reference	98
5.25.1	Detailed	Description	98

CONTENTS xiii

5.25.2	Field Doc	cumentation	. 98
	5.25.2.1	colourPlaneId	. 98
	5.25.2.2	constrainedFrame	. 98
	5.25.2.3	displayPOCSyntax	. 98
	5.25.2.4	forceIntraRefreshWithFrameCnt	. 99
	5.25.2.5	ltrMarkFrame	. 99
	5.25.2.6	ltrMarkFrameIdx	. 99
	5.25.2.7	ltrUsageMode	. 99
	5.25.2.8	ltrUseFrameBitmap	. 99
	5.25.2.9	ltrUseFrames	. 99
	5.25.2.10	refPicFlag	. 99
	5.25.2.11	reserved	. 99
	5.25.2.12	reserved2	. 99
	5.25.2.13	reserved3	. 99
	5.25.2.14	reservedBitFields	. 99
	5.25.2.15	seiPayloadArray	. 100
	5.25.2.16	seiPayloadArrayCnt	. 100
	5.25.2.17	sliceMode	. 100
	5.25.2.18	sliceModeData	. 100
	5.25.2.19	sliceModeDataUpdate	. 100
	5.25.2.20	sliceTypeArrayCnt	. 100
	5.25.2.21	sliceTypeData	. 100
5.26 NV_EN	NC_PIC_P	ARAMS_HEVC Struct Reference	. 101
5.26.1	Detailed I	Description	. 101
5.26.2	Field Doc	cumentation	. 101
	5.26.2.1	constrainedFrame	. 101
	5.26.2.2	displayPOCSyntax	. 101
	5.26.2.3	forceIntraRefreshWithFrameCnt	. 101
	5.26.2.4	ltrMarkFrame	. 102
	5.26.2.5	ltrMarkFrameIdx	. 102
	5.26.2.6	ltrUsageMode	. 102
	5.26.2.7	ltrUseFrameBitmap	. 102
	5.26.2.8	ltrUseFrames	. 102
	5.26.2.9	refPicFlag	. 102
	5.26.2.10	reserved	. 102
	5.26.2.11	reserved2	. 102
	5.26.2.12	reserved3	. 102

5.26.2.13 reservedBitFields	. 102
5.26.2.14 seiPayloadArray	. 102
5.26.2.15 seiPayloadArrayCnt	. 103
5.26.2.16 sliceMode	. 103
5.26.2.17 sliceModeData	. 103
5.26.2.18 sliceModeDataUpdate	. 103
5.26.2.19 sliceTypeArrayCnt	. 103
5.26.2.20 sliceTypeData	. 103
5.26.2.21 temporalId	. 103
5.27 NV_ENC_PRESET_CONFIG Struct Reference	. 104
5.27.1 Detailed Description	. 104
5.27.2 Field Documentation	. 104
5.27.2.1 presetCfg	. 104
5.27.2.2 reserved1	. 104
5.27.2.3 reserved2	. 104
5.27.2.4 version	. 104
5.28 NV_ENC_QP Struct Reference	. 105
5.28.1 Detailed Description	. 105
5.29 NV_ENC_RC_PARAMS Struct Reference	. 106
5.29.1 Detailed Description	. 106
5.29.2 Field Documentation	. 106
5.29.2.1 aqStrength	. 106
5.29.2.2 averageBitRate	. 106
5.29.2.3 constQP	. 107
5.29.2.4 disableBadapt	. 107
5.29.2.5 disableIadapt	. 107
5.29.2.6 enableAQ	. 107
5.29.2.7 enableExtQPDeltaMap	. 107
5.29.2.8 enableInitialRCQP	. 107
5.29.2.9 enableLookahead	. 107
5.29.2.10 enableMaxQP	. 107
5.29.2.11 enableMinQP	. 107
5.29.2.12 enableNonRefP	. 107
5.29.2.13 enableTemporalAQ	. 107
5.29.2.14 initialRCQP	. 108
5.29.2.15 lookaheadDepth	. 108
5.29.2.16 maxBitRate	. 108

	5.29.2.17 maxQP
	5.29.2.18 minQP
	5.29.2.19 rateControlMode
	5.29.2.20 reservedBitFields
	5.29.2.21 strictGOPTarget
	5.29.2.22 targetQuality
	5.29.2.23 temporallayerIdxMask
	5.29.2.24 temporalLayerQP
	5.29.2.25 vbvBufferSize
	5.29.2.26 vbvInitialDelay
	5.29.2.27 zeroReorderDelay
5.30 NV_E	NC_RECONFIGURE_PARAMS Struct Reference
5.30.1	Detailed Description
5.30.2	Field Documentation
	5.30.2.1 forceIDR
	5.30.2.2 reInitEncodeParams
	5.30.2.3 resetEncoder
	5.30.2.4 version
5.31 NV_E	NC_REGISTER_RESOURCE Struct Reference
5.31.1	Detailed Description
5.31.2	Field Documentation
	5.31.2.1 bufferFormat
	5.31.2.2 height
	5.31.2.3 pitch
	5.31.2.4 registeredResource
	5.31.2.5 reserved1
	5.31.2.6 reserved2
	5.31.2.7 resourceToRegister
	5.31.2.8 resourceType
	5.31.2.9 subResourceIndex
	5.31.2.10 version
	5.31.2.11 width
5.32 NV_E	NC_SEI_PAYLOAD Struct Reference
5.32.1	Detailed Description
5.32.2	Field Documentation
	5.32.2.1 payload
	5.32.2.2 payloadSize

	5.32.2.3	payloadType	3
5.33 NV_E	NC_SEQU	TENCE_PARAM_PAYLOAD Struct Reference	4
5.33.1	Detailed 1	Description	4
5.33.2	Field Doo	cumentation	4
	5.33.2.1	inBufferSize	4
	5.33.2.2	outSPSPPSPayloadSize	4
	5.33.2.3	ppsId	4
	5.33.2.4	reserved	4
	5.33.2.5	reserved2	4
	5.33.2.6	spsId	4
	5.33.2.7	spsppsBuffer	5
	5.33.2.8	version	5
5.34 NV_E	NC_STAT	Struct Reference	6
5.34.1	Detailed 1	Description	6
5.34.2	Field Doo	cumentation	6
	5.34.2.1	bitStreamSize	6
	5.34.2.2	lastValidByteOffset	6
	5.34.2.3	outputBitStream	6
	5.34.2.4	picIdx	6
	5.34.2.5	picType	6
	5.34.2.6	reserved	6
	5.34.2.7	reserved1	7
	5.34.2.8	reserved2	7
	5.34.2.9	sliceOffsets	7
	5.34.2.10	version	7
5.35 NV_E	NCODE_A	API_FUNCTION_LIST Struct Reference	8
5.35.1	Detailed 1	Description	8
5.35.2	Field Doo	cumentation	9
	5.35.2.1	nvEncCreateBitstreamBuffer	9
	5.35.2.2	nvEncCreateInputBuffer	9
	5.35.2.3	nvEncCreateMVBuffer	9
	5.35.2.4	nvEncDestroyBitstreamBuffer	9
	5.35.2.5	nvEncDestroyEncoder	9
	5.35.2.6	nvEncDestroyInputBuffer	9
	5.35.2.7	nvEncDestroyMVBuffer	9
	5.35.2.8	nvEncEncodePicture	9
	5.35.2.9	nvEncGetEncodeCaps	9

CONTENTS xvii

	5.35.2.10 nvEncGetEncodeGUIDCount	19
	5.35.2.11 nvEncGetEncodeGUIDs	20
	5.35.2.12 nvEncGetEncodePresetConfig	20
	5.35.2.13 nvEncGetEncodePresetCount	20
	5.35.2.14 nvEncGetEncodePresetGUIDs	20
	5.35.2.15 nvEncGetEncodeProfileGUIDCount	20
	5.35.2.16 nvEncGetEncodeProfileGUIDs	20
	5.35.2.17 nvEncGetEncodeStats	20
	5.35.2.18 nvEncGetInputFormatCount	20
	5.35.2.19 nvEncGetInputFormats	20
	5.35.2.20 nvEncGetSequenceParams	20
	5.35.2.21 nvEncInitializeEncoder	21
	5.35.2.22 nvEncInvalidateRefFrames	21
	5.35.2.23 nvEncLockBitstream	21
	5.35.2.24 nvEncLockInputBuffer	21
	5.35.2.25 nvEncMapInputResource	21
	5.35.2.26 nvEncOpenEncodeSession	21
	5.35.2.27 nvEncOpenEncodeSessionEx	21
	5.35.2.28 nvEncReconfigureEncoder	21
	5.35.2.29 nvEncRegisterAsyncEvent	21
	5.35.2.30 nvEncRegisterResource	21
	5.35.2.31 nvEncRunMotionEstimationOnly	22
	5.35.2.32 nvEncUnlockBitstream	22
	5.35.2.33 nvEncUnlockInputBuffer	22
	5.35.2.34 nvEncUnmapInputResource	22
	5.35.2.35 nvEncUnregisterAsyncEvent	22
	5.35.2.36 nvEncUnregisterResource	22
	5.35.2.37 reserved	22
	5.35.2.38 reserved2	22
	5.35.2.39 version	22
5.36 NVEN	C_EXTERNAL_ME_HINT Struct Reference	23
5.36.1	Detailed Description	23
5.36.2	Field Documentation	23
	5.36.2.1 dir	23
	5.36.2.2 lastOfMB	23
	5.36.2.3 lastofPart	23
	5.36.2.4 mvx	23

xviii CONTENTS

5.36.2.5 mvy
5.36.2.6 partType
5.36.2.7 refidx
5.37 NVENC_EXTERNAL_ME_HINT_COUNTS_PER_BLOCKTYPE Struct Reference
5.37.1 Detailed Description
5.37.2 Field Documentation
5.37.2.1 numCandsPerBlk16x16
5.37.2.2 numCandsPerBlk16x8
5.37.2.3 numCandsPerBlk8x16
5.37.2.4 numCandsPerBlk8x8
5.37.2.5 reserved
5.37.2.6 reserved1
5.38 NVENC_RECT Struct Reference
5.38.1 Detailed Description
5.38.2 Field Documentation
5.38.2.1 bottom
5.38.2.2 left
5.38.2.3 right
5.38.2.4 top

Chapter 1

Legal Notice

Copyright (c) 2011-2016 NVIDIA Corporation. All rights reserved.

Notice

This source code and/or documentation ("Licensed Deliverables") are subject to NVIDIA intellectual property rights under U.S. and international Copyright laws.

These Licensed Deliverables contained herein is PROPRIETARY and to NVIDIA and is being provided under the terms and conditions of a form of NVIDIA software license agreement by and between NVIDIA and Licensee ("License Agreement") or electronically accepted by Licensee. Notwithstanding any terms or conditions to the contrary in the License Agreement, reproduction or disclosure of the Licensed Deliverables to any third party without the express written consent of NVIDIA is prohibited.

ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." WITHOUT EXPRESS OR IMPLIED WARRANTY OF ANY KIND. NVIDIA DISCLAIMS ALL WARRANTIES WITH REGARD TO THESE LICENSED DELIVERABLES, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY, NONINFRINGEMENT, AND FITNESS FOR A PARTICULAR PURPOSE. NOTWITHSTANDING ANY TERMS OR CONDITIONS TO THE CONTRARY IN THE LICENSE AGREEMENT, IN NO EVENT SHALL NVIDIA BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THESE LICENSED DELIVERABLES.

Information furnished is believed to be accurate and reliable. However, NVIDIA assumes no responsibility for the consequences of use of such information nor for any infringement of patents or other rights of third parties, which may result from its use. No License is granted by implication or otherwise under any patent or patent rights of NVIDIA Corporation. Specifications mentioned in the software are subject to change without notice. This publication supersedes and replaces all other information previously supplied.

NVIDIA Corporation products are not authorized for use as critical components in life support devices or systems without express written approval of NVIDIA Corporation.

U.S. Government End Users. These Licensed Deliverables are a "commercial item" as that term is defined at 48 C.F.R. 2.101 (OCT * 1995), consisting of "commercial computer software" and "commercial computer software documentation" as such terms are used in 48 C.F.R. 12.212 (SEPT 1995) and is provided to the U.S. Government only as a commercial end item. Consistent with 48 C.F.R.12.212 and 48 C.F.R. 227.7202-1 through 227.7202-4 (JUNE 1995), all U.S. Government End Users acquire the Licensed Deliverables with only those rights set forth herein.

Any use of the Licensed Deliverables in individual and commercial software must include, in the user documentation and internal comments to the code, the above Disclaimer and U.S. Government End Users Notice.

2 Legal Notice

Trademarks

NVIDIA and the NVIDIA logo are trademarks or registered trademarks of NVIDIA Corporation in the U.S. and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

Microsoft, Windows, and the Windows logo are registered trademarks of Microsoft Corporation.

Other company and product names may be trademarks or registered trademarks of the respective companies with which they are associated.

Chapter 2

Module Index

2.1 Modules

Here	ic a	list	of all	modules:

vEncodeAPI Data structures	 7
vEncodeAPI Functions	 23

Module Index

Chapter 3

Data Structure Index

3.1 Data Structures

Here are the data structures with brief descriptions:
GUID
NV_ENC_CAPS_PARAM
NV_ENC_CODEC_CONFIG
NV_ENC_CODEC_PIC_PARAMS
NV_ENC_CONFIG
NV ENC CONFIG H264
NV_ENC_CONFIG_H264_MEONLY
NV_ENC_CONFIG_H264_VUI_PARAMETERS
NV_ENC_CONFIG_HEVC
NV_ENC_CONFIG_HEVC_MEONLY
NV_ENC_CREATE_BITSTREAM_BUFFER
NV_ENC_CREATE_INPUT_BUFFER
NV_ENC_CREATE_MV_BUFFER
NV_ENC_EVENT_PARAMS
NV_ENC_H264_MV_DATA 76
NV_ENC_HEVC_MV_DATA
NV_ENC_INITIALIZE_PARAMS
NV_ENC_LOCK_BITSTREAM 82
NV_ENC_LOCK_INPUT_BUFFER85
NV_ENC_MAP_INPUT_RESOURCE
NV_ENC_MEONLY_PARAMS
NV_ENC_MVECTOR
NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS 92
NV_ENC_PIC_PARAMS
NV_ENC_PIC_PARAMS_H264
NV_ENC_PIC_PARAMS_HEVC
NV_ENC_PRESET_CONFIG
NV_ENC_QP
NV_ENC_RC_PARAMS
NV_ENC_RECONFIGURE_PARAMS
NV_ENC_REGISTER_RESOURCE
NV_ENC_SEI_PAYLOAD
NV_ENC_SEQUENCE_PARAM_PAYLOAD

Data Structure	Inc	lex
----------------	-----	-----

NV_ENC_STAT	116
NV_ENCODE_API_FUNCTION_LIST	118
NVENC_EXTERNAL_ME_HINT	123
NVENC_EXTERNAL_ME_HINT_COUNTS_PER_BLOCKTYPE	125
NVENC RECT	126

Chapter 4

Module Documentation

4.1 NvEncodeAPI Data structures

Data Structures

- struct GUID
- struct NVENC RECT
- struct NV_ENC_CAPS_PARAM
- struct NV_ENC_CREATE_INPUT_BUFFER
- struct NV_ENC_CREATE_BITSTREAM_BUFFER
- struct NV_ENC_MVECTOR
- struct NV_ENC_H264_MV_DATA
- struct NV_ENC_HEVC_MV_DATA
- struct NV_ENC_CREATE_MV_BUFFER
- struct NV_ENC_QP
- struct NV_ENC_RC_PARAMS
- struct NV_ENC_CONFIG_H264_VUI_PARAMETERS
- struct NVENC_EXTERNAL_ME_HINT_COUNTS_PER_BLOCKTYPE
- struct NVENC_EXTERNAL_ME_HINT
- struct NV_ENC_CONFIG_H264
- struct NV_ENC_CONFIG_HEVC
- struct NV_ENC_CONFIG_H264_MEONLY
- struct NV_ENC_CONFIG_HEVC_MEONLY
- union NV ENC CODEC CONFIG
- struct NV_ENC_CONFIG
- struct NV_ENC_INITIALIZE_PARAMS
- struct NV_ENC_RECONFIGURE_PARAMS
- struct NV_ENC_PRESET_CONFIG
- struct NV_ENC_SEI_PAYLOAD
- struct NV_ENC_PIC_PARAMS_H264
- struct NV_ENC_PIC_PARAMS_HEVC
- union NV_ENC_CODEC_PIC_PARAMS
- struct NV_ENC_PIC_PARAMS
- struct NV_ENC_MEONLY_PARAMS
- struct NV_ENC_LOCK_BITSTREAM
- struct NV_ENC_LOCK_INPUT_BUFFER

- struct NV ENC MAP INPUT RESOURCE
- struct NV_ENC_REGISTER_RESOURCE
- struct NV_ENC_STAT
- struct NV_ENC_SEQUENCE_PARAM_PAYLOAD
- struct NV_ENC_EVENT_PARAMS
- struct NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS
- struct NV_ENCODE_API_FUNCTION_LIST

Defines

- #define NV_ENC_PARAMS_RC_VBR_MINQP (NV_ENC_PARAMS_RC_MODE)0x4
- #define NV_ENC_PARAMS_RC_2_PASS_QUALITY NV_ENC_PARAMS_RC_CBR_LOWDELAY_HQ
- #define NV_ENC_PARAMS_RC_2_PASS_FRAMESIZE_CAP NV_ENC_PARAMS_RC_CBR_HQ
- #define NV_ENC_PARAMS_RC_2_PASS_VBR NV_ENC_PARAMS_RC_VBR_HQ
- #define NV_ENC_PARAMS_RC_CBR2 NV_ENC_PARAMS_RC_CBR
- #define NV_ENC_CAPS_PARAM_VER NVENCAPI_STRUCT_VERSION(1)
- #define NV_ENC_CREATE_INPUT_BUFFER_VER NVENCAPI_STRUCT_VERSION(1)
- #define NV_ENC_CREATE_BITSTREAM_BUFFER_VER NVENCAPI_STRUCT_VERSION(1)
- #define NV_ENC_CREATE_MV_BUFFER_VER NVENCAPI_STRUCT_VERSION(1)
- #define NV ENC RC PARAMS VER NVENCAPI STRUCT VERSION(1)
- #define NV_ENC_CONFIG_VER (NVENCAPI_STRUCT_VERSION(6) | (1<<31))
- #define NV_ENC_INITIALIZE_PARAMS_VER (NVENCAPI_STRUCT_VERSION(5) | (1<<31))
- #define NV_ENC_RECONFIGURE_PARAMS_VER (NVENCAPI_STRUCT_VERSION(1) | (1<<31))
- #define NV_ENC_PRESET_CONFIG_VER (NVENCAPI_STRUCT_VERSION(4) | (1<<31))
- #define NV_ENC_PIC_PARAMS_VER (NVENCAPI_STRUCT_VERSION(4) | (1<<31))
- #define NV ENC MEONLY PARAMS VER NVENCAPI STRUCT VERSION(3)
- #define NV_ENC_LOCK_BITSTREAM_VER NVENCAPI_STRUCT_VERSION(1)
- #define NV_ENC_LOCK_INPUT_BUFFER_VER NVENCAPI_STRUCT_VERSION(1)
- #define NV_ENC_MAP_INPUT_RESOURCE_VER NVENCAPI_STRUCT_VERSION(4)
- #define NV_ENC_REGISTER_RESOURCE_VER NVENCAPI_STRUCT_VERSION(3)
- #define NV_ENC_STAT_VER NVENCAPI_STRUCT_VERSION(1)
- #define NV ENC SEQUENCE PARAM PAYLOAD VER NVENCAPI STRUCT VERSION(1)
- #define NV_ENC_EVENT_PARAMS_VER NVENCAPI_STRUCT_VERSION(1)
- #define NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS_VER NVENCAPI_STRUCT_VERSION(1)

Enumerations

```
enum NV_ENC_PARAMS_FRAME_FIELD_MODE {
    NV_ENC_PARAMS_FRAME_FIELD_MODE_FRAME = 0x01,
    NV_ENC_PARAMS_FRAME_FIELD_MODE_FIELD = 0x02,
    NV_ENC_PARAMS_FRAME_FIELD_MODE_MBAFF = 0x03 }

enum NV_ENC_PARAMS_RC_MODE {
    NV_ENC_PARAMS_RC_CONSTQP = 0x0,
    NV_ENC_PARAMS_RC_VBR = 0x1,
    NV_ENC_PARAMS_RC_CBR = 0x2,
    NV_ENC_PARAMS_RC_CBR_LOWDELAY_HQ = 0x8,
    NV_ENC_PARAMS_RC_CBR_LOWDELAY_HQ = 0x8,
    NV_ENC_PARAMS_RC_CBR_HQ = 0x10,
    NV_ENC_PARAMS_RC_VBR_HQ = 0x20 }
```

```
enum NV_ENC_PIC_STRUCT {
 NV\_ENC\_PIC\_STRUCT\_FRAME = 0x01,
 NV_ENC_PIC_STRUCT_FIELD_TOP_BOTTOM = 0x02,
 NV ENC PIC STRUCT FIELD BOTTOM TOP = 0x03 }
• enum NV ENC PIC TYPE {
 NV ENC PIC TYPE P = 0x0,
 NV\_ENC\_PIC\_TYPE\_B = 0x01,
 NV\_ENC\_PIC\_TYPE\_I = 0x02,
 NV\_ENC\_PIC\_TYPE\_IDR = 0x03,
 NV\_ENC\_PIC\_TYPE\_BI = 0x04,
 NV\_ENC\_PIC\_TYPE\_SKIPPED = 0x05,
 NV_{ENC_{PIC_{TYPE_{INTRA_{REFRESH}}}} = 0x06,
 NV ENC PIC TYPE UNKNOWN = 0xFF }
• enum NV_ENC_MV_PRECISION {
 NV_ENC_MV_PRECISION_DEFAULT = 0x0,
 NV\_ENC\_MV\_PRECISION\_FULL\_PEL = 0x01,
 NV\_ENC\_MV\_PRECISION\_HALF\_PEL = 0x02,
 NV_ENC_MV_PRECISION_QUARTER_PEL = 0x03 }
• enum NV_ENC_BUFFER_FORMAT {
 NV_{ENC_BUFFER_FORMAT_UNDEFINED = 0x000000000,
 NV_{ENC_BUFFER_FORMAT_NV12} = 0x00000001,
 NV_ENC_BUFFER_FORMAT_YV12 = 0x00000010,
 NV_ENC_BUFFER_FORMAT_IYUV = 0x00000100,
 NV_ENC_BUFFER_FORMAT_YUV444 = 0x00001000,
 NV_ENC_BUFFER_FORMAT_YUV420_10BIT = 0x00010000,
 NV_ENC_BUFFER_FORMAT_YUV444_10BIT = 0x00100000,
 NV\_ENC\_BUFFER\_FORMAT\_ARGB = 0x010000000,
 NV\_ENC\_BUFFER\_FORMAT\_ARGB10 = 0x020000000,
 NV_{ENC_BUFFER_FORMAT_AYUV = 0x04000000,
 NV_ENC_BUFFER_FORMAT_ABGR = 0x100000000,
 NV_ENC_BUFFER_FORMAT_ABGR10 = 0x20000000 }
• enum NV_ENC_LEVEL
• enum NVENCSTATUS {
 NV_ENC_SUCCESS,
 NV_ENC_ERR_NO_ENCODE_DEVICE,
 NV_ENC_ERR_UNSUPPORTED_DEVICE,
 NV_ENC_ERR_INVALID_ENCODERDEVICE,
 NV_ENC_ERR_INVALID_DEVICE,
 NV_ENC_ERR_DEVICE_NOT_EXIST,
 NV_ENC_ERR_INVALID_PTR,
 NV_ENC_ERR_INVALID_EVENT,
 NV_ENC_ERR_INVALID_PARAM,
```

```
NV_ENC_ERR_INVALID_CALL,
 NV_ENC_ERR_OUT_OF_MEMORY,
 NV_ENC_ERR_ENCODER_NOT_INITIALIZED,
 NV_ENC_ERR_UNSUPPORTED_PARAM,
 NV_ENC_ERR_LOCK_BUSY,
 NV_ENC_ERR_NOT_ENOUGH_BUFFER,
 NV_ENC_ERR_INVALID_VERSION,
 NV_ENC_ERR_MAP_FAILED,
 NV_ENC_ERR_NEED_MORE_INPUT,
 NV_ENC_ERR_ENCODER_BUSY,
 NV ENC ERR EVENT NOT REGISTERD,
 NV ENC ERR GENERIC,
 NV_ENC_ERR_INCOMPATIBLE_CLIENT_KEY,
 NV_ENC_ERR_UNIMPLEMENTED,
 NV_ENC_ERR_RESOURCE_REGISTER_FAILED,
 NV_ENC_ERR_RESOURCE_NOT_REGISTERED,
 NV_ENC_ERR_RESOURCE_NOT_MAPPED }
• enum NV_ENC_PIC_FLAGS {
 NV_ENC_PIC_FLAG_FORCEINTRA = 0x1,
 NV_ENC_PIC_FLAG_FORCEIDR = 0x2,
 NV\_ENC\_PIC\_FLAG\_OUTPUT\_SPSPPS = 0x4,
 NV_ENC_PIC_FLAG_EOS = 0x8 }
• enum NV_ENC_MEMORY_HEAP {
 NV_ENC_MEMORY_HEAP_AUTOSELECT = 0,
 NV\_ENC\_MEMORY\_HEAP\_VID = 1,
 NV\_ENC\_MEMORY\_HEAP\_SYSMEM\_CACHED = 2,
 NV ENC MEMORY HEAP SYSMEM UNCACHED = 3 }
• enum NV_ENC_H264_ENTROPY_CODING_MODE {
 NV_ENC_H264_ENTROPY_CODING_MODE_AUTOSELECT = 0x0,
 NV_ENC_H264_ENTROPY_CODING_MODE_CABAC = 0x1,
 NV_ENC_H264_ENTROPY_CODING_MODE_CAVLC = 0x2 }
enum NV_ENC_H264_BDIRECT_MODE {
 NV_ENC_H264_BDIRECT_MODE_AUTOSELECT = 0x0,
 NV_ENC_H264_BDIRECT_MODE_DISABLE = 0x1,
 NV_ENC_H264_BDIRECT_MODE_TEMPORAL = 0x2,
 NV ENC H264 BDIRECT MODE SPATIAL = 0x3 }
• enum NV_ENC_H264_FMO_MODE {
 NV_ENC_H264_FMO_AUTOSELECT = 0x0,
 NV_ENC_H264_FMO_ENABLE = 0x1,
 NV_ENC_H264_FMO_DISABLE = 0x2}
```

```
enum NV_ENC_H264_ADAPTIVE_TRANSFORM_MODE {
 NV_ENC_H264_ADAPTIVE_TRANSFORM_AUTOSELECT = 0x0,
 NV_ENC_H264_ADAPTIVE_TRANSFORM_DISABLE = 0x1,
 NV_ENC_H264_ADAPTIVE_TRANSFORM_ENABLE = 0x2 }
• enum NV ENC STEREO PACKING MODE {
 NV ENC STEREO PACKING MODE NONE = 0x0,
 NV_ENC_STEREO_PACKING_MODE_CHECKERBOARD = 0x1,
 NV_ENC_STEREO_PACKING_MODE_COLINTERLEAVE = 0x2,
 NV_ENC_STEREO_PACKING_MODE_ROWINTERLEAVE = 0x3,
 NV_ENC_STEREO_PACKING_MODE_SIDEBYSIDE = 0x4,
 NV\_ENC\_STEREO\_PACKING\_MODE\_TOPBOTTOM = 0x5,
 NV ENC STEREO PACKING MODE FRAMESEQ = 0x6 }
• enum NV_ENC_INPUT_RESOURCE_TYPE {
 NV_{ENC_{INPUT_{RESOURCE_{TYPE_{DIRECTX}}}} = 0x0,
 NV_ENC_INPUT_RESOURCE_TYPE_CUDADEVICEPTR = 0x1,
 NV_ENC_INPUT_RESOURCE_TYPE_CUDAARRAY = 0x2 }
• enum NV_ENC_DEVICE_TYPE {
 NV_ENC_DEVICE_TYPE_DIRECTX = 0x0,
 NV ENC DEVICE TYPE CUDA = 0x1 }
• enum NV_ENC_CAPS {
 NV_ENC_CAPS_NUM_MAX_BFRAMES,
 NV_ENC_CAPS_SUPPORTED_RATECONTROL_MODES,
 NV_ENC_CAPS_SUPPORT_FIELD_ENCODING,
 NV_ENC_CAPS_SUPPORT_MONOCHROME,
 NV_ENC_CAPS_SUPPORT_FMO,
 NV ENC CAPS SUPPORT OPELMV,
 NV_ENC_CAPS_SUPPORT_BDIRECT_MODE,
 NV_ENC_CAPS_SUPPORT_CABAC,
 NV_ENC_CAPS_SUPPORT_ADAPTIVE_TRANSFORM,
 NV_ENC_CAPS_SUPPORT_RESERVED,
 NV_ENC_CAPS_NUM_MAX_TEMPORAL_LAYERS,
 NV_ENC_CAPS_SUPPORT_HIERARCHICAL_PFRAMES,
 NV_ENC_CAPS_SUPPORT_HIERARCHICAL_BFRAMES,
 NV_ENC_CAPS_LEVEL_MAX,
 NV_ENC_CAPS_LEVEL_MIN,
 NV_ENC_CAPS_SEPARATE_COLOUR_PLANE,
 NV_ENC_CAPS_WIDTH_MAX,
 NV_ENC_CAPS_HEIGHT_MAX,
 NV_ENC_CAPS_SUPPORT_TEMPORAL_SVC,
 NV_ENC_CAPS_SUPPORT_DYN_RES_CHANGE,
 NV_ENC_CAPS_SUPPORT_DYN_BITRATE_CHANGE,
 NV_ENC_CAPS_SUPPORT_DYN_FORCE_CONSTQP,
```

```
NV ENC CAPS SUPPORT DYN RCMODE CHANGE.
 NV_ENC_CAPS_SUPPORT_SUBFRAME_READBACK,
 NV_ENC_CAPS_SUPPORT_CONSTRAINED_ENCODING,
 NV_ENC_CAPS_SUPPORT_INTRA_REFRESH,
 NV_ENC_CAPS_SUPPORT_CUSTOM_VBV_BUF_SIZE,
 NV_ENC_CAPS_SUPPORT_DYNAMIC_SLICE_MODE,
 NV_ENC_CAPS_SUPPORT_REF_PIC_INVALIDATION,
 NV ENC CAPS PREPROC SUPPORT,
 NV_ENC_CAPS_ASYNC_ENCODE_SUPPORT,
 NV_ENC_CAPS_MB_NUM_MAX,
 NV ENC CAPS MB PER SEC MAX,
 NV ENC CAPS SUPPORT YUV444 ENCODE,
 NV_ENC_CAPS_SUPPORT_LOSSLESS_ENCODE,
 NV_ENC_CAPS_SUPPORT_SAO,
 NV_ENC_CAPS_SUPPORT_MEONLY_MODE,
 NV_ENC_CAPS_SUPPORT_LOOKAHEAD,
 NV_ENC_CAPS_SUPPORT_TEMPORAL_AQ,
 NV_ENC_CAPS_SUPPORT_10BIT_ENCODE,
 NV ENC CAPS EXPOSED COUNT }
• enum NV_ENC_HEVC_CUSIZE
```

4.1.1 Define Documentation

4.1.1.1 #define NV ENC CAPS PARAM VER NVENCAPI STRUCT VERSION(1)

NV_ENC_CAPS_PARAM struct version.

4.1.1.2 #define NV_ENC_CONFIG_VER (NVENCAPI_STRUCT_VERSION(6) | (1<<31))

macro for constructing the version field of _NV_ENC_CONFIG

4.1.1.3 #define NV_ENC_CREATE_BITSTREAM_BUFFER_VER NVENCAPI_STRUCT_VERSION(1)

NV_ENC_CREATE_BITSTREAM_BUFFER struct version.

4.1.1.4 #define NV_ENC_CREATE_INPUT_BUFFER_VER NVENCAPI_STRUCT_VERSION(1)

NV_ENC_CREATE_INPUT_BUFFER struct version.

4.1.1.5 #define NV_ENC_CREATE_MV_BUFFER_VER NVENCAPI_STRUCT_VERSION(1)

NV_ENC_CREATE_MV_BUFFER struct version

4.1.1.6 #define NV_ENC_EVENT_PARAMS_VER NVENCAPI_STRUCT_VERSION(1)

Macro for constructing the version field of _NV_ENC_EVENT_PARAMS

4.1.1.7 #define NV_ENC_INITIALIZE_PARAMS_VER (NVENCAPI_STRUCT_VERSION(5) | (1<<31))

macro for constructing the version field of _NV_ENC_INITIALIZE_PARAMS

4.1.1.8 #define NV_ENC_LOCK_BITSTREAM_VER NVENCAPI_STRUCT_VERSION(1)

Macro for constructing the version field of _NV_ENC_LOCK_BITSTREAM

4.1.1.9 #define NV_ENC_LOCK_INPUT_BUFFER_VER NVENCAPI_STRUCT_VERSION(1)

Macro for constructing the version field of _NV_ENC_LOCK_INPUT_BUFFER

4.1.1.10 #define NV_ENC_MAP_INPUT_RESOURCE_VER NVENCAPI_STRUCT_VERSION(4)

Macro for constructing the version field of _NV_ENC_MAP_INPUT_RESOURCE

4.1.1.11 #define NV_ENC_MEONLY_PARAMS_VER NVENCAPI_STRUCT_VERSION(3)

NV_ENC_MEONLY_PARAMS struct version

4.1.1.12 #define NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS_VER NVENCAPI_STRUCT_-VERSION(1)

Macro for constructing the version field of _NV_ENC_OPEN_ENCODE_SESSIONEX_PARAMS

4.1.1.13 #define NV_ENC_PARAMS_RC_2_PASS_FRAMESIZE_CAP NV_ENC_PARAMS_RC_CBR_HQ

Deprecated

4.1.1.14 #define NV_ENC_PARAMS_RC_2_PASS_QUALITY NV_ENC_PARAMS_RC_CBR_-LOWDELAY_HQ

Deprecated

4.1.1.15 #define NV_ENC_PARAMS_RC_2_PASS_VBR NV_ENC_PARAMS_RC_VBR_HQ

Deprecated

4.1.1.16 #define NV_ENC_PARAMS_RC_CBR2 NV_ENC_PARAMS_RC_CBR

Deprecated

4.1.1.17 #define NV_ENC_PARAMS_RC_VBR_MINQP (NV_ENC_PARAMS_RC_MODE)0x4

Deprecated

4.1.1.18 #define NV_ENC_PIC_PARAMS_VER (NVENCAPI_STRUCT_VERSION(4) | (1<<31))

Macro for constructing the version field of _NV_ENC_PIC_PARAMS

4.1.1.19 #define NV_ENC_PRESET_CONFIG_VER (NVENCAPI_STRUCT_VERSION(4) | (1<<31))

macro for constructing the version field of _NV_ENC_PRESET_CONFIG

4.1.1.20 #define NV_ENC_RC_PARAMS_VER NVENCAPI_STRUCT_VERSION(1)

macro for constructing the version field of _NV_ENC_RC_PARAMS

4.1.1.21 #define NV_ENC_RECONFIGURE_PARAMS_VER (NVENCAPI_STRUCT_VERSION(1) \mid (1<<31))

macro for constructing the version field of _NV_ENC_RECONFIGURE_PARAMS

4.1.1.22 #define NV_ENC_REGISTER_RESOURCE_VER NVENCAPI_STRUCT_VERSION(3)

Macro for constructing the version field of _NV_ENC_REGISTER_RESOURCE

4.1.1.23 #define NV_ENC_SEQUENCE_PARAM_PAYLOAD_VER NVENCAPI_STRUCT_VERSION(1)

Macro for constructing the version field of _NV_ENC_SEQUENCE_PARAM_PAYLOAD

4.1.1.24 #define NV_ENC_STAT_VER NVENCAPI_STRUCT_VERSION(1)

Macro for constructing the version field of _NV_ENC_STAT

4.1.2 Enumeration Type Documentation

4.1.2.1 enum NV_ENC_BUFFER_FORMAT

Input buffer formats

Enumerator:

NV_ENC_BUFFER_FORMAT_UNDEFINED Undefined buffer format

NV_ENC_BUFFER_FORMAT_NV12 Semi-Planar YUV [Y plane followed by interleaved UV plane]

NV_ENC_BUFFER_FORMAT_YV12 Planar YUV [Y plane followed by V and U planes]

NV_ENC_BUFFER_FORMAT_IYUV Planar YUV [Y plane followed by U and V planes]

NV_ENC_BUFFER_FORMAT_YUV444 Planar YUV [Y plane followed by U and V planes]

- NV_ENC_BUFFER_FORMAT_YUV420_10BIT 10 bit Semi-Planar YUV [Y plane followed by interleaved UV plane]. Each pixel of size 2 bytes. Most Significant 10 bits contain pixel data.
- NV_ENC_BUFFER_FORMAT_YUV444_10BIT 10 bit Planar YUV444 [Y plane followed by U and V planes]. Each pixel of size 2 bytes. Most Significant 10 bits contain pixel data.
- NV_ENC_BUFFER_FORMAT_ARGB 8 bit Packed A8R8G8B8
- NV_ENC_BUFFER_FORMAT_ARGB10 10 bit Packed A2R10G10B10. Each pixel of size 2 bytes. Most Significant 10 bits contain pixel data.
- NV_ENC_BUFFER_FORMAT_AYUV 8 bit Packed A8Y8U8V8
- NV_ENC_BUFFER_FORMAT_ABGR 8 bit Packed A8B8G8R8
- NV_ENC_BUFFER_FORMAT_ABGR10 10 bit Packed A2B10G10R10. Each pixel of size 2 bytes. Most Significant 10 bits contain pixel data.

4.1.2.2 enum NV_ENC_CAPS

Encoder capabilities enumeration.

Enumerator:

- NV_ENC_CAPS_NUM_MAX_BFRAMES Maximum number of B-Frames supported.
- NV_ENC_CAPS_SUPPORTED_RATECONTROL_MODES Rate control modes supported.

The API return value is a bitmask of the values in NV_ENC_PARAMS_RC_MODE.

- NV_ENC_CAPS_SUPPORT_FIELD_ENCODING Indicates HW support for field mode encoding.
 - 0: Interlaced mode encoding is not supported.
 - 1: Interlaced field mode encoding is supported.
 - 2: Interlaced frame encoding and field mode encoding are both supported.
- NV_ENC_CAPS_SUPPORT_MONOCHROME Indicates HW support for monochrome mode encoding.
 - 0: Monochrome mode not supported.
 - 1: Monochrome mode supported.
- NV_ENC_CAPS_SUPPORT_FMO Indicates HW support for FMO.
 - 0 : FMO not supported.
 - 1: FMO supported.
- NV_ENC_CAPS_SUPPORT_QPELMV Indicates HW capability for Quarter pel motion estimation.
 - 0: QuarterPel Motion Estimation not supported.
 - 1: QuarterPel Motion Estimation supported.
- NV_ENC_CAPS_SUPPORT_BDIRECT_MODE H.264 specific. Indicates HW support for BDirect modes.
 - 0: BDirect mode encoding not supported.
 - 1: BDirect mode encoding supported.
- NV_ENC_CAPS_SUPPORT_CABAC H264 specific. Indicates HW support for CABAC entropy coding mode.
 - 0 : CABAC entropy coding not supported.
 - 1: CABAC entropy coding supported.
- NV_ENC_CAPS_SUPPORT_ADAPTIVE_TRANSFORM Indicates HW support for Adaptive Transform.
 - 0: Adaptive Transform not supported.
 - 1 : Adaptive Transform supported.
- NV_ENC_CAPS_SUPPORT_RESERVED Reserved enum field.
- NV_ENC_CAPS_NUM_MAX_TEMPORAL_LAYERS Indicates HW support for encoding Temporal layers.
 - 0: Encoding Temporal layers not supported.
 - 1: Encoding Temporal layers supported.

NV_ENC_CAPS_SUPPORT_HIERARCHICAL_PFRAMES Indicates HW support for Hierarchical P frames.

- 0: Hierarchical P frames not supported.
- 1 : Hierarchical P frames supported.
- NV_ENC_CAPS_SUPPORT_HIERARCHICAL_BFRAMES Indicates HW support for Hierarchical B frames.
 - 0: Hierarchical B frames not supported.
 - 1: Hierarchical B frames supported.
- NV_ENC_CAPS_LEVEL_MAX Maximum Encoding level supported (See NV_ENC_LEVEL for details).
- NV_ENC_CAPS_LEVEL_MIN Minimum Encoding level supported (See NV_ENC_LEVEL for details).
- NV_ENC_CAPS_SEPARATE_COLOUR_PLANE Indicates HW support for separate colour plane encoding.
 - 0: Separate colour plane encoding not supported.
 - 1 : Separate colour plane encoding supported.
- NV_ENC_CAPS_WIDTH_MAX Maximum output width supported.
- NV_ENC_CAPS_HEIGHT_MAX Maximum output height supported.
- NV_ENC_CAPS_SUPPORT_TEMPORAL_SVC Indicates Temporal Scalability Support.
 - 0 : Temporal SVC encoding not supported.
 - 1: Temporal SVC encoding supported.
- NV_ENC_CAPS_SUPPORT_DYN_RES_CHANGE Indicates Dynamic Encode Resolution Change Support. Support added from NvEncodeAPI version 2.0.
 - 0: Dynamic Encode Resolution Change not supported.
 - 1 : Dynamic Encode Resolution Change supported.
- NV_ENC_CAPS_SUPPORT_DYN_BITRATE_CHANGE Indicates Dynamic Encode Bitrate Change Support. Support added from NvEncodeAPI version 2.0.
 - 0 : Dynamic Encode bitrate change not supported.
 - 1 : Dynamic Encode bitrate change supported.
- NV_ENC_CAPS_SUPPORT_DYN_FORCE_CONSTQP Indicates Forcing Constant QP On The Fly Support. Support added from NvEncodeAPI version 2.0.
 - 0: Forcing constant QP on the fly not supported.
 - 1: Forcing constant QP on the fly supported.
- NV_ENC_CAPS_SUPPORT_DYN_RCMODE_CHANGE Indicates Dynamic rate control mode Change Support.
 - 0: Dynamic rate control mode change not supported.
 - 1 : Dynamic rate control mode change supported.
- NV_ENC_CAPS_SUPPORT_SUBFRAME_READBACK Indicates Subframe readback support for slice-based encoding.
 - 0 : Subframe readback not supported.
 - 1 : Subframe readback supported.
- NV_ENC_CAPS_SUPPORT_CONSTRAINED_ENCODING Indicates Constrained Encoding mode support. Support added from NvEncodeAPI version 2.0.
 - 0 : Constrained encoding mode not supported.
 - 1: Constarined encoding mode supported. If this mode is supported client can enable this during initialisation. Client can then force a picture to be coded as constrained picture where each slice in a constrained picture will have constrained_intra_pred_flag set to 1 and disable_deblocking_filter_idc will be set to 2 and prediction vectors for inter macroblocks in each slice will be restricted to the slice region.

- NV_ENC_CAPS_SUPPORT_INTRA_REFRESH Indicates Intra Refresh Mode Support. Support added from NvEncodeAPI version 2.0.
 - 0: Intra Refresh Mode not supported.
 - 1: Intra Refresh Mode supported.
- NV_ENC_CAPS_SUPPORT_CUSTOM_VBV_BUF_SIZE Indicates Custom VBV Bufer Size support. It can be used for capping frame size. Support added from NvEncodeAPI version 2.0.
 - 0: Custom VBV buffer size specification from client, not supported.
 - 1: Custom VBV buffer size specification from client, supported.
- NV_ENC_CAPS_SUPPORT_DYNAMIC_SLICE_MODE Indicates Dynamic Slice Mode Support. Support added from NvEncodeAPI version 2.0.
 - 0 : Dynamic Slice Mode not supported.
 - 1: Dynamic Slice Mode supported.
- NV_ENC_CAPS_SUPPORT_REF_PIC_INVALIDATION Indicates Reference Picture Invalidation Support. Support added from NvEncodeAPI version 2.0.
 - 0: Reference Picture Invalidation not supported.
 - 1 : Reference Picture Invalidation supported.
- NV_ENC_CAPS_PREPROC_SUPPORT Indicates support for PreProcessing. The API return value is a bit-mask of the values defined in NV_ENC_PREPROC_FLAGS
- NV_ENC_CAPS_ASYNC_ENCODE_SUPPORT Indicates support Async mode.
 - 0 : Async Encode mode not supported.
 - 1: Async Encode mode supported.
- NV_ENC_CAPS_MB_NUM_MAX Maximum MBs per frame supported.
- NV_ENC_CAPS_MB_PER_SEC_MAX Maximum aggregate throughput in MBs per sec.
- NV_ENC_CAPS_SUPPORT_YUV444_ENCODE Indicates HW support for YUV444 mode encoding.
 - 0: YUV444 mode encoding not supported.
 - 1: YUV444 mode encoding supported.
- NV_ENC_CAPS_SUPPORT_LOSSLESS_ENCODE Indicates HW support for lossless encoding.
 - 0: lossless encoding not supported.
 - 1: lossless encoding supported.
- NV_ENC_CAPS_SUPPORT_SAO Indicates HW support for Sample Adaptive Offset.
 - 0: SAO not supported.
 - 1 : SAO encoding supported.
- NV_ENC_CAPS_SUPPORT_MEONLY_MODE Indicates HW support for MEOnly Mode.
 - 0: MEOnly Mode not supported.
 - 1 : MEOnly Mode supported.
- NV_ENC_CAPS_SUPPORT_LOOKAHEAD Indicates HW support for lookahead encoding (enableLookahead=1).
 - 0: Lookahead not supported.
 - 1: Lookahead supported.
- NV_ENC_CAPS_SUPPORT_TEMPORAL_AQ Indicates HW support for temporal AQ encoding (enableTemporalAQ=1).
 - 0: Temporal AQ not supported.
 - 1 : Temporal AQ supported.
- NV_ENC_CAPS_SUPPORT_10BIT_ENCODE Indicates HW support for 10 bit encoding.
 - 0: 10 bit encoding not supported.
 - 1: 10 bit encoding supported.
- NV_ENC_CAPS_EXPOSED_COUNT Reserved Not to be used by clients.

4.1.2.3 enum NV_ENC_DEVICE_TYPE

Encoder Device type

Enumerator:

NV_ENC_DEVICE_TYPE_DIRECTX encode device type is a directx9 device
NV_ENC_DEVICE_TYPE_CUDA encode device type is a cuda device

4.1.2.4 enum NV_ENC_H264_ADAPTIVE_TRANSFORM_MODE

H.264 specific Adaptive Transform modes

Enumerator:

NV_ENC_H264_ADAPTIVE_TRANSFORM_AUTOSELECT Adaptive Transform 8x8 mode is auto selected by the encoder driver

NV_ENC_H264_ADAPTIVE_TRANSFORM_DISABLE Adaptive Transform 8x8 mode disabled
NV_ENC_H264_ADAPTIVE_TRANSFORM_ENABLE Adaptive Transform 8x8 mode should be used

4.1.2.5 enum NV_ENC_H264_BDIRECT_MODE

H.264 specific Bdirect modes

Enumerator:

NV_ENC_H264_BDIRECT_MODE_AUTOSELECT BDirect mode is auto selected by the encoder driver NV_ENC_H264_BDIRECT_MODE_DISABLE Disable BDirect mode
NV_ENC_H264_BDIRECT_MODE_TEMPORAL Temporal BDirect mode
NV_ENC_H264_BDIRECT_MODE_SPATIAL Spatial BDirect mode

4.1.2.6 enum NV ENC H264 ENTROPY CODING MODE

H.264 entropy coding modes.

Enumerator:

NV_ENC_H264_ENTROPY_CODING_MODE_AUTOSELECT Entropy coding mode is auto selected by the encoder driver

NV_ENC_H264_ENTROPY_CODING_MODE_CABAC Entropy coding mode is CABAC NV_ENC_H264_ENTROPY_CODING_MODE_CAVLC Entropy coding mode is CAVLC

4.1.2.7 enum NV_ENC_H264_FMO_MODE

H.264 specific FMO usage

Enumerator:

NV_ENC_H264_FMO_AUTOSELECT FMO usage is auto selected by the encoder driver
NV_ENC_H264_FMO_ENABLE Enable FMO
NV_ENC_H264_FMO_DISABLE Disble FMO

4.1.2.8 enum NV_ENC_HEVC_CUSIZE

HEVC CU SIZE

4.1.2.9 enum NV_ENC_INPUT_RESOURCE_TYPE

Input Resource type

Enumerator:

NV_ENC_INPUT_RESOURCE_TYPE_DIRECTX input resource type is a directx9 surface

NV_ENC_INPUT_RESOURCE_TYPE_CUDADEVICEPTR input resource type is a cuda device pointer surface

NV_ENC_INPUT_RESOURCE_TYPE_CUDAARRAY input resource type is a cuda array surface

4.1.2.10 enum NV_ENC_LEVEL

Encoding levels

4.1.2.11 enum NV_ENC_MEMORY_HEAP

Memory heap to allocate input and output buffers.

Enumerator:

NV_ENC_MEMORY_HEAP_AUTOSELECT Memory heap to be decided by the encoder driver based on the usage

NV_ENC_MEMORY_HEAP_VID Memory heap is in local video memory

NV_ENC_MEMORY_HEAP_SYSMEM_CACHED Memory heap is in cached system memory

NV_ENC_MEMORY_HEAP_SYSMEM_UNCACHED Memory heap is in uncached system memory

4.1.2.12 enum NV_ENC_MV_PRECISION

Motion vector precisions

Enumerator:

NV_ENC_MV_PRECISION_DEFAULT Driver selects QuarterPel motion vector precision by default

NV_ENC_MV_PRECISION_FULL_PEL FullPel motion vector precision

NV_ENC_MV_PRECISION_HALF_PEL HalfPel motion vector precision

NV_ENC_MV_PRECISION_QUARTER_PEL QuarterPel motion vector precision

4.1.2.13 enum NV_ENC_PARAMS_FRAME_FIELD_MODE

Input frame encode modes

Enumerator:

NV_ENC_PARAMS_FRAME_FIELD_MODE_FRAME Frame mode

NV ENC PARAMS FRAME FIELD MODE FIELD Field mode

NV_ENC_PARAMS_FRAME_FIELD_MODE_MBAFF MB adaptive frame/field

4.1.2.14 enum NV ENC PARAMS RC MODE

Rate Control Modes

Enumerator:

```
NV_ENC_PARAMS_RC_CONSTQP Constant QP mode
NV_ENC_PARAMS_RC_VBR Variable bitrate mode
NV_ENC_PARAMS_RC_CBR Constant bitrate mode
NV_ENC_PARAMS_RC_CBR_LOWDELAY_HQ low-delay CBR, high quality
NV_ENC_PARAMS_RC_CBR_HQ CBR, high quality (slower)
NV_ENC_PARAMS_RC_VBR_HQ VBR, high quality (slower)
```

4.1.2.15 enum NV ENC PIC FLAGS

Encode Picture encode flags.

Enumerator:

```
NV_ENC_PIC_FLAG_FORCEINTRA Encode the current picture as an Intra picture
```

NV_ENC_PIC_FLAG_FORCEIDR Encode the current picture as an IDR picture. This flag is only valid when Picture type decision is taken by the Encoder [_NV_ENC_INITIALIZE_PARAMS::enablePTD == 1].

NV_ENC_PIC_FLAG_OUTPUT_SPSPPS Write the sequence and picture header in encoded bitstream of the current picture

NV_ENC_PIC_FLAG_EOS Indicates end of the input stream

4.1.2.16 enum NV_ENC_PIC_STRUCT

Input picture structure

Enumerator:

```
    NV_ENC_PIC_STRUCT_FRAME Progressive frame
    NV_ENC_PIC_STRUCT_FIELD_TOP_BOTTOM Field encoding top field first
    NV ENC PIC STRUCT FIELD BOTTOM TOP Field encoding bottom field first
```

4.1.2.17 enum NV_ENC_PIC_TYPE

Input picture type

Enumerator:

```
NV_ENC_PIC_TYPE_P Forward predicted

NV_ENC_PIC_TYPE_B Bi-directionally predicted picture

NV_ENC_PIC_TYPE_I Intra predicted picture

NV_ENC_PIC_TYPE_IDR IDR picture

NV_ENC_PIC_TYPE_BI Bi-directionally predicted with only Intra MBs

NV_ENC_PIC_TYPE_SKIPPED Picture is skipped

NV_ENC_PIC_TYPE_INTRA_REFRESH First picture in intra refresh cycle

NV_ENC_PIC_TYPE_UNKNOWN Picture type unknown
```

4.1.2.18 enum NV ENC STEREO PACKING MODE

Stereo frame packing modes.

Enumerator:

- NV_ENC_STEREO_PACKING_MODE_NONE No Stereo packing required
- NV_ENC_STEREO_PACKING_MODE_CHECKERBOARD Checkerboard mode for packing stereo frames
- NV_ENC_STEREO_PACKING_MODE_COLINTERLEAVE Column Interleave mode for packing stereo frames
- NV_ENC_STEREO_PACKING_MODE_ROWINTERLEAVE Row Interleave mode for packing stereo frames
- NV_ENC_STEREO_PACKING_MODE_SIDEBYSIDE Side-by-side mode for packing stereo frames
- NV_ENC_STEREO_PACKING_MODE_TOPBOTTOM Top-Bottom mode for packing stereo frames
- NV_ENC_STEREO_PACKING_MODE_FRAMESEQ Frame Sequential mode for packing stereo frames

4.1.2.19 enum NVENCSTATUS

Error Codes

Enumerator:

- NV_ENC_SUCCESS This indicates that API call returned with no errors.
- NV_ENC_ERR_NO_ENCODE_DEVICE This indicates that no encode capable devices were detected.
- NV_ENC_ERR_UNSUPPORTED_DEVICE This indicates that devices pass by the client is not supported.
- NV_ENC_ERR_INVALID_ENCODERDEVICE This indicates that the encoder device supplied by the client is not valid.
- NV_ENC_ERR_INVALID_DEVICE This indicates that device passed to the API call is invalid.
- NV_ENC_ERR_DEVICE_NOT_EXIST This indicates that device passed to the API call is no longer available and needs to be reinitialized. The clients need to destroy the current encoder session by freeing the allocated input output buffers and destroying the device and create a new encoding session.
- NV_ENC_ERR_INVALID_PTR This indicates that one or more of the pointers passed to the API call is invalid.
- NV_ENC_ERR_INVALID_EVENT This indicates that completion event passed in NvEncEncodePicture() call is invalid.
- NV_ENC_ERR_INVALID_PARAM This indicates that one or more of the parameter passed to the API call is invalid.
- NV_ENC_ERR_INVALID_CALL This indicates that an API call was made in wrong sequence/order.
- NV_ENC_ERR_OUT_OF_MEMORY This indicates that the API call failed because it was unable to allocate enough memory to perform the requested operation.
- NV_ENC_ERR_ENCODER_NOT_INITIALIZED This indicates that the encoder has not been initialized with NvEncInitializeEncoder() or that initialization has failed. The client cannot allocate input or output buffers or do any encoding related operation before successfully initializing the encoder.
- NV_ENC_ERR_UNSUPPORTED_PARAM This indicates that an unsupported parameter was passed by the client.
- NV_ENC_ERR_LOCK_BUSY This indicates that the NvEncLockBitstream() failed to lock the output buffer. This happens when the client makes a non blocking lock call to access the output bitstream by passing NV_ENC_LOCK_BITSTREAM::doNotWait flag. This is not a fatal error and client should retry the same operation after few milliseconds.

NV_ENC_ERR_NOT_ENOUGH_BUFFER This indicates that the size of the user buffer passed by the client is insufficient for the requested operation.

- NV_ENC_ERR_INVALID_VERSION This indicates that an invalid struct version was used by the client.
- NV_ENC_ERR_MAP_FAILED This indicates that NvEncMapInputResource() API failed to map the client provided input resource.
- NV_ENC_ERR_NEED_MORE_INPUT This indicates encode driver requires more input buffers to produce an output bitstream. If this error is returned from NvEncEncodePicture() API, this is not a fatal error. If the client is encoding with B frames then, NvEncEncodePicture() API might be buffering the input frame for re-ordering.
 - A client operating in synchronous mode cannot call NvEncLockBitstream() API on the output bitstream buffer if NvEncEncodePicture() returned the NV_ENC_ERR_NEED_MORE_INPUT error code. The client must continue providing input frames until encode driver returns NV_ENC_SUCCESS. After receiving NV_ENC_SUCCESS status the client can call NvEncLockBitstream() API on the output buffers in the same order in which it has called NvEncEncodePicture().
- **NV_ENC_ERR_ENCODER_BUSY** This indicates that the HW encoder is busy encoding and is unable to encode the input. The client should call **NvEncEncodePicture()** again after few milliseconds.
- NV_ENC_ERR_EVENT_NOT_REGISTERD This indicates that the completion event passed in NvEncEncodePicture() API has not been registered with encoder driver using NvEncRegisterAsyncEvent().
- NV_ENC_ERR_GENERIC This indicates that an unknown internal error has occurred.
- NV_ENC_ERR_INCOMPATIBLE_CLIENT_KEY This indicates that the client is attempting to use a feature that is not available for the license type for the current system.
- NV_ENC_ERR_UNIMPLEMENTED This indicates that the client is attempting to use a feature that is not implemented for the current version.
- NV_ENC_ERR_RESOURCE_REGISTER_FAILED This indicates that the NvEncRegisterResource API failed to register the resource.
- **NV_ENC_ERR_RESOURCE_NOT_REGISTERED** This indicates that the client is attempting to unregister a resource that has not been successfully registered.
- **NV_ENC_ERR_RESOURCE_NOT_MAPPED** This indicates that the client is attempting to unmap a resource that has not been successfully mapped.

4.2 NvEncodeAPI Functions

Functions

NVENCSTATUS NVENCAPI NvEncOpenEncodeSession (void *device, uint32_t deviceType, void **encoder)

Opens an encoding session.

- NVENCSTATUS NVENCAPI NvEncGetEncodeGUIDCount (void *encoder, uint32_t *encodeGUIDCount)
 Retrieves the number of supported encode GUIDs.
- NVENCSTATUS NVENCAPI NvEncGetEncodeGUIDs (void *encoder, GUID *GUIDs, uint32_t guidArray-Size, uint32_t *GUIDCount)

Retrieves an array of supported encoder codec GUIDs.

NVENCSTATUS NVENCAPI NvEncGetEncodeProfileGUIDCount (void *encoder, GUID encodeGUID, uint32_t *encodeProfileGUIDCount)

Retrieves the number of supported profile GUIDs.

• NVENCSTATUS NVENCAPI NvEncGetEncodeProfileGUIDs (void *encoder, GUID encodeGUID, GUID *profileGUIDs, uint32_t guidArraySize, uint32_t *GUIDCount)

Retrieves an array of supported encode profile GUIDs.

NVENCSTATUS NVENCAPI NvEncGetInputFormatCount (void *encoder, GUID encodeGUID, uint32_t *inputFmtCount)

Retrieve the number of supported Input formats.

• NVENCSTATUS NVENCAPI NvEncGetInputFormats (void *encoder, GUID encodeGUID, NV_ENC_-BUFFER_FORMAT *inputFmts, uint32_t inputFmtArraySize, uint32_t *inputFmtCount)

Retrieves an array of supported Input formats.

• NVENCSTATUS NVENCAPI NvEncGetEncodeCaps (void *encoder, GUID encodeGUID, NV_ENC_CAPS_-PARAM *capsParam, int *capsVal)

Retrieves the capability value for a specified encoder attribute.

NVENCSTATUS NVENCAPI NvEncGetEncodePresetCount (void *encoder, GUID encodeGUID, uint32_t *encodePresetGUIDCount)

Retrieves the number of supported preset GUIDs.

• NVENCSTATUS NVENCAPI NvEncGetEncodePresetGUIDs (void *encoder, GUID encodeGUID, GUID *presetGUIDs, uint32_t guidArraySize, uint32_t *encodePresetGUIDCount)

Receives an array of supported encoder preset GUIDs.

 NVENCSTATUS NVENCAPI NvEncGetEncodePresetConfig (void *encoder, GUID encodeGUID, GUID presetGUID, NV_ENC_PRESET_CONFIG *presetConfig)

Returns a preset config structure supported for given preset GUID.

NVENCSTATUS NVENCAPI NvEncInitializeEncoder (void *encoder, NV_ENC_INITIALIZE_PARAMS *createEncodeParams)

Initialize the encoder.

NVENCSTATUS NVENCAPI NvEncCreateInputBuffer (void *encoder, NV_ENC_CREATE_INPUT_-BUFFER *createInputBufferParams)

Allocates Input buffer.

NVENCSTATUS NVENCAPI NvEncDestroyInputBuffer (void *encoder, NV_ENC_INPUT_PTR input-Buffer)

Release an input buffers.

• NVENCSTATUS NVENCAPI NvEncCreateBitstreamBuffer (void *encoder, NV_ENC_CREATE_-BITSTREAM_BUFFER *createBitstreamBufferParams)

Allocates an output bitstream buffer.

• NVENCSTATUS NVENCAPI NvEncDestroyBitstreamBuffer (void *encoder, NV_ENC_OUTPUT_PTR bitstreamBuffer)

Release a bitstream buffer.

• NVENCSTATUS NVENCAPI NvEncEncodePicture (void *encoder, NV_ENC_PIC_PARAMS *encodePicParams)

Submit an input picture for encoding.

NVENCSTATUS NVENCAPI NvEncLockBitstream (void *encoder, NV_ENC_LOCK_BITSTREAM *lockBitstreamBufferParams)

Lock output bitstream buffer.

 NVENCSTATUS NVENCAPI NvEncUnlockBitstream (void *encoder, NV_ENC_OUTPUT_PTR bitstream-Buffer)

Unlock the output bitstream buffer.

• NVENCSTATUS NVENCAPI NvEncLockInputBuffer (void *encoder, NV_ENC_LOCK_INPUT_BUFFER *lockInputBufferParams)

Locks an input buffer.

• NVENCSTATUS NVENCAPI NvEncUnlockInputBuffer (void *encoder, NV_ENC_INPUT_PTR input-Buffer)

Unlocks the input buffer.

- NVENCSTATUS NVENCAPI NvEncGetEncodeStats (void *encoder, NV_ENC_STAT *encodeStats)
 Get encoding statistics.
- NVENCSTATUS NVENCAPI NvEncGetSequenceParams (void *encoder, NV_ENC_SEQUENCE_PARAM_-PAYLOAD *sequenceParamPayload)

Get encoded sequence and picture header.

• NVENCSTATUS NVENCAPI NvEncRegisterAsyncEvent (void *encoder, NV_ENC_EVENT_PARAMS *eventParams)

Register event for notification to encoding completion.

• NVENCSTATUS NVENCAPI NvEncUnregisterAsyncEvent (void *encoder, NV_ENC_EVENT_PARAMS *eventParams)

Unregister completion event.

• NVENCSTATUS NVENCAPI NvEncMapInputResource (void *encoder, NV_ENC_MAP_INPUT_-RESOURCE *mapInputResParams)

Map an externally created input resource pointer for encoding.

NVENCSTATUS NVENCAPI NvEncUnmapInputResource (void *encoder, NV_ENC_INPUT_PTR mapped-InputBuffer)

UnMaps a NV_ENC_INPUT_PTR which was mapped for encoding.

• NVENCSTATUS NVENCAPI NvEncDestroyEncoder (void *encoder)

Destroy Encoding Session.

NVENCSTATUS NVENCAPI NvEncInvalidateRefFrames (void *encoder, uint64_t invalidRefFrameTimeS-tamp)

Invalidate reference frames.

 NVENCSTATUS NVENCAPI NvEncOpenEncodeSessionEx (NV_ENC_OPEN_ENCODE_SESSION_EX_-PARAMS *openSessionExParams, void **encoder)

Opens an encoding session.

NVENCSTATUS NVENCAPI NvEncRegisterResource (void *encoder, NV_ENC_REGISTER_RESOURCE *registerResParams)

Registers a resource with the Nvidia Video Encoder Interface.

NVENCSTATUS NVENCAPI NvEncUnregisterResource (void *encoder, NV_ENC_REGISTERED_PTR registeredResource)

Unregisters a resource previously registered with the Nvidia Video Encoder Interface.

• NVENCSTATUS NVENCAPI NvEncReconfigureEncoder (void *encoder, NV_ENC_RECONFIGURE_-PARAMS *reInitEncodeParams)

Reconfigure an existing encoding session.

• NVENCSTATUS NVENCAPI NvEncCreateMVBuffer (void *encoder, NV_ENC_CREATE_MV_BUFFER *createMVBufferParams)

Allocates output MV buffer for ME only mode.

NVENCSTATUS NVENCAPI NvEncDestroyMVBuffer (void *encoder, NV_ENC_OUTPUT_PTR mvBuffer)

Release an output MV buffer for ME only mode.

 NVENCSTATUS NVENCAPI NvEncRunMotionEstimationOnly (void *encoder, NV_ENC_MEONLY_-PARAMS *meOnlyParams)

Submit an input picture and reference frame for motion estimation in ME only mode.

NVENCSTATUS NVENCAPI NvEncodeAPIGetMaxSupportedVersion (uint32_t *version)

Get the largest NvEncodeAPI version supported by the driver.

NVENCSTATUS NVENCAPI NvEncodeAPICreateInstance (NV_ENCODE_API_FUNCTION_LIST *functionList)

4.2.1 Function Documentation

4.2.1.1 NVENCSTATUS NVENCAPI NvEncCreateBitstreamBuffer (void * encoder, NV_ENC_CREATE_BITSTREAM_BUFFER * createBitstreamBufferParams)

This function is used to allocate an output bitstream buffer and returns a NV_ENC_OUTPUT_PTR to bitstream buffer to the client in the NV_ENC_CREATE_BITSTREAM_BUFFER::bitstreamBuffer field. The client can only call this function after the encoder session has been initialized using NvEncInitializeEncoder() API. The minimum number of output buffers allocated by the client must be at least 4 more than the number of B B frames being used for encoding. The client can only access the output bitsteam data by locking the bitstreamBuffer using the NvEncLockBitstream() function.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ⇔ createBitstreamBufferParams Pointer NV_ENC_CREATE_BITSTREAM_BUFFER for details.

Returns:

```
NV_ENC_SUCCESS

NV_ENC_ERR_INVALID_PTR

NV_ENC_ERR_INVALID_ENCODERDEVICE

NV_ENC_ERR_DEVICE_NOT_EXIST

NV_ENC_ERR_UNSUPPORTED_PARAM

NV_ENC_ERR_OUT_OF_MEMORY

NV_ENC_ERR_INVALID_PARAM

NV_ENC_ERR_INVALID_VERSION

NV_ENC_ERR_ENCODER_NOT_INITIALIZED

NV_ENC_ERR_GENERIC
```

4.2.1.2 NVENCSTATUS NVENCAPI NvEncCreateInputBuffer (void * encoder, NV_ENC_CREATE_INPUT_BUFFER * createInputBufferParams)

This function is used to allocate an input buffer. The client must enumerate the input buffer format before allocating the input buffer resources. The NV_ENC_INPUT_PTR returned by the NvEncodeAPI interface in the NV_ENC_CREATE_INPUT_BUFFER::inputBuffer field can be directly used in NvEncEncodePicture() API. The number of input buffers to be allocated by the client must be at least 4 more than the number of B frames being used for encoding.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← createInputBufferParams Pointer to the NV_ENC_CREATE_INPUT_BUFFER structure.

Returns:

```
NV_ENC_SUCCESS

NV_ENC_ERR_INVALID_PTR

NV_ENC_ERR_INVALID_ENCODERDEVICE

NV_ENC_ERR_DEVICE_NOT_EXIST

NV_ENC_ERR_UNSUPPORTED_PARAM

NV_ENC_ERR_OUT_OF_MEMORY

NV_ENC_ERR_INVALID_PARAM

NV_ENC_ERR_INVALID_VERSION

NV_ENC_ERR_GENERIC
```

4.2.1.3 NVENCSTATUS NVENCAPI NvEncCreateMVBuffer (void * encoder, NV_ENC_CREATE_MV_BUFFER * createMVBufferParams)

This function is used to allocate an output MV buffer. The size of the mvBuffer is dependent on the frame height and width of the last NvEncCreateInputBuffer() call. The NV_ENC_OUTPUT_PTR returned by the NvEncodeAPI interface in the NV_ENC_CREATE_MV_BUFFER::mvBuffer field should be used in NvEncRunMotionEstimationOnly() API. Client must lock NV_ENC_CREATE_MV_BUFFER::mvBuffer using NvEncLockBitstream() API to get the motion vector data.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← createMVBufferParams Pointer to the NV_ENC_CREATE_MV_BUFFER structure.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_INVALID_VERSION
NV_ENC_ERR_GENERIC
```

4.2.1.4 NVENCSTATUS NVENCAPI NvEncDestroyBitstreamBuffer (void * encoder, NV ENC OUTPUT PTR bitstreamBuffer)

This function is used to release the output bitstream buffer allocated using the NvEncCreateBitstreamBuffer() function. The client must release the output bitstreamBuffer using this function before destroying the encoder session.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← *bitstreamBuffer* Pointer to the bitstream buffer being released.

Returns:

```
NV_ENC_SUCCESS

NV_ENC_ERR_INVALID_PTR

NV_ENC_ERR_INVALID_ENCODERDEVICE

NV_ENC_ERR_DEVICE_NOT_EXIST

NV_ENC_ERR_UNSUPPORTED_PARAM

NV_ENC_ERR_OUT_OF_MEMORY

NV_ENC_ERR_INVALID_PARAM

NV_ENC_ERR_INVALID_VERSION

NV_ENC_ERR_ENCODER_NOT_INITIALIZED

NV_ENC_ERR_GENERIC
```

4.2.1.5 NVENCSTATUS NVENCAPI NvEncDestroyEncoder (void * encoder)

Destroys the encoder session previously created using NvEncOpenEncodeSession() function. The client must flush the encoder before freeing any resources. In order to flush the encoder the client must pass a NULL encode picture

packet and either wait for the NvEncEncodePicture() function to return in synchronous mode or wait for the flush event to be signaled by the encoder in asynchronous mode. The client must free all the input and output resources created using the NvEncodeAPI interface before destroying the encoder. If the client is operating in asynchronous mode, it must also unregister the completion events previously registered.

Parameters:

← *encoder* Pointer to the NvEncodeAPI interface.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_GENERIC
```

4.2.1.6 NVENCSTATUS NVENCAPI NvEncDestroyInputBuffer (void * encoder, NV_ENC_INPUT_PTR inputBuffer)

This function is used to free an input buffer. If the client has allocated any input buffer using NvEncCreateInputBuffer() API, it must free those input buffers by calling this function. The client must release the input buffers before destroying the encoder using NvEncDestroyEncoder() API.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← *inputBuffer* Pointer to the input buffer to be released.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_INVALID_VERSION
NV_ENC_ERR_GENERIC
```

4.2.1.7 NVENCSTATUS NVENCAPI NvEncDestroyMVBuffer (void * encoder, NV_ENC_OUTPUT_PTR mvBuffer)

This function is used to release the output MV buffer allocated using the NvEncCreateMVBuffer() function. The client must release the output mvBuffer using this function before destroying the encoder session.

Parameters:

← *encoder* Pointer to the NvEncodeAPI interface.

← mvBuffer Pointer to the mvBuffer being released.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_INVALID_VERSION
NV_ENC_ERR_ENCODER_NOT_INITIALIZED
NV_ENC_ERR_GENERIC
```

4.2.1.8 NVENCSTATUS NVENCAPI NvEncEncodePicture (void * encoder, NV_ENC_PIC_PARAMS * encodePicParams)

This function is used to submit an input picture buffer for encoding. The encoding parameters are passed using *encodePicParams which is a pointer to the _NV_ENC_PIC_PARAMS structure.

If the client has set NV_ENC_INITIALIZE_PARAMS::enablePTD to 0, then it must send a valid value for the following fields.

- NV_ENC_PIC_PARAMS::pictureType
- NV_ENC_PIC_PARAMS_H264::displayPOCSyntax (H264 only)
- NV_ENC_PIC_PARAMS_H264::frameNumSyntax(H264 only)
- NV_ENC_PIC_PARAMS_H264::refPicFlag(H264 only)

Asynchronous Encoding

If the client has enabled asynchronous mode of encoding by setting NV_ENC_INITIALIZE_PARAMS::enableEncodeAsync to 1 in the NvEncInitializeEncoder() API ,then the client must send a valid NV_ENC_PIC_PARAMS::completionEvent. Incase of asynchronous mode of operation, client can queue the NvEncEncodePicture() API commands from the main thread and then queue output buffers to be processed to a secondary worker thread. Before the locking the output buffers in the secondary thread , the client must wait on NV_ENC_PIC_PARAMS::completionEvent it has queued in NvEncEncodePicture() API call. The client must always process completion event and the output buffer in the same order in which they have been submitted for encoding. The NvEncodeAPI interface is responsible for any re-ordering required for B frames and will always ensure that encoded bitstream data is written in the same order in which output buffer is submitted.

```
For example:
1st EncodePicture parameters - (I1, O1, E1)
2nd EncodePicture parameters - (I2, O2, E2)
3rd EncodePicture parameters - (I3, O3, E3)
b) NvEncodeAPI SW will receive the following encode Commands from the client.
The left side shows input from client in the form (Input buffer, Output Buffer,
Output Event). The right hand side shows a possible picture type decision take by
the NvEncodeAPI interface.
               ---P1 Frame
(I1, O1, E1)
(I2, O2, E2)
                ---B2 Frame
               ---P3 Frame
(I3, O3, E3)
c) NvEncodeAPI interface will make a copy of the input buffers to its internal
 buffers for re-ordering. These copies are done as part of nvEncEncodePicture
 function call from the client and NvEncodeAPI interface is responsible for
 synchronization of copy operation with the actual encoding operation.
 T1 --> NvT1
 I2 --> NvI2
 I3 --> NvI3
d) After returning from :: NvEncEncodePicture() call , the client must queue the output
 bitstream processing work to the secondary thread. The output bitstream processing
 for asynchronous mode consist of first waiting on completion event(E1, E2..)
 and then locking the output bitstream buffer(O1, O2..) for reading the encoded
 data. The work queued to the secondary thread by the client is in the following order
 (I1, O1, E1)
 (I2, O2, E2)
 (I3, O3, E3)
 Note they are in the same order in which client calls :: NvEncEncodePicture() API
 in \p step a).
e) NvEncodeAPI interface will do the re-ordering such that Encoder HW will receive
the following encode commands:
(NvI1, O1, E1) ---P1 Frame
                ---P3 Frame
(NvI3, O2, E2)
(NvI2, O3, E3)
               ---B2 frame
f) After the encoding operations are completed, the events will be signalled
by NvEncodeAPI interface in the following order :
(01, E1) ---P1 Frame ,output bitstream copied to 01 and event E1 signalled.
(O2, E2) ---P3 Frame ,output bitstream copied to O2 and event E2 signalled.
(O3, E3) ---B2 Frame ,output bitstream copied to O3 and event E3 signalled.
g) The client must lock the bitstream data using :: NvEncLockBitstream() API in
 the order 01,02,03 to read the encoded data, after waiting for the events
 to be signalled in the same order i.e E1, E2 and E3. The output processing is
 done in the secondary thread in the following order:
 Waits on El, copies encoded bitstream from Ol
 Waits on E2, copies encoded bitstream from O2
 Waits on E3, copies encoded bitstream from O3
-Note the client will receive the events signalling and output buffer in the
 same order in which they have submitted for encoding.
-Note the LockBitstream will have picture type field which will notify the
output picture type to the clients.
-Note the input, output buffer and the output completion event are free to be
 reused once NvEncodeAPI interfaced has signalled the event and the client has
 copied the data from the output buffer.
```

Synchronous Encoding

The client can enable synchronous mode of encoding by setting NV_ENC_INITIALIZE_-PARAMS::enableEncodeAsync to 0 in NvEncInitializeEncoder() API. The NvEncodeAPI interface may return NV_ENC_ERR_NEED_MORE_INPUT error code for some NvEncEncodePicture() API calls when NV_ENC_INITIALIZE_PARAMS::enablePTD is set to 1, but the client must not treat it as a fatal error. The NvEncodeAPI interface might not be able to submit an input picture buffer for encoding immediately due to

re-ordering for B frames. The NvEncodeAPI interface cannot submit the input picture which is decided to be encoded as B frame as it waits for backward reference from temporally subsequent frames. This input picture is buffered internally and waits for more input picture to arrive. The client must not call NvEncLockBitstream() API on the output buffers whose NvEncEncodePicture() API returns NV_ENC_ERR_NEED_MORE_INPUT. The client must wait for the NvEncodeAPI interface to return NV_ENC_SUCCESS before locking the output bitstreams to read the encoded bitstream data. The following example explains the scenario with synchronous encoding with 2 B frames.

```
The below example shows how synchronous encoding works in case of 1 B frames
Suppose the client allocated 4 input buffers (I1, I2..), 4 output buffers (O1, O2..)
and 4 completion events(E1, E2, \dots). The NvEncodeAPI interface will need to
keep a copy of the input buffers for re-ordering and it allocates following
internal buffers (NvI1, NvI2...). These internal buffers are managed by NvEncodeAPI
and the client is not responsible for the allocating or freeing the memory of
the internal buffers.
The client calls :: NvEncEncodePicture() API with input buffer I1 and output buffer O1.
The NvEncodeAPI decides to encode I1 as P frame and submits it to encoder
HW and returns :: NV_ENC_SUCCESS.
The client can now read the encoded data by locking the output O1 by calling
NvEncLockBitstream API.
The client calls :: NvEncEncodePicture() API with input buffer I2 and output buffer O2.
The NvEncodeAPI decides to encode I2 as B frame and buffers I2 by copying it
to internal buffer and returns :: NV_ENC_ERR_NEED_MORE_INPUT.
The error is not fatal and it notifies client that it cannot read the encoded
data by locking the output O2 by calling ::NvEncLockBitstream() API without submitting
more work to the NvEncodeAPI interface.
The client calls :: NvEncEncodePicture() with input buffer I3 and output buffer O3.
The NvEncodeAPI decides to encode I3 as P frame and it first submits I3 for
encoding which will be used as backward reference frame for I2.
The NvEncodeAPI then submits I2 for encoding and returns :: NV_ENC_SUCESS. Both
the submission are part of the same :: NvEncEncodePicture() function call.
The client can now read the encoded data for both the frames by locking the output
02 followed by 03 ,by calling :: NvEncLockBitstream() API.
The client must always lock the output in the same order in which it has submitted
to receive the encoded bitstream in correct encoding order.
```

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← encodePicParams Pointer to the _NV_ENC_PIC_PARAMS structure.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_INVALID_VERSION
NV_ENC_ERR_ENCODER_BUSY
NV_ENC_ERR_NEED_MORE_INPUT
NV_ENC_ERR_ENCODER_NOT_INITIALIZED
NV_ENC_ERR_GENERIC
```

4.2.1.9 NVENCSTATUS NVENCAPI NvEncGetEncodeCaps (void * encoder, GUID encodeGUID, NV_ENC_CAPS_PARAM * capsParam, int * capsVal)

The function returns the capability value for a given encoder attribute. The client must validate the encodeGUID using NvEncGetEncodeGUIDs() API before calling this function. The encoder attribute being queried are enumerated in NV ENC CAPS PARAM enum.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← *encodeGUID* Encode GUID, corresponding to which the capability attribute is to be retrieved.
- ← capsParam Used to specify attribute being queried. Refer NV_ENC_CAPS_PARAM for more details.
- \rightarrow caps Val The value corresponding to the capability attribute being queried.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_GENERIC
```

4.2.1.10 NVENCSTATUS NVENCAPI NvEncGetEncodeGUIDCount (void * encoder, uint32_t * encodeGUIDCount)

The function returns the number of codec guids supported by the NvEncodeAPI interface.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- → *encodeGUIDCount* Number of supported encode GUIDs.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_GENERIC
```

4.2.1.11 NVENCSTATUS NVENCAPI NvEncGetEncodeGUIDs (void * encoder, GUID * GUIDs, uint32_t guidArraySize, uint32_t * GUIDCount)

The function returns an array of codec guids supported by the NvEncodeAPI interface. The client must allocate an array where the NvEncodeAPI interface can fill the supported guids and pass the pointer in *GUIDs parameter. The size of the array can be determined by using NvEncGetEncodeGUIDCount() API. The Nvidia Encoding interface returns the number of codec guids it has actually filled in the guid array in the GUIDCount parameter.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← guidArraySize Number of GUIDs to retrieved. Should be set to the number retrieved using NvEncGetEncodeGUIDCount.
- \rightarrow **GUIDs** Array of supported Encode GUIDs.
- → *GUIDCount* Number of supported Encode GUIDs.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_GENERIC
```

4.2.1.12 NVENCSTATUS NVENCAPI NvEncGetEncodePresetConfig (void * encoder, GUID encodeGUID, GUID presetGUID, NV_ENC_PRESET_CONFIG * presetConfig)

The function returns a preset config structure for a given preset guid. Before using this function the client must enumerate the preset guids available for a given codec. The preset config structure can be modified by the client depending upon its use case and can be then used to initialize the encoder using NvEncInitializeEncoder() API. The client can use this function only if it wants to modify the NvEncodeAPI preset configuration, otherwise it can directly use the preset guid.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← *encodeGUID* Encode GUID, corresponding to which the list of supported presets is to be retrieved.
- ← presetGUID Preset GUID, corresponding to which the Encoding configurations is to be retrieved.
- → presetConfig The requested Preset Encoder Attribute set. Refer _NV_ENC_CONFIG for more details.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_INVALID_VERSION
NV_ENC_ERR_GENERIC
```

4.2.1.13 NVENCSTATUS NVENCAPI NvEncGetEncodePresetCount (void * encoder, GUID encodeGUID, uint32_t * encodePresetGUIDCount)

The function returns the number of preset GUIDs available for a given codec. The client must validate the codec guid using NvEncGetEncodeGUIDs() API before calling this function.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← *encodeGUID* Encode GUID, corresponding to which the number of supported presets is to be retrieved.
- → *encodePresetGUIDCount* Receives the number of supported preset GUIDs.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_GENERIC
```

4.2.1.14 NVENCSTATUS NVENCAPI NvEncGetEncodePresetGUIDs (void * encoder, GUID encodeGUID, GUID * presetGUIDs, uint32_t guidArraySize, uint32_t * encodePresetGUIDCount)

The function returns an array of encode preset guids available for a given codec. The client can directly use one of the preset guids based upon the use case or target device. The preset guid chosen can be directly used in NV_ENC_INITIALIZE_PARAMS::presetGUID parameter to NvEncEncodePicture() API. Alternately client can also use the preset guid to retrieve the encoding config parameters being used by NvEncodeAPI interface for that given preset, using NvEncGetEncodePresetConfig() API. It can then modify preset config parameters as per its use case and send it to NvEncodeAPI interface as part of Nv_ENC_INITIALIZE_PARAMS::encodeConfig parameter for NvEncInitializeEncoder() API.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← *encodeGUID* Encode GUID, corresponding to which the list of supported presets is to be retrieved.
- ← guidArraySize Size of array of preset guids passed in preset GUIDs
- → presetGUIDs Array of supported Encode preset GUIDs from the NvEncodeAPI interface to client.
- → encodePresetGUIDCount Receives the number of preset GUIDs returned by the NvEncodeAPI interface.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_GENERIC
```

4.2.1.15 NVENCSTATUS NVENCAPI NvEncGetEncodeProfileGUIDCount (void * encoder, GUID encodeGUID, uint32_t * encodeProfileGUIDCount)

The function returns the number of profile GUIDs supported for a given codec. The client must first enumerate the codec guids supported by the NvEncodeAPI interface. After determining the codec guid, it can query the NvEncodeAPI interface to determine the number of profile guids supported for a particular codec guid.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← *encodeGUID* The codec guid for which the profile guids are being enumerated.
- → encodeProfileGUIDCount Number of encode profiles supported for the given encodeGUID.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_GENERIC
```

4.2.1.16 NVENCSTATUS NVENCAPI NvEncGetEncodeProfileGUIDs (void * encoder, GUID encodeGUID, GUID * profileGUIDs, uint32 t guidArraySize, uint32 t * GUIDCount)

The function returns an array of supported profile guids for a particular codec guid. The client must allocate an array where the NvEncodeAPI interface can populate the profile guids. The client can determine the array size using NvEncGetEncodeProfileGUIDCount() API. The client must also validiate that the NvEncodeAPI interface supports the GUID the client wants to pass as encodeGUID parameter.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← *encodeGUID* The encode guid whose profile guids are being enumerated.
- ← guidArraySize Number of GUIDs to be retrieved. Should be set to the number retrieved using NvEncGetEncodeProfileGUIDCount.
- → *profileGUIDs* Array of supported Encode Profile GUIDs
- → *GUIDCount* Number of valid encode profile GUIDs in profileGUIDs array.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_GENERIC
```

4.2.1.17 NVENCSTATUS NVENCAPI NvEncGetEncodeStats (void * encoder, NV_ENC_STAT * encodeStats)

This function is used to retrieve the encoding statistics. This API is not supported when encode device type is CUDA.

Parameters:

← *encoder* Pointer to the NvEncodeAPI interface.

⇔ encodeStats Pointer to the NV ENC STAT structure.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_ENCODER_NOT_INITIALIZED
NV_ENC_ERR_GENERIC
```

4.2.1.18 NVENCSTATUS NVENCAPI NvEncGetInputFormatCount (void * encoder, GUID encodeGUID, uint32 t * inputFmtCount)

The function returns the number of supported input formats. The client must query the NvEncodeAPI interface to determine the supported input formats before creating the input surfaces.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← *encodeGUID* Encode GUID, corresponding to which the number of supported input formats is to be retrieved.
- → *inputFmtCount* Number of input formats supported for specified Encode GUID.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_GENERIC
```

4.2.1.19 NVENCSTATUS NVENCAPI NvEncGetInputFormats (void * encoder, GUID encodeGUID, NV_ENC_BUFFER_FORMAT * inputFmts, uint32_t inputFmtArraySize, uint32_t * inputFmtCount)

Returns an array of supported input formats The client must use the input format to create input surface using NvEnc-CreateInputBuffer() API.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← encodeGUID Encode GUID, corresponding to which the number of supported input formats is to be retrieved.
- ← *inputFmtArraySize* Size input format count array passed in inputFmts.
- \rightarrow *inputFmts* Array of input formats supported for this Encode GUID.

→ *inputFmtCount* The number of valid input format types returned by the NvEncodeAPI interface in inputFmts array.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_GENERIC
```

4.2.1.20 NVENCSTATUS NVENCAPI NvEncGetSequenceParams (void * encoder, NV ENC SEQUENCE PARAM PAYLOAD * sequenceParamPayload)

This function can be used to retrieve the sequence and picture header out of band. The client must call this function only after the encoder has been initialized using NvEncInitializeEncoder() function. The client must allocate the memory where the NvEncodeAPI interface can copy the bitstream header and pass the pointer to the memory in NV_ENC_SEQUENCE_PARAM_PAYLOAD::spsppsBuffer. The size of buffer is passed in the field NV_ENC_SEQUENCE_PARAM_PAYLOAD::inBufferSize. The NvEncodeAPI interface will copy the bitstream header payload and returns the actual size of the bitstream header in the field NV_ENC_SEQUENCE_PARAM_PAYLOAD::outSPSPPSPayloadSize. The client must call NvEncGetSequenceParams() function from the same thread which is being used to call NvEncEncodePicture() function.

Parameters:

```
← encoder Pointer to the NvEncodeAPI interface.
```

⇔ sequenceParamPayload Pointer to the _NV_ENC_SEQUENCE_PARAM_PAYLOAD structure.

Returns:

```
NV_ENC_SUCCESS

NV_ENC_ERR_INVALID_PTR

NV_ENC_ERR_INVALID_ENCODERDEVICE

NV_ENC_ERR_DEVICE_NOT_EXIST

NV_ENC_ERR_UNSUPPORTED_PARAM

NV_ENC_ERR_OUT_OF_MEMORY

NV_ENC_ERR_INVALID_VERSION

NV_ENC_ERR_INVALID_PARAM

NV_ENC_ERR_ENCODER_NOT_INITIALIZED

NV_ENC_ERR_GENERIC
```

4.2.1.21 NVENCSTATUS NVENCAPI NvEncInitializeEncoder (void * encoder, NV_ENC_INITIALIZE_PARAMS * createEncodeParams)

This API must be used to initialize the encoder. The initialization parameter is passed using *createEncodeParams The client must send the following fields of the _NV_ENC_INITIALIZE_PARAMS structure with a valid value.

• NV_ENC_INITIALIZE_PARAMS::encodeGUID

- NV_ENC_INITIALIZE_PARAMS::encodeWidth
- NV_ENC_INITIALIZE_PARAMS::encodeHeight

The client can pass a preset guid directly to the NvEncodeAPI interface using NV_ENC_INITIALIZE_PARAMS::presetGUID field. If the client doesn't pass NV_ENC_INITIALIZE_PARAMS::encodeConfig structure, the codec specific parameters will be selected based on the preset guid. The preset guid must have been validated by the client using NvEncGetEncodePresetGUIDs() API. If the client passes a custom _NV_ENC_CONFIG structure through NV_ENC_INITIALIZE_PARAMS::encodeConfig , it will override the codec specific parameters based on the preset guid. It is recommended that even if the client passes a custom config, it should also send a preset guid. In this case, the preset guid passed by the client will not override any of the custom config parameters programmed by the client, it is only used as a hint by the NvEncodeAPI interface to determine certain encoder parameters which are not exposed to the client.

There are two modes of operation for the encoder namely:

- · Asynchronous mode
- · Synchronous mode

The client can select asynchronous or synchronous mode by setting the <code>enableEncodeAsync</code> field in _NV_ENC_-INITIALIZE_PARAMS to 1 or 0 respectively.

Asynchronous mode of operation:

The Asynchronous mode can be enabled by setting NV_ENC_INITIALIZE_PARAMS::enableEncodeAsync to 1. The client operating in asynchronous mode must allocate completion event object for each output buffer and pass the completion event object in the NvEncEncodePicture() API. The client can create another thread and wait on the event object to be signalled by NvEncodeAPI interface on completion of the encoding process for the output frame. This should unblock the main thread from submitting work to the encoder. When the event is signalled the client can call NvEncodeAPI interfaces to copy the bitstream data using NvEncLockBitstream() API. This is the preferred mode of operation.

NOTE: Asynchronous mode is not supported on Linux.

Synchronous mode of operation:

The client can select synchronous mode by setting NV_ENC_INITIALIZE_PARAMS::enableEncodeAsync to 0. The client working in synchronous mode can work in a single threaded or multi threaded mode. The client need not allocate any event objects. The client can only lock the bitstream data after NvEncodeAPI interface has returned NV_ENC_SUCCESS from encode picture. The NvEncodeAPI interface can return NV_ENC_ERR_NEED_MORE_INPUT error code from NvEncEncodePicture() API. The client must not lock the output buffer in such case but should send the next frame for encoding. The client must keep on calling NvEncEncodePicture() API until it returns NV_ENC_SUCCESS.

The client must always lock the bitstream data in order in which it has submitted. This is true for both asynchronous and synchronous mode.

Picture type decision:

If the client is taking the picture type decision and it must disable the picture type decision module in NvEncodeAPI by setting NV_ENC_INITIALIZE_PARAMS::enablePTD to 0. In this case the client is required to send the picture in encoding order to NvEncodeAPI by doing the re-ordering for B frames.

If the client doesn't want to take the picture type decision it can enable picture type decision module in the NvEncodeAPI interface by setting NV_ENC_INITIALIZE_PARAMS::enablePTD to 1 and send the input pictures in display order.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← createEncodeParams Refer _NV_ENC_INITIALIZE_PARAMS for details.

Returns:

```
NV_ENC_SUCCESS

NV_ENC_ERR_INVALID_PTR

NV_ENC_ERR_INVALID_ENCODERDEVICE

NV_ENC_ERR_DEVICE_NOT_EXIST

NV_ENC_ERR_UNSUPPORTED_PARAM

NV_ENC_ERR_OUT_OF_MEMORY

NV_ENC_ERR_INVALID_PARAM

NV_ENC_ERR_INVALID_VERSION

NV_ENC_ERR_GENERIC
```

4.2.1.22 NVENCSTATUS NVENCAPI NvEncInvalidateRefFrames (void * encoder, uint64_t invalidRefFrameTimeStamp)

Invalidates reference frame based on the time stamp provided by the client. The encoder marks any reference frames or any frames which have been reconstructed using the corrupt frame as invalid for motion estimation and uses older reference frames for motion estimation. The encoded forces the current frame to be encoded as an intra frame if no reference frames are left after invalidation process. This is useful for low latency application for error resiliency. The client is recommended to set NV_ENC_CONFIG_H264::maxNumRefFrames to a large value so that encoder can keep a backup of older reference frames in the DPB and can use them for motion estimation when the newer reference frames have been invalidated. This API can be called multiple times.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← invalidRefFrameTimeStamp Timestamp of the invalid reference frames which needs to be invalidated.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_GENERIC
```

4.2.1.23 NVENCSTATUS NVENCAPI NvEncLockBitstream (void * encoder, NV_ENC_LOCK_BITSTREAM * lockBitstreamBufferParams)

This function is used to lock the bitstream buffer to read the encoded data. The client can only access the encoded data by calling this function. The pointer to client accessible encoded data is returned in the NV_ENC_LOCK_BITSTREAM::bitstreamBufferPtr field. The size of the encoded data in the output buffer is returned in the NV_ENC_LOCK_BITSTREAM::bitstreamSizeInBytes The NvEncodeAPI interface also returns the output picture type and picture structure of the encoded frame in NV_ENC_LOCK_BITSTREAM::pictureType and NV_ENC_LOCK_BITSTREAM::pictureStruct fields respectively. If the client has set NV_ENC_LOCK_BITSTREAM::doNotWait to

1, the function might return NV_ENC_ERR_LOCK_BUSY if client is operating in synchronous mode. This is not a fatal failure if NV_ENC_LOCK_BITSTREAM::doNotWait is set to 1. In the above case the client can retry the function after few milliseconds.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_INVALID_VERSION
NV_ENC_ERR_LOCK_BUSY
NV_ENC_ERR_ENCODER_NOT_INITIALIZED
NV_ENC_ERR_GENERIC
```

4.2.1.24 NVENCSTATUS NVENCAPI NvEncLockInputBuffer (void * encoder, NV_ENC_LOCK_INPUT_BUFFER * lockInputBufferParams)

This function is used to lock the input buffer to load the uncompressed YUV pixel data into input buffer memory. The client must pass the NV_ENC_INPUT_PTR it had previously allocated using NvEncCreateInputBuffer()in the NV_ENC_LOCK_INPUT_BUFFER::inputBuffer field. The NvEncodeAPI interface returns pointer to client accessible input buffer memory in NV_ENC_LOCK_INPUT_BUFFER::bufferDataPtr field.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_INVALID_VERSION
NV_ENC_ERR_LOCK_BUSY
NV_ENC_ERR_ENCODER_NOT_INITIALIZED
NV_ENC_ERR_GENERIC
```

4.2.1.25 NVENCSTATUS NVENCAPI NvEncMapInputResource (void * encoder, NV_ENC_MAP_INPUT_RESOURCE * mapInputResParams)

Maps an externally allocated input resource [using and returns a NV_ENC_INPUT_PTR which can be used for encoding in the NvEncEncodePicture() function. The mapped resource is returned in the field NV_ENC_MAP_INPUT_RESOURCE::outputResourcePtr. The NvEncodeAPI interface also returns the buffer format of the mapped resource in the field NV_ENC_MAP_INPUT_RESOURCE::outbufferFmt. This function provides synchronization guarantee that any direct3d or cuda work submitted on the input buffer is completed before the buffer is used for encoding. The client should not access any input buffer while they are mapped by the encoder.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← mapInputResParams Pointer to the _NV_ENC_MAP_INPUT_RESOURCE structure.

Returns:

```
NV_ENC_SUCCESS

NV_ENC_ERR_INVALID_PTR

NV_ENC_ERR_INVALID_ENCODERDEVICE

NV_ENC_ERR_DEVICE_NOT_EXIST

NV_ENC_ERR_UNSUPPORTED_PARAM

NV_ENC_ERR_OUT_OF_MEMORY

NV_ENC_ERR_INVALID_VERSION

NV_ENC_ERR_INVALID_PARAM

NV_ENC_ERR_ENCODER_NOT_INITIALIZED

NV_ENC_ERR_RESOURCE_NOT_REGISTERED

NV_ENC_ERR_MAP_FAILED

NV_ENC_ERR_GENERIC
```

4.2.1.26 NVENCSTATUS NVENCAPI NvEncodeAPICreateInstance (NV_ENCODE_API_FUNCTION_-LIST * functionList)

Entry Point to the NvEncodeAPI interface.

Creates an instance of the NvEncodeAPI interface, and populates the pFunctionList with function pointers to the API routines implemented by the NvEncodeAPI interface.

Parameters:

→ functionList

Returns:

NV_ENC_SUCCESS NV_ENC_ERR_INVALID_PTR

4.2.1.27 NVENCSTATUS NVENCAPI NvEncodeAPIGetMaxSupportedVersion (uint32_t * version)

This function can be used by clients to determine if the driver supports the NvEncodeAPI header the application was compiled with.

Parameters:

→ version Pointer to the requested value. The 4 least significant bits in the returned indicate the minor version and the rest of the bits indicate the major version of the largest supported version.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
```

4.2.1.28 NVENCSTATUS NVENCAPI NvEncOpenEncodeSession (void * device, uint32_t deviceType, void ** encoder)

Deprecated.

Returns:

```
NV ENC ERR INVALID CALL
```

4.2.1.29 NVENCSTATUS NVENCAPI NvEncOpenEncodeSessionEx (NV_ENC_-OPEN_ENCODE_SESSION_EX_PARAMS * openSessionExParams, void ** encoder)

Opens an encoding session and returns a pointer to the encoder interface in the **encoder parameter. The client should start encoding process by calling this API first. The client must pass a pointer to IDirect3DDevice9/CUDA interface in the *device parameter. If the creation of encoder session fails, the client must call NvEncDestroyEncoder API before exiting.

Parameters:

- \leftarrow openSessionExParams Pointer to a NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS structure.
- → *encoder* Encode Session pointer to the NvEncodeAPI interface.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_NO_ENCODE_DEVICE
NV_ENC_ERR_UNSUPPORTED_DEVICE
NV_ENC_ERR_INVALID_DEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_GENERIC
```

4.2.1.30 NVENCSTATUS NVENCAPI NvEncReconfigureEncoder (void * encoder, NV_ENC_RECONFIGURE_PARAMS * reInitEncodeParams)

Reconfigure an existing encoding session. The client should call this API to change/reconfigure the parameter passed during NvEncInitializeEncoder API call. Currently Reconfiguration of following are not supported. Change in GOP structure. Change in sync-Async mode. Change in MaxWidth & MaxHeight. Change in PTDmode.

Resolution change is possible only if maxEncodeWidth & maxEncodeHeight of NV_ENC_INITIALIZE_PARAMS is set while creating encoder session.

Parameters:

← *encoder* Pointer to the NVEncodeAPI interface.

← reInitEncodeParams Pointer to a NV_ENC_RECONFIGURE_PARAMS structure.

Returns:

```
NV_ENC_SUCCESS

NV_ENC_ERR_INVALID_PTR

NV_ENC_ERR_NO_ENCODE_DEVICE

NV_ENC_ERR_UNSUPPORTED_DEVICE

NV_ENC_ERR_INVALID_DEVICE

NV_ENC_ERR_DEVICE_NOT_EXIST

NV_ENC_ERR_UNSUPPORTED_PARAM

NV_ENC_ERR_GENERIC
```

4.2.1.31 NVENCSTATUS NVENCAPI NvEncRegisterAsyncEvent (void * encoder, NV_ENC_EVENT_PARAMS * eventParams)

This function is used to register the completion event with NvEncodeAPI interface. The event is required when the client has configured the encoder to work in asynchronous mode. In this mode the client needs to send a completion event with every output buffer. The NvEncodeAPI interface will signal the completion of the encoding process using this event. Only after the event is signalled the client can get the encoded data using NvEncLockBitstream() function.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← *eventParams* Pointer to the _NV_ENC_EVENT_PARAMS structure.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_VERSION
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_ENCODER_NOT_INITIALIZED
NV_ENC_ERR_GENERIC
```

4.2.1.32 NVENCSTATUS NVENCAPI NvEncRegisterResource (void * encoder, NV_ENC_REGISTER_RESOURCE * registerResParams)

Registers a resource with the Nvidia Video Encoder Interface for book keeping. The client is expected to pass the registered resource handle as well, while calling NvEncMapInputResource API.

Parameters:

- ← *encoder* Pointer to the NVEncodeAPI interface.
- ← registerResParams Pointer to a _NV_ENC_REGISTER_RESOURCE structure

Returns:

```
NV_ENC_SUCCESS
```

```
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_VERSION
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_ENCODER_NOT_INITIALIZED
NV_ENC_ERR_RESOURCE_REGISTER_FAILED
NV_ENC_ERR_GENERIC
NV_ENC_ERR_UNIMPLEMENTED
```

4.2.1.33 NVENCSTATUS NVENCAPI NvEncRunMotionEstimationOnly (void * encoder, NV_ENC_MEONLY_PARAMS * meOnlyParams)

This function is used to submit the input frame and reference frame for motion estimation. The ME parameters are passed using *meOnlyParams which is a pointer to _NV_ENC_MEONLY_PARAMS structure. Client must lock NV_ENC_CREATE_MV_BUFFER::mvBuffer using NvEncLockBitstream() API to get the motion vector data. to get motion vector data.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← meOnlyParams Pointer to the _NV_ENC_MEONLY_PARAMS structure.

Returns:

```
NV_ENC_SUCCESS
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_INVALID_VERSION
NV_ENC_ERR_NEED_MORE_INPUT
NV_ENC_ERR_ENCODER_NOT_INITIALIZED
NV_ENC_ERR_GENERIC
```

4.2.1.34 NVENCSTATUS NVENCAPI NvEncUnlockBitstream (void * encoder, NV_ENC_OUTPUT_PTR bitstreamBuffer)

This function is used to unlock the output bitstream buffer after the client has read the encoded data from output buffer. The client must call this function to unlock the output buffer which it has previously locked using NvEncLockBitstream() function. Using a locked bitstream buffer in NvEncEncodePicture() API will cause the function to fail.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ⇔ bitstreamBuffer bitstream buffer pointer being unlocked

Returns:

```
NV_ENC_SUCCESS

NV_ENC_ERR_INVALID_PTR

NV_ENC_ERR_INVALID_ENCODERDEVICE

NV_ENC_ERR_DEVICE_NOT_EXIST

NV_ENC_ERR_UNSUPPORTED_PARAM

NV_ENC_ERR_OUT_OF_MEMORY

NV_ENC_ERR_INVALID_PARAM

NV_ENC_ERR_ENCODER_NOT_INITIALIZED

NV_ENC_ERR_GENERIC
```

4.2.1.35 NVENCSTATUS NVENCAPI NvEncUnlockInputBuffer (void * encoder, NV_ENC_INPUT_PTR inputBuffer)

This function is used to unlock the input buffer memory previously locked for uploading YUV pixel data. The input buffer must be unlocked before being used again for encoding, otherwise NvEncodeAPI will fail the NvEncEncode-Picture()

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← inputBuffer Pointer to the input buffer that is being unlocked.

Returns:

```
NV_ENC_SUCCESS

NV_ENC_ERR_INVALID_PTR

NV_ENC_ERR_INVALID_ENCODERDEVICE

NV_ENC_ERR_DEVICE_NOT_EXIST

NV_ENC_ERR_UNSUPPORTED_PARAM

NV_ENC_ERR_OUT_OF_MEMORY

NV_ENC_ERR_INVALID_VERSION

NV_ENC_ERR_INVALID_PARAM

NV_ENC_ERR_ENCODER_NOT_INITIALIZED

NV_ENC_ERR_GENERIC
```

4.2.1.36 NVENCSTATUS NVENCAPI NvEncUnmapInputResource (void * encoder, NV_ENC_INPUT_PTR mappedInputBuffer)

UnMaps an input buffer which was previously mapped using NvEncMapInputResource() API. The mapping created using NvEncMapInputResource() should be invalidated using this API before the external resource is destroyed by the client. The client must unmap the buffer after NvEncLockBitstream() API returns succuessfully for encode work submitted using the mapped input buffer.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← mappedInputBuffer Pointer to the NV_ENC_INPUT_PTR

Returns:

```
NV_ENC_SUCCESS
```

```
NV_ENC_ERR_INVALID_PTR
NV_ENC_ERR_INVALID_ENCODERDEVICE
NV_ENC_ERR_DEVICE_NOT_EXIST
NV_ENC_ERR_UNSUPPORTED_PARAM
NV_ENC_ERR_OUT_OF_MEMORY
NV_ENC_ERR_INVALID_VERSION
NV_ENC_ERR_INVALID_PARAM
NV_ENC_ERR_ENCODER_NOT_INITIALIZED
NV_ENC_ERR_RESOURCE_NOT_REGISTERED
NV_ENC_ERR_RESOURCE_NOT_MAPPED
NV_ENC_ERR_GENERIC
```

4.2.1.37 NVENCSTATUS NVENCAPI NvEncUnregisterAsyncEvent (void * encoder, NV_ENC_EVENT_PARAMS * eventParams)

This function is used to unregister completion event which has been previously registered using NvEncRegisterAsyncEvent() function. The client must unregister all events before destroying the encoder using NvEncDestroyEncoder() function.

Parameters:

- ← *encoder* Pointer to the NvEncodeAPI interface.
- ← eventParams Pointer to the NV ENC EVENT PARAMS structure.

Returns:

```
NV_ENC_SUCCESS

NV_ENC_ERR_INVALID_PTR

NV_ENC_ERR_INVALID_ENCODERDEVICE

NV_ENC_ERR_DEVICE_NOT_EXIST

NV_ENC_ERR_UNSUPPORTED_PARAM

NV_ENC_ERR_OUT_OF_MEMORY

NV_ENC_ERR_INVALID_VERSION

NV_ENC_ERR_INVALID_PARAM

NV_ENC_ERR_ENCODER_NOT_INITIALIZED

NV_ENC_ERR_GENERIC
```

4.2.1.38 NVENCSTATUS NVENCAPI NvEncUnregisterResource (void * encoder, NV_ENC_REGISTERED_PTR registeredResource)

Unregisters a resource previously registered with the Nvidia Video Encoder Interface. The client is expected to unregister any resource that it has registered with the Nvidia Video Encoder Interface before destroying the resource.

Parameters:

- ← *encoder* Pointer to the NVEncodeAPI interface.
- ← registeredResource The registered resource pointer that was returned in NvEncRegisterResource.

Returns:

```
NV_ENC_SUCCESS
NV ENC ERR INVALID PTR
```

- NV_ENC_ERR_INVALID_ENCODERDEVICE
- NV_ENC_ERR_DEVICE_NOT_EXIST
- NV_ENC_ERR_UNSUPPORTED_PARAM
- NV_ENC_ERR_OUT_OF_MEMORY
- NV_ENC_ERR_INVALID_VERSION
- NV_ENC_ERR_INVALID_PARAM
- NV_ENC_ERR_ENCODER_NOT_INITIALIZED
- NV_ENC_ERR_RESOURCE_NOT_REGISTERED
- NV_ENC_ERR_GENERIC
- NV_ENC_ERR_UNIMPLEMENTED

Chapter 5

Data Structure Documentation

5.1 GUID Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t Data1
- uint16_t Data2
- uint16_t Data3
- uint8_t Data4 [8]

5.1.1 Detailed Description

Abstracts the **GUID** structure for non-windows platforms.

5.1.2 Field Documentation

5.1.2.1 uint32_t GUID::Data1

[in]: Specifies the first 8 hexadecimal digits of the GUID.

5.1.2.2 uint16_t GUID::Data2

[in]: Specifies the first group of 4 hexadecimal digits.

5.1.2.3 uint16_t GUID::Data3

[in]: Specifies the second group of 4 hexadecimal digits.

5.1.2.4 uint8_t GUID::Data4[8]

[in]: Array of 8 bytes. The first 2 bytes contain the third group of 4 hexadecimal digits. The remaining 6 bytes contain the final 12 hexadecimal digits.

5.2 NV_ENC_CAPS_PARAM Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t version
- NV_ENC_CAPS capsToQuery
- uint32_t reserved [62]

5.2.1 Detailed Description

Input struct for querying Encoding capabilities.

5.2.2 Field Documentation

5.2.2.1 NV_ENC_CAPS NV_ENC_CAPS_PARAM::capsToQuery

[in]: Specifies the encode capability to be queried. Client should pass a member for NV_ENC_CAPS enum.

5.2.2.2 uint32_t NV_ENC_CAPS_PARAM::reserved[62]

[in]: Reserved and must be set to 0

5.2.2.3 uint32_t NV_ENC_CAPS_PARAM::version

[in]: Struct version. Must be set to NV_ENC_CAPS_PARAM_VER

5.3 NV_ENC_CODEC_CONFIG Union Reference

#include <nvEncodeAPI.h>

Data Fields

- NV_ENC_CONFIG_H264 h264Config
- NV_ENC_CONFIG_HEVC hevcConfig
- NV ENC CONFIG H264 MEONLY h264MeOnlyConfig
- NV_ENC_CONFIG_HEVC_MEONLY hevcMeOnlyConfig
- uint32_t reserved [320]

5.3.1 Detailed Description

Codec-specific encoder configuration parameters to be set during initialization.

5.3.2 Field Documentation

5.3.2.1 NV_ENC_CONFIG_H264 NV_ENC_CODEC_CONFIG::h264Config

[in]: Specifies the H.264-specific encoder configuration.

5.3.2.2 NV_ENC_CONFIG_H264_MEONLY NV_ENC_CODEC_CONFIG::h264MeOnlyConfig

[in]: Specifies the H.264-specific ME only encoder configuration.

5.3.2.3 NV_ENC_CONFIG_HEVC NV_ENC_CODEC_CONFIG::hevcConfig

[in]: Specifies the HEVC-specific encoder configuration.

5.3.2.4 NV_ENC_CONFIG_HEVC_MEONLY NV_ENC_CODEC_CONFIG::hevcMeOnlyConfig

[in]: Specifies the HEVC-specific ME only encoder configuration.

5.3.2.5 uint32_t NV_ENC_CODEC_CONFIG::reserved[320]

[in]: Reserved and must be set to 0

5.4 NV_ENC_CODEC_PIC_PARAMS Union Reference

#include <nvEncodeAPI.h>

Data Fields

- NV_ENC_PIC_PARAMS_H264 h264PicParams
- NV_ENC_PIC_PARAMS_HEVC hevcPicParams
- uint32_t reserved [256]

5.4.1 Detailed Description

Codec specific per-picture encoding parameters.

5.4.2 Field Documentation

5.4.2.1 NV_ENC_PIC_PARAMS_H264 NV_ENC_CODEC_PIC_PARAMS::h264PicParams

[in]: H264 encode picture params.

5.4.2.2 NV_ENC_PIC_PARAMS_HEVC NV_ENC_CODEC_PIC_PARAMS::hevcPicParams

[in]: HEVC encode picture params. Currently unsupported and must not to be used.

5.4.2.3 uint32_t NV_ENC_CODEC_PIC_PARAMS::reserved[256]

[in]: Reserved and must be set to 0.

5.5 NV_ENC_CONFIG Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32 t version
- GUID profileGUID
- uint32_t gopLength
- int32_t frameIntervalP
- uint32_t monoChromeEncoding
- NV_ENC_PARAMS_FRAME_FIELD_MODE frameFieldMode
- NV_ENC_MV_PRECISION mvPrecision
- NV ENC RC PARAMS rcParams
- NV_ENC_CODEC_CONFIG encodeCodecConfig
- uint32_t reserved [278]
- void * reserved2 [64]

5.5.1 Detailed Description

Encoder configuration parameters to be set during initialization.

5.5.2 Field Documentation

5.5.2.1 NV_ENC_CODEC_CONFIG NV_ENC_CONFIG::encodeCodecConfig

[in]: Specifies the codec specific config parameters through this union.

5.5.2.2 NV_ENC_PARAMS_FRAME_FIELD_MODE NV_ENC_CONFIG::frameFieldMode

[in]: Specifies the frame/field mode. Check support for field encoding using NV_ENC_CAPS_SUPPORT_FIELD_ENCODING caps. Using a frameFieldMode other than NV_ENC_PARAMS_FRAME_FIELD_MODE_FRAME for RGB input is not supported.

5.5.2.3 int32_t NV_ENC_CONFIG::frameIntervalP

[in]: Specifies the GOP pattern as follows: frameIntervalP = 0: I, 1: IPP, 2: IBP, 3: IBBP If goplength is set to NVENC_INFINITE_GOPLENGTH frameIntervalP should be set to 1.

5.5.2.4 uint32_t NV_ENC_CONFIG::gopLength

[in]: Specifies the number of pictures in one GOP. Low latency application client can set goplength to NVENC_-INFINITE_GOPLENGTH so that keyframes are not inserted automatically.

5.5.2.5 uint32_t NV_ENC_CONFIG::monoChromeEncoding

[in]: Set this to 1 to enable monochrome encoding for this session.

5.5.2.6 NV_ENC_MV_PRECISION NV_ENC_CONFIG::mvPrecision

[in]: Specifies the desired motion vector prediction precision.

5.5.2.7 GUID NV_ENC_CONFIG::profileGUID

[in]: Specifies the codec profile guid. If client specifies NV_ENC_CODEC_PROFILE_AUTOSELECT_GUID the NvEncodeAPI interface will select the appropriate codec profile.

5.5.2.8 NV_ENC_RC_PARAMS NV_ENC_CONFIG::rcParams

[in]: Specifies the rate control parameters for the current encoding session.

5.5.2.9 uint32_t NV_ENC_CONFIG::reserved[278]

[in]: Reserved and must be set to 0

5.5.2.10 void* NV_ENC_CONFIG::reserved2[64]

[in]: Reserved and must be set to NULL

5.5.2.11 uint32_t NV_ENC_CONFIG::version

[in]: Struct version. Must be set to NV_ENC_CONFIG_VER.

5.6 NV_ENC_CONFIG_H264 Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t enableTemporalSVC:1
- uint32_t enableStereoMVC:1
- uint32 t hierarchicalPFrames:1
- uint32_t hierarchicalBFrames:1
- uint32_t outputBufferingPeriodSEI:1
- uint32_t outputPictureTimingSEI:1
- uint32_t outputAUD:1
- uint32_t disableSPSPPS:1
- uint32_t outputFramePackingSEI:1
- uint32_t outputRecoveryPointSEI:1
- uint32_t enableIntraRefresh:1
- uint32_t enableConstrainedEncoding:1
- uint32_t repeatSPSPPS:1
- uint32 t enableVFR:1
- uint32_t enableLTR:1
- uint32_t qpPrimeYZeroTransformBypassFlag:1
- uint32_t useConstrainedIntraPred:1
- uint32_t reservedBitFields:15
- uint32_t level
- uint32_t idrPeriod
- uint32_t separateColourPlaneFlag
- uint32_t disableDeblockingFilterIDC
- uint32_t numTemporalLayers
- uint32_t spsId
- uint32 t ppsId
- NV_ENC_H264_ADAPTIVE_TRANSFORM_MODE adaptiveTransformMode
- NV_ENC_H264_FMO_MODE fmoMode
- NV_ENC_H264_BDIRECT_MODE bdirectMode
- NV_ENC_H264_ENTROPY_CODING_MODE entropyCodingMode
- NV_ENC_STEREO_PACKING_MODE stereoMode
- uint32_t intraRefreshPeriod
- uint32_t intraRefreshCnt
- uint32_t maxNumRefFrames
- uint32_t sliceMode
- uint32_t sliceModeData
- NV_ENC_CONFIG_H264_VUI_PARAMETERS h264VUIParameters
- uint32_t ltrNumFrames
- uint32_t ltrTrustMode
- uint32_t chromaFormatIDC
- uint32_t maxTemporalLayers
- uint32_t reserved1 [270]
- void * reserved2 [64]

5.6.1 Detailed Description

H264 encoder configuration parameters

5.6.2 Field Documentation

5.6.2.1 NV_ENC_H264_ADAPTIVE_TRANSFORM_MODE NV_ENC_CONFIG_-H264::adaptiveTransformMode

[in]: Specifies the AdaptiveTransform Mode. Check support for AdaptiveTransform mode using NV_ENC_CAPS_-SUPPORT_ADAPTIVE_TRANSFORM caps.

5.6.2.2 NV_ENC_H264_BDIRECT_MODE NV_ENC_CONFIG_H264::bdirectMode

[in]: Specifies the BDirect mode. Check support for BDirect mode using NV_ENC_CAPS_SUPPORT_BDIRECT_-MODE caps.

5.6.2.3 uint32_t NV_ENC_CONFIG_H264::chromaFormatIDC

[in]: Specifies the chroma format. Should be set to 1 for yuv420 input, 3 for yuv444 input. Check support for YUV444 encoding using NV_ENC_CAPS_SUPPORT_YUV444_ENCODE caps.

5.6.2.4 uint32_t NV_ENC_CONFIG_H264::disableDeblockingFilterIDC

[in]: Specifies the deblocking filter mode. Permissible value range: [0,2]

5.6.2.5 uint32_t NV_ENC_CONFIG_H264::disableSPSPPS

[in]: Set to 1 to disable writing of Sequence and Picture parameter info in bitstream

5.6.2.6 uint32_t NV_ENC_CONFIG_H264::enableConstrainedEncoding

[in]: Set this to 1 to enable constrainedFrame encoding where each slice in the constarined picture is independent of other slices Check support for constrained encoding using NV_ENC_CAPS_SUPPORT_CONSTRAINED_-ENCODING caps.

5.6.2.7 uint32_t NV_ENC_CONFIG_H264::enableIntraRefresh

[in]: Set to 1 to enable gradual decoder refresh or intra refresh. If the GOP structure uses B frames this will be ignored

5.6.2.8 uint32 t NV ENC CONFIG H264::enableLTR

[in]: Currently this feature is not available and must be set to 0. Set to 1 to enable LTR support and auto-mark the first

5.6.2.9 uint32_t NV_ENC_CONFIG_H264::enableStereoMVC

[in]: Set to 1 to enable stereo MVC

5.6.2.10 uint32_t NV_ENC_CONFIG_H264::enableTemporalSVC

[in]: Set to 1 to enable SVC temporal

5.6.2.11 uint32_t NV_ENC_CONFIG_H264::enableVFR

[in]: Set to 1 to enable variable frame rate.

5.6.2.12 NV_ENC_H264_ENTROPY_CODING_MODE NV_ENC_CONFIG_H264::entropyCodingMode

[in]: Specifies the entropy coding mode. Check support for CABAC mode using NV_ENC_CAPS_SUPPORT_-CABAC caps.

5.6.2.13 NV_ENC_H264_FMO_MODE NV_ENC_CONFIG_H264::fmoMode

[in]: Specified the FMO Mode. Check support for FMO using NV_ENC_CAPS_SUPPORT_FMO caps.

5.6.2.14 NV_ENC_CONFIG_H264_VUI_PARAMETERS NV_ENC_CONFIG_H264::h264VUIParameters

[in]: Specifies the H264 video usability info pamameters

5.6.2.15 uint32_t NV_ENC_CONFIG_H264::hierarchicalBFrames

[in]: Set to 1 to enable hierarchical BFrames

5.6.2.16 uint32_t NV_ENC_CONFIG_H264::hierarchicalPFrames

[in]: Set to 1 to enable hierarchical PFrames

5.6.2.17 uint32_t NV_ENC_CONFIG_H264::idrPeriod

[in]: Specifies the IDR interval. If not set, this is made equal to gopLength in NV_ENC_CONFIG.Low latency application client can set IDR interval to NVENC_INFINITE_GOPLENGTH so that IDR frames are not inserted automatically.

5.6.2.18 uint32_t NV_ENC_CONFIG_H264::intraRefreshCnt

[in]: Specifies the length of intra refresh in number of frames for periodic intra refresh. This value should be smaller than intraRefreshPeriod

5.6.2.19 uint32 t NV ENC CONFIG H264::intraRefreshPeriod

[in]: Specifies the interval between successive intra refresh if enableIntrarefresh is set. Requires enableIntraRefresh to be set. Will be disabled if NV_ENC_CONFIG::gopLength is not set to NVENC_INFINITE_GOPLENGTH.

5.6.2.20 uint32_t NV_ENC_CONFIG_H264::level

[in]: Specifies the encoding level. Client is recommended to set this to NV_ENC_LEVEL_AUTOSELECT in order to enable the NvEncodeAPI interface to select the correct level.

5.6.2.21 uint32_t NV_ENC_CONFIG_H264::ltrNumFrames

[in]: Specifies the number of LTR frames used. If ltrTrustMode=1, encoder will mark first numLTRFrames base layer reference frames within each IDR interval as LTR. If ltrMarkFrame=1, ltrNumFrames specifies maximum number of ltr frames in DPB. If ltrNumFrames value is more that DPB size(maxNumRefFrames) encoder will take decision on its own.

5.6.2.22 uint32_t NV_ENC_CONFIG_H264::ltrTrustMode

[in]: Specifies the LTR operating mode. Set to 0 to disallow encoding using LTR frames until later specified. Set to 1 to allow encoding using LTR frames unless later invalidated.

5.6.2.23 uint32_t NV_ENC_CONFIG_H264::maxNumRefFrames

[in]: Specifies the DPB size used for encoding. Setting it to 0 will let driver use the default dpb size. The low latency application which wants to invalidate reference frame as an error resilience tool is recommended to use a large DPB size so that the encoder can keep old reference frames which can be used if recent frames are invalidated.

5.6.2.24 uint32_t NV_ENC_CONFIG_H264::maxTemporalLayers

[in]: Specifies the max temporal layer used for hierarchical coding.

5.6.2.25 uint32_t NV_ENC_CONFIG_H264::numTemporalLayers

[in]: Specifies max temporal layers to be used for hierarchical coding. Valid value range is [1,NV_ENC_CAPS_NUM_MAX_TEMPORAL_LAYERS]

5.6.2.26 uint32_t NV_ENC_CONFIG_H264::outputAUD

[in]: Set to 1 to write access unit delimiter syntax in bitstream

5.6.2.27 uint32_t NV_ENC_CONFIG_H264::outputBufferingPeriodSEI

[in]: Set to 1 to write SEI buffering period syntax in the bitstream

5.6.2.28 uint32_t NV_ENC_CONFIG_H264::outputFramePackingSEI

[in]: Set to 1 to enable writing of frame packing arrangement SEI messages to bitstream

5.6.2.29 uint32_t NV_ENC_CONFIG_H264::outputPictureTimingSEI

[in]: Set to 1 to write SEI picture timing syntax in the bitstream. When set for following rateControlMode: NV_ENC_PARAMS_RC_CBR, NV_ENC_PARAMS_RC_CBR_LOWDELAY_HQ, NV_ENC_PARAMS_RC_CBR_HQ, filler data is inserted if needed to achieve hrd bitrate

5.6.2.30 uint32_t NV_ENC_CONFIG_H264::outputRecoveryPointSEI

[in]: Set to 1 to enable writing of recovery point SEI message

5.6.2.31 uint32_t NV_ENC_CONFIG_H264::ppsId

[in]: Specifies the PPS id of the picture header. Currently reserved and must be set to 0.

5.6.2.32 uint32_t NV_ENC_CONFIG_H264::qpPrimeYZeroTransformBypassFlag

[in]: To enable lossless encode set this to 1, set QP to 0 and RC_mode to NV_ENC_PARAMS_RC_CONSTQP and profile to HIGH_444_PREDICTIVE_PROFILE. Check support for lossless encoding using NV_ENC_CAPS_SUPPORT_LOSSLESS_ENCODE caps.

5.6.2.33 uint32_t NV_ENC_CONFIG_H264::repeatSPSPPS

[in]: Set to 1 to enable writing of Sequence and Picture parameter for every IDR frame

5.6.2.34 uint32_t NV_ENC_CONFIG_H264::reserved1[270]

[in]: Reserved and must be set to 0

5.6.2.35 void* NV_ENC_CONFIG_H264::reserved2[64]

[in]: Reserved and must be set to NULL

5.6.2.36 uint32_t NV_ENC_CONFIG_H264::reservedBitFields

[in]: Reserved bitfields and must be set to 0

5.6.2.37 uint32_t NV_ENC_CONFIG_H264::separateColourPlaneFlag

[in]: Set to 1 to enable 4:4:4 separate colour planes

5.6.2.38 uint32_t NV_ENC_CONFIG_H264::sliceMode

[in]: This parameter in conjunction with sliceModeData specifies the way in which the picture is divided into slices sliceMode = 0 MB based slices, sliceMode = 1 Byte based slices, sliceMode = 2 MB row based slices, sliceMode = 3, numSlices in Picture When forceIntraRefreshWithFrameCnt is set it will have priority over sliceMode setting When sliceMode == 0 and sliceModeData == 0 whole picture will be coded with one slice

5.6.2.39 uint32_t NV_ENC_CONFIG_H264::sliceModeData

[in]: Specifies the parameter needed for sliceMode. For: sliceMode = 0, sliceModeData specifies # of MBs in each slice (except last slice) sliceMode = 1, sliceModeData specifies maximum # of bytes in each slice (except last slice) sliceMode = 2, sliceModeData specifies # of MB rows in each slice (except last slice) sliceMode = 3, sliceModeData specifies number of slices in the picture. Driver will divide picture into slices optimally

5.6.2.40 uint32_t NV_ENC_CONFIG_H264::spsId

[in]: Specifies the SPS id of the sequence header. Currently reserved and must be set to 0.

5.6.2.41 NV_ENC_STEREO_PACKING_MODE NV_ENC_CONFIG_H264::stereoMode

[in]: Specifies the stereo frame packing mode which is to be signalled in frame packing arrangement SEI

5.6.2.42 uint32_t NV_ENC_CONFIG_H264::useConstrainedIntraPred

[in]: Set 1 to enable constrained intra prediction.

5.7 NV_ENC_CONFIG_H264_MEONLY Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32 t disablePartition16x16:1
- uint32_t disablePartition8x16:1
- uint32 t disablePartition16x8:1
- uint32_t disablePartition8x8:1
- uint32_t disableIntraSearch:1
- uint32_t bStereoEnable:1
- uint32_t reserved:26
- uint32_t reserved1 [255]
- void * reserved2 [64]

5.7.1 Detailed Description

H264 encoder configuration parameters for ME only Mode

5.7.2 Field Documentation

5.7.2.1 uint32_t NV_ENC_CONFIG_H264_MEONLY::bStereoEnable

[in]: Enable Stereo Mode for Motion Estimation where each view is independently executed

5.7.2.2 uint32_t NV_ENC_CONFIG_H264_MEONLY::disableIntraSearch

[in]: Disable Intra search during MotionEstimation

5.7.2.3 uint32_t NV_ENC_CONFIG_H264_MEONLY::disablePartition16x16

[in]: Disable MotionEstimation on 16x16 blocks

5.7.2.4 uint32_t NV_ENC_CONFIG_H264_MEONLY::disablePartition16x8

[in]: Disable MotionEstimation on 16x8 blocks

5.7.2.5 uint32_t NV_ENC_CONFIG_H264_MEONLY::disablePartition8x16

[in]: Disable MotionEstimation on 8x16 blocks

5.7.2.6 uint32_t NV_ENC_CONFIG_H264_MEONLY::disablePartition8x8

[in]: Disable MotionEstimation on 8x8 blocks

5.7.2.7 uint32_t NV_ENC_CONFIG_H264_MEONLY::reserved

[in]: Reserved and must be set to 0

5.7.2.8 uint32_t NV_ENC_CONFIG_H264_MEONLY::reserved1[255]

[in]: Reserved and must be set to 0

5.7.2.9 void* NV_ENC_CONFIG_H264_MEONLY::reserved2[64]

[in]: Reserved and must be set to NULL

5.8 NV_ENC_CONFIG_H264_VUI_PARAMETERS Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t overscanInfoPresentFlag
- uint32_t overscanInfo
- uint32_t videoSignalTypePresentFlag
- uint32_t videoFormat
- uint32_t videoFullRangeFlag
- uint32_t colourDescriptionPresentFlag
- uint32_t colourPrimaries
- uint32 t transferCharacteristics
- uint32_t colourMatrix
- uint32_t chromaSampleLocationFlag
- uint32_t chromaSampleLocationTop
- uint32_t chromaSampleLocationBot
- uint32_t bitstreamRestrictionFlag

5.8.1 Detailed Description

H264 Video Usability Info parameters

5.8.2 Field Documentation

5.8.2.1 uint32_t NV_ENC_CONFIG_H264_VUI_PARAMETERS::bitstreamRestrictionFlag

[in]: if set to 1, it specifies the bitstream restriction parameters are present in the bitstream.

5.8.2.2 uint32_t NV_ENC_CONFIG_H264_VUI_PARAMETERS::chromaSampleLocationBot

[in]: Specifies the chroma sample location for bottom field(as defined in Annex E of the ITU-T Specification)

5.8.2.3 uint32_t NV_ENC_CONFIG_H264_VUI_PARAMETERS::chromaSampleLocationFlag

[in]: if set to 1, it specifies that the chromaSampleLocationTop and chromaSampleLocationBot are present.

5.8.2.4 uint32_t NV_ENC_CONFIG_H264_VUI_PARAMETERS::chromaSampleLocationTop

[in]: Specifies the chroma sample location for top field(as defined in Annex E of the ITU-T Specification)

5.8.2.5 uint32 t NV ENC CONFIG H264 VUI PARAMETERS::colourDescriptionPresentFlag

[in]: If set to 1, it specifies that the colourPrimaries, transferCharacteristics and colourMatrix are present.

5.8,2.6 uint32_t NV_ENC_CONFIG_H264_VUI_PARAMETERS::colourMatrix

[in]: Specifies the matrix coefficients used in deriving the luma and chroma from the RGB primaries (as defined in Annex E of the ITU-T Specification).

5.8.2.7 uint32_t NV_ENC_CONFIG_H264_VUI_PARAMETERS::colourPrimaries

[in]: Specifies color primaries for converting to RGB(as defined in Annex E of the ITU-T Specification)

5.8.2.8 uint32_t NV_ENC_CONFIG_H264_VUI_PARAMETERS::overscanInfo

[in]: Specifies the overscan info(as defined in Annex E of the ITU-T Specification).

5.8.2.9 uint32_t NV_ENC_CONFIG_H264_VUI_PARAMETERS::overscanInfoPresentFlag

[in]: if set to 1, it specifies that the overscanInfo is present

5.8.2.10 uint32_t NV_ENC_CONFIG_H264_VUI_PARAMETERS::transferCharacteristics

[in]: Specifies the opto-electronic transfer characteristics to use (as defined in Annex E of the ITU-T Specification)

5.8.2.11 uint32_t NV_ENC_CONFIG_H264_VUI_PARAMETERS::videoFormat

[in]: Specifies the source video format(as defined in Annex E of the ITU-T Specification).

5.8.2.12 uint32_t NV_ENC_CONFIG_H264_VUI_PARAMETERS::videoFullRangeFlag

[in]: Specifies the output range of the luma and chroma samples(as defined in Annex E of the ITU-T Specification).

5.8.2.13 uint32 t NV ENC CONFIG H264 VUI PARAMETERS::videoSignalTypePresentFlag

[in]: If set to 1, it specifies that the videoFormat, videoFullRangeFlag and colourDescriptionPresentFlag are present.

5.9 NV_ENC_CONFIG_HEVC Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32 t level
- uint32_t tier
- NV ENC HEVC CUSIZE minCUSize
- NV_ENC_HEVC_CUSIZE maxCUSize
- uint32_t useConstrainedIntraPred:1
- uint32_t disableDeblockAcrossSliceBoundary:1
- uint32_t outputBufferingPeriodSEI:1
- uint32_t outputPictureTimingSEI:1
- uint32_t outputAUD:1
- uint32_t enableLTR:1
- uint32 t disableSPSPPS:1
- uint32_t repeatSPSPPS:1
- uint32_t enableIntraRefresh:1
- uint32_t chromaFormatIDC:2
- uint32_t pixelBitDepthMinus8:3
- uint32_t reserved:18
- uint32_t idrPeriod
- uint32_t intraRefreshPeriod
- uint32_t intraRefreshCnt
- uint32_t maxNumRefFramesInDPB
- uint32_t ltrNumFrames
- uint32_t vpsId
- uint32_t spsId
- uint32_t ppsId
- uint32 t sliceMode
- uint32_t sliceModeData
- uint32_t maxTemporalLayersMinus1
- NV_ENC_CONFIG_HEVC_VUI_PARAMETERS hevcVUIParameters
- uint32_t ltrTrustMode
- uint32_t reserved1 [217]
- void * reserved2 [64]

5.9.1 Detailed Description

HEVC encoder configuration parameters to be set during initialization.

5.9.2 Field Documentation

5.9.2.1 uint32_t NV_ENC_CONFIG_HEVC::chromaFormatIDC

[in]: Specifies the chroma format. Should be set to 1 for yuv420 input, 3 for yuv444 input.

5.9.2.2 uint32 t NV ENC CONFIG HEVC::disableDeblockAcrossSliceBoundary

[in]: Set 1 to disable in loop filtering across slice boundary.

5.9.2.3 uint32_t NV_ENC_CONFIG_HEVC::disableSPSPPS

[in]: Set 1 to disable VPS,SPS and PPS signalling in the bitstream.

5.9.2.4 uint32_t NV_ENC_CONFIG_HEVC::enableIntraRefresh

[in]: Set 1 to enable gradual decoder refresh or intra refresh. If the GOP structure uses B frames this will be ignored

5.9.2.5 uint32_t NV_ENC_CONFIG_HEVC::enableLTR

[in]: Set 1 to enable use of long term reference pictures for inter prediction.

5.9.2.6 NV_ENC_CONFIG_HEVC_VUI_PARAMETERS NV_ENC_CONFIG_HEVC::hevcVUIParameters

[in]: Specifies the HEVC video usability info pamameters

5.9.2.7 uint32_t NV_ENC_CONFIG_HEVC::idrPeriod

[in]: Specifies the IDR interval. If not set, this is made equal to gopLength in NV_ENC_CONFIG.Low latency application client can set IDR interval to NVENC_INFINITE_GOPLENGTH so that IDR frames are not inserted automatically.

5.9.2.8 uint32_t NV_ENC_CONFIG_HEVC::intraRefreshCnt

[in]: Specifies the length of intra refresh in number of frames for periodic intra refresh. This value should be smaller than intraRefreshPeriod

5.9.2.9 uint32_t NV_ENC_CONFIG_HEVC::intraRefreshPeriod

[in]: Specifies the interval between successive intra refresh if enableIntrarefresh is set. Requires enableIntraRefresh to be set. Will be disabled if NV_ENC_CONFIG::gopLength is not set to NVENC_INFINITE_GOPLENGTH.

5.9.2.10 uint32_t NV_ENC_CONFIG_HEVC::level

[in]: Specifies the level of the encoded bitstream.

5.9.2.11 uint32_t NV_ENC_CONFIG_HEVC::ltrNumFrames

[in]: Specifies the number of LTR frames used. If ltrTrustMode=1, encoder will mark first numLTRFrames base layer reference frames within each IDR interval as LTR. If ltrMarkFrame=1, ltrNumFrames specifies maximum number of ltr frames in DPB. If ltrNumFrames value is more that DPB size(maxNumRefFramesInDPB) encoder will take decision on its own.

5.9.2.12 uint32_t NV_ENC_CONFIG_HEVC::ltrTrustMode

[in]: Specifies the LTR operating mode. Set to 0 to disallow encoding using LTR frames until later specified. Set to 1 to allow encoding using LTR frames unless later invalidated.

5.9.2.13 NV_ENC_HEVC_CUSIZE NV_ENC_CONFIG_HEVC::maxCUSize

[in]: Specifies the maximum size of luma coding unit. Currently NVENC SDK only supports maxCUSize equal to NV_ENC_HEVC_CUSIZE_32x32.

5.9.2.14 uint32 t NV ENC CONFIG HEVC::maxNumRefFramesInDPB

[in]: Specifies the maximum number of references frames in the DPB.

5.9.2.15 uint32_t NV_ENC_CONFIG_HEVC::maxTemporalLayersMinus1

[in]: Specifies the max temporal layer used for hierarchical coding.

5.9.2.16 NV_ENC_HEVC_CUSIZE NV_ENC_CONFIG_HEVC::minCUSize

[in]: Specifies the minimum size of luma coding unit.

5.9.2.17 uint32_t NV_ENC_CONFIG_HEVC::outputAUD

[in]: Set 1 to write Access Unit Delimiter syntax.

5.9.2.18 uint32_t NV_ENC_CONFIG_HEVC::outputBufferingPeriodSEI

[in]: Set 1 to write SEI buffering period syntax in the bitstream

5.9.2.19 uint32 t NV ENC CONFIG HEVC::outputPictureTimingSEI

[in]: Set 1 to write SEI picture timing syntax in the bitstream

5.9.2.20 uint32_t NV_ENC_CONFIG_HEVC::pixelBitDepthMinus8

[in]: Specifies pixel bit depth minus 8. Should be set to 0 for 8 bit input, 2 for 10 bit input.

5.9.2.21 uint32_t NV_ENC_CONFIG_HEVC::ppsId

[in]: Specifies the PPS id of the picture header. Currently reserved and must be set to 0.

5.9.2.22 uint32_t NV_ENC_CONFIG_HEVC::repeatSPSPPS

[in]: Set 1 to output VPS,SPS and PPS for every IDR frame.

5.9.2.23 uint32_t NV_ENC_CONFIG_HEVC::reserved

[in]: Reserved bitfields.

5.9.2.24 uint32_t NV_ENC_CONFIG_HEVC::reserved1[217]

[in]: Reserved and must be set to 0.

5.9.2.25 void* NV_ENC_CONFIG_HEVC::reserved2[64]

[in]: Reserved and must be set to NULL

5.9.2.26 uint32_t NV_ENC_CONFIG_HEVC::sliceMode

[in]: This parameter in conjunction with sliceModeData specifies the way in which the picture is divided into slices sliceMode = 0 CTU based slices, sliceMode = 1 Byte based slices, sliceMode = 2 CTU row based slices, sliceMode = 3, numSlices in Picture When sliceMode == 0 and sliceModeData == 0 whole picture will be coded with one slice

5.9.2.27 uint32_t NV_ENC_CONFIG_HEVC::sliceModeData

[in]: Specifies the parameter needed for sliceMode. For: sliceMode = 0, sliceModeData specifies # of CTUs in each slice (except last slice) sliceMode = 1, sliceModeData specifies maximum # of bytes in each slice (except last slice) sliceModeData specifies # of CTU rows in each slice (except last slice) sliceMode = 3, sliceModeData specifies number of slices in the picture. Driver will divide picture into slices optimally

5.9.2.28 uint32_t NV_ENC_CONFIG_HEVC::spsId

[in]: Specifies the SPS id of the sequence header. Currently reserved and must be set to 0.

5.9.2.29 uint32_t NV_ENC_CONFIG_HEVC::tier

[in]: Specifies the level tier of the encoded bitstream.

5.9.2.30 uint32_t NV_ENC_CONFIG_HEVC::useConstrainedIntraPred

[in]: Set 1 to enable constrained intra prediction.

5.9.2.31 uint32_t NV_ENC_CONFIG_HEVC::vpsId

[in]: Specifies the VPS id of the video parameter set. Currently reserved and must be set to 0.

5.10 NV_ENC_CONFIG_HEVC_MEONLY Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t reserved [256]
- void * reserved1 [64]

5.10.1 Detailed Description

HEVC encoder configuration parameters for ME only Mode

5.10.2 Field Documentation

5.10.2.1 uint32_t NV_ENC_CONFIG_HEVC_MEONLY::reserved[256]

[in]: Reserved and must be set to 0

5.10.2.2 void* NV_ENC_CONFIG_HEVC_MEONLY::reserved1[64]

[in]: Reserved and must be set to NULL

5.11 NV_ENC_CREATE_BITSTREAM_BUFFER Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32 t version
- uint32_t size
- NV_ENC_MEMORY_HEAP memoryHeap
- uint32_t reserved
- NV_ENC_OUTPUT_PTR bitstreamBuffer
- void * bitstreamBufferPtr
- uint32_t reserved1 [58]
- void * reserved2 [64]

5.11.1 Detailed Description

Creation parameters for output bitstream buffer.

5.11.2 Field Documentation

5.11.2.1 NV_ENC_OUTPUT_PTR NV_ENC_CREATE_BITSTREAM_BUFFER::bitstreamBuffer

[out]: Pointer to the output bitstream buffer

5.11.2.2 void* NV_ENC_CREATE_BITSTREAM_BUFFER::bitstreamBufferPtr

[out]: Reserved and should not be used

5.11.2.3 NV_ENC_MEMORY_HEAP NV_ENC_CREATE_BITSTREAM_BUFFER::memoryHeap

[in]: Deprecated. Will be removed in sdk 8.0

5.11.2.4 uint32_t NV_ENC_CREATE_BITSTREAM_BUFFER::reserved

[in]: Reserved and must be set to 0

5.11.2.5 uint32_t NV_ENC_CREATE_BITSTREAM_BUFFER::reserved1[58]

[in]: Reserved and should be set to 0

5.11.2.6 void* NV_ENC_CREATE_BITSTREAM_BUFFER::reserved2[64]

[in]: Reserved and should be set to NULL

5.11.2.7 uint32_t NV_ENC_CREATE_BITSTREAM_BUFFER::size

[in]: Size of the bitstream buffer to be created

5.11.2.8 uint32_t NV_ENC_CREATE_BITSTREAM_BUFFER::version

[in]: Struct version. Must be set to NV_ENC_CREATE_BITSTREAM_BUFFER_VER

5.12 NV_ENC_CREATE_INPUT_BUFFER Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t version
- uint32_t width
- uint32_t height
- NV_ENC_MEMORY_HEAP memoryHeap
- NV_ENC_BUFFER_FORMAT bufferFmt
- uint32_t reserved
- NV_ENC_INPUT_PTR inputBuffer
- void * pSysMemBuffer
- uint32_t reserved1 [57]
- void * reserved2 [63]

5.12.1 Detailed Description

Creation parameters for input buffer.

5.12.2 Field Documentation

5.12.2.1 NV ENC BUFFER FORMAT NV ENC CREATE INPUT BUFFER::bufferFmt

[in]: Input buffer format

5.12.2.2 uint32 t NV ENC CREATE INPUT BUFFER::height

[in]: Input buffer width

5.12.2.3 NV_ENC_INPUT_PTR NV_ENC_CREATE_INPUT_BUFFER::inputBuffer

[out]: Pointer to input buffer

5.12.2.4 NV_ENC_MEMORY_HEAP NV_ENC_CREATE_INPUT_BUFFER::memoryHeap

[in]: Deprecated. Will be removed in sdk 8.0

5.12.2.5 void* NV_ENC_CREATE_INPUT_BUFFER::pSysMemBuffer

[in]: Pointer to existing sysmem buffer

5.12.2.6 uint32_t NV_ENC_CREATE_INPUT_BUFFER::reserved

[in]: Reserved and must be set to 0

5.12.2.7 uint32_t NV_ENC_CREATE_INPUT_BUFFER::reserved1[57]

[in]: Reserved and must be set to 0

5.12.2.8 void* NV_ENC_CREATE_INPUT_BUFFER::reserved2[63]

[in]: Reserved and must be set to NULL

5.12.2.9 uint32_t NV_ENC_CREATE_INPUT_BUFFER::version

[in]: Struct version. Must be set to NV_ENC_CREATE_INPUT_BUFFER_VER

5.12.2.10 uint32_t NV_ENC_CREATE_INPUT_BUFFER::width

[in]: Input buffer width

5.13 NV_ENC_CREATE_MV_BUFFER Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32 t version
- NV_ENC_OUTPUT_PTR mvBuffer
- uint32_t reserved1 [255]
- void * reserved2 [63]

5.13.1 Detailed Description

Creation parameters for output motion vector buffer for ME only mode.

5.13.2 Field Documentation

5.13.2.1 NV_ENC_OUTPUT_PTR NV_ENC_CREATE_MV_BUFFER::mvBuffer

[out]: Pointer to the output motion vector buffer

5.13.2.2 uint32_t NV_ENC_CREATE_MV_BUFFER::reserved1[255]

[in]: Reserved and should be set to 0

5.13.2.3 void* NV_ENC_CREATE_MV_BUFFER::reserved2[63]

[in]: Reserved and should be set to NULL

5.13.2.4 uint32_t NV_ENC_CREATE_MV_BUFFER::version

[in]: Struct version. Must be set to NV_ENC_CREATE_MV_BUFFER_VER

5.14 NV_ENC_EVENT_PARAMS Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t version
- uint32_t reserved
- void * completionEvent
- uint32_t reserved1 [253]
- void * reserved2 [64]

5.14.1 Detailed Description

Event registration/unregistration parameters.

5.14.2 Field Documentation

5.14.2.1 void* NV_ENC_EVENT_PARAMS::completionEvent

[in]: Handle to event to be registered/unregistered with the NvEncodeAPI interface.

5.14.2.2 uint32_t NV_ENC_EVENT_PARAMS::reserved

[in]: Reserved and must be set to 0

5.14.2.3 uint32_t NV_ENC_EVENT_PARAMS::reserved1[253]

[in]: Reserved and must be set to 0

5.14.2.4 void* NV_ENC_EVENT_PARAMS::reserved2[64]

[in]: Reserved and must be set to NULL

5.14.2.5 uint32_t NV_ENC_EVENT_PARAMS::version

[in]: Struct version. Must be set to NV_ENC_EVENT_PARAMS_VER.

5.15 NV ENC H264 MV DATA Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- NV_ENC_MVECTOR mv [4]
- uint8_t mbType
- uint8_t partitionType
- uint16_t reserved

5.15.1 Detailed Description

Motion vector structure per macroblock for H264 motion estimation.

5.15.2 Field Documentation

5.15.2.1 uint8_t NV_ENC_H264_MV_DATA::mbType

0 (I), 1 (P), 2 (IPCM), 3 (B)

5.15.2.2 NV_ENC_MVECTOR NV_ENC_H264_MV_DATA::mv[4]

up to 4 vectors for 8x8 partition

5.15.2.3 uint8_t NV_ENC_H264_MV_DATA::partitionType

Specifies the block partition type. 0:16x16, 1:8x8, 2:16x8, 3:8x16

5.15.2.4 uint16_t NV_ENC_H264_MV_DATA::reserved

reserved padding for alignment

5.16 NV_ENC_HEVC_MV_DATA Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- NV_ENC_MVECTOR mv [4]
- uint8_t cuType
- uint8_t cuSize
- uint8_t partitionMode
- uint8_t lastCUInCTB

5.16.1 Detailed Description

Motion vector structure per CU for HEVC motion estimation.

5.16.2 Field Documentation

5.16.2.1 uint8_t NV_ENC_HEVC_MV_DATA::cuSize

0: 8x8, 1: 16x16, 2: 32x32, 3: 64x64

5.16.2.2 uint8_t NV_ENC_HEVC_MV_DATA::cuType

0 (I), 1(P), 2 (Skip)

5.16.2.3 uint8_t NV_ENC_HEVC_MV_DATA::lastCUInCTB

Marker to separate CUs in the current CTB from CUs in the next CTB

5.16.2.4 NV_ENC_MVECTOR NV_ENC_HEVC_MV_DATA::mv[4]

up to 4 vectors within a CU

5.16.2.5 uint8_t NV_ENC_HEVC_MV_DATA::partitionMode

The CU partition mode 0 (2Nx2N), 1 (2NxN), 2(Nx2N), 3 (NxN), 4 (2NxnU), 5 (2NxnD), 6(nLx2N), 7 (nRx2N)

5.17 NV_ENC_INITIALIZE_PARAMS Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32 t version
- GUID encodeGUID
- GUID presetGUID
- uint32_t encodeWidth
- uint32_t encodeHeight
- uint32_t darWidth
- uint32_t darHeight
- uint32_t frameRateNum
- uint32_t frameRateDen
- uint32_t enableEncodeAsync
- uint32_t enablePTD
- uint32_t reportSliceOffsets:1
- uint32_t enableSubFrameWrite:1
- uint32_t enableExternalMEHints:1
- uint32_t enableMEOnlyMode:1
- uint32_t reservedBitFields:28
- uint32_t privDataSize
- void * privData
- NV_ENC_CONFIG * encodeConfig
- uint32_t maxEncodeWidth
- uint32_t maxEncodeHeight
- NVENC_EXTERNAL_ME_HINT_COUNTS_PER_BLOCKTYPE maxMEHintCountsPerBlock [2]
- uint32_t reserved [289]
- void * reserved2 [64]

5.17.1 Detailed Description

Encode Session Initialization parameters.

5.17.2 Field Documentation

5.17.2.1 uint32_t NV_ENC_INITIALIZE_PARAMS::darHeight

[in]: Specifies the display aspect ratio height.

5.17.2.2 uint32_t NV_ENC_INITIALIZE_PARAMS::darWidth

[in]: Specifies the display aspect ratio Width.

5.17.2.3 uint32_t NV_ENC_INITIALIZE_PARAMS::enableEncodeAsync

[in]: Set this to 1 to enable asynchronous mode and is expected to use events to get picture completion notification.

5.17.2.4 uint32_t NV_ENC_INITIALIZE_PARAMS::enableExternalMEHints

[in]: Set to 1 to enable external ME hints for the current frame. For NV_ENC_INITIALIZE_PARAMS::enablePTD=1 with B frames, programming L1 hints is optional for B frames since Client doesn't know internal GOP structure. NV_ENC_PIC_PARAMS::meHintRefPicDist should preferably be set with enablePTD=1.

5.17.2.5 uint32_t NV_ENC_INITIALIZE_PARAMS::enableMEOnlyMode

[in]: Set to 1 to enable ME Only Mode.

5.17.2.6 uint32 t NV ENC INITIALIZE PARAMS::enablePTD

[in]: Set this to 1 to enable the Picture Type Decision is be taken by the NvEncodeAPI interface.

5.17.2.7 uint32_t NV_ENC_INITIALIZE_PARAMS::enableSubFrameWrite

[in]: Set this to 1 to write out available bitstream to memory at subframe intervals

5.17.2.8 NV_ENC_CONFIG* NV_ENC_INITIALIZE_PARAMS::encodeConfig

[in]: Specifies the advanced codec specific structure. If client has sent a valid codec config structure, it will override parameters set by the NV_ENC_INITIALIZE_PARAMS::presetGUID parameter. If set to NULL the NvEncodeAPI interface will use the NV_ENC_INITIALIZE_PARAMS::presetGUID to set the codec specific parameters. Client can also optionally query the NvEncodeAPI interface to get codec specific parameters for a presetGUID using NvEncGetEncodePresetConfig() API. It can then modify (if required) some of the codec config parameters and send down a custom config structure as part of _NV_ENC_INITIALIZE_PARAMS. Even in this case client is recommended to pass the same preset guid it has used in NvEncGetEncodePresetConfig() API to query the config structure; as NV_ENC_INITIALIZE_PARAMS::presetGUID. This will not override the custom config structure but will be used to determine other Encoder HW specific parameters not exposed in the API.

5.17.2.9 GUID NV_ENC_INITIALIZE_PARAMS::encodeGUID

[in]: Specifies the Encode GUID for which the encoder is being created. NvEncInitializeEncoder() API will fail if this is not set, or set to unsupported value.

5.17.2.10 uint32_t NV_ENC_INITIALIZE_PARAMS::encodeHeight

[in]: Specifies the encode height. If not set NvEncInitializeEncoder() API will fail.

5.17.2.11 uint32_t NV_ENC_INITIALIZE_PARAMS::encodeWidth

[in]: Specifies the encode width. If not set NvEncInitializeEncoder() API will fail.

5.17.2.12 uint32 t NV ENC INITIALIZE PARAMS::frameRateDen

[in]: Specifies the denominator for frame rate used for encoding in frames per second (Frame rate = frameRateNum / frameRateDen).

5.17.2.13 uint32 t NV ENC INITIALIZE PARAMS::frameRateNum

[in]: Specifies the numerator for frame rate used for encoding in frames per second (Frame rate = frameRateNum / frameRateDen).

5.17.2.14 uint32_t NV_ENC_INITIALIZE_PARAMS::maxEncodeHeight

[in]: Maximum encode height to be allowed for current Encode session. Client should allocate output buffers according to this dimension for dynamic resolution change. If set to 0, Encode will not allow dynamic resolution change.

5.17.2.15 uint32_t NV_ENC_INITIALIZE_PARAMS::maxEncodeWidth

[in]: Maximum encode width to be used for current Encode session. Client should allocate output buffers according to this dimension for dynamic resolution change. If set to 0, Encoder will not allow dynamic resolution change.

5.17.2.16 NVENC_EXTERNAL_ME_HINT_COUNTS_PER_BLOCKTYPE NV_ENC_INITIALIZE_-PARAMS::maxMEHintCountsPerBlock[2]

[in]: If Client wants to pass external motion vectors in NV_ENC_PIC_PARAMS::meExternalHints buffer it must specify the maximum number of hint candidates per block per direction for the encode session. The NV_ENC_INITIALIZE_PARAMS::maxMEHintCountsPerBlock[0] is for L0 predictors and NV_ENC_INITIALIZE_PARAMS::maxMEHintCountsPerBlock[1] is for L1 predictors. This client must also set NV_ENC_INITIALIZE_PARAMS::enableExternalMEHints to 1.

5.17.2.17 GUID NV_ENC_INITIALIZE_PARAMS::presetGUID

[in]: Specifies the preset for encoding. If the preset GUID is set then , the preset configuration will be applied before any other parameter.

5.17.2.18 void* NV_ENC_INITIALIZE_PARAMS::privData

[in]: Reserved private data buffer and must be set to NULL

5.17.2.19 uint32_t NV_ENC_INITIALIZE_PARAMS::privDataSize

[in]: Reserved private data buffer size and must be set to 0

5.17.2.20 uint32_t NV_ENC_INITIALIZE_PARAMS::reportSliceOffsets

[in]: Set this to 1 to enable reporting slice offsets in _NV_ENC_LOCK_BITSTREAM. NV_ENC_INITIALIZE_-PARAMS::enableEncodeAsync must be set to 0 to use this feature. Client must set this to 0 if NV_ENC_CONFIG_-H264::sliceMode is 1 on Kepler GPUs

5.17.2.21 uint32 t NV ENC INITIALIZE PARAMS::reserved[289]

[in]: Reserved and must be set to 0

5.17.2.22 void* NV_ENC_INITIALIZE_PARAMS::reserved2[64]

[in]: Reserved and must be set to NULL

$5.17.2.23 \quad uint 32_t \ NV_ENC_INITIALIZE_PARAMS:: reserved Bit Fields$

[in]: Reserved bitfields and must be set to 0

5.17.2.24 uint32_t NV_ENC_INITIALIZE_PARAMS::version

[in]: Struct version. Must be set to NV_ENC_INITIALIZE_PARAMS_VER.

5.18 NV_ENC_LOCK_BITSTREAM Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32 t version
- uint32_t doNotWait:1
- uint32 t ltrFrame:1
- uint32_t reservedBitFields:30
- void * outputBitstream
- uint32_t * sliceOffsets
- uint32_t frameIdx
- uint32 t hwEncodeStatus
- uint32_t numSlices
- uint32_t bitstreamSizeInBytes
- uint64 t outputTimeStamp
- uint64_t outputDuration
- void * bitstreamBufferPtr
- NV_ENC_PIC_TYPE pictureType
- NV_ENC_PIC_STRUCT pictureStruct
- uint32_t frameAvgQP
- uint32_t frameSatd
- uint32_t ltrFrameIdx
- uint32_t ltrFrameBitmap
- uint32_t reserved [236]
- void * reserved2 [64]

5.18.1 Detailed Description

Bitstream buffer lock parameters.

5.18.2 Field Documentation

5.18.2.1 void* NV_ENC_LOCK_BITSTREAM::bitstreamBufferPtr

[out]: Pointer to the generated output bitstream. For MEOnly mode _NV_ENC_LOCK_-BITSTREAM::bitstreamBufferPtr should be typecast to NV_ENC_H264_MV_DATA/NV_ENC_HEVC_MV_DATA pointer respectively for H264/HEVC

5.18.2.2 uint32_t NV_ENC_LOCK_BITSTREAM::bitstreamSizeInBytes

[out]: Actual number of bytes generated and copied to the memory pointed by bitstreamBufferPtr.

5.18.2.3 uint32_t NV_ENC_LOCK_BITSTREAM::doNotWait

[in]: If this flag is set, the NvEncodeAPI interface will return buffer pointer even if operation is not completed. If not set, the call will block until operation completes.

5.18.2.4 uint32_t NV_ENC_LOCK_BITSTREAM::frameAvgQP

[out]: Average QP of the frame.

5.18.2.5 uint32_t NV_ENC_LOCK_BITSTREAM::frameIdx

[out]: Frame no. for which the bitstream is being retrieved.

5.18.2.6 uint32_t NV_ENC_LOCK_BITSTREAM::frameSatd

[out]: Total SATD cost for whole frame.

5.18.2.7 uint32_t NV_ENC_LOCK_BITSTREAM::hwEncodeStatus

[out]: The NvEncodeAPI interface status for the locked picture.

5.18.2.8 uint32_t NV_ENC_LOCK_BITSTREAM::ltrFrame

[out]: Flag indicating this frame is marked as LTR frame

5.18.2.9 uint32_t NV_ENC_LOCK_BITSTREAM::ltrFrameBitmap

[out]: Bitmap of LTR frames indices which were used for encoding this frame. Value of 0 if no LTR frames were used.

5.18.2.10 uint32_t NV_ENC_LOCK_BITSTREAM::ltrFrameIdx

[out]: Frame index associated with this LTR frame.

5.18.2.11 uint32_t NV_ENC_LOCK_BITSTREAM::numSlices

[out]: Number of slices in the encoded picture. Will be reported only if NV_ENC_INITIALIZE_-PARAMS::reportSliceOffsets set to 1.

5.18.2.12 void* NV_ENC_LOCK_BITSTREAM::outputBitstream

[in]: Pointer to the bitstream buffer being locked.

5.18.2.13 uint64_t NV_ENC_LOCK_BITSTREAM::outputDuration

[out]: Presentation duration associates with the encoded output.

5.18.2.14 uint64_t NV_ENC_LOCK_BITSTREAM::outputTimeStamp

[out]: Presentation timestamp associated with the encoded output.

5.18.2.15 NV_ENC_PIC_STRUCT NV_ENC_LOCK_BITSTREAM::pictureStruct

[out]: Structure of the generated output picture.

5.18.2.16 NV_ENC_PIC_TYPE NV_ENC_LOCK_BITSTREAM::pictureType

[out]: Picture type of the encoded picture.

5.18.2.17 uint32_t NV_ENC_LOCK_BITSTREAM::reserved[236]

[in]: Reserved and must be set to 0

5.18.2.18 void* NV_ENC_LOCK_BITSTREAM::reserved2[64]

[in]: Reserved and must be set to NULL

5.18.2.19 uint32_t NV_ENC_LOCK_BITSTREAM::reservedBitFields

[in]: Reserved bit fields and must be set to 0

5.18.2.20 uint32_t* NV_ENC_LOCK_BITSTREAM::sliceOffsets

[in,out]: Array which receives the slice offsets. This is not supported if NV_ENC_CONFIG_H264::sliceMode is 1 on Kepler GPUs. Array size must be equal to size of frame in MBs.

5.18.2.21 uint32_t NV_ENC_LOCK_BITSTREAM::version

[in]: Struct version. Must be set to NV_ENC_LOCK_BITSTREAM_VER.

5.19 NV ENC LOCK INPUT BUFFER Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32 t version
- uint32_t doNotWait:1
- uint32 t reservedBitFields:31
- NV_ENC_INPUT_PTR inputBuffer
- void * bufferDataPtr
- uint32_t pitch
- uint32_t reserved1 [251]
- void * reserved2 [64]

5.19.1 Detailed Description

Uncompressed Input Buffer lock parameters.

5.19.2 Field Documentation

5.19.2.1 void* NV_ENC_LOCK_INPUT_BUFFER::bufferDataPtr

[out]: Pointed to the locked input buffer data. Client can only access input buffer using the bufferDataPtr.

5.19.2.2 uint32_t NV_ENC_LOCK_INPUT_BUFFER::doNotWait

[in]: Set to 1 to make NvEncLockInputBuffer() a unblocking call. If the encoding is not completed, driver will return NV ENC ERR ENCODER BUSY error code.

5.19.2.3 NV ENC INPUT PTR NV ENC LOCK INPUT BUFFER::inputBuffer

[in]: Pointer to the input buffer to be locked, client should pass the pointer obtained from NvEncCreateInputBuffer() or NvEncMapInputResource API.

5.19.2.4 uint32_t NV_ENC_LOCK_INPUT_BUFFER::pitch

[out]: Pitch of the locked input buffer.

5.19.2.5 uint32_t NV_ENC_LOCK_INPUT_BUFFER::reserved1[251]

[in]: Reserved and must be set to 0

5.19.2.6 void* NV ENC LOCK INPUT BUFFER::reserved2[64]

[in]: Reserved and must be set to NULL

5.19.2.7 uint32_t NV_ENC_LOCK_INPUT_BUFFER::reservedBitFields

[in]: Reserved bitfields and must be set to 0

5.19.2.8 uint32_t NV_ENC_LOCK_INPUT_BUFFER::version

[in]: Struct version. Must be set to NV_ENC_LOCK_INPUT_BUFFER_VER.

5.20 NV_ENC_MAP_INPUT_RESOURCE Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32 t version
- uint32_t subResourceIndex
- void * inputResource
- NV_ENC_REGISTERED_PTR registeredResource
- NV_ENC_INPUT_PTR mappedResource
- NV_ENC_BUFFER_FORMAT mappedBufferFmt
- uint32_t reserved1 [251]
- void * reserved2 [63]

5.20.1 Detailed Description

Map an input resource to a Nvidia Encoder Input Buffer

5.20.2 Field Documentation

5.20.2.1 void* NV_ENC_MAP_INPUT_RESOURCE::inputResource

[in]: Deprecated. Do not use.

5.20.2.2 NV_ENC_BUFFER_FORMAT NV_ENC_MAP_INPUT_RESOURCE::mappedBufferFmt

[out]: Buffer format of the outputResource. This buffer format must be used in NV_ENC_PIC_PARAMS::bufferFmt if client using the above mapped resource pointer.

5.20.2.3 NV ENC INPUT PTR NV ENC MAP INPUT RESOURCE::mappedResource

[out]: Mapped pointer corresponding to the registeredResource. This pointer must be used in NV_ENC_PIC_-PARAMS::inputBuffer parameter in NvEncEncodePicture() API.

5.20.2.4 NV_ENC_REGISTERED_PTR NV_ENC_MAP_INPUT_RESOURCE::registeredResource

[in]: The Registered resource handle obtained by calling NvEncRegisterInputResource.

5.20.2.5 uint32_t NV_ENC_MAP_INPUT_RESOURCE::reserved1[251]

[in]: Reserved and must be set to 0.

5.20.2.6 void* NV ENC MAP INPUT RESOURCE::reserved2[63]

[in]: Reserved and must be set to NULL

5.20.2.7 uint32_t NV_ENC_MAP_INPUT_RESOURCE::subResourceIndex

[in]: Deprecated. Do not use.

5.20.2.8 uint32_t NV_ENC_MAP_INPUT_RESOURCE::version

[in]: Struct version. Must be set to NV_ENC_MAP_INPUT_RESOURCE_VER.

5.21 NV_ENC_MEONLY_PARAMS Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32 t version
- uint32_t inputWidth
- uint32_t inputHeight
- NV_ENC_INPUT_PTR inputBuffer
- NV_ENC_INPUT_PTR referenceFrame
- NV_ENC_OUTPUT_PTR mvBuffer
- NV_ENC_BUFFER_FORMAT bufferFmt
- void * completionEvent
- uint32_t viewID
- uint32_t reserved1 [251]
- void * reserved2 [60]

5.21.1 Detailed Description

MEOnly parameters that need to be sent on a per motion estimation basis.

5.21.2 Field Documentation

5.21.2.1 NV_ENC_BUFFER_FORMAT NV_ENC_MEONLY_PARAMS::bufferFmt

[in]: Specifies the input buffer format.

5.21.2.2 void* NV_ENC_MEONLY_PARAMS::completionEvent

[in]: Specifies an event to be signalled on completion of motion estimation of this Frame [only if operating in Asynchronous mode]. Each output buffer should be associated with a distinct event pointer.

5.21.2.3 NV_ENC_INPUT_PTR NV_ENC_MEONLY_PARAMS::inputBuffer

[in]: Specifies the input buffer pointer. Client must use a pointer obtained from NvEncCreateInputBuffer() or NvEncMapInputResource() APIs.

5.21.2.4 uint32_t NV_ENC_MEONLY_PARAMS::inputHeight

[in]: Specifies the input buffer height

5.21.2.5 uint32_t NV_ENC_MEONLY_PARAMS::inputWidth

[in]: Specifies the input buffer width

5.21.2.6 NV_ENC_OUTPUT_PTR NV_ENC_MEONLY_PARAMS::mvBuffer

[in]: Specifies the pointer to motion vector data buffer allocated by NvEncCreateMVBuffer. Client must lock mvBuffer using NvEncLockBitstream() API to get the motion vector data.

5.21.2.7 NV_ENC_INPUT_PTR NV_ENC_MEONLY_PARAMS::referenceFrame

[in]: Specifies the reference frame pointer

5.21.2.8 uint32_t NV_ENC_MEONLY_PARAMS::reserved1[251]

[in]: Reserved and must be set to 0

5.21.2.9 void* NV_ENC_MEONLY_PARAMS::reserved2[60]

[in]: Reserved and must be set to NULL

5.21.2.10 uint32_t NV_ENC_MEONLY_PARAMS::version

[in]: Struct version. Must be set to NV_ENC_MEONLY_PARAMS_VER.

5.21.2.11 uint32_t NV_ENC_MEONLY_PARAMS::viewID

[in]: Specifies left,right viewID if NV_ENC_CONFIG_H264_MEONLY::bStereoEnable is set. viewID can be 0,1 if bStereoEnable is set, 0 otherwise.

5.22 NV_ENC_MVECTOR Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- int16_t mvx
- int16_t mvy

5.22.1 Detailed Description

Structs needed for ME only mode.

5.22.2 Field Documentation

5.22.2.1 int16_t NV_ENC_MVECTOR::mvx

the x component of MV in qpel units

5.22.2.2 int16_t NV_ENC_MVECTOR::mvy

the y component of MV in qpel units

5.23 NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t version
- NV_ENC_DEVICE_TYPE deviceType
- void * device
- void * reserved
- uint32_t apiVersion
- uint32_t reserved1 [253]
- void * reserved2 [64]

5.23.1 Detailed Description

Encoder Session Creation parameters

5.23.2 Field Documentation

5.23.2.1 uint32_t NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS::apiVersion

[in]: API version. Should be set to NVENCAPI_VERSION.

5.23.2.2 void* NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS::device

[in]: Pointer to client device.

5.23.2.3 NV_ENC_DEVICE_TYPE NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS::deviceType

[in]: Specified the device Type

$\textbf{5.23.2.4} \quad void*\ NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS:: reserved$

[in]: Reserved and must be set to 0.

5.23.2.5 uint32_t NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS::reserved1[253]

[in]: Reserved and must be set to 0

5.23.2.6 void* NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS::reserved2[64]

[in]: Reserved and must be set to NULL

5.23.2.7 uint32_t NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS::version

[in]: Struct version. Must be set to NV_ENC_OPEN_ENCODE_SESSION_EX_PARAMS_VER.

5.24 NV ENC PIC PARAMS Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32 t version
- uint32_t inputWidth
- uint32 t inputHeight
- uint32_t inputPitch
- uint32_t encodePicFlags
- uint32_t frameIdx
- uint64_t inputTimeStamp
- uint64_t inputDuration
- NV_ENC_INPUT_PTR inputBuffer
- NV_ENC_OUTPUT_PTR outputBitstream
- void * completionEvent
- NV_ENC_BUFFER_FORMAT bufferFmt
- NV_ENC_PIC_STRUCT pictureStruct
- NV_ENC_PIC_TYPE pictureType
- NV_ENC_CODEC_PIC_PARAMS codecPicParams
- NVENC_EXTERNAL_ME_HINT_COUNTS_PER_BLOCKTYPE meHintCountsPerBlock [2]
- NVENC_EXTERNAL_ME_HINT * meExternalHints
- uint32_t reserved1 [6]
- void * reserved2 [2]
- int8_t * qpDeltaMap
- uint32_t qpDeltaMapSize
- uint32_t reservedBitFields
- uint16_t meHintRefPicDist [2]
- uint32_t reserved3 [286]
- void * reserved4 [60]

5.24.1 Detailed Description

Encoding parameters that need to be sent on a per frame basis.

5.24.2 Field Documentation

5.24.2.1 NV ENC BUFFER FORMAT NV ENC PIC PARAMS::bufferFmt

[in]: Specifies the input buffer format.

5.24.2.2 NV_ENC_CODEC_PIC_PARAMS NV_ENC_PIC_PARAMS::codecPicParams

[in]: Specifies the codec specific per-picture encoding parameters.

5.24.2.3 void* NV_ENC_PIC_PARAMS::completionEvent

[in]: Specifies an event to be signalled on completion of encoding of this Frame [only if operating in Asynchronous mode]. Each output buffer should be associated with a distinct event pointer.

5.24.2.4 uint32_t NV_ENC_PIC_PARAMS::encodePicFlags

[in]: Specifies bit-wise OR'ed encode pic flags. See NV ENC PIC FLAGS enum.

5.24.2.5 uint32_t NV_ENC_PIC_PARAMS::frameIdx

[in]: Specifies the frame index associated with the input frame [optional].

5.24.2.6 NV_ENC_INPUT_PTR NV_ENC_PIC_PARAMS::inputBuffer

[in]: Specifies the input buffer pointer. Client must use a pointer obtained from NvEncCreateInputBuffer() or NvEncMapInputResource() APIs.

5.24.2.7 uint64_t NV_ENC_PIC_PARAMS::inputDuration

[in]: Specifies duration of the input picture

5.24.2.8 uint32_t NV_ENC_PIC_PARAMS::inputHeight

[in]: Specifies the input buffer height

5.24.2.9 uint32_t NV_ENC_PIC_PARAMS::inputPitch

[in]: Specifies the input buffer pitch. If pitch value is not known, set this to inputWidth.

5.24.2.10 uint64 t NV ENC PIC PARAMS::inputTimeStamp

[in]: Specifies presentation timestamp associated with the input picture.

5.24.2.11 uint32_t NV_ENC_PIC_PARAMS::inputWidth

[in]: Specifies the input buffer width

$\textbf{5.24.2.12} \quad NVENC_EXTERNAL_ME_HINT* \\ NV_ENC_PIC_PARAMS::meExternalHints$

[in]: Specifies the pointer to ME external hints for the current frame. The size of ME hint buffer should be equal to number of macroblocks multiplied by the total number of candidates per macroblock. The total number of candidates per MB per direction = 1*meHintCountsPerBlock[Lx].numCandsPerBlk16x16 + 2*meHintCountsPerBlock[Lx].numCandsPerBlk16x8 + 2*meHintCountsPerBlock[Lx].numCandsPerBlk8x8 + 4*meHintCountsPerBlock[Lx].numCandsPerBlk8x8. For frames using bidirectional ME, the total number of candidates for single macroblock is sum of total number of candidates per MB for each direction (L0 and L1)

5.24.2.13 NVENC_EXTERNAL_ME_HINT_COUNTS_PER_BLOCKTYPE NV_ENC_PIC_-PARAMS::meHintCountsPerBlock[2]

[in]: Specifies the number of hint candidates per block per direction for the current frame. meHintCountsPerBlock[0] is for L0 predictors and meHintCountsPerBlock[1] is for L1 predictors. The candidate count in NV_ENC_PIC_PARAMS::meHintCountsPerBlock[1x] must never exceed NV_ENC_INITIALIZE_PARAMS::maxMEHintCountsPerBlock[1x] provided during encoder intialization.

5.24.2.14 uint16_t NV_ENC_PIC_PARAMS::meHintRefPicDist[2]

[in]: Specifies temporal distance for reference picture (NVENC_EXTERNAL_ME_HINT::refidx = 0) used during external ME with NV_ENC_INITALIZE_PARAMS::enablePTD = 1 . meHintRefPicDist[0] is for L0 hints and meHintRefPicDist[1] is for L1 hints. If not set, will internally infer distance of 1. Ignored for NV_ENC_INITALIZE_PARAMS::enablePTD = 0

5.24.2.15 NV_ENC_OUTPUT_PTR NV_ENC_PIC_PARAMS::outputBitstream

[in]: Specifies the pointer to output buffer. Client should use a pointer obtained from NvEncCreateBitstreamBuffer() API.

5.24.2.16 NV_ENC_PIC_STRUCT NV_ENC_PIC_PARAMS::pictureStruct

[in]: Specifies structure of the input picture.

5.24.2.17 NV_ENC_PIC_TYPE NV_ENC_PIC_PARAMS::pictureType

[in]: Specifies input picture type. Client required to be set explicitly by the client if the client has not set NV_ENC_-INITALIZE PARAMS::enablePTD to 1 while calling NvInitializeEncoder.

5.24.2.18 int8_t* NV_ENC_PIC_PARAMS::qpDeltaMap

[in]: Specifies the pointer to signed byte array containing QP delta value per MB in raster scan order in the current picture. This QP modifier is applied on top of the QP chosen by rate control.

5.24.2.19 uint32_t NV_ENC_PIC_PARAMS::qpDeltaMapSize

[in]: Specifies the size in bytes of qpDeltaMap surface allocated by client and pointed to by NV_ENC_PIC_-PARAMS::qpDeltaMap. Surface (array) should be picWidthInMbs * picHeightInMbs

5.24.2.20 uint32_t NV_ENC_PIC_PARAMS::reserved1[6]

[in]: Reserved and must be set to 0

5.24.2.21 void* NV ENC PIC PARAMS::reserved2[2]

[in]: Reserved and must be set to NULL

5.24.2.22 uint32_t NV_ENC_PIC_PARAMS::reserved3[286]

[in]: Reserved and must be set to 0

5.24.2.23 void* NV_ENC_PIC_PARAMS::reserved4[60]

[in]: Reserved and must be set to NULL

5.24.2.24 uint32_t NV_ENC_PIC_PARAMS::reservedBitFields

[in]: Reserved bitfields and must be set to 0

5.24.2.25 uint32_t NV_ENC_PIC_PARAMS::version

[in]: Struct version. Must be set to NV_ENC_PIC_PARAMS_VER.

5.25 NV ENC PIC PARAMS H264 Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t displayPOCSyntax
- uint32_t reserved3
- uint32 t refPicFlag
- uint32_t colourPlaneId
- uint32_t forceIntraRefreshWithFrameCnt
- uint32_t constrainedFrame:1
- uint32_t sliceModeDataUpdate:1
- uint32_t ltrMarkFrame:1
- uint32_t ltrUseFrames:1
- uint32_t reservedBitFields:28
- uint8_t * sliceTypeData
- uint32_t sliceTypeArrayCnt
- uint32_t seiPayloadArrayCnt
- NV ENC SEI PAYLOAD * seiPayloadArray
- uint32_t sliceMode
- uint32_t sliceModeData
- uint32_t ltrMarkFrameIdx
- uint32_t ltrUseFrameBitmap
- uint32_t ltrUsageMode
- uint32_t reserved [243]
- void * reserved2 [62]

5.25.1 Detailed Description

H264 specific enc pic params. sent on a per frame basis.

5.25.2 Field Documentation

5.25.2.1 uint32_t NV_ENC_PIC_PARAMS_H264::colourPlaneId

[in]: Specifies the colour plane ID associated with the current input.

5.25.2.2 uint32_t NV_ENC_PIC_PARAMS_H264::constrainedFrame

[in]: Set to 1 if client wants to encode this frame with each slice completely independent of other slices in the frame. NV_ENC_INITIALIZE_PARAMS::enableConstrainedEncoding should be set to 1

5.25.2.3 uint32_t NV_ENC_PIC_PARAMS_H264::displayPOCSyntax

[in]: Specifies the display POC syntax This is required to be set if client is handling the picture type decision.

5.25.2.4 uint32_t NV_ENC_PIC_PARAMS_H264::forceIntraRefreshWithFrameCnt

[in]: Forces an intra refresh with duration equal to intraRefreshFrameCnt. When outputRecoveryPointSEI is set this is value is used for recovery_frame_cnt in recovery point SEI message forceIntraRefreshWithFrameCnt cannot be used if B frames are used in the GOP structure specified

5.25.2.5 uint32_t NV_ENC_PIC_PARAMS_H264::ltrMarkFrame

[in]: Set to 1 if client wants to mark this frame as LTR

5.25.2.6 uint32_t NV_ENC_PIC_PARAMS_H264::ltrMarkFrameIdx

[in]: Specifies the long term referenceframe index to use for marking this frame as LTR.

5.25.2.7 uint32_t NV_ENC_PIC_PARAMS_H264::ltrUsageMode

[in]: Specifies additional usage constraints for encoding using LTR frames from this point further. 0: no constraints, 1: no short term refs older than current, no previous LTR frames.

5.25.2.8 uint32_t NV_ENC_PIC_PARAMS_H264::ltrUseFrameBitmap

[in]: Specifies the the associated bitmap of LTR frame indices when encoding this frame.

5.25.2.9 uint32 t NV ENC PIC PARAMS H264::ltrUseFrames

[in]: Set to 1 if client allows encoding this frame using the LTR frames specified in ltrFrameBitmap

5.25.2.10 uint32_t NV_ENC_PIC_PARAMS_H264::refPicFlag

[in]: Set to 1 for a reference picture. This is ignored if NV_ENC_INITIALIZE_PARAMS::enablePTD is set to 1.

5.25.2.11 uint32_t NV_ENC_PIC_PARAMS_H264::reserved[243]

[in]: Reserved and must be set to 0.

5.25.2.12 void* NV_ENC_PIC_PARAMS_H264::reserved2[62]

[in]: Reserved and must be set to NULL.

5.25.2.13 uint32_t NV_ENC_PIC_PARAMS_H264::reserved3

[in]: Reserved and must be set to 0

5.25.2.14 uint32_t NV_ENC_PIC_PARAMS_H264::reservedBitFields

[in]: Reserved bit fields and must be set to 0

5.25,2.15 NV_ENC_SEI_PAYLOAD* NV_ENC_PIC_PARAMS_H264::seiPayloadArray

[in]: Array of SEI payloads which will be inserted for this frame.

5.25.2.16 uint32_t NV_ENC_PIC_PARAMS_H264::seiPayloadArrayCnt

[in]: Specifies the number of elements allocated in seiPayloadArray array.

5.25.2.17 uint32_t NV_ENC_PIC_PARAMS_H264::sliceMode

[in]: This parameter in conjunction with sliceModeData specifies the way in which the picture is divided into slices sliceMode = 0 MB based slices, sliceMode = 1 Byte based slices, sliceMode = 2 MB row based slices, sliceMode = 3, numSlices in Picture When forceIntraRefreshWithFrameCnt is set it will have priority over sliceMode setting When sliceMode == 0 and sliceModeData == 0 whole picture will be coded with one slice

5.25.2.18 uint32_t NV_ENC_PIC_PARAMS_H264::sliceModeData

[in]: Specifies the parameter needed for sliceMode. For: sliceMode = 0, sliceModeData specifies # of MBs in each slice (except last slice) sliceMode = 1, sliceModeData specifies maximum # of bytes in each slice (except last slice) sliceModeData specifies # of MB rows in each slice (except last slice) sliceMode = 3, sliceModeData specifies number of slices in the picture. Driver will divide picture into slices optimally

5.25.2.19 uint32_t NV_ENC_PIC_PARAMS_H264::sliceModeDataUpdate

[in]: Set to 1 if client wants to change the sliceModeData field to specify new sliceSize Parameter When forceIntraRefreshWithFrameCnt is set it will have priority over sliceMode setting

5.25.2.20 uint32_t NV_ENC_PIC_PARAMS_H264::sliceTypeArrayCnt

[in]: Deprecated.

5.25.2.21 uint8 t* NV ENC PIC PARAMS H264::sliceTypeData

[in]: Deprecated.

5.26 NV_ENC_PIC_PARAMS_HEVC Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t displayPOCSyntax
- uint32_t refPicFlag
- uint32 t temporalId
- uint32_t forceIntraRefreshWithFrameCnt
- uint32_t constrainedFrame:1
- uint32_t sliceModeDataUpdate:1
- uint32_t ltrMarkFrame:1
- uint32 t ltrUseFrames:1
- uint32_t reservedBitFields:28
- uint8_t * sliceTypeData
- uint32_t sliceTypeArrayCnt
- uint32_t sliceMode
- uint32_t sliceModeData
- uint32 t ltrMarkFrameIdx
- uint32_t ltrUseFrameBitmap
- uint32_t ltrUsageMode
- uint32_t seiPayloadArrayCnt
- uint32_t reserved
- NV_ENC_SEI_PAYLOAD * seiPayloadArray
- uint32_t reserved2 [244]
- void * reserved3 [61]

5.26.1 Detailed Description

HEVC specific enc pic params. sent on a per frame basis.

5.26.2 Field Documentation

5.26.2.1 uint32_t NV_ENC_PIC_PARAMS_HEVC::constrainedFrame

[in]: Set to 1 if client wants to encode this frame with each slice completely independent of other slices in the frame. NV_ENC_INITIALIZE_PARAMS::enableConstrainedEncoding should be set to 1

5.26.2.2 uint32_t NV_ENC_PIC_PARAMS_HEVC::displayPOCSyntax

[in]: Specifies the display POC syntax This is required to be set if client is handling the picture type decision.

5.26.2.3 uint32_t NV_ENC_PIC_PARAMS_HEVC::forceIntraRefreshWithFrameCnt

[in]: Forces an intra refresh with duration equal to intraRefreshFrameCnt. When outputRecoveryPointSEI is set this is value is used for recovery_frame_cnt in recovery point SEI message forceIntraRefreshWithFrameCnt cannot be used if B frames are used in the GOP structure specified

5.26.2.4 uint32_t NV_ENC_PIC_PARAMS_HEVC::ltrMarkFrame

[in]: Set to 1 if client wants to mark this frame as LTR

5.26.2.5 uint32_t NV_ENC_PIC_PARAMS_HEVC::ltrMarkFrameIdx

[in]: Specifies the long term reference frame index to use for marking this frame as LTR.

5.26.2.6 uint32_t NV_ENC_PIC_PARAMS_HEVC::ltrUsageMode

[in]: Specifies additional usage constraints for encoding using LTR frames from this point further. 0: no constraints, 1: no short term refs older than current, no previous LTR frames.

5.26.2.7 uint32_t NV_ENC_PIC_PARAMS_HEVC::ltrUseFrameBitmap

[in]: Specifies the associated bitmap of LTR frame indices when encoding this frame.

5.26.2.8 uint32_t NV_ENC_PIC_PARAMS_HEVC::ltrUseFrames

[in]: Set to 1 if client allows encoding this frame using the LTR frames specified in ltrFrameBitmap

5.26.2.9 uint32_t NV_ENC_PIC_PARAMS_HEVC::refPicFlag

[in]: Set to 1 for a reference picture. This is ignored if NV_ENC_INITIALIZE_PARAMS::enablePTD is set to 1.

5.26.2.10 uint32_t NV_ENC_PIC_PARAMS_HEVC::reserved

[in]: Reserved and must be set to 0.

5.26.2.11 uint32_t NV_ENC_PIC_PARAMS_HEVC::reserved2[244]

[in]: Reserved and must be set to 0.

5.26.2.12 void* NV_ENC_PIC_PARAMS_HEVC::reserved3[61]

[in]: Reserved and must be set to NULL.

5.26.2.13 uint32_t NV_ENC_PIC_PARAMS_HEVC::reservedBitFields

[in]: Reserved bit fields and must be set to 0

5.26.2.14 NV ENC SEI PAYLOAD* NV ENC PIC PARAMS HEVC::seiPayloadArray

[in]: Array of SEI payloads which will be inserted for this frame.

5.26.2.15 uint32_t NV_ENC_PIC_PARAMS_HEVC::seiPayloadArrayCnt

[in]: Specifies the number of elements allocated in seiPayloadArray array.

5.26.2.16 uint32_t NV_ENC_PIC_PARAMS_HEVC::sliceMode

[in]: This parameter in conjunction with sliceModeData specifies the way in which the picture is divided into slices sliceMode = 0 CTU based slices, sliceMode = 1 Byte based slices, sliceMode = 2 CTU row based slices, sliceMode = 3, numSlices in Picture When forceIntraRefreshWithFrameCnt is set it will have priority over sliceMode setting When sliceMode == 0 and sliceModeData == 0 whole picture will be coded with one slice

5.26.2.17 uint32_t NV_ENC_PIC_PARAMS_HEVC::sliceModeData

[in]: Specifies the parameter needed for sliceMode. For: sliceMode = 0, sliceModeData specifies # of CTUs in each slice (except last slice) sliceMode = 1, sliceModeData specifies maximum # of bytes in each slice (except last slice) sliceMode = 2, sliceModeData specifies # of CTU rows in each slice (except last slice) sliceMode = 3, sliceModeData specifies number of slices in the picture. Driver will divide picture into slices optimally

5.26.2.18 uint32_t NV_ENC_PIC_PARAMS_HEVC::sliceModeDataUpdate

[in]: Set to 1 if client wants to change the sliceModeData field to specify new sliceSize Parameter When forceIntraRefreshWithFrameCnt is set it will have priority over sliceMode setting

5.26.2.19 uint32_t NV_ENC_PIC_PARAMS_HEVC::sliceTypeArrayCnt

[in]: Client should set this to the number of elements allocated in sliceTypeData array. If sliceTypeData is NULL then this should be set to 0

5.26.2.20 uint8_t* NV_ENC_PIC_PARAMS_HEVC::sliceTypeData

[in]: Array which specifies the slice type used to force intra slice for a particular slice. Currently supported only for NV_ENC_CONFIG_H264::sliceMode == 3. Client should allocate array of size sliceModeData where sliceModeData is specified in field of _NV_ENC_CONFIG_H264 Array element with index n corresponds to nth slice. To force a particular slice to intra client should set corresponding array element to NV_ENC_SLICE_TYPE_I all other array elements should be set to NV_ENC_SLICE_TYPE_DEFAULT

5.26.2.21 uint32_t NV_ENC_PIC_PARAMS_HEVC::temporalId

[in]: Specifies the temporal id of the picture

5.27 NV_ENC_PRESET_CONFIG Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t version
- NV_ENC_CONFIG presetCfg
- uint32_t reserved1 [255]
- void * reserved2 [64]

5.27.1 Detailed Description

Encoder preset config

5.27.2 Field Documentation

5.27.2.1 NV_ENC_CONFIG NV_ENC_PRESET_CONFIG::presetCfg

[out]: preset config returned by the Nvidia Video Encoder interface.

5.27.2.2 uint32_t NV_ENC_PRESET_CONFIG::reserved1[255]

[in]: Reserved and must be set to 0

5.27.2.3 void* NV_ENC_PRESET_CONFIG::reserved2[64]

[in]: Reserved and must be set to NULL

5.27.2.4 uint32_t NV_ENC_PRESET_CONFIG::version

[in]: Struct version. Must be set to NV_ENC_PRESET_CONFIG_VER.

5.28 NV_ENC_QP Struct Reference

#include <nvEncodeAPI.h>

5.28.1 Detailed Description

QP value for frames

5.29 NV_ENC_RC_PARAMS Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- NV_ENC_PARAMS_RC_MODE rateControlMode
- NV_ENC_QP constQP
- uint32_t averageBitRate
- uint32_t maxBitRate
- uint32_t vbvBufferSize
- uint32_t vbvInitialDelay
- uint32 t enableMinQP:1
- uint32_t enableMaxQP:1
- uint32 t enableInitialRCQP:1
- uint32_t enableAQ:1
- uint32_t enableExtQPDeltaMap:1
- uint32_t enableLookahead:1
- uint32_t disableIadapt:1
- uint32_t disableBadapt:1
- uint32_t enableTemporalAQ:1
- uint32_t zeroReorderDelay:1
- uint32_t enableNonRefP:1
- uint32_t strictGOPTarget:1
- uint32_t aqStrength:4
- uint32_t reservedBitFields:16
- NV_ENC_QP minQP
- NV_ENC_QP maxQP
- NV_ENC_QP initialRCQP
- uint32_t temporallayerIdxMask
- uint8_t temporalLayerQP [8]
- uint16_t targetQuality
- uint16_t lookaheadDepth

5.29.1 Detailed Description

Rate Control Configuration Paramters

5.29.2 Field Documentation

5.29.2.1 uint32_t NV_ENC_RC_PARAMS::aqStrength

[in]: When AQ (Spatial) is enabled (i.e. NV_ENC_RC_PARAMS::enableAQ is set), this field is used to specify AQ strength. AQ strength scale is from 1 (low) - 15 (aggressive). If not set, strength is autoselected by driver. Currently supported only with h264

5.29.2.2 uint32_t NV_ENC_RC_PARAMS::averageBitRate

[in]: Specifies the average bitrate(in bits/sec) used for encoding.

5.29.2.3 NV_ENC_QP NV_ENC_RC_PARAMS::constQP

[in]: Specifies the initial QP to be used for encoding, these values would be used for all frames if in Constant QP mode.

5.29.2.4 uint32_t NV_ENC_RC_PARAMS::disableBadapt

[in]: Set this to 1 to disable adaptive B-frame decision (only has an effect when lookahead is enabled)

5.29.2.5 uint32_t NV_ENC_RC_PARAMS::disableIadapt

[in]: Set this to 1 to disable adaptive I-frame insertion at scene cuts (only has an effect when lookahead is enabled)

5.29.2.6 uint32_t NV_ENC_RC_PARAMS::enableAQ

[in]: Set this to 1 to enable adaptive quantization (Spatial).

5.29.2.7 uint32_t NV_ENC_RC_PARAMS::enableExtQPDeltaMap

[in]: Set this to 1 to enable additional QP modifier for each MB supplied by client though signed byte array pointed to by NV_ENC_PIC_PARAMS::qpDeltaMap (Not Supported when AQ(Spatial/Temporal) is enabled)

5.29.2.8 uint32_t NV_ENC_RC_PARAMS::enableInitialRCQP

[in]: Set this to 1 if user suppplied initial QP is used for rate control.

5.29.2.9 uint32_t NV_ENC_RC_PARAMS::enableLookahead

[in]: Set this to 1 to enable lookahead with depth <lookaheadDepth> (if lookahead is enabled, input frames must remain available to the encoder until encode completion)

5.29.2.10 uint32_t NV_ENC_RC_PARAMS::enableMaxQP

[in]: Set this to 1 if maximum QP used for rate control.

5.29.2.11 uint32_t NV_ENC_RC_PARAMS::enableMinQP

[in]: Set this to 1 if minimum QP used for rate control.

5.29.2.12 uint32_t NV_ENC_RC_PARAMS::enableNonRefP

[in]: Set this to 1 to enable automatic insertion of non-reference P-frames (no effect if enablePTD=0)

5.29.2.13 uint32_t NV_ENC_RC_PARAMS::enableTemporalAQ

[in]: Set this to 1 to enable temporal AQ for H.264

5.29.2.14 NV_ENC_QP NV_ENC_RC_PARAMS::initialRCQP

[in]: Specifies the initial QP used for rate control. Client must set NV_ENC_CONFIG::enableInitialRCQP to 1.

5.29.2.15 uint16_t NV_ENC_RC_PARAMS::lookaheadDepth

[in]: Maximum depth of lookahead with range 0-32 (only used if enableLookahead=1)

5.29.2.16 uint32_t NV_ENC_RC_PARAMS::maxBitRate

[in]: Specifies the maximum bitrate for the encoded output. This is used for VBR and ignored for CBR mode.

5.29.2.17 NV_ENC_QP NV_ENC_RC_PARAMS::maxQP

[in]: Specifies the maximum QP used for rate control. Client must set NV_ENC_CONFIG::enableMaxQP to 1.

5.29.2.18 NV_ENC_QP NV_ENC_RC_PARAMS::minQP

[in]: Specifies the minimum QP used for rate control. Client must set NV_ENC_CONFIG::enableMinQP to 1.

5.29.2.19 NV_ENC_PARAMS_RC_MODE NV_ENC_RC_PARAMS::rateControlMode

[in]: Specifies the rate control mode. Check support for various rate control modes using NV_ENC_CAPS_-SUPPORTED_RATECONTROL_MODES caps.

5.29.2.20 uint32_t NV_ENC_RC_PARAMS::reservedBitFields

[in]: Reserved bitfields and must be set to 0

5.29.2.21 uint32 t NV ENC RC PARAMS::strictGOPTarget

[in]: Set this to 1 to minimize GOP-to-GOP rate fluctuations

5.29.2.22 uint16_t NV_ENC_RC_PARAMS::targetQuality

[in]: Target CQ (Constant Quality) level for VBR mode (range 0-51 with 0-automatic)

5.29.2.23 uint32_t NV_ENC_RC_PARAMS::temporallayerIdxMask

[in]: Specifies the temporal layers (as a bitmask) whose QPs have changed. Valid max bitmask is [2^NV_ENC_-CAPS_NUM_MAX_TEMPORAL_LAYERS - 1]

5.29.2.24 uint8_t NV_ENC_RC_PARAMS::temporalLayerQP[8]

[in]: Specifies the temporal layer QPs used for rate control. Temporal layer index is used as as the array index

5.29.2.25 uint32_t NV_ENC_RC_PARAMS::vbvBufferSize

[in]: Specifies the VBV(HRD) buffer size. in bits. Set 0 to use the default VBV buffer size.

5.29.2.26 uint32_t NV_ENC_RC_PARAMS::vbvInitialDelay

[in]: Specifies the VBV(HRD) initial delay in bits. Set 0 to use the default VBV initial delay .

5.29.2.27 uint32_t NV_ENC_RC_PARAMS::zeroReorderDelay

[in]: Set this to 1 to indicate zero latency operation (no reordering delay, num_reorder_frames=0)

5.30 NV_ENC_RECONFIGURE_PARAMS Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32 t version
- NV_ENC_INITIALIZE_PARAMS reInitEncodeParams
- uint32 t resetEncoder:1
- uint32_t forceIDR:1

5.30.1 Detailed Description

Encode Session Reconfigured parameters.

5.30.2 Field Documentation

5.30.2.1 uint32_t NV_ENC_RECONFIGURE_PARAMS::forceIDR

[in]: Encode the current picture as an IDR picture. This flag is only valid when Picture type decision is taken by the Encoder [_NV_ENC_INITIALIZE_PARAMS::enablePTD == 1].

5.30.2.2 NV_ENC_INITIALIZE_PARAMS NV_ENC_RECONFIGURE_PARAMS::reInitEncodeParams

[in]: Encoder session re-initialization parameters.

5.30.2.3 uint32_t NV_ENC_RECONFIGURE_PARAMS::resetEncoder

[in]: This resets the rate control states and other internal encoder states. This should be used only with an IDR frame. If NV_ENC_INITIALIZE_PARAMS::enablePTD is set to 1, encoder will force the frame type to IDR

5.30.2.4 uint32_t NV_ENC_RECONFIGURE_PARAMS::version

[in]: Struct version. Must be set to NV_ENC_RECONFIGURE_PARAMS_VER.

5.31 NV_ENC_REGISTER_RESOURCE Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t version
- NV_ENC_INPUT_RESOURCE_TYPE resourceType
- uint32_t width
- uint32_t height
- uint32 t pitch
- uint32_t subResourceIndex
- void * resourceToRegister
- NV_ENC_REGISTERED_PTR registeredResource
- NV_ENC_BUFFER_FORMAT bufferFormat
- uint32_t reserved1 [248]
- void * reserved2 [62]

5.31.1 Detailed Description

Register a resource for future use with the Nvidia Video Encoder Interface.

5.31.2 Field Documentation

5.31.2.1 NV_ENC_BUFFER_FORMAT NV_ENC_REGISTER_RESOURCE::bufferFormat

[in]: Buffer format of resource to be registered.

5.31.2.2 uint32_t NV_ENC_REGISTER_RESOURCE::height

[in]: Input buffer Height.

5.31.2.3 uint32_t NV_ENC_REGISTER_RESOURCE::pitch

[in]: Input buffer Pitch.

5.31.2.4 NV_ENC_REGISTERED_PTR NV_ENC_REGISTER_RESOURCE::registeredResource

[out]: Registered resource handle. This should be used in future interactions with the Nvidia Video Encoder Interface.

5.31.2.5 uint32_t NV_ENC_REGISTER_RESOURCE::reserved1[248]

[in]: Reserved and must be set to 0.

5.31.2.6 void* NV_ENC_REGISTER_RESOURCE::reserved2[62]

[in]: Reserved and must be set to NULL.

5.31.2.7 void* NV_ENC_REGISTER_RESOURCE::resourceToRegister

[in]: Handle to the resource that is being registered.

5.31.2.8 NV_ENC_INPUT_RESOURCE_TYPE NV_ENC_REGISTER_RESOURCE::resourceType

[in]: Specifies the type of resource to be registered. Supported values are NV_ENC_INPUT_RESOURCE_TYPE_DIRECTX, NV_ENC_INPUT_RESOURCE_TYPE_CUDADEVICEPTR.

5.31.2.9 uint32_t NV_ENC_REGISTER_RESOURCE::subResourceIndex

[in]: Subresource Index of the DirectX resource to be registered. Should be set to 0 for other interfaces.

5.31.2.10 uint32_t NV_ENC_REGISTER_RESOURCE::version

[in]: Struct version. Must be set to NV_ENC_REGISTER_RESOURCE_VER.

5.31.2.11 uint32_t NV_ENC_REGISTER_RESOURCE::width

[in]: Input buffer Width.

5.32 NV ENC SEI PAYLOAD Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t payloadSize
- uint32_t payloadType
- uint8_t * payload

5.32.1 Detailed Description

User SEI message

5.32.2 Field Documentation

5.32.2.1 uint8_t* NV_ENC_SEI_PAYLOAD::payload

[in] pointer to user data

5.32.2.2 uint32_t NV_ENC_SEI_PAYLOAD::payloadSize

[in] SEI payload size in bytes. SEI payload must be byte aligned, as described in Annex D

5.32.2.3 uint32_t NV_ENC_SEI_PAYLOAD::payloadType

[in] SEI payload types and syntax can be found in Annex D of the H.264 Specification.

5.33 NV_ENC_SEQUENCE_PARAM_PAYLOAD Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32 t version
- uint32_t inBufferSize
- uint32 t spsId
- uint32_t ppsId
- void * spsppsBuffer
- uint32_t * outSPSPPSPayloadSize
- uint32_t reserved [250]
- void * reserved2 [64]

5.33.1 Detailed Description

Sequence and picture paramaters payload.

5.33.2 Field Documentation

5.33.2.1 uint32_t NV_ENC_SEQUENCE_PARAM_PAYLOAD::inBufferSize

[in]: Specifies the size of the spsppsBuffer provied by the client

5.33.2.2 uint32_t* NV_ENC_SEQUENCE_PARAM_PAYLOAD::outSPSPPSPayloadSize

[out]: Size of the sequence and picture header in bytes written by the NvEncodeAPI interface to the SPSPPSBuffer.

5.33.2.3 uint32_t NV_ENC_SEQUENCE_PARAM_PAYLOAD::ppsId

[in]: Specifies the PPS id to be used in picture header. Default value is 0.

5.33.2.4 uint32_t NV_ENC_SEQUENCE_PARAM_PAYLOAD::reserved[250]

[in]: Reserved and must be set to 0

5.33.2.5 void* NV_ENC_SEQUENCE_PARAM_PAYLOAD::reserved2[64]

[in]: Reserved and must be set to NULL

5.33.2.6 uint32_t NV_ENC_SEQUENCE_PARAM_PAYLOAD::spsId

[in]: Specifies the SPS id to be used in sequence header. Default value is 0.

$\textbf{5.33.2.7} \quad void*\ NV_ENC_SEQUENCE_PARAM_PAYLOAD::spsppsBuffer$

[in]: Specifies bitstream header pointer of size NV_ENC_SEQUENCE_PARAM_PAYLOAD::inBufferSize. It is the client's responsibility to manage this memory.

5.33.2.8 uint32_t NV_ENC_SEQUENCE_PARAM_PAYLOAD::version

[in]: Struct version. Must be set to NV_ENC_INITIALIZE_PARAMS_VER.

5.34 NV_ENC_STAT Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t version
- uint32_t reserved
- NV_ENC_OUTPUT_PTR outputBitStream
- uint32_t bitStreamSize
- uint32_t picType
- uint32_t lastValidByteOffset
- uint32_t sliceOffsets [16]
- uint32_t picIdx
- uint32_t reserved1 [233]
- void * reserved2 [64]

5.34.1 Detailed Description

Encode Stats structure.

5.34.2 Field Documentation

5.34.2.1 uint32_t NV_ENC_STAT::bitStreamSize

[out]: Size of generated bitstream in bytes.

5.34.2.2 uint32_t NV_ENC_STAT::lastValidByteOffset

[out]: Offset of last valid bytes of completed bitstream

5.34.2.3 NV_ENC_OUTPUT_PTR NV_ENC_STAT::outputBitStream

[out]: Specifies the pointer to output bitstream.

5.34.2.4 uint32_t NV_ENC_STAT::picIdx

[out]: Picture number

5.34.2.5 uint32_t NV_ENC_STAT::picType

[out]: Picture type of encoded picture. See NV_ENC_PIC_TYPE.

5.34.2.6 uint32_t NV_ENC_STAT::reserved

[in]: Reserved and must be set to 0

5.34.2.7 uint32_t NV_ENC_STAT::reserved1[233]

[in]: Reserved and must be set to 0

5.34.2.8 void* NV_ENC_STAT::reserved2[64]

[in]: Reserved and must be set to NULL

5.34.2.9 uint32_t NV_ENC_STAT::sliceOffsets[16]

[out]: Offsets of each slice

5.34.2.10 uint32_t NV_ENC_STAT::version

[in]: Struct version. Must be set to NV_ENC_STAT_VER.

5.35 NV_ENCODE_API_FUNCTION_LIST Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32 t version
- uint32_t reserved
- PNVENCOPENENCODESESSION nvEncOpenEncodeSession
- PNVENCGETENCODEGUIDCOUNT nvEncGetEncodeGUIDCount
- PNVENCGETENCODEPRESETCOUNT nvEncGetEncodeProfileGUIDCount
- PNVENCGETENCODEPRESETGUIDS nvEncGetEncodeProfileGUIDs
- PNVENCGETENCODEGUIDS nvEncGetEncodeGUIDs
- PNVENCGETINPUTFORMATCOUNT nvEncGetInputFormatCount
- PNVENCGETINPUTFORMATS nvEncGetInputFormats
- PNVENCGETENCODECAPS nvEncGetEncodeCaps
- PNVENCGETENCODEPRESETCOUNT nvEncGetEncodePresetCount
- PNVENCGETENCODEPRESETGUIDS nvEncGetEncodePresetGUIDs
- PNVENCGETENCODEPRESETCONFIG nvEncGetEncodePresetConfig
- PNVENCINITIALIZEENCODER nvEncInitializeEncoder
- PNVENCCREATEINPUTBUFFER nvEncCreateInputBuffer
- PNVENCDESTROYINPUTBUFFER nvEncDestroyInputBuffer
- PNVENCCREATEBITSTREAMBUFFER nvEncCreateBitstreamBuffer
- PNVENCDESTROYBITSTREAMBUFFER nvEncDestroyBitstreamBuffer
- PNVENCENCODEPICTURE nvEncEncodePicture
- PNVENCLOCKBITSTREAM nvEncLockBitstream
- PNVENCUNLOCKBITSTREAM nvEncUnlockBitstream
- PNVENCLOCKINPUTBUFFER nvEncLockInputBuffer
- PNVENCUNLOCKINPUTBUFFER nvEncUnlockInputBuffer
- PNVENCGETENCODESTATS nvEncGetEncodeStats
- PNVENCGETSEQUENCEPARAMS nvEncGetSequenceParams
- PNVENCREGISTERASYNCEVENT nvEncRegisterAsyncEvent
- PNVENCUNREGISTERASYNCEVENT nvEncUnregisterAsyncEvent
- PNVENCMAPINPUTRESOURCE nvEncMapInputResource
- PNVENCUNMAPINPUTRESOURCE nvEncUnmapInputResource
- PNVENCDESTROYENCODER nvEncDestroyEncoder
- PNVENCINVALIDATEREFFRAMES nvEncInvalidateRefFrames
- PNVENCOPENENCODESESSIONEX nvEncOpenEncodeSessionEx
- PNVENCREGISTERRESOURCE nvEncRegisterResource
- PNVENCUNREGISTERRESOURCE nvEncUnregisterResource
- PNVENCRECONFIGUREENCODER nvEncReconfigureEncoder
- PNVENCCREATEMVBUFFER nvEncCreateMVBuffer
- PNVENCDESTROYMVBUFFER nvEncDestroyMVBuffer
- PNVENCRUNMOTIONESTIMATIONONLY nvEncRunMotionEstimationOnly
- void * reserved2 [281]

5.35.1 Detailed Description

NV_ENCODE_API_FUNCTION_LIST

5.35.2 Field Documentation

5.35.2.1 PNVENCCREATEBITSTREAMBUFFER NV_ENCODE_API_FUNCTION_-LIST::nvEncCreateBitstreamBuffer

[out]: Client should access NvEncCreateBitstreamBuffer() API through this pointer.

5.35.2.2 PNVENCCREATEINPUTBUFFER NV_ENCODE_API_FUNCTION_-LIST::nvEncCreateInputBuffer

[out]: Client should access NvEncCreateInputBuffer() API through this pointer.

5.35.2.3 PNVENCCREATEMVBUFFER NV_ENCODE_API_FUNCTION_LIST::nvEncCreateMVBuffer

[out]: Client should access NvEncCreateMVBuffer API through this pointer.

5.35.2.4 PNVENCDESTROYBITSTREAMBUFFER NV_ENCODE_API_FUNCTION_-LIST::nvEncDestroyBitstreamBuffer

[out]: Client should access NvEncDestroyBitstreamBuffer() API through this pointer.

5.35.2.5 PNVENCDESTROYENCODER NV_ENCODE_API_FUNCTION_LIST::nvEncDestroyEncoder

[out]: Client should access NvEncDestroyEncoder() API through this pointer.

5.35.2.6 PNVENCDESTROYINPUTBUFFER NV_ENCODE_API_FUNCTION_-LIST::nvEncDestroyInputBuffer

[out]: Client should access NvEncDestroyInputBuffer() API through this pointer.

5.35.2.7 PNVENCDESTROYMVBUFFER NV_ENCODE_API_FUNCTION_-LIST::nvEncDestroyMVBuffer

[out]: Client should access NvEncDestroyMVBuffer API through this pointer.

5.35.2.8 PNVENCENCODEPICTURE NV_ENCODE_API_FUNCTION_LIST::nvEncEncodePicture

[out]: Client should access NvEncEncodePicture() API through this pointer.

5.35.2.9 PNVENCGETENCODECAPS NV_ENCODE_API_FUNCTION_LIST::nvEncGetEncodeCaps

[out]: Client should access NvEncGetEncodeCaps() API through this pointer.

5.35.2.10 PNVENCGETENCODEGUIDCOUNT NV_ENCODE_API_FUNCTION_-LIST::nvEncGetEncodeGUIDCount

[out]: Client should access NvEncGetEncodeGUIDCount() API through this pointer.

5.35.2.11 PNVENCGETENCODEGUIDS NV ENCODE API FUNCTION LIST::nvEncGetEncodeGUIDs

[out]: Client should access NvEncGetEncodeGUIDs() API through this pointer.

5.35.2.12 PNVENCGETENCODEPRESETCONFIG NV_ENCODE_API_FUNCTION_-LIST::nvEncGetEncodePresetConfig

[out]: Client should access NvEncGetEncodePresetConfig() API through this pointer.

5.35.2.13 PNVENCGETENCODEPRESETCOUNT NV_ENCODE_API_FUNCTION_-LIST::nvEncGetEncodePresetCount

[out]: Client should access NvEncGetEncodePresetCount() API through this pointer.

5.35.2.14 PNVENCGETENCODEPRESETGUIDS NV_ENCODE_API_FUNCTION_-LIST::nvEncGetEncodePresetGUIDs

[out]: Client should access NvEncGetEncodePresetGUIDs() API through this pointer.

5.35.2.15 PNVENCGETENCODEPRESETCOUNT NV_ENCODE_API_FUNCTION_-LIST::nvEncGetEncodeProfileGUIDCount

[out]: Client should access NvEncGetEncodeProfileGUIDCount() API through this pointer.

5.35.2.16 PNVENCGETENCODEPRESETGUIDS NV_ENCODE_API_FUNCTION_-LIST::nvEncGetEncodeProfileGUIDs

[out]: Client should access NvEncGetEncodeProfileGUIDs() API through this pointer.

5.35,2.17 PNVENCGETENCODESTATS NV_ENCODE_API_FUNCTION_LIST::nvEncGetEncodeStats

[out]: Client should access NvEncGetEncodeStats() API through this pointer.

5.35.2.18 PNVENCGETINPUTFORMATCOUNT NV_ENCODE_API_FUNCTION_-LIST::nvEncGetInputFormatCount

[out]: Client should access NvEncGetInputFormatCount() API through this pointer.

5.35.2.19 PNVENCGETINPUTFORMATS NV_ENCODE_API_FUNCTION_-LIST::nvEncGetInputFormats

[out]: Client should access NvEncGetInputFormats() API through this pointer.

5.35.2.20 PNVENCGETSEQUENCEPARAMS NV_ENCODE_API_FUNCTION_-LIST::nvEncGetSequenceParams

[out]: Client should access NvEncGetSequenceParams() API through this pointer.

5.35.2.21 PNVENCINITIALIZEENCODER NV_ENCODE_API_FUNCTION_-LIST::nvEncInitializeEncoder

[out]: Client should access NvEncInitializeEncoder() API through this pointer.

5.35.2.22 PNVENCINVALIDATEREFFRAMES NV_ENCODE_API_FUNCTION_-LIST::nvEncInvalidateRefFrames

[out]: Client should access NvEncInvalidateRefFrames() API through this pointer.

5.35.2.23 PNVENCLOCKBITSTREAM NV ENCODE API FUNCTION LIST::nvEncLockBitstream

[out]: Client should access NvEncLockBitstream() API through this pointer.

5.35.2.24 PNVENCLOCKINPUTBUFFER NV_ENCODE_API_FUNCTION_LIST::nvEncLockInputBuffer

[out]: Client should access NvEncLockInputBuffer() API through this pointer.

5.35.2.25 PNVENCMAPINPUTRESOURCE NV_ENCODE_API_FUNCTION_-LIST::nvEncMapInputResource

[out]: Client should access NvEncMapInputResource() API through this pointer.

5.35.2.26 PNVENCOPENENCODESESSION NV_ENCODE_API_FUNCTION_-LIST::nvEncOpenEncodeSession

[out]: Client should access NvEncOpenEncodeSession() API through this pointer.

5.35.2.27 PNVENCOPENENCODESESSIONEX NV_ENCODE_API_FUNCTION_-LIST::nvEncOpenEncodeSessionEx

[out]: Client should access NvEncOpenEncodeSession() API through this pointer.

5.35.2.28 PNVENCRECONFIGUREENCODER NV_ENCODE_API_FUNCTION_-LIST::nvEncReconfigureEncoder

[out]: Client should access NvEncReconfigureEncoder() API through this pointer.

5.35.2.29 PNVENCREGISTERASYNCEVENT NV_ENCODE_API_FUNCTION_-LIST::nvEncRegisterAsyncEvent

[out]: Client should access NvEncRegisterAsyncEvent() API through this pointer.

5.35.2.30 PNVENCREGISTERRESOURCE NV_ENCODE_API_FUNCTION_-LIST::nvEncRegisterResource

[out]: Client should access NvEncRegisterResource() API through this pointer.

5.35.2.31 PNVENCRUNMOTIONESTIMATIONONLY NV_ENCODE_API_FUNCTION_-LIST::nvEncRunMotionEstimationOnly

[out]: Client should access NvEncRunMotionEstimationOnly API through this pointer.

5.35.2.32 PNVENCUNLOCKBITSTREAM NV_ENCODE_API_FUNCTION_-LIST::nvEncUnlockBitstream

[out]: Client should access NvEncUnlockBitstream() API through this pointer.

5.35.2.33 PNVENCUNLOCKINPUTBUFFER NV_ENCODE_API_FUNCTION_-LIST::nvEncUnlockInputBuffer

[out]: Client should access NvEncUnlockInputBuffer() API through this pointer.

5.35.2.34 PNVENCUNMAPINPUTRESOURCE NV_ENCODE_API_FUNCTION_-LIST::nvEncUnmapInputResource

[out]: Client should access NvEncUnmapInputResource() API through this pointer.

5.35.2.35 PNVENCUNREGISTERASYNCEVENT NV_ENCODE_API_FUNCTION_-LIST::nvEncUnregisterAsyncEvent

[out]: Client should access NvEncUnregisterAsyncEvent() API through this pointer.

5.35.2.36 PNVENCUNREGISTERRESOURCE NV_ENCODE_API_FUNCTION_-LIST::nvEncUnregisterResource

[out]: Client should access NvEncUnregisterResource() API through this pointer.

5.35.2.37 uint32_t NV_ENCODE_API_FUNCTION_LIST::reserved

[in]: Reserved and should be set to 0.

5.35.2.38 void* NV_ENCODE_API_FUNCTION_LIST::reserved2[281]

[in]: Reserved and must be set to NULL

5.35.2.39 uint32_t NV_ENCODE_API_FUNCTION_LIST::version

[in]: Client should pass NV_ENCODE_API_FUNCTION_LIST_VER.

5.36 NVENC EXTERNAL ME HINT Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- int32_t mvx: 12
 int32_t mvy: 10
 int32_t refidx: 5
 int32_t dir: 1
 int32_t partType: 2
- int32_t lastofPart: 1
- int32_t lastOfMB: 1

5.36.1 Detailed Description

External Motion Vector hint structure.

5.36.2 Field Documentation

5.36.2.1 int32_t NVENC_EXTERNAL_ME_HINT::dir

[in]: Specifies the direction of motion estimation . 0=L0 1=L1.

5.36.2.2 int32_t NVENC_EXTERNAL_ME_HINT::lastOfMB

[in]: Set to 1 for the last MV of macroblock.

5.36.2.3 int32_t NVENC_EXTERNAL_ME_HINT::lastofPart

[in]: Set to 1 for the last MV of (sub) partition

5.36.2.4 int32_t NVENC_EXTERNAL_ME_HINT::mvx

[in]: Specifies the x component of integer pixel MV (relative to current MB) S12.0.

5.36.2.5 int32_t NVENC_EXTERNAL_ME_HINT::mvy

[in]: Specifies the y component of integer pixel MV (relative to current MB) S10.0.

5.36.2.6 int32_t NVENC_EXTERNAL_ME_HINT::partType

[in]: Specifies the block partition type.0=16x16 1=16x8 2=8x16 3=8x8 (blocks in partition must be consecutive).

5.36.2.7 int32_t NVENC_EXTERNAL_ME_HINT::refidx

[in]: Specifies the reference index (31=invalid). Current we support only 1 reference frame per direction for external hints, so refidx must be 0.

5.37 NVENC_EXTERNAL_ME_HINT_COUNTS_PER_BLOCKTYPE Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t numCandsPerBlk16x16: 4
- uint32_t numCandsPerBlk16x8: 4
- uint32_t numCandsPerBlk8x16: 4
- uint32_t numCandsPerBlk8x8: 4
- uint32_t reserved: 16
- uint32_t reserved1 [3]

5.37.1 Detailed Description

External motion vector hint counts per block type.

5.37.2 Field Documentation

5.37.2.1 uint32_t NVENC_EXTERNAL_ME_HINT_COUNTS_PER_-BLOCKTYPE::numCandsPerBlk16x16

[in]: Specifies the number of candidates per 16x16 block.

5.37.2.2 uint32_t NVENC_EXTERNAL_ME_HINT_COUNTS_PER_-BLOCKTYPE::numCandsPerBlk16x8

[in]: Specifies the number of candidates per 16x8 block.

5.37.2.3 uint32_t NVENC_EXTERNAL_ME_HINT_COUNTS_PER_-BLOCKTYPE::numCandsPerBlk8x16

[in]: Specifies the number of candidates per 8x16 block.

5.37.2.4 uint32_t NVENC_EXTERNAL_ME_HINT_COUNTS_PER_BLOCKTYPE::numCandsPerBlk8x8

[in]: Specifies the number of candidates per 8x8 block.

5.37.2.5 uint32_t NVENC_EXTERNAL_ME_HINT_COUNTS_PER_BLOCKTYPE::reserved

[in]: Reserved for padding.

5.37.2.6 uint32_t NVENC_EXTERNAL_ME_HINT_COUNTS_PER_BLOCKTYPE::reserved1[3]

[in]: Reserved for future use.

5.38 NVENC_RECT Struct Reference

#include <nvEncodeAPI.h>

Data Fields

- uint32_t left
- uint32_t top
- uint32 t right
- uint32_t bottom

5.38.1 Detailed Description

Defines a Rectangle. Used in NV_ENC_PREPROCESS_FRAME.

5.38.2 Field Documentation

5.38.2.1 uint32_t NVENC_RECT::bottom

[in]: Y coordinate of the bottom right corner of the rectangular area to be specified.

5.38.2.2 uint32_t NVENC_RECT::left

[in]: X coordinate of the upper left corner of rectangular area to be specified.

5.38.2.3 uint32_t NVENC_RECT::right

[in]: X coordinate of the bottom right corner of the rectangular area to be specified.

5.38.2.4 uint32_t NVENC_RECT::top

[in]: Y coordinate of the upper left corner of the rectangular area to be specified.

Index

adaptiveTransformMode	chromaSampleLocationFlag
NV_ENC_CONFIG_H264, 56	NV_ENC_CONFIG_H264_VUI_PARAMETERS
apiVersion	63
NV_ENC_OPEN_ENCODE_SESSION_EX	chromaSampleLocationTop
PARAMS, 92	NV_ENC_CONFIG_H264_VUI_PARAMETERS
aqStrength	63
NV_ENC_RC_PARAMS, 106	codecPicParams
averageBitRate	NV_ENC_PIC_PARAMS, 94
NV_ENC_RC_PARAMS, 106	colourDescriptionPresentFlag
	NV_ENC_CONFIG_H264_VUI_PARAMETERS
bdirectMode	63
NV_ENC_CONFIG_H264, 56	colourMatrix
bitstreamBuffer	NV_ENC_CONFIG_H264_VUI_PARAMETERS
NV_ENC_CREATE_BITSTREAM_BUFFER, 70	63
bitstreamBufferPtr	colourPlaneId
NV_ENC_CREATE_BITSTREAM_BUFFER, 70	NV_ENC_PIC_PARAMS_H264, 98
NV_ENC_LOCK_BITSTREAM, 82	colourPrimaries
bitstreamRestrictionFlag	NV ENC CONFIG H264 VUI PARAMETERS
NV_ENC_CONFIG_H264_VUI_PARAMETERS,	64
63	completionEvent
bitStreamSize	NV_ENC_EVENT_PARAMS, 75
NV_ENC_STAT, 116	NV_ENC_MEONLY_PARAMS, 89
bitstreamSizeInBytes	NV_ENC_PIC_PARAMS, 94
NV_ENC_LOCK_BITSTREAM, 82	constQP
bottom	NV_ENC_RC_PARAMS, 106
NVENC_RECT, 126	constrainedFrame
bStereoEnable	NV_ENC_PIC_PARAMS_H264, 98
NV_ENC_CONFIG_H264_MEONLY, 61	NV_ENC_PIC_PARAMS_HEVC, 101
bufferDataPtr	cuSize
NV_ENC_LOCK_INPUT_BUFFER, 85	NV_ENC_HEVC_MV_DATA, 77
bufferFmt	cuType
NV_ENC_CREATE_INPUT_BUFFER, 72	NV_ENC_HEVC_MV_DATA, 77
NV_ENC_MEONLY_PARAMS, 89	/
NV_ENC_PIC_PARAMS, 94	darHeight
bufferFormat	NV_ENC_INITIALIZE_PARAMS, 78
NV_ENC_REGISTER_RESOURCE, 111	darWidth
	NV_ENC_INITIALIZE_PARAMS, 78
capsToQuery	Data1
NV_ENC_CAPS_PARAM, 50	GUID, 49
chromaFormatIDC	Data2
NV_ENC_CONFIG_H264, 56	GUID, 49
NV_ENC_CONFIG_HEVC, 65	Data3
chromaSampleLocationBot	GUID, 49
NV_ENC_CONFIG_H264_VUI_PARAMETERS,	Data4
63	CUID 40

device	NV_ENC_CONFIG_H264, 56
NV_ENC_OPEN_ENCODE_SESSION_EX	NV_ENC_CONFIG_HEVC, 66
PARAMS, 92	enableMaxQP
deviceType	NV_ENC_RC_PARAMS, 107
NV_ENC_OPEN_ENCODE_SESSION_EX	enableMEOnlyMode
PARAMS, 92	NV_ENC_INITIALIZE_PARAMS, 79
dir	enableMinQP
NVENC_EXTERNAL_ME_HINT, 123	NV_ENC_RC_PARAMS, 107
disableBadapt	enableNonRefP
NV_ENC_RC_PARAMS, 107	NV_ENC_RC_PARAMS, 107
disableDeblockAcrossSliceBoundary	enablePTD
NV_ENC_CONFIG_HEVC, 65	NV_ENC_INITIALIZE_PARAMS, 79
disableDeblockingFilterIDC	enableStereoMVC
NV_ENC_CONFIG_H264, 56	NV_ENC_CONFIG_H264, 56
disableIadapt	enableSubFrameWrite
NV_ENC_RC_PARAMS, 107	NV_ENC_INITIALIZE_PARAMS, 79
disableIntraSearch	enableTemporalAQ
NV_ENC_CONFIG_H264_MEONLY, 61	NV_ENC_RC_PARAMS, 107
disablePartition16x16	enableTemporalSVC
NV_ENC_CONFIG_H264_MEONLY, 61	NV_ENC_CONFIG_H264, 57
disablePartition16x8	enableVFR
NV_ENC_CONFIG_H264_MEONLY, 61	NV_ENC_CONFIG_H264, 57
disablePartition8x16	ENCODE_FUNC
NV_ENC_CONFIG_H264_MEONLY, 61	NvEncCreateBitstreamBuffer, 26
disablePartition8x8	NvEncCreateInputBuffer, 26
NV_ENC_CONFIG_H264_MEONLY, 61	NvEncCreateMVBuffer, 26
disableSPSPPS	NvEncDestroyBitstreamBuffer, 27
NV_ENC_CONFIG_H264, 56	NvEncDestroyEncoder, 27
NV_ENC_CONFIG_HEVC, 66	NvEncDestroyInputBuffer, 28
displayPOCSyntax	NvEncDestroyMVBuffer, 28
NV_ENC_PIC_PARAMS_H264, 98	NvEncEncodePicture, 29
NV_ENC_PIC_PARAMS_HEVC, 101	NvEncGetEncodeCaps, 31
doNotWait	NvEncGetEncodeGUIDCount, 32
NV_ENC_LOCK_BITSTREAM, 82	NvEncGetEncodeGUIDs, 32
NV_ENC_LOCK_INPUT_BUFFER, 85	NvEncGetEncodePresetConfig, 33
	NvEncGetEncodePresetCount, 33
enableAQ	NvEncGetEncodePresetGUIDs, 34
NV_ENC_RC_PARAMS, 107	NvEncGetEncodeProfileGUIDCount, 34
enableConstrainedEncoding	NvEncGetEncodeProfileGUIDs, 35
NV_ENC_CONFIG_H264, 56	NvEncGetEncodeStats, 35
enableEncodeAsync	NvEncGetInputFormatCount, 36
NV_ENC_INITIALIZE_PARAMS, 78	NvEncGetInputFormats, 36
enableExternalMEHints	NvEncGetSequenceParams, 37
NV_ENC_INITIALIZE_PARAMS, 78	NvEncInitializeEncoder, 37
enableExtQPDeltaMap	NvEncInvalidateRefFrames, 39
NV_ENC_RC_PARAMS, 107	NvEncLockBitstream, 39
enableInitialRCQP	NvEncLockInputBuffer, 40
NV_ENC_RC_PARAMS, 107	NvEncMapInputResource, 40
enableIntraRefresh	
NV_ENC_CONFIG_H264, 56	NvEncodeAPICreateInstance, 41
NV_ENC_CONFIG_HEVC, 66	NvEncodeAPIGetMaxSupportedVersion, 43
enableLookahead	NvEncOpenEncodeSession, 42
	NvEncOpenEncodeSessionEx, 42
NV_ENC_RC_PARAMS, 107	NvEncReconfigureEncoder, 42
enableLTR	NvEncRegisterAsyncEvent, 43

NvEncRegisterResource, 43	NV_ENC_CAPS_SUPPORT_CUSTOM_VBV
NvEncRunMotionEstimationOnly, 44	BUF_SIZE, 17
NvEncUnlockBitstream, 44	NV_ENC_CAPS_SUPPORT_DYN_BITRATE
NvEncUnlockInputBuffer, 45	CHANGE, 16
NvEncUnmapInputResource, 45	NV_ENC_CAPS_SUPPORT_DYN_FORCE
NvEncUnregisterAsyncEvent, 46	CONSTQP, 16
NvEncUnregisterResource, 46	NV_ENC_CAPS_SUPPORT_DYN_RCMODE
encodeCodecConfig	CHANGE, 16
NV_ENC_CONFIG, 53	NV_ENC_CAPS_SUPPORT_DYN_RES
encodeConfig	CHANGE, 16
NV_ENC_INITIALIZE_PARAMS, 79	NV_ENC_CAPS_SUPPORT_DYNAMIC
encodeGUID	SLICE_MODE, 17
NV_ENC_INITIALIZE_PARAMS, 79	NV_ENC_CAPS_SUPPORT_FIELD
encodeHeight	ENCODING, 15
NV_ENC_INITIALIZE_PARAMS, 79	NV_ENC_CAPS_SUPPORT_FMO, 15
encodePicFlags	NV_ENC_CAPS_SUPPORT_HIERARCHICAL
NV_ENC_PIC_PARAMS, 95	BFRAMES, 16
ENCODER_STRUCTURE	NV_ENC_CAPS_SUPPORT_HIERARCHICAL
NV_ENC_BUFFER_FORMAT_ABGR, 15	PFRAMES, 15
NV_ENC_BUFFER_FORMAT_ABGR10, 15	NV_ENC_CAPS_SUPPORT_INTRA_REFRESH,
NV_ENC_BUFFER_FORMAT_ARGB, 15	16
NV_ENC_BUFFER_FORMAT_ARGB10, 15	NV_ENC_CAPS_SUPPORT_LOOKAHEAD, 17
NV_ENC_BUFFER_FORMAT_AYUV, 15	NV_ENC_CAPS_SUPPORT_LOSSLESS
NV_ENC_BUFFER_FORMAT_IYUV, 14	ENCODE, 17
NV_ENC_BUFFER_FORMAT_NV12, 14	NV_ENC_CAPS_SUPPORT_MEONLY_MODE,
NV_ENC_BUFFER_FORMAT_UNDEFINED, 14	17
NV_ENC_BUFFER_FORMAT_YUV420_10BIT,	NV_ENC_CAPS_SUPPORT_MONOCHROME,
14	15
NV_ENC_BUFFER_FORMAT_YUV444, 14	NV_ENC_CAPS_SUPPORT_QPELMV, 15
NV_ENC_BUFFER_FORMAT_YUV444_10BIT,	NV_ENC_CAPS_SUPPORT_REF_PIC
15	INVALIDATION, 17
NV_ENC_BUFFER_FORMAT_YV12, 14	NV_ENC_CAPS_SUPPORT_RESERVED, 15
NV_ENC_CAPS_ASYNC_ENCODE_SUPPORT,	NV_ENC_CAPS_SUPPORT_SAO, 17
17	NV_ENC_CAPS_SUPPORT_SUBFRAME
NV_ENC_CAPS_EXPOSED_COUNT, 17	READBACK, 16
NV_ENC_CAPS_HEIGHT_MAX, 16	NV_ENC_CAPS_SUPPORT_TEMPORAL_AQ,
NV_ENC_CAPS_LEVEL_MAX, 16	17
NV_ENC_CAPS_LEVEL_MIN, 16	NV_ENC_CAPS_SUPPORT_TEMPORAL_SVC,
NV_ENC_CAPS_MB_NUM_MAX, 17	16
NV_ENC_CAPS_MB_PER_SEC_MAX, 17	NV_ENC_CAPS_SUPPORT_YUV444_ENCODE,
NV_ENC_CAPS_NUM_MAX_BFRAMES, 15	17
NV_ENC_CAPS_NUM_MAX_TEMPORAL	NV_ENC_CAPS_SUPPORTED
LAYERS, 15	RATECONTROL MODES, 15
NV_ENC_CAPS_PREPROC_SUPPORT, 17	NV_ENC_CAPS_WIDTH_MAX, 16
NV_ENC_CAPS_SEPARATE_COLOUR_PLANE,	NV_ENC_DEVICE_TYPE_CUDA, 18
16	NV_ENC_DEVICE_TYPE_DIRECTX, 18
NV_ENC_CAPS_SUPPORT_10BIT_ENCODE, 17	NV_ENC_ERR_DEVICE_NOT_EXIST, 21
NV_ENC_CAPS_SUPPORT_IDBIT_ENCODE, 17 NV_ENC_CAPS_SUPPORT_ADAPTIVE	NV ENC ERR ENCODER BUSY, 22
TRANSFORM, 15	NV_ENC_ERR_ENCODER_NOT_INITIALIZED,
NV_ENC_CAPS_SUPPORT_BDIRECT_MODE,	21
15	NV_ENC_ERR_EVENT_NOT_REGISTERD, 22
NV_ENC_CAPS_SUPPORT_CABAC, 15	NV_ENC_ERR_GENERIC, 22
NV_ENC_CAPS_SUPPORT_CONSTRAINED	NV_ENC_ERR_INCOMPATIBLE_CLIENT
ENCODING, 16	KEY, 22

NV_ENC_ERR_INVALID_CALL, 21	NV_ENC_MEMORY_HEAP_SYSMEM
NV_ENC_ERR_INVALID_DEVICE, 21	UNCACHED, 19
NV_ENC_ERR_INVALID_ENCODERDEVICE,	NV_ENC_MEMORY_HEAP_VID, 19
21	NV_ENC_MV_PRECISION_DEFAULT, 19
NV_ENC_ERR_INVALID_EVENT, 21	NV_ENC_MV_PRECISION_FULL_PEL, 19
NV_ENC_ERR_INVALID_PARAM, 21	NV_ENC_MV_PRECISION_HALF_PEL, 19
NV_ENC_ERR_INVALID_PTR, 21	NV_ENC_MV_PRECISION_QUARTER_PEL, 19
NV_ENC_ERR_INVALID_VERSION, 22	NV_ENC_PARAMS_FRAME_FIELD_MODE
NV_ENC_ERR_LOCK_BUSY, 21	FIELD, 19
NV_ENC_ERR_MAP_FAILED, 22	NV_ENC_PARAMS_FRAME_FIELD_MODE
NV_ENC_ERR_NEED_MORE_INPUT, 22	FRAME, 19
NV_ENC_ERR_NO_ENCODE_DEVICE, 21	NV_ENC_PARAMS_FRAME_FIELD_MODE
NV_ENC_ERR_NOT_ENOUGH_BUFFER, 21	MBAFF, 19
NV_ENC_ERR_OUT_OF_MEMORY, 21	NV_ENC_PARAMS_RC_CBR, 20
NV_ENC_ERR_RESOURCE_NOT_MAPPED, 22	NV_ENC_PARAMS_RC_CBR_HQ, 20
NV_ENC_ERR_RESOURCE_NOT	NV_ENC_PARAMS_RC_CBR_LOWDELAY
REGISTERED, 22	HQ, 20
NV_ENC_ERR_RESOURCE_REGISTER	NV_ENC_PARAMS_RC_CONSTQP, 20
FAILED, 22	NV_ENC_PARAMS_RC_VBR, 20
NV_ENC_ERR_UNIMPLEMENTED, 22	NV_ENC_PARAMS_RC_VBR_HQ, 20
NV ENC ERR UNSUPPORTED DEVICE, 21	NV_ENC_PIC_FLAG_EOS, 20
NV_ENC_ERR_UNSUPPORTED_PARAM, 21	NV_ENC_PIC_FLAG_FORCEIDR, 20
NV_ENC_H264_ADAPTIVE_TRANSFORM	NV_ENC_PIC_FLAG_FORCEINTRA, 20
AUTOSELECT, 18	NV_ENC_PIC_FLAG_OUTPUT_SPSPPS, 20
NV_ENC_H264_ADAPTIVE_TRANSFORM	NV_ENC_PIC_STRUCT_FIELD_BOTTOM_TOP,
DISABLE, 18	20
NV_ENC_H264_ADAPTIVE_TRANSFORM	NV_ENC_PIC_STRUCT_FIELD_TOP_BOTTOM,
ENABLE, 18	NV_ENC_FIC_STRUCT_FIELD_TOF_BOTTOM,
NV_ENC_H264_BDIRECT_MODE	NV_ENC_PIC_STRUCT_FRAME, 20
AUTOSELECT, 18	NV_ENC_PIC_TYPE_B, 20
NV_ENC_H264_BDIRECT_MODE_DISABLE,	NV_ENC_PIC_TYPE_BI, 20
18	NV_ENC_PIC_TYPE_I, 20
	NV_ENC_PIC_TYPE_IDR, 20
NV_ENC_H264_BDIRECT_MODE_SPATIAL, 18	
NV_ENC_H264_BDIRECT_MODE	NV_ENC_PIC_TYPE_INTRA_REFRESH, 20 NV_ENC_PIC_TYPE_P, 20
TEMPORAL, 18	
NV_ENC_H264_ENTROPY_CODING_MODE	NV_ENC_PIC_TYPE_SKIPPED, 20
AUTOSELECT, 18	NV_ENC_PIC_TYPE_UNKNOWN, 20
NV_ENC_H264_ENTROPY_CODING_MODE	NV_ENC_STEREO_PACKING_MODE
CABAC, 18	CHECKERBOARD, 21
NV_ENC_H264_ENTROPY_CODING_MODE	NV_ENC_STEREO_PACKING_MODE
CAVLC, 18	COLINTERLEAVE, 21
NV_ENC_H264_FMO_AUTOSELECT, 18	NV_ENC_STEREO_PACKING_MODE
NV_ENC_H264_FMO_DISABLE, 18	FRAMESEQ, 21
NV_ENC_H264_FMO_ENABLE, 18	NV_ENC_STEREO_PACKING_MODE_NONE,
NV_ENC_INPUT_RESOURCE_TYPE	21
CUDAARRAY, 19	NV_ENC_STEREO_PACKING_MODE
NV_ENC_INPUT_RESOURCE_TYPE	ROWINTERLEAVE, 21
CUDADEVICEPTR, 19	NV_ENC_STEREO_PACKING_MODE
NV_ENC_INPUT_RESOURCE_TYPE	SIDEBYSIDE, 21
DIRECTX, 19	NV_ENC_STEREO_PACKING_MODE
NV_ENC_MEMORY_HEAP_AUTOSELECT, 19	TOPBOTTOM, 21
NV_ENC_MEMORY_HEAP_SYSMEM	NV_ENC_SUCCESS, 21
CACHED, 19	ENCODER_STRUCTURE
	NV ENC BUFFER FORMAT 14

NV_ENC_CAPS, 15	NV_ENC_CONFIG_H264, 57
NV_ENC_CAPS_PARAM_VER, 12	forceIDR
NV_ENC_CONFIG_VER, 12	NV_ENC_RECONFIGURE_PARAMS, 110
NV_ENC_CREATE_BITSTREAM_BUFFER	forceIntraRefreshWithFrameCnt
VER, 12	NV_ENC_PIC_PARAMS_H264, 98
NV_ENC_CREATE_INPUT_BUFFER_VER, 12	NV_ENC_PIC_PARAMS_HEVC, 101
NV_ENC_CREATE_MV_BUFFER_VER, 12	frameAvgQP
NV_ENC_DEVICE_TYPE, 17	NV_ENC_LOCK_BITSTREAM, 82
NV_ENC_EVENT_PARAMS_VER, 12	frameFieldMode
NV_ENC_H264_ADAPTIVE_TRANSFORM	NV_ENC_CONFIG, 53
MODE, 18	frameIdx
NV_ENC_H264_BDIRECT_MODE, 18	NV_ENC_LOCK_BITSTREAM, 83
NV_ENC_H204_BDIRECT_MODE, 18 NV_ENC_H264_ENTROPY_CODING_MODE,	
	NV_ENC_PIC_PARAMS, 95
18	frameIntervalP
NV_ENC_H264_FMO_MODE, 18	NV_ENC_CONFIG, 53
NV_ENC_HEVC_CUSIZE, 18	frameRateDen
NV_ENC_INITIALIZE_PARAMS_VER, 13	NV_ENC_INITIALIZE_PARAMS, 79
NV_ENC_INPUT_RESOURCE_TYPE, 19	frameRateNum
NV_ENC_LEVEL, 19	NV_ENC_INITIALIZE_PARAMS, 79
NV_ENC_LOCK_BITSTREAM_VER, 13	frameSatd
NV_ENC_LOCK_INPUT_BUFFER_VER, 13	NV_ENC_LOCK_BITSTREAM, 83
NV_ENC_MAP_INPUT_RESOURCE_VER, 13	
NV_ENC_MEMORY_HEAP, 19	gopLength
NV_ENC_MEONLY_PARAMS_VER, 13	NV_ENC_CONFIG, 53
NV_ENC_MV_PRECISION, 19	GUID, 49
NV_ENC_OPEN_ENCODE_SESSION_EX	Data1, 49
PARAMS_VER, 13	Data2, 49
NV_ENC_PARAMS_FRAME_FIELD_MODE, 19	Data3, 49
NV_ENC_PARAMS_RC_2_PASS_FRAMESIZE	Data4, 49
CAP, 13	
NV_ENC_PARAMS_RC_2_PASS_QUALITY, 13	h264Config
NV_ENC_PARAMS_RC_2_PASS_VBR, 13	NV_ENC_CODEC_CONFIG, 51
NV_ENC_PARAMS_RC_CBR2, 13	h264MeOnlyConfig
NV ENC PARAMS RC MODE, 19	NV_ENC_CODEC_CONFIG, 51
NV_ENC_PARAMS_RC_VBR_MINQP, 13	h264PicParams
NV ENC PIC FLAGS, 20	NV_ENC_CODEC_PIC_PARAMS, 52
NV_ENC_PIC_PARAMS_VER, 14	h264VUIParameters
NV_ENC_PIC_STRUCT, 20	NV_ENC_CONFIG_H264, 57
	height
NV_ENC_PIC_TYPE, 20	NV_ENC_CREATE_INPUT_BUFFER, 72
NV_ENC_PRESET_CONFIG_VER, 14	NV_ENC_REGISTER_RESOURCE, 111
NV_ENC_RC_PARAMS_VER, 14	hevcConfig
NV_ENC_RECONFIGURE_PARAMS_VER, 14	NV_ENC_CODEC_CONFIG, 51
NV_ENC_REGISTER_RESOURCE_VER, 14	hevcMeOnlyConfig
NV_ENC_SEQUENCE_PARAM_PAYLOAD	NV ENC CODEC CONFIG, 51
VER, 14	hevcPicParams
NV_ENC_STAT_VER, 14	NV_ENC_CODEC_PIC_PARAMS, 52
NV_ENC_STEREO_PACKING_MODE, 20	heveVUIParameters
NVENCSTATUS, 21	
encodeWidth	NV_ENC_CONFIG_HEVC, 66
NV_ENC_INITIALIZE_PARAMS, 79	hierarchicalBFrames
entropyCodingMode	NV_ENC_CONFIG_H264, 57
NV_ENC_CONFIG_H264, 57	hierarchicalPFrames
	NV_ENC_CONFIG_H264, 57
fmoMode	hwEncodeStatus

NV_ENC_LOCK_BITSTREAM, 83	ltrFrameIdx NV_ENC_LOCK_BITSTREAM, 83
idrPeriod	ltrMarkFrame
NV_ENC_CONFIG_H264, 57	NV_ENC_PIC_PARAMS_H264, 99
NV_ENC_CONFIG_HEVC, 66	NV ENC PIC PARAMS HEVC, 101
inBufferSize	ltrMarkFrameIdx
NV_ENC_SEQUENCE_PARAM_PAYLOAD, 114	NV_ENC_PIC_PARAMS_H264, 99
initialRCQP	NV_ENC_PIC_PARAMS_HEVC, 102
NV_ENC_RC_PARAMS, 107	ltrNumFrames
inputBuffer	NV_ENC_CONFIG_H264, 58
NV_ENC_CREATE_INPUT_BUFFER, 72	NV_ENC_CONFIG_HEVC, 66
NV_ENC_LOCK_INPUT_BUFFER, 85	ltrTrustMode
NV_ENC_MEONLY_PARAMS, 89	NV_ENC_CONFIG_H264, 58
NV_ENC_PIC_PARAMS, 95	NV_ENC_CONFIG_HEVC, 66
inputDuration	ltrUsageMode
NV_ENC_PIC_PARAMS, 95	NV_ENC_PIC_PARAMS_H264, 99
inputHeight	NV_ENC_PIC_PARAMS_HEVC, 102
NV_ENC_MEONLY_PARAMS, 89	ltrUseFrameBitmap
NV_ENC_PIC_PARAMS, 95	NV_ENC_PIC_PARAMS_H264, 99
inputPitch	NV_ENC_PIC_PARAMS_HEVC, 102
NV_ENC_PIC_PARAMS, 95	ltrUseFrames
inputResource	NV ENC PIC PARAMS H264, 99
NV_ENC_MAP_INPUT_RESOURCE, 87	NV_ENC_PIC_PARAMS_HEVC, 102
inputTimeStamp	
NV_ENC_PIC_PARAMS, 95	mappedBufferFmt
inputWidth	NV_ENC_MAP_INPUT_RESOURCE, 87
NV_ENC_MEONLY_PARAMS, 89	mappedResource
NV_ENC_PIC_PARAMS, 95	NV_ENC_MAP_INPUT_RESOURCE, 87
intraRefreshCnt	maxBitRate
NV_ENC_CONFIG_H264, 57	NV_ENC_RC_PARAMS, 108
NV_ENC_CONFIG_HEVC, 66	maxCUSize
intraRefreshPeriod	NV_ENC_CONFIG_HEVC, 67
NV_ENC_CONFIG_H264, 57	maxEncodeHeight
NV_ENC_CONFIG_HEVC, 66	NV_ENC_INITIALIZE_PARAMS, 80
	maxEncodeWidth
lastCUInCTB	NV_ENC_INITIALIZE_PARAMS, 80
NV_ENC_HEVC_MV_DATA, 77	maxMEHintCountsPerBlock
lastOfMB	NV_ENC_INITIALIZE_PARAMS, 80
NVENC_EXTERNAL_ME_HINT, 123	maxNumRefFrames
lastofPart	NV_ENC_CONFIG_H264, 58
NVENC_EXTERNAL_ME_HINT, 123	maxNumRefFramesInDPB
lastValidByteOffset	NV_ENC_CONFIG_HEVC, 67
NV_ENC_STAT, 116	maxQP
left	NV_ENC_RC_PARAMS, 108
NVENC_RECT, 126	maxTemporalLayers
level	NV_ENC_CONFIG_H264, 58
NV_ENC_CONFIG_H264, 58	maxTemporalLayersMinus1
NV_ENC_CONFIG_HEVC, 66	NV_ENC_CONFIG_HEVC, 67
lookaheadDepth	mbType
NV_ENC_RC_PARAMS, 108	NV_ENC_H264_MV_DATA, 76
ltrFrame	meExternalHints
NV_ENC_LOCK_BITSTREAM, 83	NV_ENC_PIC_PARAMS, 95
ltrFrameBitmap	meHintCountsPerBlock
NV_ENC_LOCK_BITSTREAM, 83	NV_ENC_PIC_PARAMS, 95

meHintRefPicDist	NV_ENC_BUFFER_FORMAT_NV12
NV_ENC_PIC_PARAMS, 96	ENCODER_STRUCTURE, 14
memoryHeap	NV_ENC_BUFFER_FORMAT_UNDEFINED
NV_ENC_CREATE_BITSTREAM_BUFFER, 70	ENCODER_STRUCTURE, 14
NV_ENC_CREATE_INPUT_BUFFER, 72	NV_ENC_BUFFER_FORMAT_YUV420_10BIT
minCUSize	ENCODER_STRUCTURE, 14
NV_ENC_CONFIG_HEVC, 67	NV_ENC_BUFFER_FORMAT_YUV444
minQP	ENCODER_STRUCTURE, 14
NV_ENC_RC_PARAMS, 108	NV_ENC_BUFFER_FORMAT_YUV444_10BIT
monoChromeEncoding	ENCODER_STRUCTURE, 15
NV_ENC_CONFIG, 53	NV_ENC_BUFFER_FORMAT_YV12
mv	ENCODER_STRUCTURE, 14
NV_ENC_H264_MV_DATA, 76	NV_ENC_CAPS_ASYNC_ENCODE_SUPPORT
NV_ENC_HEVC_MV_DATA, 77	ENCODER_STRUCTURE, 17
mvBuffer	NV_ENC_CAPS_EXPOSED_COUNT
NV_ENC_CREATE_MV_BUFFER, 74	ENCODER_STRUCTURE, 17
NV_ENC_MEONLY_PARAMS, 89	NV_ENC_CAPS_HEIGHT_MAX
mvPrecision	ENCODER_STRUCTURE, 16
NV_ENC_CONFIG, 53	NV_ENC_CAPS_LEVEL_MAX
mvx	ENCODER_STRUCTURE, 16
NV_ENC_MVECTOR, 91	NV_ENC_CAPS_LEVEL_MIN
NVENC_EXTERNAL_ME_HINT, 123	ENCODER_STRUCTURE, 16
mvy	NV_ENC_CAPS_MB_NUM_MAX
NV_ENC_MVECTOR, 91	ENCODER_STRUCTURE, 17
NVENC_EXTERNAL_ME_HINT, 123	NV_ENC_CAPS_MB_PER_SEC_MAX
TVERCENTERIAL DELINETING, 123	ENCODER_STRUCTURE, 17
numCandsPerBlk16x16	NV_ENC_CAPS_NUM_MAX_BFRAMES
NVENC_EXTERNAL_ME_HINT_COUNTS	ENCODER_STRUCTURE, 15
PER_BLOCKTYPE, 125	NV_ENC_CAPS_NUM_MAX_TEMPORAL_LAYERS
numCandsPerBlk16x8	ENCODER_STRUCTURE, 15
NVENC_EXTERNAL_ME_HINT_COUNTS	NV_ENC_CAPS_PREPROC_SUPPORT
PER_BLOCKTYPE, 125	ENCODER_STRUCTURE, 17
numCandsPerBlk8x16	NV_ENC_CAPS_SEPARATE_COLOUR_PLANE
NVENC_EXTERNAL_ME_HINT_COUNTS	ENCODER_STRUCTURE, 16
PER_BLOCKTYPE, 125	NV_ENC_CAPS_SUPPORT_10BIT_ENCODE
numCandsPerBlk8x8	ENCODER_STRUCTURE, 17
NVENC_EXTERNAL_ME_HINT_COUNTS	NV_ENC_CAPS_SUPPORT_ADAPTIVE
PER_BLOCKTYPE, 125	TRANSFORM
numSlices	ENCODER_STRUCTURE, 15
NV_ENC_LOCK_BITSTREAM, 83	NV_ENC_CAPS_SUPPORT_BDIRECT_MODE
numTemporalLayers	ENCODER_STRUCTURE, 15
NV_ENC_CONFIG_H264, 58	NV_ENC_CAPS_SUPPORT_CABAC
NV_ENC_BUFFER_FORMAT_ABGR	ENCODER_STRUCTURE, 15
ENCODER_STRUCTURE, 15	NV_ENC_CAPS_SUPPORT_CONSTRAINED
NV_ENC_BUFFER_FORMAT_ABGR10	ENCODING
ENCODER_STRUCTURE, 15	ENCODER_STRUCTURE, 16
NV ENC BUFFER FORMAT ARGB	NV_ENC_CAPS_SUPPORT_CUSTOM_VBV_BUF
ENCODER_STRUCTURE, 15	SIZE
NV_ENC_BUFFER_FORMAT_ARGB10	ENCODER_STRUCTURE, 17
ENCODER_STRUCTURE, 15	NV_ENC_CAPS_SUPPORT_DYN_BITRATE
NV_ENC_BUFFER_FORMAT_AYUV	CHANGE
ENCODER_STRUCTURE, 15	ENCODER_STRUCTURE, 16
NV_ENC_BUFFER_FORMAT_IYUV	NV_ENC_CAPS_SUPPORT_DYN_FORCE
ENCODER_STRUCTURE, 14	CONSTQP
_ ,	CO1101Q1

NV ENC DEVICE TYPE DIRECTX ENCODER STRUCTURE, 16 NV_ENC_CAPS_SUPPORT_DYN_RCMODE_-**ENCODER_STRUCTURE, 18 CHANGE** NV ENC ERR DEVICE NOT EXIST ENCODER_STRUCTURE, 16 ENCODER_STRUCTURE, 21 NV ENC CAPS SUPPORT DYN RES CHANGE NV ENC ERR ENCODER BUSY **ENCODER STRUCTURE, 16 ENCODER STRUCTURE, 22** NV ENC CAPS SUPPORT DYNAMIC SLICE -NV ENC ERR ENCODER NOT INITIALIZED **ENCODER STRUCTURE, 21** MODE NV_ENC_ERR_EVENT_NOT_REGISTERD **ENCODER_STRUCTURE, 17** NV_ENC_CAPS_SUPPORT_FIELD_ENCODING ENCODER_STRUCTURE, 22 **ENCODER_STRUCTURE, 15** NV_ENC_ERR_GENERIC NV_ENC_CAPS_SUPPORT_FMO ENCODER_STRUCTURE, 22 ENCODER_STRUCTURE, 15 NV_ENC_ERR_INCOMPATIBLE_CLIENT_KEY NV_ENC_CAPS_SUPPORT_HIERARCHICAL_-ENCODER_STRUCTURE, 22 NV_ENC_ERR_INVALID_CALL **BFRAMES** ENCODER_STRUCTURE, 16 ENCODER_STRUCTURE, 21 NV_ENC_CAPS_SUPPORT_HIERARCHICAL_-NV_ENC_ERR_INVALID_DEVICE **PFRAMES ENCODER STRUCTURE, 21** ENCODER_STRUCTURE, 15 NV_ENC_ERR_INVALID_ENCODERDEVICE NV ENC CAPS SUPPORT INTRA REFRESH ENCODER STRUCTURE, 21 **ENCODER_STRUCTURE, 16** NV_ENC_ERR_INVALID_EVENT NV ENC CAPS SUPPORT LOOKAHEAD **ENCODER STRUCTURE, 21** NV_ENC_ERR_INVALID_PARAM **ENCODER_STRUCTURE, 17** NV ENC CAPS SUPPORT LOSSLESS ENCODE **ENCODER STRUCTURE, 21 ENCODER STRUCTURE, 17** NV ENC ERR INVALID PTR NV ENC CAPS SUPPORT MEONLY MODE **ENCODER STRUCTURE, 21** ENCODER_STRUCTURE, 17 NV_ENC_ERR_INVALID_VERSION NV_ENC_CAPS_SUPPORT_MONOCHROME ENCODER_STRUCTURE, 22 ENCODER_STRUCTURE, 15 NV_ENC_ERR_LOCK_BUSY NV_ENC_CAPS_SUPPORT_QPELMV ENCODER_STRUCTURE, 21 NV_ENC_ERR_MAP_FAILED ENCODER_STRUCTURE, 15 NV_ENC_CAPS_SUPPORT_REF_PIC_-ENCODER_STRUCTURE, 22 INVALIDATION NV_ENC_ERR_NEED_MORE_INPUT **ENCODER_STRUCTURE, 17** ENCODER_STRUCTURE, 22 NV ENC CAPS SUPPORT RESERVED NV ENC ERR NO ENCODE DEVICE **ENCODER_STRUCTURE, 15 ENCODER_STRUCTURE, 21** NV ENC CAPS SUPPORT SAO NV ENC ERR NOT ENOUGH BUFFER **ENCODER_STRUCTURE, 17** ENCODER_STRUCTURE, 21 NV_ENC_CAPS_SUPPORT_SUBFRAME_-NV ENC ERR OUT OF MEMORY ENCODER_STRUCTURE, 21 READBACK **ENCODER STRUCTURE, 16** NV ENC ERR RESOURCE NOT MAPPED NV ENC CAPS SUPPORT TEMPORAL AQ **ENCODER STRUCTURE, 22** NV ENC ERR RESOURCE NOT REGISTERED ENCODER STRUCTURE, 17 NV_ENC_CAPS_SUPPORT_TEMPORAL_SVC ENCODER_STRUCTURE, 22 ENCODER_STRUCTURE, 16 NV_ENC_ERR_RESOURCE_REGISTER_FAILED NV_ENC_CAPS_SUPPORT_YUV444_ENCODE ENCODER_STRUCTURE, 22 ENCODER_STRUCTURE, 17 NV_ENC_ERR_UNIMPLEMENTED NV_ENC_CAPS_SUPPORTED_RATECONTROL_-ENCODER_STRUCTURE, 22 **MODES** NV_ENC_ERR_UNSUPPORTED_DEVICE **ENCODER_STRUCTURE, 15** ENCODER_STRUCTURE, 21 NV_ENC_CAPS_WIDTH_MAX NV_ENC_ERR_UNSUPPORTED_PARAM ENCODER_STRUCTURE, 16 ENCODER STRUCTURE, 21 NV ENC DEVICE TYPE CUDA NV_ENC_H264_ADAPTIVE_TRANSFORM_-ENCODER STRUCTURE, 18 AUTOSELECT

ENCODER STRUCTURE, 18 **ENCODER STRUCTURE, 19** NV_ENC_H264_ADAPTIVE_TRANSFORM_-NV_ENC_PARAMS_FRAME_FIELD_MODE_-DISABLE **FRAME** ENCODER_STRUCTURE, 18 ENCODER_STRUCTURE, 19 NV_ENC_H264_ADAPTIVE_TRANSFORM_-NV ENC PARAMS FRAME FIELD MODE -**ENABLE MBAFF ENCODER STRUCTURE, 18 ENCODER STRUCTURE, 19** NV_ENC_H264_BDIRECT_MODE_AUTOSELECT NV ENC PARAMS RC CBR **ENCODER STRUCTURE, 18** ENCODER_STRUCTURE, 20 NV_ENC_PARAMS_RC_CBR_HQ NV_ENC_H264_BDIRECT_MODE_DISABLE ENCODER_STRUCTURE, 18 ENCODER_STRUCTURE, 20 NV_ENC_H264_BDIRECT_MODE_SPATIAL NV_ENC_PARAMS_RC_CBR_LOWDELAY_HQ ENCODER_STRUCTURE, 18 ENCODER_STRUCTURE, 20 NV_ENC_PARAMS_RC_CONSTQP NV_ENC_H264_BDIRECT_MODE_TEMPORAL **ENCODER_STRUCTURE, 18** ENCODER_STRUCTURE, 20 NV_ENC_H264_ENTROPY_CODING_MODE_-NV_ENC_PARAMS_RC_VBR AUTOSELECT ENCODER_STRUCTURE, 20 **ENCODER STRUCTURE, 18** NV ENC PARAMS RC VBR HO NV_ENC_H264_ENTROPY_CODING_MODE_-ENCODER_STRUCTURE, 20 **CABAC** NV ENC PIC FLAG EOS ENCODER_STRUCTURE, 18 ENCODER_STRUCTURE, 20 NV_ENC_H264_ENTROPY_CODING_MODE_-NV ENC PIC FLAG FORCEIDR ENCODER_STRUCTURE, 20 CAVLC **ENCODER STRUCTURE, 18** NV ENC PIC FLAG FORCEINTRA NV ENC H264 FMO AUTOSELECT ENCODER STRUCTURE, 20 **ENCODER STRUCTURE, 18** NV ENC PIC FLAG OUTPUT SPSPPS NV_ENC_H264_FMO_DISABLE ENCODER_STRUCTURE, 20 NV_ENC_PIC_STRUCT_FIELD_BOTTOM_TOP ENCODER_STRUCTURE, 18 NV_ENC_H264_FMO_ENABLE ENCODER_STRUCTURE, 20 ENCODER_STRUCTURE, 18 NV_ENC_PIC_STRUCT_FIELD_TOP_BOTTOM NV_ENC_INPUT_RESOURCE_TYPE_CUDAARRAY ENCODER_STRUCTURE, 20 ENCODER_STRUCTURE, 19 NV_ENC_PIC_STRUCT_FRAME NV_ENC_INPUT_RESOURCE_TYPE_-ENCODER_STRUCTURE, 20 CUDADEVICEPTR NV_ENC_PIC_TYPE_B **ENCODER STRUCTURE, 19 ENCODER STRUCTURE, 20** NV_ENC_INPUT_RESOURCE_TYPE_DIRECTX NV_ENC_PIC_TYPE_BI ENCODER STRUCTURE, 19 ENCODER STRUCTURE, 20 NV_ENC_MEMORY_HEAP_AUTOSELECT NV_ENC_PIC_TYPE_I **ENCODER STRUCTURE, 19** ENCODER_STRUCTURE, 20 NV_ENC_MEMORY_HEAP_SYSMEM_CACHED NV_ENC_PIC_TYPE_IDR **ENCODER STRUCTURE, 19 ENCODER STRUCTURE, 20** NV ENC PIC TYPE INTRA REFRESH NV ENC MEMORY HEAP SYSMEM UNCACHED **ENCODER STRUCTURE, 19** ENCODER_STRUCTURE, 20 NV_ENC_MEMORY_HEAP_VID NV_ENC_PIC_TYPE_P ENCODER_STRUCTURE, 19 ENCODER_STRUCTURE, 20 NV_ENC_PIC_TYPE_SKIPPED NV_ENC_MV_PRECISION_DEFAULT ENCODER_STRUCTURE, 19 ENCODER_STRUCTURE, 20 NV_ENC_MV_PRECISION_FULL_PEL NV_ENC_PIC_TYPE_UNKNOWN ENCODER_STRUCTURE, 19 ENCODER_STRUCTURE, 20 NV_ENC_MV_PRECISION_HALF_PEL NV_ENC_STEREO_PACKING_MODE_-**ENCODER_STRUCTURE, 19** CHECKERBOARD NV_ENC_MV_PRECISION_QUARTER_PEL ENCODER STRUCTURE, 21 **ENCODER STRUCTURE, 19** NV_ENC_STEREO_PACKING_MODE_-NV ENC PARAMS FRAME FIELD MODE FIELD COLINTERLEAVE

ENCODER_STRUCTURE, 21	enableIntraRefresh, 56
NV_ENC_STEREO_PACKING_MODE_FRAMESEQ	enableLTR, 56
ENCODER_STRUCTURE, 21	enableStereoMVC, 56
NV_ENC_STEREO_PACKING_MODE_NONE	enableTemporalSVC, 57
ENCODER_STRUCTURE, 21	enableVFR, 57
NV_ENC_STEREO_PACKING_MODE	entropyCodingMode, 57
ROWINTERLEAVE	fmoMode, 57
ENCODER_STRUCTURE, 21	h264VUIParameters, 57
NV_ENC_STEREO_PACKING_MODE_SIDEBYSIDE	hierarchicalBFrames, 57
ENCODER_STRUCTURE, 21	hierarchicalPFrames, 57
NV_ENC_STEREO_PACKING_MODE	idrPeriod, 57
TOPBOTTOM	intraRefreshCnt, 57
ENCODER_STRUCTURE, 21	intraRefreshPeriod, 57
NV_ENC_SUCCESS	level, 58
ENCODER_STRUCTURE, 21	ltrNumFrames, 58
NV_ENC_BUFFER_FORMAT	ltrTrustMode, 58
ENCODER_STRUCTURE, 14	maxNumRefFrames, 58
NV_ENC_CAPS	maxTemporalLayers, 58
ENCODER_STRUCTURE, 15	numTemporalLayers, 58
NV_ENC_CAPS_PARAM, 50	outputAUD, 58
capsToQuery, 50	outputBufferingPeriodSEI, 58
reserved, 50	outputFramePackingSEI, 58
version, 50	outputPictureTimingSEI, 58
NV_ENC_CAPS_PARAM_VER	outputRecoveryPointSEI, 59
ENCODER_STRUCTURE, 12	ppsId, 59
NV_ENC_CODEC_CONFIG, 51	qpPrimeYZeroTransformBypassFlag, 59
h264Config, 51	repeatSPSPPS, 59
h264MeOnlyConfig, 51	reserved1, 59
hevcConfig, 51	reserved2, 59
hevcMeOnlyConfig, 51	reservedBitFields, 59
reserved, 51	separateColourPlaneFlag, 59
NV_ENC_CODEC_PIC_PARAMS, 52	sliceMode, 59
h264PicParams, 52	sliceModeData, 59
hevePicParams, 52	spsId, 60
reserved, 52	stereoMode, 60
NV_ENC_CONFIG, 53	useConstrainedIntraPred, 60
encodeCodecConfig, 53	NV_ENC_CONFIG_H264_MEONLY, 61
frameFieldMode, 53	bStereoEnable, 61
frameIntervalP, 53	disableIntraSearch, 61
	disablePartition16x16, 61
gopLength, 53 monoChromeEncoding, 53	disablePartition16x8, 61
mvPrecision, 53	disablePartition8x16, 61
profileGUID, 54 rcParams, 54	disablePartition8x8, 61
reserved, 54	reserved, 61
reserved2, 54	reserved1, 62 reserved2, 62
version, 54	NV_ENC_CONFIG_H264_VUI_PARAMETERS, 63
NV_ENC_CONFIG_H264, 55	bitstreamRestrictionFlag, 63
adaptiveTransformMode, 56	chromaSampleLocationBot, 63
bdirectMode, 56	chromaSampleLocationFlag, 63
chromaFormatIDC, 56	chromaSampleLocationTop, 63
disableDeblockingFilterIDC, 56	colourDescriptionPresentFlag, 63
disable SPSPPS, 56	colourMatrix, 63
enableConstrainedEncoding, 56	colourPrimaries, 64

NV_	overscanInfo, 64 overscanInfoPresentFlag, 64 transferCharacteristics, 64 videoFormat, 64 videoFullRangeFlag, 64 videoSignalTypePresentFlag, 64 ENC_CONFIG_HEVC, 65 chromaFormatIDC, 65 disableDeblockAcrossSliceBoundary, 65 disableSPSPPS, 66	NV_	ENC_CREATE_INPUT_BUFFER, 72 bufferFmt, 72 height, 72 inputBuffer, 72 memoryHeap, 72 pSysMemBuffer, 72 reserved, 72 reserved1, 72 reserved2, 73 version, 73 width, 72
	enableIntraRefresh, 66 enableLTR, 66	NW	width, 73 _ENC_CREATE_INPUT_BUFFER_VER
	hevcVUIParameters, 66	111.	ENCODER_STRUCTURE, 12
	idrPeriod, 66	NV	_ENC_CREATE_MV_BUFFER, 74
	intraRefreshCnt, 66	_	mvBuffer, 74
	intraRefreshPeriod, 66		reserved1, 74
	level, 66		reserved2, 74
	ltrNumFrames, 66		version, 74
	ltrTrustMode, 66	NV_	_ENC_CREATE_MV_BUFFER_VER
	maxCUSize, 67		ENCODER_STRUCTURE, 12
	maxNumRefFramesInDPB, 67	NV.	_ENC_DEVICE_TYPE
	maxTemporalLayersMinus1, 67	NIX 7	ENCODER_STRUCTURE, 17
	minCUSize, 67 outputAUD, 67	NV.	_ENC_EVENT_PARAMS, 75 completionEvent, 75
	outputBufferingPeriodSEI, 67		reserved, 75
	outputPictureTimingSEI, 67		reserved1, 75
	pixelBitDepthMinus8, 67		reserved2, 75
	ppsId, 67		version, 75
	repeatSPSPPS, 67	NV	_ENC_EVENT_PARAMS_VER
	reserved, 67		ENCODER_STRUCTURE, 12
	reserved1, 68	NV_	_ENC_H264_ADAPTIVE_TRANSFORM_MODE
	reserved2, 68		ENCODER_STRUCTURE, 18
	sliceMode, 68	NV.	_ENC_H264_BDIRECT_MODE
	sliceModeData, 68	NIX 7	ENCODER_STRUCTURE, 18
	spsId, 68 tier, 68	IN V	_ENC_H264_ENTROPY_CODING_MODE ENCODER_STRUCTURE, 18
	useConstrainedIntraPred, 68	NV	ENC_H264_FMO_MODE
	vpsId, 68	14 4	ENCODER_STRUCTURE, 18
NV	ENC_CONFIG_HEVC_MEONLY, 69	NV	ENC_H264_MV_DATA, 76
_	reserved, 69	-	mbType, 76
	reserved1, 69		mv, 76
NV_{-}	ENC_CONFIG_VER		partitionType, 76
	ENCODER_STRUCTURE, 12		reserved, 76
NV_	ENC_CREATE_BITSTREAM_BUFFER, 70	NV_	_ENC_HEVC_CUSIZE
	bitstreamBuffer, 70	.	ENCODER_STRUCTURE, 18
	bitstreamBufferPtr, 70	NV_	_ENC_HEVC_MV_DATA, 77
	memoryHeap, 70		cuSize, 77
	reserved, 70 reserved1, 70		cuType, 77 lastCUInCTB, 77
	reserved2, 70		mv, 77
	size, 70		partitionMode, 77
	version, 71	NV	_ENC_INITIALIZE_PARAMS, 78
NV_	ENC_CREATE_BITSTREAM_BUFFER_VER		darHeight, 78
	ENCODER_STRUCTURE, 12		darWidth, 78

	enableEncodeAsync, 78		doNotWait, 85
	enableExternalMEHints, 78		inputBuffer, 85
	enableMEOnlyMode, 79		pitch, 85
	enablePTD, 79		reserved1, 85
	enableSubFrameWrite, 79		reserved2, 85
	encodeConfig, 79		reservedBitFields, 85
	encodeGUID, 79		version, 86
	encodeHeight, 79	NV	_ENC_LOCK_INPUT_BUFFER_VER
	encodeWidth, 79		ENCODER_STRUCTURE, 13
	frameRateDen, 79	NV	_ENC_MAP_INPUT_RESOURCE, 87
	frameRateNum, 79		inputResource, 87
	maxEncodeHeight, 80		mappedBufferFmt, 87
	maxEncodeWidth, 80		mappedResource, 87
	maxMEHintCountsPerBlock, 80		registeredResource, 87
	presetGUID, 80		reserved1, 87
	privData, 80		reserved2, 87
	privDataSize, 80		subResourceIndex, 87
	reportSliceOffsets, 80		version, 88
	reserved, 80	NV	_ENC_MAP_INPUT_RESOURCE_VER
	reserved2, 80	-	ENCODER_STRUCTURE, 13
	reservedBitFields, 81	NV	_ENC_MEMORY_HEAP
	version, 81	-	ENCODER_STRUCTURE, 19
NV	_ENC_INITIALIZE_PARAMS_VER	NV	_ENC_MEONLY_PARAMS, 89
	ENCODER_STRUCTURE, 13		bufferFmt, 89
NV	_ENC_INPUT_RESOURCE_TYPE		completionEvent, 89
	ENCODER_STRUCTURE, 19		inputBuffer, 89
NV	_ENC_LEVEL		inputHeight, 89
	ENCODER_STRUCTURE, 19		inputWidth, 89
NV	_ENC_LOCK_BITSTREAM, 82		mvBuffer, 89
	bitstreamBufferPtr, 82		referenceFrame, 90
	bitstreamSizeInBytes, 82		reserved1, 90
	doNotWait, 82		reserved2, 90
	frameAvgQP, 82		version, 90
	frameIdx, 83		viewID, 90
	frameSatd, 83	NV	_ENC_MEONLY_PARAMS_VER
	hwEncodeStatus, 83	-	ENCODER_STRUCTURE, 13
	ltrFrame, 83	NV	_ENC_MV_PRECISION
	ltrFrameBitmap, 83		ENCODER_STRUCTURE, 19
	ltrFrameIdx, 83	NV	_ENC_MVECTOR, 91
	numSlices, 83		mvx, 91
	outputBitstream, 83		mvy, 91
	outputDuration, 83	NV	_ENC_OPEN_ENCODE_SESSION_EX_PARAMS,
	outputTimeStamp, 83		92
	pictureStruct, 83		apiVersion, 92
	pictureType, 84		device, 92
	reserved, 84		deviceType, 92
	reserved2, 84		reserved, 92
	reservedBitFields, 84		reserved1, 92
	sliceOffsets, 84		reserved2, 92
	version, 84		version, 92
NV	_ENC_LOCK_BITSTREAM_VER	NV	_ENC_OPEN_ENCODE_SESSION_EX
	ENCODER_STRUCTURE, 13		PARAMS_VER
NV	_ENC_LOCK_INPUT_BUFFER, 85		ENCODER_STRUCTURE, 13
	bufferDataPtr, 85	NV	_ENC_PARAMS_FRAME_FIELD_MODE
	,		

	ENCODER_STRUCTURE, 19		reserved3, 99
NV_	ENC_PARAMS_RC_2_PASS_FRAMESIZE_CAP		reservedBitFields, 99
	ENCODER_STRUCTURE, 13		seiPayloadArray, 99
NV_	ENC_PARAMS_RC_2_PASS_QUALITY		seiPayloadArrayCnt, 100
	ENCODER_STRUCTURE, 13		sliceMode, 100
NV_	ENC_PARAMS_RC_2_PASS_VBR		sliceModeData, 100
	ENCODER_STRUCTURE, 13		sliceModeDataUpdate, 100
NV_	_ENC_PARAMS_RC_CBR2		sliceTypeArrayCnt, 100
	ENCODER_STRUCTURE, 13		sliceTypeData, 100
NV_	ENC_PARAMS_RC_MODE	NV_	_ENC_PIC_PARAMS_HEVC, 101
	ENCODER_STRUCTURE, 19		constrainedFrame, 101
NV_	_ENC_PARAMS_RC_VBR_MINQP		displayPOCSyntax, 101
	ENCODER_STRUCTURE, 13		forceIntraRefreshWithFrameCnt, 101
NV_	ENC_PIC_FLAGS		ltrMarkFrame, 101
	ENCODER_STRUCTURE, 20		ltrMarkFrameIdx, 102
NV_	ENC_PIC_PARAMS, 94		ltrUsageMode, 102
	bufferFmt, 94		ltrUseFrameBitmap, 102
	codecPicParams, 94		ltrUseFrames, 102
	completionEvent, 94		refPicFlag, 102
	encodePicFlags, 95		reserved, 102
	frameIdx, 95		reserved2, 102
	inputBuffer, 95		reserved3, 102
	inputDuration, 95		reservedBitFields, 102
	inputHeight, 95		seiPayloadArray, 102
	inputPitch, 95		seiPayloadArrayCnt, 102
	inputTimeStamp, 95		sliceMode, 103
	inputWidth, 95		sliceModeData, 103
	meExternalHints, 95		sliceModeDataUpdate, 103
	meHintCountsPerBlock, 95		sliceTypeArrayCnt, 103
	meHintRefPicDist, 96		sliceTypeData, 103
	outputBitstream, 96		temporalId, 103
	pictureStruct, 96	$NV_{}$	_ENC_PIC_PARAMS_VER
	pictureType, 96		ENCODER_STRUCTURE, 14
	qpDeltaMap, 96	$NV_{}$	_ENC_PIC_STRUCT
	qpDeltaMapSize, 96		ENCODER_STRUCTURE, 20
	reserved1, 96	$NV_{}$	_ENC_PIC_TYPE
	reserved2, 96		ENCODER_STRUCTURE, 20
	reserved3, 96	NV	_ENC_PRESET_CONFIG, 104
	reserved4, 97		presetCfg, 104
	reservedBitFields, 97		reserved1, 104
	version, 97		reserved2, 104
NV	ENC_PIC_PARAMS_H264, 98		version, 104
	colourPlaneId, 98	NV	_ENC_PRESET_CONFIG_VER
	constrainedFrame, 98		ENCODER_STRUCTURE, 14
	displayPOCSyntax, 98	NV	ENC_QP, 105
	forceIntraRefreshWithFrameCnt, 98		ENC_RC_PARAMS, 106
	ltrMarkFrame, 99		aqStrength, 106
	ltrMarkFrameIdx, 99		averageBitRate, 106
	ltrUsageMode, 99		constQP, 106
	ltrUseFrameBitmap, 99		disableBadapt, 107
	ltrUseFrames, 99		disableIadapt, 107
	refPicFlag, 99		enableAQ, 107
	reserved, 99		enableExtQPDeltaMap, 107
	reserved2, 99		enableInitialRCQP, 107
	· · · · · · · · · · · · · · · · · · ·		~ /

enableLookahead, 107	version, 115
enableMaxQP, 107	NV_ENC_SEQUENCE_PARAM_PAYLOAD_VER
enableMinQP, 107	ENCODER_STRUCTURE, 14
enableNonRefP, 107	NV_ENC_STAT, 116
enableTemporalAQ, 107	bitStreamSize, 116
initialRCQP, 107	lastValidByteOffset, 116
lookaheadDepth, 108	outputBitStream, 116
maxBitRate, 108	picIdx, 116
maxQP, 108	picType, 116
minQP, 108	reserved, 116
rateControlMode, 108	reserved1, 116
reservedBitFields, 108	reserved2, 117
strictGOPTarget, 108	sliceOffsets, 117
<u> </u>	
targetQuality, 108	version, 117
temporallayerIdxMask, 108	NV_ENC_STAT_VER
temporalLayerQP, 108	ENCODER_STRUCTURE, 14
vbvBufferSize, 108	NV_ENC_STEREO_PACKING_MODE
vbvInitialDelay, 109	ENCODER_STRUCTURE, 20
zeroReorderDelay, 109	NV_ENCODE_API_FUNCTION_LIST, 118
NV_ENC_RC_PARAMS_VER	nvEncCreateBitstreamBuffer, 119
ENCODER_STRUCTURE, 14	nvEncCreateInputBuffer, 119
NV_ENC_RECONFIGURE_PARAMS, 110	nvEncCreateMVBuffer, 119
forceIDR, 110	nvEncDestroyBitstreamBuffer, 119
reInitEncodeParams, 110	nvEncDestroyEncoder, 119
resetEncoder, 110	nvEncDestroyInputBuffer, 119
version, 110	nvEncDestroyMVBuffer, 119
NV_ENC_RECONFIGURE_PARAMS_VER	nvEncEncodePicture, 119
ENCODER_STRUCTURE, 14	nvEncGetEncodeCaps, 119
NV_ENC_REGISTER_RESOURCE, 111	nvEncGetEncodeGUIDCount, 119
bufferFormat, 111	nvEncGetEncodeGUIDs, 119
height, 111	nvEncGetEncodePresetConfig, 120
pitch, 111	nvEncGetEncodePresetCount, 120
•	
registeredResource, 111	nvEncGetEncodePresetGUIDs, 120
reserved1, 111	nvEncGetEncodeProfileGUIDCount, 120
reserved2, 111	nvEncGetEncodeProfileGUIDs, 120
resourceToRegister, 111	nvEncGetEncodeStats, 120
resourceType, 112	nvEncGetInputFormatCount, 120
subResourceIndex, 112	nvEncGetInputFormats, 120
version, 112	nvEncGetSequenceParams, 120
width, 112	nvEncInitializeEncoder, 120
NV_ENC_REGISTER_RESOURCE_VER	nvEncInvalidateRefFrames, 121
ENCODER_STRUCTURE, 14	nvEncLockBitstream, 121
NV_ENC_SEI_PAYLOAD, 113	nvEncLockInputBuffer, 121
payload, 113	nvEncMapInputResource, 121
payloadSize, 113	nvEncOpenEncodeSession, 121
payloadType, 113	nvEncOpenEncodeSessionEx, 121
NV_ENC_SEQUENCE_PARAM_PAYLOAD, 114	nvEncReconfigureEncoder, 121
inBufferSize, 114	nvEncRegisterAsyncEvent, 121
outSPSPPSPayloadSize, 114	nvEncRegisterResource, 121
ppsId, 114	nvEncRunMotionEstimationOnly, 121
reserved, 114	nvEncUnlockBitstream, 122
reserved2, 114	nvEncUnlockInputBuffer, 122
spsId, 114	nvEncUnmapInputResource, 122
spspus Buffer, 114	nvEncUnregisterAsyncEvent, 122
spsppsbutter, 114	nvencomegister Asynce vent, 122

nvEncUnregisterResource, 122	ENCODE_FUNC, 29
reserved, 122	nvEncEncodePicture
reserved2, 122	NV_ENCODE_API_FUNCTION_LIST, 119
version, 122	NvEncGetEncodeCaps
NVENC_EXTERNAL_ME_HINT, 123	ENCODE_FUNC, 31
dir, 123	nvEncGetEncodeCaps
lastOfMB, 123	NV_ENCODE_API_FUNCTION_LIST, 119
lastofPart, 123	NvEncGetEncodeGUIDCount
mvx, 123	ENCODE FUNC, 32
mvy, 123	nvEncGetEncodeGUIDCount
partType, 123	NV_ENCODE_API_FUNCTION_LIST, 119
refidx, 123	NvEncGetEncodeGUIDs
NVENC_EXTERNAL_ME_HINT_COUNTS_PER	ENCODE_FUNC, 32
BLOCKTYPE, 125	nvEncGetEncodeGUIDs
numCandsPerBlk16x16, 125	NV_ENCODE_API_FUNCTION_LIST, 119
numCandsPerBlk16x8, 125	NvEncGetEncodePresetConfig
numCandsPerBlk8x16, 125	ENCODE_FUNC, 33
numCandsPerBlk8x8, 125	nvEncGetEncodePresetConfig
reserved, 125	NV_ENCODE_API_FUNCTION_LIST, 120
reserved1, 125	NvEncGetEncodePresetCount
NVENC_RECT, 126	ENCODE FUNC, 33
bottom, 126	nvEncGetEncodePresetCount
left, 126	NV_ENCODE_API_FUNCTION_LIST, 120
right, 126	NvEncGetEncodePresetGUIDs
•	ENCODE_FUNC, 34
top, 126 NvEncCreateBitstreamBuffer	
	nvEncGetEncodePresetGUIDs
ENCODE_FUNC, 26	NV_ENCODE_API_FUNCTION_LIST, 120
nvEncCreateBitstreamBuffer	NvEncGetEncodeProfileGUIDCount
NV_ENCODE_API_FUNCTION_LIST, 119	ENCODE_FUNC, 34
NvEncCreateInputBuffer	nvEncGetEncodeProfileGUIDCount
ENCODE_FUNC, 26	NV_ENCODE_API_FUNCTION_LIST, 120
nvEncCreateInputBuffer	NvEncGetEncodeProfileGUIDs
NV_ENCODE_API_FUNCTION_LIST, 119	ENCODE_FUNC, 35
NvEncCreateMVBuffer	nvEncGetEncodeProfileGUIDs
ENCODE_FUNC, 26	NV_ENCODE_API_FUNCTION_LIST, 120
nvEncCreateMVBuffer	NvEncGetEncodeStats
NV_ENCODE_API_FUNCTION_LIST, 119	ENCODE_FUNC, 35
NvEncDestroyBitstreamBuffer	nvEncGetEncodeStats
ENCODE_FUNC, 27	NV_ENCODE_API_FUNCTION_LIST, 120
nvEncDestroyBitstreamBuffer	NvEncGetInputFormatCount
NV_ENCODE_API_FUNCTION_LIST, 119	ENCODE_FUNC, 36
NvEncDestroyEncoder	nvEncGetInputFormatCount
ENCODE_FUNC, 27	NV_ENCODE_API_FUNCTION_LIST, 120
nvEncDestroyEncoder	NvEncGetInputFormats
NV_ENCODE_API_FUNCTION_LIST, 119	ENCODE_FUNC, 36
NvEncDestroyInputBuffer	nvEncGetInputFormats
ENCODE_FUNC, 28	NV_ENCODE_API_FUNCTION_LIST, 120
nvEncDestroyInputBuffer	NvEncGetSequenceParams
NV_ENCODE_API_FUNCTION_LIST, 119	ENCODE_FUNC, 37
NvEncDestroyMVBuffer	nvEncGetSequenceParams
ENCODE_FUNC, 28	NV_ENCODE_API_FUNCTION_LIST, 120
nvEncDestroyMVBuffer	NvEncInitializeEncoder
NV_ENCODE_API_FUNCTION_LIST, 119	ENCODE_FUNC, 37
NvEncEncodePicture	nvEncInitializeEncoder

NV_ENCODE_API_FUNCTION_LIST, 120	ENCODE_FUNC, 45
NvEncInvalidateRefFrames	nvEncUnlockInputBuffer
ENCODE_FUNC, 39	NV_ENCODE_API_FUNCTION_LIST, 122
nvEncInvalidateRefFrames	NvEncUnmapInputResource
NV_ENCODE_API_FUNCTION_LIST, 121	ENCODE_FUNC, 45
NvEncLockBitstream	nvEncUnmapInputResource
ENCODE_FUNC, 39	NV_ENCODE_API_FUNCTION_LIST, 122
nvEncLockBitstream	NvEncUnregisterAsyncEvent
NV_ENCODE_API_FUNCTION_LIST, 121	ENCODE_FUNC, 46
NvEncLockInputBuffer	nvEncUnregisterAsyncEvent
ENCODE_FUNC, 40	NV_ENCODE_API_FUNCTION_LIST, 122
nvEncLockInputBuffer	NvEncUnregisterResource
NV_ENCODE_API_FUNCTION_LIST, 121	ENCODE_FUNC, 46
NvEncMapInputResource	nvEncUnregisterResource
ENCODE_FUNC, 40	NV_ENCODE_API_FUNCTION_LIST, 122
nvEncMapInputResource	
NV_ENCODE_API_FUNCTION_LIST, 121	outputAUD
NvEncodeAPI Data structures, 7	NV_ENC_CONFIG_H264, 58
NvEncodeAPI Functions, 23	NV_ENC_CONFIG_HEVC, 67
NvEncodeAPICreateInstance	outputBitStream
ENCODE_FUNC, 41	NV_ENC_STAT, 116
NvEncodeAPIGetMaxSupportedVersion	outputBitstream
ENCODE_FUNC, 41	NV_ENC_LOCK_BITSTREAM, 83
NvEncOpenEncodeSession	NV_ENC_PIC_PARAMS, 96
ENCODE_FUNC, 42	outputBufferingPeriodSEI
nvEncOpenEncodeSession	NV_ENC_CONFIG_H264, 58
NV_ENCODE_API_FUNCTION_LIST, 121	NV_ENC_CONFIG_HEVC, 67
NvEncOpenEncodeSessionEx	outputDuration
ENCODE_FUNC, 42	NV_ENC_LOCK_BITSTREAM, 83
nvEncOpenEncodeSessionEx	outputFramePackingSEI
NV_ENCODE_API_FUNCTION_LIST, 121	NV_ENC_CONFIG_H264, 58
NvEncReconfigureEncoder	outputPictureTimingSEI
ENCODE_FUNC, 42	NV_ENC_CONFIG_H264, 58
nvEncReconfigureEncoder	NV_ENC_CONFIG_HEVC, 67
NV_ENCODE_API_FUNCTION_LIST, 121	outputRecoveryPointSEI
NvEncRegisterAsyncEvent	NV_ENC_CONFIG_H264, 59
ENCODE_FUNC, 43	outputTimeStamp
nvEncRegisterAsyncEvent	NV_ENC_LOCK_BITSTREAM, 83
NV_ENCODE_API_FUNCTION_LIST, 121	outSPSPPSPayloadSize
NvEncRegisterResource	NV_ENC_SEQUENCE_PARAM_PAYLOAD, 114
ENCODE_FUNC, 43	overscanInfo
nvEncRegisterResource	NV_ENC_CONFIG_H264_VUI_PARAMETERS,
NV_ENCODE_API_FUNCTION_LIST, 121	64
NvEncRunMotionEstimationOnly	overscanInfoPresentFlag
ENCODE_FUNC, 44	NV_ENC_CONFIG_H264_VUI_PARAMETERS,
nvEncRunMotionEstimationOnly	64
NV_ENCODE_API_FUNCTION_LIST, 121	
NVENCSTATUS	partitionMode
ENCODER_STRUCTURE, 21	NV_ENC_HEVC_MV_DATA, 77
NvEncUnlockBitstream	partitionType
ENCODE_FUNC, 44	NV_ENC_H264_MV_DATA, 76
nvEncUnlockBitstream	partType
NV_ENCODE_API_FUNCTION_LIST, 122	NVENC_EXTERNAL_ME_HINT, 123
NvEncUnlockInputBuffer	payload

NV_ENC_SEI_PAYLOAD, 113	NV_ENC_PIC_PARAMS_HEVC, 102
payloadSize	registeredResource
NV_ENC_SEI_PAYLOAD, 113	NV_ENC_MAP_INPUT_RESOURCE, 87
	NV_ENC_REGISTER_RESOURCE, 111
payloadType NY ENC SEL PAYLOAD 112	reInitEncodeParams
NV_ENC_SEI_PAYLOAD, 113	
picIdx	NV_ENC_RECONFIGURE_PARAMS, 110
NV_ENC_STAT, 116	repeatSPSPPS
pictureStruct	NV_ENC_CONFIG_H264, 59
NV_ENC_LOCK_BITSTREAM, 83	NV_ENC_CONFIG_HEVC, 67
NV_ENC_PIC_PARAMS, 96	reportSliceOffsets
pictureType	NV_ENC_INITIALIZE_PARAMS, 80
NV_ENC_LOCK_BITSTREAM, 84	reserved
NV_ENC_PIC_PARAMS, 96	NV_ENC_CAPS_PARAM, 50
picType	NV_ENC_CODEC_CONFIG, 51
NV_ENC_STAT, 116	NV_ENC_CODEC_PIC_PARAMS, 52
pitch	NV_ENC_CONFIG, 54
NV_ENC_LOCK_INPUT_BUFFER, 85	NV_ENC_CONFIG_H264_MEONLY, 61
NV_ENC_REGISTER_RESOURCE, 111	NV_ENC_CONFIG_HEVC, 67
pixelBitDepthMinus8	NV_ENC_CONFIG_HEVC_MEONLY, 69
NV_ENC_CONFIG_HEVC, 67	NV_ENC_CREATE_BITSTREAM_BUFFER, 70
ppsId	NV_ENC_CREATE_INPUT_BUFFER, 72
NV_ENC_CONFIG_H264, 59	NV_ENC_EVENT_PARAMS, 75
NV_ENC_CONFIG_HEVC, 67	NV_ENC_H264_MV_DATA, 76
NV_ENC_SEQUENCE_PARAM_PAYLOAD, 114	NV_ENC_INITIALIZE_PARAMS, 80
presetCfg	NV_ENC_LOCK_BITSTREAM, 84
NV_ENC_PRESET_CONFIG, 104	NV_ENC_OPEN_ENCODE_SESSION_EX
presetGUID	PARAMS, 92
NV_ENC_INITIALIZE_PARAMS, 80	NV_ENC_PIC_PARAMS_H264, 99
privData	NV_ENC_PIC_PARAMS_HEVC, 102
NV_ENC_INITIALIZE_PARAMS, 80	NV_ENC_SEQUENCE_PARAM_PAYLOAD, 114
privDataSize	NV_ENC_STAT, 116
NV_ENC_INITIALIZE_PARAMS, 80	NV_ENCODE_API_FUNCTION_LIST, 122
profileGUID	NVENC_EXTERNAL_ME_HINT_COUNTS
•	PER_BLOCKTYPE, 125
NV_ENC_CONFIG, 54	
pSysMemBuffer	reserved1
NV_ENC_CREATE_INPUT_BUFFER, 72	NV_ENC_CONFIG_H264, 59
qpDeltaMap	NV_ENC_CONFIG_H264_MEONLY, 62
	NV_ENC_CONFIG_HEVC, 68
NV_ENC_PIC_PARAMS, 96	NV_ENC_CONFIG_HEVC_MEONLY, 69
qpDeltaMapSize	NV_ENC_CREATE_BITSTREAM_BUFFER, 70
NV_ENC_PIC_PARAMS, 96	NV_ENC_CREATE_INPUT_BUFFER, 72
qpPrimeYZeroTransformBypassFlag	NV_ENC_CREATE_MV_BUFFER, 74
NV_ENC_CONFIG_H264, 59	NV_ENC_EVENT_PARAMS, 75
mata Cantual Mada	NV_ENC_LOCK_INPUT_BUFFER, 85
rateControlMode	NV_ENC_MAP_INPUT_RESOURCE, 87
NV_ENC_RC_PARAMS, 108	NV_ENC_MEONLY_PARAMS, 90
rcParams	NV_ENC_OPEN_ENCODE_SESSION_EX
NV_ENC_CONFIG, 54	PARAMS, 92
referenceFrame	NV_ENC_PIC_PARAMS, 96
NV_ENC_MEONLY_PARAMS, 90	NV_ENC_PRESET_CONFIG, 104
refidx	NV_ENC_REGISTER_RESOURCE, 111
NVENC_EXTERNAL_ME_HINT, 123	NV_ENC_STAT, 116
refPicFlag	NVENC_EXTERNAL_ME_HINT_COUNTS
NV_ENC_PIC_PARAMS_H264, 99	PER_BLOCKTYPE, 125

reserved2	separateColourPlaneFlag
NV_ENC_CONFIG, 54	NV_ENC_CONFIG_H264, 59
NV_ENC_CONFIG_H264, 59	size
NV_ENC_CONFIG_H264_MEONLY, 62	NV_ENC_CREATE_BITSTREAM_BUFFER, 70
NV_ENC_CONFIG_HEVC, 68	sliceMode
NV_ENC_CREATE_BITSTREAM_BUFFER, 70	NV_ENC_CONFIG_H264, 59
NV_ENC_CREATE_INPUT_BUFFER, 73	NV_ENC_CONFIG_HEVC, 68
NV_ENC_CREATE_MV_BUFFER, 74	NV_ENC_PIC_PARAMS_H264, 100
NV_ENC_EVENT_PARAMS, 75	NV_ENC_PIC_PARAMS_HEVC, 103
NV_ENC_INITIALIZE_PARAMS, 80	sliceModeData
NV_ENC_LOCK_BITSTREAM, 84	NV_ENC_CONFIG_H264, 59
NV_ENC_LOCK_INPUT_BUFFER, 85	NV_ENC_CONFIG_HEVC, 68
NV_ENC_MAP_INPUT_RESOURCE, 87	NV_ENC_PIC_PARAMS_H264, 100
NV_ENC_MEONLY_PARAMS, 90	NV_ENC_PIC_PARAMS_HEVC, 103
NV_ENC_OPEN_ENCODE_SESSION_EX	sliceModeDataUpdate
PARAMS, 92	NV_ENC_PIC_PARAMS_H264, 100
NV_ENC_PIC_PARAMS, 96	NV_ENC_PIC_PARAMS_HEVC, 103
NV_ENC_PIC_PARAMS_H264, 99	sliceOffsets
NV_ENC_PIC_PARAMS_HEVC, 102	NV_ENC_LOCK_BITSTREAM, 84
NV_ENC_PRESET_CONFIG, 104	NV ENC STAT, 117
NV_ENC_REGISTER_RESOURCE, 111	sliceTypeArrayCnt
NV_ENC_SEQUENCE_PARAM_PAYLOAD, 114	NV_ENC_PIC_PARAMS_H264, 100
NV_ENC_STAT, 117	NV ENC PIC PARAMS HEVC, 103
NV_ENCODE_API_FUNCTION_LIST, 122	sliceTypeData
reserved3	NV_ENC_PIC_PARAMS_H264, 100
NV_ENC_PIC_PARAMS, 96	NV_ENC_PIC_PARAMS_HEVC, 103
NV_ENC_PIC_PARAMS_H264, 99	spsId
NV_ENC_PIC_PARAMS_HEVC, 102	NV_ENC_CONFIG_H264, 60
reserved4	NV_ENC_CONFIG_HEVC, 68
NV_ENC_PIC_PARAMS, 97	NV_ENC_SEQUENCE_PARAM_PAYLOAD, 114
reservedBitFields	spsppsBuffer
NV_ENC_CONFIG_H264, 59	NV_ENC_SEQUENCE_PARAM_PAYLOAD, 114
NV_ENC_INITIALIZE_PARAMS, 81	stereoMode
NV_ENC_LOCK_BITSTREAM, 84	NV_ENC_CONFIG_H264, 60
NV_ENC_LOCK_INPUT_BUFFER, 85	strictGOPTarget
NV_ENC_PIC_PARAMS, 97	NV_ENC_RC_PARAMS, 108
NV_ENC_PIC_PARAMS_H264, 99	subResourceIndex
NV_ENC_PIC_PARAMS_HEVC, 102	NV_ENC_MAP_INPUT_RESOURCE, 87
NV_ENC_RC_PARAMS, 108	NV_ENC_REGISTER_RESOURCE, 112
resetEncoder	TV_LIVE_REGISTER_REGOURCE, 112
NV_ENC_RECONFIGURE_PARAMS, 110	targetQuality
resourceToRegister	NV_ENC_RC_PARAMS, 108
NV_ENC_REGISTER_RESOURCE, 111	temporalId
resourceType	NV_ENC_PIC_PARAMS_HEVC, 103
NV_ENC_REGISTER_RESOURCE, 112	temporallayerIdxMask
	NV_ENC_RC_PARAMS, 108
right	temporalLayerQP
NVENC_RECT, 126	NV_ENC_RC_PARAMS, 108
seiPayloadArray	tier
NV_ENC_PIC_PARAMS_H264, 99	NV_ENC_CONFIG_HEVC, 68
NV_ENC_PIC_PARAMS_HEVC, 102	top
seiPayloadArrayCnt	NVENC_RECT, 126
NV_ENC_PIC_PARAMS_H264, 100	transferCharacteristics
NV_ENC_PIC_PARAMS_HEVC, 102	tunistes Characteristics

```
NV_ENC_CONFIG_H264_VUI_PARAMETERS,
       64
useConstrainedIntraPred
   NV_ENC_CONFIG_H264, 60
   NV_ENC_CONFIG_HEVC, 68
vbvBufferSize
   NV_ENC_RC_PARAMS, 108
vbvInitialDelay
   NV_ENC_RC_PARAMS, 109
version
   NV_ENC_CAPS_PARAM, 50
   NV ENC CONFIG, 54
   NV_ENC_CREATE_BITSTREAM_BUFFER, 71
   NV ENC CREATE INPUT BUFFER, 73
   NV ENC CREATE MV BUFFER, 74
   NV_ENC_EVENT_PARAMS, 75
   NV ENC INITIALIZE PARAMS, 81
   NV_ENC_LOCK_BITSTREAM, 84
   NV ENC LOCK INPUT BUFFER, 86
   NV_ENC_MAP_INPUT_RESOURCE, 88
   NV ENC MEONLY PARAMS, 90
   NV_ENC_OPEN_ENCODE_SESSION_EX_-
       PARAMS, 92
   NV_ENC_PIC_PARAMS, 97
   NV_ENC_PRESET_CONFIG, 104
   NV_ENC_RECONFIGURE_PARAMS, 110
   NV_ENC_REGISTER_RESOURCE, 112
   NV_ENC_SEQUENCE_PARAM_PAYLOAD, 115
   NV_ENC_STAT, 117
   NV_ENCODE_API_FUNCTION_LIST, 122
videoFormat
   NV ENC CONFIG H264 VUI PARAMETERS,
       64
videoFullRangeFlag
   NV_ENC_CONFIG_H264_VUI_PARAMETERS,
videoSignalTypePresentFlag
   NV_ENC_CONFIG_H264_VUI_PARAMETERS,
       64
viewID
   NV_ENC_MEONLY_PARAMS, 90
vpsId
   NV_ENC_CONFIG_HEVC, 68
width
   NV_ENC_CREATE_INPUT_BUFFER, 73
   NV_ENC_REGISTER_RESOURCE, 112
zeroReorderDelay
   NV_ENC_RC_PARAMS, 109
```

Notice

ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." NVIDIA MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NONINFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE.

Information furnished is believed to be accurate and reliable. However, NVIDIA Corporation assumes no responsibility for the consequences of use of such information or for any infringement of patents or other rights of third parties that may result from its use. No license is granted by implication of otherwise under any patent rights of NVIDIA Corporation. Specifications mentioned in this publication are subject to change without notice. This publication supersedes and replaces all other information previously supplied. NVIDIA Corporation products are not authorized as critical components in life support devices or systems without express written approval of NVIDIA Corporation.

Trademarks

NVIDIA and the NVIDIA logo are trademarks or registered trademarks of NVIDIA Corporation in the U.S. and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

Copyright

© 2011-2016 NVIDIA Corporation. All rights reserved.

