NAME

mbsegypsd − Calculates the power spectral densisty function (PSD) of each trace in a segy file, outputting the PSD estimates as a GMT grid file with trace number along the x axis and frequency along the y axis.

VERSION

Version 5.0

SYNOPSIS

mbsegypsd −I*file* **−O***root [−***A***shotscale* **−D***decimatex* **−R −S***mode[/start/end[/schan/echan]]* **−T***sweep[/delay]* **−W***mode/start/end* **−H −V];**

DESCRIPTION

mbsegypsd calculates the power spectral densisty function (PSD) of each trace in a segy file, outputting the PSD estimates as a grid with trace number along the x axis and frequency along the y axis. The output files are **GMT** netCDF format grid files.

The x-dimension of the grid is determined by the number of traces specified by the **−S** option and any decimation specified with option **−D**. If the**−S** option is not specified, then all of the traces in the se gy file will be processed. If the time sweep and delay (if any) are not specified using the **−T** option, then the sweep and delay will be set so that all trace samples are incorporated into the grid.

The y-dimension of the grid is determined by the sample interval in the time series data. The frequency range runs from zero Hz to a maximum frequency given in Hz by 1/(2*sampleinterval), where the sampleinterval is in seconds. So, for instance, hydrophone data sampled at 26 kHz (26000 samples/second) will have a sample interval of (1/26000 = 0.00003846 seconds). In this case, the PSD will be calculated for frequencies ranging from 0 Hz to 13000 Hz (13 kHz).

For each trace, the PSD will be calculated by ensemble averaging, which means that the trace will be broken up into a number of segments of length *nfft* (specified with the **−N** option, default = 1024), a fast-Fourier-transform (FFT) will be calculated for each segment, and the PSD estimate will be the average of the FFT magnitudes over all segments. Before the FFT is calculated, each segment is multiplied by a Hanning (cosine) taper; the PSD estimates are normalized to account for the loss of signal due to the taper application.

The output grid can be either in linear units (Intensity/Hz) or in log-scaled dB/Hz calculated as 20 * log10 (raw-PSD-value). The default is the former, and the **−L** option causes output in the dB/Hz form.

A shellscript invoking **GMT** programs to plot the PSD grid is automatically generated.

MB-SYSTEM AUTHORSHIP

David W. Caress
Monterey Bay Aquarium Research Institute
Dale N. Chayes
Center for Coastal and Ocean Mapping
University of New Hampshire
Christian do Santos Ferreira
MARUM - Center for Marine Environmental Sciences
University of Bremen

OPTIONS

−A *shotscale*
This option causes the x-axis to be rescaled from shot number to distance in meters. The *shotscale* value represents the shot spacing in meters.

−D *decimatex*
Sets the decimation of traces (*decimatex*) used in generating the output grid.

−H This "help" flag cause the program to print out a description of its operation and then exit immediately.

−I *segyfile*
Sets the filename of the input segy seismic data file to be gridded.

−L
Sets the PSD grid output to be in dB/Hz.

−O *root*
Sets the filename root for the output GMT netCDF format grid.

−S *mode[/start/end[/schan/echan]]*
This option sets the range of traces that are gridded, and thus determines the x-dimension of the output grid (also impacted by any decimation specified with **−D**). If *mode* = 0, then *start* and *end* refer to shot numbers. This typically is useful for subbottom data or seismic data in shot gather form. If *mode* = 1, then *start* and *end* refer to CMP (or RP or CDP) numbers. This typically is useful for seismic reflection data in stacked or CMP gather forms. If the data are multichannel seismic reflection or seismic refraction in either shot or CMP gathers, the start and end of the channels selected for gridding is set using the optional *schan* and *echan*, respectively. The x-dimension of the output grid is determined by (*end* − *start* + 1) * (*echan* − *schan* + 1) / *decimatex*.

−T *sweep[/delay]*
The *sweep* value sets the time range of seismic data to be processed in seconds. The optional *delay* value sets the sweep start time, again in seconds.

−V Normally, **mbsegypsd** prints out information regarding its controlling parameters during execution; the **−V** option causes the program to also print out statements indicating its progress.

−W *mode/start/end*
This option can be used to limit the data being processed to a particular time window in various ways. This option does not impact the definition of the overall grid bounds, but does restrict the data processed to samples within particular times of interest. If *mode* = 1, then *start* and *end* are simply start and end times of good data in seconds. If *mode* = 2, then *start* and *end* are relative to the time of the bottom return. In this case *start* is often negative so that the grid shows data above the seafloor, and then down into the subsurface. Finally, if *mode* = 3, then *start* and *end* are relative to the time corresponding to the sonar depth.

EXAMPLES

Suppose that one has a segy file of hydrophone data sampled at a 37 microsecond interval, corresponding to a 27027 Hz sampling rate. Each of 1610 traces consists of 64865 samples. In order to create a sonogram displaying the power spectral density as a function of time, execute mbsegypsd as follows:

```
mbsegypsd −I 20090922_1833_V3422_S7_CH025ms.segy −N1024 −L −O testpsd −V
```

Here the **−N** option sets the FFT dimension used to be 1024 samples, which means that the PSD estimate for each trace is the average of 64865 / 1024 = 63 calculations. The shell output of the program is:

```
Program mbsegypsd
MB-system Version 5.1.2beta12

MBsegypsd Parameters:
Input segy file:        20090922_1833_V3422_S7_CH025ms.segy
Output fileroot:        testpsd
Input Parameters:
```

trace mode: 0
trace start: 0
trace end: 1609
channel start: 1
channel end: 1
trace decimation: 1
time sweep: 2.399968 seconds
time delay: 0.000000 seconds
sample interval: 0.000037 seconds
window mode: 0
window start: 0.000000 seconds
window end: 0.000000 seconds
Output Parameters:
grid filename: testpsd.grd
psd filename: testpsd_psd.txt
x grid dimension: 1610
y grid dimension: 513
grid xmin: −0.500000
grid xmax: 1609.500000
grid ymin: −13.171066
grid ymax: 13500.342448
NaN values used to flag regions with no data
shotscale: 1.000000
frequencyscale: 1.000000

PROCESS read:0 position:0 shot:0 channel:1 2009/265 18:32:59.000 samples:64864 interval:37 usec minmax: −102498.789062 −187.008667

PROCESS read:25 position:25 shot:25 channel:1 2009/265 18:34:14.000 samples:64864 interval:37 usec minmax: −201902.890625 9166.462891

PROCESS read:50 position:50 shot:50 channel:1 2009/265 18:35:29.000 samples:64864 interval:37 usec minmax: −203695.765625 28316.906250

PROCESS read:75 position:75 shot:75 channel:1 2009/265 18:36:44.000 samples:64864 interval:37 usec minmax: −201434.375000 24819.115234

PROCESS read:100 position:100 shot:100 channel:1 2009/265 18:37:59.000 samples:64864 interval:37 usec minmax: −16544.123047 37.462040

.....

PROCESS read:1500 position:1500 shot:1500 channel:1 2009/265 19:47:59.000 samples:64864 interval:37 usec minmax: −8367.179688 −876.420044

PROCESS read:1525 position:1525 shot:1525 channel:1 2009/265 19:49:14.000 samples:64864 interval:37 usec minmax: −9163.580078 201.037201

PROCESS read:1550 position:1550 shot:1550 channel:1 2009/265 19:50:29.000 samples:64864 interval:37 usec minmax: −12128.291016 −993.766357

PROCESS read:1575 position:1575 shot:1575 channel:1 2009/265 19:51:44.000 samples:64864 interval:37 usec minmax: −67764.585938 2457.883789

PROCESS read:1600 position:1600 shot:1600 channel:1 2009/265 19:52:59.000 samples:64864 interval:37 usec minmax: −190216.031250 −14304.720703

.br

.br The output PSD grid file is named testpsd.grd. A shellscript named testpsd.grd.cmd is also created that, when executed, will generate a plot of the sonogram. **MBsegypsd** also outputs an ascii file containing the average PSD for the entire segy file in the form of frequency PSD pairs. In this case, the average PSD file is named testpsd_psd.txt, and has contents like:

0.000000 193.762464
26.342132 99.114274
52.684263 93.781880

79.026395 86.775795
105.368526 80.297280
131.710658 74.908340
158.052790 71.366137
184.394921 70.319082
210.737053 69.840534
237.079184 70.794517
263.421316 72.002905
289.763448 71.979001
316.105579 70.637717
342.447711 69.652364
.....
13329.118592 −13.659568
13355.460724 −13.722928
13381.802855 −12.981740
13408.144987 −12.626286
13434.487119 −12.533222
13460.829250 −13.659002
13487.171382 −24.474310

A shellscript named testpsd_psd.txt.cmd is created that will, when executed, generate a plot of the average PSD.

SEE ALSO

mbsystem(1), **mbm_grdplot**(1), **mbmosaic**(1), **mbm_grid**(1)

BUGS

Probably... The plots could be better...