我们经常看到很多driver会或者cpufreq governor等等会创建一些进程,并在创建之后使用 wake_up_process(struct task_struct *p)函数直接wakeup这个task,下面看看这个 wake_up_process函数是怎么实现进程调度,怎么实现放在哪个CPU上执行调度的? 先列出起源码如下:

```
wake_up_process(p)---->try_to_wake_up(p,TASK_NORMAL,0,1)---->
 * wake up process - Wake up a specific process
* @p: The process to be woken up.
 * Attempt to wake up the nominated process and move it to the set of
runnable
* processes.
 * Return: 1 if the process was woken up, 0 if it was already running.
 * It may be assumed that this function implies a write memory barrier
before
 * changing the task state if and only if any tasks are woken up.
int wake up process(struct task struct *p)
{ /*wake up process直接调用try_to_wake_up函数,并添加三个限定参数*/
    return try to wake up(p, TASK NORMAL, 0, 1);
/st Convenience macros for the sake of wake up st/
#define TASK NORMAL (TASK INTERRUPTIBLE | TASK UNINTERRUPTIBLE)
 * try_to_wake_up - wake up a thread
 * @p: the thread to be awakened
 ^{\star} @state: the mask of task states that can be woken
 * @wake flags: wake modifier flags (WF *)
* @sibling count hint: A hint at the number of threads that are being woken
up
                        in this event.
 * Put it on the run-queue if it's not already there. The "current"
 * thread is always on the run-queue (except when the actual
 ^{\star} re-schedule is in progress), and as such you're allowed to do
 * the simpler "current->state = TASK RUNNING" to mark yourself
 * runnable without the overhead of this.
 * Return: %true if @p was woken up, %false if it was already running.
 * or @state didn't match @p's state.
 * /
 static int
try_to_wake_up(struct task_struct *p, unsigned int state, int wake_flags,
          int sibling count hint)
    unsigned long flags;
    int cpu, success = 0;
#ifdef CONFIG SMP
    struct rq *rq;
  u64 wallclock;
```

```
#endif
    /*
    * If we are going to wake up a thread waiting for CONDITION we
    * need to ensure that CONDITION=1 done by the caller can not be
    * reordered with p->state check below. This pairs with mb() in
    * set current state() the waiting thread does.
    */ /*很有可能需要唤醒一个thread的函数,某个条件必须成立,为了取到最新的没有没优化
   的条件数值,使用内存屏障来实现.*/
   smp_mb__before_spinlock();
   raw spin lock irqsave(&p->pi lock, flags);
   /*如果进程不是在:TASK INTERRUPTIBLE | TASK UNINTERRUPTIBLE下,则就不是normal
  task,直接退出wakeup流程.所以在内核里面看到的wake up process,可以看到起主函数都会
   将进程设置为TASK_INTERRUPTIBLE or TASK UNINTERRUPTIBLE这两种状态之一*/
   if (!(p->state & state))
       goto out;
   trace_sched_waking(p);
    success = 1; /* we're going to change ->state */
    /*获取这个进程当前处在的cpu上面,并不是时候进程就在这个cpu上运行,后面会挑选cpu*/
   cpu = task cpu(p);
    * Ensure we load p->on_rq _after_ p->state, otherwise it would
    * be possible to, falsely, observe p->on rq == 0 and get stuck
    * in smp cond load acquire() below.
     * sched ttwu pending()
                                      try_to_wake_up()
    * [S] p->on_rq = 1;
                                       [L] P->state
         UNLOCK rq->lock ----.
                  +--- RMB
    * schedule()
    * LOCK rq->lock ----'
          UNLOCK rq->lock
    * [task p]
    * [S] p->state = UNINTERRUPTIBLE [L] p->on rq
     * Pairs with the UNLOCK+LOCK on rq->lock from the
    * last wakeup of our task and the schedule that got our task
    * current.
    */
   smp rmb();
   /*使用内存屏障保证p->on rq的数值是最新的.如果task已经在rq里面,即进程已经处于
   runnable/running状态.ttwu remote目的是由于task p已经在rq里面了,并且并没有完全
   取消调度,再次会wakeup的话,需要将task的状态翻转,将状态设置为TASK RUNNING,这样
   task就一直在rq里面运行了.这种情况直接退出下面的流程,并对调度状态/数据进行统计*/
   if (p->on rq && ttwu remote(p, wake flags))
       goto stat;
#ifdef CONFIG SMP
```

```
* Ensure we load p->on cpu after p->on rq, otherwise it would be
 * possible to, falsely, observe p->on cpu == 0.
 * One must be running (->on cpu == 1) in order to remove oneself
 * from the runqueue.
 * [S] ->on cpu = 1;
                       [L] ->on rq
      UNLOCK rq->lock
           RMB
      LOCK rq->lock
 * [S] ->on_rq = 0; [L] ->on_cpu
 * Pairs with the full barrier implied in the UNLOCK+LOCK on rq->lock
 * from the consecutive calls to schedule(); the first switching to our
 * task, the second putting it to sleep.
 * /
smp rmb();
 * If the owning (remote) cpu is still in the middle of schedule() with
 * this task as prev, wait until its done referencing the task.
 */
 /*如果拥有(远程)cpu仍然在schedule()的中间,并且此任务为prev,请等待
 其完成引用任务,意思是说,task p是作为其他cpu上的调度实体被调度,并且没有调度完毕,需要
 等待其完毕,加内屏屏障就是保证on cpu的数值是内存里面最新的数据
while (p->on cpu)
    cpu relax();/*cpu 忙等待,期望有人修改p->on cpu的数值,退出忙等待*/
 * Combined with the control dependency above, we have an effective
 * smp load acquire() without the need for full barriers.
 * Pairs with the smp store release() in finish lock switch().
 * This ensures that tasks getting woken will be fully ordered against
 * their previous state and preserve Program Order.
 */
smp rmb();
/*获取当前进程所在的cpu的rq*/
rq = cpu rq(task cpu(p));
raw spin lock(&rq->lock);
/*获取当前时间作为walt的wallclock*/
wallclock = walt ktime clock();
/*更新rq->curr在当前时间对进程负载/对累加的runnable time的影响*/
walt_update_task_ravg(rq->curr, rq, TASK_UPDATE, wallclock, 0);
/*更新新创建的进程p在当前时间对进程负载/对累加的runnable time的影响*/
walt_update_task_ravg(p, rq, TASK_WAKE, wallclock, 0);
raw spin unlock(&rq->lock);
/*根据进程p的状态来确定,如果调度器调度这个task是否会对load有贡献.*/
p->sched contributes to load = !!task contributes to load(p);
/*设置进程状态为TASK WAKING*/
p->state = TASK WAKING;
```

```
/*根据进程的所属的调度类调用相关的callback函数,这里进程会减去当前所处的cfs rq的最小
   vrunime,因为这里还没有确定进程会在哪个cpu上运行,等确定之后,会在入队的时候加上新cpu的
   cfs rq的最小vruntime*/
   if (p->sched class->task waking)
       p->sched class->task waking(p);
    /*根据进程p相关参数设定和系统状态,为进程p选择合适的cpu供其运行*/
    cpu = select_task_rq(p, p->wake_cpu, SD_BALANCE_WAKE, wake flags,
               sibling count hint);
    /*如果选择的cpu与进程p当前所在的cpu不相同,则将进程的wake flags标记添加需要迁移
    ,并将进程p迁移到cpu上.*/
    if (task cpu(p) != cpu) {
       wake flags |= WF MIGRATED;
       set task cpu(p, cpu);
    }
#endif /* CONFIG SMP */
    /*进程p入队操作并标记p为runnable状态,同时执行wakeup preemption,即唤醒抢占.*/
   ttwu_queue(p, cpu);
   /*调度相关的统计*/
   ttwu stat(p, cpu, wake flags);
out:
   raw spin unlock irqrestore(&p->pi lock, flags);
   return success;
```

try_to_wake_up函数解析

try_to_wakeup_up函数的主要功能解析如下:

- 根据进行状态state来决定是否需要继续唤醒动作,这就是p->state & state的目的
- 获取进程p所在的当前cpu
- 如果当前cpu已经在rq里面了,则需要翻转进程p的状态为TASK_RUNNING,这样进程p 就一直在rq里面,不需要继续调度,退出唤醒动作
- 如果进程p在cpu上,则期待某个时刻去修改这个数值on_cpu为0,这样代码可以继续运行.
- 根据WALT算法来实现rq当前task和新唤醒的task p相关的task load和rq相关的runnable_load的数值,具体怎么实现看walt.c文件。
- 为task p挑选合适的cpu
- 如果挑选的cpu与进程p所在的cpu不是同一个cpu,则进程task migration操作
- 将进程p入队操作
- 统计调度相关信息作为debug使用.

对于关键的几个点,详细分析如下:

1 How does the scheduler pick a suitable CPU?

```
cpu = select_task_rq(p, p->wake_cpu, SD_BALANCE_WAKE, wake_flags,
sibling_count_hint);
```

对函数select_task_rq的实现原理如下:

```
/*
    * The caller (fork, wakeup) owns p->pi_lock, ->cpus_allowed is stable.
    */
    static inline
```

```
int select task rq(struct task struct *p, int cpu, int sd flags, int
wake flags,
          int sibling_count_hint)
   lockdep assert held(&p->pi lock);
   /*nr cpus allowed这个变量是进程p可以运行的cpu数量,一般在系统初始化的时候就已经
    设定好了的,或者可以通过设定cpu的亲和性来修改*/
   if (p->nr_cpus_allowed > 1)
       /*核心函数的callback*/
       cpu = p->sched_class->select_task_rq(p, cpu, sd_flags, wake_flags,
                           sibling count hint);
    * In order not to call set_task_cpu() on a blocking task we need
    * to rely on ttwu() to place the task on a valid ->cpus allowed
    * cpu.
    * Since this is common to all placement strategies, this lives here.
     * [ this allows ->select task() to simply return task cpu(p) and
        not worry about this generic constraint ]
   /*1.如果选择的cpu与进程p允许运行的cpu不匹配 或者
     2.如果挑选的cpu offline
    只要满足上面的任何一条,则重新选择cpu在进程p成员变cpus allowed里面选择*/
   if (unlikely(!cpumask test cpu(cpu, tsk cpus allowed(p)) ||
           !cpu online(cpu)))
       cpu = select fallback rq(task cpu(p), p);
   return cpu;
```

所以select task rq函数分两部分来分析:

1.1 select_task_rq callback函数分析

```
struct sched_domain *tmp, *affine_sd = NULL, *sd = NULL;
   int cpu = smp_processor_id(); /*获取当前运行的cpu id*/
   int new_cpu = prev_cpu; /*将唤醒此进程p的cpu作为new cpu*/
   int want affine = 0;
   /*wake falgs=0,so sync=0*/
   int sync = wake flags & WF SYNC;
#ifdef CONFIG 64BIT ONLY CPU
   struct cpumask tmpmask;
   if (find packing cpu(p, &new cpu))
       return new cpu;
   cpumask andnot(&tmpmask, cpu present mask, &b64 only cpu mask);
   if (cpumask_test_cpu(cpu, &tmpmask)) {
       if (weighted cpuload 32bit(cpu) >
           sysctl_sched_32bit_load_threshold &&
           !test tsk thread flag(p, TIF 32BIT))
           return min load 64bit only cpu();
#endif
   /*sd flag = SD BALANCE WAKE,是成立的,want affine是一个核心变量包括三个部分数值
   的&&,后面会详细分析*/
   if (sd_flag & SD_BALANCE_WAKE) {
       record wakee(p);
       want affine = !wake wide(p, sibling count hint) &&
                 !wake_cap(p, cpu, prev_cpu) &&
                 cpumask_test_cpu(cpu, &p->cpus_allowed);
    /*如果系统使用EAS来决策的,则走这个分支,这种重点,也是新加的调度方案,根据cpu的能效和
   capacity来挑选cpu*/
   if (energy aware())
       return select energy cpu brute(p, prev cpu, sync);
   rcu read lock();
   for_each_domain(cpu, tmp) {
       if (!(tmp->flags & SD_LOAD_BALANCE))
           break;
         * If both cpu and prev cpu are part of this domain,
         * cpu is a valid SD WAKE AFFINE target.
       if (want_affine && (tmp->flags & SD_WAKE AFFINE) &&
           cpumask test cpu(prev cpu, sched domain span(tmp))) {
           affine sd = tmp;
           break;
       if (tmp->flags & sd_flag)
           sd = tmp;
       else if (!want_affine)
           break;
```

```
if (affine sd) {
    sd = NULL; /* Prefer wake affine over balance flags */
    if (cpu != prev cpu && wake affine(affine sd, p, prev cpu, sync))
        new cpu = cpu;
if (sd && !(sd flag & SD BALANCE FORK)) {
     * We're going to need the task's util for capacity spare wake
     * in find idlest group. Sync it up to prev cpu's
     * last update time.
    sync entity load avg(&p->se);
if (!sd) {
    if (sd flag & SD BALANCE WAKE) /* XXX always ? */
        new cpu = select idle sibling(p, prev cpu, new cpu);
} else {
    new cpu = find idlest cpu(sd, p, cpu, prev cpu, sd flag);
rcu_read_unlock();
return new cpu;
```

分别分几个部分来select_task_rq_fair函数:

1.1 want_affine变量怎么获取的呢?

```
want affine = !wake wide(p, sibling count hint) &&
                   !wake cap(p, cpu, prev cpu) &&
                   cpumask_test_cpu(cpu, &p->cpus_allowed);
  --->
/*
 * Detect M:N waker/wakee relationships via a
switching-frequency heuristic.
 * A waker of many should wake a different task than the one
last awakened
  * at a frequency roughly N times higher than one of its
wakees. In order
 * to determine whether we should let the load spread vs
consolodating to
 * shared cache, we look for a minimum 'flip' frequency of
llc size in one
 * partner, and a factor of lls size higher frequency in the
other. With
 * both conditions met, we can be relatively sure that the
relationship is
 * non-monogamous, with partner count exceeding socket size.
Waker/wakee
```

```
* being client/server, worker/dispatcher, interrupt source
or whatever is
 * irrelevant, spread criteria is apparent partner count
exceeds socket size.
/*当前cpu的唤醒次数没有超标*/
static int wake wide(struct task struct *p, int
 sibling count hint)
 {
     unsigned int master = current->wakee flips;
     unsigned int slave = p->wakee flips;
     int llc size = this cpu read(sd llc size);
     if (sibling count hint >= llc size)
         return 1;
     if (master < slave)</pre>
         swap(master, slave);
     if (slave < llc size || master < slave * llc size)</pre>
        return 0;
     return 1;
}
 * Disable WAKE AFFINE in the case where task @p doesn't fit
in the
  * capacity of either the waking CPU @cpu or the previous CPU
@prev cpu.
 * In that case WAKE AFFINE doesn't make sense and we'll let
 * BALANCE WAKE sort things out.
static int wake cap(struct task struct *p, int cpu, int
prev cpu)
     long min cap, max cap;
     /*获取当前cpu的orig of和唤醒进程p的cpu的orig of capacity的最小
 值
* /
     min_cap = min(capacity_orig_of(prev_cpu),
capacity orig of(cpu));
     /*获取最大的capacity,为1024*/
     max cap = cpu rq(cpu)->rd->max cpu capacity.val;
     /* Minimum capacity is close to max, no need to abort
wake affine */
     if (max cap - min cap < max cap >> 3)
         return 0;
     /*根据PELT算法更新进程p作为调度实体的负载*/
     /* Bring task utilization in sync with prev cpu */
     sync entity load avg(&p->se);
```

```
/*根据条件判断min cap的capacity能够能够满足进程p吗?*/
       /*min cap * 1024 < task util(p) * 1138,
          task util(p) \in [0,1024] */
       return min cap * 1024 < task util(p) * capacity margin;</pre>
•
 static inline unsigned long task_util(struct task_struct *p)
 { /*WALT启用*/
 #ifdef CONFIG SCHED WALT
      if (!walt disabled && sysctl sched use walt task util) {
         unsigned long demand = p->ravg.demand;/*task的真实运行时间*/
         /*在一个窗口内是多少,注意是*了1024的,比如占用了50%的窗口时间,则这个
 task util = 0.5 * 1024=512.*/
         return (demand << 10) / walt_ravg_window;</pre>
     }
 #endif
      return p->se.avg.util avg;
   * Synchronize entity load avg of dequeued entity without locking
   * the previous rq.
 void sync entity load avg(struct sched entity *se)
   struct cfs_rq *cfs_rq = cfs_rq_of(se);
     u64 last update time;
      last_update_time = cfs_rq_last_update_time(cfs rq);
    /*PELT计算sched entity调度实体的负载*/
   update load avg(last update time, cpu of(rq of(cfs rq)), &se->avg, 0, 0,
  NULL);
 }
   * cpumask test cpu - test for a cpu in a cpumask
  * @cpu: cpu number (< nr cpu ids)
   * @cpumask: the cpumask pointer
  * Returns 1 if @cpu is set in @cpumask, else returns 0
 /*当前运行的cpu是否是task p cpu亲和数里面的一个*/
 static inline int cpumask test cpu(int cpu, const struct
 cpumask *cpumask)
       return test bit(cpumask_check(cpu),
 cpumask bits((cpumask)));
```

只有满足下面三个条件:

- 当前cpu的唤醒次数没有超标
- 当前task p消耗的capacity * 1138小于min cap * 1024
- 当前cpu在task p的cpu亲和数里面的一个

1.2 使用EAS调度,怎么挑选合理的cpu呢?

如果使用EAS调度算法,则energy aware()为true:

```
if (energy aware())
        return select_energy_cpu_brute(p, prev_cpu, sync);
static inline bool energy aware(void)
{ /*energy aware调度类*/
    return sched feat(ENERGY AWARE);
static int select energy cpu brute(struct task struct *p, int prev cpu, int
sync)
{
    struct sched domain *sd;
    int target_cpu = prev_cpu, tmp_target, tmp_backup;
    bool boosted, prefer idle;
    /*调度统计信息*/
    schedstat inc(p, se.statistics.nr wakeups secb attempts);
    schedstat_inc(this_rq(), eas_stats.secb attempts);
    /*条件不成立*/
    if (sysctl sched sync hint enable && sync) {
        int cpu = smp_processor_id();
        if (cpumask_test_cpu(cpu, tsk_cpus_allowed(p))) {
            schedstat_inc(p, se.statistics.nr_wakeups_secb_sync);
            schedstat inc(this rq(), eas stats.secb sync);
            return cpu;
    }
    rcu read lock();
    /*下面的两个参数都可以在init.rc里面配置,一般boost都会配置,尤其是top-app*/
#ifdef CONFIG CGROUP SCHEDTUNE
    /*获取当前task是否有util boost增益.如果有则boosted=true.
     即如果原先的负载为util,那么boost之后的负载为util+boost/100*util*/
    boosted = schedtune task boost(p) > 0;
    /*获取在挑选cpu的时候,是否更倾向于idle cpu,默认为0,也就是说 prefer idle=false*/
    prefer idle = schedtune prefer idle(p) > 0;
    boosted = get sysctl sched cfs boost() > 0;
    prefer idle = 0;
#endif
    /*再次更新调度实体负载,使用PELT算法,比较奇怪的时候,在计算want affine→
wake cap函数里面已经update了调度实体的负载了,为何在这里还需要再次计算呢?*/
    sync_entity_load_avg(&p->se);
    /*DEFINE PER CPU(struct sched domain *, sd ea),在解析调度域调度组的创建和初始
化的时候,解析过,每个cpu在每个SDTL上面都有对应的调度域*/
    sd = rcu dereference(per cpu(sd ea, prev cpu));
    /* Find a cpu with sufficient capacity */
    tmp_target = find_best_target(p, &tmp_backup, boosted, prefer_idle);
```

•

1.2.1 下面讲解核心函数find_best_target,函数比较长:

```
1. static inline int find_best_target(struct task_struct *p, int *backup_cpu,
2.
                      bool boosted, bool prefer idle)
3. {
       unsigned long best idle min cap orig = ULONG MAX;
4.
       /*计算task p经过boost之后的util数值,即在task util(p)的基础上+boost%*util*/
       unsigned long min util = boosted task util(p);
6.
       unsigned long target capacity = ULONG MAX;
8.
       unsigned long min wake util = ULONG MAX;
9.
       unsigned long target max spare cap = 0;
    int best_idle cstate = INT MAX;
10.
11. unsigned long target cap = ULONG MAX;
12.
       unsigned long best idle cap orig = ULONG MAX;
13.
       int best idle = INT MAX;
    int backup_idle_cpu = -1;
14.
15. struct sched_domain *sd;
     struct sched_group *sg;
16.
     int best_active_cpu = -1;
17.
    int best_idle_cpu = -1;
18.
19.
     int target cpu = -1;
20.
      int cpu, i;
21.
       /*获取当前cpu的运行队列rq的root domain*/
22.
       struct root domain *rd = cpu rq(smp processor id())->rd;
23.
      /*获取当前root_domain的最大capacity数值*/
24.
       unsigned long max cap = rd->max cpu capacity.val;
25.
26.
       *backup cpu = -1;
27.
28.
      schedstat inc(p, se.statistics.nr wakeups fbt attempts);
29.
       schedstat inc(this rq(), eas stats.fbt attempts);
30.
     /* Find start CPU based on boost value */
31.
32.
      /*start cpu找出rd->min cap orig cpu,即min cap orig的第一个cpu id
     min的cpu为0*/
33.
34.
      cpu = start_cpu(boosted);
35.
       if (cpu < 0) {
36.
           schedstat_inc(p, se.statistics.nr_wakeups_fbt_no_cpu);
37.
           schedstat inc(this rq(), eas stats.fbt no cpu);
38.
           return -1;
39.
40.
     ^{\prime \star} Find SD for the start CPU ^{\star \prime}
41.
       /*找到启动cpu的调度域*/
42.
43.
       sd = rcu dereference(per_cpu(sd_ea, cpu));
44.
       if (!sd) {
45.
           schedstat inc(p, se.statistics.nr wakeups fbt no sd);
46.
          schedstat inc(this rq(), eas stats.fbt no sd);
47.
           return -1;
48.
       }
49.
     /* Scan CPUs in all SDs */
50.
51.
       sq = sd->groups;
52.
       do {
```

```
53.
            for each cpu and(i, tsk cpus allowed(p), sched group cpus(sg)) {
54.
                unsigned long capacity orig = capacity orig of(i);
55.
                unsigned long wake util, new util;
56.
57.
                if (!cpu online(i))
58.
                    continue;
59.
60.
                if (walt_cpu_high_irqload(i))
61.
                    continue;
62.
63.
                 * p's blocked utilization is still accounted for on prev cpu
64.
65.
                 * so prev cpu will receive a negative bias due to the double
66.
                 * accounting. However, the blocked utilization may be zero.
67.
                 */
68.
                wake_util = cpu_util_wake(i, p);
69.
                new util = wake util + task util(p);
70.
71.
72.
                 * Ensure minimum capacity to grant the required boost.
73.
                 * The target CPU can be already at a capacity level higher
74.
                 * than the one required to boost the task.
75.
76.
                new util = max(min util, new util);
77.
                if (new util > capacity orig) {
78.
                    if (idle cpu(i)) {
79.
                        int idle idx;
80.
81.
                        idle idx =
82.
                             idle get state idx(cpu rq(i));
83.
84.
                        if (capacity orig >
85.
                            best idle cap orig) {
86.
                            best idle cap orig =
                                capacity orig;
87.
88.
                            best idle = idle idx;
89.
                            backup idle cpu = i;
90.
                             continue;
91.
92.
93.
94.
                          * Skip CPUs in deeper idle state, but
95.
                          * only if they are also less energy
96.
                          * efficient.
                          * IOW, prefer a deep IDLE LITTLE CPU
97.
                          * vs a shallow idle big CPU.
98.
99.
100.
                            if (sysctl sched cstate aware &&
101.
                                best idle <= idle idx)</pre>
102.
                                continue;
103.
104.
                            /* Keep track of best idle CPU */
105.
                            best_idle_cap_orig = capacity_orig;
106.
                            best idle = idle idx;
```

```
107.
                            backup idle cpu = i;
108.
                            continue;
109.
110.
111.
                        if (capacity orig > target cap) {
112.
                            target_cap = capacity_orig;
113.
                            min wake util = wake util;
114.
                            best_active_cpu = i;
115.
                            continue;
116.
117.
118.
                        if (wake util > min wake util)
119.
                            continue;
120.
121.
                       min wake util = wake util;
122.
                       best_active_cpu = i;
123.
                        continue;
124.
125.
126.
127.
                    * Enforce EAS mode
128.
129.
                     * For non latency sensitive tasks, skip CPUs that
130.
                     * will be overutilized by moving the task there.
131.
132.
                     * The goal here is to remain in EAS mode as long as
133.
                     * possible at least for !prefer idle tasks.
134.
135.
                   if (capacity_orig == max_cap)
136.
                       if (idle_cpu(i))
137.
                            goto skip;
138.
139.
                   if ((new_util * capacity_margin) >
140.
                        (capacity orig * SCHED CAPACITY SCALE))
141.
                       continue;
142.
       skip:
143.
                   if (idle cpu(i)) {
144.
                        int idle idx;
145.
146.
                        if (prefer idle ||
147.
                            cpumask test cpu(i, &min cap cpu mask)) {
148.
                            trace sched find best target(p,
149.
                                prefer idle, min util, cpu,
150.
                                best idle cpu, best active cpu,
151.
                                i);
152.
                            return i;
153.
154.
                        idle idx = idle get state idx(cpu rq(i));
155.
156.
                        /* Select idle CPU with lower cap orig */
157.
                        if (capacity_orig > best_idle_min_cap_orig)
158.
                            continue;
159.
160.
```

```
161.
                        * Skip CPUs in deeper idle state, but only
162.
                        * if they are also less energy efficient.
163.
                        * IOW, prefer a deep IDLE LITTLE CPU vs a
164.
                        * shallow idle big CPU.
165.
                        */
166.
                       if (sysctl sched cstate aware &&
167.
                           best idle cstate <= idle idx)</pre>
168.
                           continue;
169.
170.
                       /* Keep track of best idle CPU */
171.
                       best idle min cap orig = capacity orig;
172.
                       best idle cstate = idle idx;
173.
                       best idle cpu = i;
174.
                       continue;
175.
176.
                   /* Favor CPUs with smaller capacity */
177.
178.
                   if (capacity_orig > target_capacity)
179.
                       continue;
180.
181.
                   /* Favor CPUs with maximum spare capacity */
182.
                   if ((capacity orig - new util) < target max spare cap)</pre>
183.
                       continue;
184.
185.
                   target max spare cap = capacity orig - new util;
186.
                   target capacity = capacity orig;
187.
                   target cpu = i;
188.
189.
190.
           } while (sg = sg->next, sg != sd->groups);
191.
192.
193.
            * For non latency sensitive tasks, cases B and C in the previous
 loop,
194.
            * we pick the best IDLE CPU only if we was not able to find a target
195.
            * ACTIVE CPU.
196.
197.
            * Policies priorities:
198.
199.
            * - prefer idle tasks:
200.
201.
              a) IDLE CPU available, we return immediately
202.
              b) ACTIVE CPU where task fits and has the bigger maximum spare
203.
                   capacity (i.e. target cpu)
204.
               c) ACTIVE CPU with less contention due to other tasks
205.
                   (i.e. best active cpu)
206.
207.
            * - NON prefer idle tasks:
208.
209.
              a) ACTIVE CPU: target cpu
210.
               b) IDLE CPU: best idle cpu
211.
            */
212.
           if (target cpu == -1) {
213.
              if (best idle cpu != -1)
```

```
214.
                  target cpu = best idle cpu;
215.
216.
                  target_cpu = (backup_idle_cpu != -1)
217.
                  ? backup idle cpu
218.
                  : best active cpu;
     } else
219.
220.
             *backup cpu = best idle cpu;
221.
     trace_sched_find_best_target(p, prefer_idle, min util, cpu,
222.
223.
                          best idle cpu, best active cpu,
224.
                           target cpu);
225.
     schedstat_inc(p, se.statistics.nr_wakeups_fbt_count);
226.
227.
         schedstat_inc(this_rq(), eas_stats.fbt_count);
228.
229.
         return target cpu;
230.
```

分下面如下几个部分来分析上面的do{}while()循环

- do{}while()循环是对sched domain里面的所有调度组进行遍历
- for_each_cpu_and(i, tsk_cpus_allowed(p), sched_group_cpus(sg)),这个for循环比较有意思,sched_group_cpus(sg),表示这个调度组所有的cpumask,其返回值就是sg->cpumask.for_each_cpu_and抽象循环的意思是i必须在tsk_cpus_allowed(p) && sched_group_cpus(sg)交集里面.

- 如果cpu id为i的cpu offline,则遍历下一个cpu
- 如果这个cpu是一个irq high load的cpu,则遍历下一个cpu
- 计算wake_util,即为当前cpu id=i的cpu_util的数值,new_util为cpu i的cpu_util+进程p的 task_util数值,最后new_util = max(min_util, new_util);min_util数值是task_util boost之后的数值,如果没有boost,则min_util=task_util.

上面条件判断之后,并且获取了当前遍历cpu的util和新唤醒的进程task_util叠加到cpu_util变成new_util之后,通过capacity/util的比较来获取target_cpu,<mark>下面分析代码77~187行代码</mark>: 在遍历cpu的时候

如果new_util > 遍历的cpu的capacity数值(dts获取),分两部分逻辑处理:

- 1. 如果cpu是idle状态.记录此cpu处在idle的level_idx,并修改下面三个参数数值之后遍历下一个符合条件的cpu:
 - /***获取当前遍历**cpu**的**capacity**,并保存在**best_idle_cap_orig**变量中** */
 - best idle cap orig = capacity orig;
 - best idle = idle idx; //获取idle level index
 - backup_idle_cpu = i; //idle cpu number,后面会使用到
- 2.如果不是idle cpu,则修正下面两个参数之后遍历下一个符合条件的cpu:
 - min_wake_util = wake_util; //将遍历的cpu_util赋值给min_wake_uti
 - best active cpu = i; //得到best active cpu id

如果new_util <= 遍历的cpu的capacity数值(dts获取),分如下几部分逻辑处理:

- 1.如果capacity_orig == max_cap并且遍历的cpu恰好是idle状态,直接调到去更新下面三个参数:
 - /***将当前遍历的**cpu**的**capacity**保存到**best idle min cap orig**变量中***/
 - best_idle_min_cap_orig = capacity_orig;
 - best idle cstate = idle idx; //保存idleindex
 - best idle cpu = i; //保存最佳的idle cpu,后面会用到
- 2.如果(new_util * capacity_margin) > (capacity_orig * SCHED_CAPACITY_SCALE)成立,则 直接遍历下一个cpu,说明此时遍历的cpu已经overutilization,没必须继续遍历了.
- 3.如果capacity_orig==max_cap不成立,也会执行第一条先判断遍历的cpu是否是idle,是的话,执行1一样的流程
- 4.如果遍历的cpu不是idle,则比较capacity_orig-new_util差值与target_max_spare_cap的比较目的是选择一个差值余量最大的cpu,防止新唤醒的task p在余量不足的cpu上运行导致后面的负载均衡,白白浪费系统资源,同时更新下面三个参数,并在每次遍历的时候更新:

```
/*util余量,目的找出最大余量的cpu id*/
target_max_spare_cap = capacity_orig - new_util;
/*目标capacity*/
target_capacity = capacity_orig;
/*选择的目标cpu*/
target_cpu = i;
```

下面分析212~220之间的代码:

从解释来看(对于非敏感延迟性进程)进程分两种,prefer idle flag:

- 1. 一种是偏爱idle cpu运行的进程,那么如果有idle cpu,则优先选择idle cpu并立即返回,如代码145~152行的代码;之后task的util不太大,就选择有最大余量的cpu了;最后挑选有更少争抢的cpu,比如best_avtive_cpu
- 2. 不偏爱idle cpu运行的进程,优先选择余量最大的cpu,之后选择best_idle_cpu 明白了prefer_idle这个flag会影响对cpu类型的选择,那么分析212~220行之间的代码如下,即在 没有机会执行寻找最大余量的cpu capacity的情况下:

如果target_cpu = -1

- 如果best_idle_cpu更新过,表明要么new_util很大,要么大部分cpu处于idle状态,这时候直接选择best_idle_cpu为target_cpu
- 否则,根据backup_idle_cpu是否update过来决定target_cpu选择是backup_idle_cpu还是best active cpu

如果target cpu!=-1

● 候选cpu设置为best_idle_cpu,通过函数指针被使用 最后返回target_cpu的作为选择的cpu id.

1.2.2 select_energy_cpu_brute函数剩余部分分析:


```
static int select energy cpu brute(struct task struct *p, int prev cpu, int
sync)
{
/* Find a cpu with sufficient capacity */
    /*下面这个函数已经解析完毕*/
    tmp_target = find_best_target(p, &tmp_backup, boosted, prefer_idle);
   if (!sd)
       goto unlock;
   if (tmp target >= 0) {
       target cpu = tmp_target;
       /*如果boosted or prefer idle && target cpu为idlecpu,或者target cpu为
       min cap的cpu,则挑选的cpu就是target cpu了并直接退出代码流程*/
       if (((boosted || prefer_idle) && idle_cpu(target_cpu)) ||
            cpumask_test_cpu(target_cpu, &min_cap_cpu_mask)) {
           schedstat inc(p, se.statistics.nr wakeups secb idle bt);
           schedstat inc(this rq(), eas stats.secb idle bt);
           goto unlock;
    /*如果target cpu等于唤醒进程p的cpu并且best idle cpu>=0,则修改target cpu为
    best idle cpu数值,目的不在唤醒进程P的cpu上运行.why???*/
    if (target cpu == prev cpu && tmp backup >= 0) {
       target cpu = tmp backup;
       tmp backup = -1;
    if (target cpu != prev cpu) {
       int delta = 0;
       /*构造需要迁移的环境变量*/
       struct energy env eenv = {
          .util_delta = task_util(p),
           .src_cpu = prev_cpu,
           .dst_cpu = target_cpu,
           .task
                         = p,
           .trg_cpu
                      = target_cpu,
        };
#ifdef CONFIG SCHED WALT
       if (!walt disabled && sysctl sched use walt cpu util &&
           p->state == TASK WAKING)
           /*获取进程P本身的util load*/
           delta = task util(p);
#endif
        /* Not enough spare capacity on previous cpu */
       /*唤醒进程p的cpu负载过载,超过本身capacity的90%.*/
       if (__cpu_overutilized(prev_cpu, delta, p)) {
           /*有限选择Energy合理的cpu,即小的cluster的idle cpu*/
           if (tmp_backup >= 0 &&
               capacity orig of(tmp backup) <
                   capacity orig of (target cpu))
```

```
target_cpu = tmp_backup;
            schedstat_inc(p, se.statistics.nr_wakeups_secb_insuff_cap);
            schedstat_inc(this_rq(), eas_stats.secb_insuff_cap);
            goto unlock;
        /*计算pre cpu与target cpu的功耗差异,如果大于0,则执行下面的代码流程
        就是计算MC知道DIE的SDTL的功耗总和的差异*/
        if (energy_diff(&eenv) >= 0) {
            /* No energy saving for target cpu, try backup */
            target_cpu = tmp_backup;
            eenv.dst cpu = target cpu;
            eenv.trg cpu = target cpu;
            if (tmp backup < 0 ||</pre>
                tmp_backup == prev_cpu ||
                energy diff(&eenv) >= 0) {
                schedstat_inc(p, se.statistics.nr_wakeups_secb_no_nrg_sav);
                schedstat_inc(this_rq(), eas_stats.secb_no_nrg_sav);
                target_cpu = prev_cpu;
                goto unlock;
        schedstat inc(p, se.statistics.nr wakeups secb nrg sav);
        schedstat_inc(this_rq(), eas_stats.secb_nrg_sav);
        goto unlock;
    schedstat_inc(p, se.statistics.nr_wakeups_secb_count);
    schedstat_inc(this_rq(), eas_stats.secb_count);
unlock:
    rcu_read_unlock();
    return target cpu;
```


总结下就是如下四点:

1. EAS通过对sd = rcu_dereference(per_cpu(sd_ea, cpu)), 是DIE顶层domain, 这个调度域的调度组和符合进程亲和数调度组内cpu进行遍历,查找出符合要求


的目标cpu。




2. 当target_cpu!=-1,将task_util放在余量最大的cpu上。



3. prev_cpu是进程p上一次运行的cpu作为src_cpu, 上面选择的target_cpu作为 dst_cpu, 就是尝试计算进程p从prev_cpu迁移到target_cpu系统的功耗差异, 如果进程在target_cpu上的power < prev_cpu上的power, 则直接选择 target_cpu



4. 计算负载变化前后,target_cpu和prev_cpu带来的power变化。如果power的变化超过一定的门限比重,则直接选择target_cpu,如果有power增加超过一定门限比重,根据情况返回best_idle_cpu或者prev_cpu。计算负载变化的函数energy_diff()循环很多比较复杂,仔细分析下来就是计算target_cpu/prev_cpu在"MC层次cpu所在sg链表"+"DIE层级cpu所在sg",这两种范围在负载变化中的功耗差异。示意图如下。



上面四个过程很清晰明了的pre cpu和target cpu的转换关系

接下来分析energy_diff(&eenv)怎么来计算pre_cpu与target_cpu power之间的关系的。

```
static inline int
•
   energy diff(struct energy env *eenv)
   {
       int boost = schedtune_task_boost(eenv->task);
       int nrg delta;
       /*计算绝对功耗差值*/
•
       /* Conpute "absolute" energy diff */
       __energy_diff(eenv);
•
       /st Return energy diff when boost margin is 0 st/
•
       if (1 || boost == 0) {
           trace sched energy diff(eenv->task,
•
                   eenv->src_cpu, eenv->dst_cpu, eenv->util_delta,
                   eenv->nrg.before, eenv->nrg.after, eenv->nrg.diff,
                   eenv->cap.before, eenv->cap.after, eenv->cap.delta,
•
                   0, -eenv->nrg.diff);
           return eenv->nrg.diff;
.
       }
       /* Compute normalized energy diff */
•
       nrg_delta = normalize_energy(eenv->nrg.diff);
       eenv->nrg.delta = nrg delta;
•
       eenv->payoff = schedtune_accept_deltas(
•
               eenv->nrg.delta,
               eenv->cap.delta,
               eenv->task);
```

```
trace sched energy diff(eenv->task,
              eenv->src cpu, eenv->dst cpu, eenv->util delta,
              eenv->nrg.before, eenv->nrg.after, eenv->nrg.diff,
              eenv->cap.before, eenv->cap.after, eenv->cap.delta,
              eenv->nrg.delta, eenv->payoff);
       * When SchedTune is enabled, the energy diff() function will return
•
       * the computed energy payoff value. Since the energy diff() return
        * value is expected to be negative by its callers, this evaluation
       * function return a negative value each time the evaluation return a
        * positive payoff, which is the condition for the acceptance of
        * a scheduling decision
•
       return -eenv->payoff;
•
•
    * energy_diff(): Estimate the energy impact of changing the utilization
.
    * distribution. eenv specifies the change: utilisation amount, source, and
    * destination cpu. Source or destination cpu may be -1 in which case the
    * utilization is removed from or added to the system (e.g. task wake-up).
  If
    * both are specified, the utilization is migrated.
   static inline int energy diff(struct energy env *eenv)
       struct sched_domain *sd;
       struct sched group *sg;
       int sd_cpu = -1, energy_before = 0, energy_after = 0;
       int diff, margin;
       /*在brute函数里面设置好的eenv参数,构造迁移前的环境变量*/
       struct energy_env eenv_before = {
           .util delta = task util(eenv->task),
                     = eenv->src cpu,
           .src cpu
           .dst_cpu
                      = eenv->dst cpu,
                      = eenv->src_cpu,
           .trg_cpu
                      = { 0, 0, 0, 0},
           .nrg
                      = { 0, 0, 0 },
•
           .cap
                      = eenv->task,
           .task
•
       };
       if (eenv->src cpu == eenv->dst cpu)
           return 0;
       /*sd来至于cache sd_ea,是cpu对应的顶层sd(tl DIE层)*/
       sd cpu = (eenv->src cpu != -1) ? eenv->src cpu : eenv->dst cpu;
       sd = rcu_dereference(per_cpu(sd_ea, sd_cpu));
•
       if (!sd)
           return 0; /* Error */
       sg = sd->groups;
       /*遍历sg所在sg链表,找到符合条件的sg, 累加计算eenv_before、eenv
       相关sg的功耗*/
       do { /*如果当前sg包含src_cpu或者dst_cpu,则进行计算*/
           if (cpu in_sg(sg, eenv->src_cpu) || cpu_in_sg(sg, eenv->dst_cpu)) {
               /*当前顶层sg为eenv的sg top*/
              eenv_before.sg_top = eenv->sg_top = sg;
               /*计算eenv_before负载下sg的power*/
              if (sched group energy(&eenv before))
                  return 0; /* Invalid result abort */
              energy_before += eenv_before.energy;
              /* Keep track of SRC cpu (before) capacity */
```

```
eenv->cap.before = eenv before.cap.before;
               eenv->cap.delta = eenv before.cap.delta;
               /*计算eenv负载下sg的power*/
               if (sched_group_energy(eenv))
                   return 0; /* Invalid result abort */
               energy_after += eenv->energy;
           }
       } while (sg = sg->next, sg != sd->groups);
       /*计算energy_after - energy_before*/
       eenv->nrg.before = energy_before;
       eenv->nrg.after = energy after;
       eenv->nrg.diff = eenv->nrg.after - eenv->nrg.before;
       eenv->payoff = 0;
   #ifndef CONFIG SCHED TUNE
•
       trace_sched_energy_diff(eenv->task,
               eenv->src cpu, eenv->dst cpu, eenv->util delta,
               eenv->nrg.before, eenv->nrg.after, eenv->nrg.diff,
               eenv->cap.before, eenv->cap.after, eenv->cap.delta,
               eenv->nrg.delta, eenv->payoff);
   #endif
•
        * Dead-zone margin preventing too many migrations.
       margin = eenv->nrg.before >> 6; /* ~1.56% */
.
       diff = eenv->nrg.after - eenv->nrg.before;
       eenv->nrg.diff = (abs(diff) < margin) ? 0 : eenv->nrg.diff;
.
       return eenv->nrg.diff;
   /*接下来看sched_group_energy函数的实现过程*/
•
   /*
    * sched group energy(): Computes the absolute energy consumption of cpus
    * belonging to the sched group including shared resources shared only by
    * members of the group. Iterates over all cpus in the hierarchy below the
    * sched group starting from the bottom working it's way up before going to
    * the next cpu until all cpus are covered at all levels. The current
    * implementation is likely to gather the same util statistics multiple
   times.
   * This can probably be done in a faster but more complex way.
    * Note: sched_group_energy() may fail when racing with sched_domain
   updates.
    */
   static int sched group energy(struct energy env *eenv)
       struct cpumask visit cpus;
       u64 total energy = 0;
       int cpu count;
       WARN_ON(!eenv->sg_top->sge);
       cpumask copy(&visit cpus, sched group cpus(eenv->sg top));
       /* If a cpu is hotplugged in while we are in this function,
        * it does not appear in the existing visit cpus mask
        * which came from the sched group pointer of the
        * sched domain pointed at by sd ea for either the prev
        * or next cpu and was dereferenced in energy diff.
```

```
* Since we will dereference sd scs later as we iterate
    * through the CPUs we expect to visit, new CPUs can
    * be present which are not in the visit cpus mask.
    * Guard this with cpu count.
   cpu_count = cpumask_weight(&visit_cpus);
   /*根据sg_top顶层sd,找到需要计算的cpu集合visit_cpus,逐个遍历其中每一个
   cpu,这一套复杂的循环算法计算下来,其实就计算了几个power,以cpu0-cpu3为例
  :4个底层sg的power + 1个顶层sg的power*/
   while (!cpumask empty(&visit cpus)) {
       struct sched group *sg shared cap = NULL;
       /*选取visit_cpus中的第一个cpu*/
       int cpu = cpumask first(&visit cpus);
       struct sched domain *sd;
        * Is the group utilization affected by cpus outside this
        * sched group?
        * This sd may have groups with cpus which were not present
        * when we took visit cpus.
       sd = rcu dereference(per cpu(sd scs, cpu));
       if (sd && sd->parent)
           sg shared cap = sd->parent->groups;
        /*从底层到顶层逐个遍历cpu所在的sd*/
       for each domain(cpu, sd) {
           struct sched group *sg = sd->groups;
            /*如果是顶层sd, 只会计算一个sg*/
           /* Has this sched domain already been visited? */
           if (sd->child && group_first_cpu(sg) != cpu)
              break;
           /*逐个遍历该层次sg链表所在sg*/
           do {
              unsigned long group_util;
              int sg_busy_energy, sg_idle_energy;
              int cap_idx, idle_idx;
              if (sg shared cap && sg shared cap->group weight >=
sg->group weight)
                  eenv->sg_cap = sg_shared_cap;
                  eenv->sg cap = sg;
               /*根据eenv指示的负载变化,找出满足该sg中最大负载cpu的
                 capacity_index*/
              cap_idx = find_new_capacity(eenv, sg->sge);
              if (sg->group weight == 1) {
                  /* Remove capacity of src CPU (before task move) */
                  if (eenv->trg cpu == eenv->src cpu &&
                      cpumask_test_cpu(eenv->src_cpu,
sched_group_cpus(sg))) {
```

```
eenv->cap.before = sg->sge->cap states[cap idx].cap;
                           eenv->cap.delta -= eenv->cap.before;
                       /* Add capacity of dst CPU (after task move) */
                      if (eenv->trg cpu == eenv->dst cpu &&
                          cpumask_test_cpu(eenv->dst_cpu,
   sched_group_cpus(sg))) {
                          eenv->cap.after = sg->sge->cap states[cap idx].cap;
                           eenv->cap.delta += eenv->cap.after;
                   }
                   /*找出sg所有cpu中最小的idle index*/
                   idle_idx = group_idle_state(eenv, sg);
    /*累加sg中所有cpu的相对负载,
                最大负载为sg->sge->cap_states[eenv->cap_idx].cap*/
                   group_util = group_norm_util(eenv, sg);
         /*计算power = busy_power + idle_power*/
                   sg_busy_energy = (group_util *
   sg->sge->cap_states[cap_idx].power);
                   sg idle energy = ((SCHED LOAD SCALE-group util)
                                   * sg->sge->idle states[idle idx].power);
                   total energy += sg busy energy + sg idle energy;
                   if (!sd->child) {
                        * cpu count here is the number of
                       * cpus we expect to visit in this
                       * calculation. If we race against
                       * hotplug, we can have extra cpus
                        * added to the groups we are
                        * iterating which do not appear in
                       * the visit cpus mask. In that case
                       * we are not able to calculate energy
                        * without restarting so we will bail
                       * out and use prev cpu this time.
                       */
                       if (!cpu count)
                          return -EINVAL;
                       /*如果遍历了底层sd. 从visit cpus中去掉对应的sq cpu*/
                       cpumask xor(&visit cpus, &visit cpus,
   sched_group_cpus(sg));
                       cpu_count--;
                   }
•
                  if (cpumask equal(sched group cpus(sg),
   sched_group_cpus(eenv->sg_top)))
                      goto next_cpu;
               } while (sg = sg->next, sg != sd->groups);
           }
```

```
* If we raced with hotplug and got an sd NULL-pointer;
            * returning a wrong energy estimation is better than
            * entering an infinite loop.
            * Specifically: If a cpu is unplugged after we took
            * the visit cpus mask, it no longer has an sd scs
            * pointer, so when we dereference it, we get NULL.
          if (cpumask test cpu(cpu, &visit cpus))
              return -EINVAL;
  next cpu: /*如果遍历了cpu的底层到顶层sd, 从visit_cpus中去掉对应的cpu*/
•
          cpumask clear cpu(cpu, &visit cpus);
•
          continue;
       eenv->energy = total energy >> SCHED CAPACITY SHIFT;
•
      return 0;
```

计算思想简单,但是代码计算比较烧脑,痛苦。。。。。。。。。。。。。

1.3 如果不使用EAS,那又怎么挑选合理的cpu呢?

接着分析select_task_rq_fair函数剩下的部分:

```
static int
select task rq fair(struct task struct *p, int prev cpu, int sd flag, int
wake flags,
            int sibling_count_hint)
    if (energy_aware())
        return select energy cpu brute(p, prev cpu, sync);
    /*如果没有启用EAS,则使用传统的方式来挑选合适的cpu*/
    rcu read lock();
    for each domain(cpu, tmp) {
        if (!(tmp->flags & SD LOAD BALANCE))
            break:
         * If both cpu and prev cpu are part of this domain,
         * cpu is a valid SD WAKE AFFINE target.
         */
        if (want affine && (tmp->flags & SD WAKE AFFINE) &&
            cpumask_test_cpu(prev_cpu, sched_domain_span(tmp))) {
            affine sd = tmp;
            break;
        if (tmp->flags & sd flag)
            sd = tmp;
        else if (!want affine)
            break;
    if (affine sd) {
```

2 当挑选的cpu与当前唤醒进程所在的cpu不同时,怎么处理?

```
cpu = select task rq(p, p->wake cpu, SD BALANCE WAKE, wake flags,
                 sibling_count_hint);
    if (task cpu(p) != cpu) {
       wake_flags |= WF_MIGRATED;
        set task_cpu(p, cpu);
    }
void set task cpu(struct task struct *p, unsigned int new cpu)
#ifdef CONFIG SCHED DEBUG
     * We should never call set task cpu() on a blocked task,
     * ttwu() will sort out the placement.
    WARN ON ONCE(p->state != TASK RUNNING && p->state != TASK WAKING &&
            !p->on rq);
#ifdef CONFIG LOCKDEP
     * The caller should hold either p->pi lock or rq->lock, when changing
    * a task's CPU. ->pi lock for waking tasks, rq->lock for runnable
tasks.
     * sched move task() holds both and thus holding either pins the cgroup,
```

```
* see task group().
     * Furthermore, all task rq users should acquire both locks, see
     * task_rq_lock().
    WARN ON ONCE (debug locks && !(lockdep is held(&p->pi lock) ||
                      lockdep is held(&task rq(p)->lock)));
#endif
#endif
    trace sched migrate task(p, new cpu);
   if (task cpu(p) != new cpu) {
        if (p->sched_class->migrate_task_rq)
           p->sched class->migrate task rq(p);
        p->se.nr_migrations++;
        perf_event_task_migrate(p);
       walt fixup busy time(p, new cpu);
    }
   __set_task_cpu(p, new_cpu);
 * Called immediately before a task is migrated to a new cpu; task cpu(p)
* cfs rq of(p) references at time of call are still valid and identify the
 * previous cpu. However, the caller only guarantees p->pi_lock is held; no
 * other assumptions, including the state of rq->lock, should be made.
static void migrate task rq fair(struct task struct *p)
     * We are supposed to update the task to "current" time, then its up to
date
     * and ready to go to new CPU/cfs_rq. But we have difficulty in getting
     * what current time is, so simply throw away the out-of-date time. This
     * will result in the wakee task is less decayed, but giving the wakee
more
     * load sounds not bad.
   /*重新计算在新cpu上的调度实体的负载*/
   remove entity load avg(&p->se);
   /*重置新的调度实体的负载的最后更新时间和调度实体的执行时间*/
    /* Tell new CPU we are migrated */
    p->se.avg.last update time = 0;
   /* We have migrated, no longer consider this task hot */
    p->se.exec start = 0;
/*
 * Synchronize entity load avg of dequeued entity without locking
```

```
void sync entity load avg(struct sched entity *se)
•
      struct cfs_rq *cfs_rq = cfs_rq_of(se);
       u64 last update time;
      last update time = cfs rq last update time(cfs rq);
      __update_load_avg(last_update_time, cpu_of(rq_of(cfs_rq)), &se->avg, 0,
   0, NULL);
    * Task first catches up with cfs rg, and then subtract
    * itself from the cfs rq (task must be off the queue now).
  void remove_entity_load_avg(struct sched_entity *se)
       struct cfs_rq *cfs_rq = cfs_rq_of(se);
        * tasks cannot exit without having gone through wake up new task() ->
        * post init entity util avg() which will have added things to the
        * cfs rq, so we can remove unconditionally.
        * Similarly for groups, they will have passed through
        * post init entity util avg() before unregister sched fair group()
        * calls this.
        * /
       sync entity load avg(se);
       atomic long add(se->avg.load avg, &cfs rq->removed load avg);
       atomic long add(se->avg.util avg, &cfs rq->removed util avg);
```

3 How task p enqueue?

入队操作:ttwu_queue(p, cpu);

```
static void ttwu_queue(struct task_struct *p, int cpu)
{
    struct rq *rq = cpu_rq(cpu);

#if defined(CONFIG_SMP)

if (sched_feat(TTWU_QUEUE) && !cpus_share_cache(smp_processor_id(), cpu)) {
    sched_clock_cpu(cpu); /* sync clocks x-cpu */
    ttwu_queue_remote(p, cpu);
    return;
}

#endif

raw_spin_lock(&rq->lock);
lockdep_pin_lock(&rq->lock);
ttwu_do_activate(rq, p, 0);
lockdep_unpin_lock(&rq->lock);
```

```
raw spin unlock(&rq->lock);
static void
ttwu do activate(struct rq *rq, struct task struct *p, int wake flags)
    lockdep assert held(&rq->lock);
#ifdef CONFIG SMP
   if (p->sched contributes to load)
       rq->nr uninterruptible--;
#endif
   ttwu_activate(rq, p, ENQUEUE_WAKEUP | ENQUEUE_WAKING);
    ttwu do wakeup(rq, p, wake flags);
static inline void ttwu_activate(struct rq *rq, struct task_struct *p, int
{ /*实际入队的核心函数,同时更新task的vruntime并插入rb tree*/
 activate_task(rq, p, en flags);
   p->on rq = TASK ON RQ QUEUED;
    /* if a worker is waking up, notify workqueue */
    if (p->flags & PF WQ WORKER)
        wq worker waking up(p, cpu of(rq));
 * Mark the task runnable and perform wakeup-preemption.
static void
ttwu do wakeup(struct rq *rq, struct task struct *p, int wake flags)
    check preempt curr(rq, p, wake flags);
    /*修改task的状态为running状态,即task正在cpu上运行*/
  p->state = TASK RUNNING;
    trace_sched_wakeup(p);
#ifdef CONFIG SMP
    /*cfs没有定义*/
    if (p->sched class->task woken) {
         * Our task @p is fully woken up and running; so its safe to
         * drop the rq->lock, hereafter rq is only used for statistics.
        lockdep unpin lock(&rq->lock);
        p->sched class->task woken(rq, p);
        lockdep pin lock(&rq->lock);
    /*如果之前rq处于idle状态,即cpu处于idle状态,则修正rq的idle时间戳和判决idle时间*/
    if (rq->idle stamp) {
        u64 delta = rq_clock(rq) - rq->idle_stamp;
        u64 max = 2*rq->max idle balance cost;//max=1ms
```

3.1 核心函数activate task分析

```
void activate task(struct rq *rq, struct task struct *p, int flags)
    /*如果进程被置为TASK UNINTERRUPTIBLE状态的话,减少处于uninterruptible状态的进程
   数量,因为当前是进程处于唤醒运行阶段*/
    if (task contributes to load(p))
       rq->nr uninterruptible--;
    /*入队操作*/
    enqueue_task(rq, p, flags);
}
#define task contributes to load(task)
               ((task->state & TASK UNINTERRUPTIBLE) != 0 && \
                 (task->flags & PF FROZEN) == 0 && \
                 (task->state & TASK NOLOAD) == 0)
static inline void enqueue_task(struct rq *rq, struct task_struct *p, int
flags)
    update rq clock(rq);
    /*flag=0x3 \& 0x10 = 0*/
    if (!(flags & ENQUEUE RESTORE))
        /*更新task p入队的时间戳*/
        sched_info_queued(rq, p);
#ifdef CONFIG_INTEL_DWS //没有定义
    if (sched feat(INTEL DWS))
        update rq runnable task avg(rq);
#endif
    /*callback enqueue task fair函数*/
    p->sched_class->enqueue_task(rq, p, flags);
```

核心函数enqueue_task_fair解析如下:

```
/*
  * The enqueue_task method is called before nr_running is
  * increased. Here we update the fair scheduling stats and
  * then put the task into the rbtree:
  */
  static void
  enqueue_task_fair(struct rq *rq, struct task_struct *p, int flags)
  {
    struct cfs_rq *cfs_rq;
    struct sched_entity *se = &p->se;
  #ifdef CONFIG_SMP
    /*task_new = 0x3 & 0x20 = 0*/
```

```
int task new = flags & ENQUEUE WAKEUP NEW;
   #endif
       /*进程p开始运行,并将进程p的运行时间累加到整个rq的cumulative_runnable_avg时间
•
       上,作为rq的负载值*/
       walt inc cumulative runnable avg(rq, p);
       * Update SchedTune accounting.
        * We do it before updating the CPU capacity to ensure the
       * boost value of the current task is accounted for in the
       * selection of the OPP.
        * We do it also in the case where we enqueue a throttled task;
        * we could argue that a throttled task should not boost a CPU,
        * however:
        * a) properly implementing CPU boosting considering throttled
           tasks will increase a lot the complexity of the solution
       * b) it's not easy to quantify the benefits introduced by
       * such a more complex solution.
        * Thus, for the time being we go for the simple solution and boost
        * also for throttled RQs.
       /*主要根据这个task的属性是否需要update task group的boost参数*/
       schedtune_enqueue_task(p, cpu_of(rq));
       * If in iowait is set, the code below may not trigger any cpufreq
        * utilization updates, so do it here explicitly with the IOWAIT flag
        * passed.
       */
       /*如果进程p是一个iowait的进程,则进行cpu频率调整*/
       if (p->in iowait)
           cpufreq update util(rq, SCHED CPUFREQ IOWAIT);
       for each sched entity(se) {
           if (se->on rq)
              break;
          cfs_rq = cfs_rq_of(se);
           walt inc cfs cumulative runnable avg(cfs rq, p);
           enqueue entity(cfs rq, se, flags);
           * end evaluation on encountering a throttled cfs rq
           * note: in the case of encountering a throttled cfs rq we will
            * post the final h nr running increment below.
           if (cfs_rq_throttled(cfs_rq))
           cfs_rq->h_nr_running++;
          flags = ENQUEUE WAKEUP;
```

```
for_each_sched_entity(se) {
       cfs_rq = cfs_rq_of(se);
        cfs_rq->h_nr_running++;
        walt_inc_cfs_cumulative_runnable_avg(cfs_rq, p);
        if (cfs_rq_throttled(cfs_rq))
           break;
        update_load_avg(se, UPDATE_TG);
        update_cfs_shares(se);
    }
    if (!se)
        add_nr_running(rq, 1);
#ifdef CONFIG SMP
    if (!se) {
       struct sched domain *sd;
        rcu_read_lock();
        sd = rcu_dereference(rq->sd);
        if (!task_new && sd) {
            if (cpu_overutilized(rq->cpu))
                set_sd_overutilized(sd);
            if (rq->misfit_task && sd->parent)
                set_sd_overutilized(sd->parent);
        rcu_read_unlock();
    }
#endif /* CONFIG_SMP */
    hrtick update(rq);
```

后面的流程与新创建进程的流程一致了。