ZGHA AD 2.1 机场地名代码和名称 Aerodrome location indicator and name

ZGHA-长沙/黄花 CHANGSHA/Huanghua

ZGHA AD 2.2 机场地理位置和管理资料 Aerodrome geographical and administrative data

1	机场基准点坐标及其在机场的位置 ARP coordinates and site at AD	N28° 11.4' E113° 13.1' 181° MAG, 300m from RWY18R/36L center
2	方向、距离 Direction and distance from city	92° GEO, 24.4km from May Day Square of Changsha city
3	标高 / 参考气温 Elevation/Reference temperature	67m / 34.4° C(JUL)
4	机场标高位置 / 高程异常 AD ELEV PSN/ geoid undulation	THR18R/-
5	磁差 / 年变率 MAG VAR/Annual change	3° W (2016) /-
6	机场管理部门、地址、电话、传真、 AFS、电子邮箱、网址 AD administration, address, telephone, telefax, AFS, E-mail, website	Hunan Airport CO.LTD Changsha Huanghua International Airport Branch Company Changsha Huanghua Airport, Changsha 410141, Hunan province, China TEL: 86-731-84797022 FAX: 86-731-84799343 AFS: ZGHAYDYX E-mail: csjcjm@hncaac.com
7	允许飞行种类 Types of traffic permitted(IFR/VFR)	IFR/VFR
8	机场性质 / 飞行区指标 Military or civil airport & Reference code	Civil/4E
9	备注 Remarks	Nil

ZGHA AD 2.3 工作时间 Operational hours

1	机场当局(机场开放时间) AD Administration (AD operational hours)	H24
2	海关和移民 Customs and immigration	H24
3	卫生健康部门 Health and sanitation	H24
4	航行情报服务讲解室 AIS Briefing Office	H24
5	空中交通服务报告室 ATS Reporting Office (ARO)	H24
6	气象讲解室 MET Briefing Office	H24
7	空中交通服务 ATS	H24
8	加油 Fuelling	H24

9	地勤服务 Handling	H24
10	保安 Security	H24
11	除冰 De-icing	H24
12	备注 Remarks	Nil

ZGHA AD 2.4 地勤服务和设施 Handling services and facilities

1	货物装卸设施 Cargo-handling facilities	Container platform lift, conveyor belt truck, luggage towing vehicle, loading supervision truck, fork, ferry, baggage trailer, container tractor, multifuctional container&paneling trailer, electric pallet dolly, electric tractor
2	燃油 / 滑油牌号 Fuel/oil types	Nr.3 jet fuel
3	加油设施 / 能力 Fuelling facilities/capacity	Hydrant dispenser: 20 litres/ sec; tank vehicle: 20 litres/ sec; apron refueling well
4	除冰设施 De-icing facilities	5 de-icers, de-icing fluid
5	过站航空器机库 Hangar space for visiting aircraft	Nil
6	过站航空器的维修设施 Repair facilities for visiting aircraft	Line maintenance available for: B737-300/400/500/600/700/800/900、B757-200、B767-300、A300-600、A310-200、A319、A320-200、A321、A330-200/300、MD-90、DORNIER328-300、CRJ-200、EMB-145, etc.
7	备注 Remarks	Ground power unit, ground air supply unit, ground air preconditioning unit, jet bridge power unit, jet bridge air-conditioning

ZGHA AD 2.5 旅客设施 Passenger facilities

1	宾馆 Hotels	At AD
2	餐馆 Restaurants	At AD
3	交通工具 Transportation	Passenger's coaches, taxis
4	医疗设施 Medical facilities	First aid at AD, hospital in the city
5	银行和邮局 Bank and Post Office	At AD
6	旅行社 Tourist Office	At AD

7	备注 Remarks	Nil
---	---------------	-----

ZGHA AD 2.6 援救与消防服务 Rescue and fire fighting services

1	机场消防等级 AD category for fire fighting	CAT 9	
2	援救设备 Rescue equipment	Fire fighting facilities: primary foam tender, dry-chemical tender, heavy-duty foam tender, command car, disassembly rescue truck, illumination truck, rapid intervention vehicle Rescue equipment: hoodexhaustfan, electric handdrill, toothless cutting saw, life-saving air-cushion, hydraulic expander, temperature tester, combustible gas detector, fire axe, fire crowbar.	
3	搬移受损航空器的能力 Capability for removal of disabled aircraft	MTWA up to B747-400	
4	备注 Remarks	Nil	

ZGHA AD 2.7 可用季节 - 扫雪 Seasonal availability-clearing

1	扫雪设备类型 Types of clearing equipment	All seasons snow blower
2	扫雪顺序 Clearance priorities	RWY18R/36L, TWY B, Apron(TWY A inclusive), RWY18L/36R, TWY C
3	备注 Remarks	Nil

ZGHA AD 2.8 停机坪、滑行道及校正位置数据 Aprons, taxiways and check locations data

		Surface:	Cement concrete	
1	停机坪道面和强度 Apron surface and strength	Strength:	PCN 102/R/C/W/T (stands Nr.241-243) PCN 98/R/B/W/T (stands Nr.251-257, 257R, 307) PCN 74/R/B/W/T (stands Nr.201-207, 211-216, 221-228, 231-238) PCN 67/R/B/W/T (stands Nr.301-306) PCN 64/R/C/W/T (stands Nr.121-128) PCN 53/R/B/W/T (stands Nr.1-10, 12, 14, 16-20, 210) PCN 52/R/B/W/T (stands Nr.308-310)	I

		2 滑行道宽度、道面和强度 Taxiway width, surface and strength	Width:	44m: C2-C5, C14-C17, D1, D2, D7, D8, N; 39m:B2; 34.5m: B7, C1, C19, D9; 34m: A(BTN A1 & A3); 31m: A1-A4, B9; 27m: A5-A7; 25m: C, C6, C7, C12, C13, D(BTN D2 & M), D(BTN D7 & D9), M; 23m: B, B1, B3-B6, C8-C11, T7, T8; 22m: A(BTN A3 & A5), A(BTN A6 & A7); 20m: A(BTN A5 & A6); 18m: T3, T6, T13
1	2		Surface:	Asphalt: B, B1-B7, B9 Cement concrete: A, A1-A7, C,C1-C17, C19, D(BTN D2 & M), D(BTN D7 & D9), D1, D2, D7-D9, M, N, T3, T4, T6-T8, T10, T11, T13
			Strength:	PCN 102/R/C/W/T (C, C1-C5, C14-C17, C19, D(BTN D2 & M), D(BTN D7 & D9), D1, D2, D7-D9, M, N) PCN 98/R/B/W/T (T6-T8,T10, T11) PCN 82/R/C/W/T (C6, C7, C12, C13) PCN 81/F/B/W/T (B, B1, B2, B7, B9) PCN 74/R/B/W/T (A(BTN A1 & A5), A1-A4) PCN 73/R/C/W/T (C8-C11) PCN 72/F/B/W/T (B3-B6) PCN 67/R/B/W/T (T4) PCN 53/R/C/W/T (T13) PCN 53/R/B/W/T (A(BTN A5 & A7), A5-A7, T1-T3)
-	3	高度表校正点的位置及其标高 ACL location and elevation	Nil	
	4	VOR/INS 校正点 VOR/INS checkpoints	Nil	
	5	5 备注 Remarks		ne on single side: A, B(North of B9), T3, T6-T8, T13

ZGHA AD 2.9 地面活动引导和管制系统与标识

Surface movement guidance and control system and markings

			Taxiing guidance signs at all intersections of TWY and RWY and at all	l
		航空器机位号码标记牌、滑行道引导	RWY holding positions.	
		线、航空器目视停靠/停放位置引导系	Guide lines at apron and TWY.	
	1	统的使用	Refer AD1.1 for Visual docking guidance system at stands Nr.211-216,	
	1	Use of aircraft stand ID signs, TWY	Nr.221-228, Nr.231-238;	
		guide lines and visual docking/parking	Marshalling assistance for stands Nr. 1-10, 12, 14, 16-20, 121-128, 201-	
ı		guidance system of aircraft stands	207, 210, 241-243, 251-257, 257R, 301-310.	
			Aircraft stand identification sign board at boarding bridge stands.	
				1

	跑道和滑行道标志及灯光 RWY and TWY marking and LGT	RWY markings	THR, RWY designation, TDZ, edge line, center line and aiming point
		RWY lights	Center line, edge line, THR, RWY end, THR wing bar, TDZ(THR36R)
2		TWY markings	Center line, edge line, RWY holding positions, intermediate holding position, No-entry marking(from TWYs B3-B6, C6-C13 to RWY), TWY shoulder,
		TWY lights	Center line, edge line, intermediate holding position, RWY guard lights(TWYs B1, B2, B7, B9, C1-C5, C14-C17, C19, N,D1, D2, D7-D9), rapid exit taxiway indicator(TWYs C6-C13)
3	停止排灯 Stop bars	holding positions On TWY C, BTN	TWY C3 and C5, C15 and C17; lirection of entry rapid exit TWY C6-C13, parallel with
4	备注 Remarks		line lights. sition sign(RWY18L/36R) gn board (MAX wingspan).

ZGHA AD 2.10 机场障碍物 Aerodrome obstacles

Obstacles within a circle with a radius of 15km centered on ARP							
序号 Serial Nr.	障碍物类型 (* 代表有灯光) Obstacle type (*Lighted)	磁方位 BRG (MAG)(degree)	距离 DIST(m)	海拔高度 Elevation(m)	影响的飞行程序及起飞航径区 Flight procedure/take-off flight path area affected		
1	TWR	001	5703	106.5	RWY36R/ Take-off path		
2	TWR	004	10226	141.4	RWY18L/R/ GP INOP final approach		
3	Antenna	005	1579	80.6	RWY18R/ ILS/DME approach		
4	TWR	106	8215	169.3	Circling/ CAT C		
5	TWR	116	5206	145.4	Circling/ CAT B		
6	Antenna	173	1016	77.6	RWY36L/R/ ILS/DME approach		
7	TWR	185	8362	125.4	RWY36R/ GP INOP final approach		
8	TWR	187	10368	130.6	RWY36L/ GP INOP final approach		
9	Chimney	211	2080	106			
10	BLDG	294	10080	277.6	Circling/ CAT D		
11	*New Control TWR	310	825	126.5	Circling/ CAT A		

序号 Serial Nr.	障碍物类型 (* 代表有灯光) Obstacle type (*Lighted)	磁方位 BRG (MAG)(degree)	距离 DIST(m)	海拔高度 Elevation(m)	影响的飞行程序及起飞航径区 Flight procedure/take-off flight path area affected
12	*Control TWR	327	918	104.7	
13	Chimney	354	4253	106.2	RWY36L/ Departure
14	TWR	358	5568	114.5	RWY36L/ Take-off path
15	*TWR	359	7173	131.8	RWY36L/R/ Take-off path; RWY18R/ GP INOP final approach

序号 Serial Nr.	障碍物类型 (* 代表有灯光) Obstacle type (*Lighted)	磁方位 BRG (MAG)(degree)	距离 DIST(m)	海拔高度 Elevation(m)	影响的飞行程序及起飞航径区 Flight procedure/take-off flight path area affected	
1	MT	025	24789	228	RWY36L/R/ Departure	
2	MT	028	28000	302	RWY18L/R/ Initial approach	
3	MT	030	27685	288	RWY18L/R/ RNAV initial approach	
4	MT	032	28408	291	RWY18L/R/ RNAV Arrival (from DAPRO)	
5	MT	032	33070	486	RWY18L/R/ Arrival (from DAPRO)	
6	MT	033	21000	200	RWY36L/R/ Departure	
7	MT	034	32106	368		
8	MT	035	24657	215	RWY36L/R/ Departure	
9	MT	036	47220	654	RWY18L/R/ Arrival (from DAPRO); RWY36L/R/ Arrival (from DAPRO)	
10	MT	061	72731	1600	Minimum surveillance altitude sector Nr.8	
11	MT	064	49437	1298	RWY36L/R/ Arrival (from DAPRO)	
12	MT	064	63450	1571	Sector	
13	MT	065	50300	1360	RWY36L/R/ Arrival (from DAPRO); RWY18L/R/ Holding; Sector	

序号 Serial Nr.	障碍物类型 (* 代表有灯光) Obstacle type (*Lighted)	磁方位 BRG (MAG)(degree)	距离 DIST(m)	海拔高度 Elevation(m)	影响的飞行程序及起飞航径区 Flight procedure/take-off flight path area affected	
14	MT	071	45800	991	RWY18L/R/ Arrival (from OVTAN); Minimum surveillance altitude sector Nr.2	
15	MT	080	39900	831	RWY18L/R/ Arrival (from OVTAN); RWY36L/R/ Arrival (from OVTAN); Minimum surveillance altitude sector Nr.3	
16	MT	091	34505	786	RWY18L/R/ RNAV Arrival (from OVTAN); RWY36L/R/ RNAV Arrival (from OVTAN)	
17	MT	095	21483	549	RWY36L/R/ Arrival (from OVTAN,DAPRO)	
18	MT	097	18662	471	Minimum surveillance altitude sector Nr.4	
19	MT	103	26000	794	RWY18L/R/ RNAV Arrival (from LIG)	
20	MT	106	25714	755	RWY18L/R/ RNAV Holding	
21	MT	107	21629	751	RWY36L/R/ Arrival	
22	MT	115	22630	556	RWY36L/R/ Arrival	
23	MT	124	17600	388	RWY18L/R/ ILS/DME, GP INOP missed approach; RWY36L/R/ Arrival	
24	MT	132	48000	817		
25	MT	136	47398	817	RWY36L/R/ Holding; Sector	
26	MT	137	40050	811	RWY18L/R/ Arrival (from LIG	
27	MT	140	44750	690	RWY36L/R/ Arrival (from LIG	
28	MT	142	38226	663	RWY36L/R/ Arrival (from LIC	
29	MT	146	37718	598	RWY36L/R/ Arrival (from LIC	
30	MT	153	43816	191	RWY18L/R/ Departure (from NIVEM)	
31	MT	154	47940	708	RWY36L/R/ Arrival (from LIG	

序号 Serial Nr.	障碍物类型 (* 代表有灯光) Obstacle type (*Lighted)	磁方位 BRG (MAG)(degree)	距离 DIST(m)	海拔高度 Elevation(m)	影响的飞行程序及起飞航径区 Flight procedure/take-off flight path area affected	
32	MT	156	40625	363	RWY18L/R/ Departure (from NIVEM); Minimum surveillance altitude sector Nr.5	
33	MT	176	28066	227	RWY36L/R Initial approach	
34	MT	177	18943	206	RWY18L/R/ Departure	
35	MT	177	36426	319	RWY36L/R/ Initial approach (from LIG)	
36	MT	184	16800	234	RWY18L/R/ Departure	
37	MT	184	16910	237	RWY36L/R/ Intermediate approach	
38	MT	204	19265	235	RWY18L/R/ Departure	
39	MT	205	32996	328		
40	MT	217	24700	274	RWY36L/R/ Initial approach	
41	MT	253	91500	523	Minimum surveillance altitude sector Nr.6	
42	BLDG	276	24220	498		
43	MT	342	29300	319	Minimum surveillance altitude sector Nr.1	
44	MT	344	43600	777	Minimum surveillance altitude sector Nr.7	
45	TWR	360	17517	157	RWY18L/R/ Intermediate approach	

ZGHA AD 2.11 提供的气象信息、机场观测与报告

Meteorological information provided & aerodrome observations and reports

ſ	1	相关气象室的名称 Associated MET Office	Hunan ATMB MET Office of CAAC
	2	气象服务时间、服务时间以外的责任 气象室 Hours of service, MET Office outside hours	H24
	3	负责编发 TAF 的办公室 ; 有效期 Office responsible for TAF preparation,Periods of validity	Hunan ATMB MET Office of CAAC 9 HR, 24 HR

4	着陆预报类型、发布间隔 Type of landing forecast, Interval of issuance	Trend 1 HR
5	所提供的讲解 / 咨询服务 Briefing/consultation provided	P, T
6	飞行文件及其使用语言 Flight documentation, Languages used	Chart, International MET Codes, Abbreviated Plain Language Text Ch, En
7	讲解 / 咨询服务时可利用的图表和其 它信息 Charts and other information available for briefing or consultation	Synoptic charts, significant weather charts, upper W/T charts, satellite and radar material, AWOS real-time data
8	提供信息的辅助设备 Supplementary equipment available for providing information	FAX, MET radar display, satellite cloud display, AWOS data display
9	接收气象信息的空中交通服务单位 ATS units provided with information	TWR, Changsha ACC, Changsha APP
10	观测类型与频率 / 自动观测设备 Type & frequency of observation/ Automatic observation equipment	Hourly plus special observation/Yes
11	气象报告类型及所包含的补充资料 Type of MET Report & supplementary information included	METAR, SPECI, TREND
12	观测系统及位置 Observation System & Site(s)	SFC wind sensors: RWY18R: 120m E of RCL, 340m inward THR18R; RWY36L: 120m E of RCL, 425m inward THR36L; RWY18R/36L center: 120m E of RCL, 1590m inward THR36L; RWY18L: 110m E of RCL, 462m inward THR18L; RWY36R: 110m E of RCL, 450m inward THR36R; RWY18L/36R center: 110m E of RCL, 1620m inward THR36R. RVR EQPT: A: 120m E of RCL, 380m inward THR18R; B: 120m E of RCL, 1600m inward THR36L; C: 120m E of RCL, 435m inward THR36L; D: 110m E of RCL, 500m inward THR18L; E: 110m E of RCL, 1580m inward THR36R; F: 110m E of RCL, 458m inward THR36R; Ceilometer: RWY18R: 110m E of RCL, 335m inward THR18R; RWY36L: 110m E of RCL, 420m inward THR36L; RWY18L: 100m E of RCL, 457m inward THR18L; RWY36R: 100m E of RCL, 445m inward THR36R;
13	气象观测系统的工作时间 Hours of operation for meteorological observation system	H24
14	气候资料 Climatological information	Climatological tables AVBL
15	其他信息 Additional information	TEL: 86-731-84798822

ZGHA AD 2.12 跑道物理特征 Runway physical characteristics

跑道号码 Designation s RWY NR	真方位和磁方 位 TRUE & MAG BRG	跑道长宽 Dimensions of RWY (m)	跑道强度 (PCN), 跑道 道面 / 停止道道面 RWY strength (PCN), RWY surface/SWY surface	着陆入口坐标及 高程异常 THR coordinates and geoid undulation	跑道着陆入口标高 ,精密进近跑道接 地地带最高标高 THR elevation and highest elevation of TDZ of precision APP RWY
1	2	3	4	5	6

跑道号码 Designation s RWY NR	真方位和磁方 位 TRUE & MAG BRG	跑道长宽 Dimensions of RWY (m)	跑道强度 (PCN), 跑道 道面 / 停止道道面 RWY strength (PCN), RWY surface/SWY surface	着陆入口坐标及 高程异常 THR coordinates and geoid undulation	跑道着陆入口标高 ,精密进近跑道接 地地带最高标高 THR elevation and highest elevation of TDZ of precision APP RWY
18R	177° GEO 181° MAG	3200 × 45	79/F/B/W/T Asphalt/-	Nil	THR66.9m
36L	357° GEO 001° MAG	3200 × 45	00 × 45 79/F/B/W/T Asphalt/-		THR60.4m
18L	177° GEO 181° MAG	3800 × 60	102/R/C/W/T Concrete/-	Nil	THR64.5m
36R	357° GEO 001° MAG	3800 × 60	102/R/C/W/T Concrete/-	Nil	THR57.2m
跑道 - 停止 道坡度 Slope of RWY-SWY	停止道长宽 SWY dimensions (m)	净空道长宽 CWY dimensions (m)	升降带长宽 Strip dimensions (m)	无障碍物地带 OFZ	跑道端安全区长宽 RWY end safety area dimensions (m)
7	8	9	10	11	12
See AOC	Nil	Nil	3320 × 300	Nil	130 × 120
See AOC	Nil	Nil	3320 × 300	Nil	190 × 150
See AOC	Nil	Nil	3920 × 300	Nil	240 × 150
See AOC	Nil	Nil	3920 × 300	Nil	240 × 150

Remarks:

- 1. RWY18L/36R shoulder: 7.5m on each side, RWY18R/36L shoulder: 7.5m on each side;
- 2. RWY18L/36R grooved: 6mm × 6mm × 32mm;
- 3. RWY18L/36R parallels to RWY18R/36L;
- 4. Distance between RCL of RWY18L/36R and RCL of RWY18R/36L is 380m; THR36R is 300m south of THR36L; THR18L is 300m north of THR18R.

ZGHA AD 2.13 公布距离 Declared distances

跑道代号 RWY Designator	可用起飞滑跑 距离 TORA (m)	可用起飞距离 TODA (m)	可用加速停止距离 ASDA (m)	可用着陆距离 LDA (m)	备注 Remarks
18R	3200	3200	3200	3200	Nil
18R	2600	2600	2600	3200	FM B7
36L	3200	3200	3200	3200	Nil
36L	2800	2800	2800	3200	FM B2
18L	3800	3800	3800	3800	Nil
36R	3800	3800	3800	3800	Nil
Remarks:					

ZGHA AD 2.14 进近和跑道灯光 Approach and runway lighting

跑道 代号 RWY Desig nator	进近灯 类型、 长强度 APCH LGT type LEN INTST	入口灯 颜色、 翼排灯 THR LGT colour WBAR	目视研究 (度指道系 (題) , 就	接地地带 灯长度 TDZ LGT LEN	跑道中心线灯 长度、间隔、 颜色、强度 RWY Center line LGT LEN, spacing, colour, INTST	跑道边灯长 度、间隔、颜 色、强度 RWY edge LGT LEN, spacing, colour, INTST	跑道未端 灯颜色 RWY end LGT colour	停止道灯 长度、颜 色 SWY LGT LEN, colour
1	2	3	4	5	6	7	8	9
18R	CAT I 900m* LIH	Green Yes	PAPI Left/3° (18.4m)	Nil	3200m** spacing 30m	3200m*** spacing 60m	Red	Nil
36L	CAT I 900m* LIH	Green Yes	PAPI Right/3° (17m)	Nil	3200m** spacing 30m	3200m*** spacing 60m	Red	Nil
18L	CAT I 900m* LIH	Green Yes	PAPI Left/3° (22.8m)	Nil	3800m**** spacing 15m	3800m**** spacing 60m	Red	Nil
36R	CAT III 900m* LIH	Green Yes	PAPI Right/3° (22.8m)	900m	3800m**** spacing 15m	3800m***** spacing 60m	Red	Nil

Remarks: *SFL

ZGHA AD 2.15 其它灯光, 备份电源 Other lighting, secondary power supply

1	机场灯标 / 识别灯标位置、特性和工作时间 ABN/IBN location, characteristics and hours of operation	Nil
2	着陆方向指示器位置和灯光; 风速表位置和灯光 LDI location and LGT, Anemometer location and LGT	WDI: 18R: 115m E of RCL, 450m inward THR18R; 36L: 115m E of RCL, 530m inward THR36L; 18L: 100m E of RCL, 454.1m inward THR18L; 36R: 100m W of RCL, 435.6m inward THR36R;
3	滑行道边灯和中心线灯光 TWY edge and center line lighting	All TWYs
4	备份电源 / 转换时间 Secondary power supply/switch-over time	Secondary power supply available/15 sec
5	备注 Remarks	Nil

^{** 0-2300}m White VRB LIH, 2300-2900m Red/White VRB LIH, 2900m-3200m Red VRB LIH

^{*** 0-2600}m White VRB LIH, 2600-3200m Yellow VRB LIH

^{**** 0-2900}m White VRB LIH, 2900-3500m Red/White VRB LIH, 3500m-3800m Red VRB LIH

^{***** 0-3200}m White VRB LIH, 3200-3800m Yellow VRB LIH

ZGHA AD 2.16 直升机着陆区域 Helicopter landing area

1	TLOF 坐标或 FATO 入口坐标及高程异常 Coordinates TLOF or THR of FATO Geoid undulation	Nil
2	TLOF 和 / 或 FATO 标高 (m) TLOF and/or FATO elevation (m)	Nil
3	TLOF 和 FATO 区域范围、道面、强度 和标志 TLOF and FATO area dimensions,surface, strength, marking	Nil
4	FATO 的真方位和磁方位 True and MAG BRG of FATO	Nil
5	公布距离 Declared distance available	Nil
6	进近灯光和 FATO 灯光 APP and FATO lighting	Nil
7	备注 Remarks	Nil

ZGHA AD 2.17 空中交通服务空域 ATS airspace

名称 Designation	横向界限 Lateral limits	垂直界限 Vertical limits	备注 Remarks
Huanghua tower control area	A circuit, 4 arcs with radius 13km centered at centers of RWY18R/36L THRs and 4 lines tangential to the adjacent 2 arcs.	750m(QNH) and below	AD Control Zone is same as TWR Control area
Fuel dumping area	N29 15.0E113 49.0 - N29 02.0E114 34.0 - N28 32.0E114 22.0 - N28 57.0E113 59.0 - N29 15.0E113 49.0	Above 4000m	
Altimeter setting region and TL/TA	Same as Changsha APP Control Area	TL 3600m TA 3000m 3300m(QNH ≥ 1031hPa) 2700m(QNH ≤ 979hPa)	

ZGHA AD 2.18 空中交通服务通信设施 ATS communication facilities

服务名称 Service Designation	呼号 Call sign	频率 Frequency (MHz)	工作时间 Hours of operation	备注 Remarks
1	2	3	4	5
ATIS		127.075	H24	for DEP
ATIS		127.6	H24	for ARR
APP	Changsha Approach	119.65 (120.6) AP01	H24	Nil
APP	Changsha Approach	125.65 (125.05) AP02	BY ATC	Nil
APP	Changsha Approach	124.6 (125.05) AP03	BY ATC	Nil
TWR	Huanghua Tower	118.55/118.025 (118.175)	H24	Nil
GND	Huanghua Ground	121.75	0100-1530	contact Huanghua TWR when Huanghua Ground U/S
GND	Huanghua Delivery	121.95	Ву АТС	contact Huanghua Ground when Huanghua Delivery U/S
APN	Changsha Apron	121.85	HO or By ATC	contact Huanghua Ground when Changsha Apron U/S
EMG		121.5	H24	

ZGHA AD 2.19 无线电导航和着陆设施 Radio navigation and landing aids

Name an	称和类型 nd type of iid	识别 ID	频率 Frequency	发射天线位置、 坐标 Antenna site coordinates	DME 发射天线 标高 Elevation of DME transmitting antenna	备注 Remarks
	1	2	3	4	5	6

设施名称和类型 Name and type of aid	识别 ID	频率 Frequency	发射天线位置、 坐标 Antenna site coordinates	DME 发射天线 标高 Elevation of DME transmitting antenna	备注 Remarks
Luchong NDB	SV	345kHz	N28° 13.0′ E113° 20.9′ 081° MAG/ 12862m FM RWY18R/36L center		11NM-13NM and 20NM-22NM on bearing 272°, beyond 14NM on bearing 067° U/S;For departure procedure, 5NM-7NM, 9NM-10NM and 14NM-19NM on bearing 304° U/S; For arrival procedure, 15NM-18NM on bearing 071° U/S, 12NM-13.5NM and 19NM-20.5NM on bearing 270° U/S, 16NM-17NM and 18NM-20NM on bearing 339° U/S; For holding procedure, 18NM-20NM on bearing 339° U/S
Tiaoma VOR/DME	DTM	114.05MHz CH 87Y	N27° 59.0′ E113° 07.5′ 206° MAG/ 24719m FM RWY18R/36L center	186m	
Liuyang VOR/DME	LYH	113.55MHz CH 82Y	N28° 23.6′ E113° 20.6′ 032° MAG/ 25221m FM RWY18R/36L center	215m	
Liling VOR/DME	LIG	112.4MHz CH 71X	N27° 38.9′ E113° 31.0′	85m	
OM 18R		75MHz	001° MAG/ 6822m FM THR 18R		
LOC 18R ILS CAT I	IWW	110.3MHz	181° MAG/ 190m FM RWY 18R end		Beyond 20NM of front course U/S
GP 18R		335.0MHz	120m E of RCL , 326m inward THR 18R		Angle 3° RDH 15m
DME 18R	IWW	CH 40X (110.3MHz)		72m	Co-located with GP18R

设施名称和类型 Name and type of aid	识别 ID	频率 Frequency	发射天线位置、 坐标 Antenna site coordinates	DME 发射天线 标高 Elevation of DME transmitting antenna	备注 Remarks
OM 36L		75MHz	181° MAG/ 8455m FM THR 36L		
LMM 36L	Q	265kHz	181° MAG/ 1203m FM THR 36L		
LOC 36L ILS CAT I	ISV	109.9MHz	001° MAG/ 250m FM RWY 36L end		
GP 36L		333.8MHz	130m E of RCL , 292m inward THR36L		Angle 3° RDH 15m
IM 36R		75MHz	181° MAG/ 286m FM THR 36R		
LOC 36R ILS CAT III	ICR	111.1MHz	001° MAG/ 295m FM RWY 36R end		CAT I operation
GP 36R		331.7MHz	120m E of RCL , 288m inward THR36R		Angle 3° RDH 15m
DME 36R	ICR	CH 48X (111.1MHz)		57m	Co-located with GP36R
LOC 18L ILS CAT I	ISL	109.3MHz	181° MAG/ 265m FM RWY 18L end		
GP 18L		332.0MHz	120m E of RCL , 306m inward THR 18L		Angle 3° RDH 15m
DME 18L	ISL	CH 30X (109.3MHz)		64m	Co-located with GP18L
Gutang NDB	W	388kHz	N28° 13.1′ E113° 13.0′ 001° MAG/ 1518m FM THR 18R		Beyond 30NM on bearing 080° U/S
Remark: Nil					1

ZGHA AD 2.20 本场飞行规定

1. 机场使用规定

- 1.1 所有技术试飞需事先申请,并在得到空中交通管制部门批准后方可进行;
- 1.2 禁止未安装二次雷达应答机的航空器起降,在 特殊情况下,可允许无二次雷达应答机的航空器 起降。

2. 跑道和滑行道的使用

- 2.1 禁止航空器在跑道和滑行道上作180°的大转弯;
- 2.2 当转换使用跑道方向的过程中,短时使用跑道顺风分量超过3.5m/s但不大于5m/s时,管制员应通知机组,飞行员应根据机型性能或者运行手册,决定是否使用管制员安排的顺风跑道起飞或者着陆,并通知管制员;
- 2.3 因管制调配等原因需要或机组提出申请,征得 塔台管制员同意后,离场航空器可实施非全跑道 起飞;
- 2.4 跑道运行规则
- 18R/36L号跑道主要用于离场;
- 18L/36R 号跑道主要用于进场,经管制员许可,可用于出港;
- 2.5 穿越跑道规定 /RWY crossing rules:

ZGHA AD 2.20 Local traffic regulations

1. Airport operations regulations

- 1.1 Each and every technical test flight shall be filed in advance and conducted only after clearance has been obtained from ATC:
- 1.2 Take off/landing of aircraft without SSR transponder are forbidden unless under exceptional circumstances.

2. Use of runways and taxiways

- 2.1 180° turn around on RWY and TWY is forbidden for all aircraft:
- 2.2 when aircraft change direction of runway in use, if downwind speed is more than 3.5m/s and not exceeding 5m/s for short time, ATC controller shall inform flight crew. According to aircraft performance or operation handbook, pilot shall decide whether aircraft will take off or land on downwind runway allocated, then inform ATC controller;
- 2.3 Due to ATC control allocation and other reasons or flight crew request, it is available to use partial runway to take-off when flight crew get permission from TWR ATC;
- 2.4 General rules for the use of runways

18R/36L is mainly used for departure;

18L/36R is mainly used for arrival, and departure with ATC permission;

	RWY36R(for arrival) RWY36L(for departure)	Landing A/C: C14 \rightarrow RWY36L \rightarrow B7 or C16 \rightarrow RWY36L \rightarrow B9
航空器穿越跑道时	RWY18L(for arrival) RWY18R(for departure)	Landing A/C: C2 \rightarrow RWY18R \rightarrow B1 or C4 \rightarrow RWY18R \rightarrow B2
使用的滑行道 TWYs used for A/C crossing RWY	RWY36R(for depart arrival)	Departure A/C: B1 → RWY36L → C2 Landing A/C: C14 → RWY36L → B7 or C16 → RWY36L → B9
	RWY18L(for depart arrival)	Departure A/C: B9 → RWY18R → C16 Landing A/C: C2 → RWY18R → B1 or C4 → RWY18R → B2

按照管制员指挥滑行至跑道等待点外等待;

Taxi following the instructions of controller to the holding position and hold short of RWY;

收到穿越指令后,需尽快实施穿越,如有疑问,请在穿越前证实;

Cross the runway immediately upon receiving the crossing clearance. Any questions shall be clarified before crossing RWY;

机组应完整复诵管制员有关穿越跑道和跑道外等待的指令,穿越结束后,机组需向塔台报告"已脱离跑道";

Repeat all the ATC instructions concerning 'hold short of RWY or cross the RWY', finally, report to TWR Control 'RWY vacated'; 穿越跑道时, 机组应注意监听其他有关跑道的指令或信息通报, 并注意观察跑道及附近的活动;

Pilots shall monitor the ATC instructions or information about RWY and watch the activities on and around RWY;

紧跟在起飞航空器后穿越跑道时,机组自行负责其与起飞航空器之间的距离 以免受起飞航空器喷流的影响;

While crossing RWY after the take-off aircraft, pilots shall be responsible for the safety distance with the aircraft to avoid the effect of wake turbulence;

穿越程序

Procedures for RWY crossing

2.6 跑道等待位置

- 2.6.1 航空器在进入跑道前应在指定的跑道等待位置处等待塔台管制员指令,参见 AD2.24-1A/2:
- 2.6.2 航空器未获管制员许可, 机头越过跑道等待位置时, 立即向管制员报告;
- 2.7 禁止翼展大于52米 (含)的航空器使用滑行道B4, B5; T10 机坪滑行道翼展限制65m (不含), T11 机坪滑行道翼展限制36m (不含);
- 2.8 当航空器在跑道等待点外等待时,禁止其它 航空器从其后方通过;
- 2.9 机场冲突多发地带运行要求
- 2.9.1 机动区冲突多发地带位置见AD2.24-1A/2;

HS1: 滑行道A7、B7、B及交叉区域。航空器在 HS1 区域运行时需加强观察,严格照管制员的指 令运行,避免冲突。若观察到B7有航空器脱离, 应主动避让;

HS2: 滑行道C16穿越36L跑道等待区域。航空器由此区域穿越跑道之前,必须得到塔台管制员的许可。

HS3: 滑行道C14穿越36L跑道等待区域。航空器由此区域穿越跑道之前,必须得到塔台管制员的许可。

2.6 Runway holding position

- 2.6.1 Aircraft shall stop and wait for TWR ATC instruction at the runway holding positions. Refer to AD2.24-1A/2;
- 2.6.2 A/C shall report to ATC when the nose of A/C exceeding holding position without instruction;
- 2.7 TWY B4, B5 are only available for aircraft with wing span less than 52m. TWY T10 is only available for aircraft with wing span less than 65m. TWY T11 is only available for aircraft with wing span less than 36m.
- 2.8 It is forbidden that taxiing behind the A/C which is holding at short of the runway holding position;
- 2.9 Hot spot procedure
- 2.9.1 Refer to AD2.24-1A/2;

HS1: Intersections of TWYs A7, B7, B. A/C in HS1 shall observe cautiously, then operate according to ATC clearance, and avoid conflict. A/C shall hold short in front of TWY B7, when other A/C is vacating TWY B7;

HS2: Cross RWY36L at TWY C16 holding area. A/C shall get clearance from TWR controller before crossing RWY36L.

HS3: Cross RWY36L at TWY C14 holding area. A/C shall get clearance from TWR controller before crossing RWY36L.

HS4: 滑行道 C4 穿越 18R 跑道等待区域。航空器 由此区域穿越跑道之前,必须得到塔台管制员的 许可。

HS5: 滑行道 C2 穿越 18R 跑道等待区域。航空器由此区域穿越跑道之前,必须得到塔台管制员的许可。

- 2.10 离港航空器应按照ATC指定的滑行路线滑行,得到允许后方可由滑行道进入跑道;
- 2.11 当307号机位无飞机停放时,滑行线T8限制 为翼展65米 (不含)以下的航空器滑行;当307 号机位有飞机停放时,滑行线T8限制为翼展36米 (不含)以下的航空器滑行;
- 2.12 管制范围规定如下:

空管塔台管制区: B滑行道(含)以东的机动区, 以及241-243号停机位;

长沙机坪管制区: B滑行道 (不含)以西的联络道及机坪, 241-243号停机位除外;

机坪管制区范围见ZGGG AD2.24-1A, 2;

具体管制移交点及移交方式听从管制员指令执 行。 HS4: Cross RWY18R at TWY C4 holding area. A/C shall get clearance from TWR controller before crossing RWY18R.

HS5: Cross RWY18R at TWY C2 holding area. A/C shall get clearance from TWR controller before crossing RWY18R.

- 2.10 Departure aircraft shall taxi on the route designated by ATC. And shall receive clearance before entering RWY.
- 2.11 When parking stand Nr.307 is available, the wing span limit for TWY T8 is less than 65m; when parking stand Nr.307 is unavailable, the wing span limit for TWY T8 is less than 36m.
- 2.12 Rules of ATC scope as follows:

TWR ATC: maneuvering area (east of TWY B(inclusive)), stands Nr. 241-243;

APN ATC: TWYs (west of TWY B(exclusive)), apron (except for stands Nr.241-243);

APN ATC refers to ZGGG AD2.24-1A, 2;

The specific hand-over point and mode shall be instructed by ATC.

3. 机坪和机位的使用

3.1 航空器滑入机坪须由引导车引导。

3. Use of aprons and parking stands

3.1 A/C taxiing into apron shall guided by follow-me vehicle.

3.2 机位使用限制 /Limits for aircraft parking on the following stands:

停机位 /Stands	航空器翼展限制 /Wing span limits for A/C(m)	机身长度限制 /Fuselage limits for A/C(m)	滑入、滑出方式 /Enter or Exit
Nr.305,306,308-310	24	33.5	Taxi in and push back
Nr.301-303	29	36.9	Taxi ili aliu pusii back
Nr.121-128	36	44	Taxi in and taxi out
Nr.251-256, 257R	36	44.5	Taxi in and taxi out

	1	T	T
Nr.2		54.1	
Nr.3		53.7	
Nr.7		83	
Nr.9,304		51.7	
Nr.201-207		70	
Nr.215,216		51	Taxi in and push back
Nr.221,222,224,225	36	60	
Nr.227,228		59	
Nr.231		62.5	
Nr.232		64	
Nr.238		65.7	
Nr.12		83.6	
Nr.16-20		36.7	Taxi in and taxi out
Nr.8	38	63.5	
Nr.4		93.8	
Nr.5		113.2	
Nr.6		113.9	
Nr.211		75.7	
Nr.213	52	73.4	Taxi in and push back
Nr.223		75	
Nr.226		91	
Nr.234		76.3	
Nr.236,237		65.7	
Nr.1	60.3	81.8	
Nr.14		83.6	Taxi in and taxi out
Nr.10		94.5	
Nr.214	61	94	
Nr.233		83	
Nr.241		94.7	
Nr.210		103.1	Taxi in and push back
Nr.212		99.1	1
Nr.235	65	113	
Nr.242-243		94.7	
Nr.307	 	83.5	
Nr.257	65	84.5	Push in and taxi out
D 1 1 C 1N 0:	1 111 6 4/04	D757 200 11 1	- don in this thin out

Remarks: 1. Stand Nr.8 is only available for A/C type B757-200 and below;

3.3 航空器不能同时使用的机位 / Pair of stands forbidden to use simultaneously:

使用机位 /The stand in use	不能同时停放的机位 / The stands forbidden to park

^{2.}Stands Nr.16-20, 121-128 are only available for A/C parking with nose-to-west;

^{3.}A/C shall taxi out apron by its own power after exiting stands by the way mentioned on the table above.

^{4.}A/C CAT D&E shall taxi to stand Nr.257 via TWY T10 and be pushed into the stand with nose to north.

210	211		
211	210		
257	257R		
257R	257		
使用机位 /The stand in use	不能同时滑行或推出的机位 / The stands forbidden to taxi in or pushed back		
210 or 211	212 or 1		
1 or 212	210 or 211		
10	12 or 14		
12 or 14	10		
Remarks: All the adjacent stands on apron cannot operate simultaneously.			

- 3.4 航空器在进入16-20号机位时,不得在已开车 3.4 A/C entering into stands Nr. 16-20 cannot taxi behind 航空器的后方通过;
- 3.5 进场航空器需要申请地面服务时,可联系机 场运行控制室(131.15MHZ);
- 3.6 需要试车的航空器,需经长沙机坪和机务维 修部门许可,并在指定地点进行。严禁在廊桥附 近、滑行道上试大车;
- 3.7 241-243 号停机位属于空管塔台的地面管制责 任区。 航空器在该区域运行时, 由黄花地面负责 发布推出、开车许可以及进、出停机位滑行路线 等指令。

- started-up A/C at these stands;
- 3.5 Arrival A/C shall contact Areodrome Operation Control Office on 131.15MHZ to apply handling services;
- 3.6 Engine run-ups are subject to Changsha Apron and maintenace department clearance, and may only be carried out at a designated location. Fast engine run-ups in the vicinity of boarding bridges and TWYs are strictly forbidden;
- 3.7 Stands Nr.241-243 belong to the TWR control area. A/C taxiing in/out stands Nr.241-243 shall contact Huanghua Ground for push-back or start-up clearence and taxiing instructions.

4. 进、离场管制规定

- 4.1 进港航空器管制规定
- 4.1.1 为规范跑道占用时间,提高跑道容量,做出以 下规定 (湿跑道或污染跑道除外):

落地航空器应尽快退出跑道,从接地到脱离跑道 时间应控制在50秒以内;

如机组认为无法在上述要求的时间内完成,须在 着陆前通知管制员;

4.1.2 进场航空器脱离跑道后,由黄花塔台指挥其 脱波联系黄花地面。航空器与黄花地面联系时, 必须向黄花地面报告脱离的跑道和所使用的滑 行道等具体位置;

4. Air traffic control regulations

- 4.1 Control regulations for arrival A/C
- 4.1.1 Except for wet RWY or contaminated RWY, requirement as follows to increase RWY operation capacity: Aircraft shall fully vacate runway within 50 seconds after touching down;
- If flight crew consider that they can not fulfill the process within the required time, pilot shall inform ATC controller before landing;
- 4.1.2 Arrival A/C shall follow Huanghua Tower instructions to change to contact Huanghua Ground after vacating RWY. Then report the specific position of vacated RWY and TWY in use to Huanghua Ground;

4.1.3进港航空器滑行至相应机坪联络道口(B滑行道与停机坪的交汇处)并目视引导车后,由黄花地面指挥其联系长沙机坪。航空器按照长沙机坪的指令跟随引导车进入停机位,并在到达机位后报告。

42 离港航空器管制规定

- 4.2.1 离港航空器通过语音或者 PDC 向黄花放行申请放行许可,复诵正确后由黄花放行指挥其联系长沙机坪,并与长沙机坪保持长守;
- 4.2.2 长沙机坪负责发布离港航空器的推出、开车和滑行等指令。在航空器进入地面移交位置(B滑行道与停机坪的交汇处)前,由长沙机坪指挥联系黄花地面。黄花地面继续指挥航空器滑行至跑道等待位置;
- 4.2.3 为减少波道占用时间, 航空器起飞离地后自动与黄花塔台脱波(不需要通话脱波), 塔台将在ATC 许可中明确脱波后应该联系的离场管制频率:
- 4.2.4 为规范跑道占用时间,提高跑道容量,做出以下规定 (湿跑道或污染跑道除外):

起飞的航空器从接到管制员进跑道指令至对正 跑道时间应控制在60秒以内;

如机组认为无法在上述要求的时间内完成,须在 到达跑道外等待点之前向塔台管制员说明;

- 4.1.3 Arrival A/C shall follow Huanghua Ground instructions to change to contact Changsha Apron when taxi into the intersection between TWY B and apron. With Changsha Apron instructions, A/C shall be guided by follow-me vehicle to enter into stand and report to Changsha Apron after parking.
- 4.2 Control regulations for departure A/C
- 4.2.1 Departure A/C shall contact Huanghua Delivery to obtain delivery clearance via voice or PDC. Then A/C shall follow Huanghua Delivery instructions to change to contact Changsha Apron after repeating correctly. And keep listening the Changsha Apron frequency;
- 4.2.4 Changsha Apron issued information such as push-back, start-up and taxiing. Departure A/C shall follow Changsha Apron instructions to change to contact Huanghua Ground before entering the intersection between TWY B and apron. Then taxi to the RWY holding position with Huanghua Ground instructions;
- 4.2.3 In order to avoid frequency congestion, pilot shall leave Huanghua Tower frequency without radiotelephony instruction from controller after taking off and contact APP immediately on the frequency assigned by ATC clearance;
- 4.2.2 Except for wet RWY or contaminated RWY, requirement as follows to increase RWY operation capacity: Departure aircraft shall finish runway alignment within 60 seconds after receiving ATC instructions of entering runway; If flight crew consider that they can not fulfill the process within the required time, pilot shall inform TWR ATC controller before reaching the runway holding point;

5. 机场的 II/III 类运行

- 5.1 HUD特殊批准 I / II 类运行程序
- 5.1.1 跑道运行方式

5. CAT II/III operations at AD

- 5.1 HUD SA CAT I/II operation procedures
- 5.1.1 RWY operation

运行标准 Operating Standards	可使用跑道 RWY available
ILS 特殊 I 类运行 ILS SA CAT I	RWY18L、RWY18R/36L
ILS 特殊 II 类运行 ILS SA CAT II	RWY18L
低能见度起飞 Low visibility take-off	RWY18L/36R、 RWY18R/36L

5.1.2 天气条件

5.1.2 Weather conditions

	实施阶段天气条件 Weather conditions for implementation	结束阶段天气条件 Weather conditions for termination
特殊 I 类 SA CAT I	550m>RVR ≥ 450m or 60m>ceiling ≥ 45m	RVR ≥ 550m and ceiling ≥ 60m(getting better) RVR<450m or ceiling<45m(getting bad)
特殊Ⅱ类 SA CAT II	450m>RVR ≥ 350m or 45m>ceiling ≥ 30m	RVR ≥ 450m and ceiling ≥ 45m(getting better) RVR<350m or ceiling<30m(getting bad)
低能见度起飞 Low visibility take-off	400m>RVR ≥ 200m	RVR ≥ 400m(getting better) RVR<200(getting bad)

5.1.3 信息发布及启动申请

5.1.3.1 根据天气条件及地面保障情况,由机场运行控制室宣布启动或结束HUD特殊批准II类运行和低能见度起飞,由民航湖南空管分局塔台管制室通过D-ATIS、ATIS、VHF(根据运行情况选择方式)向机组发布信息。

5.1.3.2 航空公司飞行机组在运行 HUD 特殊批准 I 类前应主动向管制员报告。

5.1.4 地面运行规定

5.1.4.1 实施HUD低能见度运行时, 机组严格按照 管制指令给出的地面路线滑行。

5.1.4.2 进场航班从建立 18L 跑道航向道至落地期间,离场航班不得进入 18R 跑道,应在 B9、 18R 跑道等待位置等待; 航班在 18L 跑道落地后,必须滑行穿越 18R 跑道后方可指挥后续进场航班使用 18L 跑道进近落地。

5.1.4.3 实施HUD低能见度运行时,通常情况下, B滑行道上同时运行的航空器不超过两架。

5.1.4.4 在实施HUD低能见度运行时, 所有进离港 航空器的地面滑行根据机组需求提供引导车引 导

5.1.5 特殊要求

5.1.5.1 机场 HUD 低能见度程序从准备至启动一般需要20-30分钟,准备实施HUD低能见度运行的航空公司应提前向机场运行控制室或空管提出申请。

5.1.5.2 如机组确定自身具备 RVR200m 起飞运行能力,应在申请放行许可时向空管塔台予以说明。

5.1.3 LPV commencement and termination

5.1.3.1 Depending on weather and ground service conditions, HUD SA CAT II and low visibility takeoff procedures commencement and termination will be issued by Areodrome Operation Control Office, ATC will inform flightcrew via D-ATIS, ATIS, VHF(depending on operational situations).

5.1.3.2 Flightcrew shall report to ATC before implementing HUD SA CAT I.

5.1.4 Ground operation rules.

5.1.4.1 Flightcrew shall strictly follow ATC instructions when conducting LVP.

5.1.4.2 If an approaching aircraft have established on the ILS RWY 18L, depature aircraft shall hold short of RWY18R at TWY B9 until arrival aircraft getting off the RWY. only after approaching aircraft landed on the RWY18L and taxi across RWY 18R, the following approaching aircraft can be instructed to approach and land on RWY18L.

5.1.4.3 Generally, when conducting LPV, not more than 2 aircraft are allowed to taxi simultaneously on TWY B.

5.1.4.4 All arrival and departure aircraft will be guided by follow-me vehicle depending on flightcrew demands when conducting LPV.

5.1.5 Special requirements

5.1.5.1 It usually takes about 20-30min from preparation to implement LPV, flightcrew shall file an application in advance to Areodrome Operation Control Office.

5.1.5.2 If flightcrew confirms aircraft capable of low visibility take-off(RVR 200m), flightcrew shall report to ATC when requesting delivery clearance.

6. 除冰规则

冬季除冰,经机场运行控制室许可,可在停机坪 上或指定除冰位置为航空器除冰。除冰结束后, 向长沙机坪申请回到原机位或就地进入滑行起 飞程序。

7. 平行跑道同时仪表运行

无

8. 警告

无

9. 直升机飞行限制, 直升机停靠区

- 9.1 直升机的停靠由机场运行控制室指定位置, 按照长沙机坪的指令执行,并注意不得妨碍其它 航空器的运行;
- 9.2 直升机进出停机位必须由引导车引导。

ZGHA AD 2.21 噪音限制规定及减噪程序

1. 起飞减噪程序

在保证安全超障和飞行程序最低爬升梯度的条件下,执行如下起飞减噪程序。由于非管制原因不执行减噪程序,飞行员必须在起飞前告知管制员并说明原因(校验飞行等特殊飞行除外)。

1.1 在飞机起飞性能运行允许的情况下,尽可能使用减推力起飞;

6. Rules for deicing

De-icing for aircraft shall be carried out at apron or designated location with clearance of Aerodrome Operation Control Office,

A/C shall contact Changsha Apron to apply the procedure for taxiing back to the stands or directly taxiing and takingoff when de-icing finished.

7. Simultaneous operations on parallel runways

Nil

8. Warning

Nil

9. Helicopter operation restrictions and helicopter parking/docking area

- 9.1 Helicopter shall park at the designated stand by Aerodrome Operation Control Office and conduct with Changsha Apron instructions. Helicopter shall avoid affecting other A/C operation.
- 9.2 Helicopter taxiing enter into or exit stands shall be guided by follow-me vehicle.

ZGHA AD 2.21 Noise restrictions and Noise abatement procedures

1. Noise abatement procedures for departure

In condition of complying with the requirements of obstacle clearance and climb gradient required by flight procedure, the following noise abatement climb procedures shall be implemented. If the procedures can not be implemented due to any reason except ATC, pilot shall inform the controller with a reasonable explanation(except for flight check and other special flight).

1.1 The derated take-off is strongly recommended if the take-off performance of aircraft permit;

- 1.2 在高度 450 米时,起始爬升速度 V2+20km/h (10海里/小时),减小功率和俯仰角,保持可靠上升率和襟翼继续爬升;
- 1.3 高度900米以上时,转为正常航路爬升速度并按规定收襟翼/缝翼。
- 1.2 At altitude 450m, with a climb speed of V2 plus 20km/h(10kt), reduce engine power/thrust and angle of pitch, maintain a speed with flaps and slats in the take-off configuration;
- 1.3 At altitude 900m or above, maintain a positive rate of climb, accelerate to normal en-route climb speed and retract flaps/slats on schedule.

ZGHA AD 2.22 飞行程序

1. 总则

除经长沙进近或塔台特殊许可外,在长沙进近管制区和机场管制地带内的飞行,必须按照仪表飞行规则进行。

2. 起落航线

起落航线在跑道东侧, A、B 类航空器高度 400 米。C、D类航空器高度 600米。

3. 仪表飞行程序

- 3.1 严格按照航图中公布的进、离场程序飞行。如果需要,航空器可在空中交通管制部门指定的航路、导航台或定位点上空等待或做机动飞行;
- 3.2 本场 24小时实行 RNAV 1 进离场程序, 不能执行 RNAV 1 程序的航空器驾驶员应在首次联系黄花塔台或长沙进近时报告;
- 3.3 等待程序见标准仪表进场图。

4. 雷达程序和 / 或 ADS-B 程序

- 4.1 长沙进近管制区域内实施雷达管制。航空器最小水平间隔为6千米,最小垂直间隔为300米;
- 4.2 通常, 航空器从管制移交点得到进近雷达引导和排序, 直至相应的最后进近航迹或目视跑道.

ZGHA AD 2.22 Flight procedures

1. General

Flights within Changsha APP Control Area and Aerodrome Control Zone shall operate under IFR unless special clearance has been obtained from APP and TWR Control.

2. Traffic circuits

Traffic circuits shall be made to the east of RWY, at the altitude of 400m for aircraft CAT A/B, and 600m for aircraft CAT C/D.

3. IFR flight procedures

- 3.1 Strict adherence is required to the relevant arrival/departure procedures published in the aeronautical charts. Aircraft may, if necessary, hold or maneuver on an airway, over a navigation facility or a fix designated by ATC;
- 3.2 RNAV 1 procedures are implemented in the Changsha/ Huanghua airport for the whole day. If A/C can not fulfill the requirements of the RNAV 1 procedures operation, pilot shall inform the TWR or APP ATC at the first contact;
- 3.2 Holding procedures refer to STAR.

4. Radar procedures and/or ADS-B procedures

- 4.1 Radar control within Changsha APP has been implemented. The minimum horizontal radar separation is 6km, the minimum vertical radar separation is 300m;
- 4.2 Normally, aircraft will be vectored and sequenced from transfer of control point to the appropriate final approach segment or to the time when RWY is in sight;

- 4.3 若离场航空器在起飞前收到塔台管制员给出 的起飞限制条件,则起飞后由雷达管制员引导加 入标准离场航线;
- 4.4 雷达管制规定
- 4.4.1 有 SSR 应答机的航空器
- 4.4.1.1 按照管制员要求开放A模式;
- 4.4.1.2 开放应答机时应同时开放编码和高度,除 非管制员另有要求;
- 4.4.1.3 进入长沙管制区的航班应保留管制单位制定的最后一个应答机编码,如整个飞行过程中没有管制单位指定SSR编码的应开 "2000";
- 4.4.1.4 如机组已知应答机故障(包括无显示或显示错误),在进入长沙管制区时应主动向管制员报告;
- 4.4.2 无 SSR 应答机的航空器进入长沙管制区时, 应主动向管制员报告机上未装应答机。
- 4.5 最低监视引导高度扇区
- 4.5.1 扇区位置点坐标

- 4.3 If aircraft receive the departure clearance including departure limitation from controller, the aircraft will be vectored to join in the standard departure routes by radar controller;
- 4.4 Radar control rules
- 4.4.1 For A/C with SSR transponder
- 4.4.1.1 Set to model A as required;
- 4.4.1.2 Code and altitude should both set to open, except required by ATC;
- 4.4.1.3 A/C entering into Changsha APP shall retain the last code. Set the SSR transponder code '2000' if A/C not be designated any code during flight.
- 4.4.1.4 For A/C with transponder malfunction (including non-display or display error), pilot shall report to ATC controller before entering Changsha APP;
- 4.4.2 A/C without SSR transponder shall report to ATC before entering into Changsha APP.
- 4.5 Surveillance Minimum Altitude Sectors
- 4.5.1 Coordinates of sector location point

Location Point	Coordinate	Location Point	Coordinate	Location Point	Coordinate
A1	N282500E1130600	C1	N273906E1131850	E2	N280500E1125400
A2	N282847E1131631	C2	N275543E1132317	F1	N280400E1121234
A3	N281612E1132218	C3	N280218E1132018	F2	N282945E1124155
A4	N281218E1132100	C4	N280800E1132018	F3	N282402E1125958
A5	N280818E1130600	C5	N273743E1133143	G1	N284900E1130406
B1	N281918E1133346	D1	N280400E1131700	G2	N284332E1135132
B2	N281844E1135909	D2	N281016E1131924	G3	N282850E1133502
В3	N273754E1135054	E1	N274400E1123124	H1	N284203E1140355

4.5.2 扇区范围及最低引导高度

4.5.2 Range of sectors and minimum altitude limits

Sector 1	ALT limit: 650m or above
A1-A2-A3-A4-A5-A1	
Sector 2	ALT limit: 1350m or above
B1-B2-B3-B1	
Sector 3	ALT limit: 1150m or above
A3-B1-B3-C5-C1-C2-C3-C4-A3	
Sector 4	ALT limit: 800m or above
A3-C4-C3-D1-D2-A4-A3	
Sector 5	ALT limit: 700m or above
E1-E2-A5-A4-D2-D1-C3-C2-C1-E1	•

Sector 6	ALT limit: 850m or above
E1-F1-F2-F3-A1-A5-E2-E1	
Sector 7	ALT limit: 1100m or above
F2-G1-G2-G3-B1-A3-A2-A1-F3-F2	
Sector 8	ALT limit: 1950m or above
B1-G3-G2-H1-B2-B1	

5. 无线电通信失效程序

无

5. Radio communication failure procedures

Nil

6. 目视飞行程序

- 6.1 机场塔台 (进近)管制区正式实施目视间隔和目视进近运行,此运行方式须得到ATC许可;
- 6.2 实施目视进近时,机组应控制表速,预计飞行航迹距接地点10海里时速度不大于180节,距接地点5海里时速度不大于160节。如果不能执行,应及时通知管制员;
- 6.3 实施目视进近的航空器在四边上得到许可前,无法与进近保持联系时,应及时转弯切入指定跑道的五边实施盲降进近,并联系塔台。

6. Procedures for VFR flights

- 6.1 With the prior permission of ATC, visual separation and visual approach can be implemented within TWR control area and APP control area;
- 6.2 In visual approach, flight crew shall control IAS, IAS is no more than 180kt, when predict flight track-mile are 10NM from touch down, and IAS is no more than 160kt, when predict flight track-mile are 5NM. If flight crew can not conduct, inform ATC;
- 6.3 In visual approach, when aircraft on the base before permission and can not contact APP, they should turn in time and intercept designated RWY final, then ILS approach and contact TWR.

7. 目视飞行航线

无

7. VFR route

Nil

8. 目视参考点

无

8. Visual reference point

Nil

9. 其它规定

9.1 对机组的要求

9. Other regulations

9.1 Requirements for flight crew

听清并重复地面管制员的滑行指令,尤其是界限 Repeat the whole taxiing instructions issued by GND 性指令,发现疑问及时证实。

Control, especially the boundary instructions, and make it clear when there is a doubt.

10. 区域导航飞行程序相关数据

10. Data for RNAV flight procedures

Waypoint Coordinates

Waypoint ID	COORDINATES(WGS-84)	Waypoint ID	COORDINATES(WGS-84)
CS01	N281517 E1135813	HA368	N281431 E1131313
CS02	N280455 E1135601	HA372	N275924 E1131356
CS03	N273822 E1133737	HA374	N275924 E1131409
CS04	N275959 E1121622	HA375	N275946 E1132139
CS06	N284557 E1133051	HA376	N275624 E1131915
CS07	N284438 E1134205	HA378	N275146 E1132710
		HA379	N280639 E1132114
HA301	N280512 E1131334	HA381	N281013 E1132403
HA302	N275905 E1131357	HA382	N281325 E1132635
HA304	N275918 E1130105	HA383	N281603 E1132840
HA306	N280640 E1132012	HA384	N283544 E1133006
HA307	N280344 E1132942	HA385	N280600 E1130751
HA309	N281104 E1133928		
HA310	N290642 E1134350	DTM	N2759.0 E11307.5
HA311	N280646 E1141203	LIG	N2738.9 E11331.0
HA312	N282427 E1134031	LLC	N2804.1 E11212.5
HA321	N281657 E1131250	LYH	N2823.6 E11320.6
HA324	N281703 E1132054		
HA325	N281034 E1131339	BEMTA	N2808.9 E11216.4
HA326	N280947 E1133006	DAPRO	N2915.5 E11338.4
		DODSA	N2806.6 E11221.7
HA350	N290656 E1133224	EKIBA	N2805.7 E11300.9
HA356	N281539 E1140436	KAPSA	N2759.1 E11320.4
HA357	N281446 E1134919	MOMRA	N2802.9 E11338.8
HA358	N275156 E1133154	NIVEM	N2719.9 E11336.7
HA359	N280022 E1133232	NODEB	N2823.9 E11329.2
HA362	N282308 E1131227	OKIXA	N2800.6 E11221.5
HA364	N282309 E1131241	OVTAN	N2812.7 E11420.9
HA365	N281752 E1132038	PUKAD	N2759.1 E11209.1
HA367	N281322 E1132544	TASAD	N2833.7 E11341.2

Path	Waypoint	Fly	Magnetic Course	Turn	Altitude	IAS	VPA/	Navigation
Terminator	ID	over	(°)	Direction	(m)	(km/h)	ТСН	Specification
RWY18L SID	LLC-6W							
CF	HA301		183					RNP1
TF	HA302					MAX380		RNP1
TF	KAPSA							RNP1
TF	HA306					MAX380		RNP1
TF	HA301							RNP1
TF	HA304				↓ 5100 ↑ 3000 or by ATC			RNP1
TF	OKIXA							RNP1
TF	LLC							RNP1
RWY18L SID	PUK-6W			1				
CF	HA301		183					RNP1
TF	HA302					MAX380		RNP1
TF	KAPSA							RNP1
TF	HA306					MAX380		RNP1
TF	HA301							RNP1
TF	HA304				↓ 5100 ↑ 3000 or by ATC			RNP1
TF	OKIXA							RNP1
TF	CS04							RNP1
TF	PUKAD							RNP1
RWY18L SID	LLC-7W					_		<u> </u>
CF	HA301		183					RNP1
TF	HA302					MAX380		RNP1
TF	DTM							RNP1
TF	HA304				↓ 5100 ↑ 3000 or by ATC			RNP1
TF	OKIXA							RNP1
TF	LLC							RNP1
RWY18L SID	PUK-7W	1	1	1	<u> </u>	1	l	1
CF	HA301		183					RNP1
TF	HA302					MAX380		RNP1
TF	DTM							RNP1
TF	HA304				↓ 5100 ↑ 3000 or by ATC			RNP1
TF	OKIXA							RNP1

TF	CS04				RNP1
TF	PUKAD				RNP1
RWY18L	SID NIV-7W		I		I
CF	HA301	183		MAX380	RNP1
TF	KAPSA				RNP1
TF	LIG				RNP1
TF	NIVEM				RNP1
RWY18L	SID OVT-7W	1	'	<u> </u>	'
CF	HA301	183			RNP1
TF	HA307		↓ 1800 ↑ 1200		RNP1
TF	MOMRA				RNP1
TF	CS02				RNP1
TF	HA311				RNP1
TF	OVTAN				RNP1
RWY18L	SID DPR-7W	1		-	
CF	HA301	183			RNP1
TF	HA307		↓ 1800 ↑ 1200		RNP1
TF	MOMRA				RNP1
TF	HA309		1 3000		RNP1
TF	HA312				RNP1
TF	TASAD				RNP1
TF	CS07				RNP1
TF	HA310				RNP1
TF	DAPRO				RNP1
RWY18R	SID LLC-8W		<u>.</u>	•	
CF	HA301	181			RNP1
TF	HA302			MAX380	RNP1
TF	KAPSA				RNP1
TF	HA306			MAX380	RNP1
TF	HA301				RNP1
TF	HA304		↓ 5100 ↑ 3000 or by ATC		RNP1
TF	OKIXA				RNP1
TF	LLC				RNP1
RWY18R	R SID PUK-8W		·		1
CF	HA301	181			RNP1
TF	HA302			MAX380	RNP1
TF	KAPSA				RNP1
TF	HA306			MAX380	RNP1
TF	HA301				RNP1

			↓ 5100		
TF	HA304		↑ 3000		RNP1
			or by ATC		
TF	OKIXA				RNP1
TF	CS04				RNP1
TF	PUKAD				RNP1
RWY18R	SID LLC-9W	1	-	1	-
CF	HA301	181			RNP1
TF	HA302			MAX380	RNP1
TF	DTM				RNP1
TF	HA304		↓ 5100 ↑ 3000 or by ATC		RNP1
TF	OKIXA				RNP1
TF	LLC				RNP1
RWY18R	SID PUK-9W	1	1	1	
CF	HA301	181			RNP1
TF	HA302			MAX380	RNP1
TF	DTM				RNP1
TF	HA304		↓ 5100 ↑ 3000 or by ATC		RNP1
TF	OKIXA				RNP1
TF	CS04				RNP1
TF	PUKAD				RNP1
RWY18R	SID NIV-9W	1	-	1	-
CF	HA301	181		MAX380	RNP1
TF	KAPSA				RNP1
TF	LIG				RNP1
TF	NIVEM				RNP1
RWY18R	SID OVT-9W				•
CF	HA301	181			RNP1
TF	HA307		↓ 1800 ↑ 1200		RNP1
TF	MOMRA				RNP1
TF	CS02				RNP1
TF	HA311				RNP1
TF	OVTAN				RNP1
RWY18R	SID DPR-9W	1	L	1	1
CF	HA301	181			RNP1
TF	HA307		↓ 1800 ↑ 1200		RNP1
TF	MOMRA				RNP1
TF	HA309		↑ 3000		RNP1

TF	HA312			T T	RNP1
TF	TASAD				RNP1
TF	CS07				RNP1
TF	HA310				RNP1
TF	DAPRO				RNP1
	SID LLC-9X				KINF I
		001		<u> </u>	DAID1
CF	HA321	001			RNP1
TF	HA362				RNP1
TF	LYH				RNP1
TF	HA324			MAX380	RNP1
TF	HA325		1 2700		RNP1
TF	HA304		↓ 5100 ↑ 3000 or by ATC		RNP1
TF	OKIXA				RNP1
TF	LLC				RNP1
RWY36L	SID PUK-9X				
CF	HA321	001			RNP1
TF	HA362				RNP1
TF	LYH				RNP1
TF	HA324			MAX380	RNP1
TF	HA325		1 2700		RNP1
TF	HA304		↓ 5100 ↑ 3000 or by ATC		RNP1
TF	OKIXA				RNP1
TF	CS04				RNP1
TF	PUKAD				RNP1
RWY36L	SID NIV-9X				
CF	HA321	001			RNP1
TF	HA324			MAX380	RNP1
TF	HA326		↓ 1800 ↑ 1200		RNP1
TF	MOMRA				RNP1
TF	CS03				RNP1
TF	NIVEM				RNP1
RWY36L	SID OVT-9X	<u> </u>	l	1	l
CF	HA321	001			RNP1
TF	HA324			MAX380	RNP1
TF	HA326		↓ 1800 ↑ 1200		RNP1
TF	MOMRA				RNP1
TF	CS02				RNP1
TF	HA311				RNP1

TF	OVTAN				RNP1
RWY36L	SID DPR-9X		l		
CF	HA321	001		MAX380	RNP1
TF	TASAD		↓ 2700 ↑ 2100		RNP1
TF	CS07				RNP1
TF	HA310				RNP1
TF	DAPRO				RNP1
RWY36R	SID LLC-7X	<u> </u>	<u> </u>		I
CF	HA321	358			RNP1
TF	HA362				RNP1
TF	LYH				RNP1
TF	HA324			MAX380	RNP1
TF	HA325		1 2700		RNP1
TF	HA304		↓ 5100 ↑ 3000 or by ATC		RNP1
TF	OKIXA				RNP1
TF	LLC				RNP1
RWY36R	SID PUK-7X				
CF	HA321	358			RNP1
TF	HA362				RNP1
TF	LYH				RNP1
TF	HA324			MAX380	RNP1
TF	HA325		1 2700		RNP1
TF	HA304		↓ 5100 ↑ 3000 or by ATC		RNP1
TF	OKIXA				RNP1
TF	CS04				RNP1
TF	PUKAD				RNP1
RWY36R	SID NIV-7X				
CF	HA321	358			RNP1
TF	HA324			MAX380	RNP1
TF	HA326		↓ 1800 ↑ 1200		RNP1
TF	MOMRA				RNP1
TF	CS03				RNP1
TF	NIVEM				RNP1
RWY36R	SID OVT-7X			1	
CF	HA321	358			RNP1
TF	HA324			MAX380	RNP1
TF	HA326		↓ 1800 ↑ 1200		RNP1

TF	MOMRA				RNP1
TF	CS02				RNP1
TF	HA311				RNP1
TF	OVTAN				RNP1
RWY36R	SID DPR-7X		<u> </u>		
CF	HA321	358		MAX380	RNP1
TE	TAGAD		↓ 2700		DNID1
TF	TASAD		1 2100		RNP1
TF	CS07				RNP1
TF	HA310				RNP1
TF	DAPRO				RNP1
RWY18L/	R STAR LLC-1W	1	,	1	-
IF	LLC				RNP1
TF	DODSA			MAX460	RNP1
TF	EKIBA		↓ 5100 ↑ 3000		RNP1
			or by ATC		
TF	HA368				RNP1
TF	HA365				RNP1
TF	LYH		↑ 900	MAX380	RNP1
RWY18L/	R STAR BEM-1W	·	·		·
IF	BEMTA				RNP1
TF	DODSA			MAX460	RNP1
TF	EKIBA		↓ 5100 ↑ 3000 or by ATC		RNP1
TF	HA368				RNP1
TF	HA365				RNP1
TF	LYH		1 900	MAX380	RNP1
RWY18L/	R STAR LIG-1W			l l	
IF	LIG			MAX460	RNP1
TF	HA358		↑ 3000		RNP1
TF	HA359				RNP1
TF	HA367		↑ 1800		RNP1
TF	HA365				RNP1
TF	LYH		↑ 900	MAX380	RNP1
RWY18L/	R STAR OVT-1W		,	· '	
IF	OVTAN				RNP1
TF	HA356				RNP1
TF	CS01			MAX460	RNP1
TF	HA357		1 2100		RNP1
TF	HA367		↑ 1800		RNP1
TF	HA365				RNP1
TF	LYH		↑ 900	MAX380	RNP1

RWY18L	R STAR DPR-1W				
IF	DAPRO				RNP1
TF	HA350				RNP1
TF	CS06			MAX460	RNP1
TF	HA384				RNP1
TF	NODEB		↑ 1500		RNP1
TF	LYH		1 900	MAX380	RNP1
RWY36L	'R STAR LLC-1X		<u> </u>		
IF	LLC				RNP1
TF	DODSA			MAX460	RNP1
TF	EKIBA		↓ 5100 ↑ 3000 or by ATC		RNP1
TF	HA385		↓ 2700		RNP1
TF	HA379				RNP1
TF	HA375		↑ 1200	MAX380	RNP1
RWY36L	R STAR LLC-2X(by A	TC)	1	<u> </u>	1
IF	LLC				RNP1
TF	DODSA			MAX460	RNP1
TF	EKIBA		↓ 1800 or by ATC		RNP1
TF	DTM		1 900	MAX380	RNP1
RWY36L	'R STAR BEM-1X				
IF	BEMTA				RNP1
TF	DODSA			MAX460	RNP1
TF	EKIBA		↓ 5100 ↑ 3000 or by ATC		RNP1
TF	HA385		↓ 2700		RNP1
TF	HA379				RNP1
TF	HA375		1200	MAX380	RNP1
RWY36L	R STAR BEM-2X(by	ATC)	•		•
IF	BEMTA				RNP1
TF	DODSA			MAX460	RNP1
TF	EKIBA		↓ 1800 or by ATC		RNP1
TF	DTM		↑ 900	MAX380	RNP1
RWY36L	R STAR LIG-1X		<u> </u>	<u>. </u>	l
IF	LIG			MAX460	RNP1
TF	HA378		1500		RNP1
TF	HA375		1200	MAX380	RNP1
RWY36L	R STAR LIG-2X(by A	ГС)	•	<u>. </u>	1
IF	LIG			MAX460	RNP1
TF	HA378		1500		RNP1

TF	HA376				1200	MAX380	RNP1
RWY36L	/R STAR OVT-1X	<u> </u>	1	I	1	<u> </u>	L
IF	OVTAN						RNP1
TF	HA356						RNP1
TF	CS01					MAX460	RNP1
TF	HA357				1 2100		RNP1
TF	HA382				1 2100		RNP1
TF	HA381						RNP1
TF	HA379						RNP1
TF	HA375				1200	MAX380	RNP1
RWY36L	R STAR DPR-1X	:	<u> </u>	I			
IF	DAPRO						RNP1
TF	HA350						RNP1
TF	CS06					MAX460	RNP1
TF	HA384						RNP1
TF	NODEB						RNP1
TF	HA383						RNP1
TF	HA382				1 2100		RNP1
TF	HA381						RNP1
TF	HA379						RNP1
TF	HA375				1200	MAX380	RNP1
RWY18L	R Holding (outbo	und time	: 1min)		1	<u> </u>	1
HM	LLC	Y	034	L	3000	MAX380	RNP1
HM	HA358	Y	007	R	3000	MAX380	RNP1
HM	HA357	Y	270	L	2100	MAX380	RNP1
HM	HA357	Y	270	R	2100	MAX380	RNP1
HM	HA384	Y	187	L	2400	MAX380	RNP1
HM	HA365	Y	002	R	1200	MAX380	RNP1
RWY36L	R Holding (outbo	und time	: 1min)		1	<u> </u>	1
HM	LLC	Y	034	L	3000	MAX380	RNP1
НМ	HA381	Y	218	L	2100 or by	MAX380	RNP1
111V1					ATC		
НМ	HA357	Y	270	L	2100	MAX380	RNP1
HM	HA357	Y	270	R	2100	MAX380	RNP1
НМ	HA384	Y	187	L	2400	MAX380	RNP1
НМ	HA375	Y	332	R	1200	MAX380	RNP1
HM	HA378	Y	348	R	1500	MAX380	RNP1
RWY18L	Transition (From	LYH)	-	•		<u>.</u>	<u>.</u>
IF	LYH				1 900	MAX380	RNP1
TF	HA364				650	MAX315	RNP1
RWY18R	Transition (From	LYH)	-	•		<u>.</u>	<u>.</u>
IF	LYH				1 900	MAX380	RNP1
TF	HA362				650	MAX315	RNP1

RWY36L	Transition (From	HA375)			
IF	HA375		↑ 1200	MAX380	RNP1
TF	HA372		700	MAX315	RNP1
RWY36L	Transition (From	HA376)			-
IF	HA376		↑ 1200	MAX380	RNP1
TF	HA372		700	MAX315	RNP1
RWY36L	Transition (From	DTM)			
IF	DTM		↑ 900	MAX380	RNP1
TF	HA372		700	MAX315	RNP1
RWY36R	Transition (From	HA375)			-
IF	HA375		↑ 1200	MAX380	RNP1
TF	HA374		700	MAX315	RNP1
RWY36R	Transition (From	HA376)			-
IF	HA376		↑ 1200	MAX380	RNP1
TF	HA374		700	MAX315	RNP1
RWY36R	Transition (From	DTM)	- '		
IF	DTM		↑ 900	MAX380	RNP1
TF	HA374		700	MAX315	RNP1

ZGHA AD 2.23 其它资料

ZGHA AD 2.23 Other information

机场附近有鸟类活动,主要在昼间活动,各类鸟的数量较多,主要在200m以下的高空活动,有明显的季节变化,有候鸟活动。本场有多种驱鸟设施。

Birds activity are found around aerodrome in all seasons all the year round, and their activities mainly take place in daytime. There are a fairly great number of birds of various species, and their activities mainly take place below 200m, the number changes obviously with the change of season. Activities of migratory birds are also found. The aerodrome is equipped with many kinds of bird dispersal facilities.

Bird name	Activity season	Activity time	Flight height
Alauda gulgula	All seasons	22:30-10:30	0-100m
Pycnonotus sinensis	All seasons	22:30-10:30	0-100m
Snipe	Spring and summer	The whole day	0-100m
Grey-headed Lapwing	Spring, summer, autumn	The whole day	0-100m
Turtledove	All seasons	22:30-10:30	0-100m
Lanius schach	All seasons	22:30-10:30	0-100m
Crested myna	All seasons	22:30-10:30	0-100m