

Two-stroke

Copenhagen, November 2025

### Action code: WHEN CONVENIENT

#### Sampling of scavenge drain oil

Adjust feed rate factor in service, and monitor piston ring and cylinder liner wear

#### Concerns

Owners and operators of Everlence B&W two-stroke marine diesel engines.

Type: MC/MC-C and ME/ME-C, all fuel types

#### Summary

New guidelines for iron (Fe) content and base number (BN) of the scavenge drain oil.

Guiding intervals for sampling and advising on interpretation of the results.

#### Contact details

[operationcylindercondition2s@everlence.com](mailto:operationcylindercondition2s@everlence.com)

#### References

[SL2019-685](#), [SL2023-737/NHN](#), [Service Letters](#)



Sampling of scavenge drain oil

### Sampling of scavenge drain oil

Drain oil is used cylinder oil scraped down from the liner, which is drained from the bottom of the scavenge air space. **Scavenge drain oil analysis (SDA)** is a commonly used method for monitoring wear and cylinder oil utilisation on individual cylinder units.

In general, drain oil samples can be analysed by laboratories ashore or onboard by the crew. Drain oil is sampled in small quantities and therefore **the analysis result is sensitive to contamination**. It is essential to keep the sampling environment and equipment clean to get valid results:

- Clean the scavenge box bottom frequently
- Deposits may be a source of contamination
- Keep the drain line open during operation
- To collect a drain oil sample:
  1. Close the drain cutoff ball valve (normally open).
  2. Open the sample valve. Make sure to flush out all impurities into a sludge container/bottle.
  3. Close the sample valve. Wait for 30 – 300 minutes to accumulate a full sample.
  4. Open the sample valve very shortly into a sludge container/bottle to ensure a representative sample.
  5. Finally, draw the sample in a clean sample bottle.
  6. Close the sample valve and open the drain valve to the normal position.

Note: To avoid contamination of the sample, **use only clean sampling bottles** and devices:

- Sample directly into the sample/forwarding container, when sampling for analysis by an accredited laboratory.
- Use disposable containers for onboard sampling where possible.
- Alternatively, **sample only in pre-cleaned and dried containers**.
- Ensure that the onboard test equipment is always cleaned before use.

To determine a potential dilution of the drain oil with system oil, **take samples of the system oil in use, a new system oil, and a new cylinder oil** together with the collected scavenge drain oil samples for laboratory analysis.

### Laboratory analyses

A laboratory analysis is accurate and can determine residual base number (BN), magnetic index (PQ index), water content, wear particles, contaminants, and additives.

Typically, an iron (Fe) content is specified as the “**total iron content**”, which is the sum of corrosive (non-magnetic) and abrasive/adhesive (magnetic) iron particles. **The wear type and the extent can be assessed from the iron content, residual BN, and magnetic index of the drain oil**. Table 1 shows a simplified assessment guidance.

Table 1: Typical correlation between cause of wear and iron content in the drain oil

Wear type	Possible cause	Iron type		
		Total	Non-magnetic	Magnetic
Abrasive	Cat fines in fuel Sand and dust in air	x		x
Adhesive	Water carryover Lack of cylinder oil	x		x
Corrosive	Sulphuric acid Too low cylinder oil dosage	x	x	

The presence of other metals or elements in the drain oil can indicate wear of the piston skirt, running-in wear, contamination, or dilution with system oil. See [Appendix I](#).

System oil dilution lowers the iron content and lowers the BN of the drain oil. If the drain oil is excessively diluted, the analysis results may be misleading. High dilution levels can indicate excessive leakage from the stuffing box, the piston, or the telescopic pipe, but it can also be the result of low cylinder scrape down volumes combined with minor, yet unavoidable, system oil leakages. This does not indicate a defect, which needs attention.

Lube oil laboratories should be able to determine the dilution level of the samples, provided analysis results of used system oil (drawn together with SDA samples) and new cylinder oil are available.

### Sampling frequency

As a minimum, laboratory analyses should be carried out at intervals of 1,500 running hours, or every third month, depending on which criterium is met first.

Onboard drain oil analyses are considered an effective monitoring and optimisation measure, but they cannot substitute drain oil analyses made by an accredited laboratory. Everlence only accepts analysis results from accredited laboratories as documentation of the condition.

### Onboard analyses

Drain oil analyses done onboard are considered supplementary to analyses carried out at laboratories ashore. However, onboard analyses done at short intervals enable early detection, correction, or mitigation of abnormal conditions, which can occur, for example, when operating on contaminated fuels. Onboard monitoring of the drain oil may also support decisions in an optimisation of the cylinder oil feed rate.

Three analysis methods are available: X-ray fluorescence (XRF), chemical reaction, and magnetic detection. When evaluating the drain oil analysis, both the fuel type and the used analysis method must be considered.

### Drain oil iron content

The iron content in the drain oil depends on fuel sulphur content, cylinder oil grade and feed rate, engine type, and engine condition. For evaluation of the measured iron content, the analysis method must be considered. The iron content can be measured as magnetic particles, as iron oxide (non-magnetic), or as the total iron content. Wear to cylinder unit components is unavoidable, but a high wear rate may be critical. To distinguish between different degrees of wear, four categories are considered:

1. "Normal" wear indicates a good cylinder condition and adequate lubrication with low wear.
2. "Raised" wear indicates acceptable and uncritical wear within the limits of the component service life.
3. "Abnormal" wear is acceptable for shorter periods, however, it indicates increased wear. It is recommended to make (onboard) drain oil analyses more frequently.  
Observe that the wear level neither remains abnormal nor escalates. If successive or repeated abnormal values are recorded, the cause must be identified and addressed. Typically, increased wear is caused by water in the scavenge air, contaminants in the fuel, or insufficient neutralisation of sulphur (high-sulphur fuel). However, do not rule out other causes. Abnormal wear is expected during running-in of new liners and new piston rings. Findings of "abnormal wear" should be followed up by increasing the feed rate by 0.1 g/kWh and repeating the analysis process.
4. "Alert" indicates an ongoing high-wear situation, which must be identified immediately and corrected. Continuous operation in the critical range can lead to engine damage and/or reduced service life of components. Findings of "alert wear" should be followed up by increasing the feed rate to 1.2 g/kWh or more, and repeating the analysis process.

Tables 2 and 3 show guiding drain oil values for the total iron content and the magnetic iron content, respectively, for the four wear categories. These values correspond to a reference feed rate of 1.0 g/kWh. An iron content obtained at a given feed rate must be corrected to reflect the content at 1.0 g/kWh, considering the same iron quantity (absolute wear). See Eq. 1 and the example.

$$Fe_{Corr1.0} = Fe_{Act} \cdot FR_{Act}$$
 Eq. (1)

Example: An iron content ( $Fe_{Act}$ ) of 35 ppm at feed rate ( $FR_{Act}$ ) 0.80 g/kWh corresponds to 28 ppm at feed rate 1.0 g/kWh.

Table 2: Guiding values for the total iron content in drain oil, depending on the fuel type, for the four wear categories

Guiding total iron (Fe) content in drain oil [mg/kg]				
Fuel type	Normal	Raised	Abnormal	Alert
ULSFO, ≤0.1% S	≤25	25–40	>40	>300
VLSFO, 0.10–0.50% S	≤40	40–80	>80	>300
HSFO, 0.50–3.5% S	≤100	100–200	>200	>800

Table 3: Guiding values for the magnetic iron content in drain oil, depending on the fuel type, for the four wear categories

Guiding magnetic iron (Fe) content in drain oil [mg/kg]				
Fuel type	Normal	Raised	Abnormal	Alert
ULSFO, ≤0.1% S	≤25	25–40	>40	>300
VLSFO, 0.10–0.50% S	≤30	30–70	>70	>300
HSFO, 0.50–3.5% S	≤40	40–100	>100	>600

### Drain oil residual base number

The cylinder oil BN reduction mainly depends on the sulphur content of the fuel. The lower the sulphur content, the lower the utilisation of cylinder oil BN for neutralisation. Table 4 shows guiding values for drain oil residual BN.

Table 4: Guiding values for drain oil residual BN

Guiding expected residual BN values			
Fuel type	Normal	Low	Alert
BN 40			
≤0.1% S	40-24	23-16	15-0
0.10–0.50% S*	40-20	19-16	15-0
BN 70			
≤0.1% S	70-42	41-28	27-0
0.10–0.50% S*	70-35	34-28	27-0
0.50–3.5% S*	70-21	20-14	13-0
BN 100			
≤0.1% S	100-60	59-40	39-0
0.10–0.50% S*	100-50	49-40	39-0
0.50–3.5% S*	100-30	29-20	19-0
BN 140			
≤0.1% S	140-84	83-56	55-0
0.10–0.50% S*	140-70	69-56	55-0
0.50–3.5% S*	140-42	41-28	27-0

\*depending on fuel sulphur content, ambient humidity and temperature

The use of a fuel without sulphur, or a low-sulphur fuel results in a small BN reduction. It means that the drain oil can have a correspondingly high residual BN, which is not critical in terms of cylinder condition.

The piston cleaning ring (PC-ring) scrapes possible surplus calcium-derived deposits off the piston top land. Observe that a certain deposit level is always maintained on the piston top land. Within a very wide range, Calcium-derived deposits accumulating on the piston crown top are not critical.

Note: An unexpected low residual BN can be caused by water in the scavenge air or by excessive dilution with system oil.

For operation on low-sulphur fuels, Everllence recommends using a cylinder oil with a BN as low as possible without compromising detergency requirements. Reference is made to SL2023-737/NHN.

For cermet-coated piston rings in service on high-sulphur fuels, both SDA results and piston ring coating wear rates must be considered when evaluating the cylinder oil feed rate.

Inadequate sulphur neutralisation increases the coating wear and should be addressed if the wear rate is too high. Reference is made to SL2019-685.

### Sampling schedule

Onboard analyses can be done as a supplement to the regular laboratory analyses. More frequently, onboard analyses are used as an extra control between the regular analyses every third month, or after 1,500 running hours. When operating on a high-sulphur fuel, evaluation of drain oil BN is important to make sure that the level of corrosion is under control. Table 5 shows guiding intervals (running hours) for sweep test, drain oil laboratory analyses, and onboard drain oil analyses, respectively.

Table 5: Guideline intervals [running hours] for drain oil sampling

Guiding intervals for sweep test, drain oil laboratory analyses, and onboard drain oil analyses [running hours]			
Analysis	≤0.1% S LNG, LPG, MeOH	0.5% S Residual fuel	>0.5% S HSFO, residual fuel
Sweep test*** (high-sulphur fuel)	not applicable	not applicable	Initial sweep test after approx. 500 running hours*
Drain oil analyses - laboratory ashore	1,500	1,500	1,500
Drain oil analyses onboard	BN	200**	100–120**
	Fe	not applicable	not applicable 100–120**

\* To be done when the running-in is completed

\*\* If the iron content is abnormal or critical, reduce the interval

\*\*\* See Appendix II

If you have further questions to this Service Letter, contact

[operationcylindercondition2s@everllence.com](mailto:operationcylindercondition2s@everllence.com)

Yours sincerely,



Susanne Kindt  
Senior Vice President Engineering



Kim Blichfeldt Kirkeby  
Senior Manager Engine Support

### Appendix I – List of substances and possible origins

Substance	Chemical symbol	Typical origin
Iron	Fe	Wear to liner, uncoated piston rings, and base material of coated piston rings
Chromium	Cr	Wear to piston ring grooves and piston rings
Molybdenum	Mo	Wear to piston skirt (if molybdenum coated) and/or cermet coating on piston rings
Copper	Cu	Running-in of alu-coated piston rings Wear to stuffing box bronze parts Wear to piston skirt
Lead	Pb	Dilution with system oil/bearing wear
Tin	Sn	Dilution with system oil/bearing wear
Aluminium	Al	Cat fines in residual fuels Dilution with system oil/bearing wear <sup>1</sup>
Vanadium	V	Fuel oil remains (residual fuels only)
Silicon	Si	Cat fines in residual fuels Lube oil additive <sup>2</sup>
Calcium	Ca	Lube oil additive <sup>2</sup>
Magnesium	Mg	
Zinc	Zn	
Phosphorus	P	
Boron	B	
Silver	Ag	Contamination – not additives or wear components. Should only be observed in insignificant concentrations.
Potassium	K	
Nickel	Ni	
Barium	Ba	
Sodium	Na	Seawater (via scavenge air or fuel oil)

<sup>1</sup> Metals used in bearings. These can be carried over by leaked system oil. Check for system oil dilution. Check system oil

<sup>2</sup> Additives in cylinder oil and/or system oil. Levels will vary depending on brand and grade.

Table 6: List of substances and possible origins

### Appendix II – Sweep test result

A sweep test is only applicable for engines operated on high-sulphur fuel. The sweep test establishes engine corrosiveness and should be done after completion of running-in and before reducing the initial feed rate factor (FRF) below 0.40 g/kWh/%S. A sweep test must also be done:

- If the engine specification is altered
- If operating conditions have changed.

The sweep test consists of a series of four (or five) sets of drain oil samples collected under the following conditions:

- Collect samples at feed rates: 1.4, 1.2, 1.0, 0.8 g/kWh (and if applicable 0.6 g/kWh)
- Operate the engine on fuel with minimum 2.8% S
- Engine conditions should be uniform during the sweep test:
  - o Stable engine load, not less than 50% of MCR, at a typical navigational speed
  - o Stable air temperature and humidity
- Maintain the feed rate for 24 hours before sampling.

The FRF [g/kWh/%S] must be calculated for each sample set.

The iron content and the residual BN results from the analyses of the samples have to be correlated by plotting both as a function of the feed rate factor in a diagram. See also Fig. 1. Next, graphs can be drawn, which show the iron content and residual BN relative to the calculated FRF. The FRF and the residual BN corresponding to the selected iron content can be established from the graphs.

The conclusion of the sweep test is an approximation, which should be verified by scheduled drain oil analyses. If the service experience deviates from the result of the sweep test, the concluded FRF should be adjusted. Significant deviations in operating conditions (load, climate) affect the sweep test results. If the operating conditions change compared to the typical conditions, or if the engine has been modified, it may be required to repeat the sweep test. If the sweep test results in a necessary FRF of more than 0.32, a cylinder oil with a higher BN should be considered.




Fig. 1: The curves: fe1-fe12, Avg. Fe, and BN1-BN12, and Avg. BN show the iron content and the residual BN as a function of the feed rate factor for the sweep test, respectively. Based on a selected iron content: 100 mg/kg, the FRF must be 0.32 g/kWh/%S, and BN41 is the residual level for 100 ppm iron