GUIslice 0.8.5

Generated by Doxygen 1.8.8

Mon Mar 13 2017 23:10:39

Contents

1	KEA	DME												1
2	Clas	s Index	C											3
	2.1	Class	List				 	 	 	 		 		 3
3	File	Index												5
	3.1	File Lis	st				 	 	 	 		 		 5
4	Clas	s Docu	mentation	n										7
	4.1	gslc_ts	sCollect St	truct Refere	ence		 	 	 	 	 	 		 7
		4.1.1	Detailed	Descriptio	n		 	 	 	 	 	 		 8
		4.1.2	Member	Data Docu	ımentatio	n	 	 	 	 	 	 		 8
			4.1.2.1	asElem			 	 	 	 	 	 		 8
			4.1.2.2	asElemF	Ref		 	 	 	 	 	 		 8
			4.1.2.3	nElemAu	itoldNext		 	 	 	 	 	 		 8
			4.1.2.4	nElemCr	nt		 	 	 	 	 	 		 8
			4.1.2.5	nElemMa	ax		 	 	 	 	 	 		 8
			4.1.2.6	nElemRe	efCnt		 	 	 	 	 	 		 8
			4.1.2.7	nElemRe	efMax .		 	 	 	 	 	 		 8
			4.1.2.8	pElemTra	acked .		 	 	 	 	 	 		 8
			4.1.2.9	pfuncXE	vent		 	 	 	 	 	 		 9
	4.2	gslc_ts	sColor Stru	uct Referer	ice		 	 	 	 	 	 		 9
		4.2.1	Detailed	Descriptio	n		 	 	 	 	 	 		 9
		4.2.2	Member	Data Docu	ımentatio	n	 	 	 	 	 	 		 9
			4.2.2.1	b			 	 	 	 	 	 		 9
			4.2.2.2	g			 	 	 	 	 	 		 9
			4.2.2.3	r			 	 	 	 	 	 		 9
			4.2.2.4	unused			 	 	 	 	 	 		 9
	4.3	gslc_ts	sDriver Str	uct Refere	nce		 	 	 	 	 	 		 10
		4.3.1	Member	Data Docu	ımentatio	n	 	 	 	 	 	 		 10
			4.3.1.1	nColRaw	Bkgnd		 	 	 	 	 	 		 10
			4312	nSurfScr	een									10

iv CONTENTS

		4.3.1.3	pTsDev	10
		4.3.1.4	rClipRect	10
4.4	gslc_ts	Elem Stru	uct Reference	11
	4.4.1	Detailed	Description	12
	4.4.2	Member	Data Documentation	12
		4.4.2.1	bClickEn	12
		4.4.2.2	bFillEn	13
		4.4.2.3	bFrameEn	13
		4.4.2.4	bGlowEn	13
		4.4.2.5	bGlowing	13
		4.4.2.6	bNeedRedraw	13
		4.4.2.7	bValid	13
		4.4.2.8	colElemFill	13
		4.4.2.9	colElemFillGlow	13
		4.4.2.10	colElemFrame	13
		4.4.2.11	colElemFrameGlow	13
		4.4.2.12	colElemText	13
		4.4.2.13	colElemTextGlow	13
		4.4.2.14	eTxtAlign	14
		4.4.2.15	eTxtFlags	14
		4.4.2.16	nGroup	14
		4.4.2.17	nld	14
		4.4.2.18	nStrBufMax	14
		4.4.2.19	nTxtMargin	14
		4.4.2.20	nType	14
		4.4.2.21	pElemParent	14
		4.4.2.22	pfuncXDraw	14
		4.4.2.23	pfuncXEvent	14
		4.4.2.24	pfuncXTick	14
		4.4.2.25	pfuncXTouch	14
		4.4.2.26	pStrBuf	15
		4.4.2.27	pTxtFont	15
		4.4.2.28	pXData	15
		4.4.2.29	rElem	15
		4.4.2.30	sImgRefGlow	15
		4.4.2.31	sImgRefNorm	15
4.5	gslc_ts	ElemRef	Struct Reference	15
	4.5.1	Detailed	Description	16
	4.5.2	Member	Data Documentation	16
		4.5.2.1	eElemFlags	16

CONTENTS

		4.5.2.2	pElem	16
4.6	gslc_ts	Event Stru	uct Reference	16
	4.6.1	Detailed	Description	16
	4.6.2	Member	Data Documentation	16
		4.6.2.1	eType	16
		4.6.2.2	nSubType	17
		4.6.2.3	pvData	17
		4.6.2.4	pvScope	17
4.7	gslc_ts	EventTouc	ch Struct Reference	17
	4.7.1	Detailed	Description	17
	4.7.2	Member	Data Documentation	17
		4.7.2.1	eTouch	17
		4.7.2.2	nX	17
		4.7.2.3	nY	18
4.8	gslc_ts	Font Struc	ct Reference	18
	4.8.1	Detailed	Description	18
	4.8.2	Member	Data Documentation	18
		4.8.2.1	nld	18
		4.8.2.2	nSize	18
		4.8.2.3	pvFont	18
4.9	gslc_ts	Gui Struct	t Reference	18
	4.9.1	Detailed	Description	20
	4.9.2	Member	Data Documentation	20
		4.9.2.1	asFont	20
		4.9.2.2	asPage	20
		4.9.2.3	bRedrawPartialEn	20
		4.9.2.4	nDispDepth	20
		4.9.2.5	nDispH	20
		4.9.2.6	nDispW	20
		4.9.2.7	nFontCnt	21
		4.9.2.8	nFontMax	21
		4.9.2.9	nFrameRateCnt	21
		4.9.2.10	nFrameRateStart	21
		4.9.2.11	nPageCnt	21
		4.9.2.12	nPageMax	21
		4.9.2.13	nTouchLastPress	21
		4.9.2.14	nTouchLastX	21
		4.9.2.15	nTouchLastY	21
		4.9.2.16	pCurPage	21
		4.9.2.17	pCurPageCollect	21

vi CONTENTS

		4.9.2.18	pfuncXEvent	21
		4.9.2.19	pvDriver	22
		4.9.2.20	sElemTmp	22
		4.9.2.21	sImgRefBkgnd	22
4.10	gslc_ts	ImgRef St	ruct Reference	22
	4.10.1	Detailed I	Description	22
	4.10.2	Member I	Data Documentation	22
		4.10.2.1	elmgFlags	22
		4.10.2.2	pFname	22
		4.10.2.3	plmgBuf	22
		4.10.2.4	pvlmgRaw	23
4.11	gslc_ts	Page Struc	ct Reference	23
	4.11.1	Detailed I	Description	23
	4.11.2	Member I	Data Documentation	24
		4.11.2.1	bPageNeedFlip	24
		4.11.2.2	bPageNeedRedraw	24
		4.11.2.3	nPageId	24
		4.11.2.4	pfuncXEvent	24
		4.11.2.5	sCollect	24
4.12	gslc_ts	Pt Struct F	Reference	24
	4.12.1	Detailed I	Description	24
	4.12.2	Member I	Data Documentation	25
		4.12.2.1	\mathbf{x}	25
		4.12.2.2	$y \ \dots $	25
4.13	gslc_ts	Rect Struc	ct Reference	25
	4.13.1	Detailed I	Description	25
	4.13.2	Member I	Data Documentation	25
		4.13.2.1	h	25
		4.13.2.2	$\mathbf{w} \ldots \ldots$	25
		4.13.2.3	$x \ \dots $	25
		4.13.2.4	$y \ \dots $	26
4.14	gslc_ts	XCheckbo	x Struct Reference	26
	4.14.1	Detailed I	Description	26
	4.14.2	Member I	Data Documentation	27
		4.14.2.1	bChecked	27
			bRadio	27
			colCheck	27
			nStyle	27
		4.14.2.5	pGui	27
4.15	gslc_ts	XGauge S	Struct Reference	27

CONTENTS vii

	4.15.1	Detailed Description	28
	4.15.2	Member Data Documentation	28
		4.15.2.1 bGaugeFlip	28
		4.15.2.2 bGaugeVert	28
		4.15.2.3 colGauge	28
		4.15.2.4 nGaugeMax	28
		4.15.2.5 nGaugeMin	28
		4.15.2.6 nGaugeVal	28
4.16	gslc_ts	XSelNum Struct Reference	28
	4.16.1	Detailed Description	29
	4.16.2	Member Data Documentation	29
		4.16.2.1 acElemTxt	29
		4.16.2.2 asElem	29
		4.16.2.3 asElemRef	30
		4.16.2.4 nCounter	30
		4.16.2.5 sCollect	30
4.17	gslc_ts	XSlider Struct Reference	30
	4.17.1	Detailed Description	31
	4.17.2	Member Data Documentation	31
		4.17.2.1 bTrim	31
		4.17.2.2 bVert	31
		4.17.2.3 colTick	31
		4.17.2.4 colTrim	31
		4.17.2.5 nPos	31
		4.17.2.6 nPosMax	31
		4.17.2.7 nPosMin	31
		4.17.2.8 nThumbSz	31
		4.17.2.9 nTickDiv	32
		4.17.2.10 nTickLen	32
		4.17.2.11 pfuncXPos	32
File	Docume	entation 3	33
5.1			33
5.2			33
	5.2.1		38
		5.2.1.1 GUISLICE_VER	38
	5.2.2		38
		5.2.2.1 gslc_ClipLine	88
		5.2.2.2 gslc_ClipPt	38
		5.2.2.3 gslc_ClipRect	39

5

viii CONTENTS

5.2.2.4	gslc_CollectDestruct	39
5.2.2.5	gslc_CollectElemAdd	39
5.2.2.6	gslc_CollectEvent	40
5.2.2.7	gslc_CollectFindElemByld	40
5.2.2.8	gslc_CollectFindElemFromCoord	40
5.2.2.9	gslc_CollectGetElemTracked	40
5.2.2.10	gslc_CollectGetNextId	41
5.2.2.11	gslc_CollectGetRedraw	41
5.2.2.12	gslc_CollectReset	41
5.2.2.13	gslc_CollectSetElemTracked	41
5.2.2.14	gslc_CollectSetEventFunc	42
5.2.2.15	gslc_CollectSetParent	42
5.2.2.16	gslc_CollectTouch	42
5.2.2.17	gslc_DebugPrintf	43
5.2.2.18	gslc_DrawFillRect	44
5.2.2.19	gslc_DrawFrameCircle	44
5.2.2.20	gslc_DrawFrameRect	44
5.2.2.21	gslc_DrawLine	44
5.2.2.22	gslc_DrawLineH	45
5.2.2.23	gslc_DrawLineV	45
5.2.2.24	gslc_DrawSetPixel	45
5.2.2.25	gslc_ElemAdd	46
5.2.2.26	gslc_ElemCreate	46
5.2.2.27	gslc_ElemCreateBox	47
5.2.2.28	gslc_ElemCreateBtnImg	47
5.2.2.29	gslc_ElemCreateBtnTxt	47
5.2.2.30	gslc_ElemCreateImg	48
5.2.2.31	gslc_ElemCreateLine	48
5.2.2.32	gslc_ElemCreateTxt	49
5.2.2.33	gslc_ElemDestruct	49
5.2.2.34	gslc_ElemDraw	49
5.2.2.35	gslc_ElemDrawByRef	49
5.2.2.36	gslc_ElemEvent	50
5.2.2.37	gslc_ElemGetGlow	50
5.2.2.38	gslc_ElemGetGlowEn	50
5.2.2.39	gslc_ElemGetGroup	50
5.2.2.40	gslc_ElemGetId	51
5.2.2.41	gslc_ElemGetRedraw	51
5.2.2.42	gslc_ElemOwnsCoord	51
5.2.2.43	gslc_ElemSendEventTouch	51

CONTENTS

5.2.2.44	gslc_ElemSetCol	52
5.2.2.45	gslc_ElemSetDrawFunc	52
5.2.2.46	gslc_ElemSetEventFunc	52
5.2.2.47	gslc_ElemSetFillEn	53
5.2.2.48	gslc_ElemSetFrameEn	53
5.2.2.49	gslc_ElemSetGlow	53
5.2.2.50	gslc_ElemSetGlowCol	53
5.2.2.51	gslc_ElemSetGlowEn	54
5.2.2.52	gslc_ElemSetGroup	54
5.2.2.53	gslc_ElemSetImage	54
5.2.2.54	gslc_ElemSetRedraw	54
5.2.2.55	gslc_ElemSetStyleFrom	55
5.2.2.56	gslc_ElemSetTickFunc	55
5.2.2.57	gslc_ElemSetTxtAlign	56
5.2.2.58	gslc_ElemSetTxtCol	56
5.2.2.59	gslc_ElemSetTxtMargin	56
5.2.2.60	gslc_ElemSetTxtMem	57
5.2.2.61	gslc_ElemSetTxtStr	57
5.2.2.62	gslc_ElemUpdateFont	57
5.2.2.63	gslc_EventCreate	57
5.2.2.64	gslc_ExpandRect	58
5.2.2.65	gslc_FontAdd	58
5.2.2.66	gslc_FontGet	58
5.2.2.67	gslc_GetImageFromFile	59
5.2.2.68	gslc_GetImageFromProg	60
5.2.2.69	gslc_GetImageFromRam	60
5.2.2.70	gslc_GetImageFromSD	60
5.2.2.71	gslc_GetPageCur	60
5.2.2.72	gslc_GetTouch	61
5.2.2.73	gslc_GetVer	61
5.2.2.74	gslc_GuiDestruct	61
5.2.2.75	gslc_Init	61
5.2.2.76	gslc_InitDebug	62
5.2.2.77	gslc_InitTouch	62
5.2.2.78	gslc_lsInRect	62
5.2.2.79	gslc_lslnWH	63
5.2.2.80	gslc_OrderCoord	63
5.2.2.81	gslc_PageAdd	63
5.2.2.82	gslc_PageDestruct	64
5.2.2.83	gslc_PageEvent	64

X CONTENTS

		5.2.2.84	gslc_PageFindByld	64
		5.2.2.85	gslc_PageFindElemByld	64
		5.2.2.86	gslc_PageFlipGet	65
		5.2.2.87	gslc_PageFlipGo	65
		5.2.2.88	gslc_PageFlipSet	65
		5.2.2.89	gslc_PageRedrawCalc	65
		5.2.2.90	gslc_PageRedrawGet	66
		5.2.2.91	gslc_PageRedrawGo	66
		5.2.2.92	gslc_PageRedrawSet	66
		5.2.2.93	gslc_PageSetEventFunc	66
		5.2.2.94	gslc_Quit	67
		5.2.2.95	gslc_ResetElem	67
		5.2.2.96	gslc_ResetFont	67
		5.2.2.97	gslc_ResetImage	67
		5.2.2.98	gslc_SetBkgndColor	68
		5.2.2.99	gslc_SetBkgndImage	68
		5.2.2.100	gslc_SetClipRect	68
			gslc_SetPageCur	68
		5.2.2.102	gslc_TrackTouch	69
		5.2.2.103	B gslc_Update	69
	5.2.3	Variable I	Documentation	69
		5.2.3.1	g_pfDebugOut	69
5.3	src/GU	Ilslice.h Fil	e Reference	69
	5.3.1	Macro De	efinition Documentation	79
		5.3.1.1	GSLC_ALIGN_BOT_LEFT	79
		5.3.1.2	GSLC_ALIGN_BOT_MID	79
		5.3.1.3	GSLC_ALIGN_BOT_RIGHT	79
		5.3.1.4	GSLC_ALIGN_MID_LEFT	79
		5.3.1.5	GSLC_ALIGN_MID_MID	79
		5.3.1.6	GSLC_ALIGN_MID_RIGHT	80
		5.3.1.7	GSLC_ALIGN_TOP_LEFT	80
		5.3.1.8	GSLC_ALIGN_TOP_MID	80
		5.3.1.9	GSLC_ALIGN_TOP_RIGHT	80
		5.3.1.10	GSLC_ALIGNH_LEFT	80
		5.3.1.11	GSLC_ALIGNH_MID	80
		5.3.1.12	GSLC_ALIGNH_RIGHT	80
		5.3.1.13	GSLC_ALIGNV_BOT	80
		5.3.1.14	GSLC_ALIGNV_MID	80
		5.3.1.15	GSLC_ALIGNV_TOP	80
		5.3.1.16	GSLC_COL_BLACK	80

CONTENTS xi

5.3.1.17	GSLC_COL_BLUE	80
5.3.1.18	GSLC_COL_BLUE_DK1	81
5.3.1.19	GSLC_COL_BLUE_DK2	81
5.3.1.20	GSLC_COL_BLUE_DK3	81
5.3.1.21	GSLC_COL_BLUE_DK4	81
5.3.1.22	GSLC_COL_BLUE_LT1	81
5.3.1.23	GSLC_COL_BLUE_LT2	81
5.3.1.24	GSLC_COL_BLUE_LT3	81
5.3.1.25	GSLC_COL_BLUE_LT4	81
5.3.1.26	GSLC_COL_BROWN	81
5.3.1.27	GSLC_COL_CYAN	81
5.3.1.28	GSLC_COL_GRAY	81
5.3.1.29	GSLC_COL_GRAY_DK1	81
5.3.1.30	GSLC_COL_GRAY_DK2	82
5.3.1.31	GSLC_COL_GRAY_DK3	82
5.3.1.32	GSLC_COL_GRAY_LT1	82
5.3.1.33	GSLC_COL_GRAY_LT2	82
5.3.1.34	GSLC_COL_GRAY_LT3	82
5.3.1.35	GSLC_COL_GREEN	82
5.3.1.36	GSLC_COL_GREEN_DK1	82
5.3.1.37	GSLC_COL_GREEN_DK2	82
5.3.1.38	GSLC_COL_GREEN_DK3	82
5.3.1.39	GSLC_COL_GREEN_DK4	82
5.3.1.40	GSLC_COL_GREEN_LT1	82
5.3.1.41	GSLC_COL_GREEN_LT2	82
5.3.1.42	GSLC_COL_GREEN_LT3	83
5.3.1.43		83
5.3.1.44	GSLC_COL_MAGENTA	83
5.3.1.45		83
5.3.1.46		83
5.3.1.47	GSLC_COL_RED	83
5.3.1.48	GSLC_COL_RED_DK1	83
5.3.1.49	GSLC_COL_RED_DK2	83
5.3.1.50	GSLC_COL_RED_DK3	83
5.3.1.51	GSLC_COL_RED_DK4	83
5.3.1.52	GSLC_COL_RED_LT1	83
5.3.1.53	GSLC_COL_RED_LT2	83
5.3.1.54	GSLC_COL_RED_LT3	84
5.3.1.55		84
5.3.1.56	GSLC_COL_TEAL	84

xii CONTENTS

	5.3.1.57	GSLC_COL_WHITE	84
	5.3.1.58	GSLC_COL_YELLOW	84
	5.3.1.59	GSLC_COL_YELLOW_DK	84
	5.3.1.60	GSLC_DEBUG_PRINT	84
	5.3.1.61	gslc_ElemCreateBox_P	84
	5.3.1.62	gslc_ElemCreateTxt_P	85
5.3.2	Typedef I	Documentation	86
	5.3.2.1	GSLC_CB_DEBUG_OUT	86
	5.3.2.2	GSLC_CB_DRAW	86
	5.3.2.3	GSLC_CB_EVENT	86
	5.3.2.4	GSLC_CB_TICK	86
	5.3.2.5	GSLC_CB_TOUCH	86
	5.3.2.6	gslc_tsColor	86
	5.3.2.7	gslc_tsElem	87
	5.3.2.8	gslc_tsEvent	87
	5.3.2.9	gslc_tsEventTouch	87
	5.3.2.10	gslc_tsPt	87
	5.3.2.11	gslc_tsRect	87
5.3.3	Enumera	tion Type Documentation	87
	5.3.3.1	gslc_teDebugPrintState	87
	5.3.3.2	gslc_teElemId	87
	5.3.3.3	gslc_teElemInd	88
	5.3.3.4	gslc_teElemRefFlags	88
	5.3.3.5	gslc_teEventSubType	88
	5.3.3.6	gslc_teEventType	89
	5.3.3.7	gslc_teFontId	89
	5.3.3.8	gslc_teGroupId	89
	5.3.3.9	gslc_teImgRefFlags	89
	5.3.3.10	gslc_tePageId	90
	5.3.3.11	gslc_teTouch	90
	5.3.3.12	gslc_teTxtFlags	90
	5.3.3.13	gslc_teTypeCore	91
5.3.4	Function	Documentation	91
	5.3.4.1	gslc_ClipLine	91
	5.3.4.2	gslc_ClipPt	91
	5.3.4.3	gslc_ClipRect	92
	5.3.4.4	gslc_CollectDestruct	92
	5.3.4.5	gslc_CollectElemAdd	92
	5.3.4.6	gslc_CollectEvent	92
	5.3.4.7	gslc_CollectFindElemByld	93

CONTENTS xiii

5.3.4.8	gslc_CollectFindElemFromCoord
5.3.4.9	gslc_CollectGetElemTracked
5.3.4.10	gslc_CollectGetNextId
5.3.4.11	gslc_CollectGetRedraw
5.3.4.12	gslc_CollectReset
5.3.4.13	gslc_CollectSetElemTracked
5.3.4.14	gslc_CollectSetEventFunc
5.3.4.15	gslc_CollectSetParent
5.3.4.16	gslc_CollectTouch
5.3.4.17	gslc_DebugPrintf
5.3.4.18	gslc_DrawFillRect
5.3.4.19	gslc_DrawFrameCircle
5.3.4.20	gslc_DrawFrameRect
5.3.4.21	gslc_DrawLine
5.3.4.22	gslc_DrawLineH
5.3.4.23	gslc_DrawLineV
5.3.4.24	gslc_DrawSetPixel
5.3.4.25	gslc_ElemAdd
5.3.4.26	gslc_ElemCreate
5.3.4.27	gslc_ElemCreateBox
5.3.4.28	gslc_ElemCreateBtnImg
5.3.4.29	gslc_ElemCreateBtnTxt
5.3.4.30	gslc_ElemCreateImg
5.3.4.31	gslc_ElemCreateLine
5.3.4.32	gslc_ElemCreateTxt
5.3.4.33	gslc_ElemDestruct
5.3.4.34	gslc_ElemDraw
5.3.4.35	gslc_ElemDrawByRef
5.3.4.36	gslc_ElemEvent
5.3.4.37	gslc_ElemGetGlow
5.3.4.38	gslc_ElemGetGlowEn
5.3.4.39	gslc_ElemGetGroup
5.3.4.40	gslc_ElemGetId
5.3.4.41	gslc_ElemGetRedraw
5.3.4.42	gslc_ElemOwnsCoord
5.3.4.43	gslc_ElemSendEventTouch
5.3.4.44	gslc_ElemSetCol
5.3.4.45	gslc_ElemSetDrawFunc
5.3.4.46	gslc_ElemSetEventFunc
5.3.4.47	gslc_ElemSetFillEn

XIV

5.3.4.48	gslc_ElemSetFrameEn
5.3.4.49	gslc_ElemSetGlow
5.3.4.50	gslc_ElemSetGlowCol
5.3.4.51	gslc_ElemSetGlowEn
5.3.4.52	gslc_ElemSetGroup
5.3.4.53	gslc_ElemSetImage
5.3.4.54	gslc_ElemSetRedraw
5.3.4.55	gslc_ElemSetStyleFrom
5.3.4.56	gslc_ElemSetTickFunc
5.3.4.57	gslc_ElemSetTxtAlign
5.3.4.58	gslc_ElemSetTxtCol
5.3.4.59	gslc_ElemSetTxtMargin
5.3.4.60	gslc_ElemSetTxtMem
5.3.4.61	gslc_ElemSetTxtStr
5.3.4.62	gslc_ElemUpdateFont
5.3.4.63	gslc_EventCreate
5.3.4.64	gslc_ExpandRect
5.3.4.65	gslc_FontAdd
5.3.4.66	gslc_FontGet
5.3.4.67	gslc_GetImageFromFile
5.3.4.68	gslc_GetImageFromProg
5.3.4.69	gslc_GetImageFromRam
5.3.4.70	gslc_GetImageFromSD
5.3.4.71	gslc_GetPageCur
5.3.4.72	gslc_GetTouch
5.3.4.73	gslc_GetVer
5.3.4.74	gslc_GuiDestruct
5.3.4.75	gslc_Init
5.3.4.76	gslc_InitDebug
5.3.4.77	gslc_InitTouch
5.3.4.78	gslc_lslnRect
5.3.4.79	gslc_lslnWH
5.3.4.80	gslc_PageAdd
5.3.4.81	gslc_PageDestruct
5.3.4.82	gslc_PageEvent
5.3.4.83	gslc_PageFindByld
5.3.4.84	gslc_PageFindElemByld
5.3.4.85	gslc_PageFlipGet
5.3.4.86	gslc_PageFlipGo
5.3.4.87	gslc_PageFlipSet

CONTENTS xv

		5.3.4.88	gslc_PageRedrawCalc
		5.3.4.89	gslc_PageRedrawGet
		5.3.4.90	gslc_PageRedrawGo
		5.3.4.91	gslc_PageRedrawSet
		5.3.4.92	gslc_PageSetEventFunc
		5.3.4.93	gslc_Quit
		5.3.4.94	gslc_ResetElem
		5.3.4.95	gslc_ResetFont
		5.3.4.96	gslc_ResetImage
		5.3.4.97	gslc_SetBkgndColor
		5.3.4.98	gslc_SetBkgndImage
		5.3.4.99	gslc_SetClipRect
		5.3.4.100	gslc_SetPageCur
		5.3.4.101	gslc_TrackTouch
		5.3.4.102	gslc_Update
	5.3.5	Variable I	Documentation
		5.3.5.1	g_pfDebugOut
5.4	src/GU	Islice_con	fig.h File Reference
	5.4.1	Macro De	efinition Documentation
		5.4.1.1	ADATOUCH_FLIP_X
		5.4.1.2	ADATOUCH_FLIP_Y
		5.4.1.3	ADATOUCH_SWAP_XY
		5.4.1.4	DEBUG_ERR
		5.4.1.5	DRV_DISP_SDL1
		5.4.1.6	DRV_SDL_FIX_START
		5.4.1.7	DRV_SDL_MOUSE_SHOW
		5.4.1.8	DRV_TOUCH_TSLIB
		5.4.1.9	GSLC_BMP_TRANS_EN
		5.4.1.10	GSLC_BMP_TRANS_RGB
		5.4.1.11	GSLC_DEV_FB
		5.4.1.12	GSLC_DEV_TOUCH
		5.4.1.13	GSLC_LOCAL_STR
		5.4.1.14	GSLC_LOCAL_STR_LEN
		5.4.1.15	GSLC_USE_PROGMEM
5.5	src/GU	Islice_drv.	h File Reference
5.6	src/GU	Islice_drv_	_adagfx.cpp File Reference
	5.6.1	Function	Documentation
		5.6.1.1	gslc_DrvAdaptColorToRaw
		5.6.1.2	gslc_DrvDestruct
		5.6.1.3	gslc_DrvDrawBkgnd

xvi CONTENTS

.6.1.4	gslc_DrvDrawFillCircle	
.6.1.5	gslc_DrvDrawFillRect	126
.6.1.6	gslc_DrvDrawFrameCircle	126
.6.1.7	gslc_DrvDrawFrameRect	127
.6.1.8	gslc_DrvDrawImage	128
.6.1.9	gslc_DrvDrawLine	128
.6.1.10	gslc_DrvDrawMonoFromMem	128
.6.1.11	gslc_DrvDrawPoint	128
.6.1.12	gslc_DrvDrawPoints	129
.6.1.13	gslc_DrvDrawTxt	129
.6.1.14	gslc_DrvFontAdd	129
.6.1.15	gslc_DrvFontsDestruct	130
.6.1.16	gslc_DrvGetTouch	131
.6.1.17	gslc_DrvGetTxtSize	131
.6.1.18	gslc_DrvImageDestruct	131
.6.1.19	gslc_DrvInit	132
.6.1.20	gslc_DrvInitTouch	132
.6.1.21	gslc_DrvLoadImage	132
.6.1.22	gslc_DrvPageFlipNow	132
.6.1.23	gslc_DrvSetBkgndColor	133
.6.1.24	gslc_DrvSetBkgndImage	133
	gslc_DrvSetClipRect	
.6.1.27	gslc_DrvSetElemImageNorm	134
ice_drv_	adagfx.h File Reference	134
.7.1.1	DRV_HAS_DRAW_CIRCLE_FILL	137
.7.1.2	DRV_HAS_DRAW_CIRCLE_FRAME	137
.7.1.3	DRV_HAS_DRAW_LINE	137
.7.1.4	DRV_HAS_DRAW_POINT	137
.7.1.5	DRV_HAS_DRAW_POINTS	137
	DRV_HAS_DRAW_RECT_FILL	
.7.1.7	DRV_HAS_DRAW_RECT_FRAME	137
	DRV_HAS_DRAW_TEXT	
	gslc_DrvDrawBkgnd	
	gslc_DrvDrawFillCircle	
.7.2.5	gslc_DrvDrawFillRect	139
	6.1.6 6.1.7 6.1.8 6.1.9 6.1.10 6.1.11 6.1.12 6.1.13 6.1.14 6.1.15 6.1.16 6.1.17 6.1.18 6.1.20 6.1.21 6.1.22 6.1.23 6.1.24 6.1.25 6.1.26 6.1.27 ice_drv_ lacro Dellacro Del	6.1.6 gslc_DrvDrawFrameCircle 6.1.7 gslc_DrvDrawHrameRect 6.1.8 gslc_DrvDrawImage 6.1.9 gslc_DrvDrawMonoFromMem 6.1.10 gslc_DrvDrawPoint 6.1.11 gslc_DrvDrawPoint 6.1.12 gslc_DrvDrawPoints 6.1.13 gslc_DrvFontAdd 6.1.14 gslc_DrvFontAdd 6.1.15 gslc_DrvGetTouch 6.1.16 gslc_DrvGetTouch 6.1.17 gslc_DrvIndageDestruct 6.1.18 gslc_DrvIndageDestruct 6.1.19 gslc_DrvInitTouch 6.1.20 gslc_DrvIndageDestruct 6.1.21 gslc_DrvIndadinage 6.1.22 gslc_DrvNeadBinage 6.1.23 gslc_DrvNeatBisgndColor 6.1.24 gslc_DrvSetBisgndColor 6.1.25 gslc_DrvSetBisgndImage 6.1.26 gslc_DrvSetBisgndColor 6.1.27 gslc_DrvSetBismageRorm 6.1.28 pslc_DrvSetBismageRorm 6.1.29 pslc_DrvSetBismageRorm 6.1.20 pslc_DrvSetBismageRorm 6.1.21 pslc_DrvBas_DRAW_CIRCLE_FILL 7.1.1

CONTENTS xvii

		5.7.2.6	gslc_DrvDrawFrameCircle
		5.7.2.7	gslc_DrvDrawFrameRect
		5.7.2.8	gslc_DrvDrawImage
		5.7.2.9	gslc_DrvDrawLine
		5.7.2.10	gslc_DrvDrawPoint
		5.7.2.11	gslc_DrvDrawPoints
		5.7.2.12	gslc_DrvDrawTxt
		5.7.2.13	gslc_DrvFontAdd
		5.7.2.14	gslc_DrvFontsDestruct
		5.7.2.15	gslc_DrvGetTouch
		5.7.2.16	gslc_DrvGetTxtSize
		5.7.2.17	gslc_DrvImageDestruct
		5.7.2.18	gslc_DrvInit
		5.7.2.19	gslc_DrvInitTouch
		5.7.2.20	gslc_DrvInitTs
		5.7.2.21	gslc_DrvLoadImage
		5.7.2.22	gslc_DrvPageFlipNow
		5.7.2.23	gslc_DrvSetBkgndColor
		5.7.2.24	gslc_DrvSetBkgndImage
		5.7.2.25	gslc_DrvSetClipRect
		5.7.2.26	gslc_DrvSetElemImageGlow
		5.7.2.27	gslc_DrvSetElemImageNorm
5.8	src/GU	Islice_drv_	_sdl.c File Reference
	5.8.1	Macro De	efinition Documentation
		5.8.1.1	DRV_SDL_FIX_TTY
	5.8.2	Function	Documentation
		5.8.2.1	gslc_DrvAdaptColor
		5.8.2.2	gslc_DrvAdaptColorRaw
		5.8.2.3	gslc_DrvAdaptRect
		5.8.2.4	gslc_DrvCleanStart
		5.8.2.5	gslc_DrvDestruct
		5.8.2.6	gslc_DrvDrawBkgnd
		5.8.2.7	gslc_DrvDrawFillRect
		5.8.2.8	gslc_DrvDrawFrameRect
		5.8.2.9	gslc_DrvDrawGetPixelRaw
		5.8.2.10	gslc_DrvDrawImage
		5.8.2.11	gslc_DrvDrawLine
		5.8.2.12	gslc_DrvDrawPoint
		5.8.2.13	gslc_DrvDrawPoints
		5.8.2.14	gslc_DrvDrawSetPixelRaw
			• -

xviii CONTENTS

		5.8.2.15	gslc_DrvDrawTxt
		5.8.2.16	gslc_DrvFontAdd
		5.8.2.17	gslc_DrvFontsDestruct
		5.8.2.18	gslc_DrvGetTouch
		5.8.2.19	gslc_DrvGetTxtSize
		5.8.2.20	gslc_DrvImageDestruct
		5.8.2.21	gslc_DrvInit
		5.8.2.22	gslc_DrvInitTouch
		5.8.2.23	gslc_DrvLoadImage
		5.8.2.24	gslc_DrvPageFlipNow
		5.8.2.25	gslc_DrvPasteSurface
		5.8.2.26	gslc_DrvScreenLock
		5.8.2.27	gslc_DrvScreenUnlock
		5.8.2.28	gslc_DrvSetBkgndColor
		5.8.2.29	gslc_DrvSetBkgndImage
		5.8.2.30	gslc_DrvSetClipRect
		5.8.2.31	gslc_DrvSetElemImageGlow
		5.8.2.32	gslc_DrvSetElemImageNorm
		5.8.2.33	gslc_TDrvGetTouch
		5.8.2.34	gslc_TDrvInitTouch
5.9	src/GU	Ilslice_drv_	_sdl.h File Reference
	5.9.1	Macro De	efinition Documentation
		5.9.1.1	DRV_HAS_DRAW_CIRCLE_FILL
		5.9.1.2	DRV_HAS_DRAW_CIRCLE_FRAME
		5.9.1.3	DRV_HAS_DRAW_LINE
		5.9.1.4	DRV_HAS_DRAW_POINT 161
		5.9.1.5	DRV_HAS_DRAW_POINTS
		5.9.1.6	DRV_HAS_DRAW_RECT_FILL
		5.9.1.7	DRV_HAS_DRAW_RECT_FRAME
		5.9.1.8	DRV_HAS_DRAW_TEXT
	5.9.2	Function	Documentation
		5.9.2.1	gslc_DrvAdaptColor
		5.9.2.2	gslc_DrvAdaptColorRaw
		5.9.2.3	gslc_DrvAdaptRect
		5.9.2.4	gslc_DrvCleanStart
		5.9.2.5	gslc_DrvDestruct
		5.9.2.6	gslc_DrvDrawBkgnd
		5.9.2.7	gslc_DrvDrawFillRect
		5.9.2.7 5.9.2.8	gslc_DrvDrawFillRect 163 gslc_DrvDrawFrameRect 163

CONTENTS xix

	5.9.2.10	gslc_DrvDrawImage	164
	5.9.2.11	gslc_DrvDrawLine	164
	5.9.2.12	gslc_DrvDrawPoint	164
	5.9.2.13	gslc_DrvDrawPoints	165
	5.9.2.14	gslc_DrvDrawSetPixelRaw	165
	5.9.2.15	gslc_DrvDrawTxt	165
	5.9.2.16	gslc_DrvFontAdd	166
	5.9.2.17	gslc_DrvFontsDestruct	166
	5.9.2.18	gslc_DrvGetTouch	166
	5.9.2.19	gslc_DrvGetTxtSize	168
	5.9.2.20	gslc_DrvImageDestruct	168
	5.9.2.21	gslc_DrvInit	169
	5.9.2.22	gslc_DrvInitTouch	169
	5.9.2.23	gslc_DrvLoadImage	170
	5.9.2.24	gslc_DrvPageFlipNow	170
	5.9.2.25	gslc_DrvPasteSurface	170
	5.9.2.26	gslc_DrvScreenLock	171
	5.9.2.27	gslc_DrvScreenUnlock	171
	5.9.2.28	gslc_DrvSetBkgndColor	171
	5.9.2.29	gslc_DrvSetBkgndImage	172
	5.9.2.30	gslc_DrvSetClipRect	172
	5.9.2.31	gslc_DrvSetElemImageGlow	172
	5.9.2.32	gslc_DrvSetElemImageNorm	173
	5.9.2.33	gslc_TDrvGetTouch	173
	5.9.2.34	gslc_TDrvInitTouch	173
5.10 src/GU	Islice_ex.c	File Reference	173
5.10.1	Function I	Documentation	175
	5.10.1.1	gslc_ElemXCheckboxCreate	175
	5.10.1.2	gslc_ElemXCheckboxDraw	176
	5.10.1.3	gslc_ElemXCheckboxFindChecked	176
	5.10.1.4	gslc_ElemXCheckboxGetState	176
	5.10.1.5	gslc_ElemXCheckboxSetState	176
	5.10.1.6	gslc_ElemXCheckboxToggleState	177
	5.10.1.7	gslc_ElemXCheckboxTouch	177
	5.10.1.8	gslc_ElemXGaugeCreate	177
	5.10.1.9	gslc_ElemXGaugeDraw	178
	5.10.1.10	gslc_ElemXGaugeSetFlip	178
	5.10.1.11	gslc_ElemXGaugeUpdate	178
	5.10.1.12	gslc_ElemXSelNumClick	179
	5.10.1.13	gslc_ElemXSelNumCreate	179

CONTENTS

		5.10.1.14 gslc_ElemXSelNumDraw	'9
		5.10.1.15 gslc_ElemXSelNumGetCounter	0
		5.10.1.16 gslc_ElemXSelNumSetCounter	0
		5.10.1.17 gslc_ElemXSelNumTouch	0
		5.10.1.18 gslc_ElemXSliderCreate	0
		5.10.1.19 gslc_ElemXSliderDraw	1
		5.10.1.20 gslc_ElemXSliderGetPos	1
		5.10.1.21 gslc_ElemXSliderSetPos	1
		5.10.1.22 gslc_ElemXSliderSetPosFunc	2
		5.10.1.23 gslc_ElemXSliderSetStyle	2
		5.10.1.24 gslc_ElemXSliderTouch	2
	5.10.2	Variable Documentation	3
		5.10.2.1 SELNUM_ID_BTN_DEC	3
		5.10.2.2 SELNUM_ID_BTN_INC	3
		5.10.2.3 SELNUM_ID_TXT	3
5.11	src/GU	Islice_ex.h File Reference	3
	5.11.1	Macro Definition Documentation	5
		5.11.1.1 SELNUM_STR_LEN	5
	5.11.2	Typedef Documentation	5
		5.11.2.1 GSLC_CB_XSLIDER_POS	5
	5.11.3	Enumeration Type Documentation	5
		5.11.3.1 gslc_teTypeExtend	5
		5.11.3.2 gslc_teXCheckboxStyle	
	5.11.4	Function Documentation	5
		5.11.4.1 gslc_ElemXCheckboxCreate	5
		5.11.4.2 gslc_ElemXCheckboxDraw	6
		5.11.4.3 gslc_ElemXCheckboxFindChecked	6
		5.11.4.4 gslc_ElemXCheckboxGetState	6
		5.11.4.5 gslc_ElemXCheckboxSetState	57
		5.11.4.6 gslc_ElemXCheckboxToggleState	8
		5.11.4.7 gslc_ElemXCheckboxTouch	8
		5.11.4.8 gslc_ElemXGaugeCreate	8
		5.11.4.9 gslc_ElemXGaugeDraw	9
		5.11.4.10 gslc_ElemXGaugeSetFlip	9
		5.11.4.11 gslc_ElemXGaugeUpdate	9
		5.11.4.12 gslc_ElemXSelNumClick	10
		5.11.4.13 gslc_ElemXSelNumCreate	0
		5.11.4.14 gslc_ElemXSelNumDraw	0
		5.11.4.15 gslc_ElemXSelNumGetCounter	
		5.11.4.16 gslc_ElemXSelNumSetCounter	11

CONTENTS xxi

5.11.4.17 gslc_ElemXSelNumTouch	1
5.11.4.18 gslc_ElemXSliderCreate	1
5.11.4.19 gslc_ElemXSliderDraw	2
5.11.4.20 gslc_ElemXSliderGetPos	2
5.11.4.21 gslc_ElemXSliderSetPos	2
5.11.4.22 gslc_ElemXSliderSetPosFunc	3
5.11.4.23 gslc_ElemXSliderSetStyle	3
5.11.4.24 gslc_ElemXSliderTouch	3

Chapter 1

README

GUIslice library

A lightweight GUI framework suitable for embedded displays

- Website (www.impulseadventure.com)
- Documentation wiki (github)
- Release notes
- Pure C library, no dynamic memory allocation
- Widgets: text, images, buttons, checkboxes, radio buttons, sliders, etc. plus extensions and multiple pages.
- Platform-independent GUI core currently supports: SDL1.2, SDL2.0, Adafruit-GFX
- Typical target: Raspberry Pi, Arduino, Cortex M0 (Feather M0), LINUX
- Typical displays: PiTFT, Waveshare, Adafruit TFT 2.2" / 2.8"
- · Supports touchscreen control
- No GUIslice installation just add include files and go!
- · LINUX Dependencies: sdl, sdl-ttf, optional: tslib
- · Arduino Dependencies: Adafruit-GFX plus display (eg. ILI9341) / touch driver library (eg. STMPE610)

Screenshots

2 README

Chapter 2

Class Index

2.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

gslc_tsCollect	
Element collection struct	7
gslc_tsColor	
Color structure. Defines RGB triplet	9
gslc_tsDriver	10
gslc_tsElem	
Element Struct	11
gslc_tsElemRef	
Element reference structure	15
gslc_tsEvent	
Event structure	16
gslc_tsEventTouch	
Structure used to pass touch data through event	17
gslc_tsFont	
Font reference structure	18
gslc_tsGui	
GUI structure	18
gslc_tsImgRef	00
Image reference structure	22
gslc_tsPage	-
Page structure	23
gslc_tsPt	0.4
Define point coordinates	24
gslc_tsRect	0.5
Rectangular region. Defines X,Y corner coordinates plus dimensions	25
gslc_tsXCheckbox	200
Extended data for Checkbox element	26
gslc_tsXGauge	27
Extended data for Gauge element	21
gslc_tsXSelNum Extended data for SelNum element	28
Extended data for SelNum element	28
gslc_tsXSlider Extended data for Slider element	30

Class Index

Chapter 3

File Index

3.1 File List

Here is a list of all files with brief descriptions:

rc/GUIslice.c	33
rc/GUIslice.h	69
rc/GUIslice_config.h	22
rc/GUIslice_drv.h	123
rc/GUIslice_drv_adagfx.cpp	124
rc/GUIslice_drv_adagfx.h	134
rc/GUIslice_drv_sdl.c	
rc/GUIslice_drv_sdl.h	58
rc/GUIslice_ex.c	173
rc/GUIslice ex.h	183

6 File Index

Chapter 4


Class Documentation

4.1 gslc_tsCollect Struct Reference

Element collection struct.

#include <GUIslice.h>

Collaboration diagram for gslc_tsCollect:



Public Attributes

• gslc_tsElem * asElem

Array of elements.

uint16_t nElemMax

Maximum number of elements to allocate (in RAM)

• uint16_t nElemCnt

Number of elements allocated.

int16_t nElemAutoIdNext

Next Element ID for auto-assignment.

• gslc_tsElemRef * asElemRef

Array of element references.

8 Class Documentation

uint16_t nElemRefMax

Maximum number of element references to allocate.

uint16_t nElemRefCnt

Number of element references allocated.

gslc_tsElem * pElemTracked

Element currently being touch-tracked (NULL for none)

GSLC_CB_EVENT pfuncXEvent

Callback func ptr for events.

4.1.1 Detailed Description

Element collection struct.

- · Collections are used to maintain a list of elements and any touch tracking status.
- · Pages and Compound Elements both instantiate a Collection

4.1.2 Member Data Documentation

4.1.2.1 gslc_tsElem* gslc_tsCollect::asElem

Array of elements.

4.1.2.2 gslc_tsElemRef* gslc_tsCollect::asElemRef

Array of element references.

4.1.2.3 int16_t gslc_tsCollect::nElemAutoIdNext

Next Element ID for auto-assignment.

4.1.2.4 uint16_t gslc_tsCollect::nElemCnt

Number of elements allocated.

4.1.2.5 uint16_t gslc_tsCollect::nElemMax

Maximum number of elements to allocate (in RAM)

4.1.2.6 uint16_t gslc_tsCollect::nElemRefCnt

Number of element references allocated.

4.1.2.7 uint16_t gslc_tsCollect::nElemRefMax

Maximum number of element references to allocate.

4.1.2.8 gslc_tsElem* gslc_tsCollect::pElemTracked

Element currently being touch-tracked (NULL for none)

4.1.2.9 GSLC_CB_EVENT gslc_tsCollect::pfuncXEvent

Callback func ptr for events.

The documentation for this struct was generated from the following file:

• src/GUIslice.h

4.2 gslc_tsColor Struct Reference

```
Color structure. Defines RGB triplet.
```

```
#include <GUIslice.h>
```

Public Attributes

• uint8_t r

RGB red value.

uint8_t g

RGB green value.

• uint8 t b

RGB blue value.

· uint8_t unused

Unused value to pad structure.

4.2.1 Detailed Description

Color structure. Defines RGB triplet.

4.2.2 Member Data Documentation

```
4.2.2.1 uint8_t gslc_tsColor::b
```

RGB blue value.

4.2.2.2 uint8_t gslc_tsColor::g

RGB green value.

4.2.2.3 uint8_t gslc_tsColor::r

RGB red value.

4.2.2.4 uint8_t gslc_tsColor::unused

Unused value to pad structure.

The documentation for this struct was generated from the following file:


• src/GUIslice.h

10 Class Documentation

4.3 gslc_tsDriver Struct Reference

#include <GUIslice_drv_adagfx.h>

Collaboration diagram for gslc_tsDriver:



Public Attributes

• uint16_t nColRawBkgnd

Background color (if not image-based)

gslc_tsRect rClipRect

Clipping rectangle.

• SDL_Surface * pSurfScreen

Surface ptr for screen.

struct tsdev * pTsDev

Ptr to touchscreen device.

4.3.1 Member Data Documentation

4.3.1.1 uint16_t gslc_tsDriver::nColRawBkgnd

Background color (if not image-based)

4.3.1.2 SDL_Surface* gslc_tsDriver::pSurfScreen

Surface ptr for screen.

4.3.1.3 struct tsdev* gslc_tsDriver::pTsDev

Ptr to touchscreen device.

4.3.1.4 gslc_tsRect gslc_tsDriver::rClipRect

Clipping rectangle.

The documentation for this struct was generated from the following files:


- src/GUIslice_drv_adagfx.h
- src/GUIslice_drv_sdl.h

4.4 gslc_tsElem Struct Reference

Element Struct.

#include <GUIslice.h>

Collaboration diagram for gslc_tsElem:



Public Attributes

• int16_t nld

Element ID specified by user.

bool bValid

Element was created properly.

int16_t nType

Element type enumeration.

· gslc tsRect rElem

Rect region containing element.

int16_t nGroup

Group ID that the element belongs to.

bool bGlowEn

Enable glowing visual state.

bool bClickEn

Element accepts touch events.

bool bFrameEn

Element is drawn with frame.

• bool bFillEn

Element is drawn with inner fill.

• gslc_tsColor colElemFrame

Color for frame.

• gslc_tsColor colElemFill

Color for background fill.

gslc_tsColor colElemFrameGlow

Color to use for frame when glowing.

• gslc_tsColor colElemFillGlow

Color to use for fill when glowing.

gslc_tslmgRef slmgRefNorm

Image reference to draw (normal)

• gslc_tslmgRef slmgRefGlow

Image reference to draw (glowing)

12 Class Documentation

· gslc_tsElem * pElemParent

Parent element reference.

• char pStrBuf [GSLC_LOCAL_STR_LEN]

Text string to overlay.

· uint8 t nStrBufMax

Size of string buffer.

gslc_teTxtFlags eTxtFlags

Flags associated with text buffer.

gslc_tsColor colElemText

Color of overlay text.

• gslc_tsColor colElemTextGlow

Color of overlay text when glowing.

int8_t eTxtAlign

Alignment of overlay text.

• uint8_t nTxtMargin

Margin of overlay text within rect region.

gslc_tsFont * pTxtFont

Ptr to Font for overlay text.

void * pXData

Ptr to extended data structure.

• GSLC_CB_EVENT pfuncXEvent

Callback func ptr for event tree (draw,touch,tick)

GSLC_CB_DRAW pfuncXDraw

Callback func ptr for custom drawing.

• GSLC_CB_TOUCH pfuncXTouch

Callback func ptr for touch.

GSLC_CB_TICK pfuncXTick

Callback func ptr for timer/main loop tick.

bool bNeedRedraw

Element needs to be redrawn.

bool bGlowing

Element is currently glowing.

4.4.1 Detailed Description

Element Struct.

- Represents a single graphic element in the GUIslice environment
- · A page is made up of a number of elements
- Each element is created with a user-specified ID for further accesses (or GSLC_ID_AUTO for it to be autogenerated)
- · Display order of elements in a page is based upon the creation order
- Extensions to the core element types is provided through the pXData reference and pfuncX* callback functions.

4.4.2 Member Data Documentation

4.4.2.1 bool gslc_tsElem::bClickEn

Element accepts touch events.

4.4.2.2 bool gslc_tsElem::bFillEn

Element is drawn with inner fill.

This is also used during redraw to determine if elements underneath are visible and must be redrawn as well.

4.4.2.3 bool gslc_tsElem::bFrameEn

Element is drawn with frame.

4.4.2.4 bool gslc_tsElem::bGlowEn

Enable glowing visual state.

4.4.2.5 bool gslc_tsElem::bGlowing

Element is currently glowing.

4.4.2.6 bool gslc_tsElem::bNeedRedraw

Element needs to be redrawn.

4.4.2.7 bool gslc_tsElem::bValid

Element was created properly.

4.4.2.8 gslc_tsColor gslc_tsElem::colElemFill

Color for background fill.

4.4.2.9 gslc_tsColor gslc_tsElem::colElemFillGlow

Color to use for fill when glowing.

4.4.2.10 gslc_tsColor gslc_tsElem::colElemFrame

Color for frame.

4.4.2.11 gslc_tsColor gslc_tsElem::colElemFrameGlow

Color to use for frame when glowing.

4.4.2.12 gslc_tsColor gslc_tsElem::colElemText

Color of overlay text.

4.4.2.13 gslc_tsColor gslc_tsElem::colElemTextGlow

Color of overlay text when glowing.

14 Class Documentation

4.4.2.14 int8_t gslc_tsElem::eTxtAlign

Alignment of overlay text.

4.4.2.15 gslc_teTxtFlags gslc_tsElem::eTxtFlags

Flags associated with text buffer.

4.4.2.16 int16_t gslc_tsElem::nGroup

Group ID that the element belongs to.

4.4.2.17 int16_t gslc_tsElem::nld

Element ID specified by user.

4.4.2.18 uint8_t gslc_tsElem::nStrBufMax

Size of string buffer.

4.4.2.19 uint8_t gslc_tsElem::nTxtMargin

Margin of overlay text within rect region.

4.4.2.20 int16_t gslc_tsElem::nType

Element type enumeration.

4.4.2.21 gslc_tsElem* gslc_tsElem::pElemParent

Parent element reference.

Used during redraw to notify parent elements that they require redraw as well. Primary usage is in compound elements.

4.4.2.22 GSLC_CB_DRAW gslc_tsElem::pfuncXDraw

Callback func ptr for custom drawing.

4.4.2.23 GSLC_CB_EVENT gslc_tsElem::pfuncXEvent

Callback func ptr for event tree (draw,touch,tick)

4.4.2.24 GSLC_CB_TICK gslc_tsElem::pfuncXTick

Callback func ptr for timer/main loop tick.

4.4.2.25 GSLC_CB_TOUCH gslc_tsElem::pfuncXTouch

Callback func ptr for touch.

4.4.2.26 char gslc_tsElem::pStrBuf[GSLC_LOCAL_STR_LEN]

Text string to overlay.

4.4.2.27 gslc_tsFont* gslc_tsElem::pTxtFont

Ptr to Font for overlay text.

4.4.2.28 void* gslc_tsElem::pXData

Ptr to extended data structure.

4.4.2.29 gslc_tsRect gslc_tsElem::rElem

Rect region containing element.

4.4.2.30 gslc_tsImgRef gslc_tsElem::sImgRefGlow

Image reference to draw (glowing)

4.4.2.31 gslc_tslmgRef gslc_tsElem::slmgRefNorm

Image reference to draw (normal)

The documentation for this struct was generated from the following file:


• src/GUIslice.h

4.5 gslc_tsElemRef Struct Reference

Element reference structure.

#include <GUIslice.h>

Collaboration diagram for gslc_tsElemRef:



Public Attributes

• gslc_tsElem * pElem

Pointer to element in memory [RAM,FLASH].

• gslc_teElemRefFlags eElemFlags

Element reference flags.

4.5.1 Detailed Description

Element reference structure.

4.5.2 Member Data Documentation

4.5.2.1 gslc_teElemRefFlags gslc_tsElemRef::eElemFlags

Element reference flags.

```
4.5.2.2 gslc_tsElem* gslc_tsElemRef::pElem
```

Pointer to element in memory [RAM,FLASH].

The documentation for this struct was generated from the following file:

· src/GUIslice.h

4.6 gslc_tsEvent Struct Reference

Event structure.

#include <GUIslice.h>

Public Attributes

• gslc_teEventType eType

Event type.

uint8_t nSubType

Event sub-type.

void * pvScope

Event target scope (eg. Page, Collection, Event)

void * pvData

Generic data pointer for event.

4.6.1 Detailed Description

Event structure.

4.6.2 Member Data Documentation

4.6.2.1 gslc_teEventType gslc_tsEvent::eType

Event type.

4.6.2.2 uint8_t gslc_tsEvent::nSubType

Event sub-type.

4.6.2.3 void* gslc_tsEvent::pvData

Generic data pointer for event.

This member is used to either pass a pointer to a simple data datatype (such as Element or Collection) or to a another structure that contains multiple fields.

4.6.2.4 void* gslc_tsEvent::pvScope

Event target scope (eg. Page, Collection, Event)

The documentation for this struct was generated from the following file:

• src/GUIslice.h

4.7 gslc_tsEventTouch Struct Reference

Structure used to pass touch data through event.

#include <GUIslice.h>

Public Attributes

• gslc_teTouch eTouch

Touch state.

int16_t nX

Touch X coordinate (absolute)

int16_t nY

Touch Y coordinate (absolute)

4.7.1 Detailed Description

Structure used to pass touch data through event.

4.7.2 Member Data Documentation

4.7.2.1 gslc_teTouch gslc_tsEventTouch::eTouch

Touch state.

4.7.2.2 int16_t gslc_tsEventTouch::nX

Touch X coordinate (absolute)

4.7.2.3 int16_t gslc_tsEventTouch::nY

Touch Y coordinate (absolute)

The documentation for this struct was generated from the following file:

• src/GUIslice.h

4.8 gslc_tsFont Struct Reference

```
Font reference structure.
```

```
#include <GUIslice.h>
```

Public Attributes

• int16_t nld

Font ID specified by user.

void * pvFont

Void ptr to the Font (type defined by driver)

• uint16_t nSize

Font size.

4.8.1 Detailed Description

Font reference structure.

4.8.2 Member Data Documentation

```
4.8.2.1 int16_t gslc_tsFont::nld
```

Font ID specified by user.

4.8.2.2 uint16_t gslc_tsFont::nSize

Font size.

4.8.2.3 void* gslc_tsFont::pvFont

Void ptr to the Font (type defined by driver)

The documentation for this struct was generated from the following file:


• src/GUIslice.h

4.9 gslc_tsGui Struct Reference

GUI structure.

#include <GUIslice.h>

Collaboration diagram for gslc_tsGui:



Public Attributes

uint16_t nDispW

Width of the display (pixels)

• uint16_t nDispH

Height of the display (pixels)

uint8_t nDispDepth

Bit depth of display (bits per pixel)

• gslc tsFont * asFont

Collection of loaded fonts.

uint8_t nFontMax

Maximum number of fonts to allocate.

uint8_t nFontCnt

Number of fonts allocated.

gslc_tsElem sElemTmp

Temporary element.

int16_t nTouchLastX

Last touch event X coord.

int16 t nTouchLastY

Last touch event Y coord.

• uint16_t nTouchLastPress

Last touch event pressure (0=none))

void * pvDriver

Driver-specific members (gslc_tsDriver*)

• bool bRedrawPartialEn

Driver supports partial page redraw.

gslc_tslmgRef slmgRefBkgnd

Image reference for background.

uint8_t nFrameRateCnt

Diagnostic frame rate count.

• uint8_t nFrameRateStart

Diagnostic frame rate timestamp.

gslc_tsPage * asPage

Array of pages.

uint8_t nPageMax

Maximum number of pages.

uint8_t nPageCnt

Current page index.

gslc_tsPage * pCurPage

Currently active page.

gslc_tsCollect * pCurPageCollect

Ptr to active page collection.

GSLC_CB_EVENT pfuncXEvent

Callback func ptr for events.

4.9.1 Detailed Description

GUI structure.

- · Contains all GUI state and content
- · Maintains list of one or more pages

4.9.2 Member Data Documentation

4.9.2.1 gslc_tsFont* gslc_tsGui::asFont

Collection of loaded fonts.

4.9.2.2 gslc_tsPage* gslc_tsGui::asPage

Array of pages.

4.9.2.3 bool gslc_tsGui::bRedrawPartialEn

Driver supports partial page redraw.

If true, only changed elements are redrawn during next page redraw command. If false, entire page is redrawn when any element has been updated prior to next page redraw command.

4.9.2.4 uint8_t gslc_tsGui::nDispDepth

Bit depth of display (bits per pixel)

4.9.2.5 uint16_t gslc_tsGui::nDispH

Height of the display (pixels)

4.9.2.6 uint16_t gslc_tsGui::nDispW

Width of the display (pixels)

4.9.2.7 uint8_t gslc_tsGui::nFontCnt

Number of fonts allocated.

4.9.2.8 uint8_t gslc_tsGui::nFontMax

Maximum number of fonts to allocate.

4.9.2.9 uint8_t gslc_tsGui::nFrameRateCnt

Diagnostic frame rate count.

4.9.2.10 uint8_t gslc_tsGui::nFrameRateStart

Diagnostic frame rate timestamp.

4.9.2.11 uint8_t gslc_tsGui::nPageCnt

Current page index.

4.9.2.12 uint8_t gslc_tsGui::nPageMax

Maximum number of pages.

4.9.2.13 uint16_t gslc_tsGui::nTouchLastPress

Last touch event pressure (0=none))

4.9.2.14 int16_t gslc_tsGui::nTouchLastX

Last touch event X coord.

4.9.2.15 int16_t gslc_tsGui::nTouchLastY

Last touch event Y coord.

4.9.2.16 gslc_tsPage* gslc_tsGui::pCurPage

Currently active page.

4.9.2.17 gslc_tsCollect* gslc_tsGui::pCurPageCollect

Ptr to active page collection.

4.9.2.18 GSLC_CB_EVENT gslc_tsGui::pfuncXEvent

Callback func ptr for events.

```
4.9.2.19 void* gslc_tsGui::pvDriver
```

Driver-specific members (gslc_tsDriver*)

4.9.2.20 gslc_tsElem gslc_tsGui::sElemTmp

Temporary element.

4.9.2.21 gslc_tslmgRef gslc_tsGui::slmgRefBkgnd

Image reference for background.

The documentation for this struct was generated from the following file:

• src/GUIslice.h

4.10 gslc_tslmgRef Struct Reference

Image reference structure.

```
#include <GUIslice.h>
```

Public Attributes

· const unsigned char * plmgBuf

Pointer to input image buffer in memory [RAM,FLASH].

• const char * pFname

Pathname to input image file [FILE,SD].

• gslc_teImgRefFlags eImgFlags

Image reference flags.

void * pvImgRaw

Ptr to raw output image data (for pre-loaded images)

4.10.1 Detailed Description

Image reference structure.

4.10.2 Member Data Documentation

4.10.2.1 gslc_telmgRefFlags gslc_tslmgRef::elmgFlags

Image reference flags.

4.10.2.2 const char* gslc_tslmgRef::pFname

Pathname to input image file [FILE,SD].

4.10.2.3 const unsigned char* gslc_tslmgRef::plmgBuf

Pointer to input image buffer in memory [RAM,FLASH].

4.10.2.4 void* gslc_tslmgRef::pvlmgRaw

Ptr to raw output image data (for pre-loaded images)

The documentation for this struct was generated from the following file:


· src/GUIslice.h

4.11 gslc_tsPage Struct Reference

Page structure.

#include <GUIslice.h>

Collaboration diagram for gslc_tsPage:



Public Attributes

• gslc_tsCollect sCollect

Collection of elements on page.

• int8_t nPageId

Page identifier.

bool bPageNeedRedraw

Page require a redraw.

bool bPageNeedFlip

Screen requires a page flip.

GSLC_CB_EVENT pfuncXEvent

Callback func ptr for events.

4.11.1 Detailed Description

Page structure.

- · A page contains a collection of elements
- · Many redraw functions operate at a page level
- · Maintains state as to whether redraw or screen flip is required

4.11.2 Member Data Documentation

4.11.2.1 bool gslc_tsPage::bPageNeedFlip

Screen requires a page flip.

4.11.2.2 bool gslc_tsPage::bPageNeedRedraw

Page require a redraw.

4.11.2.3 int8_t gslc_tsPage::nPageId

Page identifier.

4.11.2.4 GSLC_CB_EVENT gslc_tsPage::pfuncXEvent

Callback func ptr for events.

4.11.2.5 gslc_tsCollect gslc_tsPage::sCollect

Collection of elements on page.

The documentation for this struct was generated from the following file:

• src/GUIslice.h

4.12 gslc_tsPt Struct Reference

Define point coordinates.

#include <GUIslice.h>

Public Attributes

• int x

X coordinate.

int y

Y coordinate.

4.12.1 Detailed Description

Define point coordinates.

4.12.2 Member Data Documentation

```
4.12.2.1 int gslc_tsPt::x
```

X coordinate.

```
4.12.2.2 int gslc_tsPt::y
```

Y coordinate.

The documentation for this struct was generated from the following file:

• src/GUIslice.h

4.13 gslc_tsRect Struct Reference

Rectangular region. Defines X,Y corner coordinates plus dimensions.

```
#include <GUIslice.h>
```

Public Attributes

int16_t x

X coordinate of corner.

• int16_t y

Y coordinate of corner.

• uint16_t w

Width of region.

• uint16_t h

Height of region.

4.13.1 Detailed Description

Rectangular region. Defines X,Y corner coordinates plus dimensions.

4.13.2 Member Data Documentation

```
4.13.2.1 uint16_t gslc_tsRect::h
```

Height of region.

4.13.2.2 uint16_t gslc_tsRect::w

Width of region.

4.13.2.3 int16_t gslc_tsRect::x

X coordinate of corner.

4.13.2.4 int16_t gslc_tsRect::y

Y coordinate of corner.

The documentation for this struct was generated from the following file:


· src/GUIslice.h

4.14 gslc_tsXCheckbox Struct Reference

Extended data for Checkbox element.

#include <GUIslice_ex.h>

Collaboration diagram for gslc tsXCheckbox:



Public Attributes

• gslc_tsGui * pGui

Ptr to GUI (for radio group control)

bool bRadio

Radio-button operation if true.

• gslc_teXCheckboxStyle nStyle

Drawing style for element.

bool bChecked

Indicates if it is selected (checked)

• gslc_tsColor colCheck

Color of checked inner fill.

4.14.1 Detailed Description

Extended data for Checkbox element.

4.14.2 Member Data Documentation

4.14.2.1 bool gslc_tsXCheckbox::bChecked

Indicates if it is selected (checked)

4.14.2.2 bool gslc_tsXCheckbox::bRadio

Radio-button operation if true.

4.14.2.3 gslc_tsColor gslc_tsXCheckbox::colCheck

Color of checked inner fill.

4.14.2.4 gslc_teXCheckboxStyle gslc_tsXCheckbox::nStyle

Drawing style for element.

4.14.2.5 gslc_tsGui* gslc_tsXCheckbox::pGui

Ptr to GUI (for radio group control)

The documentation for this struct was generated from the following file:


• src/GUIslice_ex.h

4.15 gslc_tsXGauge Struct Reference

Extended data for Gauge element.

#include <GUIslice_ex.h>

 $Collaboration\ diagram\ for\ gslc_tsXGauge:$



Public Attributes

• int16_t nGaugeMin

Minimum control value.

int16_t nGaugeMax

Maximum control value.

int16_t nGaugeVal

Current control value.

gslc_tsColor colGauge

Color of gauge fill bar.

bool bGaugeVert

Vertical if true, else Horizontal.

bool bGaugeFlip

Reverse direction of gauge.

4.15.1 Detailed Description

Extended data for Gauge element.

4.15.2 Member Data Documentation

4.15.2.1 bool gslc_tsXGauge::bGaugeFlip

Reverse direction of gauge.

4.15.2.2 bool gslc_tsXGauge::bGaugeVert

Vertical if true, else Horizontal.

4.15.2.3 gslc_tsColor gslc_tsXGauge::colGauge

Color of gauge fill bar.

4.15.2.4 int16_t gslc_tsXGauge::nGaugeMax

Maximum control value.

4.15.2.5 int16_t gslc_tsXGauge::nGaugeMin

Minimum control value.

4.15.2.6 int16_t gslc_tsXGauge::nGaugeVal

Current control value.

The documentation for this struct was generated from the following file:


• src/GUIslice_ex.h

4.16 gslc_tsXSelNum Struct Reference

Extended data for SelNum element.

#include <GUIslice_ex.h>

Collaboration diagram for gslc_tsXSelNum:



Public Attributes

• int16_t nCounter

Counter for demo purposes.

gslc_tsCollect sCollect

Collection management for sub-elements.

• gslc_tsElemRef asElemRef [4]

Storage for sub-element references.

• gslc_tsElem asElem [4]

Storage for sub-elements.

char acElemTxt [4][SELNUM_STR_LEN]

Storage for strings.

4.16.1 Detailed Description

Extended data for SelNum element.

4.16.2 Member Data Documentation

4.16.2.1 char gslc_tsXSelNum::acElemTxt[4][SELNUM_STR_LEN]

Storage for strings.

4.16.2.2 gslc_tsElem gslc_tsXSelNum::asElem[4]

Storage for sub-elements.

4.16.2.3 gslc_tsElemRef gslc_tsXSelNum::asElemRef[4]

Storage for sub-element references.

4.16.2.4 int16_t gslc_tsXSelNum::nCounter

Counter for demo purposes.

4.16.2.5 gslc_tsCollect gslc_tsXSelNum::sCollect

Collection management for sub-elements.

The documentation for this struct was generated from the following file:


• src/GUIslice_ex.h

4.17 gslc_tsXSlider Struct Reference

Extended data for Slider element.

#include <GUIslice_ex.h>

Collaboration diagram for gslc_tsXSlider:



Public Attributes

bool bVert

Orientation: true if vertical, else horizontal.

• int16_t nThumbSz

Size of the thumb control.

• int16_t nPosMin

Minimum position value of the slider.

int16_t nPosMax

Maximum position value of the slider.

uint16_t nTickDiv

Style: number of tickmark divisions (0 for none)

• int16_t nTickLen

Style: length of tickmarks.

gslc_tsColor colTick

Style: color of ticks.

bool bTrim

Style: show a trim color.

• gslc_tsColor colTrim

Style: color of trim.

• int16_t nPos

Current position value of the slider.

• GSLC_CB_XSLIDER_POS pfuncXPos

Callback func ptr for position update.

4.17.1 Detailed Description

Extended data for Slider element.

4.17.2 Member Data Documentation

4.17.2.1 bool gslc_tsXSlider::bTrim

Style: show a trim color.

4.17.2.2 bool gslc_tsXSlider::bVert

Orientation: true if vertical, else horizontal.

4.17.2.3 gslc_tsColor gslc_tsXSlider::colTick

Style: color of ticks.

4.17.2.4 gslc_tsColor gslc_tsXSlider::colTrim

Style: color of trim.

4.17.2.5 int16_t gslc_tsXSlider::nPos

Current position value of the slider.

4.17.2.6 int16_t gslc_tsXSlider::nPosMax

Maximum position value of the slider.

4.17.2.7 int16_t gslc_tsXSlider::nPosMin

Minimum position value of the slider.

4.17.2.8 int16_t gslc_tsXSlider::nThumbSz

Size of the thumb control.

4.17.2.9 uint16_t gslc_tsXSlider::nTickDiv

Style: number of tickmark divisions (0 for none)

4.17.2.10 int16_t gslc_tsXSlider::nTickLen

Style: length of tickmarks.

4.17.2.11 GSLC_CB_XSLIDER_POS gslc_tsXSlider::pfuncXPos

Callback func ptr for position update.

The documentation for this struct was generated from the following file:

• src/GUIslice_ex.h

Chapter 5


File Documentation

5.1 README.md File Reference

5.2 src/GUIslice.c File Reference

```
#include "GUIslice_config.h"
#include "GUIslice.h"
#include "GUIslice_ex.h"
#include "GUIslice_drv.h"
#include <stdio.h>
#include <time.h>
#include <stdarg.h>
```

Include dependency graph for GUIslice.c:



Macros

• #define GUISLICE_VER "0.8.5"

Functions

- char * gslc_GetVer (gslc_tsGui *pGui)
 - Get the GUIslice version number.
- bool gslc_Init (gslc_tsGui *pGui, void *pvDriver, gslc_tsPage *asPage, uint8_t nMaxPage, gslc_tsFont *as←
 Font, uint8_t nMaxFont)

Initialize the GUIslice library.

• void gslc_InitDebug (GSLC_CB_DEBUG_OUT pfunc)

Initialize debug output.

• void gslc_DebugPrintf (const char *pFmt,...)

Optimized printf routine for GUIslice debug/error output.

void gslc_Quit (gslc_tsGui *pGui)

Exit the GUIslice environment.

void gslc_Update (gslc_tsGui *pGui)

Perform main GUIslice handling functions.

• gslc_tsEvent gslc_EventCreate (gslc_teEventType eType, uint8_t nSubType, void *pvScope, void *pvData)

Create an event structure.

bool gslc_lsInRect (int16_t nSelX, int16_t nSelY, gslc_tsRect rRect)

Determine if a coordinate is inside of a rectangular region.

bool gslc_lsInWH (gslc_tsGui *pGui, int16_t nSelX, int16_t nSelY, uint16_t nWidth, uint16_t nHeight)

Determine if a coordinate is inside of a width x height region.

- void gslc OrderCoord (int16 t*pnX0, int16 t*pnY0, int16 t*pnX1, int16 t*pnY1)
- bool gslc ClipPt (gslc tsRect *pClipRect, int16 t nX, int16 t nY)

Perform basic clipping of a single point to a clipping region.

bool gslc_ClipLine (gslc_tsRect *pClipRect, int16_t *pnX0, int16_t *pnY0, int16_t *pnX1, int16_t *pnY1)

Perform basic clipping of a line to a clipping region.

bool gslc_ClipRect (gslc_tsRect *pClipRect, gslc_tsRect *pRect)

Perform basic clipping of a rectangle to a clipping region.

• gslc_tslmgRef gslc_ResetImage ()

Create a blank image reference structure.

gslc_tslmgRef gslc_GetImageFromFile (const char *pFname, gslc_teImgRefFlags eFmt)

Create an image reference to a bitmap file in LINUX filesystem.

• gslc_tslmgRef gslc_GetImageFromSD (const char *pFname, gslc_teImgRefFlags eFmt)

Create an image reference to a bitmap file in SD card.

gslc tslmgRef gslc GetImageFromRam (unsigned char *pImgBuf, gslc teImgRefFlags eFmt)

Create an image reference to a bitmap in SRAM.

gslc_tslmgRef gslc_GetImageFromProg (const unsigned char *pImgBuf, gslc_teImgRefFlags eFmt)

Create an image reference to a bitmap in program memory (PROGMEM)

void gslc_DrawSetPixel (gslc_tsGui *pGui, int16_t nX, int16_t nY, gslc_tsColor nCol)

Set a pixel on the active screen to the given color with lock.

• void gslc_DrawLine (gslc_tsGui *pGui, int16_t nX0, int16_t nY0, int16_t nX1, int16_t nY1, gslc_tsColor nCol)

Draw an arbitrary line using Bresenham's algorithm.

void gslc DrawLineH (gslc tsGui *pGui, int16 t nX, int16 t nY, uint16 t nW, gslc tsColor nCol)

Draw a horizontal line.

void gslc_DrawLineV (gslc_tsGui *pGui, int16_t nX, int16_t nY, uint16_t nH, gslc_tsColor nCol)

Draw a vertical line.

void gslc_DrawFrameRect (gslc_tsGui *pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a framed rectangle.

void gslc_DrawFillRect (gslc_tsGui *pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a filled rectangle.

gslc_tsRect gslc_ExpandRect (gslc_tsRect rRect, int16_t nExpandW, int16_t nExpandH)

Expand or contract a rectangle in width and/or height (equal amounts on both side), based on the centerpoint of the rectangle.

 void gslc_DrawFrameCircle (gslc_tsGui *pGui, int16_t nMidX, int16_t nMidY, uint16_t nRadius, gslc_tsColor nCol)

Draw a framed circle.

bool gslc FontAdd (gslc tsGui *pGui, int16 t nFontId, const char *acFontName, uint16 t nFontSz)

Load a font into the local font cache and assign font ID (nFontId).

gslc_tsFont * gslc_FontGet (gslc_tsGui *pGui, int16_t nFontId)

Fetch a font from its ID value.

bool gslc_PageEvent (void *pvGui, gslc_tsEvent sEvent)

Common event handler function for a page.

void gslc_PageAdd (gslc_tsGui *pGui, int16_t nPageId, gslc_tsElem *psElem, uint16_t nMaxElem, gslc_ts
 ElemRef *psElemRef, uint16_t nMaxElemRef)

Add a page to the GUI.

int gslc_GetPageCur (gslc_tsGui *pGui)

Fetch the current page ID.

void gslc_SetPageCur (gslc_tsGui *pGui, int16_t nPageId)

Select a new page for display.

void gslc_PageRedrawSet (gslc_tsGui *pGui, bool bRedraw)

Update the need-redraw status for the current page.

bool gslc_PageRedrawGet (gslc_tsGui *pGui)

Get the need-redraw status for the current page.

• void gslc_PageRedrawCalc (gslc_tsGui *pGui)

Perform a redraw calculation on the page to determine if additional elements should also be redrawn.

void gslc_PageRedrawGo (gslc_tsGui *pGui)

Redraw all elements on the active page.

void gslc_PageFlipSet (gslc_tsGui *pGui, bool bNeeded)

Indicate whether the screen requires page flip.

bool gslc_PageFlipGet (gslc_tsGui *pGui)

Get state of pending page flip state.

void gslc_PageFlipGo (gslc_tsGui *pGui)

Update the visible screen if page has been marked for flipping.

gslc tsPage * gslc PageFindByld (gslc tsGui *pGui, int16 t nPageId)

Find a page in the GUI by its ID.

gslc_tsElem * gslc_PageFindElemByld (gslc_tsGui *pGui, int16_t nPageId, int16_t nElemId)

Find an element in the GUI by its Page ID and Element ID.

void gslc PageSetEventFunc (gslc tsPage *pPage, GSLC CB EVENT funcCb)

Assign the event callback function for a page.

int gslc_ElemGetId (gslc_tsElem *pElem)

Get an Element ID from an element structure.

 gslc_tsElem * gslc_ElemCreateTxt (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem, char *pStrBuf, uint8 t nStrBufMax, int16 t nFontId)

Create a Text Element.

• gslc_tsElem * gslc_ElemCreateBtnTxt (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem, char *pStrBuf, uint8_t nStrBufMax, int16_t nFontId, GSLC_CB_TOUCH cbTouch)

Create a textual Button Element.

gslc_tsElem * gslc_ElemCreateBtnImg (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, gslc_tsRect r←
Elem, gslc_tsImgRef sImgRef, gslc_tsImgRef sImgRefSel, GSLC_CB_TOUCH cbTouch)

Create a graphical Button Element.

• gslc_tsElem * gslc_ElemCreateBox (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem)

Create a Box Element.

• gslc_tsElem * gslc_ElemCreateLine (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, int16_t nX0, int16_t nY0, int16_t nX1, int16_t nY1)

Create a Line Element.

 gslc_tsElem * gslc_ElemCreateImg (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem, gslc_tsImgRef sImgRef)

Create an image Element.

bool gslc_ElemEvent (void *pvGui, gslc_tsEvent sEvent)

Common event handler function for an element.

void gslc_ElemDraw (gslc_tsGui *pGui, int16_t nPageId, int16_t nElemId)

Draw an element to the active display.

bool gslc_ElemDrawByRef (gslc_tsGui *pGui, gslc_tsElem *pElem)

Draw an element to the active display.

void gslc_ElemSetFillEn (gslc_tsElem *pElem, bool bFillEn)

Set the fill state for an Element.

void gslc_ElemSetFrameEn (gslc_tsElem *pElem, bool bFrameEn)

Set the frame state for an Element.

 void gslc_ElemSetCol (gslc_tsElem *pElem, gslc_tsColor colFrame, gslc_tsColor colFill, gslc_tsColor col← FillGlow)

Update the common color selection for an Element.

void gslc_ElemSetGlowCol (gslc_tsElem *pElem, gslc_tsColor colFrameGlow, gslc_tsColor colFillGlow, gslc_tsColor colTxtGlow)

Update the common color selection for glowing state of an Element.

void gslc_ElemSetGroup (gslc_tsElem *pElem, int nGroupId)

Set the group ID for an element.

int gslc_ElemGetGroup (gslc_tsElem *pElem)

Get the group ID for an element.

void gslc_ElemSetTxtAlign (gslc_tsElem *pElem, unsigned nAlign)

Set the alignment of a textual element (horizontal and vertical)

void gslc_ElemSetTxtMargin (gslc_tsElem *pElem, unsigned nMargin)

Set the margin around of a textual element.

void gslc_ElemSetTxtStr (gslc_tsElem *pElem, const char *pStr)

Update the text string associated with an Element ID.

void gslc_ElemSetTxtCol (gslc_tsElem *pElem, gslc_tsColor colVal)

Update the text string color associated with an Element ID.

void gslc_ElemSetTxtMem (gslc_tsElem *pElem, gslc_teTxtFlags eFlags)

Update the text string location in memory.

void gslc_ElemUpdateFont (gslc_tsGui *pGui, gslc_tsElem *pElem, int nFontId)

Update the Font selected for an Element's text.

void gslc_ElemSetRedraw (gslc_tsElem *pElem, bool bRedraw)

Update the need-redraw status for an element.

bool gslc_ElemGetRedraw (gslc_tsElem *pElem)

Get the need-redraw status for an element.

void gslc_ElemSetGlow (gslc_tsElem *pElem, bool bGlowing)

Update the glowing indicator for an element.

bool gslc_ElemGetGlow (gslc_tsElem *pElem)

Get the glowing indicator for an element.

void gslc_ElemSetGlowEn (gslc_tsElem *pElem, bool bGlowEn)

Update the glowing enable for an element.

bool gslc ElemGetGlowEn (gslc tsElem *pElem)

Get the glowing enable for an element.

void gslc_ElemSetStyleFrom (gslc_tsElem *pElemSrc, gslc_tsElem *pElemDest)

Copy style settings from one element to another.

void gslc ElemSetEventFunc (gslc tsElem *pElem, GSLC CB EVENT funcCb)

Assign the event callback function for a element.

void gslc ElemSetDrawFunc (gslc tsElem *pElem, GSLC CB DRAW funcCb)

Assign the drawing callback function for an element.

void gslc ElemSetTickFunc (gslc tsElem *pElem, GSLC CB TICK funcCb)

Assign the tick callback function for an element.

• bool gslc_ElemOwnsCoord (gslc_tsElem *pElem, int16_t nX, int16_t nY, bool bOnlyClickEn)

Determine if a coordinate is inside of an element.

void gslc_CollectTouch (gslc_tsGui *pGui, gslc_tsCollect *pCollect, gslc_tsEventTouch *pEventTouch)

Handle touch events within the element collection.

void gslc_TrackTouch (gslc_tsGui *pGui, gslc_tsPage *pPage, int16_t nX, int16_t nY, uint16_t nPress)

Handles a touch event and performs the necessary tracking, glowing and selection actions depending on the press state

• bool gslc_InitTouch (gslc_tsGui *pGui, const char *acDev)

Initialize the touchscreen device driver.

bool gslc_GetTouch (gslc_tsGui *pGui, int16_t *pnX, int16_t *pnY, uint16_t *pnPress)

Initialize the touchscreen device driver.

gslc_tsElem gslc_ElemCreate (gslc_tsGui *pGui, int16_t nElemId, int16_t nPageId, int16_t nType, gslc_ts
 — Rect rElem, char *pStrBuf, uint8_t nStrBufMax, int16_t nFontId)

Create a new element with default styling.

bool gslc_CollectEvent (void *pvGui, gslc_tsEvent sEvent)

Common event handler function for an element collection.

Add an element to a collection.

bool gslc_CollectGetRedraw (gslc_tsCollect *pCollect)

Determine if any elements in a collection need redraw.

 gslc_tsElem * gslc_ElemAdd (gslc_tsGui *pGui, int16_t nPageId, gslc_tsElem *pElem, gslc_teElemRefFlags eFlags)

Add the Element to the list of generated elements in the GUI environment.

bool gslc_SetClipRect (gslc_tsGui *pGui, gslc_tsRect *pRect)

Set the clipping rectangle for further drawing.

void gslc_ElemSetImage (gslc_tsGui *pGui, gslc_tsElem *pElem, gslc_tsImgRef sImgRef, gslc_tsImgRef sImgRef sImgRe

Set an element to use a bitmap image.

bool gslc_SetBkgndImage (gslc_tsGui *pGui, gslc_tsImgRef sImgRef)

Configure the background to use a bitmap image.

bool gslc_SetBkgndColor (gslc_tsGui *pGui, gslc_tsColor nCol)

Configure the background to use a solid color.

bool gslc_ElemSendEventTouch (gslc_tsGui *pGui, gslc_tsElem *pElemTracked, gslc_teTouch eTouch, int16 t nX, int16_t nY)

Trigger an element's touch event.

void gslc_ResetElem (gslc_tsElem *pElem)

Initialize an Element struct.

void gslc ResetFont (gslc tsFont *pFont)

Initialize a Font struct.

void gslc ElemDestruct (gslc tsElem *pElem)

Free up any members associated with an element.

void gslc_CollectDestruct (gslc_tsCollect *pCollect)

Free up any members associated with an element collection.

void gslc_PageDestruct (gslc_tsPage *pPage)

Free up any members associated with a page.

void gslc_GuiDestruct (gslc_tsGui *pGui)

Free up any surfaces associated with the GUI, pages, collections and elements.

void gslc_CollectReset (gslc_tsCollect *pCollect, gslc_tsElem *asElem, uint16_t nElemMax, gslc_tsElemRef
 *asElemRef, uint16_t nElemRefMax)

Reset the members of an element collection.

gslc_tsElem * gslc_CollectFindElemById (gslc_tsCollect *pCollect, int16_t nElemId)

Find an element in a collection by its Element ID.

int gslc_CollectGetNextId (gslc_tsCollect *pCollect)

Allocate the next available Element ID in a collection.

gslc_tsElem * gslc_CollectGetElemTracked (gslc_tsCollect *pCollect)

Get the element within a collection that is currently being tracked.

void gslc_CollectSetElemTracked (gslc_tsCollect *pCollect, gslc_tsElem *pElem)

Set the element within a collection that is currently being tracked.

• gslc_tsElem * gslc_CollectFindElemFromCoord (gslc_tsCollect *pCollect, int16_t nX, int16_t nY)

Find an element in a collection by a coordinate coordinate.

void gslc_CollectSetParent (gslc_tsCollect *pCollect, gslc_tsElem *pElemParent)

Assign the parent element reference to all elements within a collection.

• void gslc_CollectSetEventFunc (gslc_tsCollect *pCollect, GSLC_CB_EVENT funcCb)

Assign the event callback function for an element collection.

Variables

• GSLC_CB_DEBUG_OUT g_pfDebugOut = NULL

Global debug output function.

5.2.1 Macro Definition Documentation

5.2.1.1 #define GUISLICE_VER "0.8.5"

5.2.2 Function Documentation

5.2.2.1 bool gslc_ClipLine (gslc_tsRect * pClipRect, int16_t * pnX0, int16_t * pnY0, int16_t * pnX1, int16_t * pnX1)

Perform basic clipping of a line to a clipping region.

- · Implements Cohen-Sutherland algorithm
- · Coordinates in parameter list are modified to fit the region

Parameters

in	pClipRect	Pointer to clipping region
in,out	pnX0	Ptr to X coordinate of line start
in,out	pnY0	Ptr to Y coordinate of line start
in,out	pnX1	Ptr to X coordinate of line end
in,out	pnY1	Ptr to Y coordinate of line end

Returns

true if line is visible, false if it should be discarded

5.2.2.2 bool gslc_ClipPt (gslc_tsRect * pClipRect, int16_t nX, int16_t nY)

Perform basic clipping of a single point to a clipping region.

Parameters

in	pClipRect	Pointer to clipping region
in	nX	X coordinate of point
in	nY	Y coordinate of point

Returns

true if point is visible, false if it should be discarded

5.2.2.3 bool gslc_ClipRect (gslc_tsRect * pClipRect, gslc_tsRect * pRect)

Perform basic clipping of a rectangle to a clipping region.

• Coordinates in parameter rect are modified to fit the region

Parameters

in	pClipRect	Pointer to clipping region
in,out	pRect	Ptr to rectangle

Returns

true if rect is visible, false if it should be discarded

5.2.2.4 void gslc_CollectDestruct (gslc_tsCollect * pCollect)

Free up any members associated with an element collection.

Parameters

in	pCollect	Pointer to collection
----	----------	-----------------------

Returns

none

5.2.2.5 gslc_tsElem* gslc_CollectElemAdd (gslc_tsCollect * pCollect, const gslc_tsElem * pElem, gslc_teElemRefFlags eFlags)

Add an element to a collection.

• Note that the contents of pElem are copied to the collection's element array so the pElem pointer can be discarded are the call is complete.

Parameters

in	pCollect	Pointer to the collection
in	pElem	Ptr to the element to add

in	eFlags	Flags describing the element (eg. whether the element should be stored in
		internal RAM array or is located in Flash/PROGMEM).

Returns

Pointer to the element in the collection that has been added or NULL if there was an error

5.2.2.6 bool gslc_CollectEvent (void * pvGui, gslc_tsEvent sEvent)

Common event handler function for an element collection.

Parameters

in	pvGui	Void pointer to GUI
in	sEvent	Event data structure

Returns

true if success, false if fail

5.2.2.7 gslc_tsElem* gslc_CollectFindElemByld (gslc_tsCollect * pCollect, int16_t nElemId)

Find an element in a collection by its Element ID.

Parameters

in	pCollect	Pointer to the collection
in	nElemId	Element ID to search for

Returns

Pointer to the element in the collection that was found or NULL if no matches found

5.2.2.8 gslc_tsElem* gslc_CollectFindElemFromCoord (gslc_tsCollect * pCollect, int16_t nX, int16_t nY)

Find an element in a collection by a coordinate coordinate.

• A match is found if the element is "clickable" (bClickEn=true) and the coordinate falls within the element's bounds (rElem).

Parameters

in	pCollect	Pointer to the collection
in	nX	Absolute X coordinate to use for search
in	nY	Absolute Y coordinate to use for search

Returns

Pointer to the element in the collection that was found or NULL if no matches found

5.2.2.9 gslc_tsElem* gslc_CollectGetElemTracked (gslc_tsCollect * pCollect)

Get the element within a collection that is currently being tracked.

Parameters

in	pCollect	Pointer to the collection

Returns

Pointer to the element in the collection that is currently being tracked or NULL if no elements are being tracked

5.2.2.10 int gslc_CollectGetNextId (gslc_tsCollect * pCollect)

Allocate the next available Element ID in a collection.

Parameters

in	pCollect	Pointer to the collection
----	----------	---------------------------

Returns

Element ID that is reserved for use

5.2.2.11 bool gslc_CollectGetRedraw (gslc_tsCollect * pCollect)

Determine if any elements in a collection need redraw.

Parameters

in	pCollect	Pointer to Element collection
----	----------	-------------------------------

Returns

True if redraw required, false otherwise

5.2.2.12 void gslc_CollectReset (gslc_tsCollect * pCollect, gslc_tsElem * asElem, uint16_t nElemMax, gslc_tsElemRef * asElemRef, uint16_t nElemRefMax)

Reset the members of an element collection.

Parameters

in	pCollect	Pointer to the collection
in	asElem	Internal element array storage to associate with the collection
in	nElemMax	Maximum number of elements that can be added to the internal element array
		(ie. RAM))
in	asElemRef	Internal element reference array storage to associate with the collection. All
		elements, whether they are located in the internal element array or in external
		Flash (PROGMEM) storage, require an entry in the element reference array.
in	nElemRefMax	Maximum number of elements in the reference array. This is effectively the
		maximum number of elements that can appear in the collection, irrespective of
		whether it is stored in RAM or Flash (PROGMEM).

Returns

none

5.2.2.13 void gslc_CollectSetElemTracked (gslc_tsCollect * pCollect, gslc_tsElem * pElem)

Set the element within a collection that is currently being tracked.

Parameters

in	pCollect	Pointer to the collection
in	pElem	Ptr to element to mark as being tracked

Returns

none

5.2.2.14 void gslc_CollectSetEventFunc (gslc_tsCollect * pCollect, GSLC_CB_EVENT funcCb)

Assign the event callback function for an element collection.

Parameters

in	pCollect	Pointer to collection
in	funcCb	Function pointer to event routine (or NULL for default))

Returns

none

5.2.2.15 void gslc_CollectSetParent (gslc_tsCollect * pCollect, gslc_tsElem * pElemParent)

Assign the parent element reference to all elements within a collection.

• This is generally used in the case of compound elements where updates to a sub-element should cause the parent (compound element) to be redrawn as well.)

Parameters

in	pCollect	Pointer to the collection
in	pElemParent	Ptr to element that is the parent

Returns

none

5.2.2.16 void gslc_CollectTouch (gslc_tsGui * pGui, gslc_tsCollect * pCollect, gslc_tsEventTouch * pEventTouch)

Handle touch events within the element collection.

Parameters

in	pGui	Pointer to the GUI
in	pCollect	Ptr to the element collection
in	pEventTouch	Ptr to the touch event structure

Returns

none

5.2.2.17 void gslc_DebugPrintf (const char * pFmt, ...)

Optimized printf routine for GUIslice debug/error output.

- Only supports 's','d','u' tokens
- Calls on the output function configured in gslc_InitDebug()

Parameters

in	pFmt	Format string to use for printing
in		Variable parameter list

Returns

none

5.2.2.18 void gslc_DrawFillRect (gslc_tsGui * pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a filled rectangle.

Parameters

in	pGui	Pointer to GUI
in	rRect	Rectangular region to fill
in	nCol	Color RGB value to fill

Returns

none

5.2.2.19 void gslc_DrawFrameCircle (gslc_tsGui * pGui, int16_t nMidX, int16_t nMidY, uint16_t nRadius, gslc_tsColor nCol)

Draw a framed circle.

Parameters

in	pGui	Pointer to GUI
in	nMidX	Center X coordinate
in	nMidY	Center Y coordinate
in	nRadius	Radius of circle
in	nCol	Color RGB value for the frame

Returns

none

5.2.2.20 void gslc_DrawFrameRect ($gslc_tsGui*pGui, gslc_tsRect rRect, gslc_tsColor nCol$)

Draw a framed rectangle.

Parameters

in	pGui	Pointer to GUI
in	rRect	Rectangular region to frame
in	nCol	Color RGB value for the frame

Returns

none

5.2.2.21 void gslc_DrawLine (gslc_tsGui * pGui, int16_t nX0, int16_t nX1, int16_t nX1, int16_t nY1, gslc_tsColor nCol)

Draw an arbitrary line using Bresenham's algorithm.

Parameters

in	pGui	Pointer to GUI
in	nX0	X coordinate of line startpoint
in	nY0	Y coordinate of line startpoint
in	nX1	X coordinate of line endpoint
in	nY1	Y coordinate of line endpoint
in	nCol	Color RGB value for the line

Returns

none

5.2.2.22 void gslc_DrawLineH (gslc_tsGui * pGui, int16_t nX, int16_t nY, uint16_t nW, gslc_tsColor nCol)

Draw a horizontal line.

• Note that direction of line is in +ve X axis

Parameters

in	pGui	Pointer to GUI
in	nX	X coordinate of line startpoint
in	nY	Y coordinate of line startpoint
in	nW	Width of line (in +X direction)
in	nCol	Color RGB value for the line

Returns

none

5.2.2.23 void gslc_DrawLineV (gslc_tsGui * pGui, int16_t nX, int16_t nY, uint16_t nH, gslc_tsColor nCol)

Draw a vertical line.

· Note that direction of line is in +ve Y axis

Parameters

in	pGui	Pointer to GUI
in	nX	X coordinate of line startpoint
in	nY	Y coordinate of line startpoint
in	nH	Height of line (in +Y direction)
in	nCol	Color RGB value for the line

Returns

none

5.2.2.24 void gslc_DrawSetPixel ($gslc_tsGui*pGui$, int16_t nX, int16_t nY, $gslc_tsColor nCol$)

Set a pixel on the active screen to the given color with lock.

- Calls upon gslc_DrvDrawSetPixelRaw() but wraps with a surface lock lock
- If repeated access is needed, use gslc_DrvDrawSetPixelRaw() instead

Parameters

in	pGui	Pointer to GUI
in	nX	Pixel X coordinate to set
in	nY	Pixel Y coordinate to set
in	nCol	Color pixel value to assign

Returns

none

5.2.2.25 gslc_tsElem* gslc_ElemAdd (gslc_tsGui * pGui, int16_t nPageld, gslc_tsElem* pElem, gslc_teElemRefFlags eFlags)

Add the Element to the list of generated elements in the GUI environment.

• NOTE: The content of pElem is copied so the pointer can be released after the call.

Parameters

in	pGui	Pointer to GUI
in	nPageld	Page ID to add element to (GSLC_PAGE_NONE to skip in case of temporary
		creation for compound elements)
in	pElem	Pointer to Element to add
in	eFlags	Flags describing the element (eg. whether the element should be stored in
		internal RAM array or is located in Flash/PROGMEM).

Returns

Pointer to Element or NULL if fail

5.2.2.26 gslc_tsElem gslc_ElemCreate (gslc_tsGui * pGui, int16_t nElemId, int16_t nPageId, int16_t nType, gslc_tsRect rElem, char * pStrBuf, uint8_t nStrBufMax, int16_t nFontId)

Create a new element with default styling.

Parameters

in	pGui	Pointer to GUI
in	nElemId	User-supplied ID for referencing this element (or GSLC_ID_AUTO to auto-
		generate)
in	nPageld	The page ID on which this page should be associated
in	пТуре	Enumeration that indicates the type of element that is requested for creation.
		The type adjusts the visual representation and default styling.
in	rElem	Rectangle region framing the element
in	pStrBuf	String to copy into element
in	nStrBufMax	Maximum length of string buffer (pStrBuf). Only applicable if GSLC_LOCAL←
		_STR=0. Ignored if GSLC_LOCAL_STR=1.)
in	nFontId	Font ID for textual elements

Returns

Initialized structure

5.2.2.27 gslc_tsElem* gslc_ElemCreateBox (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem)

Create a Box Element.

· Draws a box with frame and fill

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	rElem	Rectangle coordinates defining box size

Returns

Pointer to the Element or NULL if failure

5.2.2.28 gslc_tsElem* gslc_ElemCreateBtnlmg (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem, gslc_tsImgRef sImgRef, gslc_tsImgRef sImgRefSel, GSLC_CB_TOUCH cbTouch)

Create a graphical Button Element.

- · Creates a clickable element that uses a BMP image with no frame or fill
- Transparency is supported by bitmap color (0xFF00FF)

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	rElem	Rectangle coordinates defining image size
in	sImgRef	Image reference to load (unselected state)
in	sImgRefSel	Image reference to load (selected state)
in	cbTouch	Callback for touch events

Returns

Pointer to the Element or NULL if failure

5.2.2.29 gslc_tsElem* gslc_ElemCreateBtnTxt (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem, char * pStrBuf, uint8_t nStrBufMax, int16_t nFontId, GSLC_CB_TOUCH cbTouch)

Create a textual Button Element.

· Creates a clickable element that has a textual label with frame and fill

Parameters

in	pGui	Pointer to GUI
	ρ σ.α.	· cilitar to citar

in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	rElem	Rectangle coordinates defining text background size
in	pStrBuf	String to copy into element
in	nStrBufMax	Maximum length of string buffer (pStrBuf). Only applicable if GSLC_LOCAL←
		_STR=0. Ignored if GSLC_LOCAL_STR=1.)
in	nFontId	Font ID to use for text display
in	cbTouch	Callback for touch events

Returns

Pointer to the Element or NULL if failure

5.2.2.30 gslc_tsElem* gslc_ElemCreateImg (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem, gslc_tsImgRef sImgRef)

Create an image Element.

· Draws an image

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	rElem	Rectangle coordinates defining box size
in	sImgRef	Image reference to load

Returns

Pointer to the Element or NULL if failure

5.2.2.31 gslc_tsElem* gslc_ElemCreateLine (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, int16_t nX0, int16_t nY0, int16_t nX1, int16_t nY1)

Create a Line Element.

· Draws a line with fill color

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	nX0	X coordinate of line startpoint
in	nY0	Y coordinate of line startpoint
in	nX1	X coordinate of line endpoint
in	nY1	Y coordinate of line endpoint

Returns

Pointer to the Element or NULL if failure

5.2.2.32 gslc_tsElem* gslc_ElemCreateTxt (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem, char * pStrBuf, uint8_t nStrBufMax, int16_t nFontId)

Create a Text Element.

· Draws a text string with filled background

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	rElem	Rectangle coordinates defining text background size
in	pStrBuf	String to copy into element
in	nStrBufMax	Maximum length of string buffer (pStrBuf). Only applicable if GSLC_LOCAL←
		_STR=0. Ignored if GSLC_LOCAL_STR=1.)
in	nFontld	Font ID to use for text display

Returns

Pointer to the Element or NULL if failure

5.2.2.33 void gslc_ElemDestruct (gslc_tsElem * pElem)

Free up any members associated with an element.

Parameters

- 1			
	in	pElem	Pointer to element

Returns

none

5.2.2.34 void gslc_ElemDraw (gslc_tsGui * pGui, int16_t nPageld, int16_t nElemId)

Draw an element to the active display.

· Element is referenced by a page ID and element ID

Parameters

in	pGui	Pointer to GUI
in	nPageId	ID of page containing element
in	nElemId	ID of element

Returns

none

5.2.2.35 bool gslc_ElemDrawByRef ($gslc_tsGui*pGui, gslc_tsElem*pElem$)

Draw an element to the active display.

· Element is referenced by an element pointer

Parameters

in	pGui	Pointer to GUI
in	pElem	Ptr to Element to draw

Returns

true if success, false otherwise

5.2.2.36 bool gslc_ElemEvent (void * pvGui, gslc_tsEvent sEvent)

Common event handler function for an element.

Parameters

in	pvGui	Void pointer to GUI
in	sEvent	Event data structure

Returns

true if success, false if fail

5.2.2.37 bool gslc_ElemGetGlow ($gslc_tsElem * pElem$)

Get the glowing indicator for an element.

Parameters

in	pElem	Pointer to Element

Returns

True if element is glowing

5.2.2.38 bool gslc_ElemGetGlowEn (gslc_tsElem * pElem)

Get the glowing enable for an element.

Parameters

in	pElem	Pointer to Element

Returns

True if element supports glowing

5.2.2.39 int gslc_ElemGetGroup ($gslc_tsElem*pElem*$)

Get the group ID for an element.

Parameters

in	pElem	Pointer to Element

Returns

Group ID or GSLC_GROUP_ID_NONE if unassigned

5.2.2.40 int gslc_ElemGetId (gslc_tsElem * pElem)

Get an Element ID from an element structure.

Parameters

in	pElem	Pointer to element structure

Returns

ID of element or GSLC ID NONE if not found

5.2.2.41 bool gslc_ElemGetRedraw (gslc_tsElem * pElem)

Get the need-redraw status for an element.

Parameters

in	pElem	Pointer to Element
----	-------	--------------------

Returns

True if redraw required, false otherwise

5.2.2.42 bool gslc_ElemOwnsCoord (gslc_tsElem * pElem, int16_t nX, int16_t nY, bool bOnlyClickEn)

Determine if a coordinate is inside of an element.

• This routine is useful in determining if a touch coordinate is inside of a button.

Parameters

in	pElem	Element used for boundary test
in	nX	X coordinate to test
in	nY	Y coordinate to test
in	bOnlyClickEn	Only output true if element was also marked as "clickable" (eg. bClickEn=true)

Returns

true if inside element, false otherwise

5.2.2.43 bool gslc_ElemSendEventTouch (gslc_tsGui * pGui, gslc_tsElem * pElemTracked, gslc_teTouch eTouch, int16_t nX, int16_t nY)

Trigger an element's touch event.

This is an optional behavior useful in some extended element types.

Parameters

in	pGui	Pointer to GUI
in	pElemTracked	Pointer to tracked Element (or NULL for none))
in	eTouch	Touch event type
in	nX	X coordinate of event (absolute coordinate)
in	nY	Y coordinate of event (absolute coordinate)

Returns

true if success, false if error

5.2.2.44 void gslc_ElemSetCol (gslc_tsElem * pElem, gslc_tsColor colFrame, gslc_tsColor colFill, gslc_tsColor colFillGlow)

Update the common color selection for an Element.

Parameters

in	pElem	Pointer to Element
in	colFrame	Color for the frame
in	colFill	Color for the fill
in	colFillGlow	Color for the fill when glowing

Returns

none

5.2.2.45 void gslc_ElemSetDrawFunc ($gslc_tsElem*pElem$, $GSLC_CB_DRAW$ funcCb)

Assign the drawing callback function for an element.

• This allows the user to override the default rendering for an element, enabling the creation of a custom element

Parameters

in	pElem	Pointer to Element
in	funcCb	Function pointer to drawing routine (or NULL for default))

Returns

none

5.2.2.46 void gslc_ElemSetEventFunc (gslc_tsElem * pElem, GSLC_CB_EVENT funcCb)

Assign the event callback function for a element.

Parameters

in	pElem	Pointer to element
----	-------	--------------------

in	funcCh	Function pointer to event routine (or NULL for default))
	1011000	i anotion pointer to event reating (or reception delically)

Returns

none

5.2.2.47 void gslc_ElemSetFillEn (gslc_tsElem * pElem, bool bFillEn)

Set the fill state for an Element.

Parameters

in	pElem	Pointer to Element
in	bFillEn	True if filled, false otherwise

Returns

none

5.2.2.48 void gslc_ElemSetFrameEn ($gslc_tsElem*pElem$, bool bFrameEn)

Set the frame state for an Element.

Parameters

in	pElem	Pointer to Element
in	bFrameEn	True if framed, false otherwise

Returns

none

5.2.2.49 void gslc_ElemSetGlow ($gslc_tsElem*pElem$, bool bGlowing)

Update the glowing indicator for an element.

Parameters

in	pElem	Pointer to Element
in	bGlowing	True if element is glowing

Returns

none

5.2.2.50 void gslc_ElemSetGlowCol (gslc_tsElem * pElem, gslc_tsColor colFrameGlow, gslc_tsColor colFillGlow, gslc_tsColor colTxtGlow)

Update the common color selection for glowing state of an Element.

Parameters

in	pElem	Pointer to Element
in	colFrameGlow	Color for the frame when glowing
in	colFillGlow	Color for the fill when glowing
in	colTxtGlow	Color for the text when glowing

Returns

none

5.2.2.51 void gslc_ElemSetGlowEn (gslc_tsElem * pElem, bool bGlowEn)

Update the glowing enable for an element.

Parameters

in	pElem	Pointer to Element
in	bGlowEn	True if element should support glowing

Returns

none

5.2.2.52 void gslc_ElemSetGroup ($gslc_tsElem*pElem$, int nGroupId)

Set the group ID for an element.

• Typically used to associate radio button elements together

Parameters

-	in	pElem	Pointer to Element
	in	nGroupId	Group ID to assign

Returns

none

5.2.2.53 void gslc_ElemSetImage (gslc_tsGui * pGui, gslc_tsElem * pElem, gslc_tsImgRef sImgRef, gslc_tsImgRef sImgRefSel)

Set an element to use a bitmap image.

Parameters

in	pGui	Pointer to GUI
in	pElem	Pointer to Element to update
in	sImgRef	Image reference (normal state)
in	sImgRefSel	Image reference (glowing state)

Returns

none

5.2.2.54 void gslc_ElemSetRedraw (gslc_tsElem * pElem, bool bRedraw)

Update the need-redraw status for an element.

Parameters

in	pElem	Pointer to Element
in	bRedraw	True if redraw required, false otherwise

Returns

none

5.2.2.55 void gslc_ElemSetStyleFrom (gslc_tsElem * pElemSrc, gslc_tsElem * pElemDest)

Copy style settings from one element to another.

Parameters

in	pElemSrc	Pointer to source Element
in	pElemDest	Pointer to destination Element

Returns

none

5.2.2.56 void gslc_ElemSetTickFunc (gslc_tsElem * pElem, GSLC_CB_TICK funcCb)

Assign the tick callback function for an element.

• This allows the user to provide background updates to an element triggered by the main loop call to gslc_← Update()

Parameters

in	pElem	Pointer to Element
in	funcCb	Function pointer to tick routine (or NULL for none))

Returns

none

5.2.2.57 void gslc_ElemSetTxtAlign ($gslc_tsElem*pElem*, unsigned* nAlign*)$

Set the alignment of a textual element (horizontal and vertical)

Parameters

in	pElem	Pointer to Element
in	nAlign	Alignment to specify:
		GSLC_ALIGN_TOP_LEFT
		GSLC_ALIGN_TOP_MID
		GSLC_ALIGN_TOP_RIGHT
		GSLC_ALIGN_MID_LEFT
		GSLC_ALIGN_MID_MID
		GSLC_ALIGN_MID_RIGHT
		GSLC_ALIGN_BOT_LEFT
		GSLC_ALIGN_BOT_MID
		GSLC_ALIGN_BOT_RIGHT

Returns

none

 $\textbf{5.2.2.58} \quad \text{void gslc_ElemSetTxtCol (} \quad \textbf{gslc_tsElem} * \textit{pElem,} \quad \textbf{gslc_tsColor} \; \textit{colVal} \; \textbf{)}$

Update the text string color associated with an Element ID.

Parameters

in	pElem	Pointer to Element
in	colVal	RGB color to change to

Returns

none

5.2.2.59 void gslc_ElemSetTxtMargin ($gslc_tsElem*pElem$, unsigned nMargin)

Set the margin around of a textual element.

Parameters

in	pElem	Pointer to Element

1	in	nMargin	Number of pixels gap to leave surrounding text
		a. g	i tambor or pinore gap to real or arraning tone

Returns

none

 $5.2.2.60 \quad \text{void gslc_ElemSetTxtMem (} \textbf{gslc_tsElem} * \textbf{pElem}, \textbf{gslc_teTxtFlags} \textit{eFlags} \textbf{)}$

Update the text string location in memory.

Parameters

in	pElem	Pointer to Element
in	eFlags	Flags associated with text memory location (GSLC_TXT_MEM_*)

Returns

none

5.2.2.61 void gslc_ElemSetTxtStr (gslc_tsElem * pElem, const char * pStr)

Update the text string associated with an Element ID.

Parameters

in	pElem	Pointer to Element
in	pStr	String to copy into element

Returns

none

5.2.2.62 void gslc_ElemUpdateFont (gslc_tsGui * pGui, gslc_tsElem * pElem, int nFontId)

Update the Font selected for an Element's text.

Parameters

in	pGui	Pointer to GUI
in	pElem	Pointer to Element
in	nFontld	Font ID to select

Returns

none

5.2.2.63 gslc_tsEvent gslc_EventCreate (gslc_teEventType eType, uint8_t nSubType, void * pvScope, void * pvData)

Create an event structure.

Parameters

in	еТуре	Event type (draw, touch, tick, etc.)
in	nSubType	Refinement of event type (or 0 if unused)
in	pvScope	Void ptr to object receiving event so that the event handler will have the context
in	pvData	Void ptr to additional data associated with the event (eg. coordinates for touch
		events)

Returns

None

5.2.2.64 gslc_tsRect gslc_ExpandRect (gslc_tsRect rRect, int16_t nExpandW, int16_t nExpandH)

Expand or contract a rectangle in width and/or height (equal amounts on both side), based on the centerpoint of the rectangle.

Parameters

in	rRect	Rectangular region before resizing
in	nExpandW	Number of pixels to expand the width (if positive) of contract the width (if neg-
		ative)
in	nExpandH	Number of pixels to expand the height (if positive) of contract the height (if
		negative)

Returns

gslc_tsRect() with resized dimensions

5.2.2.65 bool gslc_FontAdd (gslc_tsGui * pGui, int16_t nFontId, const char * acFontName, uint16_t nFontSz)

Load a font into the local font cache and assign font ID (nFontId).

Parameters

in	pGui	Pointer to GUI
in	nFontld	ID to use when referencing this font
in	acFontName	Filename path to the font
in	nFontSz	Typeface size to use

Returns

true if load was successful, false otherwise

5.2.2.66 gslc_tsFont* gslc_FontGet (gslc_tsGui * pGui, int16_t nFontId)

Fetch a font from its ID value.

Parameters

in	pGui	Pointer to GUI
in	nFontId	ID value used to reference the font (supplied originally to gslc_FontAdd()

Returns

A pointer to the font structure or NULL if error

 $5.2.2.67 \quad gslc_tslmgRef \ gslc_GetlmageFromFile \ (\ const \ char * pFname, \ gslc_telmgRefFlags \ eFmt \)$

Create an image reference to a bitmap file in LINUX filesystem.

Parameters

in	pFname	Pointer to filename string of image in filesystem
in	eFmt	Image format

Returns

Loaded image reference

 $5.2.2.68 \quad gslc_tslmgRef \ gslc_detlmageFromProg \ (\ const \ unsigned \ char * \textit{plmgBuf}, \ gslc_telmgRefFlags \ \textit{eFmt} \)$

Create an image reference to a bitmap in program memory (PROGMEM)

Parameters

in	pImgBuf	Pointer to image buffer in memory
in	eFmt	Image format

Returns

Loaded image reference

5.2.2.69 gslc_tslmgRef gslc_GetlmageFromRam (unsigned char * plmgBuf, gslc_telmgRefFlags eFmt)

Create an image reference to a bitmap in SRAM.

Parameters

in	pImgBuf	Pointer to image buffer in memory
in	eFmt	Image format

Returns

Loaded image reference

5.2.2.70 gslc_tslmgRef gslc_GetlmageFromSD (const char * pFname, gslc_telmgRefFlags eFmt)

Create an image reference to a bitmap file in SD card.

Parameters

in	pFname	Pointer to filename string of image in SD card
in	eFmt	Image format

Returns

Loaded image reference

5.2.2.71 int gslc_GetPageCur (gslc_tsGui * pGui)

Fetch the current page ID.

Parameters

in	pGui	Pointer to GUI

Returns

Page ID

5.2.2.72 bool gslc_GetTouch ($gslc_tsGui*pGui$, $int16_t*pnX$, $int16_t*pnY$, $uint16_t*pnPress$)

Initialize the touchscreen device driver.

Parameters

in	pGui	Pointer to GUI
out	pnX	Ptr to int to contain latest touch X coordinate
out	pnY	Ptr to int to contain latest touch Y coordinate
out	pnPress	Ptr to int to contain latest touch pressure value

Returns

true if touch event, false otherwise

5.2.2.73 char* gslc_GetVer (gslc_tsGui * pGui)

Get the GUIslice version number.

Returns

String containing version number

5.2.2.74 void gslc_GuiDestruct ($gslc_tsGui*pGui$)

Free up any surfaces associated with the GUI, pages, collections and elements.

Also frees up any fonts.

Called by gslc_Quit()

Parameters

in	pGui	Pointer to GUI
----	------	----------------

Returns

none

5.2.2.75 bool gslc_lnit (gslc_tsGui * pGui, void * pvDriver, gslc_tsPage * asPage, uint8_t nMaxPage, gslc_tsFont * asFont, uint8_t nMaxFont)

Initialize the GUIslice library.

- Configures the primary screen surface(s)
- · Initializes font support

PRE:

• The environment variables should be configured before calling gslc_Init().

Parameters

in	pGui	Pointer to GUI			
in	pvDriver	oid pointer to Driver struct (gslc_tsDriver*)			
in	asPage	Pointer to Page array			
in	nMaxPage	Size of Page array			
in	asFont	Pointer to Font array			
in	nMaxFont	Size of Font array			

Returns

true if success, false if fail

5.2.2.76 void gslc_InitDebug (GSLC_CB_DEBUG_OUT pfunc)

Initialize debug output.

- Defines the user function used for debug/error output
- pfunc is responsible for outputing a single character
- For Arduino, this user function would typically call Serial.print()

Parameters

in	pfunc	Pointer to user character-out function
----	-------	--

Returns

none

5.2.2.77 bool gslc_lnitTouch (gslc_tsGui * pGui, const char * acDev)

Initialize the touchscreen device driver.

Parameters

in	pGui	Pointer t	o GUI								
in	acDev	Device	path	to	touchscreen	(or	""	if	not	applicable))	eg.
		"/dev/inp	"/dev/input/touchscreen"								

Returns

true if successful

5.2.2.78 bool gslc_lslnRect (int16_t nSelX, int16_t nSelY, gslc_tsRect rRect)

Determine if a coordinate is inside of a rectangular region.

• This routine is useful in determining if a touch coordinate is inside of a button.

Parameters

in	nSelX	X coordinate to test
in	nSelY	X coordinate to test
in	rRect	Rectangular region to compare against

Returns

true if inside region, false otherwise

5.2.2.79 bool gslc_lslnWH (gslc_tsGui * pGui, int16_t nSelX, int16_t nSelY, uint16_t nWidth, uint16_t nHeight)

Determine if a coordinate is inside of a width x height region.

• This routine is useful in determining if a relative coordinate is within a given W x H dimension

Parameters

in	pGui	Pointer to GUI
in	nSelX	X coordinate to test
in	nSelY	X coordinate to test
in	nWidth	Width to test against
in	nHeight	Height to test against

Returns

true if inside region, false otherwise

```
5.2.2.80 void gslc_OrderCoord ( int16_t * pnX0, int16_t * pnY0, int16_t * pnX1, int16_t * pnY1 )
```

5.2.2.81 void gslc_PageAdd (gslc_tsGui * pGui, int16_t nPageId, gslc_tsElem * psElem, uint16_t nMaxElem, gslc_tsElemRef * psElemRef, uint16_t nMaxElemRef)

Add a page to the GUI.

- · This call associates an element array with the collection within the page
- Once a page has been added to the GUI, elements can be added to the page by specifying the same page ID

Parameters

in	pGui	Pointer to GUI
in	nPageld	Page ID to assign
in	psElem	Internal element array storage to associate with the page
in	nMaxElem	Maximum number of elements that can be added to the internal element array
		(ie. RAM))
in	psElemRef	Internal element reference array storage to associate with the page. All elements, whether they are located in the internal element array or in external Flash (PROGMEM) storage, require an entry in the element reference array.

in	nMaxElemRef	Maximum number of elements in the reference array. This is effectively the
		maximum number of elements that can appear on a page, irrespective of
		whether it is stored in RAM or Flash (PROGMEM).

Returns

none

5.2.2.82 void gslc_PageDestruct (gslc_tsPage * pPage)

Free up any members associated with a page.

Parameters

in	pPage	Pointer to Page

Returns

none

5.2.2.83 bool gslc_PageEvent (void * pvGui, gslc_tsEvent sEvent)

Common event handler function for a page.

Parameters

in	pvGui	Void pointer to GUI
in	sEvent	Event data structure

Returns

true if success, false if fail

5.2.2.84 gslc_tsPage* gslc_PageFindByld (gslc_tsGui * pGui, int16_t nPageld)

Find a page in the GUI by its ID.

Parameters

in	pGui	Pointer to GUI
in	nPageId	Page ID to search

Returns

Ptr to a page or NULL if none found

 $5.2.2.85 \quad \textbf{gslc_tsElem} * \textbf{gslc_PageFindElemByld (} \ \textbf{gslc_tsGui} * \textbf{\textit{pGui}}, \ \textbf{int16_t} \ \textbf{\textit{nPageId}}, \ \textbf{int16_t} \ \textbf{\textit{nElemId}})$

Find an element in the GUI by its Page ID and Element ID.

Parameters

in	pGui	Pointer to GUI
in	nPageld	Page ID to search
in	nElemId	Element ID to search

Returns

Ptr to an element or NULL if none found

5.2.2.86 bool gslc_PageFlipGet (gslc_tsGui * pGui)

Get state of pending page flip state.

Parameters

in	pGui	Pointer to GUI

Returns

True if screen requires page flip

5.2.2.87 void gslc_PageFlipGo (gslc_tsGui * pGui)

Update the visible screen if page has been marked for flipping.

• On some hardware this can trigger a double-buffering page flip.

Parameters

in	pGui	Pointer to GUI

Returns

None

5.2.2.88 void gslc_PageFlipSet (gslc_tsGui * pGui, bool bNeeded)

Indicate whether the screen requires page flip.

• This is generally called with bNeeded=true whenever drawing has been done to the active page. Page flip is actually performed later when calling PageFlipGo().

Parameters

in	pGui	Pointer to GUI
in	bNeeded	True if screen requires page flip

Returns

None

5.2.2.89 void gslc_PageRedrawCalc (gslc_tsGui * pGui)

Perform a redraw calculation on the page to determine if additional elements should also be redrawn.

This routine checks to see if any transparent elements have been marked as needing redraw. If so, the whole page may be marked as needing redraw (or at least the other elements that have been exposed underneath).

Parameters

in	pGui	Pointer to GUI

Returns

none

5.2.2.90 bool gslc_PageRedrawGet (gslc_tsGui * pGui)

Get the need-redraw status for the current page.

Parameters

in	pGui	Pointer to GUI

Returns

True if redraw required, false otherwise

5.2.2.91 void gslc_PageRedrawGo (gslc_tsGui * pGui)

Redraw all elements on the active page.

Only the elements that have been marked as needing redraw are rendered unless the entire page has been marked as needing redraw (in which case everything is drawn)

Parameters

in	pGui	Pointer to GUI

Returns

none

5.2.2.92 void gslc_PageRedrawSet (gslc_tsGui * pGui, bool bRedraw)

Update the need-redraw status for the current page.

Parameters

in	pGui	Pointer to GUI
in	bRedraw	True if redraw required, false otherwise

Returns

none

5.2.2.93 void gslc_PageSetEventFunc (gslc_tsPage * pPage, GSLC_CB_EVENT funcCb)

Assign the event callback function for a page.

Parameters

in	pPage	Pointer to page
in	funcCb	Function pointer to event routine (or NULL for default))

Returns

none

5.2.2.94 void gslc_Quit (gslc_tsGui * pGui)

Exit the GUIslice environment.

• Calls lower-level destructors to clean up any initialized subsystems and deletes any created elements or fonts

Parameters

_			
	in	pGui	Pointer to GUI

Returns

None

5.2.2.95 void gslc_ResetElem (gslc_tsElem * pElem)

Initialize an Element struct.

Parameters

in	pElem	Pointer to Element

Returns

none

5.2.2.96 void gslc_ResetFont (gslc_tsFont * pFont)

Initialize a Font struct.

Parameters

in	pFont	Pointer to Font

Returns

none

5.2.2.97 gslc_tslmgRef gslc_ResetImage ()

Create a blank image reference structure.

Returns

Image reference struct

5.2.2.98 bool gslc_SetBkgndColor (gslc_tsGui * pGui, gslc_tsColor nCol)

Configure the background to use a solid color.

• The background is used when redrawing the entire page

Parameters

in	pGui	Pointer to GUI
in	nCol	RGB Color to use

Returns

true if success, false if fail

5.2.2.99 bool gslc_SetBkgndlmage (gslc_tsGui * pGui, gslc_tslmgRef slmgRef)

Configure the background to use a bitmap image.

• The background is used when redrawing the entire page

Parameters

in	pGui	Pointer to GUI
in	sImgRef	Image reference

Returns

true if success, false if fail

5.2.2.100 bool gslc_SetClipRect ($gslc_tsGui * pGui$, $gslc_tsRect * pRect$)

Set the clipping rectangle for further drawing.

Parameters

in	pGui	Pointer to GUI
in	pRect	Pointer to Rect for clipping (or NULL for entire screen)

Returns

true if success, false if error

5.2.2.101 void gslc_SetPageCur (gslc_tsGui * pGui, int16_t nPageId)

Select a new page for display.

Parameters

in	pGui	Pointer to GUI

in	nPageId	Page ID to select as current	
----	---------	------------------------------	--

Returns

none

5.2.2.102 void gslc_TrackTouch ($gslc_tsGui*pGui*, gslc_tsPage*pPage*, int16_t nX*, int16_t nY*, uint16_t nPress*)$

Handles a touch event and performs the necessary tracking, glowing and selection actions depending on the press state.

Parameters

in	pGui	Pointer to GUI
in	pPage	Pointer to current page
in	nX	X coordinate of touch event
in	nY	Y coordinate of touch event
in	nPress	Pressure level of touch event (0 for none, else touch)

Returns

none

5.2.2.103 void gslc_Update (gslc_tsGui * pGui)

Perform main GUIslice handling functions.

- · Handles any touch events
- · Performs any necessary screen redraw

Parameters

in	pGui	Pointer to GUI

Returns

None

5.2.3 Variable Documentation

5.2.3.1 GSLC_CB_DEBUG_OUT g_pfDebugOut = NULL


Global debug output function.

• The user assigns this function via gslc_InitDebug()


5.3 src/GUIslice.h File Reference

```
#include <stdio.h>
#include <stdlib.h>
#include <stdbool.h>
#include <string.h>
#include <inttypes.h>
#include "GUIslice_config.h"
```

Include dependency graph for GUIslice.h:



This graph shows which files directly or indirectly include this file:



Classes

struct gslc_tsRect

Rectangular region. Defines X,Y corner coordinates plus dimensions.

struct gslc_tsPt

Define point coordinates.

struct gslc_tsColor

Color structure. Defines RGB triplet.

struct gslc_tsEvent

Event structure.

struct gslc_tsEventTouch

Structure used to pass touch data through event.

struct gslc_tsFont

Font reference structure.

struct gslc_tslmgRef

Image reference structure.

struct gslc_tsElem

Element Struct.

struct gslc_tsElemRef

Element reference structure.

struct gslc_tsCollect

Element collection struct.

struct gslc_tsPage

Page structure.

• struct gslc_tsGui

GUI structure.

Macros

• #define GSLC_ALIGNV_TOP 0x10

Vertical align to top.

• #define GSLC_ALIGNV_MID 0x20

Vertical align to middle.

#define GSLC_ALIGNV_BOT 0x40

Vertical align to bottom.

• #define GSLC_ALIGNH_LEFT 0x01

Horizontal align to left.

#define GSLC_ALIGNH_MID 0x02

Horizontal align to middle.

#define GSLC_ALIGNH_RIGHT 0x04

Horizontal align to right.

- #define GSLC_ALIGN_TOP_LEFT GSLC_ALIGNH_LEFT | GSLC_ALIGNV_TOP
 Align to top-left.
- #define GSLC_ALIGN_TOP_MID GSLC_ALIGNH_MID | GSLC_ALIGNV_TOP
 Align to middle of top.
- #define GSLC_ALIGN_TOP_RIGHT GSLC_ALIGNH_RIGHT | GSLC_ALIGNV_TOP
 Align to top-right.
- #define GSLC_ALIGN_MID_LEFT GSLC_ALIGNH_LEFT | GSLC_ALIGNV_MID Align to middle of left side.
- #define GSLC_ALIGN_MID_MID GSLC_ALIGNH_MID | GSLC_ALIGNV_MID Align to center.
- #define GSLC_ALIGN_MID_RIGHT GSLC_ALIGNH_RIGHT | GSLC_ALIGNV_MID Align to middle of right side.
- #define GSLC_ALIGN_BOT_LEFT GSLC_ALIGNH_LEFT | GSLC_ALIGNV_BOT Align to bottom-left.
- #define GSLC_ALIGN_BOT_MID GSLC_ALIGNH_MID | GSLC_ALIGNV_BOT Align to middle of bottom.
- #define GSLC_ALIGN_BOT_RIGHT GSLC_ALIGNH_RIGHT | GSLC_ALIGNV_BOT Align to bottom-right.
- #define GSLC_COL_RED_DK4 (gslc_tsColor) {128, 0, 0}

Red (dark4)

#define GSLC_COL_RED_DK3 (gslc_tsColor) {160, 0, 0}

Red (dark3)

#define GSLC_COL_RED_DK2 (gslc_tsColor) {192, 0, 0}

Red (dark2)

#define GSLC_COL_RED_DK1 (gslc_tsColor) {224, 0, 0}

Red (dark1)

#define GSLC_COL_RED (gslc_tsColor) {255, 0, 0}

Red.

#define GSLC_COL_RED_LT1 (gslc_tsColor) {255, 32, 32}

Red (light1)

#define GSLC_COL_RED_LT2 (gslc_tsColor) {255, 64, 64}

Red (light2)

```
#define GSLC_COL_RED_LT3 (gslc_tsColor) {255, 96, 96}
     Red (light3)
#define GSLC COL RED LT4 (gslc tsColor) {255,128,128}
     Red (light4)
#define GSLC_COL_GREEN_DK4 (gslc_tsColor) { 0,128, 0}
     Green (dark4)
• #define GSLC_COL_GREEN_DK3 (gslc_tsColor) { 0,160, 0}
     Green (dark3)
#define GSLC_COL_GREEN_DK2 (gslc_tsColor) { 0,192, 0}
     Green (dark2)
• #define GSLC COL GREEN DK1 (gslc tsColor) { 0,224, 0}
     Green (dark1)

    #define GSLC_COL_GREEN (gslc_tsColor) { 0,255, 0}

     Green.
#define GSLC_COL_GREEN_LT1 (gslc_tsColor) { 32,255, 32}
     Green (light1)
#define GSLC_COL_GREEN_LT2 (gslc_tsColor) { 64,255, 64}
     Green (light2)
#define GSLC_COL_GREEN_LT3 (gslc_tsColor) { 96,255, 96}
     Green (light3)
#define GSLC_COL_GREEN_LT4 (gslc_tsColor) {128,255,128}
     Green (light4)
#define GSLC_COL_BLUE_DK4 (gslc_tsColor) { 0, 0,128}
     Blue (dark4)
#define GSLC_COL_BLUE_DK3 (gslc_tsColor) { 0, 0,160}
     Blue (dark3)
#define GSLC_COL_BLUE_DK2 (gslc_tsColor) { 0, 0,192}
     Blue (dark2)
• #define GSLC_COL_BLUE_DK1 (gslc_tsColor) { 0, 0,224}
     Blue (dark1)
#define GSLC_COL_BLUE (gslc_tsColor) { 0, 0,255}
     Blue.
#define GSLC_COL_BLUE_LT1 (gslc_tsColor) { 32, 32,255}
     Blue (light1)
#define GSLC_COL_BLUE_LT2 (gslc_tsColor) { 64, 64,255}
     Blue (light2)
#define GSLC COL BLUE LT3 (gslc tsColor) { 96, 96,255}
     Blue (light3)
#define GSLC_COL_BLUE_LT4 (gslc_tsColor) {128,128,255}
     Blue (light4)
• #define GSLC_COL_BLACK (gslc_tsColor) { 0, 0, 0}
#define GSLC_COL_GRAY_DK3 (gslc_tsColor) { 32, 32, 32}
     Gray (dark)
#define GSLC_COL_GRAY_DK2 (gslc_tsColor) { 64, 64, 64}
     Gray (dark)
#define GSLC_COL_GRAY_DK1 (gslc_tsColor) { 96, 96, 96}
     Gray (dark)

    #define GSLC COL GRAY (gslc tsColor) {128,128,128}
```

#define GSLC_COL_GRAY_LT1 (gslc_tsColor) {160,160,160}

Gray (light1)

#define GSLC_COL_GRAY_LT2 (gslc_tsColor) {192,192,192}

Gray (light2)

• #define GSLC COL GRAY LT3 (gslc tsColor) {224,224,224}

Gray (light3)

#define GSLC_COL_WHITE (gslc_tsColor) {255,255,255}

White

#define GSLC COL YELLOW (gslc tsColor) {255,255,0}

Yellow

#define GSLC_COL_YELLOW_DK (gslc_tsColor) {64,64,0}

Yellow (dark)

• #define GSLC_COL_PURPLE (gslc_tsColor) {128,0,128}

Purple.

#define GSLC_COL_CYAN (gslc_tsColor) {0,255,255}

Cvan.

#define GSLC COL MAGENTA (gslc tsColor) {255,0,255}

Magenta.

#define GSLC_COL_TEAL (gslc_tsColor) {0,128,128}

Teal

#define GSLC_COL_ORANGE (gslc_tsColor) {255,165,0}

Orange.

#define GSLC_COL_BROWN (gslc_tsColor) {165,42,42}

Brown.

#define GSLC_DEBUG_PRINT(sFmt,...)

Macro to enable optional debug output.

#define gslc_ElemCreateTxt_P(pGui, nElemId, nPage, nX, nY, nW, nH, strTxt, pFont, colTxt, colFrame, col
 Fill, nAlignTxt, bFrameEn, bFillEn)

Create a read-only text element.

• #define gslc_ElemCreateBox_P(pGui, nElemId, nPage, nX, nY, nW, nH, colFrame, colFill, bFrameEn, bFillEn)

Create a read-only box element.

Typedefs

- typedef int16_t(* GSLC_CB_DEBUG_OUT)(char ch)
- typedef struct gslc_tsElem gslc_tsElem

Element Struct.

• typedef struct gslc_tsEvent gslc_tsEvent

Event structure.

typedef bool(* GSLC_CB_EVENT)(void *pvGui, gslc_tsEvent sEvent)

Callback function for element drawing.

typedef bool(* GSLC CB DRAW)(void *pvGui, void *pvElem)

Callback function for element drawing.

typedef bool(* GSLC_CB_TOUCH)(void *pvGui, void *pvElem, gslc_teTouch eTouch, int16_t nX, int16_t nY)

Callback function for element touch tracking.

typedef bool(* GSLC_CB_TICK)(void *pvGui, void *pvElem)

Callback function for element tick.

typedef struct gslc tsRect gslc tsRect

Rectangular region. Defines X,Y corner coordinates plus dimensions.

typedef struct gslc_tsPt gslc_tsPt

Define point coordinates.

```
    typedef struct gslc_tsColor gslc_tsColor

        Color structure. Defines RGB triplet.

    typedef struct gslc_tsEventTouch gslc_tsEventTouch

        Structure used to pass touch data through event.
Enumerations
   enum gslc_teElemId {
     GSLC_ID_USER_BASE = 0, GSLC_ID_NONE = -1999, GSLC_ID_AUTO, GSLC_ID_TEMP,
     GSLC ID AUTO BASE = 16384 }
        Element ID enumerations.

    enum gslc tePageId { GSLC PAGE USER BASE = 0, GSLC PAGE NONE = -2999 }

        Page ID enumerations.

    enum gslc teGroupId { GSLC GROUP ID USER BASE = 0, GSLC GROUP ID NONE = -6999 }

        Group ID enumerations.
   • enum gslc_teFontId { GSLC_FONT_USER_BASE = 0, GSLC_FONT_NONE = -4999 }
        Font ID enumerations.

    enum gslc teElemInd { GSLC IND NONE = -9999, GSLC IND FIRST = 0 }

        Element Index enumerations.
   enum gslc_teTypeCore {
     GSLC_TYPE_NONE, GSLC_TYPE_BKGND, GSLC_TYPE_BTN, GSLC_TYPE_TXT,
     GSLC TYPE BOX, GSLC TYPE LINE, GSLC TYPE BASE EXTEND = 0x1000 }
        Flement type.

    enum gslc teTouch {

     GSLC TOUCH NONE = 0, GSLC TOUCH DOWN = (1 << 4), GSLC TOUCH MOVE = (1 << 5), GSLC \leftrightarrow
     TOUCH UP = (1 << 6),
     GSLC_TOUCH_IN = (1<<0), GSLC_TOUCH_OUT = (1<<1), GSLC_TOUCH_INOUT_MASK = GSLC_←
     TOUCH_IN | GSLC_TOUCH_OUT, GSLC_TOUCH_DOWN_IN = GSLC_TOUCH_DOWN | GSLC_TOUC
     H IN,
     GSLC TOUCH MOVE IN = GSLC TOUCH MOVE | GSLC TOUCH IN, GSLC TOUCH MOVE OUT =
     GSLC_TOUCH_MOVE | GSLC_TOUCH_OUT, GSLC_TOUCH_UP_IN = GSLC_TOUCH_UP | GSLC_TO⊷
     UCH IN, GSLC TOUCH UP OUT = GSLC TOUCH UP | GSLC TOUCH OUT }
        Touch event type for element touch tracking.

    enum gslc teEventType {

     GSLC_EVT_NONE, GSLC_EVT_DRAW, GSLC_EVT_TOUCH, GSLC_EVT_TICK,
     GSLV_EVT_CUSTOM }
        Event types.

    enum gslc teEventSubType { GSLC EVTSUB NONE, GSLC EVTSUB DRAW NEEDED, GSLC EVTS⇔

     UB DRAW FORCE }
        Event sub-types.

    enum gslc teElemRefFlags { GSLC ELEMREF NONE = 0, GSLC ELEMREF SRC RAM = (1<<0), GS↔</li>

     LC_ELEMREF_SRC_PROG = (2<<0), GSLC_ELEMREF_SRC = (7<<0) }
        Element reference flags: Describes characteristics of an element.

    enum gslc telmgRefFlags {

     GSLC_IMGREF_NONE = 0, GSLC_IMGREF_SRC_FILE = (1<<0), GSLC_IMGREF_SRC_SD = (2<<0),
     GSLC_IMGREF_SRC_RAM = (3 << 0),
     GSLC_IMGREF_SRC_PROG = (4 << 0), GSLC_IMGREF_FMT_BMP24 = (1 << 4), GSLC_IMGREF_FM\leftrightarrow
     T_BMP16 = (2 << 4), GSLC_IMGREF_FMT_RAW1 = (3 << 4),
     GSLC_IMGREF_SRC = (7 << 0), GSLC_IMGREF_FMT = (7 << 4)
```

Image reference flags: Describes characteristics of an image reference.

_TXT_DEFAULT = GSLC_TXT_MEM_RAM | GSLC_TXT_ALLOC_NONE }

GSLC TXT MEM RAM = (0 << 0), GSLC TXT MEM PROG = (1 << 0), GSLC TXT ALLOC NONE =

 $GSLC_TXT_ALLOC_EXT = (2 << 2), GSLC_TXT_MEM = (3 << 0), GSLC_TXT_ALLOC = (3 << 2), GSLC_TXT_ALLOC = (3 << 0), GSLC_TXT_ALLOC =$

enum gslc teTxtFlags {

(0 << 2), GSLC TXT ALLOC INT = (1 << 2),

Text reference flags: Describes the characteristics of a text string (ie.

enum gslc_teDebugPrintState { GSLC_DEBUG_PRINT_NORM, GSLC_DEBUG_PRINT_TOKEN, GSLC_
DEBUG_PRINT_UINT16, GSLC_DEBUG_PRINT_STR }

Functions

char * gslc GetVer (gslc tsGui *pGui)

Get the GUIslice version number.

bool gslc_Init (gslc_tsGui *pGui, void *pvDriver, gslc_tsPage *asPage, uint8_t nMaxPage, gslc_tsFont *as←
 Font, uint8_t nMaxFont)

Initialize the GUIslice library.

void gslc InitDebug (GSLC CB DEBUG OUT pfunc)

Initialize debug output.

• void gslc_DebugPrintf (const char *pFmt,...)

Optimized printf routine for GUIslice debug/error output.

void gslc_Quit (gslc_tsGui *pGui)

Exit the GUIslice environment.

void gslc_Update (gslc_tsGui *pGui)

Perform main GUIslice handling functions.

- gslc_tsEvent gslc_EventCreate (gslc_teEventType eType, uint8_t nSubType, void *pvScope, void *pvData)

 Create an event structure.
- bool gslc IsInRect (int16 t nSelX, int16 t nSelY, gslc tsRect rRect)

Determine if a coordinate is inside of a rectangular region.

gslc_tsRect gslc_ExpandRect (gslc_tsRect rRect, int16_t nExpandW, int16_t nExpandH)

Expand or contract a rectangle in width and/or height (equal amounts on both side), based on the centerpoint of the rectangle.

bool gslc_lslnWH (gslc_tsGui *pGui, int16_t nSelX, int16_t nSelY, uint16_t nWidth, uint16_t nHeight)

Determine if a coordinate is inside of a width x height region.

bool gslc_ClipPt (gslc_tsRect *pClipRect, int16_t nX, int16_t nY)

Perform basic clipping of a single point to a clipping region.

bool gslc_ClipLine (gslc_tsRect *pClipRect, int16_t *pnX0, int16_t *pnY0, int16_t *pnX1, int16_t *pnY1)

Perform basic clipping of a line to a clipping region.

bool gslc_ClipRect (gslc_tsRect *pClipRect, gslc_tsRect *pRect)

Perform basic clipping of a rectangle to a clipping region.

gslc_tslmgRef gslc_ResetImage ()

Create a blank image reference structure.

• gslc_tslmgRef gslc_GetImageFromFile (const char *pFname, gslc_teImgRefFlags eFmt)

Create an image reference to a bitmap file in LINUX filesystem.

gslc_tslmgRef gslc_GetImageFromSD (const char *pFname, gslc_teImgRefFlags eFmt)

Create an image reference to a bitmap file in SD card.

gslc_tslmgRef gslc_GetImageFromRam (unsigned char *pImgBuf, gslc_teImgRefFlags eFmt)

Create an image reference to a bitmap in SRAM.

gslc_tslmgRef gslc_GetImageFromProg (const unsigned char *pImgBuf, gslc_teImgRefFlags eFmt)

Create an image reference to a bitmap in program memory (PROGMEM)

void gslc DrawSetPixel (gslc tsGui *pGui, int16 t nX, int16 t nY, gslc tsColor nCol)

Set a pixel on the active screen to the given color with lock.

Draw an arbitrary line using Bresenham's algorithm.

- $\bullet \ \ void\ gslc_DrawLine\ (gslc_tsGui\ *pGui,\ int16_t\ nX0,\ int16_t\ nY0,\ int16_t\ nX1,\ int16_t\ nY1,\ gslc_tsColor\ nCol)$
- void gslc DrawLineH (gslc tsGui *pGui, int16 t nX, int16 t nY, uint16 t nW, gslc tsColor nCol)

Draw a horizontal line.

• void gslc_DrawLineV (gslc_tsGui *pGui, int16_t nX, int16_t nY, uint16_t nH, gslc_tsColor nCol)

Draw a vertical line.

void gslc_DrawFrameRect (gslc_tsGui *pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a framed rectangle.

void gslc_DrawFillRect (gslc_tsGui *pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a filled rectangle.

void gslc_DrawFrameCircle (gslc_tsGui *pGui, int16_t nMidX, int16_t nMidY, uint16_t nRadius, gslc_tsColor nCol)

Draw a framed circle.

bool gslc_FontAdd (gslc_tsGui *pGui, int16_t nFontId, const char *acFontName, uint16_t nFontSz)

Load a font into the local font cache and assign font ID (nFontId).

gslc_tsFont * gslc_FontGet (gslc_tsGui *pGui, int16_t nFontId)

Fetch a font from its ID value.

bool gslc_PageEvent (void *pvGui, gslc_tsEvent sEvent)

Common event handler function for a page.

• void gslc_PageSetEventFunc (gslc_tsPage *pPage, GSLC_CB_EVENT funcCb)

Assign the event callback function for a page.

int gslc_GetPageCur (gslc_tsGui *pGui)

Fetch the current page ID.

void gslc_SetPageCur (gslc_tsGui *pGui, int16_t nPageId)

Select a new page for display.

void gslc_PageRedrawSet (gslc_tsGui *pGui, bool bRedraw)

Update the need-redraw status for the current page.

bool gslc_PageRedrawGet (gslc_tsGui *pGui)

Get the need-redraw status for the current page.

void gslc PageRedrawGo (gslc tsGui *pGui)

Redraw all elements on the active page.

void gslc_PageFlipSet (gslc_tsGui *pGui, bool bNeeded)

Indicate whether the screen requires page flip.

• bool gslc_PageFlipGet (gslc_tsGui *pGui)

Get state of pending page flip state.

void gslc_PageFlipGo (gslc_tsGui *pGui)

Update the visible screen if page has been marked for flipping.

void gslc_PageAdd (gslc_tsGui *pGui, int16_t nPageId, gslc_tsElem *psElem, uint16_t nMaxElem, gslc_ts
 ElemRef *psElemRef, uint16 t nMaxElemRef)

Add a page to the GUI.

• gslc_tsPage * gslc_PageFindByld (gslc_tsGui *pGui, int16_t nPageId)

Find a page in the GUI by its ID.

gslc_tsElem * gslc_PageFindElemByld (gslc_tsGui *pGui, int16_t nPageId, int16_t nElemId)

Find an element in the GUI by its Page ID and Element ID.

void gslc PageRedrawCalc (gslc tsGui *pGui)

Perform a redraw calculation on the page to determine if additional elements should also be redrawn.

 gslc_tsElem * gslc_ElemCreateTxt (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem, char *pStrBuf, uint8_t nStrBufMax, int16_t nFontId)

Create a Text Element.

• gslc_tsElem * gslc_ElemCreateBtnTxt (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem, char *pStrBuf, uint8_t nStrBufMax, int16_t nFontId, GSLC_CB_TOUCH cbTouch)

Create a textual Button Element.

gslc_tsElem * gslc_ElemCreateBtnImg (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, gslc_tsRect r←
 Elem, gslc_tsImgRef sImgRef, gslc_tsImgRef sImgRefSel, GSLC_CB_TOUCH cbTouch)

Create a graphical Button Element.

• gslc_tsElem * gslc_ElemCreateBox (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem)

Create a Box Element.

gslc_tsElem * gslc_ElemCreateLine (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, int16_t nX0, int16_t nY0, int16_t nX1, int16_t nY1)

Create a Line Element.

 gslc_tsElem * gslc_ElemCreateImg (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem, gslc_tsImgRef sImgRef)

Create an image Element.

int gslc_ElemGetId (gslc_tsElem *pElem)

Get an Element ID from an element structure.

void gslc_ElemSetFillEn (gslc_tsElem *pElem, bool bFillEn)

Set the fill state for an Element.

void gslc ElemSetFrameEn (gslc tsElem *pElem, bool bFrameEn)

Set the frame state for an Element.

 void gslc_ElemSetCol (gslc_tsElem *pElem, gslc_tsColor colFrame, gslc_tsColor colFill, gslc_tsColor col← FillGlow)

Update the common color selection for an Element.

void gslc_ElemSetGlowCol (gslc_tsElem *pElem, gslc_tsColor colFrameGlow, gslc_tsColor colFillGlow, gslc tsColor colTxtGlow)

Update the common color selection for glowing state of an Element.

void gslc_ElemSetGroup (gslc_tsElem *pElem, int nGroupId)

Set the group ID for an element.

int gslc_ElemGetGroup (gslc_tsElem *pElem)

Get the group ID for an element.

void gslc_ElemSetTxtAlign (gslc_tsElem *pElem, unsigned nAlign)

Set the alignment of a textual element (horizontal and vertical)

void gslc_ElemSetTxtMargin (gslc_tsElem *pElem, unsigned nMargin)

Set the margin around of a textual element.

void gslc ElemSetTxtStr (gslc tsElem *pElem, const char *pStr)

Update the text string associated with an Element ID.

void gslc_ElemSetTxtCol (gslc_tsElem *pElem, gslc_tsColor colVal)

Update the text string color associated with an Element ID.

void gslc_ElemSetTxtMem (gslc_tsElem *pElem, gslc_teTxtFlags eFlags)

Update the text string location in memory.

void gslc_ElemUpdateFont (gslc_tsGui *pGui, gslc_tsElem *pElem, int nFontId)

Update the Font selected for an Element's text.

void gslc_ElemSetRedraw (gslc_tsElem *pElem, bool bRedraw)

Update the need-redraw status for an element.

bool gslc_ElemGetRedraw (gslc_tsElem *pElem)

Get the need-redraw status for an element.

void gslc ElemSetGlowEn (gslc tsElem *pElem, bool bGlowEn)

Update the glowing enable for an element.

• void gslc_ElemSetStyleFrom (gslc_tsElem *pElemSrc, gslc_tsElem *pElemDest)

Copy style settings from one element to another.

bool gslc_ElemGetGlowEn (gslc_tsElem *pElem)

Get the glowing enable for an element.

void gslc ElemSetGlow (gslc tsElem *pElem, bool bGlowing)

Update the glowing indicator for an element.

bool gslc_ElemGetGlow (gslc_tsElem *pElem)

Get the glowing indicator for an element.

• void gslc_ElemSetEventFunc (gslc_tsElem *pElem, GSLC_CB_EVENT funcCb)

Assign the event callback function for a element.

• void gslc_ElemSetDrawFunc (gslc_tsElem *pElem, GSLC_CB_DRAW funcCb)

Assign the drawing callback function for an element.

void gslc_ElemSetTickFunc (gslc_tsElem *pElem, GSLC_CB_TICK funcCb)

Assign the tick callback function for an element.

bool gslc_ElemOwnsCoord (gslc_tsElem *pElem, int16_t nX, int16_t nY, bool bOnlyClickEn)

Determine if a coordinate is inside of an element.

bool gslc_ElemEvent (void *pvGui, gslc_tsEvent sEvent)

Common event handler function for an element.

void gslc_ElemDraw (gslc_tsGui *pGui, int16_t nPageId, int16_t nElemId)

Draw an element to the active display.

void gslc_CollectReset (gslc_tsCollect *pCollect, gslc_tsElem *asElem, uint16_t nElemMax, gslc_tsElemRef
 *asElemRef, uint16_t nElemRefMax)

Reset the members of an element collection.

Add an element to a collection.

bool gslc CollectGetRedraw (gslc tsCollect *pCollect)

Determine if any elements in a collection need redraw.

gslc_tsElem * gslc_CollectFindElemById (gslc_tsCollect *pCollect, int16_t nElemId)

Find an element in a collection by its Element ID.

gslc_tsElem * gslc_CollectFindElemFromCoord (gslc_tsCollect *pCollect, int16_t nX), int16_t nY)

Find an element in a collection by a coordinate coordinate.

int gslc CollectGetNextId (gslc tsCollect *pCollect)

Allocate the next available Element ID in a collection.

gslc_tsElem * gslc_CollectGetElemTracked (gslc_tsCollect *pCollect)

Get the element within a collection that is currently being tracked.

void gslc_CollectSetElemTracked (gslc_tsCollect *pCollect, gslc_tsElem *pElem)

Set the element within a collection that is currently being tracked.

void gslc_CollectSetParent (gslc_tsCollect *pCollect, gslc_tsElem *pElemParent)

Assign the parent element reference to all elements within a collection.

• void gslc_CollectSetEventFunc (gslc_tsCollect *pCollect, GSLC_CB_EVENT funcCb)

Assign the event callback function for an element collection.

bool gslc CollectEvent (void *pvGui, gslc tsEvent sEvent)

Common event handler function for an element collection.

void gslc_CollectTouch (gslc_tsGui *pGui, gslc_tsCollect *pCollect, gslc_tsEventTouch *pEventTouch)

Handle touch events within the element collection.

void gslc TrackTouch (gslc tsGui *pGui, gslc tsPage *pPage, int16 t nX, int16 t nY, uint16 t nPress)

Handles a touch event and performs the necessary tracking, glowing and selection actions depending on the press

bool gslc_InitTouch (gslc_tsGui *pGui, const char *acDev)

Initialize the touchscreen device driver.

• bool gslc_GetTouch (gslc_tsGui *pGui, int16_t *pnX, int16_t *pnY, uint16_t *pnPress)

Initialize the touchscreen device driver.

gslc_tsElem gslc_ElemCreate (gslc_tsGui *pGui, int16_t nElemId, int16_t nPageId, int16_t nType, gslc_ts
 — Rect rElem, char *pStrBuf, uint8_t nStrBufMax, int16_t nFontId)

Create a new element with default styling.

gslc_tsElem * gslc_ElemAdd (gslc_tsGui *pGui, int16_t nPageId, gslc_tsElem *pElem, gslc_teElemRefFlags eFlags)

Add the Element to the list of generated elements in the GUI environment.

• bool gslc_SetClipRect (gslc_tsGui *pGui, gslc_tsRect *pRect)

Set the clipping rectangle for further drawing.

void gslc_ElemSetImage (gslc_tsGui *pGui, gslc_tsElem *pElem, gslc_tsImgRef sImgRef, gslc_tsImgRef sImgRef, gslc_tsImgRef

Set an element to use a bitmap image.

bool gslc_SetBkgndImage (gslc_tsGui *pGui, gslc_tsImgRef sImgRef)

Configure the background to use a bitmap image.

bool gslc_SetBkgndColor (gslc_tsGui *pGui, gslc_tsColor nCol)

Configure the background to use a solid color.

bool gslc_ElemDrawByRef (gslc_tsGui *pGui, gslc_tsElem *pElem)

Draw an element to the active display.

void gslc_GuiDestruct (gslc_tsGui *pGui)

Free up any surfaces associated with the GUI, pages, collections and elements.

void gslc_PageDestruct (gslc_tsPage *pPage)

Free up any members associated with a page.

void gslc_CollectDestruct (gslc_tsCollect *pCollect)

Free up any members associated with an element collection.

void gslc_ElemDestruct (gslc_tsElem *pElem)

Free up any members associated with an element.

bool gslc_ElemSendEventTouch (gslc_tsGui *pGui, gslc_tsElem *pElemTracked, gslc_teTouch eTouch, int16 t nX, int16 t nY)

Trigger an element's touch event.

void gslc_ResetFont (gslc_tsFont *pFont)

Initialize a Font struct.

void gslc_ResetElem (gslc_tsElem *pElem)

Initialize an Element struct.

Variables

GSLC_CB_DEBUG_OUT g_pfDebugOut

Global debug output function.

5.3.1 Macro Definition Documentation

5.3.1.1 #define GSLC_ALIGN_BOT_LEFT GSLC_ALIGNH_LEFT | GSLC_ALIGNV_BOT

Align to bottom-left.

5.3.1.2 #define GSLC_ALIGN_BOT_MID GSLC_ALIGNH_MID | GSLC_ALIGNV_BOT

Align to middle of bottom.

5.3.1.3 #define GSLC_ALIGN_BOT_RIGHT GSLC_ALIGNH_RIGHT | GSLC_ALIGNV_BOT

Align to bottom-right.

5.3.1.4 #define GSLC_ALIGN_MID_LEFT GSLC_ALIGNH_LEFT | GSLC_ALIGNV_MID

Align to middle of left side.

5.3.1.5 #define GSLC_ALIGN_MID_MID GSLC_ALIGNH_MID | GSLC_ALIGNV_MID

Align to center.

#define GSLC_ALIGN_MID_RIGHT GSLC_ALIGNH_RIGHT | GSLC_ALIGNV_MID Align to middle of right side. 5.3.1.7 #define GSLC_ALIGN_TOP_LEFT GSLC_ALIGNH_LEFT | GSLC_ALIGNV_TOP Align to top-left. 5.3.1.8 #define GSLC_ALIGN_TOP_MID GSLC_ALIGNH_MID | GSLC_ALIGNV_TOP Align to middle of top. 5.3.1.9 #define GSLC_ALIGN_TOP_RIGHT GSLC_ALIGNH_RIGHT | GSLC_ALIGNV_TOP Align to top-right. 5.3.1.10 #define GSLC_ALIGNH_LEFT 0x01 Horizontal align to left. 5.3.1.11 #define GSLC_ALIGNH_MID 0x02 Horizontal align to middle. 5.3.1.12 #define GSLC_ALIGNH_RIGHT 0x04 Horizontal align to right. 5.3.1.13 #define GSLC_ALIGNV_BOT 0x40 Vertical align to bottom. 5.3.1.14 #define GSLC_ALIGNV_MID 0x20 Vertical align to middle. 5.3.1.15 #define GSLC_ALIGNV_TOP 0x10 Vertical align to top. 5.3.1.16 #define GSLC_COL_BLACK (gslc_tsColor) { 0, 0, 0} Black.

5.3.1.17 #define GSLC_COL_BLUE (gslc_tsColor) { 0, 0,255}

Blue.

Generated on Mon Mar 13 2017 23:10:39 for GUIslice by Doxygen

```
5.3.1.18 #define GSLC_COL_BLUE_DK1 (gslc_tsColor) { 0, 0,224}
Blue (dark1)
5.3.1.19 #define GSLC_COL_BLUE_DK2 (gslc_tsColor) { 0, 0,192}
Blue (dark2)
5.3.1.20 #define GSLC_COL_BLUE_DK3 (gslc_tsColor) { 0, 0,160}
Blue (dark3)
5.3.1.21 #define GSLC_COL_BLUE_DK4 (gslc_tsColor) { 0, 0,128}
Blue (dark4)
5.3.1.22 #define GSLC_COL_BLUE_LT1 (gslc_tsColor) { 32, 32,255}
Blue (light1)
5.3.1.23 #define GSLC_COL_BLUE_LT2 (gslc_tsColor) { 64, 64,255}
Blue (light2)
5.3.1.24 #define GSLC_COL_BLUE_LT3 (gslc_tsColor) { 96, 96,255}
Blue (light3)
5.3.1.25 #define GSLC_COL_BLUE_LT4 (gslc_tsColor) {128,128,255}
Blue (light4)
5.3.1.26 #define GSLC_COL_BROWN (gslc_tsColor) {165,42,42}
Brown.
5.3.1.27 #define GSLC_COL_CYAN (gslc_tsColor) {0,255,255}
Cyan.
5.3.1.28 #define GSLC_COL_GRAY (gslc_tsColor) {128,128,128}
Gray.
5.3.1.29 #define GSLC_COL_GRAY_DK1 (gslc_tsColor) { 96, 96, 96}
Gray (dark)
```

```
5.3.1.30 #define GSLC_COL_GRAY_DK2 (gslc_tsColor) { 64, 64, 64}
Gray (dark)
5.3.1.31 #define GSLC_COL_GRAY_DK3 (gslc_tsColor) { 32, 32, 32}
Gray (dark)
5.3.1.32 #define GSLC_COL_GRAY_LT1 (gslc_tsColor) {160,160,160}
Gray (light1)
5.3.1.33 #define GSLC_COL_GRAY_LT2 (gslc_tsColor) {192,192,192}
Gray (light2)
5.3.1.34 #define GSLC_COL_GRAY_LT3 (gslc_tsColor) {224,224,224}
Gray (light3)
5.3.1.35 #define GSLC_COL_GREEN (gslc_tsColor) { 0,255, 0}
Green.
5.3.1.36 #define GSLC_COL_GREEN_DK1 (gslc_tsColor) { 0,224, 0}
Green (dark1)
5.3.1.37 #define GSLC_COL_GREEN_DK2 (gslc_tsColor) { 0,192, 0}
Green (dark2)
5.3.1.38 #define GSLC_COL_GREEN_DK3 (gslc_tsColor) { 0,160, 0}
Green (dark3)
5.3.1.39 #define GSLC_COL_GREEN_DK4 (gslc_tsColor) { 0,128, 0}
Green (dark4)
5.3.1.40 #define GSLC_COL_GREEN_LT1 (gslc_tsColor) { 32,255, 32}
Green (light1)
5.3.1.41 #define GSLC_COL_GREEN_LT2 (gslc_tsColor) { 64,255, 64}
Green (light2)
```

```
5.3.1.42 #define GSLC_COL_GREEN_LT3 (gslc_tsColor) { 96,255, 96}
Green (light3)
5.3.1.43 #define GSLC_COL_GREEN_LT4 (gslc_tsColor) {128,255,128}
Green (light4)
5.3.1.44 #define GSLC_COL_MAGENTA (gslc_tsColor) {255,0,255}
Magenta.
5.3.1.45 #define GSLC_COL_ORANGE (gslc_tsColor) {255,165,0}
Orange.
5.3.1.46 #define GSLC_COL_PURPLE (gslc_tsColor) {128,0,128}
Purple.
5.3.1.47 #define GSLC_COL_RED (gslc_tsColor) {255, 0, 0}
Red.
5.3.1.48 #define GSLC_COL_RED_DK1 (gslc_tsColor) {224, 0, 0}
Red (dark1)
5.3.1.49 #define GSLC_COL_RED_DK2 (gslc_tsColor) {192, 0, 0}
Red (dark2)
5.3.1.50 #define GSLC_COL_RED_DK3 (gslc_tsColor) {160, 0, 0}
Red (dark3)
5.3.1.51 #define GSLC_COL_RED_DK4 (gslc_tsColor) {128, 0, 0}
Red (dark4)
5.3.1.52 #define GSLC_COL_RED_LT1 (gslc_tsColor) {255, 32, 32}
Red (light1)
5.3.1.53 #define GSLC_COL_RED_LT2 (gslc_tsColor) {255, 64, 64}
Red (light2)
```

```
5.3.1.54 #define GSLC_COL_RED_LT3 (gslc_tsColor) {255, 96, 96}
Red (light3)
5.3.1.55 #define GSLC_COL_RED_LT4 (gslc_tsColor) {255,128,128}
Red (light4)
5.3.1.56 #define GSLC_COL_TEAL (gslc_tsColor) {0,128,128}
Teal.
        #define GSLC_COL_WHITE (gslc_tsColor) {255,255,255}
5.3.1.57
White.
5.3.1.58
        #define GSLC_COL_YELLOW (gslc_tsColor) {255,255,0}
Yellow.
5.3.1.59 #define GSLC_COL_YELLOW_DK (gslc_tsColor) {64,64,0}
Yellow (dark)
5.3.1.60 #define GSLC_DEBUG_PRINT( sFmt, ... )
Value:
            if (DEBUG_ERR) {
              gslc_DebugPrintf(sFmt,__VA_ARGS__);
          } while (0)
```

Macro to enable optional debug output.

- Supports printf formatting via gslc_DebugPrintf()
- · Supports storing the format string in PROGMEM
- Note that at least one variable argument must be provided to the macro after the format string. This is a limitation of the macro definition. If no parameters are needed, then simply pass 0. For example: GSLC_D← EBUG_PRINT("Loaded OK",0);

Parameters

in	sFmt	Format string for debug message

5.3.1.61 #define gslc_ElemCreateBox_P(pGui, nElemId, nPage, nX, nY, nW, nH, colFrame, colFill, bFrameEn, bFillEn

Value:

```
static const gslc_tsElem sElem##nElemId = {
        nElemId,
        true,
        GSLC_TYPE_BOX,
        (gslc_tsRect) {nX,nY,nW,nH},
GSLC_GROUP_ID_NONE, false, false, bFrameEn, bFillEn,
colFrame, colFill, GSLC_COL_BLACK, GSLC_COL_BLACK,
(gslc_tsImgRef) {NULL, NULL, GSLC_IMGREF_NONE, NULL},
         (gslc_tsImgRef) {NULL, NULL, GSLC_IMGREF_NONE, NULL},
        NULL,
        NULL,
        Ο,
        GSLC_TXT_DEFAULT,
        GSLC_COL_WHITE,
        GSLC COL WHITE.
        GSLC_ALIGN_MID_MID,
        NULL,
        NULL,
        NULL,
        NULL,
        NULL,
        NULL,
        false,
        false,
   gslc_ElemAdd(pGui,nPage,(gslc_tsElem*)&sElem##nElemId,
        GSLC_ELEMREF_SRC_RAM);
```

Create a read-only box element.

Parameters

in	pGui	Pointer to GUI
in	nElemId	Unique element ID to assign
in	nPage	Page ID to attach element to
in	nX	X coordinate of element
in	nY	Y coordinate of element
in	nW	Width of element
in	nH	Height of element
in	colFrame	Color for the frame
in	colFill	Color for the fill
in	bFrameEn	True if framed, false otherwise
in	bFillEn	True if filled, false otherwise

5.3.1.62 #define gslc_ElemCreateTxt_P(pGui, nElemId, nPage, nX, nY, nW, nH, strTxt, pFont, colTxt, colFrame, colFill, nAlignTxt, bFrameEn, bFillEn)

Value:

```
static const char str##nElemId[] = strTxt;
   static const gslc_tsElem sElem##nElemId = {
         nElemId,
          true,
          GSLC_TYPE_TXT,
         (gslc_tsRect) {nX,nY,nW,nH},
GSLC_GROUP_ID_NONE, false, false, bFrameEn, bFillEn,
colFrame, colFill, GSLC_COL_BLACK, GSLC_COL_BLACK,
(gslc_tsImgRef) {NULL, NULL, GSLC_IMGREF_NONE, NULL},
(gslc_tsImgRef) {NULL, NULL, GSLC_IMGREF_NONE, NULL},
          NULL.
          (char*) str##nElemId,
          0,
          (gslc_teTxtFlags) (GSLC_TXT_MEM_RAM |
          GSLC_TXT_ALLOC_EXT),
          colTxt,
          colTxt,
          nAlignTxt,
          Ο,
          pFont,
          NULL,
```

```
NULL,
NULL,
NULL,
NULL,
NULL,
false,
false,
};
gslc_ElemAdd(pGui,nPage,(gslc_tsElem*)&sElem##nElemId,
GSLC_ELEMREF_SRC_RAM);
```

Create a read-only text element.

Parameters

in	pGui	Pointer to GUI
in	nElemId	Unique element ID to assign
in	nPage	Page ID to attach element to
in	nX	X coordinate of element
in	nY	Y coordinate of element
in	nW	Width of element
in	nH	Height of element
in	strTxt	Text string to display
in	pFont	Pointer to font resource
in	colTxt	Color for the text
in	colFrame	Color for the frame
in	colFill	Color for the fill
in	nAlignTxt	Text alignment
in	bFrameEn	True if framed, false otherwise
in	bFillEn	True if filled, false otherwise

5.3.2 Typedef Documentation

5.3.2.1 typedef int16_t(* GSLC_CB_DEBUG_OUT)(char ch)

5.3.2.2 typedef bool(* GSLC_CB_DRAW)(void *pvGui, void *pvElem)

Callback function for element drawing.

5.3.2.3 typedef bool(* GSLC_CB_EVENT)(void *pvGui, gslc_tsEvent sEvent)

Callback function for element drawing.

5.3.2.4 typedef bool(* GSLC_CB_TICK)(void *pvGui, void *pvElem)

Callback function for element tick.

5.3.2.5 typedef bool(* GSLC_CB_TOUCH)(void *pvGui, void *pvElem, gslc_teTouch eTouch, int16_t nX, int16_t nY)

Callback function for element touch tracking.

5.3.2.6 typedef struct gslc_tsColor gslc_tsColor

Color structure. Defines RGB triplet.

5.3.2.7 typedef struct gslc_tsElem gslc_tsElem

Element Struct.

- · Represents a single graphic element in the GUIslice environment
- · A page is made up of a number of elements
- Each element is created with a user-specified ID for further accesses (or GSLC_ID_AUTO for it to be autogenerated)
- · Display order of elements in a page is based upon the creation order
- Extensions to the core element types is provided through the pXData reference and pfuncX* callback functions.

5.3.2.8 typedef struct gslc_tsEvent gslc_tsEvent

Event structure.

5.3.2.9 typedef struct gslc_tsEventTouch gslc_tsEventTouch

Structure used to pass touch data through event.

5.3.2.10 typedef struct gslc_tsPt gslc_tsPt

Define point coordinates.

5.3.2.11 typedef struct gslc_tsRect gslc_tsRect

Rectangular region. Defines X,Y corner coordinates plus dimensions.

- 5.3.3 Enumeration Type Documentation
- 5.3.3.1 enum gslc_teDebugPrintState

Enumerator

GSLC_DEBUG_PRINT_NORM
GSLC_DEBUG_PRINT_TOKEN
GSLC_DEBUG_PRINT_UINT16
GSLC_DEBUG_PRINT_STR

5.3.3.2 enum gslc_teElemId

Element ID enumerations.

- The Element ID is the primary means for user code to reference a graphic element.
- Application code can assign arbitrary Element ID values in the range of 0...16383
- Specifying GSLC_ID_AUTO to ElemCreate() requests that GUIslice auto-assign an ID value for the Element.
 These auto-assigned values will begin at GSLC_ID_AUTO_BASE.

· Negative Element ID values are reserved

Enumerator

GSLC_ID_USER_BASE Starting Element ID for user assignments.

GSLC_ID_NONE No Element ID has been assigned.

GSLC_ID_AUTO Auto-assigned Element ID requested.

GSLC_ID_TEMP ID for Temporary Element.

GSLC_ID_AUTO_BASE Starting Element ID to start auto-assignment (when GSLC_ID_AUTO is specified)

5.3.3.3 enum gslc_teElemInd

Element Index enumerations.

· The Element Index is used for internal purposes as an offset

Enumerator

GSLC_IND_NONE No Element Index is available.

GSLC_IND_FIRST User elements start at index 0.

5.3.3.4 enum gslc_teElemRefFlags

Element reference flags: Describes characteristics of an element.

· Primarily used to support relocation of elements to Flash memory (PROGMEM)

Enumerator

GSLC_ELEMREF_NONE No element defined.

GSLC_ELEMREF_SRC_RAM Element is stored in RAM (internal element array)

GSLC_ELEMREF_SRC_PROG Element is stored in program memory (PROGMEM, read-only, external to element array)

GSLC_ELEMREF_SRC Mask for Source flags.

5.3.3.5 enum gslc_teEventSubType

Event sub-types.

Enumerator

GSLC_EVTSUB_NONE

GSLC_EVTSUB_DRAW_NEEDED

GSLC_EVTSUB_DRAW_FORCE

5.3.3.6 enum gslc_teEventType

Event types.

Enumerator

```
GSLC_EVT_NONE No event; ignore.

GSLC_EVT_DRAW Perform redraw.

GSLC_EVT_TOUCH Track touch event.

GSLC_EVT_TICK Perform background tick handling.

GSLV_EVT_CUSTOM Custom event.
```

5.3.3.7 enum gslc_teFontId

Font ID enumerations.

- The Font ID is the primary means for user code to reference a specific font.
- · Application code can assign arbitrary Font ID values in the range of 0...16383
- · Negative Font ID values are reserved

Enumerator

```
GSLC_FONT_USER_BASE Starting Font ID for user assignments. GSLC_FONT_NONE No Font ID has been assigned.
```

5.3.3.8 enum gslc_teGroupId

Group ID enumerations.

Enumerator

```
GSLC_GROUP_ID_USER_BASE Starting Group ID for user assignments. GSLC_GROUP_ID_NONE No Group ID has been assigned.
```

5.3.3.9 enum gslc_telmgRefFlags

Image reference flags: Describes characteristics of an image reference.

Enumerator

```
GSLC_IMGREF_NONE No image defined.

GSLC_IMGREF_SRC_FILE Image is stored in file system.

GSLC_IMGREF_SRC_SD Image is stored on SD card.

GSLC_IMGREF_SRC_RAM Image is stored in RAM.

GSLC_IMGREF_SRC_PROG Image is stored in program memory (PROGMEM)

GSLC_IMGREF_FMT_BMP24 Image format is BMP (24-bit)

GSLC_IMGREF_FMT_BMP16 Image format is BMP (16-bit RGB565)

GSLC_IMGREF_FMT_RAW1 Image format is raw monochrome (1-bit)

GSLC_IMGREF_SRC Mask for Source flags.

GSLC_IMGREF_FMT Mask for Format flags.
```

5.3.3.10 enum gslc_tePageId

Page ID enumerations.

- The Page ID is the primary means for user code to reference a specific page of elements.
- Application code can assign arbitrary Page ID values in the range of 0...16383
- · Negative Page ID values are reserved

Enumerator

```
GSLC_PAGE_USER_BASE Starting Page ID for user assignments. GSLC_PAGE_NONE No Page ID has been assigned.
```

```
5.3.3.11 enum gslc_teTouch
```

Touch event type for element touch tracking.

Enumerator

```
GSLC_TOUCH_NONE No touch event active.
```

GSLC_TOUCH_DOWN Touch event (down)

GSLC_TOUCH_MOVE Touch event (move)

GSLC_TOUCH_UP Touch event (up)

GSLC_TOUCH_IN Touch event inside element.

GSLC_TOUCH_OUT Touch event outside element.

GSLC_TOUCH_INOUT_MASK Mask for in/out state.

GSLC_TOUCH_DOWN_IN Touch down inside element (start tracking)

GSLC_TOUCH_MOVE_IN Touch move inside tracked element.

GSLC_TOUCH_MOVE_OUT Touch move outside tracked element.

GSLC_TOUCH_UP_IN Touch up inside tracked element.

GSLC_TOUCH_UP_OUT Touch up outside tracked element.

5.3.3.12 enum gslc_teTxtFlags

Text reference flags: Describes the characteristics of a text string (ie.

whether internal to element or external and RAM vs Flash).)

Supported flag combinations are:

- ALLOC_NONE
- ALLOC_INT | MEM_RAM
- · ALLOC EXT | MEM RAM
- ALLOC_EXT | MEM_PROG

Enumerator

```
GSLC_TXT_MEM_RAM Text string is in SRAM (read-write)

GSLC_TXT_MEM_PROG Text string is in PROGMEM (read-only)
```

GSLC_TXT_ALLOC_NONE No text string present.

GSLC_TXT_ALLOC_INT Text string allocated in internal element memory (GSLC_STR_LOCAL=1)

GSLC_TXT_ALLOC_EXT Text string allocated in external memory (GSLC_STR_LOCAL=0), ie. user code.

GSLC_TXT_MEM Mask for updating text memory type.

GSLC_TXT_ALLOC Mask for updating location of text string buffer allocation.

GSLC_TXT_DEFAULT

5.3.3.13 enum gslc_teTypeCore

Element type.

Enumerator

GSLC_TYPE_NONE No element type specified.

GSLC_TYPE_BKGND Background element type.

GSLC_TYPE_BTN Button element type.

GSLC_TYPE_TXT Text label element type.

GSLC_TYPE_BOX Box / frame element type.

GSLC_TYPE_LINE Line element type.

GSLC_TYPE_BASE_EXTEND Base value for extended type enumerations.

5.3.4 Function Documentation

5.3.4.1 bool gslc_ClipLine (gslc_tsRect * pClipRect, int16_t * pnX0, int16_t * pnY0, int16_t * pnX1, int16_t * pnX1)

Perform basic clipping of a line to a clipping region.

- · Implements Cohen-Sutherland algorithm
- · Coordinates in parameter list are modified to fit the region

Parameters

in	pClipRect	Pointer to clipping region
in,out	pnX0	Ptr to X coordinate of line start
in,out	pnY0	Ptr to Y coordinate of line start
in,out	pnX1	Ptr to X coordinate of line end
in,out	pnY1	Ptr to Y coordinate of line end

Returns

true if line is visible, false if it should be discarded

5.3.4.2 bool gslc_ClipPt (gslc_tsRect * pClipRect, int16_t nX, int16_t nY)

Perform basic clipping of a single point to a clipping region.

in	pClipRect	Pointer to clipping region
in	nX	X coordinate of point
in	nY	Y coordinate of point

Returns

true if point is visible, false if it should be discarded

5.3.4.3 bool gslc_ClipRect (gslc_tsRect * pClipRect, gslc_tsRect * pRect)

Perform basic clipping of a rectangle to a clipping region.

• Coordinates in parameter rect are modified to fit the region

Parameters

in	pClipRect	Pointer to clipping region
in,out	pRect	Ptr to rectangle

Returns

true if rect is visible, false if it should be discarded

5.3.4.4 void gslc_CollectDestruct (gslc_tsCollect * pCollect)

Free up any members associated with an element collection.

Parameters

in	pCollect	Pointer to collection
----	----------	-----------------------

Returns

none

5.3.4.5 gslc_tsElem* gslc_CollectElemAdd (gslc_tsCollect * pCollect, const gslc_tsElem * pElem, gslc_teElemRefFlags eFlags)

Add an element to a collection.

• Note that the contents of pElem are copied to the collection's element array so the pElem pointer can be discarded are the call is complete.

Parameters

in	pCollect	Pointer to the collection
in	pElem	Ptr to the element to add
in	eFlags	Flags describing the element (eg. whether the element should be stored in
		internal RAM array or is located in Flash/PROGMEM).

Returns

Pointer to the element in the collection that has been added or NULL if there was an error

5.3.4.6 bool gslc_CollectEvent (void * pvGui, gslc_tsEvent sEvent)

Common event handler function for an element collection.

in	pvGui	Void pointer to GUI
in	sEvent	Event data structure

Returns

true if success, false if fail

5.3.4.7 gslc_tsElem* gslc_CollectFindElemByld (gslc_tsCollect * pCollect, int16_t nElemId)

Find an element in a collection by its Element ID.

Parameters

in	pCollect	Pointer to the collection
in	nElemId	Element ID to search for

Returns

Pointer to the element in the collection that was found or NULL if no matches found

5.3.4.8 gslc_tsElem* gslc_CollectFindElemFromCoord (gslc_tsCollect * pCollect, int16_t nX, int16_t nY)

Find an element in a collection by a coordinate coordinate.

• A match is found if the element is "clickable" (bClickEn=true) and the coordinate falls within the element's bounds (rElem).

Parameters

in	pCollect	Pointer to the collection
in	nX	Absolute X coordinate to use for search
in	nY	Absolute Y coordinate to use for search

Returns

Pointer to the element in the collection that was found or NULL if no matches found

5.3.4.9 $gslc_tsElem* gslc_CollectGetElemTracked (<math>gslc_tsCollect* pCollect)$

Get the element within a collection that is currently being tracked.

Parameters

	in	pCollect	Pointer to the collection
--	----	----------	---------------------------

Returns

Pointer to the element in the collection that is currently being tracked or NULL if no elements are being tracked

5.3.4.10 int gslc_CollectGetNextId (gslc_tsCollect * pCollect)

Allocate the next available Element ID in a collection.

Parameters

in	pCollect	Pointer to the collection

Returns

Element ID that is reserved for use

5.3.4.11 bool gslc_CollectGetRedraw (gslc_tsCollect * pCollect)

Determine if any elements in a collection need redraw.

Parameters

in	pCollect	Pointer to Element collection
----	----------	-------------------------------

Returns

True if redraw required, false otherwise

5.3.4.12 void gslc_CollectReset (gslc_tsCollect * pCollect, gslc_tsElem * asElem, uint16_t nElemMax, gslc_tsElemRef * asElemRef, uint16_t nElemRefMax)

Reset the members of an element collection.

Parameters

in	pCollect	Pointer to the collection
in	asElem	Internal element array storage to associate with the collection
in	nElemMax	Maximum number of elements that can be added to the internal element array
		(ie. RAM))
in	asElemRef	Internal element reference array storage to associate with the collection. All
		elements, whether they are located in the internal element array or in external
		Flash (PROGMEM) storage, require an entry in the element reference array.
in	nElemRefMax	Maximum number of elements in the reference array. This is effectively the
		maximum number of elements that can appear in the collection, irrespective of
		whether it is stored in RAM or Flash (PROGMEM).

Returns

none

5.3.4.13 void gslc_CollectSetElemTracked (gslc_tsCollect * pCollect, gslc_tsElem * pElem)

Set the element within a collection that is currently being tracked.

Parameters

in	pCollect	Pointer to the collection
in	pElem	Ptr to element to mark as being tracked

Returns

none

 $5.3.4.14 \quad \text{void gslc_CollectSetEventFunc (} \quad \text{gslc_tsCollect} \\ * \textit{pCollect,} \quad \text{GSLC_CB_EVENT} \quad \textit{funcCb} \quad \text{)}$

Assign the event callback function for an element collection.

in	pCollect	Pointer to collection
in	funcCb	Function pointer to event routine (or NULL for default))

Returns

none

5.3.4.15 void gslc_CollectSetParent (gslc_tsCollect * pCollect, gslc_tsElem * pElemParent)

Assign the parent element reference to all elements within a collection.

• This is generally used in the case of compound elements where updates to a sub-element should cause the parent (compound element) to be redrawn as well.)

Parameters

in	pCollect	Pointer to the collection
in	pElemParent	Ptr to element that is the parent

Returns

none

5.3.4.16 void gslc_CollectTouch (gslc_tsGui * pGui, gslc_tsCollect * pCollect, gslc_tsEventTouch * pEventTouch)

Handle touch events within the element collection.

Parameters

in	pGui	Pointer to the GUI
in	pCollect	Ptr to the element collection
in	pEventTouch	Ptr to the touch event structure

Returns

none

5.3.4.17 void gslc_DebugPrintf (const char * pFmt, ...)

Optimized printf routine for GUIslice debug/error output.

- Only supports 's','d','u' tokens
- Calls on the output function configured in gslc_InitDebug()

in	pFmt	Format string to use for printing

in		Variable parameter list
----	--	-------------------------

Returns

none

5.3.4.18 void gslc_DrawFillRect (gslc_tsGui * pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a filled rectangle.

Parameters

ſ	in	pGui	Pointer to GUI
	in	rRect	Rectangular region to fill
Ì	in	nCol	Color RGB value to fill

Returns

none

5.3.4.19 void gslc_DrawFrameCircle (gslc_tsGui * pGui, int16_t nMidX, int16_t nMidY, uint16_t nRadius, gslc_tsColor nCol)

Draw a framed circle.

Parameters

in	pGui	Pointer to GUI
in	nMidX	Center X coordinate
in	nMidY	Center Y coordinate
in	nRadius	Radius of circle
in	nCol	Color RGB value for the frame

Returns

none

5.3.4.20 void gslc_DrawFrameRect (gslc_tsGui * pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a framed rectangle.

Parameters

in	pGui	Pointer to GUI
in	rRect	Rectangular region to frame
in	nCol	Color RGB value for the frame

Returns

none

5.3.4.21 void gslc_DrawLine (gslc_tsGui * pGui, int16_t nX0, int16_t nX1, int16_t nX1, int16_t nY1, gslc_tsColor nCol)

Draw an arbitrary line using Bresenham's algorithm.

in	pGui	Pointer to GUI
in	nX0	X coordinate of line startpoint
in	nY0	Y coordinate of line startpoint
in	nX1	X coordinate of line endpoint
in	nY1	Y coordinate of line endpoint
in	nCol	Color RGB value for the line

Returns

none

5.3.4.22 void gslc_DrawLineH (gslc_tsGui * pGui, int16_t nX, int16_t nY, uint16_t nW, gslc_tsColor nCol)

Draw a horizontal line.

• Note that direction of line is in +ve X axis

Parameters

in	pGui	Pointer to GUI
in	nX	X coordinate of line startpoint
in	nY	Y coordinate of line startpoint
in	nW	Width of line (in +X direction)
in	nCol	Color RGB value for the line

Returns

none

5.3.4.23 void gslc_DrawLineV ($gslc_tsGui * pGui$, int16_t nX, int16_t nY, uint16_t nH, $gslc_tsColor nCol$)

Draw a vertical line.

· Note that direction of line is in +ve Y axis

Parameters

in	pGui	Pointer to GUI
in	nX	X coordinate of line startpoint
in	nY	Y coordinate of line startpoint
in	nH	Height of line (in +Y direction)
in	nCol	Color RGB value for the line

Returns

none

5.3.4.24 void gslc_DrawSetPixel ($gslc_tsGui*pGui$, int16_t nX, int16_t nY, $gslc_tsColor nCol$)

Set a pixel on the active screen to the given color with lock.

- Calls upon gslc_DrvDrawSetPixelRaw() but wraps with a surface lock lock
- If repeated access is needed, use gslc_DrvDrawSetPixelRaw() instead

Parameters

in	pGui	Pointer to GUI
in	nX	Pixel X coordinate to set
in	nY	Pixel Y coordinate to set
in	nCol	Color pixel value to assign

Returns

none

5.3.4.25 gslc_tsElem* gslc_telemAdd (gslc_tsGui * pGui, int16_t nPageld, gslc_tsElem* pElem, gslc_teElemRefFlags eFlags)

Add the Element to the list of generated elements in the GUI environment.

• NOTE: The content of pElem is copied so the pointer can be released after the call.

Parameters

in	pGui	Pointer to GUI
in	nPageld	Page ID to add element to (GSLC_PAGE_NONE to skip in case of temporary
		creation for compound elements)
in	pElem	Pointer to Element to add
in	eFlags	Flags describing the element (eg. whether the element should be stored in
		internal RAM array or is located in Flash/PROGMEM).

Returns

Pointer to Element or NULL if fail

5.3.4.26 gslc_tsElem gslc_ElemCreate (gslc_tsGui * pGui, int16_t nElemId, int16_t nPageId, int16_t nType, gslc_tsRect rElem, char * pStrBuf, uint8_t nStrBufMax, int16_t nFontId)

Create a new element with default styling.

Parameters

in	pGui	Pointer to GUI
in	nElemId	User-supplied ID for referencing this element (or GSLC_ID_AUTO to auto-
		generate)
in	nPageld	The page ID on which this page should be associated
in	пТуре	Enumeration that indicates the type of element that is requested for creation.
		The type adjusts the visual representation and default styling.
in	rElem	Rectangle region framing the element
in	pStrBuf	String to copy into element
in	nStrBufMax	Maximum length of string buffer (pStrBuf). Only applicable if GSLC_LOCAL←
		_STR=0. Ignored if GSLC_LOCAL_STR=1.)
in	nFontld	Font ID for textual elements

Returns

Initialized structure

5.3.4.27 gslc_tsElem* gslc_ElemCreateBox (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem)

Create a Box Element.

· Draws a box with frame and fill

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	rElem	Rectangle coordinates defining box size

Returns

Pointer to the Element or NULL if failure

5.3.4.28 gslc_tsElem* gslc_ElemCreateBtnlmg (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem, gslc_tsImgRef sImgRef, gslc_tsImgRef sImgRefSel, GSLC_CB_TOUCH cbTouch)

Create a graphical Button Element.

- · Creates a clickable element that uses a BMP image with no frame or fill
- Transparency is supported by bitmap color (0xFF00FF)

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	rElem	Rectangle coordinates defining image size
in	sImgRef	Image reference to load (unselected state)
in	sImgRefSel	Image reference to load (selected state)
in	cbTouch	Callback for touch events

Returns

Pointer to the Element or NULL if failure

5.3.4.29 gslc_tsElem* gslc_ElemCreateBtnTxt (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem, char * pStrBuf, uint8_t nStrBufMax, int16_t nFontId, GSLC_CB_TOUCH cbTouch)

Create a textual Button Element.

· Creates a clickable element that has a textual label with frame and fill

in	pGui	Pointer to GUI
----	------	----------------

in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	rElem	Rectangle coordinates defining text background size
in	pStrBuf	String to copy into element
in	nStrBufMax	Maximum length of string buffer (pStrBuf). Only applicable if GSLC_LOCAL←
		_STR=0. Ignored if GSLC_LOCAL_STR=1.)
in	nFontId	Font ID to use for text display
in	cbTouch	Callback for touch events

Returns

Pointer to the Element or NULL if failure

5.3.4.30 gslc_tsElem* gslc_ElemCreateImg (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem, gslc_tsImgRef sImgRef)

Create an image Element.

· Draws an image

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	rElem	Rectangle coordinates defining box size
in	sImgRef	Image reference to load

Returns

Pointer to the Element or NULL if failure

5.3.4.31 gslc_tsElem* gslc_ElemCreateLine (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, int16_t nX0, int16_t nY0, int16_t nX1, int16_t nY1)

Create a Line Element.

· Draws a line with fill color

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	nX0	X coordinate of line startpoint
in	nY0	Y coordinate of line startpoint
in	nX1	X coordinate of line endpoint
in	nY1	Y coordinate of line endpoint

Returns

Pointer to the Element or NULL if failure

5.3.4.32 gslc_tsElem* gslc_ElemCreateTxt (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsRect rElem, char * pStrBuf, uint8_t nStrBufMax, int16_t nFontId)

Create a Text Element.

· Draws a text string with filled background

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	rElem	Rectangle coordinates defining text background size
in	pStrBuf	String to copy into element
in	nStrBufMax	Maximum length of string buffer (pStrBuf). Only applicable if GSLC_LOCAL ←
		_STR=0. Ignored if GSLC_LOCAL_STR=1.)
in	nFontId	Font ID to use for text display

Returns

Pointer to the Element or NULL if failure

5.3.4.33 void gslc_ElemDestruct (gslc_tsElem * pElem)

Free up any members associated with an element.

Parameters

- 1			
	in	pElem	Pointer to element

Returns

none

5.3.4.34 void gslc_ElemDraw (gslc_tsGui * pGui, int16_t nPageld, int16_t nElemId)

Draw an element to the active display.

· Element is referenced by a page ID and element ID

Parameters

in	pGui	Pointer to GUI
in	nPageId	ID of page containing element
in	nElemId	ID of element

Returns

none

5.3.4.35 bool gslc_ElemDrawByRef ($gslc_tsGui*pGui, gslc_tsElem*pElem$)

Draw an element to the active display.

· Element is referenced by an element pointer

Parameters

	in	pGui	Pointer to GUI
ſ	in	pElem	Ptr to Element to draw

Returns

true if success, false otherwise

5.3.4.36 bool gslc_ElemEvent (void * pvGui, gslc_tsEvent sEvent)

Common event handler function for an element.

Parameters

in	pvGui	Void pointer to GUI
in	sEvent	Event data structure

Returns

true if success, false if fail

5.3.4.37 bool gslc_ElemGetGlow ($gslc_tsElem * pElem$)

Get the glowing indicator for an element.

Parameters

in	pElem	Pointer to Element

Returns

True if element is glowing

5.3.4.38 bool gslc_ElemGetGlowEn (gslc_tsElem * pElem)

Get the glowing enable for an element.

Parameters

in	pElem	Pointer to Element
----	-------	--------------------

Returns

True if element supports glowing

5.3.4.39 int gslc_ElemGetGroup (gslc_tsElem * pElem)

Get the group ID for an element.

in	pElem	Pointer to Element
----	-------	--------------------

Returns

Group ID or GSLC_GROUP_ID_NONE if unassigned

5.3.4.40 int gslc_ElemGetId (gslc_tsElem * pElem)

Get an Element ID from an element structure.

Parameters

in	pElem	Pointer to element structure
----	-------	------------------------------

Returns

ID of element or GSLC ID NONE if not found

5.3.4.41 bool gslc_ElemGetRedraw (gslc_tsElem * pElem)

Get the need-redraw status for an element.

Parameters

in	pElem	Pointer to Element
----	-------	--------------------

Returns

True if redraw required, false otherwise

5.3.4.42 bool gslc_ElemOwnsCoord (gslc_tsElem * pElem, int16_t nX, int16_t nY, bool bOnlyClickEn)

Determine if a coordinate is inside of an element.

• This routine is useful in determining if a touch coordinate is inside of a button.

Parameters

in	pElem	Element used for boundary test
in	nX	X coordinate to test
in	nY	Y coordinate to test
in	bOnlyClickEn	Only output true if element was also marked as "clickable" (eg. bClickEn=true)

Returns

true if inside element, false otherwise

5.3.4.43 bool gslc_ElemSendEventTouch (gslc_tsGui * pGui, gslc_tsElem * pElemTracked, gslc_teTouch eTouch, int16_t nX, int16_t nY)

Trigger an element's touch event.

This is an optional behavior useful in some extended element types.

Parameters

in	pGui	Pointer to GUI
in	pElemTracked	Pointer to tracked Element (or NULL for none))
in	eTouch	Touch event type
in	nX	X coordinate of event (absolute coordinate)
in	nY	Y coordinate of event (absolute coordinate)

Returns

true if success, false if error

5.3.4.44 void gslc_ElemSetCol ($gslc_tsElem*pElem*, gslc_tsColor* colFrame*, gslc_tsColor* colFill, gslc_tsColor* colFillGlow*)$

Update the common color selection for an Element.

Parameters

in	pElem	Pointer to Element
in	colFrame	Color for the frame
in	colFill	Color for the fill
in	colFillGlow	Color for the fill when glowing

Returns

none

 $5.3.4.45 \quad \text{void gslc_ElemSetDrawFunc (} \ \ \text{gslc_tsElem} * \textit{pElem,} \ \ \text{GSLC_CB_DRAW} \ \textit{funcCb} \)$

Assign the drawing callback function for an element.

• This allows the user to override the default rendering for an element, enabling the creation of a custom element

Parameters

in	pElem	Pointer to Element
in	funcCb	Function pointer to drawing routine (or NULL for default))

Returns

none

5.3.4.46 void gslc_ElemSetEventFunc (gslc_tsElem * pElem, GSLC_CB_EVENT funcCb)

Assign the event callback function for a element.

in	pElem	Pointer to element
----	-------	--------------------

in	funcCh	Function pointer to event routine (or NULL for default))
	1011000	i anotion pointer to event routine (or recell for delacity)

Returns

none

5.3.4.47 void gslc_ElemSetFillEn (gslc_tsElem * pElem, bool bFillEn)

Set the fill state for an Element.

Parameters

in	pElem	Pointer to Element
in	bFillEn	True if filled, false otherwise

Returns

none

5.3.4.48 void gslc_ElemSetFrameEn ($gslc_tsElem*pElem$, bool bFrameEn)

Set the frame state for an Element.

Parameters

in	pElem	Pointer to Element
in	bFrameEn	True if framed, false otherwise

Returns

none

5.3.4.49 void gslc_ElemSetGlow ($gslc_tsElem*pElem$, bool bGlowing)

Update the glowing indicator for an element.

Parameters

in	pElem	Pointer to Element
in	bGlowing	True if element is glowing

Returns

none

5.3.4.50 void gslc_ElemSetGlowCol (gslc_tsElem * pElem, gslc_tsColor colFrameGlow, gslc_tsColor colFillGlow, gslc_tsColor colTxtGlow)

Update the common color selection for glowing state of an Element.

Parameters

in	pElem	Pointer to Element
in	colFrameGlow	Color for the frame when glowing
in	colFillGlow	Color for the fill when glowing
in	colTxtGlow	Color for the text when glowing

Returns

none

5.3.4.51 void gslc_ElemSetGlowEn (gslc_tsElem * pElem, bool bGlowEn)

Update the glowing enable for an element.

Parameters

in	pElem	Pointer to Element
in	bGlowEn	True if element should support glowing

Returns

none

5.3.4.52 void gslc_ElemSetGroup ($gslc_tsElem*pElem$, int nGroupId)

Set the group ID for an element.

• Typically used to associate radio button elements together

Parameters

in	pElem	Pointer to Element
in	nGroupId	Group ID to assign

Returns

none

5.3.4.53 void gslc_ElemSetImage (gslc_tsGui * pGui, gslc_tsElem * pElem, gslc_tsImgRef sImgRef, gslc_tsImgRef sImgRefSel)

Set an element to use a bitmap image.

Parameters

in	pGui	Pointer to GUI
in	pElem	Pointer to Element to update
in	sImgRef	Image reference (normal state)
in	sImgRefSel	Image reference (glowing state)

Returns

none

5.3.4.54 void gslc_ElemSetRedraw (gslc_tsElem * pElem, bool bRedraw)

Update the need-redraw status for an element.

in	pElem	Pointer to Element
in	bRedraw	True if redraw required, false otherwise

Returns

none

5.3.4.55 void gslc_ElemSetStyleFrom (gslc_tsElem * pElemSrc, gslc_tsElem * pElemDest)

Copy style settings from one element to another.

Parameters

in	pElemSrc	Pointer to source Element
in	pElemDest	Pointer to destination Element

Returns

none

5.3.4.56 void gslc_ElemSetTickFunc (gslc_tsElem * pElem, GSLC_CB_TICK funcCb)

Assign the tick callback function for an element.

• This allows the user to provide background updates to an element triggered by the main loop call to gslc_← Update()

in	pElem	Pointer to Element
in	funcCb	Function pointer to tick routine (or NULL for none))

Returns

none

5.3.4.57 void gslc_ElemSetTxtAlign ($gslc_tsElem*pElem*$, unsigned nAlign)

Set the alignment of a textual element (horizontal and vertical)

Parameters

in	pElem	Pointer to Element
in	nAlign	Alignment to specify:
		GSLC_ALIGN_TOP_LEFT
		GSLC_ALIGN_TOP_MID
		GSLC_ALIGN_TOP_RIGHT
		GSLC_ALIGN_MID_LEFT
		GSLC_ALIGN_MID_MID
		GSLC_ALIGN_MID_RIGHT
		GSLC_ALIGN_BOT_LEFT
		GSLC_ALIGN_BOT_MID
		GSLC_ALIGN_BOT_RIGHT
1		

Returns

none

5.3.4.58 void gslc_ElemSetTxtCol ($gslc_tsElem*pElem*, gslc_tsColor* colVal$)

Update the text string color associated with an Element ID.

Parameters

in	pElem	Pointer to Element
in	colVal	RGB color to change to

Returns

none

5.3.4.59 void gslc_ElemSetTxtMargin ($gslc_tsElem*pElem$, unsigned nMargin)

Set the margin around of a textual element.

in	pElem	Pointer to Element

in	nMargin	Number of pixels gap to leave surrounding text
----	---------	--

Returns

none

 $5.3.4.60 \quad \text{void gslc_ElemSetTxtMem (} \textbf{gslc_tsElem} * \textbf{pElem}, \textbf{gslc_teTxtFlags} \textit{eFlags} \textbf{)}$

Update the text string location in memory.

Parameters

in	pElem	Pointer to Element
in	eFlags	Flags associated with text memory location (GSLC_TXT_MEM_*)

Returns

none

5.3.4.61 void gslc_ElemSetTxtStr (gslc_tsElem * pElem, const char * pStr)

Update the text string associated with an Element ID.

Parameters

in	pElem	Pointer to Element
in	pStr	String to copy into element

Returns

none

5.3.4.62 void gslc_ElemUpdateFont (gslc_tsGui * pGui, gslc_tsElem * pElem, int nFontId)

Update the Font selected for an Element's text.

Parameters

in	pGui	Pointer to GUI
in	pElem	Pointer to Element
in	nFontId	Font ID to select

Returns

none

5.3.4.63 gslc_tsEvent gslc_EventCreate (gslc_teEventType eType, uint8_t nSubType, void * pvScope, void * pvData)

Create an event structure.

Parameters

in	еТуре	Event type (draw, touch, tick, etc.)
in	nSubType	Refinement of event type (or 0 if unused)
in	pvScope	Void ptr to object receiving event so that the event handler will have the context
in	pvData	Void ptr to additional data associated with the event (eg. coordinates for touch
		events)

Returns

None

5.3.4.64 gslc_tsRect gslc_ExpandRect (gslc_tsRect rRect, int16_t nExpandW, int16_t nExpandH)

Expand or contract a rectangle in width and/or height (equal amounts on both side), based on the centerpoint of the rectangle.

Parameters

in	rRect	Rectangular region before resizing
in	nExpandW	Number of pixels to expand the width (if positive) of contract the width (if neg-
		ative)
in	nExpandH	Number of pixels to expand the height (if positive) of contract the height (if
		negative)

Returns

gslc_tsRect() with resized dimensions

5.3.4.65 bool gslc_FontAdd (gslc_tsGui * pGui, int16_t nFontId, const char * acFontName, uint16_t nFontSz)

Load a font into the local font cache and assign font ID (nFontId).

Parameters

in	pGui	Pointer to GUI
in	nFontld	ID to use when referencing this font
in	acFontName	Filename path to the font
in	nFontSz	Typeface size to use

Returns

true if load was successful, false otherwise

5.3.4.66 gslc_tsFont* gslc_FontGet (gslc_tsGui * pGui, int16_t nFontId)

Fetch a font from its ID value.

Parameters

in	pGui	Pointer to GUI
in	nFontId	ID value used to reference the font (supplied originally to gslc_FontAdd()

Returns

A pointer to the font structure or NULL if error

 $5.3.4.67 \quad \text{gslc_tsImgRef gslc_GetImageFromFile (const char} * \textit{pFname}, \ \text{gslc_teImgRefFlags} \textit{eFmt)}$

Create an image reference to a bitmap file in LINUX filesystem.

Parameters

in	pFname	Pointer to filename string of image in filesystem
in	eFmt	Image format

Returns

Loaded image reference

 $5.3.4.68 \quad \text{gslc_tsImgRef gslc_GetImageFromProg (const unsigned char} * \textit{plmgBuf, gslc_teImgRefFlags eFmt)}$

Create an image reference to a bitmap in program memory (PROGMEM)

Parameters

in	pImgBuf	Pointer to image buffer in memory
in	eFmt	Image format

Returns

Loaded image reference

5.3.4.69 gslc_tslmgRef gslc_GetImageFromRam (unsigned char * plmgBuf, gslc_teImgRefFlags eFmt)

Create an image reference to a bitmap in SRAM.

Parameters

in	pImgBuf	Pointer to image buffer in memory
in	eFmt	Image format

Returns

Loaded image reference

5.3.4.70 gslc_tslmgRef gslc_GetlmageFromSD (const char * pFname, gslc_telmgRefFlags eFmt)

Create an image reference to a bitmap file in SD card.

Parameters

in	pFname	Pointer to filename string of image in SD card
in	eFmt	Image format

Returns

Loaded image reference

5.3.4.71 int gslc_GetPageCur ($gslc_tsGui * pGui$)

Fetch the current page ID.

in	pGui	Pointer to GUI

Returns

Page ID

5.3.4.72 bool gslc_GetTouch ($gslc_tsGui*pGui$, $int16_t*pnX$, $int16_t*pnY$, $uint16_t*pnPress$)

Initialize the touchscreen device driver.

Parameters

in	pGui	Pointer to GUI	
out	pnX	Ptr to int to contain latest touch X coordinate	
out	pnY	Ptr to int to contain latest touch Y coordinate	
out	pnPress	Ptr to int to contain latest touch pressure value	

Returns

true if touch event, false otherwise

5.3.4.73 char* gslc_GetVer (gslc_tsGui * pGui)

Get the GUIslice version number.

Returns

String containing version number

5.3.4.74 void gslc_GuiDestruct (gslc_tsGui * pGui)

Free up any surfaces associated with the GUI, pages, collections and elements.

Also frees up any fonts.

Called by gslc_Quit()

Parameters

in	pGui	Pointer to GUI
----	------	----------------

Returns

none

5.3.4.75 bool gslc_lnit (gslc_tsGui * pGui, void * pvDriver, gslc_tsPage * asPage, uint8_t nMaxPage, gslc_tsFont * asFont, uint8_t nMaxFont)

Initialize the GUIslice library.

- Configures the primary screen surface(s)
- · Initializes font support

PRE:

• The environment variables should be configured before calling gslc_Init().

Parameters

in	pGui	Pointer to GUI
in	pvDriver	Void pointer to Driver struct (gslc_tsDriver*)
in	asPage	Pointer to Page array
in	nMaxPage	Size of Page array
in	asFont	Pointer to Font array
in	nMaxFont	Size of Font array

Returns

true if success, false if fail

5.3.4.76 void gslc_InitDebug (GSLC_CB_DEBUG_OUT pfunc)

Initialize debug output.

- Defines the user function used for debug/error output
- pfunc is responsible for outputing a single character
- For Arduino, this user function would typically call Serial.print()

Parameters

in	pfunc	Pointer to user character-out function
----	-------	--

Returns

none

5.3.4.77 bool gslc_lnitTouch (gslc_tsGui * pGui, const char * acDev)

Initialize the touchscreen device driver.

Parameters

in	pGui	Pointer t	o GUI								
in	acDev	Device	path	to	touchscreen	(or	""	if	not	applicable))	eg.
		"/dev/inp	ut/toucl	nscre	en"						

Returns

true if successful

5.3.4.78 bool gslc_lslnRect (int16_t nSelX, int16_t nSelY, gslc_tsRect rRect)

Determine if a coordinate is inside of a rectangular region.

• This routine is useful in determining if a touch coordinate is inside of a button.

in	nSelX	X coordinate to test
in	nSelY	X coordinate to test
in	rRect	Rectangular region to compare against

Returns

true if inside region, false otherwise

5.3.4.79 bool gslc_lslnWH (gslc_tsGui * pGui, int16_t nSelX, int16_t nSelY, uint16_t nWidth, uint16_t nHeight)

Determine if a coordinate is inside of a width x height region.

• This routine is useful in determining if a relative coordinate is within a given W x H dimension

Parameters

in	pGui	Pointer to GUI			
in	nSelX	rdinate to test			
in	nSelY	X coordinate to test			
in	nWidth	Width to test against			
in	nHeight	Height to test against			

Returns

true if inside region, false otherwise

5.3.4.80 void gslc_PageAdd (gslc_tsGui * pGui, int16_t nPageId, gslc_tsElem * psElem, uint16_t nMaxElem, gslc_tsElemRef * psElemRef, uint16_t nMaxElemRef)

Add a page to the GUI.

- · This call associates an element array with the collection within the page
- Once a page has been added to the GUI, elements can be added to the page by specifying the same page ID

in	pGui	Pointer to GUI	
in	nPageld	Page ID to assign	
in	psElem	Internal element array storage to associate with the page	
in	nMaxElem	Maximum number of elements that can be added to the internal element array	
		(ie. RAM))	
in	psElemRef	Internal element reference array storage to associate with the page. All ele-	
		ments, whether they are located in the internal element array or in external	
		Flash (PROGMEM) storage, require an entry in the element reference array.	

in	nMaxElemRef	Maximum number of elements in the reference array. This is effectively the
		maximum number of elements that can appear on a page, irrespective of
		whether it is stored in RAM or Flash (PROGMEM).

Returns

none

5.3.4.81 void gslc_PageDestruct (gslc_tsPage * pPage)

Free up any members associated with a page.

Parameters

in	nPaga.	Pointer to Page
TU	pPage	Pointer to Page

Returns

none

5.3.4.82 bool gslc_PageEvent (void * pvGui, gslc_tsEvent sEvent)

Common event handler function for a page.

Parameters

in	pvGui	Void pointer to GUI
in	sEvent	Event data structure

Returns

true if success, false if fail

5.3.4.83 gslc_tsPage* gslc_PageFindByld (gslc_tsGui * pGui, int16_t nPageld)

Find a page in the GUI by its ID.

Parameters

in	pGui	Pointer to GUI
in	nPageId	Page ID to search

Returns

Ptr to a page or NULL if none found

 $5.3.4.84 \quad \textbf{gslc_tsElem}* \ \textbf{gslc_PageFindElemByld} \ (\ \textbf{gslc_tsGui}* \ \textbf{pGui}, \ \textbf{int16_t} \ \textbf{nPageId}, \ \textbf{int16_t} \ \textbf{nElemId} \)$

Find an element in the GUI by its Page ID and Element ID.

in	pGui	Pointer to GUI
in	nPageld	Page ID to search
in	nElemId	Element ID to search

Returns

Ptr to an element or NULL if none found

5.3.4.85 bool gslc_PageFlipGet (gslc_tsGui * pGui)

Get state of pending page flip state.

Parameters

in	pGui	Pointer to GUI

Returns

True if screen requires page flip

5.3.4.86 void gslc_PageFlipGo (gslc_tsGui * pGui)

Update the visible screen if page has been marked for flipping.

• On some hardware this can trigger a double-buffering page flip.

Parameters

in	pGui	Pointer to GUI

Returns

None

5.3.4.87 void gslc_PageFlipSet (gslc_tsGui * pGui, bool bNeeded)

Indicate whether the screen requires page flip.

• This is generally called with bNeeded=true whenever drawing has been done to the active page. Page flip is actually performed later when calling PageFlipGo().

Parameters

in	pGui	Pointer to GUI
in	bNeeded	True if screen requires page flip

Returns

None

5.3.4.88 void gslc_PageRedrawCalc (gslc_tsGui * pGui)

Perform a redraw calculation on the page to determine if additional elements should also be redrawn.

This routine checks to see if any transparent elements have been marked as needing redraw. If so, the whole page may be marked as needing redraw (or at least the other elements that have been exposed underneath).

Parameters

in	pGui	Pointer to GUI
----	------	----------------

Returns

none

5.3.4.89 bool gslc_PageRedrawGet (gslc_tsGui * pGui)

Get the need-redraw status for the current page.

Parameters

in	pGui	Pointer to GUI

Returns

True if redraw required, false otherwise

5.3.4.90 void gslc_PageRedrawGo (gslc_tsGui * pGui)

Redraw all elements on the active page.

Only the elements that have been marked as needing redraw are rendered unless the entire page has been marked as needing redraw (in which case everything is drawn)

Parameters

in	pGui	Pointer to GUI

Returns

none

5.3.4.91 void gslc_PageRedrawSet (gslc_tsGui * pGui, bool bRedraw)

Update the need-redraw status for the current page.

Parameters

in	pGui	Pointer to GUI
in	bRedraw	True if redraw required, false otherwise

Returns

none

5.3.4.92 void gslc_PageSetEventFunc (gslc_tsPage * pPage, GSLC_CB_EVENT funcCb)

Assign the event callback function for a page.

in	pPage	Pointer to page
in	funcCb	Function pointer to event routine (or NULL for default))

Returns

none

5.3.4.93 void gslc_Quit (gslc_tsGui * pGui)

Exit the GUIslice environment.

• Calls lower-level destructors to clean up any initialized subsystems and deletes any created elements or fonts

Parameters

in	pGui	Pointer to GUI

Returns

None

5.3.4.94 void gslc_ResetElem (gslc_tsElem * pElem)

Initialize an Element struct.

Parameters

in	pElem	Pointer to Element

Returns

none

5.3.4.95 void gslc_ResetFont (gslc_tsFont * pFont)

Initialize a Font struct.

Parameters

in	pFont	Pointer to Font

Returns

none

5.3.4.96 gslc_tslmgRef gslc_ResetImage ()

Create a blank image reference structure.

Returns

Image reference struct

5.3.4.97 bool gslc_SetBkgndColor (gslc_tsGui * pGui, gslc_tsColor nCol)

Configure the background to use a solid color.

• The background is used when redrawing the entire page

Parameters

in	pGui	Pointer to GUI
in	nCol	RGB Color to use

Returns

true if success, false if fail

5.3.4.98 bool gslc_SetBkgndlmage (gslc_tsGui * pGui, gslc_tsImgRef slmgRef)

Configure the background to use a bitmap image.

• The background is used when redrawing the entire page

Parameters

in	pGui	Pointer to GUI
in	sImgRef	Image reference

Returns

true if success, false if fail

5.3.4.99 bool gslc_SetClipRect (gslc_tsGui * pGui, gslc_tsRect * pRect)

Set the clipping rectangle for further drawing.

Parameters

in	pGui	Pointer to GUI
in	pRect	Pointer to Rect for clipping (or NULL for entire screen)

Returns

true if success, false if error

5.3.4.100 void gslc_SetPageCur (gslc_tsGui * pGui, int16_t nPageld)

Select a new page for display.

in	pGui	Pointer to GUI

in	nPageld	Page ID to select as current

Returns

none

5.3.4.101 void gslc_TrackTouch (gslc_tsGui * pGui, gslc_tsPage * pPage, int16_t nX, int16_t nY, uint16_t nPress)

Handles a touch event and performs the necessary tracking, glowing and selection actions depending on the press state.

Parameters

in	pGui	Pointer to GUI
in	pPage	Pointer to current page
in	nX	X coordinate of touch event
in	nY	Y coordinate of touch event
in	nPress	Pressure level of touch event (0 for none, else touch)

Returns

none

5.3.4.102 void gslc_Update (gslc_tsGui * pGui)

Perform main GUIslice handling functions.

- · Handles any touch events
- · Performs any necessary screen redraw

Parameters

in	pGui	Pointer to GUI

Returns

None

5.3.5 Variable Documentation


5.3.5.1 GSLC_CB_DEBUG_OUT g_pfDebugOut

Global debug output function.

• The user assigns this function via gslc_InitDebug()

5.4 src/GUIslice_config.h File Reference

This graph shows which files directly or indirectly include this file:



Macros

- #define DRV_DISP_SDL1
- #define DRV_TOUCH_TSLIB
- #define GSLC_DEV_FB "/dev/fb1"
- #define GSLC_DEV_TOUCH "/dev/input/touchscreen"
- #define DRV SDL FIX START 1
- #define DRV_SDL_MOUSE_SHOW 0
- #define GSLC LOCAL STR 1
- #define DEBUG_ERR 1
- #define ADATOUCH SWAP XY 1
- #define ADATOUCH_FLIP_X 0
- #define ADATOUCH_FLIP_Y 1
- #define GSLC_LOCAL_STR_LEN 30
- #define GSLC_BMP_TRANS_EN 1
- #define GSLC BMP TRANS RGB 0xFF,0x00,0xFF
- #define GSLC_USE_PROGMEM 0


5.4.1 Macro Definition Documentation

- 5.4.1.1 #define ADATOUCH_FLIP_X 0
- 5.4.1.2 #define ADATOUCH_FLIP_Y 1
- 5.4.1.3 #define ADATOUCH_SWAP_XY 1
- 5.4.1.4 #define DEBUG_ERR 1
- 5.4.1.5 #define DRV_DISP_SDL1
- 5.4.1.6 #define DRV_SDL_FIX_START 1


- 5.4.1.7 #define DRV_SDL_MOUSE_SHOW 0
- 5.4.1.8 #define DRV_TOUCH_TSLIB
- 5.4.1.9 #define GSLC_BMP_TRANS_EN 1
- 5.4.1.10 #define GSLC_BMP_TRANS_RGB 0xFF,0x00,0xFF
- 5.4.1.11 #define GSLC_DEV_FB "/dev/fb1"
- 5.4.1.12 #define GSLC_DEV_TOUCH "/dev/input/touchscreen"
- 5.4.1.13 #define GSLC_LOCAL_STR 1
- 5.4.1.14 #define GSLC_LOCAL_STR_LEN 30
- 5.4.1.15 #define GSLC_USE_PROGMEM 0

5.5 src/GUIslice_drv.h File Reference

#include "GUIslice_drv_sdl.h"
Include dependency graph for GUIslice_drv.h:




This graph shows which files directly or indirectly include this file:



5.6 src/GUIslice_drv_adagfx.cpp File Reference

```
#include "GUIslice_drv_adagfx.h"
#include <stdio.h>
#include <Adafruit_GFX.h>
#include <gfxfont.h>
```

Include dependency graph for GUIslice drv adagfx.cpp:



Functions

bool gslc_DrvInit (gslc_tsGui *pGui)

Initialize the SDL library.

• void gslc_DrvDestruct (gslc_tsGui *pGui)

Free up any members associated with the driver.

void * gslc_DrvLoadImage (gslc_tsGui *pGui, gslc_tsImgRef sImgRef)

Load a bitmap (*.bmp) and create a new image resource.

• bool gslc_DrvSetBkgndImage (gslc_tsGui *pGui, gslc_tsImgRef sImgRef)

Configure the background to use a bitmap image.

• bool gslc DrvSetBkgndColor (gslc tsGui *pGui, gslc tsColor nCol)

Configure the background to use a solid color.

- $\bullet \ \ bool\ gslc_DrvSetElemImageNorm\ (gslc_tsGui\ *pGui,\ gslc_tsElem\ *pElem,\ gslc_tsImgRef\ sImgRef)$
- bool gslc_DrvSetElemImageGlow (gslc_tsGui *pGui, gslc_tsElem *pElem, gslc_tsImgRef sImgRef)

Set an element's glow-state image.

void gslc_DrvImageDestruct (void *pvImg)

Set an element's normal-state image.

Release an image surface.

bool gslc_DrvSetClipRect (gslc_tsGui *pGui, gslc_tsRect *pRect)

Set the clipping rectangle for future drawing updates.

void * gslc_DrvFontAdd (const char *acFontName, uint16_t nFontSz)

Load a font from a file and return pointer to it.

void gslc_DrvFontsDestruct (gslc_tsGui *pGui)

Release all fonts defined in the GUI.

bool gslc_DrvGetTxtSize (gslc_tsGui *pGui, gslc_tsFont *pFont, const char *pStr, gslc_teTxtFlags eTxt←
 Flags, uint16_t *pnTxtSzW, uint16_t *pnTxtSzH)

Get the extent (width and height) of a text string.

bool gslc_DrvDrawTxt (gslc_tsGui *pGui, int16_t nTxtX, int16_t nTxtY, gslc_tsFont *pFont, const char *pStr, gslc_teTxtFlags eTxtFlags, gslc_tsColor colTxt)

Draw a text string at the given coordinate.

• void gslc_DrvPageFlipNow (gslc_tsGui *pGui)

Force a page flip to occur.

• bool gslc DrvDrawPoint (gslc tsGui *pGui, int16 t nX, int16 t nY, gslc tsColor nCol)

Draw a point.

bool gslc_DrvDrawPoints (gslc_tsGui *pGui, gslc_tsPt *asPt, uint16_t nNumPt, gslc_tsColor nCol)

Draw a point.

bool gslc_DrvDrawFillRect (gslc_tsGui *pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a filled rectangle.

bool gslc_DrvDrawFrameRect (gslc_tsGui *pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a framed rectangle.

bool gslc_DrvDrawLine (gslc_tsGui *pGui, int16_t nX0, int16_t nY0, int16_t nX1, int16_t nY1, gslc_tsColor nCol)

Draw a line.

bool gslc_DrvDrawFrameCircle (gslc_tsGui *, int16_t nMidX, int16_t nMidY, uint16_t nRadius, gslc_tsColor nCol)

Draw a framed circle.

- bool gslc_DrvDrawFillCircle (gslc_tsGui *, int16_t nMidX, int16_t nMidY, uint16_t nRadius, gslc_tsColor nCol)

 Draw a filled circle.
- void gslc_DrvDrawMonoFromMem (gslc_tsGui *pGui, int16_t x, int16_t y, const unsigned char *bitmap, bool bProgMem)
- bool gslc_DrvDrawImage (gslc_tsGui *pGui, int16_t nDstX, int16_t nDstY, gslc_tsImgRef sImgRef)

Copy all of source image to destination screen at specified coordinate.

• void gslc_DrvDrawBkgnd (gslc_tsGui *pGui)

Copy the background image to destination screen.

bool gslc DrvInitTouch (gslc tsGui *pGui, const char *acDev)

Perform any touchscreen-specific initialization.

• bool gslc_DrvGetTouch (gslc_tsGui *pGui, int16_t *pnX, int16_t *pnY, uint16_t *pnPress)

Get the last touch event from the SDL handler.

uint16_t gslc_DrvAdaptColorToRaw (gslc_tsColor nCol)

5.6.1 Function Documentation

5.6.1.1 uint16_t gslc_DrvAdaptColorToRaw (gslc_tsColor nCol)

5.6.1.2 void gslc_DrvDestruct (gslc_tsGui * pGui)

Free up any members associated with the driver.

· Eg. renderers, windows, background surfaces, etc.

Parameters

in	pGui	Pointer to GUI

Returns

none

5.6.1.3 void gslc_DrvDrawBkgnd (gslc tsGui * pGui)

Copy the background image to destination screen.

Parameters

in	pGui	Pointer to GUI

Returns

true if success, false if fail

5.6.1.4 bool gslc_DrvDrawFillCircle (gslc_tsGui * pGui, int16_t nMidX, int16_t nMidY, uint16_t nRadius, gslc_tsColor nCol)

Draw a filled circle.

Parameters

in	pGui	Pointer to GUI
in	nMidX	Center of circle (X coordinate)
in	nMidY	Center of circle (Y coordinate)
in	nRadius	Radius of circle
in	nCol	Color RGB value to fill

Returns

true if success, false if error

5.6.1.5 bool gslc_DrvDrawFillRect ($gslc_tsGui*pGui, gslc_tsRect rRect, gslc_tsColor nCol$)

Draw a filled rectangle.

Parameters

in	pGui	Pointer to GUI
in	rRect	Rectangular region to fill
in	nCol	Color RGB value to fill

Returns

true if success, false if error

5.6.1.6 bool gslc_DrvDrawFrameCircle (gslc_tsGui * pGui, int16_t nMidX, int16_t nMidY, uint16_t nRadius, gslc_tsColor nCol)

Draw a framed circle.

Parameters

in	pGui	Pointer to GUI
in	nMidX	Center of circle (X coordinate)
in	nMidY	Center of circle (Y coordinate)
in	nRadius	Radius of circle
in	nCol	Color RGB value to frame

Returns

true if success, false if error

5.6.1.7 bool gslc_DrvDrawFrameRect ($gslc_tsGui*pGui, gslc_tsRect_rRect, gslc_tsColor_nCol$)

Draw a framed rectangle.

Parameters

in	pGui	Pointer to GUI
in	rRect	Rectangular region to frame
in	nCol	Color RGB value to frame

Returns

true if success, false if error

5.6.1.8 bool gslc_DrvDrawImage (gslc_tsGui * pGui, int16_t nDstX, int16_t nDstY, gslc_tsImgRef sImgRef)

Copy all of source image to destination screen at specified coordinate.

Parameters

in	pGui	Pointer to GUI
in	nDstX	Destination X coord for copy
in	nDstY	Destination Y coord for copy
in	sImgRef	Image reference

Returns

true if success, false if fail

5.6.1.9 bool gslc_DrvDrawLine (gslc_tsGui * pGui, int16_t nX0, int16_t nY0, int16_t nX1, int16_t nY1, gslc_tsColor nCol)

Draw a line.

Parameters

in	pGui	Pointer to GUI
in	nX0	Line start (X coordinate)
in	nY0	Line start (Y coordinate)
in	nX1	Line finish (X coordinate)
in	nY1	Line finish (Y coordinate)
in	nCol	Color RGB value to draw

Returns

true if success, false if error

- 5.6.1.10 void gslc_DrvDrawMonoFromMem (gslc_tsGui * pGui, int16_t x, int16_t y, const unsigned char * bitmap, bool bProgMem)
- 5.6.1.11 bool gslc_DrvDrawPoint (gslc_tsGui * pGui, int16_t nX, int16_t nY, gslc_tsColor nCol)

Draw a point.

Parameters

in	pGui	Pointer to GUI
in	nX	X coordinate of point
in	nY	Y coordinate of point
in	nCol	Color RGB value to draw

Returns

true if success, false if error

5.6.1.12 bool gslc_DrvDrawPoints (gslc_tsGui * pGui, gslc_tsPt * asPt, uint16_t nNumPt, gslc_tsColor nCol)

Draw a point.

Parameters

in	pGui	Pointer to GUI
in	asPt	Array of points to draw
in	nNumPt	Number of points in array
in	nCol	Color RGB value to draw

Returns

true if success, false if error

5.6.1.13 bool gslc_DrvDrawTxt (gslc_tsGui * pGui, int16_t nTxtX, int16_t nTxtY, gslc_tsFont * pFont, const char * pStr, gslc_teTxtFlags eTxtFlags, gslc_tsColor colTxt)

Draw a text string at the given coordinate.

Parameters

in	pGui	Pointer to GUI
in	nTxtX	X coordinate of top-left text string
in	nTxtY	Y coordinate of top-left text string
in	pFont	Ptr to Font
in	pStr	String to display
in	eTxtFlags	Flags associated with text string
in	colTxt	Color to draw text

Returns

true if success, false if failure

5.6.1.14 void* gslc_DrvFontAdd (const char * acFontName, uint16_t nFontSz)

Load a font from a file and return pointer to it.

Parameters

in	acFontName	Filename path to the font
in	nFontSz	Typeface size to use

Returns

true if load was successful, false otherwise

5.6.1.15 void gslc_DrvFontsDestruct ($gslc_tsGui*pGui$)

Release all fonts defined in the GUI.

in	pGui	Pointer to GUI

Returns

none

5.6.1.16 bool gslc_DrvGetTouch ($gslc_tsGui*pGui$, $int16_t*pnX$, $int16_t*pnY$, $uint16_t*pnPress$)

Get the last touch event from the SDL handler.

Get the last touch event from the SDL_Event handler.

Parameters

in	pGui	Pointer to GUI
out	pnX	Ptr to X coordinate of last touch event
out	pnY	Ptr to Y coordinate of last touch event
out	pnPress	Ptr to Pressure level of last touch event (0 for none, >0 for touch)

Returns

true if an event was detected or 0 otherwise

5.6.1.17 bool gslc_DrvGetTxtSize (gslc_tsGui * pGui, gslc_tsFont * pFont, const char * pStr, gslc_teTxtFlags eTxtFlags, uint16_t * pnTxtSzW, uint16_t * pnTxtSzH)

Get the extent (width and height) of a text string.

Parameters

in	pGui	Pointer to GUI
in	pFont	Ptr to Font structure
in	pStr	String to display
in	eTxtFlags	Flags associated with text string
out	pnTxtSzW	Ptr to width of text
out	pnTxtSzH	Ptr to height of text

Returns

true if success, false if failure

5.6.1.18 void gslc_DrvImageDestruct (void * pvImg)

Release an image surface.

Parameters

in	pvlmg	Void ptr to image

Returns

none

5.6.1.19 bool gslc_DrvInit (gslc_tsGui * pGui)

Initialize the SDL library.

- Performs clean startup workaround (if enabled)
- · Configures video mode
- · Initializes font support

PRE:

The environment variables should be configured before calling gslc_DrvInit(). This can be done with gslc_←
 DrvInitEnv() or manually in user function.

Parameters

in	pGui	Pointer to GUI

Returns

true if success, false if fail

5.6.1.20 bool gslc_DrvInitTouch ($gslc_tsGui*pGui$, const char * acDev)

Perform any touchscreen-specific initialization.

Parameters

in	pGui	Pointer to GUI
in	acDev	Device path to touchscreen eg. "/dev/input/touchscreen"

Returns

true if successful

5.6.1.21 void* gslc_DrvLoadlmage (gslc_tsGui * pGui, gslc_tsImgRef slmgRef)

Load a bitmap (*.bmp) and create a new image resource.

Transparency is enabled by GSLC_BMP_TRANS_EN through use of color (GSLC_BMP_TRANS_RGB).

Parameters

in	pGui	Pointer to GUI
in	sImgRef	Image reference

Returns

Image pointer (surface/texture) or NULL if error

5.6.1.22 void gslc_DrvPageFlipNow (gslc_tsGui * pGui)

Force a page flip to occur.

This generally copies active screen surface to the display.

in	pGui	Pointer to GUI
----	------	----------------

Returns

none

5.6.1.23 bool gslc_DrvSetBkgndColor (gslc_tsGui * pGui, gslc_tsColor nCol)

Configure the background to use a solid color.

• The background is used when redrawing the entire page

Parameters

in	pGui	Pointer to GUI
in	nCol	RGB Color to use

Returns

true if success, false if fail

5.6.1.24 bool gslc_DrvSetBkgndlmage (gslc_tsGui * pGui, gslc_tsImgRef slmgRef)

Configure the background to use a bitmap image.

· The background is used when redrawing the entire page

Parameters

in	pGui	Pointer to GUI
in	sImgRef	Image reference

Returns

true if success, false if fail

5.6.1.25 bool gslc_DrvSetClipRect ($gslc_tsGui*pGui, gslc_tsRect*pRect$)

Set the clipping rectangle for future drawing updates.

Parameters

in	pGui	Pointer to GUI
in	pRect	Rectangular region to constrain edits

Returns

none

 $5.6.1.26 \quad bool\ gslc_brvSetElemImageGlow\ (\ gslc_tsGui*pGui,\ gslc_tsElem*pElem,\ gslc_tsImgRef\ sImgRef\)$

Set an element's glow-state image.

Parameters

in	pGui	Pointer to GUI
in	pElem	Pointer to Element to update
in	sImgRef	Image reference

Returns

true if success, false if error

5.6.1.27 bool gslc_DrvSetElemImageNorm (gslc_tsGui * pGui, gslc_tsElem * pElem, gslc_tsImgRef sImgRef)

Set an element's normal-state image.

Parameters

in	pGui	Pointer to GUI
in	pElem	Pointer to Element to update
in	sImgRef	Image reference


Returns

true if success, false if error


5.7 src/GUIslice_drv_adagfx.h File Reference

#include "GUIslice.h"
#include <stdio.h>

Include dependency graph for GUIslice_drv_adagfx.h:



This graph shows which files directly or indirectly include this file:



Classes

struct gslc_tsDriver

Macros

#define DRV_HAS_DRAW_POINT 1

Support gslc_DrvDrawPoint()

#define DRV_HAS_DRAW_POINTS 0

Support gslc_DrvDrawPoints()

• #define DRV_HAS_DRAW_LINE 1

Support gslc_DrvDrawLine()

#define DRV_HAS_DRAW_RECT_FRAME 1

Support gslc_DrvDrawFrameRect()

• #define DRV_HAS_DRAW_RECT_FILL 1

Support gslc_DrvDrawFillRect()

• #define DRV_HAS_DRAW_CIRCLE_FRAME 1

Support gslc_DrvDrawFrameCircle()

• #define DRV_HAS_DRAW_CIRCLE_FILL 1

Support gslc_DrvDrawFillCircle()

• #define DRV_HAS_DRAW_TEXT 1

Support gslc_DrvDrawTxt()

Functions

• bool gslc_DrvInit (gslc_tsGui *pGui)

Initialize the SDL library.

bool gslc_DrvInitTs (gslc_tsGui *pGui, const char *acDev)

Perform any touchscreen-specific initialization.

void gslc_DrvDestruct (gslc_tsGui *pGui)

Free up any members associated with the driver.

void * gslc_DrvLoadImage (gslc_tsGui *pGui, gslc_tsImgRef sImgRef)

Load a bitmap (*.bmp) and create a new image resource.

• bool gslc_DrvSetBkgndImage (gslc_tsGui *pGui, gslc_tsImgRef sImgRef)

Configure the background to use a bitmap image.

bool gslc_DrvSetBkgndColor (gslc_tsGui *pGui, gslc_tsColor nCol)

Configure the background to use a solid color.

bool gslc_DrvSetElemImageNorm (gslc_tsGui *pGui, gslc_tsElem *pElem, gslc_tsImgRef sImgRef)

Set an element's normal-state image.

bool gslc DrvSetElemImageGlow (gslc tsGui *pGui, gslc tsElem *pElem, gslc tsImgRef sImgRef)

Set an element's glow-state image.

void gslc_DrvImageDestruct (void *pvImg)

Release an image surface.

bool gslc_DrvSetClipRect (gslc_tsGui *pGui, gslc_tsRect *pRect)

Set the clipping rectangle for future drawing updates.

void * gslc DrvFontAdd (const char *acFontName, uint16 t nFontSz)

Load a font from a file and return pointer to it.

void gslc_DrvFontsDestruct (gslc_tsGui *pGui)

Release all fonts defined in the GUI.

bool gslc_DrvGetTxtSize (gslc_tsGui *pGui, gslc_tsFont *pFont, const char *pStr, gslc_teTxtFlags eTxt←
 Flags, uint16_t *pnTxtSzW, uint16_t *pnTxtSzH)

Get the extent (width and height) of a text string.

bool gslc_DrvDrawTxt (gslc_tsGui *pGui, int16_t nTxtX, int16_t nTxtY, gslc_tsFont *pFont, const char *pStr, gslc_teTxtFlags eTxtFlags, gslc_tsColor colTxt)

Draw a text string at the given coordinate.

void gslc_DrvPageFlipNow (gslc_tsGui *pGui)

Force a page flip to occur.

bool gslc DrvDrawPoint (gslc tsGui *pGui, int16 t nX, int16 t nY, gslc tsColor nCol)

Draw a point

bool gslc_DrvDrawPoints (gslc_tsGui *pGui, gslc_tsPt *asPt, uint16_t nNumPt, gslc_tsColor nCol)

Draw a point.

• bool gslc_DrvDrawFrameRect (gslc_tsGui *pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a framed rectangle.

• bool gslc_DrvDrawFillRect (gslc_tsGui *pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a filled rectangle.

bool gslc_DrvDrawLine (gslc_tsGui *pGui, int16_t nX0, int16_t nY0, int16_t nX1, int16_t nY1, gslc_tsColor nCol)

Draw a line.

bool gslc_DrvDrawFrameCircle (gslc_tsGui *pGui, int16_t nMidX, int16_t nMidY, uint16_t nRadius, gslc_ts
 — Color nCol)

Draw a framed circle.

bool gslc_DrvDrawFillCircle (gslc_tsGui *pGui, int16_t nMidX, int16_t nMidY, uint16_t nRadius, gslc_tsColor nCol)

Draw a filled circle.

bool gslc_DrvDrawImage (gslc_tsGui *pGui, int16_t nDstX, int16_t nDstY, gslc_tsImgRef sImgRef)

Copy all of source image to destination screen at specified coordinate.

void gslc_DrvDrawBkgnd (gslc_tsGui *pGui)

Copy the background image to destination screen.

• bool gslc_DrvInitTouch (gslc_tsGui *pGui, const char *acDev)

Perform any touchscreen-specific initialization.

• bool gslc_DrvGetTouch (gslc_tsGui *pGui, int16_t *pnX, int16_t *pnY, uint16_t *pnPress)

Get the last touch event from the SDL_Event handler.

uint16_t gslc_DrvAdaptColorToRaw (gslc_tsColor nCol)

```
5.7.1 Macro Definition Documentation
```

5.7.1.1 #define DRV_HAS_DRAW_CIRCLE_FILL 1

Support gslc_DrvDrawFillCircle()

5.7.1.2 #define DRV_HAS_DRAW_CIRCLE_FRAME 1

Support gslc_DrvDrawFrameCircle()

5.7.1.3 #define DRV_HAS_DRAW_LINE 1

Support gslc_DrvDrawLine()

5.7.1.4 #define DRV_HAS_DRAW_POINT 1

Support gslc_DrvDrawPoint()

5.7.1.5 #define DRV_HAS_DRAW_POINTS 0

Support gslc_DrvDrawPoints()

5.7.1.6 #define DRV_HAS_DRAW_RECT_FILL 1

Support gslc_DrvDrawFillRect()

5.7.1.7 #define DRV_HAS_DRAW_RECT_FRAME 1

Support gslc_DrvDrawFrameRect()

5.7.1.8 #define DRV_HAS_DRAW_TEXT 1

Support gslc_DrvDrawTxt()

5.7.2 Function Documentation

5.7.2.1 uint16_t gslc_DrvAdaptColorToRaw (gslc_tsColor nCol)

5.7.2.2 void gslc_DrvDestruct (gslc_tsGui * pGui)

Free up any members associated with the driver.

· Eg. renderers, windows, background surfaces, etc.

Parameters

in	pGui	Pointer to GUI

Returns

none

5.7.2.3 void gslc_DrvDrawBkgnd ($gslc_tsGui*pGui$)

Copy the background image to destination screen.

in	pGui	Pointer to GUI
----	------	----------------

Returns

true if success, false if fail

Copy the background image to destination screen.

5.7.2.4 bool gslc_DrvDrawFillCircle (gslc_tsGui * pGui, int16_t nMidX, int16_t nMidY, uint16_t nRadius, gslc_tsColor nCol)

Draw a filled circle.

Parameters

in	pGui	Pointer to GUI
in	nMidX	Center of circle (X coordinate)
in	nMidY	Center of circle (Y coordinate)
in	nRadius	Radius of circle
in	nCol	Color RGB value to fill

Returns

true if success, false if error

5.7.2.5 bool gslc_DrvDrawFillRect (gslc_tsGui * pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a filled rectangle.

Parameters

in	pGui	Pointer to GUI
in	rRect	Rectangular region to fill
in	nCol	Color RGB value to fill

Returns

true if success, false if error

5.7.2.6 bool gslc_DrvDrawFrameCircle (gslc_tsGui * pGui, int16_t nMidX, int16_t nMidY, uint16_t nRadius, gslc_tsColor nCol)

Draw a framed circle.

Parameters

in	pGui	Pointer to GUI
in	nMidX	Center of circle (X coordinate)
in	nMidY	Center of circle (Y coordinate)
in	nRadius	Radius of circle

in	nCol	Color RGB value to frame
----	------	--------------------------

Returns

true if success, false if error

5.7.2.7 bool gslc_DrvDrawFrameRect ($gslc_tsGui*pGui, gslc_tsRect rRect, gslc_tsColor nCol$)

Draw a framed rectangle.

Parameters

	in	pGui	Pointer to GUI
	in	rRect	Rectangular region to frame
Ì	in	nCol	Color RGB value to frame

Returns

true if success, false if error

5.7.2.8 bool gslc_DrvDrawlmage (gslc_tsGui * pGui, int16_t nDstX, int16_t nDstY, gslc_tsImgRef sImgRef)

Copy all of source image to destination screen at specified coordinate.

Parameters

in	pGui	Pointer to GUI
in	nDstX	Destination X coord for copy
in	nDstY	Destination Y coord for copy
in	sImgRef	Image reference

Returns

true if success, false if fail

5.7.2.9 bool gslc_DrvDrawLine ($gslc_tsGui * pGui$, int16_t nX0, int16_t nY0, int16_t nX1, int16_t nX1, int16_t nY1, $gslc_tsGolor nCol$)

Draw a line.

Parameters

in	pGui	Pointer to GUI
in	nX0	Line start (X coordinate)
in	nY0	Line start (Y coordinate)
in	nX1	Line finish (X coordinate)
in	nY1	Line finish (Y coordinate)
in	nCol	Color RGB value to draw

Returns

true if success, false if error

5.7.2.10 bool gslc_DrvDrawPoint ($gslc_tsGui * pGui$, int16_t nX, int16_t nY, $gslc_tsColor nCol$)

Draw a point.

in	pGui	Pointer to GUI
in	nX	X coordinate of point
in	nY	Y coordinate of point
in	nCol	Color RGB value to draw

Returns

true if success, false if error

5.7.2.11 bool gslc_DrvDrawPoints (gslc_tsGui * pGui, gslc_tsPt * asPt, uint16_t nNumPt, gslc_tsColor nCol)

Draw a point.

Parameters

in	pGui	Pointer to GUI
in	asPt	Array of points to draw
in	nNumPt	Number of points in array
in	nCol	Color RGB value to draw

Returns

true if success, false if error

5.7.2.12 bool gslc_DrvDrawTxt (gslc_tsGui * pGui, int16_t nTxtX, int16_t nTxtY, gslc_tsFont * pFont, const char * pStr, gslc_teTxtFlags eTxtFlags, gslc_tsColor colTxt)

Draw a text string at the given coordinate.

Parameters

in	pGui	Pointer to GUI	
in	nTxtX	X coordinate of top-left text string	
in	nTxtY	Y coordinate of top-left text string	
in	pFont	Ptr to Font	
in	pStr	String to display	
in	eTxtFlags	Flags associated with text string	
in	colTxt	Color to draw text	

Returns

true if success, false if failure

5.7.2.13 void* gslc_DrvFontAdd (const char * acFontName, uint16_t nFontSz)

Load a font from a file and return pointer to it.

Parameters

in	acFontName	Filename path to the font

in	nFontSz	Typeface size to use
----	---------	----------------------

Returns

true if load was successful, false otherwise

5.7.2.14 void gslc_DrvFontsDestruct (gslc_tsGui * pGui)

Release all fonts defined in the GUI.

Parameters

in	pGui	Pointer to GUI

Returns

none

5.7.2.15 bool gslc_DrvGetTouch ($gslc_tsGui*pGui$, $int16_t*pnX$, $int16_t*pnY$, $uint16_t*pnPress$)

Get the last touch event from the SDL Event handler.

Parameters

in	pGui	Pointer to GUI
out	pnX	Ptr to X coordinate of last touch event
out	pnY	Ptr to Y coordinate of last touch event
out	pnPress	Ptr to Pressure level of last touch event (0 for none, 1 for touch)

Returns

true if an event was detected or false otherwise

Get the last touch event from the SDL_Event handler.

Parameters

in	pGui	Pointer to GUI	
out	pnX	Ptr to X coordinate of last touch event	
out	pnY	Ptr to Y coordinate of last touch event	
out	pnPress	Ptr to Pressure level of last touch event (0 for none, >0 for touch)	

Returns

true if an event was detected or 0 otherwise

5.7.2.16 bool gslc_DrvGetTxtSize (gslc_tsGui * pGui, gslc_tsFont * pFont, const char * pStr, gslc_teTxtFlags eTxtFlags, uint16_t * pnTxtSzW, uint16_t * pnTxtSzW)

Get the extent (width and height) of a text string.

Parameters

in	pGui	Pointer to GUI	
in	pFont	Ptr to Font structure	
in	pStr	String to display	
in	eTxtFlags	Flags associated with text string	
out	pnTxtSzW	Ptr to width of text	
out	pnTxtSzH	Ptr to height of text	

Returns

true if success, false if failure

5.7.2.17 void gslc_DrvImageDestruct (void * pvImg)

Release an image surface.

Parameters

in	pvImg	Void ptr to image

Returns

none

5.7.2.18 bool gslc_DrvInit (gslc_tsGui * pGui)

Initialize the SDL library.

- Performs clean startup workaround (if enabled)
- · Configures video mode
- · Initializes font support

PRE:

The environment variables should be configured before calling gslc_DrvInit(). This can be done with gslc_←
 DrvInitEnv() or manually in user function.

Parameters

in	Pointer to GUI	
----	----------------	--

Returns

true if success, false if fail

5.7.2.19 bool gslc_DrvInitTouch ($gslc_tsGui*pGui$, const char * acDev)

Perform any touchscreen-specific initialization.

Parameters

in	pGui	Pointer to GUI
in	acDev	Device path to touchscreen eg. "/dev/input/touchscreen"

Returns

true if successful

5.7.2.20 bool gslc_DrvInitTs (gslc_tsGui * pGui, const char * acDev)

Perform any touchscreen-specific initialization.

Parameters

in	pGui	Pointer to GUI	
in	acDev	Device path to touchscreen eg. "/dev/input/touchscreen"	

Returns

true if successful

5.7.2.21 void* gslc_DrvLoadlmage (gslc_tsGui * pGui, gslc_tslmgRef slmgRef)

Load a bitmap (*.bmp) and create a new image resource.

Transparency is enabled by GSLC_BMP_TRANS_EN through use of color (GSLC_BMP_TRANS_RGB).

Parameters

in	pGui	Pointer to GUI
in	sImgRef	Image reference

Returns

Image pointer (surface/texture) or NULL if error

5.7.2.22 void gslc_DrvPageFlipNow (gslc_tsGui * pGui)

Force a page flip to occur.

This generally copies active screen surface to the display.

Parameters

in	pGui	Pointer to GUI

Returns

none

5.7.2.23 bool gslc_DrvSetBkgndColor (gslc_tsGui * pGui, gslc_tsColor nCol)

Configure the background to use a solid color.

The background is used when redrawing the entire page

	in	pGui	Pointer to GUI
ſ	in	nCol	RGB Color to use

Returns

true if success, false if fail

5.7.2.24 bool gslc_DrvSetBkgndlmage (gslc_tsGui * pGui, gslc_tsImgRef slmgRef)

Configure the background to use a bitmap image.

· The background is used when redrawing the entire page

Parameters

in	pGui	Pointer to GUI
in	sImgRef	Image reference

Returns

true if success, false if fail

5.7.2.25 bool gslc_DrvSetClipRect (gslc_tsGui * pGui, gslc_tsRect * pRect)

Set the clipping rectangle for future drawing updates.

Parameters

in	pGui	Pointer to GUI
in	pRect	Rectangular region to constrain edits

Returns

none

 $5.7.2.26 \quad bool\ gslc_brvSetElemImageGlow\ (\ gslc_tsGui*pGui,\ gslc_tsElem*pElem,\ gslc_tsImgRef\ slmgRef\)$

Set an element's glow-state image.

Parameters

	in	pGui	Pointer to GUI
ſ	in	pElem	Pointer to Element to update
	in	sImgRef	Image reference

Returns

true if success, false if error

 $5.7.2.27 \quad \text{bool gslc_DrvSetElemImageNorm (} \ \, \text{gslc_tsGui} * \textit{pGui}, \ \, \text{gslc_tsElem} * \textit{pElem}, \ \, \text{gslc_tsImgRef} \; \text{slmgRef} \;)$

Set an element's normal-state image.

Parameters

in	pGui	Pointer to GUI
in	pElem	Pointer to Element to update
in	sImgRef	Image reference


Returns

true if success, false if error

5.8 src/GUIslice_drv_sdl.c File Reference

```
#include "GUIslice_drv_sdl.h"
#include <stdio.h>
#include <fcntl.h>
#include <errno.h>
#include <unistd.h>
#include <sys/ioctl.h>
#include <sys/kd.h>
#include <sys/vt.h>
```

Include dependency graph for GUIslice_drv_sdl.c:



Macros

• #define DRV SDL FIX TTY "/dev/tty0"

Functions

• bool gslc_DrvInit (gslc_tsGui *pGui)

Initialize the SDL library.

• void gslc_DrvDestruct (gslc_tsGui *pGui)

Free up any members associated with the driver.

void * gslc_DrvLoadImage (gslc_tsGui *pGui, gslc_tsImgRef sImgRef)

Load a bitmap (*.bmp) and create a new image resource.

• bool gslc_DrvSetBkgndImage (gslc_tsGui *pGui, gslc_tsImgRef sImgRef)

Configure the background to use a bitmap image.

bool gslc_DrvSetBkgndColor (gslc_tsGui *pGui, gslc_tsColor nCol)

Configure the background to use a solid color.

- bool gslc_DrvSetElemImageNorm (gslc_tsGui *pGui, gslc_tsElem *pElem, gslc_tsImgRef sImgRef)
 Set an element's normal-state image.
- bool gslc_DrvSetElemImageGlow (gslc_tsGui *pGui, gslc_tsElem *pElem, gslc_tsImgRef sImgRef)

 Set an element's glow-state image.
- void gslc_DrvImageDestruct (void *pvImg)

Release an image surface.

bool gslc_DrvSetClipRect (gslc_tsGui *pGui, gslc_tsRect *pRect)

Set the clipping rectangle for future drawing updates.

void * gslc DrvFontAdd (const char *acFontName, uint16 t nFontSz)

Load a font from a file and return pointer to it.

void gslc DrvFontsDestruct (gslc tsGui *pGui)

Release all fonts defined in the GUI.

 bool gslc_DrvGetTxtSize (gslc_tsGui *pGui, gslc_tsFont *pFont, const char *pStr, gslc_teTxtFlags eTxt← Flags, uint16 t *pnTxtSzW, uint16 t *pnTxtSzH)

Get the extent (width and height) of a text string.

bool gslc_DrvDrawTxt (gslc_tsGui *pGui, int16_t nTxtX, int16_t nTxtY, gslc_tsFont *pFont, const char *pStr, gslc_teTxtFlags eTxtFlags, gslc_tsColor colTxt)

Draw a text string at the given coordinate.

void gslc_DrvPageFlipNow (gslc_tsGui *pGui)

Force a page flip to occur.

• bool gslc_DrvDrawPoint (gslc_tsGui *pGui, int16_t nX, int16_t nY, gslc_tsColor nCol)

Draw a point

bool gslc_DrvDrawPoints (gslc_tsGui *pGui, gslc_tsPt *asPt, uint16_t nNumPt, gslc_tsColor nCol)

Draw a point.

bool gslc DrvDrawFillRect (gslc tsGui *pGui, gslc tsRect rRect, gslc tsColor nCol)

Draw a filled rectangle.

bool gslc DrvDrawFrameRect (gslc tsGui *pGui, gslc tsRect rRect, gslc tsColor nCol)

Draw a framed rectangle.

bool gslc_DrvDrawLine (gslc_tsGui *pGui, int16_t nX0, int16_t nY0, int16_t nX1, int16_t nY1, gslc_tsColor nCol)

Draw a line.

bool gslc_DrvDrawImage (gslc_tsGui *pGui, int16_t nDstX, int16_t nDstY, gslc_tsImgRef sImgRef)

Copy all of source image to destination screen at specified coordinate.

void gslc_DrvDrawBkgnd (gslc_tsGui *pGui)

NOTE: Background image is stored in pGui->sImgRefBkgnd.

bool gslc DrvInitTouch (gslc tsGui *pGui, const char *acDev)

Perform any touchscreen-specific initialization.

bool gslc_DrvGetTouch (gslc_tsGui *pGui, int16_t *pnX, int16_t *pnY, uint16_t *pnPress)

Get the last touch event from the SDL_Event handler.

bool gslc DrvCleanStart (const char *sTTY)

Ensure SDL initializes cleanly to workaround possible issues if previous SDL application failed to close down gracefully

SDL Rect gslc DrvAdaptRect (gslc tsRect rRect)

Translate a gslc_tsRect into an SDL_Rect.

SDL_Color gslc_DrvAdaptColor (gslc_tsColor sCol)

Translate a gslc_tsColor into an SDL_Color.

uint32_t gslc_DrvAdaptColorRaw (gslc_tsGui *pGui, gslc_tsColor nCol)

Convert an RGB color triplet into the surface pixel value.

bool gslc_DrvScreenLock (gslc_tsGui *pGui)

Lock an SDL surface so that direct pixel manipulation can be done safely.

void gslc DrvScreenUnlock (gslc tsGui *pGui)

Unlock the SDL surface after pixel manipulation is complete.

uint32_t gslc_DrvDrawGetPixelRaw (gslc_tsGui *pGui, int16_t nX, int16_t nY)

Get the pixel at (X,Y) from the active screen.

void gslc_DrvDrawSetPixelRaw (gslc_tsGui *pGui, int16_t nX, int16_t nY, uint32_t nPixelVal)

Set a pixel on the active screen to the given color.

• void gslc_DrvPasteSurface (gslc_tsGui *pGui, int16_t nX, int16_t nY, void *pvSrc, void *pvDest)

Copy one image region to another.

• bool gslc_TDrvInitTouch (gslc_tsGui *pGui, const char *acDev)

Perform any touchscreen-specific initialization.

• int gslc_TDrvGetTouch (gslc_tsGui *pGui, int16_t *pnX, int16_t *pnY, uint16_t *pnPress)

Get the last touch event from the tslib handler.

5.8.1 Macro Definition Documentation

5.8.1.1 #define DRV_SDL_FIX_TTY "/dev/tty0"

5.8.2 Function Documentation

5.8.2.1 SDL_Color gslc_DrvAdaptColor (gslc_tsColor sCol)

Translate a gslc tsColor into an SDL Color.

Parameters

in	sCol	gslc_tsColor
----	------	--------------

Returns

Converted SDL Color

5.8.2.2 uint32_t gslc_DrvAdaptColorRaw (gslc_tsGui * pGui, gslc_tsColor nCol)

Convert an RGB color triplet into the surface pixel value.

This is called to produce the native pixel value required by the raw pixel manipulation routines.

Parameters

in	pGui	Pointer to GUI
in	nCol	RGB value for conversion

Returns

A pixel value for the current screen format

5.8.2.3 SDL_Rect gslc_DrvAdaptRect (gslc_tsRect rRect)

Translate a gslc_tsRect into an SDL_Rect.

Parameters

in	rRect	gslc_tsRect

Returns

Converted SDL_Rect

5.8.2.4 bool gslc_DrvCleanStart (const char * sTTY)

Ensure SDL initializes cleanly to workaround possible issues if previous SDL application failed to close down gracefully.

in	sTTY	Terminal device (eg. "/dev/tty0")

Returns

true if success

5.8.2.5 void gslc_DrvDestruct (gslc_tsGui * pGui)

Free up any members associated with the driver.

• Eg. renderers, windows, background surfaces, etc.

Parameters

in	pGui	Pointer to GUI

Returns

none

5.8.2.6 void gslc_DrvDrawBkgnd (gslc_tsGui * pGui)

NOTE: Background image is stored in pGui->sImgRefBkgnd.

Copy the background image to destination screen.

5.8.2.7 bool gslc_DrvDrawFillRect (gslc_tsGui * pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a filled rectangle.

Parameters

in	pGui	Pointer to GUI
in	rRect	Rectangular region to fill
in	nCol	Color RGB value to fill

Returns

true if success, false if error

5.8.2.8 bool gslc_DrvDrawFrameRect ($gslc_tsGui*pGui, gslc_tsRect_rRect, gslc_tsColor_nCol$)

Draw a framed rectangle.

Parameters

in	pGui	Pointer to GUI
in	rRect	Rectangular region to frame
in	nCol	Color RGB value to frame

Returns

true if success, false if error

5.8.2.9 uint32_t gslc_DrvDrawGetPixelRaw (gslc_tsGui * pGui, int16_t nX, int16_t nY)

Get the pixel at (X,Y) from the active screen.

PRE:

· Screen surface must be locked

Parameters

in	pGui	Pointer to GUI
in	nX	Pixel X coordinate
in	nY	Pixel Y coordinate

Returns

Pixel color value from the coordinate or 0 if error

5.8.2.10 bool gslc_DrvDrawlmage (gslc_tsGui * pGui, int16_t nDstX, int16_t nDstY, gslc_tslmgRef slmgRef)

Copy all of source image to destination screen at specified coordinate.

Parameters

in	pGui	Pointer to GUI
in	nDstX	Destination X coord for copy
in	nDstY	Destination Y coord for copy
in	sImgRef	Image reference

Returns

true if success, false if fail

5.8.2.11 bool gslc_DrvDrawLine (gslc_tsGui * pGui, int16_t nX0, int16_t nY0, int16_t nX1, int16_t nY1, gslc_tsColor nCol)

Draw a line.

Parameters

in	pGui	Pointer to GUI
in	nX0	Line start (X coordinate)
in	nY0	Line start (Y coordinate)
in	nX1	Line finish (X coordinate)
in	nY1	Line finish (Y coordinate)
in	nCol	Color RGB value to draw

Returns

true if success, false if error

5.8.2.12 bool gslc_DrvDrawPoint ($gslc_tsGui * pGui$, int16_t nX, int16_t nY, $gslc_tsColor nCol$)

Draw a point.

in	pGui	Pointer to GUI
in	nX	X coordinate of point
in	nY	Y coordinate of point
in	nCol	Color RGB value to draw

Returns

true if success, false if error

 $5.8.2.13 \quad \text{bool gslc_DrvDrawPoints (} \quad \text{gslc_tsGui} * \textit{pGui}, \quad \text{gslc_tsPt} * \textit{asPt}, \quad \text{uint16_t} \quad \textit{nNumPt}, \quad \text{gslc_tsColor} \quad \textit{nCol} \quad \text{)}$

Draw a point.

Parameters

in	pGui	Pointer to GUI
in	asPt	Array of points to draw
in	nNumPt	Number of points in array
in	nCol	Color RGB value to draw

Returns

true if success, false if error

5.8.2.14 void gslc_DrvDrawSetPixelRaw (gslc_tsGui * pGui, int16_t nX, int16_t nY, uint32_t nPixelCol)

Set a pixel on the active screen to the given color.

PRE:

· Screen surface must be locked

Parameters

	in	pGui	Pointer to GUI
	in	nX	Pixel X coordinate to set
	in	nY	Pixel Y coordinate to set
Γ	in	nPixelCol	Raw color pixel value to assign

Returns

none

5.8.2.15 bool gslc_DrvDrawTxt (gslc_tsGui * pGui, int16_t nTxtX, int16_t nTxtY, gslc_tsFont * pFont, const char * pStr, gslc_teTxtFlags eTxtFlags, gslc_tsColor colTxt)

Draw a text string at the given coordinate.

Param	eters
--------------	-------

Generated on Mon Mar 13 2017 23:10:39 for GUIslice by Doxygen

in	pGui	Pointer to GUI
in	nTxtX	X coordinate of top-left text string
in	nTxtY	Y coordinate of top-left text string
in	pFont	Ptr to Font
in	pStr	String to display
in	eTxtFlags	Flags associated with text string
in	colTxt	Color to draw text

Returns

true if success, false if failure

5.8.2.16 void* gslc_DrvFontAdd (const char * acFontName, uint16_t nFontSz)

Load a font from a file and return pointer to it.

Parameters

in	acFontName	Filename path to the font
in	nFontSz	Typeface size to use

Returns

true if load was successful, false otherwise

5.8.2.17 void gslc_DrvFontsDestruct (gslc_tsGui * pGui)

Release all fonts defined in the GUI.

Parameters

in	pGui	Pointer to GUI
----	------	----------------

Returns

none

5.8.2.18 bool gslc_DrvGetTouch ($gslc_tsGui*pGui$, $int16_t*pnX$, $int16_t*pnY$, $uint16_t*pnPress$)

Get the last touch event from the SDL_Event handler.

Parameters

in	pGui	Pointer to GUI
out	pnX	Ptr to X coordinate of last touch event
out	pnY	Ptr to Y coordinate of last touch event
out	pnPress	Ptr to Pressure level of last touch event (0 for none, 1 for touch)

Returns

true if an event was detected or false otherwise

Get the last touch event from the SDL_Event handler.

in	pGui	Pointer to GUI
out	pnX	Ptr to X coordinate of last touch event
out	pnY	Ptr to Y coordinate of last touch event
out	pnPress	Ptr to Pressure level of last touch event (0 for none, >0 for touch)

Returns

true if an event was detected or 0 otherwise

5.8.2.19 bool gslc_DrvGetTxtSize (gslc_tsGui * pGui, gslc_tsFont * pFont, const char * pStr, gslc_teTxtFlags eTxtFlags, uint16_t * pnTxtSzW, uint16_t * pnTxtSzW)

Get the extent (width and height) of a text string.

Parameters

in	pGui	Pointer to GUI
in	pFont	Ptr to Font structure
in	pStr	String to display
in	eTxtFlags	Flags associated with text string
out	pnTxtSzW	Ptr to width of text
out	pnTxtSzH	Ptr to height of text

Returns

true if success, false if failure

5.8.2.20 void gslc_DrvImageDestruct (void * pvImg)

Release an image surface.

Parameters

in	pvlmg	Void ptr to image	

Returns

none

5.8.2.21 bool gslc_DrvInit (gslc_tsGui * pGui)

Initialize the SDL library.

- Performs clean startup workaround (if enabled)
- · Configures video mode
- · Initializes font support

PRE:

The environment variables should be configured before calling gslc_DrvInit(). This can be done with gslc_←
DrvInitEnv() or manually in user function.

Parameters

in	pGui	Pointer to GUI

Returns

true if success, false if fail

5.8.2.22 bool gslc_DrvInitTouch (gslc_tsGui * pGui, const char * acDev)

Perform any touchscreen-specific initialization.

Parameters

in	pGui	Pointer to GUI
in	acDev	Device path to touchscreen eg. "/dev/input/touchscreen"

Returns

true if successful

5.8.2.23 void* gslc_DrvLoadImage (gslc_tsGui * pGui, gslc_tsImgRef sImgRef)

Load a bitmap (*.bmp) and create a new image resource.

Transparency is enabled by GSLC_BMP_TRANS_EN through use of color (GSLC_BMP_TRANS_RGB).

Parameters

in	pGui	Pointer to GUI
in	sImgRef	Image reference

Returns

Image pointer (surface/texture) or NULL if error

5.8.2.24 void gslc_DrvPageFlipNow (gslc_tsGui * pGui)

Force a page flip to occur.

This generally copies active screen surface to the display.

Parameters

in	pGui	Pointer to GUI
----	------	----------------

Returns

none

5.8.2.25 void gslc_DrvPasteSurface (gslc_tsGui * pGui, int16_t nX, int16_t nY, void * pvSrc, void * pvDest)

Copy one image region to another.

• This is typically used to copy an image to the main screen surface

in	pGui	Pointer to GUI
in	nX	Destination X coordinate of copy
in	nY	Destination Y coordinate of copy
in	pvSrc	Void Ptr to source surface (eg. a loaded image)
in	pvDest	Void Ptr to destination surface (typically the screen)

Returns

none

5.8.2.26 bool gslc_DrvScreenLock ($gslc_tsGui * pGui$)

Lock an SDL surface so that direct pixel manipulation can be done safely.

This function is called before any direct pixel updates.

POST:

· Primary screen surface is locked

Parameters

in	pGui	Pointer to GUI

Returns

true if success, false otherwise

5.8.2.27 void gslc_DrvScreenUnlock (gslc_tsGui * pGui)

Unlock the SDL surface after pixel manipulation is complete.

This function is called after all pixel updates are done.

POST:

· Primary screen surface is unlocked

Parameters

in	pGui	Pointer to GUI

Returns

none

 $5.8.2.28 \quad bool\ gslc_DrvSetBkgndColor\ (\ gslc_tsGui*pGui,\ gslc_tsColor\ nCol\)$

Configure the background to use a solid color.

· The background is used when redrawing the entire page

Parameters

in	pGui	Pointer to GUI
in	nCol	RGB Color to use

Returns

true if success, false if fail

5.8.2.29 bool gslc_DrvSetBkgndlmage (gslc_tsGui * pGui, gslc_tsImgRef slmgRef)

Configure the background to use a bitmap image.

· The background is used when redrawing the entire page

Parameters

in	pGui	Pointer to GUI
in	sImgRef	Image reference

Returns

true if success, false if fail

5.8.2.30 bool gslc_DrvSetClipRect (gslc_tsGui * pGui, gslc_tsRect * pRect)

Set the clipping rectangle for future drawing updates.

Parameters

in	pGui	Pointer to GUI
in	pRect	Rectangular region to constrain edits

Returns

none

 $5.8.2.31 \quad \text{bool gslc_DrvSetElemImageGlow (} \ \, \text{gslc_tsGui} * \textit{pGui}, \ \, \text{gslc_tsElem} * \textit{pElem}, \ \, \text{gslc_tsImgRef} \; \text{slmgRef} \;)$

Set an element's glow-state image.

Parameters

	in	pGui	Pointer to GUI
ſ	in	pElem	Pointer to Element to update
	in	sImgRef	Image reference

Returns

true if success, false if error

 $5.8.2.32 \quad \text{bool gslc_DrvSetElemImageNorm (} \ \, \text{gslc_tsGui} * \textit{pGui}, \ \, \text{gslc_tsElem} * \textit{pElem}, \ \, \text{gslc_tsImgRef} \; \text{slmgRef} \;)$

Set an element's normal-state image.

in	pGui	Pointer to GUI
in	pElem	Pointer to Element to update
in	sImgRef	Image reference

Returns

true if success, false if error

5.8.2.33 int gslc_TDrvGetTouch (gslc_tsGui * pGui, int16_t * pnX, int16_t * pnY, uint16_t * pnPress)

Get the last touch event from the tslib handler.

Parameters

in	pGui	Pointer to GUI
out	pnX	Ptr to X coordinate of last touch event
out	pnY	Ptr to Y coordinate of last touch event
out	pnPress	Ptr to Pressure level of last touch event (0 for none, >0 for touch)

Returns

non-zero if an event was detected or 0 otherwise

5.8.2.34 bool gslc_TDrvInitTouch (gslc_tsGui * pGui, const char * acDev)

Perform any touchscreen-specific initialization.

Parameters

in	pGui	Pointer to GUI
in	acDev	Device path to touchscreen eg. "/dev/input/touchscreen"


Returns

true if successful


5.9 src/GUIslice_drv_sdl.h File Reference

```
#include "GUIslice.h"
#include <stdio.h>
#include <SDL/SDL.h>
#include <SDL/SDL_getenv.h>
#include <SDL/SDL_ttf.h>
#include "tslib.h"
```

Include dependency graph for GUIslice_drv_sdl.h:



This graph shows which files directly or indirectly include this file:



Classes

· struct gslc_tsDriver

Macros

- #define DRV_HAS_DRAW_POINT 1
 - Support gslc_DrvDrawPoint()
- #define DRV_HAS_DRAW_POINTS 1
 - Support gslc_DrvDrawPoints()
- #define DRV_HAS_DRAW_LINE 0
 - Support gslc_DrvDrawLine()
- #define DRV_HAS_DRAW_RECT_FRAME 0
 - Support gslc_DrvDrawFrameRect()
- #define DRV_HAS_DRAW_RECT_FILL 1
 - Support gslc_DrvDrawFillRect()
- #define DRV HAS DRAW CIRCLE FRAME 0
 - Support gslc_DrvDrawFrameCircle()
- #define DRV_HAS_DRAW_CIRCLE_FILL 0

Support gslc_DrvDrawFillCircle()

#define DRV_HAS_DRAW_TEXT 1

Support gslc_DrvDrawTxt()

Functions

bool gslc DrvInit (gslc tsGui *pGui)

Initialize the SDL library.

void gslc DrvDestruct (gslc tsGui *pGui)

Free up any members associated with the driver.

void * gslc_DrvLoadImage (gslc_tsGui *pGui, gslc_tsImgRef sImgRef)

Load a bitmap (*.bmp) and create a new image resource.

bool gslc_DrvSetBkgndImage (gslc_tsGui *pGui, gslc_tsImgRef sImgRef)

Configure the background to use a bitmap image.

bool gslc_DrvSetBkgndColor (gslc_tsGui *pGui, gslc_tsColor nCol)

Configure the background to use a solid color.

bool gslc_DrvSetElemImageNorm (gslc_tsGui *pGui, gslc_tsElem *pElem, gslc_tsImgRef sImgRef)

Set an element's normal-state image.

bool gslc_DrvSetElemImageGlow (gslc_tsGui *pGui, gslc_tsElem *pElem, gslc_tsImgRef sImgRef)

Set an element's glow-state image.

void gslc DrvImageDestruct (void *pvImg)

Release an image surface.

bool gslc DrvSetClipRect (gslc tsGui *pGui, gslc tsRect *pRect)

Set the clipping rectangle for future drawing updates.

void * gslc DrvFontAdd (const char *acFontName, uint16 t nFontSz)

Load a font from a file and return pointer to it.

void gslc_DrvFontsDestruct (gslc_tsGui *pGui)

Release all fonts defined in the GUI.

bool gslc_DrvGetTxtSize (gslc_tsGui *pGui, gslc_tsFont *pFont, const char *pStr, gslc_teTxtFlags eTxt←
 Flags, uint16_t *pnTxtSzW, uint16_t *pnTxtSzH)

Get the extent (width and height) of a text string.

bool gslc_DrvDrawTxt (gslc_tsGui *pGui, int16_t nTxtX, int16_t nTxtY, gslc_tsFont *pFont, const char *pStr, gslc_teTxtFlags eTxtFlags, gslc_tsColor colTxt)

Draw a text string at the given coordinate.

void gslc_DrvPageFlipNow (gslc_tsGui *pGui)

Force a page flip to occur.

• bool gslc_DrvDrawPoint (gslc_tsGui *pGui, int16_t nX, int16_t nY, gslc_tsColor nCol)

Draw a point.

bool gslc_DrvDrawPoints (gslc_tsGui *pGui, gslc_tsPt *asPt, uint16_t nNumPt, gslc_tsColor nCol)

Draw a point.

• bool gslc_DrvDrawFrameRect (gslc_tsGui *pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a framed rectangle.

bool gslc_DrvDrawFillRect (gslc_tsGui *pGui, gslc_tsRect rRect, gslc_tsColor nCol)

Draw a filled rectangle.

bool gslc_DrvDrawLine (gslc_tsGui *pGui, int16_t nX0, int16_t nY0, int16_t nX1, int16_t nY1, gslc_tsColor nCol)

Draw a line

bool gslc DrvDrawImage (gslc tsGui *pGui, int16 t nDstX, int16 t nDstY, gslc tsImgRef sImgRef)

Copy all of source image to destination screen at specified coordinate.

• void gslc DrvDrawBkgnd (gslc tsGui *pGui)

Copy the background image to destination screen.

 bool gslc_DrvGetTouch (gslc_tsGui *pGui, int16_t *pnX, int16_t *pnY, uint16_t *pnPress) Get the last touch event from the SDL_Event handler. bool gslc DrvCleanStart (const char *sTTY) Ensure SDL initializes cleanly to workaround possible issues if previous SDL application failed to close down grace- SDL_Rect gslc_DrvAdaptRect (gslc_tsRect rRect) Translate a gslc_tsRect into an SDL_Rect. SDL_Color gslc_DrvAdaptColor (gslc_tsColor sCol) Translate a gslc_tsColor into an SDL_Color. bool gslc DrvScreenLock (gslc tsGui *pGui) Lock an SDL surface so that direct pixel manipulation can be done safely. void gslc_DrvScreenUnlock (gslc_tsGui *pGui) Unlock the SDL surface after pixel manipulation is complete. uint32 t gslc DrvAdaptColorRaw (gslc tsGui *pGui, gslc tsColor nCol) Convert an RGB color triplet into the surface pixel value. uint32_t gslc_DrvDrawGetPixelRaw (gslc_tsGui *pGui, int16_t nX, int16_t nY) Get the pixel at (X,Y) from the active screen. void gslc_DrvDrawSetPixelRaw (gslc_tsGui *pGui, int16_t nX, int16_t nY, uint32_t nPixelCol) Set a pixel on the active screen to the given color. void gslc DrvPasteSurface (gslc tsGui *pGui, int16 t nY, void *pvSrc, void *pvDest) Copy one image region to another. bool gslc_DrvInitTouch (gslc_tsGui *pGui, const char *acDev) Perform any touchscreen-specific initialization. bool gslc_TDrvInitTouch (gslc_tsGui *pGui, const char *acDev) Perform any touchscreen-specific initialization. int gslc TDrvGetTouch (gslc tsGui *pGui, int16 t *pnX, int16 t *pnY, uint16 t *pnPress) Get the last touch event from the tslib handler. 5.9.1 Macro Definition Documentation 5.9.1.1 #define DRV_HAS_DRAW_CIRCLE_FILL 0 Support gslc DrvDrawFillCircle() 5.9.1.2 #define DRV_HAS_DRAW_CIRCLE_FRAME 0 Support gslc_DrvDrawFrameCircle() 5.9.1.3 #define DRV_HAS_DRAW_LINE 0 Support gslc_DrvDrawLine() 5.9.1.4 #define DRV_HAS_DRAW_POINT 1 Support gslc DrvDrawPoint()

5.9.1.5 #define DRV_HAS_DRAW_POINTS 1

Support gslc_DrvDrawPoints()

5.9.1.6 #define DRV_HAS_DRAW_RECT_FILL 1

Support gslc_DrvDrawFillRect()

5.9.1.7 #define DRV_HAS_DRAW_RECT_FRAME 0

Support gslc_DrvDrawFrameRect()

5.9.1.8 #define DRV_HAS_DRAW_TEXT 1

Support gslc_DrvDrawTxt()

5.9.2 Function Documentation

5.9.2.1 SDL_Color gslc_DrvAdaptColor (gslc_tsColor sCol)

Translate a gslc_tsColor into an SDL_Color.

Parameters

	-0-1	
l ın	SUDI	asic istaniar
	0001	900_1000101

Returns

Converted SDL_Color

5.9.2.2 uint32_t gslc_DrvAdaptColorRaw (gslc_tsGui * pGui, gslc_tsColor nCol)

Convert an RGB color triplet into the surface pixel value.

This is called to produce the native pixel value required by the raw pixel manipulation routines.

Parameters

in	pGui	Pointer to GUI
in	nCol	RGB value for conversion

Returns

A pixel value for the current screen format

5.9.2.3 SDL_Rect gslc_DrvAdaptRect (gslc_tsRect rRect)

Translate a gslc_tsRect into an SDL_Rect.

Parameters

in	rRect	gslc_tsRect

Returns

Converted SDL_Rect

5.9.2.4 bool gslc_DrvCleanStart (const char * sTTY)

Ensure SDL initializes cleanly to workaround possible issues if previous SDL application failed to close down gracefully.

Parameters

in	sTTY	Terminal device (eg. "/dev/tty0")
----	------	-----------------------------------

Returns

true if success

5.9.2.5 void gslc_DrvDestruct (gslc_tsGui * pGui)

Free up any members associated with the driver.

• Eg. renderers, windows, background surfaces, etc.

Parameters

in	pGui	Pointer to GUI

Returns

none

5.9.2.6 void gslc_DrvDrawBkgnd (gslc_tsGui * pGui)

Copy the background image to destination screen.

Parameters

in	pGui	Pointer to GUI
----	------	----------------

Returns

true if success, false if fail

Copy the background image to destination screen.

5.9.2.7 bool gslc_DrvDrawFillRect ($gslc_tsGui*pGui, gslc_tsRect rRect, gslc_tsColor nCol$)

Draw a filled rectangle.

Parameters

in	pGui	Pointer to GUI
in	rRect	Rectangular region to fill
in	nCol	Color RGB value to fill

Returns

true if success, false if error

5.9.2.8 bool gslc_DrvDrawFrameRect ($gslc_tsGui*pGui, gslc_tsRect rRect, gslc_tsColor nCol$)

Draw a framed rectangle.

Parameters

in	pGui	Pointer to GUI
in	rRect	Rectangular region to frame
in	nCol	Color RGB value to frame

Returns

true if success, false if error

5.9.2.9 uint32_t gslc_DrvDrawGetPixelRaw ($gslc_tsGui * pGui$, int16_t nX, int16_t nY)

Get the pixel at (X,Y) from the active screen.

PRE:

· Screen surface must be locked

Parameters

in	pGui	Pointer to GUI
in	nX	Pixel X coordinate
in	nY	Pixel Y coordinate

Returns

Pixel color value from the coordinate or 0 if error

5.9.2.10 bool gslc_DrvDrawlmage (gslc_tsGui * pGui, int16_t nDstX, int16_t nDstY, gslc_tslmgRef slmgRef)

Copy all of source image to destination screen at specified coordinate.

Parameters

in	pGui	Pointer to GUI
in	nDstX	Destination X coord for copy
in	nDstY	Destination Y coord for copy
in	sImgRef	Image reference

Returns

true if success, false if fail

5.9.2.11 bool gslc_DrvDrawLine (gslc_tsGui * pGui, int16_t nX0, int16_t nY0, int16_t nX1, int16_t nY1, gslc_tsColor nCol)

Draw a line.

Parameters

in	pGui	Pointer to GUI
in	nX0	Line start (X coordinate)
in	nY0	Line start (Y coordinate)
in	nX1	Line finish (X coordinate)
in	nY1	Line finish (Y coordinate)
in	nCol	Color RGB value to draw

Returns

true if success, false if error

5.9.2.12 bool gslc_DrvDrawPoint ($gslc_tsGui * pGui$, int16_t nX, int16_t nY, $gslc_tsColor nCol$)

Draw a point.

Parameters

in	pGui	Pointer to GUI
in	nX	X coordinate of point
in	nY	Y coordinate of point
in	nCol	Color RGB value to draw

Returns

true if success, false if error

5.9.2.13 bool gslc_DrvDrawPoints (gslc_tsGui * pGui, gslc_tsPt * asPt, uint16_t nNumPt, gslc_tsColor nCol)

Draw a point.

Parameters

in	pGui	Pointer to GUI
in	asPt	Array of points to draw
in	nNumPt	Number of points in array
in	nCol	Color RGB value to draw

Returns

true if success, false if error

5.9.2.14 void gslc_DrvDrawSetPixelRaw (gslc_tsGui * pGui, int16_t nX, int16_t nY, uint32_t nPixelCol)

Set a pixel on the active screen to the given color.

PRE:

· Screen surface must be locked

Parameters

in	pGui	Pointer to GUI
in	nX	Pixel X coordinate to set
in	nY	Pixel Y coordinate to set
in	nPixelCol	Raw color pixel value to assign

Returns

none

5.9.2.15 bool gslc_DrvDrawTxt (gslc_tsGui * pGui, int16_t nTxtX, int16_t nTxtY, gslc_tsFont * pFont, const char * pStr, gslc_teTxtFlags eTxtFlags, gslc_tsColor colTxt)

Draw a text string at the given coordinate.

Parameters

in	pGui	Pointer to GUI
in	nTxtX	X coordinate of top-left text string
in	nTxtY	Y coordinate of top-left text string
in	pFont	Ptr to Font
in	pStr	String to display
in	eTxtFlags	Flags associated with text string
in	colTxt	Color to draw text

Returns

true if success, false if failure

5.9.2.16 void* gslc_DrvFontAdd (const char * acFontName, uint16_t nFontSz)

Load a font from a file and return pointer to it.

Parameters

in	acFontName	Filename path to the font
in	nFontSz	Typeface size to use

Returns

Void ptr to driver-specific font if load was successful, NULL otherwise

Parameters

in	acFontName	Filename path to the font
in	nFontSz	Typeface size to use

Returns

true if load was successful, false otherwise

5.9.2.17 void gslc_DrvFontsDestruct (gslc_tsGui * pGui)

Release all fonts defined in the GUI.

Parameters

in	pGui	Pointer to GUI
----	------	----------------

Returns

none

5.9.2.18 bool gslc_DrvGetTouch ($gslc_tsGui*pGui$, $int16_t*pnX$, $int16_t*pnY$, $uint16_t*pnPress$)

Get the last touch event from the SDL_Event handler.

Get the last touch event from the SDL handler.

Parameters

in	pGui	Pointer to GUI
out	pnX	Ptr to X coordinate of last touch event
out	pnY	Ptr to Y coordinate of last touch event
out	pnPress	Ptr to Pressure level of last touch event (0 for none, 1 for touch)

Returns

true if an event was detected or false otherwise

Parameters

in	pGui	Pointer to GUI
out	pnX	Ptr to X coordinate of last touch event
out	pnY	Ptr to Y coordinate of last touch event
out	pnPress	Ptr to Pressure level of last touch event (0 for none, >0 for touch)

Returns

true if an event was detected or 0 otherwise

Get the last touch event from the SDL_Event handler.

Parameters

in	pGui	Pointer to GUI
out	pnX	Ptr to X coordinate of last touch event
out	pnY	Ptr to Y coordinate of last touch event
out	pnPress	Ptr to Pressure level of last touch event (0 for none, >0 for touch)

Returns

true if an event was detected or 0 otherwise

Parameters

in	pGui	Pointer to GUI
out	pnX	Ptr to X coordinate of last touch event
out	pnY	Ptr to Y coordinate of last touch event
out	pnPress	Ptr to Pressure level of last touch event (0 for none, 1 for touch)

Returns

true if an event was detected or false otherwise

Get the last touch event from the SDL_Event handler.

Parameters

in	pGui	Pointer to GUI
out	pnX	Ptr to X coordinate of last touch event
out	pnY	Ptr to Y coordinate of last touch event
out	pnPress	Ptr to Pressure level of last touch event (0 for none, >0 for touch)

Returns

true if an event was detected or 0 otherwise

5.9.2.19 bool gslc_DrvGetTxtSize (gslc_tsGui * pGui, gslc_tsFont * pFont, const char * pStr, gslc_teTxtFlags eTxtFlags, uint16_t * pnTxtSzW, uint16_t * pnTxtSzW)

Get the extent (width and height) of a text string.

Parameters

in	pGui	Pointer to GUI
in	pFont	Ptr to Font structure
in	pStr	String to display
in	eTxtFlags	Flags associated with text string
out	pnTxtSzW	Ptr to width of text
out	pnTxtSzH	Ptr to height of text

Returns

true if success, false if failure

5.9.2.20 void gslc_DrvImageDestruct (void * pvImg)

Release an image surface.

Parameters

in	pvlmg	Void ptr to image

Returns

none

5.9.2.21 bool gslc_DrvInit (gslc_tsGui * pGui)

Initialize the SDL library.

- · Performs clean startup workaround (if enabled)
- · Configures video mode
- · Initializes font support

PRE:

• The environment variables should be configured before calling gslc_DrvInit().

Parameters

in	pGui	Pointer to GUI

Returns

true if success, false if fail

- Performs clean startup workaround (if enabled)
- · Configures video mode
- · Initializes font support

PRE:

The environment variables should be configured before calling gslc_DrvInit(). This can be done with gslc_←
DrvInitEnv() or manually in user function.

Parameters

in	pGui	Pointer to GUI

Returns

true if success, false if fail

5.9.2.22 bool gslc_DrvInitTouch (gslc_tsGui * pGui, const char * acDev)

Perform any touchscreen-specific initialization.

Parameters

in	pGui	Pointer to GUI
in	acDev	Device path to touchscreen eg. "/dev/input/touchscreen"

Returns

true if successful

5.9.2.23 void* gslc_DrvLoadlmage (gslc_tsGui * pGui, gslc_tsImgRef slmgRef)

Load a bitmap (*.bmp) and create a new image resource.

Transparency is enabled by GSLC_BMP_TRANS_EN through use of color (GSLC_BMP_TRANS_RGB).

Parameters

in	pGui	Pointer to GUI
in	sImgRef	Image reference

Returns

Image pointer (surface/texture/path) or NULL if error

Transparency is enabled by GSLC_BMP_TRANS_EN through use of color (GSLC_BMP_TRANS_RGB).

Parameters

in	pGui	Pointer to GUI
in	sImgRef	Image reference

Returns

Image pointer (surface/texture) or NULL if error

5.9.2.24 void gslc_DrvPageFlipNow (gslc_tsGui * pGui)

Force a page flip to occur.

This generally copies active screen surface to the display.

Parameters

in	pGui	Pointer to GUI

Returns

none

5.9.2.25 void gslc_DrvPasteSurface (gslc_tsGui * pGui, int16_t nX, int16_t nY, void * pvSrc, void * pvDest)

Copy one image region to another.

• This is typically used to copy an image to the main screen surface

Parameters

in	pGui	Pointer to GUI
in	nX	Destination X coordinate of copy
in	nY	Destination Y coordinate of copy
in	pvSrc	Void Ptr to source surface (eg. a loaded image)
in	pvDest	Void Ptr to destination surface (typically the screen)

Returns

none

5.9.2.26 bool gslc_DrvScreenLock ($gslc_tsGui * pGui$)

Lock an SDL surface so that direct pixel manipulation can be done safely.

This function is called before any direct pixel updates.

POST:

· Primary screen surface is locked

Parameters

in	pGui	Pointer to GUI
----	------	----------------

Returns

true if success, false otherwise

5.9.2.27 void gslc_DrvScreenUnlock (gslc_tsGui * pGui)

Unlock the SDL surface after pixel manipulation is complete.

This function is called after all pixel updates are done.

POST:

· Primary screen surface is unlocked

Parameters

in	pGui	Pointer to GUI

Returns

none

5.9.2.28 bool gslc_DrvSetBkgndColor (gslc_tsGui * pGui, gslc_tsColor nCol)

Configure the background to use a solid color.

• The background is used when redrawing the entire page

Parameters

in	pGui	Pointer to GUI
in	nCol	RGB Color to use

Returns

true if success, false if fail

5.9.2.29 bool gslc_DrvSetBkgndImage (gslc_tsGui * pGui, gslc_tsImgRef sImgRef)

Configure the background to use a bitmap image.

• The background is used when redrawing the entire page

Parameters

in	pGui	Pointer to GUI
in	sImgRef	Image reference

Returns

true if success, false if fail

 $5.9.2.30 \quad \mathsf{bool} \ \mathsf{gslc_brvSetClipRect} \ (\ \mathsf{gslc_tsGui} * \mathit{pGui}, \ \mathsf{gslc_tsRect} * \mathit{pRect} \)$

Set the clipping rectangle for future drawing updates.

Parameters

in	pGui	Pointer to GUI
in	pRect	Rectangular region to constrain edits

Returns

true if success, false if error

Parameters

in	pGui	Pointer to GUI
in	pRect	Rectangular region to constrain edits

Returns

none

5.9.2.31 bool gslc_DrvSetElemImageGlow (gslc_tsGui * pGui, gslc_tsElem * pElem, gslc_tsImgRef sImgRef)

Set an element's glow-state image.

Parameters

in	pGui	Pointer to GUI
in	pElem	Pointer to Element to update
in	sImgRef	Image reference

Returns

true if success, false if error

 $5.9.2.32 \quad bool\ gslc_brvSetElemlmageNorm\ (\ gslc_tsGui*pGui,\ gslc_tsElem*pElem,\ gslc_tsImgRef\ slmgRef\)$

Set an element's normal-state image.

Parameters

in	pGui	Pointer to GUI
in	pElem	Pointer to Element to update
in	sImgRef	Image reference

Returns

true if success, false if error

5.9.2.33 int gslc_TDrvGetTouch ($gslc_tsGui*pGui$, int16_t*pnX, int16_t*pnY, uint16_t*pnPress)

Get the last touch event from the tslib handler.

Parameters

in	pGui	Pointer to GUI
out	pnX	Ptr to X coordinate of last touch event
out	pnY	Ptr to Y coordinate of last touch event
out	pnPress	Ptr to Pressure level of last touch event (0 for none, >0 for touch)

Returns

non-zero if an event was detected or 0 otherwise

5.9.2.34 bool gslc_TDrvInitTouch ($gslc_tsGui * pGui$, const char * acDev)

Perform any touchscreen-specific initialization.

Parameters

in	pGui	Pointer to GUI
in	acDev	Device path to touchscreen eg. "/dev/input/touchscreen"


Returns

true if successful

5.10 src/GUIslice_ex.c File Reference

```
#include "GUIslice.h"
#include "GUIslice_ex.h"
#include <stdio.h>
```

Include dependency graph for GUIslice_ex.c:



Functions

- gslc_tsElem * gslc_ElemXGaugeCreate (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, gslc_tsXGauge *pXData, gslc_tsRect rElem, int16_t nMin, int16_t nMax, int16_t nVal, gslc_tsColor colGauge, bool bVert)
 - Create a Gauge Element.
- void gslc_ElemXGaugeUpdate (gslc_tsElem *pElem, int16_t nVal)
 - Update a Gauge element's current value.
- void gslc_ElemXGaugeSetFlip (gslc_tsGui *pGui, gslc_tsElem *pElem, bool bFlip)
 - Set a Gauge element's fill direction.
- bool gslc_ElemXGaugeDraw (void *pvGui, void *pvElem)
 - Draw a gauge element on the screen.
- gslc_tsElem * gslc_ElemXCheckboxCreate (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, gslc_tsX
 Checkbox *pXData, gslc_tsRect rElem, bool bRadio, gslc_teXCheckboxStyle nStyle, gslc_tsColor colCheck, bool bChecked)
 - Create a Checkbox Element.
- bool gslc_ElemXCheckboxGetState (gslc_tsElem *pElem)
 - Get a Checkbox element's current state.
- gslc_tsElem * gslc_ElemXCheckboxFindChecked (gslc_tsGui *pGui, int16_t nGroupId)
 - Find the checkbox within a group that has been checked.
- void gslc_ElemXCheckboxSetState (gslc_tsElem *pElem, bool bChecked)
 - Set a Checkbox element's current state.
- void gslc ElemXCheckboxToggleState (gslc tsElem *pElem)
 - Toggle a Checkbox element's current state.
- bool gslc_ElemXCheckboxDraw (void *pvGui, void *pvElem)

Draw a Checkbox element on the screen.

bool gslc_ElemXCheckboxTouch (void *pvGui, void *pvElem, gslc_teTouch eTouch, int16_t nRelX, int16_t nRelY)

Handle touch events to Checkbox element.

Create a Slider Element.

void gslc_ElemXSliderSetStyle (gslc_tsElem *pElem, bool bTrim, gslc_tsColor colTrim, uint16_t nTickDiv, int16 t nTickLen, gslc tsColor colTick)

Set a Slider element's current position.

int gslc_ElemXSliderGetPos (gslc_tsElem *pElem)

Get a Slider element's current position.

void gslc ElemXSliderSetPos (gslc tsGui *pGui, gslc tsElem *pElem, int16 t nPos)

Set a Slider element's current position.

void gslc_ElemXSliderSetPosFunc (gslc_tsElem *pElem, GSLC_CB_XSLIDER_POS funcCb)

Assign the position callback function for a slider.

bool gslc ElemXSliderDraw (void *pvGui, void *pvElem)

Draw a Slider element on the screen.

- bool gslc_ElemXSliderTouch (void *pvGui, void *pvElem, gslc_teTouch eTouch, int16_t nRelX, int16_t nRelY)

 Handle touch events to Slider element.

Create a SelNum Element.

bool gslc ElemXSelNumDraw (void *pvGui, void *pvElem)

Draw a SelNum element on the screen.

int gslc_ElemXSelNumGetCounter (gslc_tsGui *pGui, gslc_tsXSelNum *pSelNum)

Get the current counter associated with SelNum.

void gslc ElemXSelNumSetCounter (gslc tsXSelNum *pSelNum, int16 t nCount)

Set the current counter associated with SelNum.

- bool gslc_ElemXSelNumClick (void *pvGui, void *pvElem, gslc_teTouch eTouch, int16_t nX, int16_t nY)
 Handle a click event within the SelNum.
- bool gslc_ElemXSelNumTouch (void *pvGui, void *pvElem, gslc_teTouch eTouch, int16_t nRelX, int16_t n
 RelY)

Handle touch (up,down,move) events to SelNum element.

Variables

- static const int16_t SELNUM_ID_BTN_INC = 100
- static const int16_t SELNUM_ID_BTN_DEC = 101
- static const int16_t SELNUM_ID_TXT = 102

5.10.1 Function Documentation

5.10.1.1 gslc_tsElem* gslc_ElemXCheckboxCreate (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsXCheckbox * pXData, gslc_tsRect rElem, bool bRadio, gslc_teXCheckboxStyle nStyle, gslc_tsColor colCheck, bool bChecked)

Create a Checkbox Element.

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	pXData	Ptr to extended element data structure
in	rElem	Rectangle coordinates defining checkbox size
in	bRadio	Radio-button functionality if true
in	nStyle	Drawing style for checkbox / radio button
in	colCheck	Color for inner fill when checked
in	bChecked	Default state

Returns

Element pointer or NULL if failure

5.10.1.2 bool gslc_ElemXCheckboxDraw (void * pvGui, void * pvElem)

Draw a Checkbox element on the screen.

• Called from gslc_ElemDraw()

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)

Returns

true if success, false otherwise

 $5.10.1.3 \quad gslc_tsElem* gslc_ElemXCheckboxFindChecked (\ gslc_tsGui* pGui, \ int16_t \ nGroupId \)$

Find the checkbox within a group that has been checked.

Parameters

in	pGui	Pointer to GUI
in	nGroupId	Group ID to search

Returns

Element Ptr or NULL if none checked

5.10.1.4 bool gslc_ElemXCheckboxGetState ($gslc_tsElem*pElem*pElem*$)

Get a Checkbox element's current state.

Parameters

in	pElem	Pointer to Element

Returns

Current state

 $5.10.1.5 \quad \text{void gslc_ElemXCheckboxSetState (} \ \ \text{gslc_tsElem} * \textit{pElem,} \ \ \text{bool } \textit{bChecked} \ \)$

Set a Checkbox element's current state.

Parameters

in	pElem	Pointer to Element
in	bChecked	New state

Returns

none

5.10.1.6 void gslc_ElemXCheckboxToggleState (gslc_tsElem * pElem)

Toggle a Checkbox element's current state.

Parameters

in	pElem	Pointer to Element
----	-------	--------------------

Returns

none

5.10.1.7 bool gslc_ElemXCheckboxTouch (void * pvGui, void * pvElem, gslc_teTouch eTouch, int16_t nRelX, int16_t nRelY)

Handle touch events to Checkbox element.

Called from gslc_ElemSendEventTouch()

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)
in	eTouch	Touch event type
in	nRelX	Touch X coord relative to element
in	nRelY	Touch Y coord relative to element

Returns

true if success, false otherwise

5.10.1.8 gslc_tsElem* gslc_ElemXGaugeCreate (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsXGauge * pXData, gslc_tsRect rElem, int16_t nMin, int16_t nMax, int16_t nVal, gslc_tsColor colGauge, bool bVert)

Create a Gauge Element.

• Draws a horizontal or vertical box with a filled region corresponding to the proportion that nVal represents between nMin and nMax.

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	pXData	Ptr to extended element data structure
in	rElem	Rectangle coordinates defining gauge size
in	nMin	Minimum value of gauge for nVal comparison
in	nMax	Maximum value of gauge for nVal comparison
in	nVal	Starting value of gauge
in	colGauge	Color to fill the gauge with
in	bVert	Flag to indicate vertical vs horizontal action (true = vertical, false = horizontal)

Returns

Pointer to Element or NULL if failure

5.10.1.9 bool gslc_ElemXGaugeDraw (void *pvGui, void *pvElem)

Draw a gauge element on the screen.

• Called from gslc_ElemDraw()

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)

Returns

true if success, false otherwise

5.10.1.10 void gslc_ElemXGaugeSetFlip (gslc_tsGui * pGui, gslc_tsElem * pElem, bool bFlip)

Set a Gauge element's fill direction.

- Setting bFlip reverses the default fill direction
- Default fill direction for horizontal gauges: left-to-right
- · Default fill direction for vertical gauges: bottom-to-top

Parameters

in	pGui	Pointer to GUI
in	pElem	Pointer to Element
in	bFlip	If set, reverse direction of fill from default

Returns

none

5.10.1.11 void gslc_ElemXGaugeUpdate ($gslc_tsElem*pElem*, int16_t nVal$)

Update a Gauge element's current value.

• Note that min & max values are assigned in create()

Parameters

in	pElem	Pointer to Element
in	nVal	New value to show in gauge

Returns

none

5.10.1.12 bool gslc_ElemXSelNumClick (void * pvGui, void * pvElem, gslc_teTouch eTouch, int16_t nX, int16_t nY)

Handle a click event within the SelNum.

• This is called internally by the SelNum touch handler

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)
in	eTouch	Touch event type
in	nX	Touch X coord
in	nY	Touch Y coord

Returns

none

5.10.1.13 gslc_tsElem* gslc_ElemXSelNumCreate (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsXSelNum * pXData, gslc_tsRect rElem, int8_t nFontId)

Create a SelNum Element.

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	pXData	Ptr to extended element data structure
in	rElem	Rectangle coordinates defining element size
in	nFontld	Font ID to use for drawing the element

Returns

Pointer to Element or NULL if failure

5.10.1.14 bool gslc_ElemXSelNumDraw (void *pvGui, void *pvElem)

Draw a SelNum element on the screen.

· Called during redraw

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)

Returns

true if success, false otherwise

5.10.1.15 int gslc_ElemXSelNumGetCounter (gslc_tsGui * pGui, gslc_tsXSelNum * pSelNum)

Get the current counter associated with SelNum.

Parameters

in	pGui	Ptr to GUI
in	pSelNum	Ptr to Element

Returns

Current counter value

5.10.1.16 void gslc_ElemXSelNumSetCounter ($gslc_tsXSelNum*pSelNum*$, int16_t nCount)

Set the current counter associated with SelNum.

Parameters

in	pSelNum	Ptr to Element
in	nCount	New counter value

Returns

none

5.10.1.17 bool gslc_ElemXSelNumTouch (void * pvGui, void * pvElem, gslc_teTouch eTouch, int16_t nRelX, int16_t nRelX)

Handle touch (up,down,move) events to SelNum element.

Called from gslc_ElemSendEventTouch()

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)
in	eTouch	Touch event type
in	nRelX	Touch X coord relative to element
in	nRelY	Touch Y coord relative to element

Returns

true if success, false otherwise

5.10.1.18 gslc_tsElem* gslc_ElemXSliderCreate (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsXSlider * pXData, gslc_tsRect rElem, int16_t nPosMin, int16_t nPosMax, int16_t nPos, uint16_t nThumbSz, bool bVert)

Create a Slider Element.

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	pXData	Ptr to extended element data structure
in	rElem	Rectangle coordinates defining checkbox size
in	nPosMin	Minimum position value
in	nPosMax	Maximum position value
in	nPos	Starting position value
in	nThumbSz	Size of the thumb control
in	bVert	Orientation (true for vertical)

Returns

Element pointer or NULL if failure

5.10.1.19 bool gslc_ElemXSliderDraw (void *pvGui, void *pvElem)

Draw a Slider element on the screen.

• Called from gslc_ElemDraw()

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)

Returns

true if success, false otherwise

5.10.1.20 int gslc_ElemXSliderGetPos ($gslc_tsElem*pElem$)

Get a Slider element's current position.

Parameters

in	pElem	Pointer to Element

Returns

Current slider position

 $5.10.1.21 \quad \text{void gslc_ElemXSliderSetPos (} \textbf{gslc_tsGui} * \textbf{pGui}, \textbf{gslc_tsElem} * \textbf{pElem}, \textbf{int} 16_t \textbf{nPos} \textbf{)}$

Set a Slider element's current position.

Parameters

in	pGui	Pointer to GUI

in	pElem	Pointer to Element
in	nPos	New position value

Returns

none

5.10.1.22 void gslc_ElemXSliderSetPosFunc (gslc_tsElem * pElem, GSLC_CB_XSLIDER_POS funcCb)

Assign the position callback function for a slider.

Parameters

in	pElem	Pointer to element
in	funcCb	Function pointer to position routine (or NULL for none)

Returns

none

5.10.1.23 void gslc_ElemXSliderSetStyle (gslc_tsElem * pElem, bool bTrim, gslc_tsColor colTrim, uint16_t nTickDiv, int16_t nTickLen, gslc_tsColor colTick)

Set a Slider element's current position.

Parameters

in	pElem	Pointer to Element
in	bTrim	Show a colored trim?
in	colTrim	Color of trim
in	nTickDiv	Number of tick divisions to show (0 for none)
in	nTickLen	Length of tickmarks
in	colTick	Color of ticks

Returns

none

5.10.1.24 bool gslc_ElemXSliderTouch (void * pvGui, void * pvElem, gslc_teTouch eTouch, int16_t nRelX, int16_t nRelY)

Handle touch events to Slider element.

• Called from gslc_ElemSendEventTouch()

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)
in	eTouch	Touch event type
in	nRelX	Touch X coord relative to element

in	nRelY	Touch Y coord relative to element
711	1111011	100011 1 00010 10101110111

Returns


true if success, false otherwise

5.10.2 Variable Documentation

```
5.10.2.1 const int16_t SELNUM_ID_BTN_DEC = 101 [static]
5.10.2.2 const int16_t SELNUM_ID_BTN_INC = 100 [static]
5.10.2.3 const int16_t SELNUM_ID_TXT = 102 [static]
```

5.11 src/GUIslice_ex.h File Reference

This graph shows which files directly or indirectly include this file:



Classes

• struct gslc_tsXGauge

Extended data for Gauge element.

struct gslc_tsXCheckbox

Extended data for Checkbox element.

struct gslc_tsXSlider

Extended data for Slider element.

struct gslc_tsXSelNum

Extended data for SelNum element.

Macros

• #define SELNUM_STR_LEN 6

Typedefs

typedef bool(* GSLC_CB_XSLIDER_POS)(void *pvGui, void *pvElem, int16_t nPos)
 Callback function for slider feedback.

Enumerations

 enum gslc_teTypeExtend { GSLC_TYPEX_GAUGE = GSLC_TYPE_BASE_EXTEND, GSLC_TYPEX_CH← ECKBOX, GSLC_TYPEX_SLIDER, GSLC_TYPEX_SELNUM }

Extended Element types.

 enum gslc_teXCheckboxStyle { GSLCX_CHECKBOX_STYLE_BOX, GSLCX_CHECKBOX_STYLE_X, GS↔ LCX_CHECKBOX_STYLE_ROUND }

Checkbox drawing style.

Functions

• gslc_tsElem * gslc_ElemXGaugeCreate (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, gslc_tsXGauge *pXData, gslc_tsRect rElem, int16_t nMin, int16_t nMax, int16_t nVal, gslc_tsColor colGauge, bool bVert)

Create a Gauge Element.

void gslc_ElemXGaugeUpdate (gslc_tsElem *pElem, int16_t nVal)

Update a Gauge element's current value.

void gslc_ElemXGaugeSetFlip (gslc_tsGui *pGui, gslc_tsElem *pElem, bool bFlip)

Set a Gauge element's fill direction.

bool gslc_ElemXGaugeDraw (void *pvGui, void *pvElem)

Draw a gauge element on the screen.

gslc_tsElem * gslc_ElemXCheckboxCreate (gslc_tsGui *pGui, int16_t nElemId, int16_t nPage, gslc_tsX
 Checkbox *pXData, gslc_tsRect rElem, bool bRadio, gslc_teXCheckboxStyle nStyle, gslc_tsColor colCheck, bool bChecked)

Create a Checkbox Element.

bool gslc_ElemXCheckboxGetState (gslc_tsElem *pElem)

Get a Checkbox element's current state.

void gslc_ElemXCheckboxSetState (gslc_tsElem *pElem, bool bChecked)

Set a Checkbox element's current state.

• gslc tsElem * gslc ElemXCheckboxFindChecked (gslc tsGui *pGui, int16 t nGroupId)

Find the checkbox within a group that has been checked.

void gslc_ElemXCheckboxToggleState (gslc_tsElem *pElem)

Toggle a Checkbox element's current state.

bool gslc ElemXCheckboxDraw (void *pvGui, void *pvElem)

Draw a Checkbox element on the screen.

bool gslc_ElemXCheckboxTouch (void *pvGui, void *pvElem, gslc_teTouch eTouch, int16_t nRelX, int16_t nRelY)

Handle touch events to Checkbox element.

Create a Slider Element.

void gslc_ElemXSliderSetStyle (gslc_tsElem *pElem, bool bTrim, gslc_tsColor colTrim, uint16_t nTickDiv, int16_t nTickLen, gslc_tsColor colTick)

Set a Slider element's current position.

int gslc_ElemXSliderGetPos (gslc_tsElem *pElem)

Get a Slider element's current position.

void gslc ElemXSliderSetPos (gslc tsGui *pGui, gslc tsElem *pElem, int16 t nPos)

Set a Slider element's current position.

• void gslc_ElemXSliderSetPosFunc (gslc_tsElem *pElem, GSLC_CB_XSLIDER_POS funcCb)

Assign the position callback function for a slider.

bool gslc_ElemXSliderDraw (void *pvGui, void *pvElem)

Draw a Slider element on the screen.

• bool gslc_ElemXSliderTouch (void *pvGui, void *pvElem, gslc_teTouch eTouch, int16_t nRelX, int16_t nRelY)

Handle touch events to Slider element.

Create a SelNum Element.

bool gslc_ElemXSelNumDraw (void *pvGui, void *pvElem)

Draw a SelNum element on the screen.

int gslc_ElemXSelNumGetCounter (gslc_tsGui *pGui, gslc_tsXSelNum *pSelNum)

Get the current counter associated with SelNum.

void gslc_ElemXSelNumSetCounter (gslc_tsXSelNum *pSelNum, int16_t nCount)

Set the current counter associated with SelNum.

- bool gslc_ElemXSelNumClick (void *pvGui, void *pvElem, gslc_teTouch eTouch, int16_t nX, int16_t nY)

 Handle a click event within the SelNum.
- bool gslc_ElemXSelNumTouch (void *pvGui, void *pvElem, gslc_teTouch eTouch, int16_t nRelX, int16_t n
 RelY)

Handle touch (up,down,move) events to SelNum element.

5.11.1 Macro Definition Documentation

5.11.1.1 #define SELNUM_STR_LEN 6

5.11.2 Typedef Documentation

5.11.2.1 typedef bool(* GSLC_CB_XSLIDER_POS)(void *pvGui, void *pvElem, int16_t nPos)

Callback function for slider feedback.

5.11.3 Enumeration Type Documentation

5.11.3.1 enum gslc_teTypeExtend

Extended Element types.

Enumerator

GSLC_TYPEX_GAUGE Guage / progressbar extended element.

GSLC_TYPEX_CHECKBOX Checkbox extended element.

GSLC_TYPEX_SLIDER Slider extended element.

GSLC_TYPEX_SELNUM SelNum extended element.

5.11.3.2 enum gslc_teXCheckboxStyle

Checkbox drawing style.

Enumerator

GSLCX_CHECKBOX_STYLE_BOX Inner box.

GSLCX_CHECKBOX_STYLE_X Crossed.

GSLCX_CHECKBOX_STYLE_ROUND Circular.

5.11.4 Function Documentation

5.11.4.1 gslc_tsElem* gslc_ElemXCheckboxCreate (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsXCheckbox * pXData, gslc_tsRect rElem, bool bRadio, gslc_teXCheckboxStyle nStyle, gslc_tsColor colCheck, bool bChecked)

Create a Checkbox Element.

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	pXData	Ptr to extended element data structure
in	rElem	Rectangle coordinates defining checkbox size
in	bRadio	Radio-button functionality if true
in	nStyle	Drawing style for checkbox / radio button
in	colCheck	Color for inner fill when checked
in	bChecked	Default state

Returns

Element pointer or NULL if failure

5.11.4.2 bool gslc_ElemXCheckboxDraw (void * pvGui, void * pvElem)

Draw a Checkbox element on the screen.

• Called from gslc_ElemDraw()

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)

Returns

true if success, false otherwise

 $5.11.4.3 \quad gslc_tsElem* gslc_ElemXCheckboxFindChecked (\ gslc_tsGui* pGui, \ int16_t \ nGroupId \)$

Find the checkbox within a group that has been checked.

Parameters

in	pGui	Pointer to GUI
in	nGroupId	Group ID to search

Returns

Element Ptr or NULL if none checked

5.11.4.4 bool gslc_ElemXCheckboxGetState ($gslc_tsElem*pElem*$)

Get a Checkbox element's current state.

Parameters

in	pElem	Pointer to Element

Returns

Current state

 $5.11.4.5 \quad \text{void gslc_ElemXCheckboxSetState (} \ \ \text{gslc_tsElem} * \textit{pElem,} \ \ \text{bool } \textit{bChecked} \ \ \text{)}$

Set a Checkbox element's current state.

Parameters

in	pElem	Pointer to Element
in	bChecked	New state

Returns

none

5.11.4.6 void gslc_ElemXCheckboxToggleState (gslc_tsElem * pElem)

Toggle a Checkbox element's current state.

Parameters

in	pElem	Pointer to Element
----	-------	--------------------

Returns

none

5.11.4.7 bool gslc_ElemXCheckboxTouch (void * pvGui, void * pvElem, gslc_teTouch eTouch, int16_t nRelX, int16_t nRelY)

Handle touch events to Checkbox element.

Called from gslc_ElemSendEventTouch()

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)
in	eTouch	Touch event type
in	nRelX	Touch X coord relative to element
in	nRelY	Touch Y coord relative to element

Returns

true if success, false otherwise

5.11.4.8 gslc_tsElem* gslc_ElemXGaugeCreate (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsXGauge * pXData, gslc_tsRect rElem, int16_t nMin, int16_t nMax, int16_t nVal, gslc_tsColor colGauge, bool bVert)

Create a Gauge Element.

• Draws a horizontal or vertical box with a filled region corresponding to the proportion that nVal represents between nMin and nMax.

Parameters 4 8 1

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	pXData	Ptr to extended element data structure
in	rElem	Rectangle coordinates defining gauge size
in	nMin	Minimum value of gauge for nVal comparison
in	nMax	Maximum value of gauge for nVal comparison
in	nVal	Starting value of gauge
in	colGauge	Color to fill the gauge with
in	bVert	Flag to indicate vertical vs horizontal action (true = vertical, false = horizontal)

Returns

Pointer to Element or NULL if failure

5.11.4.9 bool gslc_ElemXGaugeDraw (void *pvGui, void *pvElem)

Draw a gauge element on the screen.

• Called from gslc_ElemDraw()

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)

Returns

true if success, false otherwise

5.11.4.10 void gslc_ElemXGaugeSetFlip (gslc_tsGui * pGui, gslc_tsElem * pElem, bool bFlip)

Set a Gauge element's fill direction.

- Setting bFlip reverses the default fill direction
- Default fill direction for horizontal gauges: left-to-right
- · Default fill direction for vertical gauges: bottom-to-top

Parameters

in	pGui	Pointer to GUI
in	pElem	Pointer to Element
in	bFlip	If set, reverse direction of fill from default

Returns

none

5.11.4.11 void gslc_ElemXGaugeUpdate ($gslc_tsElem*pElem*, int16_t nVal$)

Update a Gauge element's current value.

• Note that min & max values are assigned in create()

Parameters

in	pElem	Pointer to Element
in	nVal	New value to show in gauge

Returns

none

5.11.4.12 bool gslc_ElemXSelNumClick (void * pvGui, void * pvElem, gslc_teTouch eTouch, int16_t nX, int16_t nY)

Handle a click event within the SelNum.

• This is called internally by the SelNum touch handler

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)
in	eTouch	Touch event type
in	nX	Touch X coord
in	nY	Touch Y coord

Returns

none

5.11.4.13 gslc_tsElem* gslc_ElemXSelNumCreate (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsXSelNum * pXData, gslc_tsRect rElem, int8_t nFontId)

Create a SelNum Element.

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	pXData	Ptr to extended element data structure
in	rElem	Rectangle coordinates defining element size
in	nFontld	Font ID to use for drawing the element

Returns

Pointer to Element or NULL if failure

5.11.4.14 bool gslc_ElemXSelNumDraw (void *pvGui, void *pvElem)

Draw a SelNum element on the screen.

· Called during redraw

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)

Returns

true if success, false otherwise

5.11.4.15 int gslc_ElemXSelNumGetCounter (gslc_tsGui * pGui, gslc_tsXSelNum * pSelNum)

Get the current counter associated with SelNum.

Parameters

in	pGui	Ptr to GUI
in	pSelNum	Ptr to Element

Returns

Current counter value

5.11.4.16 void gslc_ElemXSelNumSetCounter ($gslc_tsXSelNum*pSelNum*$, int16_t nCount)

Set the current counter associated with SelNum.

Parameters

in	pSelNum	Ptr to Element
in	nCount	New counter value

Returns

none

5.11.4.17 bool gslc_ElemXSelNumTouch (void * pvGui, void * pvElem, gslc_teTouch eTouch, int16_t nRelX, int16_t nRelX)

Handle touch (up,down,move) events to SelNum element.

Called from gslc_ElemSendEventTouch()

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)
in	eTouch	Touch event type
in	nRelX	Touch X coord relative to element
in	nRelY	Touch Y coord relative to element

Returns

true if success, false otherwise

5.11.4.18 gslc_tsElem* gslc_ElemXSliderCreate (gslc_tsGui * pGui, int16_t nElemId, int16_t nPage, gslc_tsXSlider * pXData, gslc_tsRect rElem, int16_t nPosMin, int16_t nPosMax, int16_t nPos, uint16_t nThumbSz, bool bVert)

Create a Slider Element.

Parameters

in	pGui	Pointer to GUI
in	nElemId	Element ID to assign (016383 or GSLC_ID_AUTO to autogen)
in	nPage	Page ID to attach element to
in	pXData	Ptr to extended element data structure
in	rElem	Rectangle coordinates defining checkbox size
in	nPosMin	Minimum position value
in	nPosMax	Maximum position value
in	nPos	Starting position value
in	nThumbSz	Size of the thumb control
in	bVert	Orientation (true for vertical)

Returns

Element pointer or NULL if failure

5.11.4.19 bool gslc_ElemXSliderDraw (void *pvGui, void *pvElem)

Draw a Slider element on the screen.

• Called from gslc_ElemDraw()

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)

Returns

true if success, false otherwise

5.11.4.20 int gslc_ElemXSliderGetPos ($gslc_tsElem*pElem$)

Get a Slider element's current position.

Parameters

in	pElem	Pointer to Element

Returns

Current slider position

5.11.4.21 void gslc_ElemXSliderSetPos (gslc_tsGui * pGui, gslc_tsElem * pElem, int16_t nPos)

Set a Slider element's current position.

Parameters

in	pGui	Pointer to GUI
----	------	----------------

in	pElem	Pointer to Element
in	nPos	New position value

Returns

none

5.11.4.22 void gslc_ElemXSliderSetPosFunc (gslc_tsElem * pElem, GSLC_CB_XSLIDER_POS funcCb)

Assign the position callback function for a slider.

Parameters

in	pElem	Pointer to element
in	funcCb	Function pointer to position routine (or NULL for none)

Returns

none

5.11.4.23 void gslc_ElemXSliderSetStyle (gslc_tsElem * pElem, bool bTrim, gslc_tsColor colTrim, uint16_t nTickDiv, int16_t nTickLen, gslc_tsColor colTick)

Set a Slider element's current position.

Parameters

in	pElem	Pointer to Element
in	bTrim	Show a colored trim?
in	colTrim	Color of trim
in	nTickDiv	Number of tick divisions to show (0 for none)
in	nTickLen	Length of tickmarks
in	colTick	Color of ticks

Returns

none

5.11.4.24 bool gslc_ElemXSliderTouch (void * pvGui, void * pvElem, gslc_teTouch eTouch, int16_t nRelX, int16_t nRelY)

Handle touch events to Slider element.

• Called from gslc_ElemSendEventTouch()

Parameters

in	pvGui	Void ptr to GUI (typecast to gslc_tsGui*)
in	pvElem	Void ptr to Element (typecast to gslc_tsElem*)
in	eTouch	Touch event type
in	nRelX	Touch X coord relative to element

in	nRelY	Touch Y coord relative to element

Returns

true if success, false otherwise