

Common VVC Methods (Command Distribution Methods) - Quick Reference

await_completion (vvc_target, vvc_instance_idx, [vvc_channel,] [wanted_idx,] [timeout, [msg, [scope]]])

Example: await_completion(SBI_VVCT, 1, 100 ns, "Waiting for all SBI commands to complete");

await_any_completion (vvc_target, vvc_instance_idx, [vvc_channel,] [wanted_idx,] lastness, [timeout, [msg, [await_completion_idx, [scope]]]])

Example: await_any_completion(SBI_VVCT, 1, NOT_LAST, 100 ns, "Add SBI_VVC#1 to the await_any_completion group");
await_any_completion(SBI_VVCT, 2, LAST, 100 ns, "Add SBI_VVC#2 as the last member of the group: Waiting until the first in the group completes their commands");

disable_log_msg (vvc_target, vvc_instance_idx, [vvc_channel,] msg_id, [msg, [quietness, [scope]]])

Example: disable_log_msg(SBI_VVCT, 1, ID_BFM);

enable_log_msg (vvc_target, vvc_instance_idx, [vvc_channel,] msg_id, [msg, [quietness, [scope]]])

Example: enable_log_msg(UART_VVCT, 1, RX, ID_BFM);

flush_command_queue (vvc_target, vvc_instance_idx, [vvc_channel,] [msg, [scope]])

Example: flush command queue(AXILITE VVCT, 1);

fetch_result (vvc_target, vvc_instance_idx, [vvc_channel,] wanted_idx, result, [fetch_is_accepted,] [msg, [alert_level, [scope]]])

Example: fetch_result(SBI_VVCT, 1, v_idx, v_result, v_fetch_is_accepted);

insert_delay (vvc_target, vvc_instance, [vvc_channel,] delay, [msg, [scope]])

Example: insert_delay(SBI_VVCT, 1,100 ns);

Example: insert_delay(UART_VVCT, 1, TX, 10); -- 10 Clock cycles delay using the VVC clk

terminate_current_command (vvc_target, vvc_instance_idx, [vvc_channel, [msg, [scope]]])

Example: terminate_current_command(SBI_VVCT, 1);

terminate_all_commands (vvc_target, vvc_instance_idx, [vvc_channel, [msg. [scope]]])

Example: terminate all commands(UART VVCT, 1, RX);

get_last_received_cmd_idx (vvc_target, vvc_instance, [vvc_channel, [scope]])

Example: v cmd idx := get last received cmd idx (SBI VVCT, 1);

Example: v cmd idx := get last received cmd idx (UART VVCT, 1, RX);





UVVM methods - target parameters

Name	Туре	Example(s)	Description
vvc_target	t_vvc_target_record	UART_VVCT	VVC target type compiled into each VVC in order to differentiate between VVCs.
vvc_instance_idx	Integer	1	Instance number of the VVC used in this method
vvc_channel	t_channel	TX, RX or ALL_CHANNELS	The VVC channel of the VVC instance used in this method
void	t void	VOID	An empty input parameter for procedure waiting for UVVM to be initialized.

UVVM methods - functional parameters

Name	Туре	Example(s)	Description		
wanted_idx	natural	50	The index to be fetched or awaited		
timeout	time	100 ns	The maximum time to await completion of a specified command, or all pending commands. An alert of severity		
			ERROR will be triggered if the awaited time is equal to the specified timeout.		
msg	string	"Awaiting CR from UART"	A message parameter to be appended to the log when the method is executed.		
msg_id	t_msg_id	ID_SEQUENCER	The ID to enable/disable with enable/disable_log_msg(). For more info, see the UVVM-Util documentation.		
result	t_vvc_result	v_result	The output where the fetched data is to be placed with fetch_result()		
fetch_is_accepted	boolean	v_fetch_is_accepted	Output containing a Boolean that states if the fetch command was accepted or not. Will be false if the specified		
			command index has not been stored.		
alert_level	t_alert_level	TB_WARNING	The alert level used for the alert which occurs when a fetch_result() command is not accepted		
delay	time or natural	100 ns or 10	Delay to be inserted in the insert_delay() procedure, either as time or number of clock cycles		
quietness	t_quietness	QUIET	The logging of the command can be turned off by setting quietness=QUIET.		
scope	string	"Sequencer 1"	A string describing the scope from which the log/alert originates.		

UVVM VVC Framework command broadcasting Commands in UVVM can be distributed to all instances of a VVC or to all VVCs using dedicated parameters.



Command Parameter	Description	
VACA DECADOACE	The VVC_BROADCAST command parameter can be used when a command is to target all VVCs within the test environment, reducing the number of com-	mand instructions pooded
VVC_BROADCAST	The VVC_BROADCAST command parameter can be used when a command is to target all VVCs within the test environment, reducing the number of com-	manu msuuciions needed

The VVC_BROADCAST command parameter can be used when a command is to target all VVCs within the test environment, reducing the number of command instructions needed in the testbench.

Example:

enable_log_msg(VVC_BROADCAST, ALL_MESSAGES); -- enable logging for all VVCs await_completion(VVC_BROADCAST, 10 us); -- wait for all VVCs to complete

3 (8)



ALL_INSTANCES

The ALL_INSTANCES command parameter can be used when a command is targeting all instances of a VVC within the test environment, reducing the number of command instructions needed in the testbench.

Example:

enable_log_msg(SBI_VVCT, ALL_INSTANCES, ALL_MESSAGES); -- enable logging for all instances of SBI_VVCT
await_completion(SBI_VVCT, ALL_INSTANCES, 100 ns); -- wait for all instances of SBI_VVCT to complete

C_VVCT_ALL_INSTANCES

See description above. C_VVCT_ALL_INSTANCES = ALL_INSTANCES.

Warning! This command parameter might be removed in a future release and we encourage the use of ALL_INSTANCES.



UVVM VVC Framework Common Methods details

All VVC procedures are defined in the UVVM VVC framework common methods package, td vvc framework common methods pkg.vhd

1 UVVM VVC Framework Common Methods details and examples

Method Description await_completion() await completion(vvc target, vvc instance, timeout, msg, scope) await_completion(vvc_target, vvc_instance, wanted_idx, timeout, msg, scope) await_completion(vvc_target, vvc_instance, vvc_channel, timeout, msg, scope) await_completion(vvc_target, vvc_instance, vvc_channel, wanted_idx, timeout, msg, scope) Tells the VVC to await the completion of either all pending commands or a specified command index. A message with log ID ID_IMMEDIATE_CMD_WAIT will be logged before waiting, and a message with log ID ID_IMMEDIATE_CMD will be logged at the end of the wait. The procedure will report an alert if not all commands have completed within the specified time, timeout. The severity of this alert will be TB ERROR. It is also available as a broadcast to all VVCs. Examples: await completion(SBI VVCT, 1, 16 ns, "Await execution. For single entry queue", C SCOPE); await completion(SBI VVCT, 1, v cmd idx, 100 ns, "Wait for sbi read to finish", C SCOPE); Broadcast: await completion (VVC BROADCAST, 100 ns, "Wait for all VVCs to finish", C SCOPE);



await_any_completion()

```
await_any_completion(vvc_target, vvc_instance, lastness, timeout, msg, await_completion_idx, scope)
await_any_completion(vvc_target, vvc_instance, wanted_idx, lastness, timeout, msg, await_completion_idx, scope)
await_any_completion(vvc_target, vvc_instance, vvc_channel, lastness, timeout, msg, await_completion_idx, scope)
await_any_completion(vvc_target, vvc_instance, vvc_channel, wanted_idx, lastness, timeout, msg, await_completion_idx, scope)
```

Adds a VVC to the await_any_completion group, so that the sequencer can wait until any VVC in the group completes.

In the same way as await_completion, each await_any_completion call can specify that the VVC in question shall wait for either all pending commands (default) or a specified command index (wanted_idx parameter).

When the sequencer calls await_any_completion with 'lastness' = NOT_LAST, it is not blocked so that it can continue adding members to the await_any_completion group by calling await_any_completion for each VVC.

When the sequencer calls await_any_completion with 'lastness' = LAST, the sequencer is blocked until **any** of the VVCs in the group are done waiting for their command(s) to complete.

The optional parameter await completion idx is useful for separating the groups when calling await any completion from multiple sequencers simultaneously:

Each VVC in the group will log a message with ID ID_IMMEDIATE_CMD_WAIT before waiting, and a message with log ID ID_IMMEDIATE_CMD at the end of the wait. The procedure will report an alert if not all commands have completed within the specified time, *timeout*. The severity of this alert will be TB_ERROR.

The following example is a sequence of calls that results in waiting until the first of the 3 VVCs completes:

Limitations:

- While forming a group using await any comletion(..NOT LAST) calls followed by (...LAST) call, do not send other commands to the affected VVCs in between these calls.
- Multiple sequencers cannot call await any completion() on the same VVC instance simultaneously.

disable log msq()

disable_log_msg(vvc_target, vvc_instance, msg_id, msg, quietness, scope)
disable_log_msg(vvc_target, vvc_instance, vvc_channel, msg_id, msg, quietness, scope)

Instruct the VVC to disable a given log ID. This call will be forwarded to the UVVM Utility Library disable_log_msg function. For more information about the disable_log_msg() method, please refer to the UVVM-Util QuickRef.

It is also available as a broadcast to all VVCs

Examples:

```
disable_log_msg(SBI_VVCT, 1, ID_LOG_BFM, "Disabling SBI BFM logging");
   disable_log_msg(UART_VVCT, 1, TX, ID_LOG_BFM, "Disabling UART TX BFM logging", NON_QUIET, C_SCOPE);
roadcast:
   disable log msg(VVC BROADCAST, ALL MESSAGES, "Disables all messages in all VVCs", NON QUIET, C SCOPE);
```



enable_log_msg()

enable_log_msg(vvc_target, vvc_instance, msg_id, msg, quietness, scope)
enable_log_msg(vvc_target, vvc_instance, vvc_channel, msg_id, msg, quietness, scope)

Instruct the VVC to enable a given log ID. This call will be forwarded to the UVVM Utility Library enable_log_msg function. For more information about the enable_log_msg() method, please refer to the UVVM-Util QuickRef.

It is also available as a broadcast to all VVCs.

Examples:

```
enable_log_msg(SBI_VVCT, 1, ID_LOG_BFM, "Enabling SBI BFM logging");
enable_log_msg(UART_VVCT, 1, TX, ID_LOG_BFM, "Enabling UART TX BFM logging", NON_QUIET, C_SCOPE);
padcast:
enable_log_msg(VVC_BROADCAST, ID_LOG_BFM, "Enabling_BFM logging_for_all_VVCs", NON_QUIET, C_SCOPE);
```

flush_command_queue()

flush_command_queue(vvc_target, vvc_instance, msg, scope) flush_command_queue(vvc_target, vvc_instance, vvc_channel, msg, scope)

Flushes the VVC command queue for the specified VVC target/channel. The procedure will log information with log ID ID_IMMEDIATE_CMD. It is also available as a broadcast to all VVCs.

Example:

```
flush command queue(SBI VVCT, 1, "Flushing command queue", C SCOPE);
```

Broadcast

flush command queue(VVC BROADCAST, "Flushing command queues", C SCOPE);

fetch_result()

```
fetch_result(vvc_target, vvc_instance, wanted_id, result, msg, alert_level, scope) fetch_result(vvc_target, vvc_instance, vvc_channel, wanted_id, result, msg, alert_level, scope) fetch_result(vvc_target, vvc_instance, wanted_id, result, fetch_is_accepted, msg, alert_level, scope) fetch_result(vvc_target, vvc_instance, vvc_channel, wanted_id, result, fetch_is_accepted, msg, alert_level, scope)
```

Fetches a stored result using the command index. A result is stored when using e.g. the read or receive commands in a VVC. The fetched result is available on the 'result' output. The Boolean output 'fetch_is_accepted' is used to indicate if the fetch was successful or not. A fetch can fail if e.g. the wanted_id did not have a result to store, or the wanted_id read has not yet been executed. Omitting the 'fetch_is_accepted' parameter causes the parameters to be checked automatically in the procedure. On successful fetch, a message with log ID_UVVM_CMD_RESULT is logged.

Example:



insert_delay()

insert_delay(vvc_target, vvc_instance, delay, msg, scope) insert_delay(vvc_target, vvc_instance, vvc_channel, delay, msg, scope)

This method inserts a delay of 'delay' clock cycles or 'delay' seconds in the VVC. It is also available as a broadcast to all VVCs.

Examples:

```
insert_delay(SBI_VVCT,1, 100, "100T delay", C_SCOPE); insert_delay(SBI_VVCT,1, 50 ns, "50 ns delay", C_SCOPE);
```

Broadcast:

insert delay(VVC BROADCAST, 50 ns, "Insert 50 ns delay to all VVCs", C SCOPE);

terminate_current_command()

terminate_current_command(vvc_target, vvc_instance, msg, scope)
terminate_current_command(vvc_target, vvc_instance, vvc_channel, msg, scope)

This method terminates the current command in the VVC, if the currently running BFM command supports the terminate signal. It is also available as a broadcast to all VVCs.

Example:

```
terminate_current_command(SBI_VVCT, 1, "Terminating current command", C_SCOPE);

adcast:
terminate current command(VVC BROADCAST, "Terminating current command in all VVCs", C SCOPE);
```

terminate_all_commands()

terminate_all_commands(vvc_target, vvc_instance, msg, scope) terminate_all_commands(vvc_target, vvc_instance, vvc_channel, msg, scope)

This method terminates the current command in the VVC, if the currently running BFM command supports the terminate signal. The terminate_all_commands() procedure also flushes the VVC command queue, removing all pending commands.

It is also available as a broadcast to all VVCs.

Example:

```
terminate_all_commands(SBI_VVCT, 1, "Terminating all commands", C_SCOPE);

Broadcast:
terminate all commands(VVC BROADCAST, "Terminating all commands in all VVCs", C SCOPE);
```

get_last_received_cmd_idx()

```
get_last_received_cmd_idx(vvc_target, vvc_instance, scope)
get_last_received_cmd_idx(vvc_target, vvc_instance, vvc_channel, scope)
```

This method is used to get the command index of the last command received by the VVC interpreter. Necessary for getting the command index of a read for fetch_result.

Example:

```
v cmd idx := get last received cmd idx(SBI VVCT, 1, C SCOPE);
```

INTELLECTUAL PROPERTY

Disclaimer: This IP and any part thereof are provided "as is", without warranty of any kind, express or implied, including but not limited to the warranties of merchantability, fitness for a particular purpose and noninfringement. In no event shall the authors or copyright holders be liable for any claim, damages or other liability, whether in an action of contract, tort or otherwise, arising from, out of or in connection with this IP.