

CLOCK GENERATOR VVC – Quick Reference

For general information see UVVM VVC Framework Essential Mechanisms located in uvvm_vvc_framework/doc.

start_clock (VVCT, vvc_instance_idx, msg, [scope])

Example: start_clock(CLOCK_GENERATOR_VVCT, 1, "Start clock generator");



stop_clock (VVCT, vvc_instance_idx, msg, [scope])

Example: stop_clock(CLOCK_GENERATOR_VVCT, 1, "Stop clock generator");

clock generator vvc.vhd

set_clock_period (VVCT, vvc_instance_idx, clock_period, msg, [scope])

Example: set_clock_period(CLOCK_GENERATOR_VVCT, 1, 10 ns, "Change clock period to 10 ns");

set_clock_high_time(VVCT, vvc_instance_idx, clock_high_time, msg, [scope])

Example: set_clock_high_time(CLOCK_GENERATOR_VVCT, 1, 5 ns, "Change duty cycle to 50%");

CLOCK GENERATOR VVC Configuration record 'vvc_config' -- accessible via

shared_clock_generator_vvc_config

| | Record element | | C_CLOCK_GENERATOR_VVC_CONFIG_DEFAULT |
|--|---------------------------------------|-------------------|---|
| | inter_bfm_delay | t_inter_bfm_delay | C_CLOCK_GENERATOR_INTER_BFM_DELAY_DEFAULT |
| | cmd_queue_count_max | natural | C_CMD_QUEUE_COUNT_MAX |
| | cmd_queue_count_threshold | natural | C_CMD_QUEUE_COUNT_THRESHOLD |
| | cmd_queue_count_threshold_severity | t_alert_level | C_CMD_QUEUE_COUNT_THRESHOLD_SEVERITY |
| | result_queue_count_max | natural | C_RESULT_QUEUE_COUNT_MAX |
| | result_queue_count_threshold | natural | C_RESULT_QUEUE_COUNT_THRESHOLD |
| | result_queue_count_threshold_severity | t_alert_level | C_RESULT_QUEUE_COUNT_THERSHOLD_SEVERITY |
| | msg_id_panel | t_msg_id_panel | C_VVC_MSG_ID_PANEL_DEFAULT |
| | | | |

Clock Generator VVC Status record signal 'vvc_status' -- accessible via shared clock generator vvc status

| Record element | Туре | |
|------------------|---------|--|
| current_cmd_idx | natural | |
| previous_cmd_idx | natural | |
| pending_cmd_cnt | natural | |

Common VVC procedures applicable for this VVC

- See UVVM Methods QuickRef for details.

await_completion()

enable_log_msg()

 ${\bf disable_log_msg}()$

fetch_result()

flush_command_queue()

terminate_current_command()

terminate_all_commands()

insert_delay()

get_last_received_cmd_idx()



VHDL 2008 only



VVC target parameters

| Name | Туре | Example(s) | Description |
|------------------|---------------------|----------------------|--|
| VVCT | t_vvc_target_record | CLOCK_GENERATOR_VVCT | VVC target type compiled into each VVC in order to differentiate between VVCs. |
| vvc_instance_idx | integer | 1 | Instance number of the VVC |

VVC functional parameters

| Name | Туре | Example(s) | Description |
|-----------------|--------|-----------------------|---|
| clock_period | time | 10 ns | Clock period |
| clock_high_time | time | 5 ns | Time of the clock cycle that is '1'. Value have to be less than clock_period. |
| msg | string | "Read from DUT" | A custom message to be appended in the log/alert |
| scope | string | "CLOCK GENERATOR VVC" | A string describing the scope from which the log/alert originates. |

VVC entity signals

| Name | Туре | Direction | Description | |
|------|-----------|-----------|------------------|--|
| clk | std_logic | Output | VVC Clock signal | |

VVC entity generic constants

| Name | Туре | Default | Description |
|--|---------------|---------|---|
| GC_INSTANCE_IDX | natural | 1 | Instance number to assign the VVC |
| GC_CMD_QUEUE_COUNT_MAX | natural | 1000 | Absolute maximum number of commands in the VVC command queue |
| GC_CMD_QUEUE_COUNT_THRESHOLD | natural | 950 | An alert will be generated when reaching this threshold to indicate that the command queue is almost full. The |
| | | | queue will still accept new commands until it reaches C_CMD_QUEUE_COUNT_MAX. |
| GC_CMD_QUEUE_COUNT_THRESHOLD_SEVERITY | t_alert_level | WARNING | Alert severity which will be used when command queue reaches GC_CMD_QUEUE_COUNT_THRESHOLD. |
| GC_RESULT_QUEUE_COUNT_MAX | natural | 1000 | Maximum number of unfetched results before result_queue is full. |
| GC_RESULT_QUEUE_COUNT_THRESHOLD | natural | 950 | An alert with severity 'result_queue_count_threshold_severity' will be issued if result queue exceeds this count. |
| | | | Used for early warning if result queue is almost full. Will be ignored if set to 0. |
| GC_RESULT_QUEUE_COUNT_THRESHOLD_SEVERITY | t_alert_level | WARNING | Severity of alert to be initiated if exceeding result_queue_count_threshold |



VVC details

All VVC procedures are defined in vvc_methods_pkg (dedicated this VVC), and uvvm_vvc_framework.td_vvc_framework_common_methods_pkg (common VVC procedures) It is also possible to send a multicast to all instances of a VVC with ALL_INSTANCES as parameter for vvc_instance_idx.

Note: Every procedure here can be called without the optional parameters enclosed in [].

1 VVC procedure details and examples

| Procedure | Description | | | | | |
|-----------------------|--|--|--|--|--|--|
| start_clock() | start_clock(VVCT, vvc_instance_idx, msg, [scope]) | | | | | |
| | This procedure adds a start_clock command to the Clock Generator VVCs executor queue, which will run as soon as all preceding commands have completed. When the start_clock command is scheduled to run, the executor activates the clock generator process in the VVC. | | | | | |
| | <pre>Example: start_clock(CLOCK_GENERATOR_VVCT, 1, "Start clock generator", C_SCOPE);</pre> | | | | | |
| stop_clock() | stop_clock (VVCT, vvc_instance_idx, msg, [scope]) | | | | | |
| | This procedure adds a stop_clock command to the Clock Generator VVCs executor queue, which will run as soon as all preceding commands have completed. When the stop_clock command is scheduled to run, the executor deactivates the clock generator process in the VVC after finishing current clock cycle. | | | | | |
| | <pre>Example: stop_clock(CLOCK_GENERATOR_VVCT, 1 "Stop clock generator", C_SCOPE);</pre> | | | | | |
| set_clock_period() | set_clock_period (VVCT, vvc_instance_idx, clock_period, msg, [scope]) | | | | | |
| | This procedure adds a set_clock_period command to the CLOCK GENERATOR VVCs executor queue, which will run as soon as all preceding commands have completed. When the set_clock_period command is scheduled to run, the executor will change the clock period instantly. | | | | | |
| | <pre>Examples: set_clock_period(CLOCK_GENERATOR_VVCT, 1, 10 ns, "Change clock period to 10 ns", C_SCOPE);</pre> | | | | | |
| set_clock_high_time() | set_clock_high_time (VVCT, vvc_instance_idx, clock_high_time, msg, [scope]) | | | | | |
| | This procedure adds a set_clock_high_time command to the CLOCK_GENERATOR VVCs executor queue, which will run as soon as all preceding commands have completed. When the write command is scheduled to run, the executor changes the clock high time and the change will take effect from the next rising edge. | | | | | |
| | Examples: | | | | | |

set_clock_high_time(CLOCK_GENERATOR_VVCT, 1, 6 ns, "Changing the duty cycle to 60%", C_SCOPE);



2 VVC Configuration

| Record element | Туре | C_CLOCK_GENERATOR_CONFIG_DEFAULT | Description |
|---------------------------------------|----------------|--|--|
| cmd_queue_count_max | natural | C_CMD_QUEUE_COUNT_MAX | Maximum pending number in command queue before queue is full. Adding additional commands will result in an ERROR. |
| cmd_queue_count_threshold | natural | C_CMD_QUEUE_COUNT_THRESHOLD | An alert with severity "cmd_queue_count_threshold_severity" will be issued if command queue exceeds this count. Used for early warning if command queue is almost full. Will be ignored if set to 0. |
| cmd_queue_count_threshold_severity | t_alert_level | C_CMD_QUEUE_COUNT_THRESHOLD_SEVERITY | Severity of alert to be initiated if exceeding cmd_queue_count_threshold |
| result_queue_count_max | natural | C_RESULT_QUEUE_COUNT_MAX | Maximum number of unfetched results before result_queue is full. |
| result_queue_count_threshold | natural | C_RESULT_QUEUE_COUNT_THRESHOLD | An alert with severity 'result_queue_count_threshold_severity' will be issued if result queue exceeds this count. Used for early warning if result queue is almos full. Will be ignored if set to 0. |
| result_queue_count_threshold_severity | t_alert_level | C_ RESULT_QUEUE_COUNT_THRESHOLD_SEVERITY | Severity of alert to be initiated if exceeding result_queue_count_threshold |
| bfm_config | t_bfm_config | C_VOID_BFM_CONFIG | Record parameter required by the VVC Framework, not applicable for this VVC |
| msg_id_panel | t_msg_id_panel | C_VVC_MSG_ID_PANEL_DEFAULT | VVC dedicated message ID panel |

The configuration record can be accessed from the Central Testbench Sequencer through the shared variable array, e.g.:

shared clock generator vvc config(1).cmd queue count threshold := 250;

3 VVC Status

The current status of the VVC can be retrieved during simulation. This is achieved by reading from the shared variable shared_clock_generator_vvc_status record from the test sequencer. The record contents can be seen below:

| Record element | Туре | Description |
|------------------|---------|---|
| current_cmd_idx | natural | Command index currently running |
| previous_cmd_idx | natural | Previous command index to run |
| pending_cmd_cnt | natural | Pending number of commands in the command queue |

4 Activity watchdog

The VVCs support an activity watchdog which monitors VVC activity and will alert if no VVC activity is registered within a selected timeout value. The VVCs will register their presence to the activity watchdog at start-up, and report when busy and not, using dedicated activity watchdog methods and triggering the global_trigger_activity_watchdog signal, during simulations.

Include activity_watchdog(num_exp_vvc, timeout, alert_level, msg) in the testbench to start using the activity watchdog.

Note that the clock generator VVC is included in the total registered VVCs in the activity watchdog register, but its activity is not included in the resetting of the inactivity timeout counter. More information can be found in UVVM Essential Mechanisms PDF in the UVVM VVC Framework doc folder.



5 Additional Documentation

Additional documentation about UVVM and its features can be found under "/uvvm_vvc_framework/doc/".

6 Compilation

The Clock Generator VVC must be compiled with VHDL 2008.

It is dependent on the following libraries

- UVVM Utility Library (UVVM-Util), version 2.11.0 and up
- UVVM VVC Framework, version 2.7.1 and up

Before compiling the Clock Generator VVC, assure that uvvm_vvc_framework and uvvm_util have been compiled.

See UVVM Essential Mechanisms located in uvvm vvc framework/doc for information about compile scripts.

Compile order for the Clock Generator VVC:

| Compile to library | File | Comment |
|----------------------------|--|---|
| bitvis_vip_clock_generator | vvc_cmd_pkg.vhd | Clock Generator VVC command types and operations |
| bitvis_vip_clock_generator | /uvvm_vvc_framework/src_target_dependent/td_target_support_pkg.vhd | UVVM VVC target support package, compiled into the Clock Generator VVC library. |
| bitvis_vip_clock_generator | /uvvm_vvc_framework/src_target_dependent/td_vvc_framework_common_methods_pkg.vhd | Common UVVM framework methods compiled into the Clock Generator |
| | | VVC library |
| oitvis_vip_clock_generator | vvc_methods_pkg.vhd | Clock Generator VVC methods |
| bitvis_vip_clock_generator | /uvvm_vvc_framework/src_target_dependent/td_queue_pkg.vhd | UVVM queue package for the VVC |
| bitvis_vip_clock_generator | /uvvm_vvc_framework/src_target_dependent/td_vvc_entity_support_pkg.vhd | UVVM VVC entity support compiled into the Clock Generator VVC librar |
| bitvis vip clock generator | clock generator vvc.vhd | Clock Generator VVC |

7 Simulator compatibility and setup

See README.md for a list of supported simulators.

For required simulator setup see *UVVM-Util* Quick reference.



Disclaimer: This IP and any part thereof are provided "as is", without warranty of any kind, express or implied, including but not limited to the warranties of merchantability, fitness for a particular purpose and noninfringement. In no event shall the authors or copyright holders be liable for any claim, damages or other liability, whether in an action of contract, tort or otherwise, arising from, out of or in connection with this IP.