



## COMPUTER ORGANIZATION AND SOFTWARE SYSTEMS

BITS Pilani
Pilani Campus

Lakshmikantha G C WILP & Department of CS & IS




# Webinar-2 MIPS-Multicycle Implementation BITS Pilani Pilani Campus

#### Last Class...

- MIPS Instruction set architecture
- Datapath for
  - fetching instructions
  - updating program counter
  - implementing R-type ALU operations
  - implementing data memory unit and the sign extension unit
  - datapath for implementing branch instructions
- Effect of control signals

lead



BITS Pilani, Deemed to be University under Section 3 of UGC Act, 1956



## Effects of 7 control signals

Signal name	Effect when deasserted	Effect when asserted		
RegDst	The register destination number for the Write register comes from the rt field (bits 20:16).	The register destination number for the Write register comes from the rd field (bits 15:11).		
RegWrite	None.	The register on the Write register input is written with the value on the Write data input.		
ALUSrc	The second ALU operand comes from the second register file output (Read data 2).	The second ALU operand is the sign- extended, lower 16 bits of the instruction.		
PCSrc	The PC is replaced by the output of the adder that computes the value of PC + 4.	The PC is replaced by the output of the adder that computes the branch target.		
MemRead	None.	Data memory contents designated by the address input are put on the Read data output.		
MemWrite	None.	Data memory contents designated by the address input are replaced by the value on the Write data input.		
MemtoReg	The value fed to the register Write data input comes from the ALU.	The value fed to the register Write data input comes from the data memory.		





## Effect of ALUop

ALUop	Instructions
00 _	Iw, sw — I - type
01	Beq
10	add, sub, and, or, slt _ R - hype

## Execution steps: sw \$s1, 100(\$s2)


- 1. The instruction is fetched, and the PC is incremented
- 2. A register \$52 and \$51 value is read from the register file
- 3. The ALU computes the sum of the value read from the register s2 and the sign extended lower 16 bits of the instruction
  - 4. the sum from the ALU is used as the address for the data memory and writes the contents of \$s1 on to memory





# Home Work: Execution steps:beq \$\$1,\$\$2, offset


- 1. The instruction is fetched, and the PC is incremented
- 2. Two registers \$s1 and \$s2 are read from the register file
- 3. The ALU performs a subtract on the data values read from the register file. The value of PC + 4 is added to the sign extended, lower 16 bits of the instruction (offset) sifted left by two; the result is the branch target address
- 4. The zero result from the ALU is used to decide which adder result to store into the PC



## Single Cycle Advantages & Disadvantages



- Uses the clock cycle inefficiently the clock cycle must be timed to accommodate the slowest instruction
  - May be wasteful of area since some functional units (e.g., adders) must be duplicated since they can not be shared during a clock cycle but is simple and easy to understand



Lucy J. Gudino



## Multicycle datapath approach

- also called multiple clock cycle implementation
- an instruction is executed in multiple clock cycles
- Advantage: hardware sharing and ability to allow instructions to take different numbers of clock cycles
- Break up instructions into steps where each step takes a cycle while trying to
  - balance the amount of work to be done in each step
  - restrict each cycle to use only one major functional unit
- Not every instruction takes the same number of clock cycles

## Single cycle vs multicycle




- Single cycle:
  - Two memory units one for instruction and one for data
  - one ALU and two adders
- Multicycle:
  - A single memory unit for both instructions and data
    - · only one memory access per cycle
  - only a single ALU
    - only one ALU operation per cycle
  - one or more registers are added after every major functional unit to hold the output of that unit until the value is used in a subsequent clock cycle

## innovate achieve lead

## Temporary registers

- IR → Instruction Register
- MDR → Memory Data Register
- A,B→ used to hold the register operand values read from the register file
- ALUout 

  holds the output of the ALU




#### Contd...

#### Important note:

- 1. all data that is used in subsequent clock cycles must be stored in inter stage registers
- 2. Data used by subsequent instruction is stored in programmer visible registers (i.e., register file, PC, or memory)
- 3. All the registers except IR do not need a write control signal
- 4. Expand the multiplexer units

## The Five Steps

- Step 1: IF (Instruction Fetch)
- Step 2: ID (Instruction Decode)
- Step 3 : EX (Execute)
- Step 4: MEM (Memory) /
- Step 5: WB (Write Back)



## Step1: IF (Instruction Fetch)

Instruction Fetch and Update PC

## Step 2: ID (Instruction Decode)

- Following operations are performed
  - read two registers corresponding to rs and rt fields

```
A ← Reg [ IR [25:21]] γς-
B ← Reg [ IR [20:16]] γ<sub>ξ</sub>
```

compute branch target address with ALU

## Step 3: EX (Execute)

- · Four operations are possible
  - 1. Memory reference




ALUout  $\leftarrow$  A + sign-extend (IR[15:0])


- 2. Arithmetic and logical instruction
- ✓ ALUout ← A op B
- 3. Branch

BEQ

PC ← ALUout



>PC ← { PC[31:28], (IR [25:0] << 2)






## Step 4: MEM (Memory)

- Memory access or R type instruction completion step
  - 1. Memory Access
    - MDR ← Memory [ALUout] or FA
      - Memory [ALUout] ← B
  - 2. R-Type Instruction Completion
  - Reg [ IR [15: 11]] ← ALUout

## Step 5: WB (Write Back)

- Memory read completion step
  - Reg [ IR [20:16 ] ] ← MDR





## R-Type Instruction: add \$51, \$52, \$53


#### Step1: IFetch

IR 
$$\leftarrow$$
 Memory [PC] PC $\leftarrow$  PC + 4



#### Step 3: Exec

- 1. Memory reference
  - ALUout  $\leftarrow$  A + sign-extend (IR[15:0])
- 2. Arithmetic and logical instruction
  - ALUout  $\leftarrow$  A op B





4. Jump

PC ← { PC[31:28], (IR [25:0] << 2)

#### Step 5: WB

Memory read completion step

- Reg [ IR [20:16 ] ] ← MDR


#### Step 2: Dec

- nead two registers corresponding to rs and rt fields
  - A ← Reg [ IR [25:21] ]
  - B ← Reg [ IR [20:16] ]
- compute branch target address with ALU

  ALUout ← PC + (sign-extend (IR[15-0]) << 2)

#### Step 4: Mem

- 1. Memory Access
  - MDR ← Memory [ALUout]
  - or
  - Memory [ALUout] ← B
- 2. R-Type Instruction Completion Reg [ IR [15: 11]] ← ALUout



## lw Instruction: lw \$51, 100(\$52)

#### Step1: IFetch

IR  $\leftarrow$  Memory [PC] PC $\leftarrow$  PC + 4

#### Step 3: Exec

- 1. Memory reference
  - ALUout  $\leftarrow$  A + sign-extend (IR[15:0])
- 2. Arithmetic and logical instruction  $ALUout \leftarrow A$  op B
- 3.Branch
  if ( A == B ) PC ← ALUout
- 4. Jump
  PC ← { PC[31:28], (IR [25:0] << 2)

#### Step 5: WB

Memory read completion step

- Reg [ IR [20:16 ] ] ← MDR

#### Step 2: Dec

- read two registers corresponding to rs and rt fields
  - A ← Reg [ IR [25:21] ]
  - B 🗲 Reg [ IR [20:16] ]
- ★ compute branch target address with ALU
   ALUout ← PC + (sign-extend (IR[15-0]) << 2)
  </p>

#### Step 4: Mem

- 1. Memory Access
  - MDR ← Memory [ALUout]
    - or
    - Memory [ALUout] ← B
- 2. R-Type Instruction Completion Reg [ IR [15: 11]] ← ALUout

## sw Instruction: sw \$51, 100(\$52)

#### Step1: IFetch

IR  $\leftarrow$  Memory [PC] PC $\leftarrow$  PC + 4

#### Step 3: Exec

- 1. Memory reference

  ALUout ← A + sign-extend (IR[15:0])
- 2. Arithmetic and logical instruction ALUout  $\leftarrow$  A op B
- 3.Branch
  if ( A == B ) PC ← ALUout
- 4. Jump
  PC ← { PC[31:28], (IR [25:0] << 2)

#### Step 5: WB

Memory read completion step


- Reg [ IR [20 : 16 ] ] ← MDR

#### Step 2: Dec

- read two registers corresponding to rs and rt fields
  - A ← Reg [ IR [25:21] ]
  - B ← Reg [ IR [20:16] ]
- compute branch target address with ALU
   ALUout ← PC + (sign-extend (IR[15-0]) << 2)</li>

#### Step 4: Mem

- 1. Memory Access
  - MDR ← Memory [ALUout]
    - or
  - Memory [ALUout] ← B
- R-Type Instruction Completion Reg [ IR [15: 11]] ← ALUout



## beq Instruction: beq \$51, \$52, 100

#### Step1: IFetch

IR  $\leftarrow$  Memory [PC]  $PC \leftarrow PC + 4$ 

#### Step 3: Exec

1. Memory reference

ALUout  $\leftarrow$  A + sign-extend (IR[15:0])

2. Arithmetic and logical instruction  $ALUout \leftarrow A$  op B

3 Branch

if ( A == B )  $PC \leftarrow ALUout$ 

4. Jump

PC ← { PC[31:28], (IR [25:0] << 2)

#### Step 5: WB

Memory read completion step

- Reg [ IR [20:16 ] ] ← MDR

#### Step 2: Dec

read two registers corresponding to rs and rt fields

A ← Reg [ IR [25:21] ]

B ← Reg [ IR [20:16] ]

compute branch target address with ALU

ALUout ← PC + (sign-extend (IR[15-0]) << 2)

#### Step 4: Mem

1. Memory Access

MDR ← Memory [ALUout]

or

Memory [ALUout] ← B

2. R-Type Instruction Completion Reg [ IR [15: 11]] ← ALUout


CP1=3


## Summary

- R-Type: Require four cycles, CPI =4
   IF, ID, EX, WB
- Loads Require five cycles, CPI = 5
   IF, ID, EX, MEM, WB
- Store: Require four cycles, CPI = 4
   IF, ID, EX, MEM
- Branch: Require three cycles, CPI = 3
   IF, ID, EX

## Complete Data Path (1/3)








Complete Data Path (3/3)
1: PC gets

achieve lead innovate





## Actions of the 1 bit control signals

Signal name	Effect when deasserted	Effect when asserted	
RegDst	The register file destination number for the Write register comes from the rt field.	The register file destination number for the Write register comes from the rd field.	
RegWrite	None.	The general-purpose register selected by the Write register number is written with the value of the Write data input.	
ALUSrcA	The first ALU operand is the PC.	The first ALU operand comes from the A register.	
MemRead	None.	Content of memory at the location specified by the Address input is put on Memory data output.	
MemWrite	None.	Memory contents at the location specified by the Address input is replaced by value on Write data input.	
MemtoReg	The value fed to the register file Write data input comes from ALUOut.	The value fed to the register file Write data input comes from the MDR.	
lorD	The PC is used to supply the address to the memory unit.	ALUOut is used to supply the address to the memory unit.	
IRWrite	None.	The output of the memory is written into the IR.	
PCWrite	None.	The PC is written; the source is controlled by PCSource.	
PCWriteCond	None.	The PC is written if the Zero output from the ALU is also active.	



## Actions of the 2 bit control signals

Signal name	Value (binary)	Effect	
ALUOp	00	The ALU performs an add operation.	
	01	The ALU performs a subtract operation.	
	10	The funct field of the instruction determines the ALU operation.	
ALUSrcB	00	The second input to the ALU comes from the B register.	
	01	The second input to the ALU is the constant 4.	
	10	The second input to the ALU is the sign-extended, lower 16 bits of the IR.	
	11	The second input to the ALU is the sign-extended, lower 16 bits of the IR shifted left 2 bits.	
PCSource	00	Output of the ALU (PC + 4) is sent to the PC for writing.	
	01	The contents of ALUOut (the branch target address) are sent to the PC for writing.	
	10	The jump target address (IR[25:0] shifted left 2 bits and concatenated with PC + 4[31:28]) is sent to the PC for writing.	

## First Step



- ☐ Instruction Fetch: TFetch
- $\cdot$  IR  $\leftarrow$  Memory [PC]: 0: PC
- 1 MemRead <sub>–</sub>
- 1 IRWrite
- 🔼 IorD
- PC← PC + 4:
- ALUSrcA
- 01 ALUSrcB
  - ALUop
  - PCSource
  - PCWrite

0: First operand is in PC

1: First operand is in register A

Second operand

00: A register

01:4

1: ALUout

10:Sign Extd lower 16 bits of IR

11 :Sign Extd lower 16 bits of IR << 2

#### Contd...





#### ☐ Instruction Fetch:

- IR  $\leftarrow$  Memory [PC]:
- MemRead
- IRWrite
- o IorD
  - PC← PC + 4:
- ALUSrcA
- 01 ALUSrcB
- oo ALUop
- oo PCSource
  - PCWrite

00: Add operation

01: Subtract Operation

10: Function field of the instruction

determines the ALU operation

00: PC + 4 output of ALU

01: branch target address ALUout

10:jump target address

## Second Step

0: First operand is PC

1: First operand is register



lead

achieve

Instruction decode and rg

- read two registersfields
- compute branch

A ← Reg [ IR [/ ∠1]

B ← Reg [ IR/ 0:16]]

ALUout ← P/ + (sign-g

Second operand

00: register

01:4

10:Sign Extd lower 16 bits of IR

11 :Sign Extd lower 16 bits of IR << 2

(IR[15-0]) << 2)

ALUSrcA

**ALUSrcB** 

00: Add

01: Subtract

10:Function field determines the

**ALU** operation

00 ALUor

11



Step 3

## Execution, memory address computation, or branch completion

- Four operations are possible
- Memory reference generation
   ALUout ← A + sign-extend (IR[15:0])
- 2. Arithmetic and logical instruction  $ALUout \leftarrow A$  op B
- 3.Branch
  if ( A == B ) PC ← ALUout
- 4. Jump
  PC ← { PC[31:28], (IR [25:0] << 2)



0: First operand is PC

1. Memory reference 1: First operand is register A

ALUout A + sign-extens (IR[15:0])

1 - ALUSrcA

Second operand

- 00: register
- 01:4
- 10:Sign Extd lower 16 bits of IR
- 11 :Sign Extd lower 16 bits of IR << 2

10 - ALUSrcB

00 - ALUop

00: Add operation

**01: Subtract Operation** 

10:Function field of the instruction

determines the ALU operation





#### 2. Arithmetic and logical instruction

ALUout ← A op B

ALUSrcA

0: First operand is PC

1: First operand is register

**ALUSrcB** 

00: register

01:4

10:Sign Extd lower 16 bits of IR

11 :Sign Extd lower 16 bits of IR << 2

ALUop. 10

00: Add operation

01: Subtract Operation

10: Function field of the instruction

determines the ALU operation

- 0: First operand is PC
- 1: First operand is register



3. Branch

1 - ALUSrcA

- 00: register
- 01:4
- 10:Sign Extd lower 16 bits of IR
- 11 :Sign Extd lower 16 bits of IR << 2

- 00 ALUSrcB
- 01 ALUop
- 1 PCWrite

- 00: Add operation
- 01: Subtract Operation(beq)
- 10: Function field of the instruction
- determines the ALU operation
- 00: PC + 4 output of ALU
- 01: branch target address ALUout
- 10:jump target address

01 - PCSource





#### 4. Jump

 $PC \leftarrow \{ PC[31:28], (IR [25:0] << 2) \}$ 

10 - PCSource

1 - PCWrite

00: PC + 4 output of ALU

01: branch target address ALUout

10:jump target address

## Step 4

- Memory access or R type instruction completion step
  - Two operations are possible
    - Memory reference
       MDR ← Memory [ALUout]
       or
       Memory [ALUout] ← B
    - Arithmetic and logical instruction
       Reg [ IR [15: 11]] ← ALUout





```
Memory reference
```

lw

MDR ← Memory [ALUout]

- MemRead
- 1 IorD

Memory [ALUout] ← B

- MemWrite
- **I**orD



## Step 4 contd...



Arithmetic and logical instruction

Reg [ IR [15: 11]] ← ALUout

- RegDst\_
- RegWrite
- MemtoRég



## Step 5




Write back or Memory read completion step

- Reg [ IR [20:16] ] ← MDR

RegWrite \_\_

RegDst\_





## Summary

Step name	Action for R-type instructions	Action for memory- reference instructions	Action for branches	Action for jumps	
Instruction fetch	IR <= Memory[PC] PC <= PC + 4				
Instruction decode/register fetch	A <= Reg [IR[25:21]]  B <= Reg [IR[20:16]]  ALUOut <= PC + (sign-extend (IR[15:0]) << 2)				
Execution, address computation, branch/jump completion	ALUOut <= A op B	ALUOut <= A + sign-extend (IR[15:0])	if (A === B) PC <= ALUOut	PC <= {PC [31:28], (IR[25:0]],2'b00)}	
Memory access or R-type completion	Reg [IR[15:11]] <= ALUOut	Load: MDR <= Memory[ALUOut] or Store: Memory [ALUOut] <= B			
Memory read completion		Load: Reg[IR[20:16]] <= MDR			



