



COMPUTER ORGANIZATION AND SOFTWARE SYSTEMS SESSION 5

BITS Pilani
Pilani Campus

Prof. CR Sarma





CISC Instruction Set (Intel x86 as an example)

Pilani Campus



Today's Session

Contact Hour	List of Topic Title	Text/Ref Book/external resource
9-10	 Instruction Set Architecture - CISC Vs RISC CISC Instruction Set (Intel x86 as an example) Machine Instruction Characteristics Types of Operands Types of Operations Addressing Modes Instruction Formats 	T1

Introduction




- •What is an Instruction Set?
 - The complete collection of instructions that are understood by a CPU
- •Elements of an Instruction
 - Operation code (Op code)
 - Source Operand reference
 - Result Operand reference
 - Next Instruction Reference
- Source and Destination Operands can be found in four areas
 - Main memory (or virtual memory or cache)
 - CPU register
 - I/O device
 - Immediate

Simple Instruction Format



4 bits	6 bits	6 bits

Opcode Operand Reference Operand Reference



- During instruction execution, an instruction is read into an instruction register (IR) in the processor.
- The processor must be able to extract the data from the various instruction fields to perform the required operation.
- Opcodes are represented by abbreviations, called mnemonics

Example: ADD AX, BX -> Add instruction

Instruction Types

- Data processing: Arithmetic and logic instructions
- Data storage (main memory): Movement of data into or out of register and or memory locations
- Data movement (I/O): I/O instructions
- Program flow control: Test and branch instructions

Number of Addresses (1/2)



- 3 addresses
 - Result, Operand 1, Operand 2
 - -c = a + b; add c, a, b
 - May be a forth next instruction (usually implicit)
 - Needs very long words to hold everything
- 2 addresses
 - One address doubles as operand and result
 - a = a + b : add a, b
 - Reduces length of instruction
 - The original value of a is lost.

Number of Addresses (2/2)



- 1 address
 - -Implicit second address
 - -Usually a register (accumulator)
 - -Common on early machines
- 0 (zero) addresses
 - -All addresses implicit
 - -Uses a stack

pop c



Example

Execute
$$Y = \frac{A - B}{C + (D \times E)}$$

Instru	ction	Comment
SUB	Y, A, B	$Y \leftarrow A - B$
MPY	T, D, E	$T \leftarrow D \times E$
ADD	T, T, C	$T \leftarrow T + C$
DIV	Y, Y, T	$Y \leftarrow Y \div T$

(a) Three-address instructions

Instruction	Comment
MOVE Y, A	$Y \leftarrow A$
SUB Y, B	$Y \leftarrow Y - B$
MOVE T, D	$T \leftarrow D$
MPY T, E	$T \leftarrow T \times E$
ADD T, C	$T \leftarrow T + C$
DIV Y, T	$Y \leftarrow Y \div T$

(b) Two-address instructions

Instruc	tion	Comment
LOAD	D	$AC \leftarrow D$
MPY	E	$AC \leftarrow AC \times E$
ADD	C	$AC \leftarrow AC + C$
STOR	Y	$Y \leftarrow AC$
LOAD	A	$AC \leftarrow A$
SUB	В	$AC \leftarrow AC - F$
DIV	Y	$AC \leftarrow AC \div Y$
STOR	Y	$Y \leftarrow AC$

(c) One-address instructions

How Many Addresses

- Fewer addresses
 - More Primitive instructions, shorter length instructions
 - Less complex instructions, hence requires less complex hardware
 - More instructions per program
 - Longer programs
 - More complex programs
 - Longer execution time
- Multiple address instructions
 - Lengthy instructions
 - More registers
 - •Inter-register operations are quicker
 - Fewer instructions per program

Instruction set Design Decisions



- Operation repertoire
 - How many ops?
 - What can they do?
 - How complex are they?
- Data types
- Instruction formats
 - Length of op code field
 - Number of addresses
- Registers
 - Number of CPU registers available
 - Which operations can be performed on which registers?
- Addressing modes

innovate achieve lead

Types of Operand


- Machine instructions operate on data
- General categories of data
 - Addresses
 - Numbers
 - Binary integer or binary fixed point, floating point, decimal
 - Characters
 - · ASCII etc.
 - Logical Data
 - · Bits or flags
- Packed Decimal
 - 36:0011 0110


Binary Representation

32 16 8 4 2 1 1 0 0 1 0 0



Byte Ordering





innovate achieve lead

x86 Data Types

- General Byte, Word, double word, quadword, double quad word - arbitrary binary contents
- Integer signed binary using two's complement representation
- Ordinal unsigned integer
- Unpacked BCD One digit per byte
- Packed BCD 2 digits per byte
- Near Pointer 32 bit offset within segment
- Far pointer -
- Bit field: A contiguous sequence of bits in which the position of each bit is considered as an independent unit.
- Bit and Byte String
- Floating Point

Data Type	Description
General	Byte, word (16 bits), doubleword (32 bits), quadword (64 bits), and double quadword (128 bits) locations with arbitrary binary contents.
Integer	A signed binary value contained in a byte, word, or doubleword, using twos complement representation.
Ordinal	An unsigned integer contained in a byte, word, or doubleword.
Unpacked binary coded decimal (BCD)	A representation of a BCD digit in the range 0 through 9, with one digit in each byte.
Packed BCD	Packed byte representation of two BCD digits; value in the range 0 to 99.
Near pointer	A 16-bit, 32-bit, or 64-bit effective address that represents the offset within a segment. Used for all pointers in a nonsegmented memory and for references within a segment in a segmented memory.
Far pointer	A logical address consisting of a 16-bit segment selector and an offset of 16, 32, or 64 bits. Far pointers are used for memory references in a segmented memory model where the identity of a segment being accessed must be specified explicitly.
Bit field	A contiguous sequence of bits in which the position of each bit is considered as an independent unit. A bit string can begin at any bit position of any byte and can contain up to 32 bits.
Bit string	A contiguous sequence of bits, containing from zero to $2^{32} - 1$ bits.
Byte string	A contiguous sequence of bytes, words, or doublewords, containing from zero to $2^{32}-1$ bytes.
Floating point	See Figure 10.4.
Packed SIMD (single instruction, multiple data)	Packed 64-bit and 128-bit data types


x86 Numeric Data

innovate achieve lead

Formate

sign bit

79



Types of Operation

- Data Transfer
- Arithmetic
- Logical
- Conversion
- I/O
- System Control
- Transfer of Control

innovate achieve lead

Data Transfer

- Specify
 - Source
 - Destination
 - Amount of data
- Action:
- Calculate the memory address, based on the address mode
- If the address refers to virtual memory, translate from virtual to real memory address.
- 3. Determine whether the addressed item is in cache.
- 4. If not, issue a command to the memory module.

Arithmetic

- · Add, Subtract, Multiply, Divide
- May include
 - Absolute value (|a|)
 - Increment (a++)
 - Decrement (a--)
 - Negate (-a)
- Signed Integer
- Floating point?

Logical

- Bitwise operations
- AND, OR, NOT


Basic Logical Operations

P	Q	NOT P	P AND Q	P OR Q	P XOR Q	P = Q
0	0	1	0	0	0	1
0	1	1	0	1	1	0
1	0	0	0	1	1	0
1	1	0	1	1	0	1

Shift and Rotate

innovate achieve lead

Operations



Conversion

E.g. Binary to Decimal

Convert 174₁₀ to binary:

Division by 2	Quotient	Remainder	Bit #
174/2	87	0	0
87/2	43	1	1
43/2	21	1	2
21/2	10	1	3
10/2	5	0	4
5/2	2	1	5
2/2	1	0	6
1/2	0	1	7

So
$$174_{10} = 101011110_2$$

Input/Output

- May be specific instructions (I/O-Mapped I/O)
- May be done using data movement instructions (memory mapped)
- May be done by a separate controller (DMA)

Systems Control

- Privileged instructions
- CPU needs to be in specific state
 - User Mode
 - Kernel mode
- For operating systems use

Transfer of Control

- Jump / Branch (Unconditional / Conditional)
 - -e.g. jump to x if result is zero
- Skip (Unconditional / Conditional)
 - skip (unconditional): Increment to skip next instruction
 - -e.g. increment and skip if zero ISZ Register1


Branch xxxx

ADD A

- Subroutine call
- interrupt call

Branch / Jump Instruction





Use of Stack


4101

(b) After

CALL Proc1

(a) Initial stack

contents



BITS Pilani, Pilani Campus

Addressing Modes

- Addressing modes refers to the way in which the operand of an instruction is specified
- Types:
 - Immediate
 - Direct
 - Indirect
 - Register
 - Register Indirect
 - Displacement (Indexed)
 - Stack

Immediate Addressing

- Operand is specified in the instruction itself
- e.g. ADD #5
 - Add 5 to contents of accumulator
 - 5 is operand
- No memory reference to fetch data
- Fast
- Limited range


Instruction

Operand

innovate achieve lead

Direct Addressing


- Address of the operand is specified in the instruction
- Effective address (EA) = address field
 (A)
- e.g. ADD A
 - Add contents of memory cell whose address is A to accumulator
 - Look in memory at address A for operand
- Single memory reference to access data
- No additional calculations to work out effective address
- Limited address space





Indirect Addressing

- Memory cell pointed to by address field of the instruction contains the address of (pointer to) the operand
- EA = (A)
 - Look in A, find address and look there for operand
- e.g. ADD (A)
 - Add contents of cell pointed to by contents of A to accumulator



Indirect Addressing...


- Large address space
- 2ⁿ where n = word length
- May be nested, multilevel, cascaded

$$- e.g. EA = (((A)))$$

- Multiple memory accesses to find operand
- Slower

Register Addressing


- Operand is held in register named in address filed
- EA = R
- Limited number of registers
- Very small address field needed
 - Shorter instructions
 - Faster instruction fetch
- No memory access hence Very fast execution but very limited address space
- Multiple registers helps in improving performance
 - Requires good assembly programming or compiler writing





Register Indirect Addressing


- Similar to indirect addressing
- EA = (R)
- Operand is in memory cell pointed to by contents of register R
- Large address space (2ⁿ)
- One memory access compared indirect addressing



innovate achieve lead

Displacement Addressing

- EA = A + (R)
- Address field hold two values
 - -A = base value
 - R = register that holds displacement
 - or vice versa
- Three variants:
 - Relative addressing
 - Base register addressing
 - Indexing



Relative Addressing

- Also known as PC relative addressing
- · A version of displacement addressing
- •R = Program counter, PC
- $\bullet EA = A + (PC)$
- •Relative addressing exploits the concept of locality
 - If most memory references are relatively near to the instruction being executed, then the use of relative addressing saves address bits in the instruction.



Base-Register Addressing

- The referenced register "R" contains a main memory address
- address field contains a displacement A
- R may be explicit or implicit
- e.g. segment registers in 80x86

Indexed Addressing

- The address field references a main memory address

 A
- The referenced register R contains a positive displacement from that address.
- EA = A + R
- Good for accessing arrays
 - -EA = A + R
 - R++



Auto Indexing

Auto indexing incase certain registers are devoted exclusively to indexing

$$EA = A + (R)$$

$$(R) \leftarrow (R) + 1$$

Example: LODSB: Load byte at DS:[SI] into AL. Update SI.

SI is incremented or decremented based on direction flag.

$$D = 0 \rightarrow increment SI$$

$$D = 1 \rightarrow \text{decrement SI}$$

- Two types:
 - Postindex
 - Preindex

Post-indexing

- indexing is performed after the indirection EA = (A) + (R)
- Steps:
 - The contents of the address field are used to access a memory location containing a direct address.
 - Address is then indexed by the register value
- Use:
 - for accessing one of a number of blocks of data of a fixed format


Pre-indexing

- An address is calculated as with simple indexing EA = (A + (R))
- Use:
 - to construct a multiway branch table



Stack Addressing

- · Operand is (implicitly) on top of stack
- e.g.
 - ADD Pop top two items from stack and add, push the result on stack top





x86 Addressing Modes


Virtual or effective address is offset into segment

- Starting address plus offset gives linear address
- This goes through page translation if paging enabled

12 addressing modes available

- Immediate
- Register operand
- Displacement
- Base
- Base with displacement
- Scaled index with displacement
- Base with index and displacement
- Base scaled index with displacement
- Relative

x86 Addressing Mode Calculation



innovate achieve lead

Instruction Formats

- · Layout of bits in an instruction
- Includes opcode
- Includes (implicit or explicit) operand(s)
- Usually more than one instruction format in an instruction set



Instruction Length

Affected by and affects:

- Memory size
- Memory organization
- Bus structure
- CPU complexity
- CPU speed

Trade off between powerful instruction repertoire and saving space

Allocation of Bits

- Number of addressing modes
- Number of operands
- Register versus memory
- Number of register sets
- Address range
- Address granularity

Back2-12

Two 2 digit numbers are to be added and they are 29 & 69

- Type on keyboard 29 and the keyboard buffer will store ASCII code 32H 39H (49 57) will be stored In memory a two locations as 02 09 by stripping off the upper 4 bits 3XH and it is unpacked BCD
- This is packed up by taking the leftmost and adding its right neighbour by shifting it right 4 times 09 will be added to 02← 20 so it is packed in one byte 29
- 3. This is 36H and 39H to get 69H

Packed BCD addition

Example 1	Example 2
29H = 00101001B	27H = 00100111B
69H = 01101001B	34H = 00110100B
$\overline{92H} = \overline{10010010B}$	$\overline{5BH} = \overline{01011101B}$
Should be 98H (add 6)	Should be 61H (add 6)