J1a SwapForth Reference

James Bowman
jamesb@excamera.com
Excamera Labs
Pescadero
California USA

\odot 2015, James Bowman All rights reserved

ANS Forth Compliance Label

J1a SwapForth is an ANS Forth System

Providing names from the **Core Extensions** word set Providing names from the **Double-Number** word set

Providing names from the Facility word set

Providing names from the ${f Facility}$ ${f Extensions}$ word set

Providing names from the **String** word set

Providing names from the **Programming-Tools** word set

Providing names from the Programming-Tools Extensions word set

Contents

1.	Gettir	ng started	5
	1.1.	Some demos	6
	1.2.	Building from Scratch	8
2.	Availa	ble Words	11
	2.1.	ANS Core Words	11
	2.2.	Additional Words	12
3.	The S	wapForth Shell	15
	3.1.	Command reference	15
	3.2.	Tethered Mode	15
4.	Memo	ory	17
	4.1.	RAM Types	17
	4.2.	Dictionary Layout	17
5.	iCEsti	ick Hardware interface	19
	5.1.	Port Map	21
	5.	1.1. $\$0001$: Digilent Pmod TM data	21
	5.	1.2. \$0002: Digilent Pmod TM direction	21
	5.	1.3. \$0004: LEDs	21
	5.	1.4. \$0008: PIO output	21
	5.	1.5. \$1000: UART data	22
	5.	1.6. \$2000: IrDA, flash and UART inputs	22
In	dex		23

4 CONTENTS

Getting started



J1a SwapForth is a 16-bit version of SwapForth, intended as an interactive Forth system using very little logic and RAM. The system currently fits on a Lattice iCE40HX-1k FPGA. The J1a and peripherals uses 1100 logic elements. SwapForth uses 5 Kbytes of RAM, leaving about 3 Kbytes for the application.

After installing the icestorm tools, you can run on a Lattice iCEstick like this

git clone git@github.com:jamesbowman/swapforth.git
cd swapforth/j1a

```
iceprog icestorm/j1a.bin
python shell.py -h /dev/ttyUSB0
```

(where <code>/dev/ttyUSBO</code> is the appropriate port your iCEstick was assigned). You should see something like

```
Contacting... established
Loaded 196 words
>
```

And you can now try the usual Forth things, e.g.

```
1 2 + .
3 ok
```

There is a fairly complete core ANS-compatible Forth system running on the board, including a compiler.

1.1 Some demos

You can control the five on-board LEDs

```
-1 leds
ok

0 leds
ok
```

and to make them blink

```
: blink
32 0 do
i leds
100 ms
loop
;
blink
```

There is an Easter date calculator

```
new
#include ../demos/easter.fs
```

Now you can do

```
>2015 .easter
2015 April 5 ok
```

Or even

```
>: 20easters
+ 2035 2015 do
+ cr i .easter
+ loop
+;
ok
>20easters
2015 April 5
2016 March 27
2017 April 16
```

```
2018 April 1
2019 April 21
2020 April 12
2021 April 4
2022 April 17
2023 April 9
2024 March 31
2025 April 20
2026 April 5
2027 March 28
2028 April 16
2029 April 1
2030 April 21
2031 April 13
2032 March 28
2033 April 17
2034 April 9
               ok
```

1.2 Building from Scratch

After installing the icestorm tools, run

```
rm build/*
make -C icestorm
```

This will produce jla.bin - but it only contains the very bare-bones system; the rest of SwapForth still needs to be compiled. To do this, load jla.bin and start the shell:

```
$ iceprog icestorm/j1a.bin
$ python shell.py -h /dev/ttyUSBO -p ../common/
Contacting... established
Loaded 127 words
>
```

Then compile the rest of SwapForth and write the finished executable with these commands:

```
#include swapforth.fs
#flash build/nuc.hex
#bye
```

Now run ${\tt make}$ -C icestorm again - this compiles an FPGA image with the complete code base built-in.

Available Words

2.1 ANS Core Words

J1a SwapForth implements most of the core ANS 94 Forth standard. Implemented words are:

! # #> #s ' (* */ */mod + +! +loop , - . ." / /mod 0< 0= 1+ 1- 2! 2* 2/ 2@ 2drop 2dup 2over 2swap : ; < <# = > >in >number >r ?dup @ abort abs accept align aligned allot and base begin bl c! c, c@ cell+ cells char char+ chars constant count cr create decimal depth do does> drop dup else emit evaluate execute exit fill find fm/mod here hold i if immediate invert j key literal loop lshift m* max min mod move negate or over postpone quit r> r@ recurse repeat rot rshift s" s>d sign sm/rem source space spaces state swap then type u. u< um* um/mod unloop until variable while word xor [['] [char]] These core words are not implemented:

>body abort" environment? leave

J1a SwapForth also implements the following standard words:

.(.r .s /string 0<> 0> :noname <> ?do again ahead case cmove cmove> compile, d+ d. d.r d0= d2* dabs dnegate dump endcase endof erase false hex key? m+ marker ms nip of pad parse refill restore-input save-input sliteral throw true tuck u.r u> unused within words [compile] \setminus

Double numbers are supported using the standard . suffix. The Forth 200x number prefixes are supported: \$ for hex, # for decimal, % for binary, and 'c' for character literals. parse-name is also implemented.

2.2 Additional Words

The following words are not standard. Some are traditional Forth words, others are specific to the J1a SwapForth implementation.

```
.x
   ( n -- )
display n as a 4-digit hex number
-rot
   ( x1 x2 x3 -- x3 x1 x2 )
rotate the top three stack entries
bounds
   ( start cnt -- start+cnt start )
prepare to loop on a range
code@
   ( addr -- u )
fetch from code memory
ср
   ( -- a )
variable: code memory current pointer
dр
   ( -- a )
```

forth

variable: data memory current pointer

```
( -- a )
variable: most recent dictionary entry
io!
   ( x a -- )
```

io@
 (a -- x)
fetch from IO port a

store x to IO port a

leds
 (x --)
write x to the onboard LEDs

new (--)

restore code and data pointers to the power-up state

```
s,
    ( a u -- )
add the u-character string a to the data space
```

```
serialize
   ( -- )
display all of current memory in base 36
```

tth

(-- a)

variable: tethered mode

The SwapForth Shell

3.1 Command reference

3.2 Tethered Mode

J1a SwapForth supports tethered mode, which makes the UART protocol easier to use for host programs. The SwapForth shell uses tethered mode. To enter tethered mode, write one to the variable **tth**:

```
1 tth !
```

In tethered mode, accept transmits byte value 30 (hex 1e, ASCII code RS). This allows the listening program to know that the target machine is ready to accept a line of input. In addition, accept does not echo characters as they are typed.

Memory

4.1 RAM Types

The J1a implementation uses 8Kbytes of RAM in a split configuration.

The lower 4K is for code. This RAM is writable, and executable, but not (directly) readable. The variable CP (code pointer) points into this area. To read from this region, use the special word <code>code0</code>.

The upper 4K is for data. This RAM is writable and readable. The dictionary and all variables are located in this section. The variable DP points into this area.

4.2 Dictionary Layout

The SwapForth dictionary is a linked list; the variable forth holds the start of this list. Each dictionary entry contains:

- next pointer address of the next dictionary entry, or zero for the last dictionary entry
- imm immediate bit
- count length of the name, in characters, 1-31
- $name_1$ $name_n$ characters in name. If the length of the name is even, then a padding byte is appended
- \bullet **xt** execution token for the word

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
next poi															imm
	name_1 count														
							•								
	$name_n$ $name_{n-1}$														
	xt														

iCEstick Hardware interface



The J1a for iCEstick includes connections to the iCEstick peripherals:

- SPI flash
- LEDs
- IrDA tranceiver
- Digilent PmodTM connector
- UART

Access to peripherals is via the io@ and io! words. Peripherals are port-mapped into a 16-bit IO address space. Most ports are either read-only or write-only. For read-only ports, writing to the port has no effect. For write-only ports, reading from the port gives zero.

As an example of direct port access, this word blinks the on-board LEDs when a signal on IrDA is detected.

```
: x
begin
  $2000 io@ \ read from input port
  8 and 0= \ true if bit 3 (IrDA RXD) is 0
  $0004 io! \ write to LEDS
again
;
```

5.1. PORT MAP 21

5.1 Port Map

5.1.1 \$0001: Digilent PmodTM data

The read-write port at address \$0001 is for direct access to the Digilent PmodTM connector. The port pins are assigned:

connection	Left row pins	right row pins	connection
bit 0	1	7	bit 4
bit 1	2	8	bit 5
bit 2	3	9	bit 6
bit 3	4	10	bit 7
ground	5	11	ground
3.3v	6	12	3.3v

Correspondingly the port bits are assigned to pins as follows:

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
								10	9	8	7	4	3	2	1

Note that pin direction is controlled by the corresponding bit the port at address \$0002.

5.1.2 \$0002: Digilent PmodTM direction

Each of the 8 bits controls the direction of the corresponding pin of the Digilent PmodTM connector. 0 sets the pin to input, 1 means sets the pin to output. The bit-to-pin mapping is the same as for port \$0001.

5.1.3 \$0004: LEDs

The five on-board LEDS are controlled by write-only port at address \$0004. Setting a bit to 1 lights the corresponding LED.



Built-in word leds writes to this port.

5.1.4 \$0008: PIO output

Write-only port \$0008 controls the flash and IrDA outputs.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
											IrDA SD	IrDA TXD		flash MOSI		

5.1.5 \$1000: UART data

The read-write port at address \$1000 is for UART transmission or reception. Writing to the port starts transmission of a byte, reading the port returns the incoming byte.

Standard words key, key? and emit can be used to access this port.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
											by	rte			

5.1.6 \$2000: IrDA, flash and UART inputs

Read-only port \$2000 contains the input signals from the IrDA receiver, SPI flash, and UART.



Index

-rot, 12 .(, 11 .r, 11 .s, 11 .x, 12 /string, 11 :noname, 11	d2*, 11 dabs, 11 demos, 6 dictionary, 17 dnegate, 11 dp, 12 dump, 11
<>, 11 ?do, 11 [compile], 11 11 0<>, 11 0>, 11	easter, 7 emit, 22 endcase, 11 endof, 11 erase, 11
again, 11 ahead, 11 ANS, 11 blink, 20 bounds, 12	false, 11 forth, 12 Forth 200x, 11 FPGA, 5
case, 11 cmove, 11 cmove>, 11 compile,, 11 computus, 7 cp, 12	hex, 11 iceprog, 5 icestorm, 5 IrDA, 19
d+, 11 d., 11 d.r, 11 d0=, 11	key, 22 key?, 11, 22 LEDs, 6, 19 leds, 13, 21

24 INDEX

```
m+, 11
\mathtt{marker},\, 11
ms, 11
new, 13
nip, 11
of, 11
pad, 11
parse, 11
parse-name, 11
Pmod, 19
RAM, 5, 17
refill, 11
{\tt restore\text{-}input},\, \textcolor{red}{11}
s, 13
save-input, 11
serialize, 13
sliteral, 11
SPI flash, 19
tethered mode, 15
throw, 11
true, 11
\mathtt{tth},\ 13,\ 15
tuck, 11
u.r, 11
u>, 11
UART, 19
unused, 11
within, 11
words, 11
```