
Computer Architecture

10. Cache Memory

Jianhua Li
College of Computer and Information
Hefei University of Technology

Cache Abstraction and Metrics



- Cache hit rate = (# hits) / (# hits + # misses) = (# hits) / (# accesses)
- Average memory access time (AMAT)= (hit-rate * hit-latency) + (miss-rate * miss-latency)
- Aside: Can reducing AMAT reduce performance?

A Basic Hardware Cache Design

We will start with a basic hardware cache design

 Then, we will examine a multitude of ideas to make it better

Blocks and Addressing the Cache

- Memory is logically divided into fixed-size blocks
- Each block maps to a location in the cache, determined by the index bits in the address
 - used to index into the tag and data stores

tag index byte in block
2b 3 bits 3 bits


8-bit address

- Cache access:
 - index into the tag and data stores with index bits in address
 - check valid bit in tag store
 - compare tag bits in address with the stored tag in tag store
- If a block is in the cache (cache hit), the stored tag should be valid and match the tag of the block

Direct-Mapped Cache

- Assume byte-addressable memory: 256 bytes, 8-byte blocks → 32 blocks
- Assume cache: 64 bytes, 8 blocks
 - Direct-mapped: A block can go to only one location

tag index byte in block



- Addresses with same index contend for the same location
 - Cause conflict misses

Direct-Mapped Caches


- Direct-mapped cache: Two blocks in memory that map to the same index in the cache at the same time

 What's the problem?
 - One index → one entry •

- Can lead to 0% hit rate if more than one block accessed in an interleaved manner map to the same index
 - Assume addresses A and B have the same index bits but different tag bits
 - A, B, A, B, A, B, ... \rightarrow conflict in the cache index
 - All accesses are conflict misses

Set Associativity

- Addresses 0 and 8 always conflict in direct mapped cache
- Instead of having one column of 8, have 2 columns of 4 blocks




tag index byte in block

3b 2 bits 3 bits

Key idea: Associative memory within the set

- + Accommodates conflicts better (fewer conflict misses)
- -- More complex, slower access, larger tag store


Higher Associativity



- + Likelihood of conflict misses even lower
- -- More tag comparators and wider data mux; larger tags

Full Associativity


- Fully associative cache
 - A block can be placed in any cache location



Associativity (and Tradeoffs)

- Degree of associativity: How many blocks can map to the same set?
- Higher associativity
 - ++ Higher hit rate
 - -- Slower cache access time (hit latency and data access latency)
 - -- More expensive hardware (more comparators)

Diminishing returns from higher associativity



Issues in Set-Associative Caches

- Think of each block in a set having a "priority"
 - Indicating how important it is to keep the block in the cache
- Key issue: How do you determine block priorities?
- There are three key decisions can adjust priority:
 - Insertion, promotion, eviction (replacement)
- Insertion: What happens to priorities on a cache fill?
 - Where to insert the incoming block, whether or not to insert the block
- Promotion: What happens to priorities on a cache hit?
 - Whether and how to change block priority
- Eviction/replacement: What happens to priorities on a cache miss?
 - Which block to evict and how to adjust priorities

Here we talk about: Replacement Policy

- Which block in the set to replace on a cache miss?
 - Any invalid block first
 - If all are valid, consult the replacement policy
 - Random
 - FIFO
 - LRU: Least recently used (how to implement?)
 - NRU: Not most recently used
 - LFU: Least frequently used?
 - Least costly to re-fetch?
 - Why would memory accesses have different cost?
 - Hybrid replacement policies
 - Optimal replacement policy?

Implementing LRU

- Idea: Evict the least recently accessed block
- Problem: Need to keep track of access ordering of blocks
- Question: 2-way set associative cache:
 - How to implement LRU perfectly?
- Question: 4-way set associative cache:
 - How to implement LRU perfectly?
 - How many different orderings possible for the 4 blocks in the set?
 - How many bits needed to encode the LRU order of a block?
 - What is the logic needed to determine the LRU victim?

Approximations of LRU

- Most modern processors do not implement "true LRU" (also called "perfect LRU") in highly-associative caches
- Why?
 - True LRU is complex
 - LRU is an approximation to predict locality anyway (i.e., not the best possible cache management policy)
- Alternative examples:
 - Not MRU (not most recently used)
 - Hierarchical LRU: divide the 4-way set into 2-way "groups", track the MRU group and the MRU way in each group
 - Victim-NextVictim Replacement: Only keep track of the victim and the next victim

LRU or Random?

- LRU vs. Random: Which one is better?
 - Example: 4-way cache, cyclic references to A, B, C, D, E
 - 0% hit rate with LRU policy
- Set thrashing: When the "program working set" in a set is larger than set associativity
 - Random replacement policy is better when thrashing occurs
- In practice:
 - Depends on workload
 - Average hit rate of LRU and Random are similar
- Best of both Worlds: Hybrid of LRU and Random
 - How to choose between the two? Set sampling
 - See Qureshi et al., "A Case for MLP-Aware Cache Replacement," ISCA 2006.

What Is the Optimal Replacement Policy?

- Belady's OPT
 - Replace the block that is going to be referenced furthest in the future by the program
 - Belady, "A study of replacement algorithms for a virtualstorage computer," IBM Systems Journal, 1966.
 - How do we implement this? Simulate?
- Is this optimal for minimizing miss rate?
- Is this optimal for minimizing execution time?
 - No. Cache miss latency/cost varies from block to block!
 - Two reasons: Remote vs. local caches and miss overlapping
 - Qureshi et al. "A Case for MLP-Aware Cache Replacement,"
 ISCA 2006.

Cache versus Page Replacement

- Physical memory (DRAM) is a cache for disk
 - Usually managed by system software via the virtual memory subsystem
- Page replacement is similar to cache replacement
- Page table is the "tag store" for physical memory data store
- What is the difference?
 - Access speed: cache vs. physical memory
 - Number of blocks in a cache vs. physical memory
 - "Tolerable" amount of time to find a replacement candidate
 - Role of hardware versus software

What's in A Tag Store Entry?

- Valid bit
- Tag
- Replacement policy bits

- Dirty bit?
 - Write back vs. write through caches

Handling Writes (I)

- When do we write the modified data in a cache to the next level?
 - Write through: At the time the write happens
 - Write back: When the block is evicted
- Write-back
 - + Can consolidate multiple writes to the same block before eviction
 - + Potentially saves bandwidth between cache levels + saves energy
 - —Need a bit in the tag store indicating the block is "dirty/modified"
- Write-through
 - + Simpler
 - + All levels are up to date. Consistency: Simpler cache coherence because no need to check lower-level caches
 - More bandwidth intensive; no coalescing of writes

Handling Writes (II)

- Do we allocate a cache block on a write miss?
 - Allocate on write miss: Yes
 - No-allocate on write miss: No
- Allocate on write miss
 - + Can consolidate writes instead of writing each of them individually to next level
 - + Simpler because write misses can be treated the same way as read misses
 - —Requires (?) transfer of the whole cache block
- No-allocate
 - + Conserves cache space if locality of writes is low (potentially better cache hit rate)

Sectored Caches

- Idea: Divide a block into sub-blocks (or sectors)
 - Have separate valid and dirty bits for each sector
 - When is this useful? (Think writes...)
 - ++ No need to transfer entire cache block into cache
 - A write simply validates and updates a sub-block
 - ++ More freedom in transferring sub-blocks into cache
 - How many sub-blocks do you transfer on a read?
 - -- More complex design
 - -- May not exploit spatial locality fully for reads

Instruction vs. Data Caches

- Separate or Unified?
- Unified:
 - + Dynamic sharing of cache space: no overprovisioning that might happen with static partitioning (i.e., split I and D caches)
 - -- Instructions and data can thrash each other (i.e., no guaranteed space for either)
 - -- I and D are accessed in different places in the pipeline. Where do we place the unified cache for fast access?
- First level caches are almost always split
 - Mainly for the last reason above
- Second and higher levels are almost always unified

Multi-level Caching in a Pipelined Design

- First-level caches (instruction and data)
 - Decisions very much affected by cycle time
 - Small, lower associativity
 - Tag store and data store accessed in parallel
- Second-level caches
 - Decisions need to balance hit rate and access latency
 - Usually large and highly associative; latency not as important
 - Tag store and data store accessed serially
- Serial vs. Parallel access of levels
 - Serial: Second level cache accessed only if first-level misses
 - Second level does not see the same accesses as the first
 - First level acts as a filter (filters some temporal and spatial locality)
 - Management policies are therefore different


Cache Performance

Cache Parameters vs. Miss/Hit Rate

- Cache size
- Block size
- Associativity
- Replacement policy
- Insertion/Placement policy


Cache Size

- Cache size: total data (not including tag) capacity
 - bigger can exploit temporal locality better
 - not ALWAYS better
- Too large a cache adversely affects hit and miss latency
 - smaller is faster => bigger is slower
 - access time may degrade critical path
- Too small a cache
 - doesn't exploit temporal locality well
 - useful data replaced often
- Working set: the whole set of data the executing application references
 - Within a time interval



Block Size

- Block size is the data that is resociated with an address tag
 Can someone explain
 - not necestable this curve?
 - Sub-blocking
 - Can improve "write" performance
- Too small blocks
 - don't exploit spatial locality well
 - have larger tag overhead
- Too large blocks
 - too few total # of blocks → less temporal locality exploitation
 - waste of cache space and bandwidth/energy if spatial locality is not high



size

hierarchies


re pieces (each with V bit)

Large Blocks: Critical-Word and Sub-blocking

- Large cache blocks can take a long time to fill into the cache
 - fill cache line critical word first
 - restart cache access before complete fill
- Large cache blocks can waste bus bandwidth
 - divide a block into sub-blocks
 - associate separate valid bits for each sub-block
 - When is this useful?

Associativity

- How many blocks can map to the same index (or set)?
- Larger associativity
 - lower miss rate, less variation among programs
 - diminishing returns, higher hit latency
- Smaller associativity
 - lower cost
 - lower hit latency
 - Especially important for L1 caches
- Power of 2 required?



Classification of Cache Misses

Compulsory miss

- first reference to an address (block) always results in a miss
- subsequent references should hit unless the cache block is displaced for the reasons below

Capacity miss

- cache is too small to hold everything needed
- defined as the misses that would occur even in a fullyassociative cache (with optimal replacement) of the same capacity

Conflict miss

defined as any miss that is neither a compulsory nor a capacity miss

How to Reduce Each Miss Type

Compulsory

- Caching cannot help
- Prefetching can help

Conflict

- More associativity
- Other ways to get more associativity without making the cache associative
 - Victim cache
 - Hashing
 - Software hints?

Capacity

- Utilize cache space better: keep blocks that will be referenced
- Software management: divide working set such that each "phase" fits in cache

Improving Cache "Performance"

- Remember
 - Average memory access time (AMAT)
 - = (hit-rate * hit-latency) + (miss-rate * miss-latency)
- Reducing miss rate
 - Remind: reducing miss rate can reduce performance if more costly-to-refetch blocks are evicted
- Reducing miss latency/cost
- Reducing hit latency/cost

Improving Basic Cache Performance

- Reducing miss rate
 - More associativity
 - Alternatives/enhancements to associativity
 - Victim caches, hashing, pseudo-associativity, skewed associativity
 - Better replacement/insertion policies
 - Software approaches
- Reducing miss latency/cost
 - Multi-level caches
 - Critical word first
 - Subblocking/sectoring
 - Better replacement/insertion policies
 - Non-blocking caches (multiple cache misses in parallel)
 - Issues in multicore caches

Next Topic Optimizing Cache Performance