### **Key Concepts So Far**

**ARM** processor architecture

Assembly and machine language

**Perioherals and GPIO** 

- C language
  - Relationship between C and assembly
  - Pointers and memory addresses

## Where Are We Going?

Functions (today)


Serial communication and strings

Linking, loading, and starting

After this: the cool stuff from PL and DE

#### **Calling Functions**

Four important registers: pc, 1r, sp, fp



int A(int a, int b, int c)

## **Topics**

### **Calling functions:**

- link register (1r)
- arguments and return values

The stack and stack pointer (sp)

Activation records; the frame pointer (fp)

```
// Blink
// Setup GPIO 20
ldr r0, =0x20200008
mov r1, #1
str r1, [r0]
```

```
// turn on the led
mov r0, #(1<<20)
ldr r1, =0x2020001C // SET0
str r0, [r1]

// delay
mov r0, #0x3F0000
wait1:
    subs r0, #1
bne wait1</pre>
```

```
// turn off the LED
mov r0, #(1<<20)
ldr r1, =0x20200028 // CLR0
str r0, [r1]

// delay
mov r0, #0x3F0000
wait2:
    sub r0, #1
    bne wait2


// delay would be a useful function</pre>
```


On

Delay

Off

Delay





### **Calling and Returning**

```
// call
bl delay // branch and link : lr=pc+4

// return
bx lr // branch to register lr: pc=lr
```

```
// turn on the led
mov r0, #(1<<20)
ldr r1, =0x2020001C // SET0
str r0, [r1]

bl delay

// turn off the LED
mov r0, #(1<<20)
ldr r1, =0x20200028 // CLR0
str r0, [r1]

bl delay</pre>
```

```
// delay function
delay:
    mov r0, #0x3F0000
wait:
    sub r0, #1
    bne wait

bx lr
```

```
// delay function
delay:
    mov r0, #0x3F0000
wait:
    sub r0, #1
    bne wait

mov pc, lr
```

```
// turn on the led
mov r0, #(1<<20)
ldr r1, =0x2020001C // SET0
str r0, [r1]

mov r0, #0x3F0000
bl delay

// turn off the LED
mov r0, #(1<<20)
ldr r1, =0x20200028 // CLR0
str r0, [r1]

mov r0, #0x3F0000
bl delay</pre>
```

```
// delay function
delay:
    subs r0, #1
    bne delay

bx lr
```

```
// turn on the led
mov r0, #20
bl set

mov r0, #0x3F0000
bl delay

// turn off the LED
mov r0, #20
bl clr

mov r0, #0x3F0000
bl delay
```

```
// set bit r0 in GPIO SET0 register
set:
    mov r1, #1
    lsl r0, r1, r0
    ldr r1, =0x2020001C // SET0
    str r0, [r1]
    bx lr

// clr bit r0 in GPIO CLR0 register
clr:
    mov r1, #1
    lsl r0, r1, r0
    ldr r1, =0x20200028 // CLR0
    str r0, [r1]
    bx lr
```

## **Argument Passing: ABI**

r0-r3 are used for input arguments r0-r1 are for return values

#### Application binary interface (ABI)

```
N.B. There are ways to pass >4 args
```

N.B. ARM uses extended ABI (eabi) as in arm-none-eabi

```
int A(int a, int b)
{
    return a + b;
}

A:
    add r0, r0, r1
    bx lr
```

## **Register Conventions**

#### **Nomenclature**

- caller calling function
- callee function called

r0-r3 callee-owned registers

- Callee can change these registers
- Caller should not assume the values are the same when the function returns

## **Register Conventions**

r4-r15 caller-owned, callee-save registers

r11 (fp) - special

r12 (ip) - special (scratch register)

r13 (sp) - special

r14 (lr) - special

r15 (pc) - special

### **Discuss**

The ARM architecture includes a mechanism, the instruction (bl label) to call a function. Propose a convention to call a function using other instructions.

What is the advantage of making most registers callee-saved?

### Callee-Saved

The callee saves registers only if the callee needs to use them; if the callee does not use them, there is no need to save them

More efficient than having the caller save and restores all these registers

Caller doesn't need to make any assumptions of what the callee does

Where does the callee save registers?

```
// recursive delay function
recursive_delay:
    subs r0, #1
    blne recursive_delay
    bx lr

// Does this work?
```

### The Stack

```
// init
mov sp, #0x8000
...

// push
push {1r}
str 1r, [sp, #-4]!
*--sp = 1r

// pop
pop {1r}
ldr 1r, [sp], $4
1r = *sp++;

"Full Descending" Stack
```

```
// delay function using return stack
recursivedelay:
   str lr, [sp, #-4]! // *--sp=lr
   subs r0, #1
   blne recursivedelay
   ldr pc, [sp], #4 // pc=*sp++
```

### Using the Stack w/ Functions

Saving and restoring registers

Local variables

\* Passing extra arguments (>4)

1r
fp
d
а
b
С

```
int A(int a, int b)
{
    return a - b;
}

int B(int a, int b, int c)
{
    int d = a + 2;
    return d + A(b, c);
}
```

```
A:

push {fp}

add fp, sp, #0

sub sp, sp, #12

str r0, [fp, #-8]

str r1, [fp, #-12]

ldr r2, [fp, #-8]

ldr r3, [fp, #-12]

rsb r3, r3, r2

mov r0, r3

sub sp, fp, #0

pop {fp}

bx lr
```

```
A:

push {fp}

add fp, sp, #0

sub sp, sp, #12

str r0, [fp, #-8]

str r1, [fp, #-12]

ldr r2, [fp, #-8]

ldr r3, [fp, #-12]


rsb r3, r3, r2

mov r0, r3


sub sp, fp, #0

pop {fp}

bx lr
```



```
A:
push {fp}
add fp, sp, #0
sub sp, sp, #12
str r0, [fp, #-8]
str r1, [fp, #-12]
ldr r2, [fp, #-8]
ldr r3, [fp, #-12]
rsb r3, r3, r2
mov r0, r3
sub sp, fp, #0
pop {fp}
bx lr
```





```
A:
push {fp}
                            fp →
                                   fp
add fp, sp, #0
sub sp, sp, #12
str r0, [fp, #-8]
                            sp →
str r1, [fp, #-12]
ldr r2, [fp, #-8]
ldr r3, [fp, #-12]
rsb r3, r3, r2
mov r0, r3
sub sp, fp, #0
pop {fp}
bx 1r
```

```
A:
push {fp}
                                   fp
                            fp →
add fp, sp, #0
sub sp, sp, #12
                                    a
str r0, [fp, #-8]
                                    b
                            sp →
str r1, [fp, #-12]
ldr r2, [fp, #-8]
ldr r3, [fp, #-12]
rsb r3, r3, r2
mov r0, r3
sub sp, fp, #0
pop {fp}
bx 1r
```

N.B. Extra space is allocated so that the sp is always aligned to 8 bytes

```
A:
push {fp}
                            fp →
                                   fp
add fp, sp, #0
sub sp, sp, #12
str r0, [fp, #-8]
                                   b
                            sp →
str r1, [fp, #-12]
ldr r2, [fp, #-8]
ldr r3, [fp, #-12]
rsb r3, r3, r2
mov r0, r3
                           // return a-b
sub sp, fp, #0
pop {fp}
bx 1r
```





```
int A(int a, int b) { return a-b; }
% arm-none-eabi-gcc -O2
A:
    rsb r0, r1, r0
    bx lr
```

# Why fp?

- 1. Print "backtrace" for debugging
  - Program crashes; what happened?
- 2. Nested function scopes
  - Define function inside function
  - Inside function can refer to outer function's variables
- 3. Unwinding the stack
  - Exceptions, ...

### 1dm and stm

```
push {r0, r1}

// f = full, d = descending
stmfd sp!, {r0, r1}

// d = decrement, b = before
stmdb sp!, {r0, r1}

str r1, [sp, #-4]!
str r0, [sp, #-4]!

// stm works with up to 8 registers
```

```
pop {r0, r1}

// f = full, d = descending
ldmfd sp!, {r0, r1}

// i = increment, a = after
ldmia sp!, {r0, r1}

ldr r0, [sp], #4
ldr r1, [sp], #4

// ldm works with up to 8 registers
```