Lecture 12: CPS Networking

Seyed-Hosein Attarzadeh-Niaki

Based on the Slides from Edward Lee

Embedded Real-Time Systems

-

Review

- Processing units
 - Energy/power consumption
 - Parallel execution
 - DPM
 - DVFS
 - Application-specific processors (DS, GPU, ...)
 - Real-time capability
 - Multi-core processors
 - MPSoCs

Embedded Real-Time Systems

Outline

- Network layers in embedded systems
- · Wired and wireless networks

Embedded Real-Time Systems

The Alphabet Soup

- 1588
- GSM
- 6LoWPAN
- **HART**
- 802.15.4
- HTTP


- 802.1(AS)
- IoT
- 802.11
- IPv6
- **AVB**

- LTE
- BLE
- MAC
- CAN
- PAN
- CoAP
- PTP
- CSMA/CA
- QoS

- **REST**
- TDMA
- TSMP
- TSN
- TTEthernet
- TTP
- WAN
- WLAN
- **WPAN**

Embedded Real-Time Systems

Communications Layers




Physical Layer Technologies

Embedded Real-Time Systems

Specifies

- Electrical characteristics
- How to map signals <-> data
- Network topology
 - Busses
 - Shared physical medium
 - MAC protocol dominates
 - Star networks
 - Private medium
 - MAC protocol is less important
 - Routing protocols become important
 - Buffers in routers



Embedded Real-Time Systems

MAC: Media Access Control CSMA/CA vs. Time Slotted

Carrier Sense Multiple Access / Collision Avoidance

- Ethernet and WiFi Listen for idle channel
- Send
- Wait for ack, retransmit if no ack after some timeout

Time Division Multiple Access (TDMA)

Basis of TTA, TTEthernet, FlexRay/

- Wait your turn
- Send when it's your turn
- Add various schemes to recover unused slots
- Maybe add slots for CSMA/CA

Frequency Division Multiple Access (FDMA)

- Protocol supports multiple "channels" each at a different frequency
- Send on a specific channel to not conflict with others

Embedded Real-Time Systems

Basis of

Network Layer

- How devices are named (addressed)?
- How are messages routed?
- Issues with routing
 - Buffering

• Buffer overflow can cause packet drops.

Reliability

Routing tables

To which port should the router send a packet?

Security

Priorities

• Which packet queued for a port to send first?

QoS

Embedded Real-Time Systems

Wired Networks

- Ethernet (CSMA/CD)
- CAN: Controller Area Network (Bosch, 1983)
- TTP: Time-Triggered Protocol (Vienna U. of Tech.)
- FlexRay (Automotive industry, deployed 2006...)
- TTEthernet (Time-triggered Ethernet)
- TSN (Time-sensitive networks)
- ➤ Control over timing, guaranteed bandwidth, redundancy, and fault tolerance, are all issues that loom large in embedded systems.
- ➤ Ethernet networks are acquiring high resolution clock synchronization, which can make them more suitable.

Embedded Real-Time Systems

0

Wired Networks

Not good enough for everything:

- UART
 - Slow. Usually no shared bus.
- 12C
 - Slow. Master-initiated communication. Short distance.
- SPI
 - Master-initiated communication. Lots of pins.

Embedded Real-Time Systems

Time-Slotted Networks:


Example: TTEthernet (marketed by TTTech)

Combines three traffic types over Ethernet:

TT: Time triggered

RC: Rate constrained

• BE: Best effort




TSN: Time-Sensitive Networks


Before 2012, called AVB: Audio-Video Bridging.


Developed to solve this problem:

Broadcasting van. Photo by Gael Mace, licensed under creative commons attribution



mbedded Real-Time Systems







Press Release October 1, 2007



NEWS RELEASE

For More Information Contact

Media Contact Naomi Mitchell National Semiconductor (408) 721-2142 naomi.mitchell@nsc.com

Reader Information Design Support Group (800) 272-9959 www.national.com

Industry's First Ethernet Transceiver with IEEE 1588 PTP

Hardware Support from National Semiconductor Delivers Outstanding Clock Accuracy

Using DP83640, Designers May Choose Any Microcontroller, FPGA or ASIC to Achieve 8- Nanosecond Precision with Maximum System Flexibility

Embedded Real-Time Systems


It is becoming routine for physical network interfaces (PHY) to provide hardware support for PTPs.

With this first generation PHY, clocks on a LAN agree on the current time of day to within 8ns, far more precise than GPS older techniques like NTP.

1

An Extreme Example: The Large Hadron Collider

The WhiteRabbit project at CERN is synchronizing the clocks of computers 10 km apart to within about 80 psec using a combination of GPS, IEEE 1588 PTP and synchronousEethernet.



How PTP Synchronization works

Precision Time Protocols

Round-trip delay:

$$r = (t_4 - t_1) - ((t_3 + e) - (t_2 + e)).$$

where \overline{e} is the clock error in the slave. Estimate of the clock error is

$$\tilde{e} = (t_2 + e) - t_1 - r/2.$$

If communication latency is exactly symmetric, then $\tilde{e}=e$, the exact clock error. B calculates \tilde{e} and adjusts its local clock.


master slave A B t_1 t_1 t_2+e t_3+e IEEE 1588,
IEEE 802.1AS

Embedded Real-Time Systems

- 1

CAN Bus


- First used in 1991.
- Serial bus, 1 Mb/sec up to 40 m.
- Synchronous bus.
- Logic 0 dominates logic 1 on bus.
- Arbitrated with CSMA/AMP:
 - Arbitration on message priority.
- · Data frame
 - 11 bit destination address.
 - RTR bit determines read/write from/to destination.
 - Any node can detect bus error, interrupt packet for retransmission.



Embedded Real-Time Systems

CAN controller

- Controller implements physical and data link layers.
- No network layer needed---bus provides endto-end connections.




Embedded Real-Time Systems

19

Wireless

- Personal Area Networks (PANs)
 - Bluetooth, BLE
- Local Area Networks (LANs)
 - WiFi (IEEE 802.11.*)
 - Zigbee, et al. (IEEE 802.15.4*)
- Wide Area Networks (WANs)
 - GSM (for voice, some data)
 - LTE and 5G (for audio, video)
 - Sigfox, Lora, LTE-M (for Machine-to-Machine, M2M, IoT)

Embedded Real-Time Systems



RFID

- RFID tag can provide object ID (Electronic Product Code, etc.), other information.
- Many tags are read-only, some are writable.
- Two types of tags
 - Passive transmits only when it receives a request.
 - Active tag both transmits independently and responds to requests.
- Passive may also be used to refer to tags with no internal power source.
- RFID tags may operate in several different bands and at different ranges.

Embedded Real-Time Systems

Growing set of smart and connected devices



IEEE 802.15.4 (a.k.a. "ZigBee" stack)

- Workhorse radio technology for sensornets
- Widely adopted for low-power mesh protocols
- Middle (6LoWPAN, RPL) and upper (CoAP layers)
- Can last for years on a pair of AA batteries
- 850 million chipset sales in 2016 expected



Bluetooth Low-Energy (BLE)

- Short-range RF technology
- On phones and peripherals
- Can beacon for years on coin cells
- 3 billion chipset sales in 2014



Near-Field Communications (NFC)

- Asymmetric backscatter technology
- Small (mobile) readers in smartphones
- Large (stationary) readers in infrastructure
- Ambient backscatter now emerging







Embedded Real-Time Systems

23

IEEE 802.15.4


Physical and MAC layer standard for


- low-rate wireless personal area networks (WPAN)
- for energy constrained devices.

Provides the basis for:

- Zigbee: Adds mesh network and encryption
- WirelessHART: Highway Addressable Remote Transducer Protocol (HART)
 - Integrates TSMP, Time Synchronized Mesh Protocol, developed by Dust Networks.
- 6LoWPAN: IPv6 over low power WPAN

Embedded Real-Time Systems






Routing to Energy-Constrained Devices CoAP: Constrained Application Protocol

Access to lowpower, mesh networked devices via a gateway to give them an Internet presence (IPv6).

Gateway translates IPv6 128-bit (vs 32-bit in IPv4) addresses to 16-bit, locally unique addresses.




Embedded Real-Time Systems


2

Bluetooth

- Developed by Ericsson, Lund, Sweden, in 1994, to replace serial port wired connections over short distances.
- Standardized as IEEE 802.15.1
- Operates in unlicensed industrial, scientific and medical (ISM) radio bands, 2.4 to 2.485 GHz, same as WiFi.
- Bluetooth v4.0 includes Bluetooth Low Energy (BLE) (aka Bluetooth Smart, introduced by Nokia in 2006). Designed for low-cost, energy constrained devices.
- One application of BLE is proximity sensing, as in Apple's iBeacon technology.

Embedded Real-Time Systems





WiFi




- WLAN: Wireless Local Area Network (~20 meters)
- Developed in the 1990s (AT&T plus others)
- Access points provide gateways to wired networks
- Operates in 2.4 and 5 GHz unlicensed bands
- Requires larger antennas and more energy than Bluetooth or 802.15 networks.

Embedded Real-Time Systems

31

Example Processor ESP 8266

ESP8266 **NodeMCU CPU** Arduino IDE 32 bit Library support 26MHz-52MHz 64KB instruction RAM, 64KB boot ROM PIN DEFINITION 96KB data RAM WiFi 802.11b/g/n Access Point or Station WEP GPIO, UART, ADC, I2C, SPI, PWM Made by Expressif Embedded Real-Time Systems 32




Publishes sensor data from built-in ADCs to the cloud, and then provides a RESTful interface to the data.

setup

Embedded Real-Time Systems

33

Source: Electric Imp, Inc., founded



LoRaWAN

- LoRa
 - Physical layer protocol
 - Chirp, spread-spectrum modulation
 - Sub-GHz RF bands like 169, 433, 868, 915 MHz.



- Data-link layer protocol
- Specifies when to transmit and receive data over LoRa


Embedded Real-Time Systems

35

LoRaWAN

Network Architecture

- All communication is two or from a gateway
 - Similar to master/slave relationship in BLE
 - Devices do not directly communicate with each other



Data Rate and Distance

 LoRaWAN trades off distance and data rate

Name	Data Rate (bits/second)	Theoretical Range (kilometers)
Data Rate 0		25
Data Rate 1	980	21
Data Rate 2	1760	13
Data Rate 3	3125	12
Data Rate 4	5470	9
Data Nate 4	12500	3

Embedded Real-Time Systems

Emerging set of proximal communication interfaces

Ultrasonic

- Small, low-power, short-range
- Supports very low-power wakeup
- Can support pairwise ranging of nodes

Visible Light

- Enabled by pervasive LEDs and cameras
- Supports indoor localization and communications
- Easy to modify existing LED lighting

Vibration

- Pervasive accelerometers
- Pervasive vibration motors
- Bootstrap desktop area context






Example of an IoT Protocol: MQTT

- Machine-to-machine (M2M)/"Internet of Things" connectivity protocol
- Small code footprint
- Publish/subscribe message exchange pattern
- Works on top of TCP/IP
- Client libraries for Android, Arduino, C, C++, C#, Java, JavaScript, .NET
- Persistence: MQTT has support for persistent messages stored on the broker
- Applications: Home automation, Healthcare, Industrial automation, Automotive, etc.

Embedded Real-Time Systems

MQTT Publish/Subscribe Scheme

- Multiple clients connect to a broker and subscribe to topics that they are interested in.
- Clients connect to the broker and publish messages to topics.
- Topics are treated as a hierarchy, using a slash (/) as a separator.
- Example: sensors/COMPUTER_NAME /temperature/HARDDRIVE_ NAME



Embedded Real-Time Systems

39

Conclusion

The hot trend today is towards

- "smart sensors and actuators"
- that are equipped with network interfaces (wired or wireless)
- and are accessed via
 - web technologies (specifically HTTP)
 - or wirelessly via bluetooth.
- ➤ But quality of service (QoS) is hard to control, so these mechanisms are not always suitable.

Embedded Real-Time Systems