密级状态：绝密（　　）　秘密（　　）　内部（ √ ）　公开（　）

RK3399_VR 分体机_KEY_修改说明文档 _V1.0_2016.9.3

（技术部，第二系统产品部门）

文件状态： [　] 正在修改 [√] 正式发布	当前版本：	V1.0
	作　　者：	王剑辉
	完成日期：	2016-09-03
	审　　核：	黄祖芳、张文平、兰顺华
	完成日期：	2016-09-03

福州瑞芯微电子股份有限公司

Fuzhou　Rockchips　Semiconductor　Co . , Ltd

更新记录

版本	修改人	修改日期	修改说明	备注
V1.0	王剑辉	2016.9.3	初始版本	

目 录

1 KEY 按键修改--NANOC 端

Nanoc 端的修改，相关代码如下：

Nanoc 对应 key 值的宏定义在 NanoC_VR_Release/Common/Driver/AD_KEY/AD_Key.h 中。Nanoc key 有定义一个 key 的结构体，用来存放 key 值的状态，结构体的路径 NanoC_VR_Release\Common\Include\RkvrInterface.h

```
struct keymap_t{
    __u16 key_menu_up:1;        //这个 bit 设置为 1，表示 menu 键抬起
    __u16 key_menu_down:1;    //这个 bit 设置为 1，表示 menu 键按下
    __u16 key_home_up:1;
    __u16 key_home_down:1;
    __u16 key_power_up:1;
    __u16 key_power_down:1;
    __u16 key_volup_up:1;
    __u16 key_volup_down:1;
    __u16 key_voldn_up:1;
    __u16 key_voldn_down:1;
    __u16 key_pressed:1;
};
```

Nanoc 监听 key 按下的代码路径：NanoC_VR_Release/SDK/UI/USB/FunUSB.c

代码如下：

```
_ATTR_USB_UI_CODE_
void HID_ReportData()
{
    int16 accel_data[3] = {0};
    int16 gyro_data[3] ={0};
```

```
uint8 temperature[2] ={0};
float tempreature;
UINT32    TempKeyVal;

RKVR_DATA_UN rkvr_data_un;

if(USBWriter_IsBusy(62)) {
    return;
}

memset(rkvr_data_un.buf, 0, sizeof(rkvr_data_un.buf));

if (gSysConfig.UsbSensor == 1)
{
    //获取 Sensor  数据
    MPU6500_Read_Data(accel_data,1,gyro_data,1);
    MPU6500_Read_Temperature(temperature);
    sensor_data_fill(&(rkvr_data_un.rkvr_data.sensor_data),accel_data,gyro_data,temperature);
}

TempKeyVal =    GetKeyVal();
switch (TempKeyVal)
{
    case KEY_VAL_MENU_DOWN:
        {
            printf("menu key down\n");
```

```
                rkvr_data_un.rkvr_data.key_map.key_menu_down = 1;
                rkvr_data_un.rkvr_data.key_map.key_pressed = 1;
                USBWriteEp(HID_IN_EP_SENSOR ,62, rkvr_data_un.buf);
            }
            break;

        case KEY_VAL_MENU_LONG_UP:
        case KEY_VAL_MENU_SHORT_UP: //Menu key
            {
                printf ("Menu key up\n");
                rkvr_data_un.rkvr_data.key_map.key_menu_up = 1;
                rkvr_data_un.rkvr_data.key_map.key_pressed = 1;
                USBWriteEp(HID_IN_EP_SENSOR ,62, rkvr_data_un.buf);    // 发送数据包给
3399 端
            }
            break;

        case KEY_VAL_UP_DOWN:
            {
                printf("volup key down\n");
                rkvr_data_un.rkvr_data.key_map.key_volup_down = 1;
                rkvr_data_un.rkvr_data.key_map.key_pressed = 1;
                USBWriteEp(HID_IN_EP_SENSOR ,62, rkvr_data_un.buf);
            }
            break;
```

```
case KEY_VAL_UP_LONG_UP:        //volume increse
case KEY_VAL_UP_SHORT_UP:
    {
        printf ("volup key up\n");
        rkvr_data_un.rkvr_data.key_map.key_volup_up = 1;
        rkvr_data_un.rkvr_data.key_map.key_pressed = 1;
        USBWriteEp(HID_IN_EP_SENSOR ,62, rkvr_data_un.buf);
    }
    break;

case KEY_VAL_FFW_DOWN:
    {
        printf("voldn key down\n");
        rkvr_data_un.rkvr_data.key_map.key_voldn_down = 1;
        rkvr_data_un.rkvr_data.key_map.key_pressed = 1;
        USBWriteEp(HID_IN_EP_SENSOR ,62, rkvr_data_un.buf);
    }
    break;

case KEY_VAL_FFW_LONG_UP:
case KEY_VAL_FFW_SHORT_UP:
    {
        printf ("voldn key up\n");
        rkvr_data_un.rkvr_data.key_map.key_voldn_up = 1;
        rkvr_data_un.rkvr_data.key_map.key_pressed = 1;
        USBWriteEp(HID_IN_EP_SENSOR ,62, rkvr_data_un.buf);
```

```
        }
        break;

    case KEY_VAL_FFD_DOWN:
        {
            printf("FFD key down\n");
        }
        break;

    case KEY_VAL_FFD_SHORT_UP:
    case KEY_VAL_FFD_LONG_UP:
        {
            printf("FFD key up\n");
        }
        break;

    case KEY_VAL_DOWN_DOWN:
        {
            printf("home key down\n");
            rkvr_data_un.rkvr_data.key_map.key_home_down = 1;
            rkvr_data_un.rkvr_data.key_map.key_pressed = 1;
            USBWriteEp(HID_IN_EP_SENSOR ,62, rkvr_data_un.buf);
        }
        break;

    case KEY_VAL_DOWN_LONG_UP:
```

```
case KEY_VAL_DOWN_SHORT_UP:
    {
        printf ("home key up\n");
        rkvr_data_un.rkvr_data.key_map.key_home_up = 1;
        rkvr_data_un.rkvr_data.key_map.key_pressed = 1;
        USBWriteEp(HID_IN_EP_SENSOR ,62, rkvr_data_un.buf);
    }
    break;

case KEY_VAL_PLAY_DOWN:
    {
        printf("PLAY key down\n");
    }
    break;

case KEY_VAL_PLAY_LONG_UP:
case KEY_VAL_PLAY_SHORT_UP:
    {
        printf ("Play key up\n");
    }
    break;

case KEY_VAL_ESC_DOWN:
    {
        printf("power key down\n");
        rkvr_data_un.rkvr_data.key_map.key_power_down = 1;
```

```
                rkvr_data_un.rkvr_data.key_map.key_pressed = 1;
                USBWriteEp(HID_IN_EP_SENSOR ,62, rkvr_data_un.buf);
            }
            break;

        case KEY_VAL_ESC_LONG_UP:
        case KEY_VAL_ESC_SHORT_UP:
            {
                printf ("power key up\n");
                rkvr_data_un.rkvr_data.key_map.key_power_up = 1;
                rkvr_data_un.rkvr_data.key_map.key_pressed = 1;
                USBWriteEp(HID_IN_EP_SENSOR ,62, rkvr_data_un.buf);
            }
            break;

        default:
            {
                if (gSysConfig.UsbSensor == 1)
                {
                    rkvr_data_un.rkvr_data.key_map.key_pressed = 0;
                    USBWriteEp(HID_IN_EP_SENSOR ,62, rkvr_data_un.buf);
                }
            }
            break;
    }
}
```

下面举个例子：添加一个 play 按键

1.修改结构体：NanoC_VR_Release\Common\Include\RkvrInterface.h

```
struct keymap_t{
    __u16 key_menu_up:1;
    __u16 key_menu_down:1;
    __u16 key_home_up:1;
    __u16 key_home_down:1;
    __u16 key_power_up:1;
    __u16 key_power_down:1;
    __u16 key_volup_up:1;
    __u16 key_volup_down:1;
    __u16 key_voldn_up:1;
    __u16 key_voldn_down:1;
    __u16 key_play_up:1;
    __u16 key_play_down:1;
    __u16 key_pressed:1;
};
```

2.查找 play 按键的键值宏定义：NanoC_VR_Release/Common/Driver/AD_KEY/AD_Key.h

```
#define KEY_VAL_PLAY_DOWN          ((KEY_VAL_PLAY)|(KEY_STATUS_DOWN))
#define KEY_VAL_PLAY_SHORT_UP      ((KEY_VAL_PLAY)|(KEY_STATUS_SHORT_UP))
#define KEY_VAL_PLAY_LONG_UP       ((KEY_VAL_PLAY)|(KEY_STATUS_LONG_UP))
```

3.修改监听 key 事件的代码

```
_ATTR_USB_UI_CODE_
void HID_ReportData()
{
```

```
。。。。。
TempKeyVal =    GetKeyVal();
switch (TempKeyVal)
{
    case KEY_VAL_PLAY_DOWN:
        {
            printf("play key down\n");
            rkvr_data_un.rkvr_data.key_map.key_play_down = 1;
            rkvr_data_un.rkvr_data.key_map.key_pressed = 1;
            USBWriteEp(HID_IN_EP_SENSOR ,62, rkvr_data_un.buf);
        }
        break;
    case KEY_VAL_PLAY_LONG_UP:
    case KEY_VAL_PLAY_SHORT_UP: //Play    key
        {
            printf ("play key up\n");
            rkvr_data_un.rkvr_data.key_map.key_play_up = 1;
            rkvr_data_un.rkvr_data.key_map.key_pressed = 1;
            USBWriteEp(HID_IN_EP_SENSOR ,62, rkvr_data_un.buf);
        }
        break;
        。。。。。
}
。。。。。
}
```

2 KEY 按键修改--3399VR 端

结合上面 1 中的例子（添加 play 键）：

1.修改结构体，代码路径：kernel/drivers/hid/hid-rkvr.c

```
struct keymap_t{
    __u16 key_menu_up:1;
    __u16 key_menu_down:1;
    __u16 key_home_up:1;
    __u16 key_home_down:1;
    __u16 key_power_up:1;
    __u16 key_power_down:1;
    __u16 key_volup_up:1;
    __u16 key_volup_down:1;
    __u16 key_voldn_up:1;
    __u16 key_voldn_down:1;
    __u16 key_play_up:1;
    __u16 key_play_down:1;
    __u16 key_pressed:1;
};
```

2.修改上报 key input 的代码，路径：kernel/drivers/hid/hid-rkvr.c

```
static unsigned int key_codes[] = {
    KEY_MENU,
    KEY_HOME,
    KEY_POWER,
    KEY_VOLUMEUP,
```

```
    KEY_VOLUMEDOWN,
    KEY_WAKEUP,
    KEY_PLAYER
};

static int rkvr_keys_event(struct hid_device *hdev, void *data, unsigned long len)
{
    struct input_dev *input = hdev->hiddev;
    union rkvr_data_t *rkvr_data = (union rkvr_data_t *)data;

    if (rkvr_data->rkvr_data.key_map.key_menu_up)
        rkvr_send_key_event(input, KEY_MENU, 0);
    else if (rkvr_data->rkvr_data.key_map.key_menu_down)
        rkvr_send_key_event(input, KEY_MENU, 1);
    else if (rkvr_data->rkvr_data.key_map.key_home_up)
        rkvr_send_key_event(input, KEY_HOME, 0);
    else if (rkvr_data->rkvr_data.key_map.key_home_down)
        rkvr_send_key_event(input, KEY_HOME, 1);
    else if (rkvr_data->rkvr_data.key_map.key_power_up)
        rkvr_send_key_event(input, KEY_POWER, 0);
    else if (rkvr_data->rkvr_data.key_map.key_power_down)
        rkvr_send_key_event(input, KEY_POWER, 1);
    else if (rkvr_data->rkvr_data.key_map.key_volup_up)
        rkvr_send_key_event(input, KEY_VOLUMEUP, 0);
    else if (rkvr_data->rkvr_data.key_map.key_volup_down)
        rkvr_send_key_event(input, KEY_VOLUMEUP, 1);
```

```
    else if (rkvr_data->rkvr_data.key_map.key_voldn_up)
        rkvr_send_key_event(input, KEY_VOLUMEDOWN, 0);
    else if (rkvr_data->rkvr_data.key_map.key_voldn_down)
        rkvr_send_key_event(input, KEY_VOLUMEDOWN, 1);
    else if (rkvr_data->rkvr_data.key_map.key_play_up)
        rkvr_send_key_event(input, KEY_PLAYER, 0);
    else if (rkvr_data->rkvr_data.key_map.key_play_down)
        rkvr_send_key_event(input, KEY_PLAYER, 1);
    return 0;
}
```