Baby040 Specification

A Personal Computer Platform

Anthony Guerrero

Document Revision 0.0.1

1 System Overview

1.1 Design Goal

The primary objective of the Baby040 is to construct a personal computer platform that aligns with the capabilities and aesthetics of computing systems from the 1990s. The system is not merely a reflection of retro hardware but a modern interpretation emphasizing complete transparancy, user understanding, and modifiability. The design principles prioritize open-source documentation, source code, and hardware description language (HDL) to empower users and enthusiasts to understand, modify, and expand upon the system.

1.2 Key Features

- Open Architecture: An open-source ethos is at the core of the project. All documentation, designs, and code associated with this system will be freely accessible and modifiable by the end-users and community.
- MC68040 Processor: Serving as the heart of the system, this 32-bit microprocessor offers a blend of performance and functionality suitable for a wide range of computing tasks. It's Instruction Set Architecture (ISA) and built-in MMU lends itself well to implementing UNIX-like operating systems.
- Flexible Expansion: The platform is designed with expansion and modularity in mind, featuring an "Expansion Bus" architecture to facilitate the addition of new components. The bus dynamically assigns memory space to bus members, bypassing address conflicts and setup jumpers.
- Integrated FPGA: Utilizing the iCE40-HX4K FPGA, with full access to the CPU bus, most glue logic and peripheral controllers can be implemented and modified after the design is finalized.
- **512MB Dynamic RAM:** With four 72-pin SIMM slots, the platform supports up to 512MB of main system memory. (3.3v only!)
- Standard Form Factor: The PCB will be sized to fit in a pre-ATX form factor called "Baby AT". This allows for eight expansion slots, a DIN-5 sized cutout for a keyboard, and simple power management.

1.3 System Philosophy

Beyond the technical specifications, this project embodies a philosophy of transparency, education, and user empowerment. The system is not just a computing platform but a testament to the ethos that technology should be understandable, modifiable, and, above all, open. Whether for education, nostalgia, or innovation, this platform seeks to be a canvas for users to explore the intricacies of computing, reminiscent of an era when personal computing was just blossoming.

2 Hardware

2.1 CPU

The Motorola MC68040 was chosen because I found it in a box. Control circuitry on the mother-board asserts the $\overline{\text{MDIS}}$ and $\overline{\text{IPLx}}$ lines on processor reset to configure it for non-multiplexed bus, small output buffer, and data latch enable modes disabled. This allows for easy compatibility with the LC and EC versions of the MC68040 and these features aren't required for the system.

2.2 SRAM

There are 512KB of SRAM for boot ROM, et al...

2.3 DRAM

Four 72-pin SIMM slots provide the bulk RAM for the system. Each SIMM's \overline{RAS} lines are tied together and sent to the memory controller, \overline{CAS} lines are routed separately. The memory controller only supports 3.3v SIMMs (TODO)

The SIMMs I have (Keystron MK16DS3232LP-50) have (16) $16M \times 4$ -bit DRAMs per module. (Place chip to \overline{CAS} , \overline{RAS} , DQ here)

2.4 I2C Bus

I2C is used on-board for communication with the Real-Time Clock (DS1307) and other devices. (Temperature sensors/Fan controllers, etc.)

3 Memory Map

Pay no attention to the memory map diagram at Figure 1, it's probably inaccurate.

When $\overline{\text{RESET}}$ is asserted from a reboot, power-up, etc., the address decoder maps addresses \$00000000-\$000003FF to \$8000FC00-\$8000FFFF. This allows the processor to read the exception vector table from ROM, but writes to these addresses will be routed to RAM. Once the system RAM test passes, the boot program copies the table to system RAM and writes to a configuration register which remaps all accesses from \$00000000 to RAM.

4 Local Bus

Standard 68040 bus, DRAM data is buffered through FPGA, MC68150 bus resizer for expansion bus, I2C provided by PCA9564...

5 Expansion Bus

The system provides a Zorro III-inspired expansion slot bus, the main feature of which is dynamic memory mapping of add-in devices.

Figure 1: System Memory Map

	· ·
0000 0000	
	DRAM
1fff ffff	
2000 0000 200f ffff	SRAM
	-
8000 0000 8000 ffff	ROM
ffff ffff	-

5.1 Design Goals

- Expansion and Flexibility: A primary aim of the expansion bus is to ensure that the design does not inherently limit future enhancements or adaptations.
- **Performance:** While the exact performance target is yet to be finalized, the system aims to achieve robust performance comparable to 1990s standards.
- Support for Varied Devices: The bus should accommodate different devices, including those with different data widths.
- Reliability: Ensure robust operation and avoid complications that might make the system prone to errors.

5.2 Bus Architecture

The design of the expansion bus draws heavily from the Zorro III expansion bus designed for the Amiga 3000 series of computers, but differs in many key ways which make it incompatible.

The address and data bus are not multiplexed in this design, making use of the generous conductor count provided by the DIN 41612 connectors.

The bus system is designed for potential synchronous operation at the BCLK rate, but a lower frequency, like 10MHz, is also under consideration for ease of implementation and broader device compatibility.

5.2.1 Card Configuration

Cards must ground the $\overline{\text{CDET}}$ line to be included in the bus, and therefore is a requirement for complying with this bus specification. If the card doesn't pull this line down, or there isn't a card plugged into an expansion slot, the $\overline{\text{CFGIN}}$ line will be bridged to the $\overline{\text{CFGOUT}}$ line for that expansion slot.

5.2.2 Bus Cycles

5.2.3 Arbitration/Mastering

5.2.4 Cache Support

While the expansion bus doesn't have any cache consistency mechanisms for managing caches between several caching bus masters, it does allow cards that absolutely must not be cached to assert a cache inhibit line, $\overline{\text{CI}}$, on a per-cycle basis. This cache management is mainly useful for support of I/O and other devices that shouldn't be cached.

5.2.5 Interrupts

A card supporting interrupts has on-board registers to store one or more vector numbers. The numbers are obtained from the OS by the device driver for the card and the card/driver combination must be able to handle the situation in which no additional vectors are available.

5.3 Signal Description

5.3.1 Power Connections

- **Digital Ground (GND)** This is the digital supply ground used by all expansion cards as the return path for all expansion supplies.
- Main Supply (+5VDC) This is the main power supply for all expanion cards. (Define power specification)

5.3.2 Clock Signals

• TBD...

5.3.3 System Control Signals

- Hardware Bus Error
- System Interrupts

5.3.4 Slot Control Signals

• Configuration Chain (CFGINN, CFGOUTN) The slot configuration mechanism uses the bus signals CFGOUTN and CFGINN, where "N" refers to the slot number. Each slot has its own version of both signals, which make up the *configuration chain* between slots. Each subsequent CFGIN is a result of all previous CFGOUTs, going from slot 0 to the last slot on the expansion bus.

During the autoconfiguration process, an unconfigured card responds to the address space X if its $\overline{\text{CFGINN}}$ is asserted. All unconfigured cards start up with $\overline{\text{CFGOUTN}}$ negated. When configured, a card will assert its $\overline{\text{CFGOUTN}}$ which results in the $\overline{\text{CFGINN}}$ of the next slot being asserted. Backplane logic automatically passes on the state of the previous $\overline{\text{CFGOUTN}}$ to the next $\overline{\text{CFGINN}}$ for any slot not occupied by a card.

• Card Detect (CDET) This signal is to always be attached to ground by cards to allow them to participate in the expansion bus. This signal is part of the backplane circuitry that allows the configuration chain to function.

5.3.5 DMA Control Signals

• TBD...

5.3.6 Address and Related Control Signals

 Address Bus (A₀-A₃₁) This is the expansion address bus, which is driven by the bus master.

5.3.7 Data and Related Control Signals

- Data Bus (D_0-D_{31}) This is the expansion data bus, which is driven by either the master or the slave when "" is asserted by the master. It's valid for reads when \overline{DTACK} is asserted by the slave.
- Data Transfer Acknowledge (DTACK) This signal is used to normally terminate an expansion bus cycle. The slave is always responsible for driving this signal. For a read cycle, it asserts DTACK as soon as it has driven valid data onto the bus. For a write cycle, it asserts DTACK as soon as it's dont with the data.
- Cache Inhibit (\overline{CI}) This line is asserted at the same time as "" to indicate to the bus master that the cycle must not be cached.
- Burst Inhibit (\overline{BI}) This line is asserted at the same time as "" to indicate to the bus master that the requested burst (MOVE16) cycle should be done as four 32-bit transfers. This line is only used for 32-bit add-in cards.

5.4 Electrical Specifications

5.4.1 Standard Signals

The majority of signals on the bus are in this group. These are the bussed signals, driven actively on the bus by F-series (or compatible) drivers, usually tri-stated when ownership of the signal changed for master and slave, and generally terminated with a $220\Omega/330\Omega$ thevenin terminator.

$$\begin{array}{ccc} {\rm A_0\text{-}A_{31}} & {\rm D_0\text{-}D_{31}} & {\rm R/\overline{W}} \\ {\rm FC_0\text{-}FC_2} & & \end{array}$$

5.4.2 Clock Signals

5.4.3 Open Collector Signals

Many of the bus signals are shared via open collector or open drain outputs rather than via tri-stated signals. A backplane resistor pulls these lines high, cards only drive the line low.

$\overline{\mathrm{DTACK}}$	$\overline{ ext{CI}}$	$\overline{\mathrm{BI}}$
RESET	ĪNT	

5.4.4 Non-bussed signals

5.4.5 Slot Power Availability

The system power for the expansion bus is based on the slot configurations. A backplane is always free to supply extra power, but it must meet the minimum requirements specified here. All cards must be designed with the minimum specifications in mind, especially the tolerances.

Pin	Supply
X, X	+5 VDC ±5% @ 2A
X, X X	$-5 \text{ VDC } \pm 5\% \text{ @ } 60\text{mA}$
X	$+12 \text{ VDC} \pm 5\%$ @ 500mA
X	$-12~\mathrm{VDC}~\pm5\%~@~60\mathrm{mA}$

5.5 Mechanical Specifications

5.6 Expansion Slot Pin Assignments

Table 1: Expansion Bus Connector Pinout

Pin	Name	Pin	Name	Pin	Name
a1	NC^1	b1	NC	c1	NC
a2	NC	b2	NC	c2	NC
a3	NC	b3	NC	c3	NC
a4	NC	b4	NC	c4	NC
a5	NC	b5	NC	c5	NC
a6	NC	b6	NC	c6	NC
a7	NC	b7	NC	с7	NC
a8	NC	b8	NC	c8	NC
a9	NC	b9	NC	с9	NC
a10	NC	b10	NC	c10	NC
a11	NC	b11	NC	c11	NC
a12	NC	b12	NC	c12	NC
a13	NC	b13	NC	c13	NC
a14	NC	b14	NC	c14	NC
a15	NC	b15	NC	c15	NC
a16	NC	b16	NC	c16	NC
a17	NC	b17	NC	c17	NC
a18	NC	b18	NC	c18	NC
a19	NC	b19	NC	c19	NC
a20	NC	b20	NC	c20	NC
a21	NC	b21	NC	c21	NC
a22	NC	b22	NC	c22	NC
a23	NC	b23	NC	c23	NC
a24	NC	b24	NC	c24	NC
a25	NC	b25	NC	c25	NC
a26	NC	b26	NC	c26	NC
a27	NC	b27	NC	c27	NC
a28	NC	b28	NC	c28	NC
a29	NC	b29	NC	c29	NC
a30	NC	b30	NC	c30	NC
a31	NC	b31	NC	c31	NC
a32	NC	b32	NC	c32	NC

 $^{^{1}}$ This means it's not connected.

6 Interrupt System

7 Special Thanks

Ben Eater for creating engaging videos on computer engineering, inspiring me to build a computer of my own.

Lawrence Manning MAXI030 Stephen Moody Y Ddraig(030)

Dave Haynie Author of "The Zorro III Bus Specification"