- 1. How to get dump with CPU context?
 - Non-secure device
 - On 8937/8953/8996 platform, need consider the possibility of calling sdi disable in kernel side (scm_disable_sdi), it will take effect before power cycle.
 - Secure device
 - Legacy TZ platform: solution 00029197 works
 - Chipsets with QSEE 4.0:
 - Step1: kernel side enable CONFIG_CORESIGHT_DBGUI and CONFIG_MSM_DEBUG_LAR_UNLOCK
 - O Step2: refer solution 00031166
 - Step3: secDbg_oem.c (both sbl1 and modem side), add #define SKIP_SERIAL_NUMBER_CHECK 1
 - Step4: need disable RPMB and reflash devcfg.mbn:

```
trustzone_images/core/securemsm/trustzone/qsee/mink/oem/config/
msm8937/oem_config.xml
@@ -4,10 +4,10 @@
</global_def>
<device id="/tz/oem">
cprops name="OEM_keystore_enable_rpmb" type=
DALPROP_ATTR_TYPE_UINT32>
- 1
+ 0
</props>
counter_enable_rpmb" type=
DALPROP ATTR TYPE UINT32>
- 1
+ 0
</props>
rops name="OEM_allow_rpmb_key_provision" type=
DALPROP_ATTR_TYPE_UINT32>
0
```

- Step5: (preferred)
 - 1) In " xxxx_secimage.xml", change OU to 0:

-<debug>0x000000000000002</debug>

+<debug>0x00000000000000000</debug>

```
2) In sbl_mc.c
                         void sbl1_main_ctl(boot_pbl_shared_data_type *pbl_shared)
                         {
                    <snip>
                         /* Calculate the SBL start time for use during boot logger
                         initialization. */
                         sbl_start_time = CALCULATE_TIMESTAMP(HWIO_IN(
                         TIMETICK CLK));
                          + HWIO_OUT(OVERRIDE_2, HWIO_OVERRIDE_2_RMSK);
                          + HWIO_OUT(OVERRIDE_3, HWIO_OVERRIDE_3_RMSK);
                    3) Re-sign image and flash
          Step5 (altative)
                   1) change OU to 2:
                         In " xxxx secimage.xml"
                         -<debug>0x000000000000002</debug>
                          +<debug>0x000000000000003</debug>
                   2) Read the serial number of the device and add it in
                   xxxx_secimage.xml ( not in xxx_debugpolicy.xml) .
                   3) And re-sign sbl1.mbn and mba.mbn
Other tips:
     3G, 4G memory SDI patches, if miss CR-1003318, possible cause SDI hung
          void sys_debug_bric_settings(void)
          {
          // 1.5GB + 1.5GB configuration
          if ((HAL_SDRAM_Get_Base_Addr(SDRAM_INTERFACE_0, SDRAM_CS0) == 0x0
          ) && (device_density == 14) && (device_io_width == 1))
```

```
{.....
//SYSNOC slave address range configuration to 512MB
- HWIO_OUTXI(0x00402000, BRIC_GLOBAL2_
BRIC_SEGMENTN_ADDR_MASK_A_LOWER,2,0xE0000000);
+ HWIO OUTXI(0x00402000, BRIC GLOBAL2
BRIC SEGMENTN ADDR MASK A LOWER, 1,0xE0000000);
}
// 2GB + 2GB configuration
else if (HAL_SDRAM_Get_Base_Addr(SDRAM_INTERFACE_0, SDRAM_CS0) ==
0x0) {
//SYSNOC slave address range configuration to 256MB
    -HWIO_OUTXI(0x00402000, BRIC_GLOBAL2_
    BRIC_SEGMENTN_ADDR_MASK_A_LOWER,2,0xF0000000);
+ HWIO_OUTXI(0x00402000, BRIC_GLOBAL2_
BRIC SEGMENTN ADDR MASK A LOWER, 1,0xF0000000);
}
}
```

- Old If customer want to use disable hardware self refresh test patch, they need just only comment out the code in ABHN_SHKE_Enable_HW_Self_Refresh() and keep the code as it is in ABHN_SHKE_Disable_HW_Self_Refresh(), otherwise the phone cannot enter dload mode correctly.
- 2. Patches which can be tried if hardware related.
 - 1. Enable RTB
 - +CONFIG_MSM_RTB=y +CONFIG MSM RTB SEPARATE CPUS=y
 - 2. Disable L2 GDHS

```
diff --git a/rootdir/etc/init.qcom.post_boot.sh b/rootdir/etc/init.qcom.post_boot
index 14e3346..640afbf 100644
--- a/rootdir/etc/init.qcom.post_boot.sh
+++ b/rootdir/etc/init.qcom.post_boot.sh
@@ -1330,6 +1330,10 @@ case "$target" in
                 # re-enable thermal core_control now
                 echo 1 > /sys/module/msm_thermal/core_control/enabled
                 # Disable L2-GDHS low power modes
                 echo N > /sys/module/lpm_levels/perf/perf-l2-gdhs/idle_enabled
                 echo N > /sys/module/lpm levels/perf/perf-l2-qdhs/suspend enable
                 # Bring up all cores online
                 echo 1 > /sys/devices/system/cpu/cpu1/online
                 echo 1 > /sys/devices/system/cpu/cpu2/online
@@ -1455,6 +1459,12 @@ case "$target" in
                 # re-enable thermal core_control now
                 echo 1 > /sys/module/msm thermal/core control/enabled
                 # Disable L2-GDHS low power modes
                 echo N > /sys/module/lpm_levels/system/pwr/pwr-12-gdhs/idle_enab
                 echo N > /sys/module/lpm_levels/system/pwr/pwr-12-gdhs/suspend_e
                 echo N > /sys/module/lpm_levels/system/perf/perf-l2-gdhs/idle_en
                 echo N > /sys/module/lpm_levels/system/perf/perf-12-gdhs/suspend
                 # Bring up all cores online
                 echo 1 > /sys/devices/system/cpu/cpu1/online
                 echo 1 > /sys/devices/system/cpu/cpu2/online
```

3. Limiting Cx Automode to BIMC @384MHz from 556MHz

In rpm_proc\core\boot\ddr\hw\msm8937\ddr_target.h

- #define DDR_PMIC_AUTOMODE_THRESHOLD_2GB 556800
- #define DDR_PMIC_AUTOMODE_THRESHOLD_3GB 556800
- + #define DDR_PMIC_AUTOMODE_THRESHOLD_2GB 384000
- + #define DDR_PMIC_AUTOMODE_THRESHOLD_3GB 384000
- 4. CX auto mode totally disable
 - 1. boot_images/core/systemdrivers/pmic/config/msm8937/pmi8950/pm_config_target_sbl_sequence.c

```
// MODE - S2_HFS_CONFIG: 14
```

//sid data base_addr offset reg_op rev_id_op rev_id

- -- { 1, 0x40, 0x1700, 0x045, PM_SBL_WRITE, EQUAL, REV_ID_COMMON}, // 18
- ++ { 1, 0x80, 0x1700, 0x045, PM_SBL_WRITE, EQUAL, REV_ID_COMMON}, // 18
- rpm_proc/core/systemdrivers/pmic/config/msm8937/pm_config_target.c

```
AUTO, PM CLK 3p2 MHz, PM CLK 3p2 MHz, PM DROOP DETECT DIS, 500,
     1375, 0, PM_SETTLING_ERR_EN, PM_SETTLING_EN, 0}, // HFS 2
     +++{300, 0, PM_ACCESS_ALLOWED, PM_ALWAYS_ON,
     PM_NPA_SW_MODE_SMPS__NPM, PM_CLK_3p2_MHz, PM_CLK_3p2_MHz,
     PM_DROOP_DETECT_DIS, 500, 1375, 0, PM_SETTLING_ERR_EN,
     PM_SETTLING_EN, 0}, // HFS 2
5. Change VDD APC to max
     arch/arm/boot/dts/gcom/msm8937-regulator.dtsi | 6 ++++--
     1 file changed, 4 insertions(+), 2 deletions(-)
     diff --git a/arch/arm/boot/dts/qcom/msm8937-regulator.dtsi b/arch/arm/boot/dts/qcom/
     msm8937-regulator.dtsi
     index 9f0b79d..4124fda 100644
     --- a/arch/arm/boot/dts/gcom/msm8937-regulator.dtsi
     +++ b/arch/arm/boot/dts/qcom/msm8937-regulator.dtsi
     @@ -359,8 +359,10 @@
     regulator-max-microvolt = <6>;
     qcom,cpr-fuse-corners = <3>;
     - gcom,cpr-voltage-ceiling = <1155000 1225000 1350000>;
     - gcom,cpr-voltage-floor = <1050000 1050000 1090000>;
     + //qcom,cpr-voltage-ceiling = <1155000 1225000 1350000>;
     + //gcom,cpr-voltage-floor = <1155000 1225000 1350000>;
     + gcom,cpr-voltage-ceiling = <1350000 1350000 1350000>;
     + qcom,cpr-voltage-floor = <1350000 1350000 1350000>;
     vdd-apc-supply = <&pm8937_s5>;
     mem-acc-supply = <&mem_acc_vreg_corner>;
6. Boost LDO2, set LDO2 to 1.25V always
     1) boot_images/core/systemdrivers/pmic/target/msm8937_pm8937_pmi8937/system/src
     /pm_sbl_boot_oem.c
     pm_err_flag_type
     pm_driver_post_init(void)
     {
```

--- {300, 0, PM_ACCESS_ALLOWED, PM_ALWAYS_ON, PM_NPA_SW_MODE_SMPS

```
pm_err_flag_type err_flag = PM_ERR_FLAG__SUCCESS;
+++ err flag = pm Ido volt level(0, PM LDO 2, 1250000);
return err_flag;
}
2) rpm_proc/core/systemdrivers/pmic/config/msm8937/pm_config_target.c
pm_rpm_ldo_rail_info_type ldo_rail_a[] =
{5, 62.5, 0, PM ACCESS ALLOWED, PM NONE, PM NPA SW MODE LDO NPM,
PM_NPA_BYPASS_DISALLOWED, PM_DROOP_DETECT_DIS, 1000, 1050, 0,
PM_SETTLING_ERR_EN, PM_SETTLING_EN, 0}, // LDO1 ULT N600_Stepper
- {5, 62.5, 0, PM ACCESS ALLOWED, PM ALWAYS ON, PM NPA SW MODE LDO
__IPEAK, PM_NPA_BYPASS_DISALLOWED, PM_DROOP_DETECT_DIS, 1200, 1300,
0, PM SETTLING ERR EN, PM SETTLING EN, 0}, // LDO2 ULT N600 Stepper
+ {5, 62.5, 0, PM_ACCESS_ALLOWED, PM_ALWAYS_ON, PM_NPA_SW_MODE_LDO
IPEAK, PM NPA BYPASS DISALLOWED, PM DROOP DETECT DIS, 1250, 1300,
0, PM_SETTLING_ERR_EN, PM_SETTLING_EN, 0}, // LDO2 ULT N600_Stepper
3) core/systemdrivers/pmic/config/msm8937/pm_config_rpm_npa_pam.c
/* LPDDR Client */
static pm_npa_ldo_int_rep
pm_rpm_pam_lpddr_a_ldo2[] =
/**< Mode: PMIC NPA MODE ID DDR SLEEP SPEED*/
PM_NPA_GENERIC_DISABLE, /**< [Disable (default), Enable] -> max aggregation (left
to right). */
PM_NPA_SW_MODE_LDO__IPEAK, /**< [BYPASS, IPEAK (default), NPM] -> max
aggregation (left to right). */
PM NPA PIN CONTROL ENABLE NONE, /**< [NONE, EN1, EN2, EN3, EN4] ->
ORed value of list. */
PM NPA PIN CONTROL POWER MODE NONE, /**< [NONE, EN1, EN2, EN3, EN4
, SLEEPB] -> ORed value of list. */
2, /**< Perpherial Index */
0, /**< Primary (0) or Secondary (1) PMIC */
0, /**< If((old sw_en == disable) && (new sw_en == enable) || new pc_en == enable then
ldo_en_trans = true else ldo_en_trans = false */
PM NPA_BYPASS_DISALLOWED, /**< [Allowed (default), Disallowed]*/
0, /**< reserve 1 - for 32 bit boundary */
```

```
0, /**< [X uV] -> max aggregation. */
0, /**< [X mA] -> summed aggregation. */
0, /**< [X uV] -> voltage headroom needed. */
0, /**< [X uV] -> max aggregation. */
//PM_NPA_CORNER_MODE__NONE, /**< [None, Level1 (Retention), Level2, Level3,
Level4, Level5, Level6 (SuperTurbo), Not Used] */
/**< Mode: PMIC NPA MODE ID DDR LOW SPEED*/
PM_NPA_GENERIC_ENABLE, /**< [Disable (default), Enable] -> max aggregation (left
to right). */
PM NPA SW_MODE_LDO__NPM, /**< [BYPASS, IPEAK (default), NPM] -> max
aggregation (left to right). */
PM_NPA_PIN_CONTROL_ENABLE__NONE, /**< [NONE, EN1, EN2, EN3, EN4] ->
ORed value of list. */
PM_NPA_PIN_CONTROL_POWER_MODE__NONE, /**< [NONE, EN1, EN2, EN3, EN4
, SLEEPB] -> ORed value of list. */
2, /**< Perpherial Index */
0, /**< Primary (0) or Secondary (1) PMIC */
0, /**< If((old sw_en == disable) && (new sw_en == enable) || new pc_en == enable then
ldo_en_trans = true else ldo_en_trans = false */
PM_NPA_BYPASS_DISALLOWED, /**< [Allowed (default), Disallowed]*/
0, /**< reserve 1 - for 32 bit boundary */
0, /**< [X uV] -> max aggregation. */
300, /**< [X mA] -> summed aggregation. */
100, /**< [X uV] -> voltage headroom needed. */
1250000, /**< [X uV] -> max aggregation. */
//PM NPA CORNER MODE NONE, /**< [None, Level1 (Retention), Level2, Level3,
Level4, Level5, Level6 (SuperTurbo), Not Used] */
},
/**< Mode: PMIC NPA MODE ID DDR MID SPEED*/
PM_NPA_GENERIC_ENABLE, /**< [Disable (default), Enable] -> max aggregation (left
to right). */
PM NPA SW MODE LDO NPM, /** < [BYPASS, IPEAK (default), NPM] -> max
aggregation (left to right). */
PM_NPA_PIN_CONTROL_ENABLE__NONE, /**< [NONE, EN1, EN2, EN3, EN4] ->
ORed value of list. */
PM_NPA_PIN_CONTROL_POWER_MODE__NONE, /**< [NONE, EN1, EN2, EN3, EN4
, SLEEPB] -> ORed value of list. */
2, /**< Perpherial Index */
0, /**< Primary (0) or Secondary (1) PMIC */
```

```
0, /**< If((old sw_en == disable) && (new sw_en == enable) || new pc_en == enable then
ldo_en_trans = true else ldo_en_trans = false */
PM_NPA_BYPASS_DISALLOWED, /**< [Allowed (default), Disallowed]*/
0, /**< reserve 1 - for 32 bit boundary */
0, /**< [X uV] -> max aggregation. */
400, /**< [X mA] -> summed aggregation. */
100, /**< [X uV] -> voltage headroom needed. */
1250000, /**< [X uV] -> max aggregation. */
//PM_NPA_CORNER_MODE__NONE, /**< [None, Level1 (Retention), Level2, Level3,
Level4, Level5, Level6 (SuperTurbo), Not Used] */
},
/**< Mode: PMIC_NPA_MODE_ID_DDR_HIGH_SPEED*/
PM NPA GENERIC ENABLE, /** < [Disable (default), Enable] -> max aggregation (left
to right). */
PM_NPA_SW_MODE_LDO__NPM, /**< [BYPASS, IPEAK (default), NPM] -> max
aggregation (left to right). */
PM_NPA_PIN_CONTROL_ENABLE__NONE, /**< [NONE, EN1, EN2, EN3, EN4] ->
ORed value of list. */
PM_NPA_PIN_CONTROL_POWER_MODE__NONE, /**< [NONE, EN1, EN2, EN3, EN4
, SLEEPB] -> ORed value of list. */
2, /**< Perpherial Index */
0, /**< Primary (0) or Secondary (1) PMIC */
0, /**< If((old sw_en == disable) && (new sw_en == enable) || new pc_en == enable then
ldo_en_trans = true else ldo_en_trans = false */
PM NPA BYPASS DISALLOWED, /**< [Allowed (default), Disallowed]*/
0, /**< reserve 1 - for 32 bit boundary */
0, /**< [X uV] -> max aggregation. */
700, /**< [X mA] -> summed aggregation. */
100, /**< [X uV] -> voltage headroom needed. */
1250000, /**< [X uV] -> max aggregation. */
//PM_NPA_CORNER_MODE__NONE, /**< [None, Level1 (Retention), Level2, Level3,
Level4, Level5, Level6 (SuperTurbo), Not Used] */
},
};
```

 7. VDD_CX voltage to increase from NOMINAL to NOMINAL_HIGH when BIMC running at 748.8Mhz

```
[SBL1]
boot_images/core/systemdrivers/clock/hw/msm8937/src/ClockSBLConfig.c
Clock_SBLConfigType Clock_SBLConfigData =
```

```
{
<snip>
/* BIMC configuration BIMC Cfg */
.BIMC_Cfg_Feero =
{
<snip>
{ /* BIMC configuration BIMC_Cfg : at 748.8 Mhz */
- 748800000, RAIL_VOLTAGE_LEVEL_NOMINAL, &BIMCPLLConfig[6],
+ 748800000, RAIL VOLTAGE LEVEL NOMINAL HIGH, &BIMCPLLConfig[6],
{ /* Single clock root for BIMC and DDR. BIMC_GPU must be atleast half of BIMC */
{0},
{ HWIO ADDR(GCC DDR CMD RCGR), MUX BIMC, SRC RAW, 2, 0, 16, 0},/* GCC
DDR Mux, ddr_clk @ 748.8MHZ */
{ HWIO ADDR(GCC BIMC GPU CMD RCGR), MUX BIMCGPU, SRC GPLL0, 5, 0, 0
, 0} /* GCC BIMC GPU Mux, BIMC_GPU_clk at 320MHZ */
}
},
<snip>
{0},
},
[RPM]
rpm_proc/core/systemdrivers/clock/config/msm8937/ClockBSP.c
ClockMuxConfigType BIMCClockConfig[] =
{
<gin>>
- { 748800000, { HAL_CLK_SOURCE_RAW1, 2, 0, 16, 0 },
CLOCK VREG LEVEL NOMINAL, 0, CHIPINFO FAMILY UNKNOWN, &
BIMCPLLConfig[6]},
+ { 748800000, { HAL_CLK_SOURCE_RAW1, 2, 0, 16, 0 },
CLOCK VREG LEVEL NOMINAL PLUS, 0, CHIPINFO FAMILY UNKNOWN, &
BIMCPLLConfig[6]},
<snip>
{0}
};
```

 8. Increase static margin on CX on some modes, for example, increase 25mV on SVS+ and NORMINAL mode:

\boot_images\core\power\cpr\common\target\8937\ cpr_enablement_bsp.c:

```
// Cx config
static cpr_enablement_versioned_rail_config_t TSMC_8937_versioned_cpr_enablement
{
.hw versions =
{
.foundry_range = (const cpr_config_foundry_range[])
{
// Foundry Chip Min Rev Chip Max Rev CPR Min Rev CPR Max Rev
{CPR_FOUNDRY_TSMC, CPR_CHIPINFO_VERSION(0,0),
CPR_CHIPINFO_VERSION(0xFF, 0xFF), 0, 0xFF},
},
.foundry_range_count =
},
.enablement_init_params = &CPR_ENABLE_CLOSED_LOOP,
.supported_level = (cpr_enablement_supported_level_t[])
{
//Mode Static-Margin (mV) Custom static margin function aging_scaling_factor
{CPR_VOLTAGE_MODE_SVS, 25, NULL, 1},
{CPR_VOLTAGE_MODE_SVS_L1, 50+25, NULL, 1},
{CPR_VOLTAGE_MODE_NOMINAL, 50+25, NULL, 1},
{CPR_VOLTAGE_MODE_NOMINAL_L1, 25, NULL, 1},
{CPR_VOLTAGE_MODE_SUPER_TURBO, 63, NULL, 1},
},
```

• 9. Test by pegging Cx and Mx to Turbo

2018-12-18 22-20-A1 PST

Please NOTE that if we peg CX at Super Turbo, MX will also will peg to the same corner voltage.