Worksheet 17

To accompany Chapter 6.4 Models of Discrete-Time Systems

We will step through this worksheet in class.

You are expected to have at least watched the video presentation of <u>Chapter 6.4</u> (https://cpjobling.github.io/eg-247-textbook/dt_systems/4/dt_models) of the notes (https://cpjobling.github.io/eg-247-textbook) before coming to class.


If you haven't watch it afterwards!

Agenda

- Discrete Time Systems (Notes)
- Transfer Functions in the Z-Domain (Notes)
- · Modelling digital systems in MATLAB/Simulink
- · Continuous System Equivalents
- · In-class demonstration: Digital Butterworth Filter

Discrete Time Systems

In the lecture that introduced the z-transform we talked about the representation of a discrete-time (DT) system by the model shown below:



In this session, we want to explore the contents of the central block.

Example 5

Karris Example 9.10:

The difference equation describing the input-output relationship of a DT system with zero initial conditions, is:

$$y[n] - 0.5y[n-1] + 0.125y[n-2] = x[n] + x[n-1]$$

Compute:

- 1. The transfer function H(z)
- 2. The DT impulse response h[n]
- 3. The response y[n] when the input x[n] is the DT unit step $u_0[n]$

5.1. The transfer function

$$H(z) = \frac{Y(z)}{U(z)} = \dots?$$

5.2. The DT impulse response

Start with:

$$\frac{H(z)}{z} = \frac{z - 1}{z^2 + 0.5z + 0.125}$$



MATLAB Solution

```
In [ ]:
```

```
clear all
cd matlab
pwd
format compact
```

See dtm ex1 2.mlx (matlab/dtm ex1 2.mlx). (Also available as dtm ex1 2.m (matlab/dtm ex1 2.m).)

The difference equation describing the input-output relationship of the DT system with zero initial conditions, is:

$$y[n] - 0.5y[n-1] + 0.125y[n-2] = x[n] + x[n-1]$$

Transfer function

Numerator z + 1

In []:

$$Nz = [0 \ 1 \ 1];$$

Denominator $z^2 - 0.5z + 0.125$

```
In [ ]:
```

```
Dz = [1 -0.5 \ 0.125];
```

Poles and residues

```
In [ ]:
```

```
[r,p,k] = residue(Nz,Dz)
```

Impulse Response

```
In [ ]:
```

```
Hz = tf(Nz,Dz,1)
hn = impulse(Hz, 15);
```

Plot the response

```
In [ ]:
```

```
stem([0:15], hn)
grid
title('Example 5 - Part 2')
xlabel('n')
ylabel('Impulse response h[n]')
```

Response as stepwise continuous y(t)

```
In [ ]:
```

```
impulse(Hz,15)
grid
title('Example 5 - Part 2 - As Analogue Signal')
xlabel('nTs [s]')
ylabel('Impulse response h(t)')
```

5.3. The DT step response

$$Y(z) = H(z)X(z)$$


$$u_0[n] \Leftrightarrow \frac{z}{z-1}$$

$$Y(z) = H(z)U_0(z) = \frac{z^2 + z}{z^2 + 0.5z + 0.125} \cdot \frac{z}{z - 1}$$
$$= \frac{z(z^2 + z)}{(z^2 + 0.5z + 0.125)(z - 1)}$$

$$\frac{Y(z)}{z} = \frac{z^2 + z}{(z^2 + 0.5z + 0.125)(z - 1)}$$

Solve	ed by inverse Z-transform.
MΔ.	TLAB Solution
See	dtm ex1 3.mlx (matlab/dtm ex1 3.mlx). (Also available as dtm ex1 3.m (matlab/dtm ex1 3.m).)
In	[]:
opei	n dtm_ex1_3

Results



Modelling DT systems in MATLAB and Simulink

We will consider some examples in class

MATLAB

Code extracted from dtm ex1 3.m (matlab/dtm ex1 3.m):

```
In [ ]:
```

```
Ts = 1;
z = tf('z', Ts);
```

```
In [ ]:
```


```
Hz = (z^2 + z)/(z^2 - 0.5 * z + 0.125)
```

In []:

```
step(Hz)
grid
title('Example 1 - Part 3 - As Analogue Signal')
xlabel('nTs [s]')
ylabel('Step response y(t)')
axis([0,15,0,3.5])
```

Simulink Model


See dtm.slx (matlab/dtm.slx):



In []:

dtm

Results



Converting Continuous Time Systems to Discrete Time Systems

Continuous System Equivalents

- · There is no digital system that uniquely represents a continuous system
- This is because as we are sampling, we only have knowledge of signals being processed at the sampling instants, and need to *reconstruct* the inter-sample behaviour.
- In practice, only a small number of transformations are used.
- The derivation of these is beyond the scope of this module, but here we'll demonstrate the ones that MATLAB provides in a function called c2d

MATLAB c2d function

Let's see what the help function says:

In []:

help c2d

In []:

doc c2d

Example 6

- Design a 2nd-order butterworth low-pass anti-aliasing filter with transfer function H(s) for use in sampling music.
- The cut-off frequency $\omega_c=20$ kHz and the filter should have an attenuation of at least -80 dB in the stop band.
- Choose a suitable sampling frequency for the audio signal and give the transfer function H(z) and an algorithm to implement h[n]

Solution

See digit butter.mlx (matlab/digit butter.mlx).

First determine the cut-off frequency ω_c

$$\omega_c = 2\pi f_c = 2 \times \pi \times 20 \times 10^3 \text{ rad/s}$$

In []:

wc = 2*pi*20e3

$$\omega_c = 125.66 \times 10^3 \text{ rad/s}$$

From the lecture on filters, we know the 2nd-order butterworth filter has transfer function:

$$H(s) = \frac{Y(s)}{U(s)} = \frac{\omega_c^2}{s^2 + \omega_c \sqrt{2} s + \omega_c^2}$$

Substituting for $\omega_c = 125.6637 \times 10^3$ this is ...?

In []:

 $Hs = tf(wc^2,[1 wc*sqrt(2), wc^2])$

$$H(s) = \frac{15.79 \times 10^9}{s^2 + 177.7 \times 10^3 s + 15.79 \times 10^9}$$

Bode plot

MATLAB:

In []:

bode(Hs, {1e4,1e8})
grid

Sampling Frequency

From the bode diagram, the frequency at which $|H(j\omega)|$ is -80 dB is approx 12.6×10^6 rad/s.

To avoid aliasing, we should choose a sampling frequency twice this = ?

 $\omega_s = 2 \times 12.6 \times 10^6$ rad/s.

In []:

ws = 2* 12.6e6

So

 $\omega_s = 25.2 \times 10^6$ rad/s.

Sampling frequency (f_s) in Hz = ?

$$f_s = \omega_s/(2\pi)$$
 Mhz

In []:

fs = ws/(2*pi)

$$f_s = 40.11 \text{ Mhz}$$

Sampling time $T_s = ?$

 $T_s = 1/fs$ s

In []:

Ts = 1/fs

$$T_s = 1/f_s \approx 0.25 \ \mu s$$

Digital Butterworth

zero-order-hold equivalent

In []:

Hz = c2d(Hs, Ts)

Step response

In []:

step(Hz)

Algorithm

From previous result:

$$H(z) = \frac{Y(z)}{U(z)} = \frac{486.6 \times 10^{-6} z + 476.5 \times 10^{-6}}{z^2 - 1.956z + 0.9567}$$

Dividing top and bottom by z^2 ...

$$H(z) = \frac{Y(z)}{U(z)} = \frac{486.6 \times 10^{-6} z^{-1} + 476.5 \times 10^{-6} z^{-2}}{1 - 1.956 z^{-1} + 0.9567 z^{-2}}$$

expanding out ...

$$Y(z) - 1.956z^{-1}Y(z) + 0.9567z^{-2}Y(z) =$$

$$486.6 \times 10^{-6}z^{-1}U(z) + 476.5 \times 10^{-6}z^{-2}U(z)$$

Inverse z-transform gives ...

$$y[n] - 1.956y[n-1] + 0.9567y[n-2] =$$


 $486.6 \times 10^{-6}u[n-1] + 476.5 \times 10^{-6}u[n-2]$

in algorithmic form (compute y[n] from past values of u and y) ...

$$y[n] = 1.956y[n-1] - 0.9567y[n-2] + 486.6 \times 10^{-6}u[n-1] + \dots$$

 $476.5 \times 10^{-6}u[n-2]$

Block Diagram of the digital BW filter



As Simulink Model

```
In [ ]:
```

open digifilter

Convert to code

To implement:

$$y[n] = 1.956y[n-1] - 0.9567y[n-2] + 486.6 \times 10^{-6}u[n-1] + 476.5 \times 10^{-6}u[n-2]$$

```
/* Initialize */
Ts = 2.4933e-07; /* more probably some fraction of clock speed */
ynm1 = 0; ynm2 = 0; unm1 = 0; unm2 = 0;
while (true) {
    un = read_adc;
    yn = 1.956*ynm1 - 0.9567*ynm2 + 486.6e-6*unm1 + 476.5e-6*unm2;
    write_dac(yn);
    /* store past values */
    ynm2 = ynm1; ynm1 = yn;
    unm2 = unm1; unm1 = un;
    wait(Ts);
}
```

Comments

PC soundcards can sample audio at 44.1 kHz so this implies that the anti-aliasing filter is much sharper than this one as $f_s/2 = 22.05$ kHz.

You might wish to find out what order butterworth filter would be needed to have $f_c=20~{\rm kHz}$ and $f_{\rm stop}$ of 22.05 kHz.