To find  $K_P$  we have to start finding the damping factor. From the allowed overshoot the damping ratio  $\zeta$  can be found with the formula:

$$\zeta = \frac{-\ln(overshoot/100)}{\sqrt{\pi^2 + \ln(overshoot/100)}}$$
(8.1)

With a overshoot of 30% the damping ratio are found to be 0.409, and from this ratio the phase margin  $\Phi_M$  can then be found with the use of the formula:

$$\Phi_M = \arctan\left(\frac{2\zeta}{\sqrt{-2\zeta^2 + \sqrt{1 + 4\zeta^4}}}\right) \tag{8.2}$$

The phase margin is calculated to

# 8.3 controller implementation

The controller is implemented digitally, running as code on a micro-controller, this section will describe how the controller has been implemented in the code




Figure 8.5: Flowchart of the code

The flow-chart can be broken into 4 major blocks. First is the power-on initialization, which is the first 2 blocks following the green "start". The second logical block would be the two different Interrupt Service Routines or ISRs starting with a blue circle, and ending on an orange bar. Third would be the regulator function, starting with a gray circle, and returning with a purple bar, and the fourth block would be the main program loop, consisting of the entire bottom part of the flow-chart.

#### **Initialization**

This code runs once on start up, and waits 5 seconds for a serial connection to be established on it's USB port. If a serial instance is started, it prints out 1000 samples of the last 10sec of regulated throttle stored in EEPROM as comma separated values. Then it sets up regularly timed ISRs, one to handle the iBUS communication every 15ms, and one to sample the currently set throttle every 20ms. The Teensy 3.2 supports prioritized interrupts, and as such, the communication handling has been given a higher priority, as without it, the drone could shut off mid-flight.

#### **ISRs**

The two ISRs are quite different, both in size and execution time. The smallest is the "sample throttle" ISR, which samples the currently set throttle value to a FIFO-buffer of 1000 samples. This is done both to limit EEPROM writes, and to keep it quick.

The second ISR runs the handle() function of the iBUS object. This is a larger function that, best case, reads no bytes, and transmits 31 bytes. Worst case the function spends 2ms reading incoming serial bytes, then sending a 31 byte iBUS packet. Most of the time, the function will have 3.75 iBUS-packets waiting in its RX buffer, and have to send 1. If we round this up to 5 31 byte iBUS-packets it has to handle in total and assume that covers overhead, then at 115200 baud, this function will at most, take  $5*31*\frac{1E6}{115200}=1345.5~[\mu s]$  This is fine for an ISR run on the Teensy 3.2

## Regulator

For this project, as discussed in chapter 7, we've decided to use a proportional regulator. This is implemented in this function, where first the current error is calculated, then this error is multiplied with the gain Kp, and this output value is then constrained to be within two minimum and maximum values before being returned.

### Loop

This is the constantly looping part of the code, and this consciously reads the sensors, and transparently passes the incoming iBUS packets to the flight-controller on the drone. After that, it checks if the aux channel used for initiating regulation is in one of three states.

**0:** If it's in state 0, the throttle is read from the incoming iBUS packets, and passed to the drone, allowing for complete manual flight of the drone, additionally this state resets if throttle-offset the drone uses when regulating, and if the drone has been regulating, it flushes the last 10 seconds of throttle values to EEP-ROM.

1: If it's in state 1, and the offset hasn't been set yet, the drone will save the current throttle as the offset required to hover, and will then set the set-point for regulation, to the current height. This allows the drone operator to fly the drone to a height where it hovers, before enabling regulation. It will then run the regulator, assigning the output to the throttle channel

**2:** If it's in state 2, it will run the regulator with a +100mm set-point, compared to state 1.