Using the Diligent JTAG-HS2 Programming Cable with OpenOCD

2019-10-11

1 About

The JTAG-HS2 Programming Cable is an USB JTAG probe. It is available here: https://store.digilentinc.com/jtag-hs2-programming-cable/



The cable is fully compatible with all Xilinx tools, but it can also be used with OpenOCD.

2 Software configuration

2.1 Libusb

You need libusb to use the cable.

On Ubuntu, you can use apt:

 $\$ sudo apt install libusb $-1.0-0-\mathrm{dev}$

You can also build it yourself using the sources available on https://libusb.info

2.2 Libftdi

The cable contains an FTDI chip, so you need libftdi.

Ubuntu:

\$ sudo apt install libftdi1-dev

 ${\rm Or\ from\ sources:\ https://www.intra2net.com/en/developer/libftdi/download.php}$

2.3 OpenOCD Compilation

The OpenOCD interface used with the cable is ftdi.

To enable this interface, use the --enable-ftdi option when compiling OpenOCD.

```
$ ./configure --enable-ftdi <other options>
```

If you are not sure if your existing instance of OpenOCD supports the ftdi interface, you can list the debug adapter drivers that have been built into the running copy of OpenOCD with:

```
$ openocd -c interface_list
```

2.4 udev rules

It is necessary to add a udev rule to use the cable.

OpenOCD provides a file containing the rule we need. Copy it into /etc/udev/rules.d/

```
$ sudo cp <openocd>/contrib/60-openocd.rules /etc/udev/rules.d
```

The file is also available here: https://github.com/riscv/riscv-openocd/blob/riscv/contrib/60-openocd.rules

The particular entry about the HS2 cable is :

```
ATTRS{idVendor}=="0403", ATTRS{idProduct}=="6014", MODE="660", GROUP="plugdev", TAG+="uaccess"
```

The either reboot your system or reload the udev configuration with:

```
$ sudo udevadm control —reload
```

2.5 Checking

To check if the cable is recognized, run lsusb. There should be a line like this:

```
$ lsusb
[...]
Bus 005 Device 003: ID 0403:6014 Future Technology Devices International,
Ltd FT232H Single HS USB-UART/FIFO IC
[...]
```

For more details about the device, use more options:

```
s = 1 + v - d = 0403:6014
```

3 OpenOCD Config File

Examples of config files using the HS2 cable are:

- https://github.com/pulp-platform/pulpissimo/blob/master/fpga/pulpissimo-zedboard/openocd-zedboard-hs2.cfg
- https://github.com/arduino/OpenOCD/blob/master/tcl/interface/ftdi/digilent-hs2.cfg

Generally, for the interface part of the config file, you can use:

```
interface ftdi
ftdi_device_desc "Digilent USB Device"
ftdi_vid_pid 0x0403 0x6014
ftdi_serial 210249A85F9B
ftdi_channel 0
ftdi_layout_init 0x00e8 0x60eb
reset_config none
```

Use lsusb - v - d 0403:6014 to find the necessary values :

- ftdi_device_desc: this command should use the same value as the iProduct field
- ftdi_vid_pid: idVendor and idProduct
- ftdi_serial: this command is useful if there are more than one adapter connected to the host and can be omitted otherwise. The needed value is in the iSerial field.
- ftdi_channel: the default (channel 0) is fine
- ftdi_layout_init: initial values of the FTDI GPIO data and direction registers. Refer to the adapter schematics to find them. 0x00e8 and 0x60eb work for the HS2 cable

For more information about the OpenOCD commands, see http://www.openocd.org/doc/html/Debug-Adapter-Configuration.html

4 Hardware configuration

The HS2 cable does not use the TRST signal.

Do not leave the pin floating and tie it to 1 if the target TAP reset is active low, or 0 if it is active high.

5 Vivado Hardware Manager