# 06. ROS 2 Launch, Param, Bag

# Lecture

### ROS 2 Launch

- Launch multiple nodes
- Set arguments
- Monitor running nodes
- React on changes in the state of nodes
- Python, XML and YAML file formats

#### **Usage**

ros2 launch package\_name file.launch ros2 launch irob\_robot dvrk\_server.launch arm\_typ:=PSM1

### **ROS 2 Parameters**

- Configure nodes at startup or during runtime without changing the code
- · Associated with individual nodes
- Consists of: key, value, descriptor
- Available data types: bool, int64, float64, string, byte[], bool[], int64[], float64[] or string[].
- Useful command: ros2 param

## ROS 2 Bag

- · Record and playback ROS topics
- Command line tool
- API for C++ and Python

```
ros2 bag record -o <file_name> <topic_name>
ros2 bag record --all
ros2 bag info <filename.bag>
ros2 bag play <filename.bag>
```

# **Practice**

- 1: Launch Turtlesim Mimic
- 1. Create the launch folder inside the ros2\_course package, where the launch files can be stored:

```
cd ~/ros2_ws/src/ros2_course
mkdir launch
```

2. Create the turtlesim\_mimic\_launch.py file in the new launch folder a with the following content:

```
),
Node(
    package='turtlesim',
    executable='mimic',
    name='mimic',
    remappings=[
        ('/input/pose', '/turtlesim1/turtle1/pose'),
        ('/output/cmd_vel', '/turtlesim2/turtle1/cmd_vel'),
    ]
)
```

3. Add the followings to the setup.py file:

```
import os
from glob import glob

# ...

data_files=[
    ('share/ament_index/resource_index/packages',
        ['resource/' + package_name]),
        ('share/' + package_name, ['package.xml']),
        # Include all launch files.
        (os.path.join('share', package_name),
            glob('launch/*launch.[pxy][yma]*'))
],
```

4. Add the ros2launch dependency to the package.xml file:

```
<exec_depend>ros2launch</exec_depend>
```

5. Build the workspace:

```
cd ros2_ws
colcon build --symlink-install
```

6. Launch the launch file:

```
ros2 launch ros2_course turtlesim_mimic_launch.py
```

7. Publish to the topic from the command line, in a new terminal window:

```
ros2 topic pub -r 1 /turtlesim1/turtle1/cmd_vel geometry_msgs/msg/Twist "{linear: \{x: 2.0, y: 0.0, z: 0.0\}, angular: \{x: 0.0, y: 0.0, z: -1.8\}}"
```

8. Let's examine the operation of the system using rqt\_gui:

```
ros2 run rqt_gui rqt_gui
```

### 2: Launch Turtlesim Goto

- 1. Let's make a copy of turtlesim\_mimic\_launch.py from a file named turtlesim\_controller\_launch.py .
- 2. Add the turtlesim\_controller node written in the previous lesson to the launch file. The turtle to be controlled can be set using namespace or remappings.
- 1. Build the workspace:

```
cd ros2_ws
colcon build --symlink-install
```

2. launch the new launch file:

```
ros 2\ launch\ ros 2\_course\ turtlesim\_controller\_launch.py
```

## 3: Turtlesim controller params

1. Modify turtlesim\_controller so that the linear velocity and angular velocity is adjustable via ROS parameters. API example for parameters:

```
import rclpy
import rclpy.node
class MinimalParam(rclpy.node.Node):
  def init (self):
    super().__init__('minimal_param_node')
    # Declare parameter named 'my_parameter' and
    # set default value to 'world'
    self.declare parameter('my parameter', 'world')
    self.timer = self.create timer(1, self.timer callback)
  def timer_callback(self):
    my param =
self.get parameter('my parameter').get parameter value().string value
    self.get logger().info('Hello %s!' % my param)
def main():
  rclpy.init()
  node = MinimalParam()
  rclpy.spin(node)
if name == ' main ':
  main()
```

2. Let's run turtlesim\_controller.py using the previously written launch file. Let's list the parameters.

```
ros2 launch ros2_course turtlesim_controller_launch.py
ros2 param list
```

3. Change the speed and angular velocity parameters from the command line using the following command:

```
ros2 param set <NODE_NAME> <PARAM_NAME> <NEW_VALUE> ros2 param set controller speed 100.0
```

- 4: Turtlesim controller launch and substitutions
  - 1. Let's make a copy of turtlesim\_controller\_launch.py as turtlesim\_controller\_param\_launch.py. Modify the new launch file based on the

example below so that the velocity and angular velocity parameters of the launch can be specified as file arguments.

```
from launch ros.actions import Node
from launch import LaunchDescription
from launch.actions import DeclareLaunchArgument, ExecuteProcess, TimerAction
from launch.conditions import IfCondition
from launch.substitutions import LaunchConfiguration, PythonExpression
def generate launch description():
  turtlesim_ns_launch_arg = DeclareLaunchArgument(
    'turtlesim ns',
    default value='turtlesim1',
    description='Namespace for turtle 1'
  use provided red launch arg = DeclareLaunchArgument(
    'use provided red',
    default value='False'
  new background r launch arg = DeclareLaunchArgument(
    'new background r',
    default value='200'
  background g launch arg = DeclareLaunchArgument(
    'background g',
    default value='100'
  background_b_launch_arg = DeclareLaunchArgument(
    'background_b',
    default value='100'
  turtlesim ns value = LaunchConfiguration('turtlesim ns')
  use provided red value = LaunchConfiguration('use provided red')
  new background r value = LaunchConfiguration('new background r')
  background g value = LaunchConfiguration('background g')
  background b value = LaunchConfiguration('background b')
  turtlesim_node = Node(
    package='turtlesim',
    namespace=turtlesim ns value,
    executable='turtlesim node',
    name='sim',
    parameters=[{
       'background_g': background_g_value,
       'background b': background b value,
    }]
  spawn turtle = ExecuteProcess(
    cmd=[[
       'ros2 service call ',
       turtlesim ns,
       '/spawn ',
       'turtlesim/srv/Spawn ',
       ""{x: 2, y: 2, theta: 0.2}"
```

```
]],
  shell=True
change\_background\_r = ExecuteProcess(
  cmd=[[
    'ros2 param set ',
    turtlesim ns,
    '/sim background r',
    '120'
  ]],
  shell=True
change\_background\_r\_conditioned = ExecuteProcess(
  condition = If Condition (\\
    PythonExpression([
       new_background_r_value,
       ' == 200'
       ' and ',
       use provided red
    ])
  ),
  cmd=[[
    'ros2 param set ',
    turtlesim ns value,
    '/sim background r',
    new_background_r
  ]],
  shell=True
return LaunchDescription([
  turtlesim_ns_launch_arg,
  use_provided_red_launch_arg,
  new background r launch arg,
  turtlesim node,
  spawn turtle,
  change_background_r,
  TimerAction(
    period=2.0,
    actions=[change_background_r_conditioned],
])
```

2. Build the workspace and run turtlesim\_controller\_param\_launch.py:

```
cd ros2_ws
colcon build --symlink-install
ros2 launch ros2_course turtlesim_controller_param_launch.py
```

3. Let's list the arguments of the new launch file:

ros2 launch ros2\_course turtlesim\_controller\_param\_launch.py --show-args

4. Run the launch file by setting the arguments:

```
\label{lem:controller_param_launch.py speed:=100.0} ros2 \ launch \ ros2\_course \ turtlesim\_controller\_param\_launch.py \ speed:=100.0 \\ omega:=60.0
```

- 5. Using the above example, let's set the background color also using command line argument(s).
- 5: Rosbag
- 1. While the program implemented in the previous exercise is running, record the contents of the topics in a rosbag file.

```
ros2 bag record --all
```

!!! tip "Syntax" The filename and the topics to record can also be set, e.g.:

```
ros2 bag record -o turtle bagfile 1 /turtle1/cmd vel /turtle1/pose
```

1. Use the following command to query the properties of the bag file:

```
ros2 bag info <PATH TO BAGFILE>
```

2. Play back the bag file and plot the <code>pose/x</code> value of one of the turtles on a graph using rqt gui.

```
ros2 bag info <PATH TO BAGFILE>
```

ros2 run rqt\_gui rqt\_gui

# Useful links

- ROS 2 Launch Tutorial
- ROS 2 Parameters
- Using ROS 2 parameters in a Class
- ROS 2 Bag