Product Manual

UVCS Adapted for Linux Common Engine Library

Product Manual

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (http://www.renesas.com).

Renesas Electronics
www.renesas.com

Rev.0.91 2014.05

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
3. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics product.
5. Renesas Electronics products are classified according to the following two quality grades: “Standard” and “High Quality”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below.

   “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots etc.

   “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; and safety equipment etc.

   Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (nuclear reactor control systems, military equipment etc.). You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application for which it is not intended. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.
6. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
7. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or systems manufactured by you.
8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
9. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You should not use Renesas Electronics products or technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. When exporting the Renesas Electronics products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations.
10. It is the responsibility of the buyer or distributor of Renesas Electronics products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the contents and conditions set forth in this document, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties as a result of unauthorized use of Renesas Electronics products.
11. This document may not be reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

(2012.4)

How to Use This Manual

1. Purpose and Target Readers

This manual is designed to provide the user with an understanding of the user interface of this software.
Target reader is the user which designs the applied system using this software.
For using this manual, it is required following knowledge,

- Knowledge of Moving picture.
- Knowledge of RTOS (Real time operating system).
- Knowledge of each CODEC to use.

2. About using this software

When you use this software, you need to enter into the software license agreement with us.

3. Related Manuals

As a related document, the next manual and document are prepared for using this software.
Please contact Renesas Electronics sales office if necessary.

- UVCS Decode Engine Library User's Manual
- UVCS Encode Engine Library User's Manual

4. About Revision History

Revision history is only the main point that we corrected or added it for the former edition.
It is not the thing which recorded all the revision contents.
Please refer to this manual about a detail.

5. List of Abbreviations

Abbreviation	Long Name
UVCS-CMN	UVCS Adapted for Linux Common Engine Library
UVCS-DEC	UVCS Adapted for Linux Decode Engine Library
UVCS-ENC	UVCS Adapted for Linux Encode Engine Library
DRV-CORE	VCP3 Driver Adapted for Linux Core Library

6. List of Acronyms

Acronyms	Long Name
UVCS	Unified Video CODEC Server

All the trademarks and registered trademarks belong to each owner.

ARM is registered trademarks or trademarks of ARM Limited.
Linux is a registered trademark of Linus Torvalds.
Android is a registered trademark of Google Inc.

Table of contents

1. Product Specifications 2

2. Development Environment 3

3. File List 4

1. Product Specifications

The Product specification is described in Table 1.1.

Table 1.1 Product specification

Items	Description
Product type name	RTM0AC0000UVCSCMN1SL32C
Product Name	UVCS Adapted for Linux Common Engine Library
Software categories	Moving picture playback and recoding
CPU	ARMv7
Target LSI	R-Car H2 / M2 / E2 Series
Endian	Little
Supported OS	Linux 3.10

2. Development Environment

The toolchain of makefiles are described in Table 2.1.

The folder of each makefile refers to 3.File List.

Table 2.1 Toolchain

Folder 1	Folder 2	Folder 3	Toolchain
source	makefile	linaro_4_7_3	gcc-linaro-arm-linux-gnueabihf-4.7-2013.02-01-20130221_linux.tar.bz2

3. File List

The File-list of this library is described in Table 3.1.

Table 3.1 File List

dir			filename	description
include	-	-	uvcs_cmn.h	Header file for UVCS-CMN
			uvcs_types.h	
			GPL-COPYING	
			MIT-COPYING	
source	uvcs_cmn	-	uvcs_cmn_api.c	Source file of UVCS-CMN
			uvcs_cmn_dump.c	
			uvcs_cmn_dump.h	
			uvcs_cmn_internal.h	
			GPL-COPYING	
			MIT-COPYING	
	uvcs_lkm	-	uvcs_ioctl.h	Source file of Loadable Kernel Module for UVCS-CMN (Sample source)
			uvcs_lkm.c	
			uvcs_lkm_internal.h	
			uvcs_lkm_uf_io.c	
			uvcs_lkm_uf_other.c	
			uvcs_lkm_uf_semaphore.c	
			uvcs_lkm_uf_thread.c	
			GPL-COPYING	
			MIT-COPYING	
	driver_core	-	mcvx_api.c	Source file of VCP3 Driver Core
			mcvx_api.h	
			mcvx_register.h	
			mcvx_types.h	
			GPL-COPYING	
			MIT-COPYING	
	makefile	linaro_4_7_3	Makefile	Make file of UVCS-CMN for Linux
-	-	-	UVCS_CMN_FUNCTIONS_MANUAL.pdf	UVCS-CMN Functions Manual.
			UVCS_CMN_SAMPLE_CODES_MANUAL_FOR_LINUX.pdf	UVCS-CMN Sample Codes Manual.
			UVCS_CMN_PRODUCT_MANUAL_FOR_LINUX.pdf	UVCS-CMN Product Manual

REVISION HISTORY	UVCS Adapted for Linux Common Engine Library Product Manual

Rev.	date	revision	
		pages	point
0.10	2013.05.31	–	alpha version 1.0
0.20	2013.06.30	–	alpha version 2.0
0.30	2013.07.26	–	alpha version 3.0
0.40	2013.08.26	–	alpha version 4.0
0.50	2013.09.09	–	alpha version 5.0
0.51	2013.09.17	–	alpha version 5.1
0.60	2013.10.21	–	alpha version 6.0
0.70	2013.11.28	–	alpha version 7.0
0.80	2014.01.31	–	alpha version 8.0
0.90	2014.03.06	–	alpha version 9.0
0.91	2014.05.12	–	beta version 6.0

UVCS Adapted for Linux Common Engine Library
Product Manual

Publication Date Rev.0.91 May 12, 2014

Published by Renesas Electronics Corporation

© 2014 Renesas Electronics Corporation. All rights reserved.

UVCS Adapted for Linux Common Engine Library

Product Manual

Renesas Electronics Corporation