

# **OMX Media Component**

**Product Manual:** 

**OMX Media Component Encoder Common Library** 

for Linux

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (http://www.renesas.com).

#### Notice

- Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
- Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics
  does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages
  incurred by you resulting from errors in or omissions from the information included herein.
- 3. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
- 4. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics product.
- 5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
  - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots etc.
  - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; and safety equipment etc.

Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (nuclear reactor control systems, military equipment etc.). You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application for which it is not intended. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.

- 6. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- 7. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or systems manufactured by von
- 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 9. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You should not use Renesas Electronics products or technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. When exporting the Renesas Electronics products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations.
- 10. It is the responsibility of the buyer or distributor of Renesas Electronics products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the contents and conditions set forth in this document, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties as a result of unauthorized use of Renesas Electronics products.
- 11. This document may not be reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

# **Table of Contents**

1.	OV	/ERVIEW	. 8
		Overview of This Document	
2.	PR	ODUCT SPECIFICATION	. 4
9	2.2.	Basic Specification	. 5
3.	LIS	ST OF FILES	. 7
4.	DE	EPENDENT PRODUCTS	. 8
5.	US	SER DEFINED FUNCTIONS (UDF)	. 8
6.	IN	STALLATION	10

# **Tables**

3
4
6
r.gz7
8
r.gz





Specifications in this document are tentative and subject to change.

Product Manual: OMX Media Component Encoder Common Library for Linux

RTM0AC0000XVCMNE20SL32E Rev. 0.01 Mar. 27, 2014

#### 1. Overview

#### 1.1. Overview of This Document

This document is the Product Manual of OMX Media Component Encoder Common Library for Linux. For the functional specifications of the library, see related documents [1].

#### 1.2. Related Documents

Table 1-1 lists the related documents.

#### **Table 1-1 List of Related Documents**

No.	Document Name	Description
[1]	OMX Media Component User's Manual Encoder Common Part	The user's manual that describes functional
		specifications of this library.
[2]	OMX Integration Guide for Linux	OMX Integration Guide documents describe
		how to integrate the OMX to the system.

OMX Media Component Encoder Common Library for Linux

# 2. Product Specification

## 2.1. Basic Specification

Table 2-1 shows the basic specification of this library.

**Table 2-1 Basic Specification** 

Item	Description
Product Number	RTM0AC0000XVCMNE20SL32C
Product Name	OMX Media Component Encoder Common Library for Linux
Software categories	Multimedia codec processing
Function	Provide OpenMAX IL 1.1.2 Core / Component API
Target CPU	ARMv7 Architecture
Target LSI	R-Car H2 / M2 / E2 Series
Language	C Language
Endian	Little endian
Supported OS	Linux 3.4 (For evaluation purpose only)
Tool chain	GCC 4.7.4 (cortexa15hf-vfp-neon-poky-linux-gnueabi) built by R-CarH2/M2 Yocto
1001 CHAIT	recipe package
Library Format	Dynamic Link Library
CPU load	See each OMX Media Component Product Manual.
Number of thread	See each OMX Media Component Product Manual.
Thread priority	Thread priority shall be determined in User Defined Functions part.
System Call	This library does not call system call functions directly. All OS-dependent processing
- <b>,</b>	shall be implemented in User Defined Functions part.



2 Product Specification

for Linux 2 Product Specification

## 2.2. Memory Requirement

Table 2-2 shows the memory requirement of this library. The sizes in Table 2-2 do not include the memory consumption in User Defined Functions.

**Table 2-2 Memory Requirement** 

Item	Description	
Object Size	312 [Kbyte]	
Stack Size	See each OMX Media Component Product Manual.	
Heap Memory Size	See each OMX Media Component Product Manual.	
Shared Memory Size	See each OMX Media Component Product Manual.	



**OMX Media Component Encoder Common Library** 

for Linux 2 Product Specification

#### 2.3. Reserved Words

Table 2-3 lists reserved words of this library.

## **Table 2-3 Reserved Words**

Reserved Words	Description
OMX	The prefix word for the names of defines, functions and Macros that is defined in OpenMAX IL Specification.
OMXR	The prefix word for the names of defines and Macros in this library.
Omxr	The prefix word for the names of functions and variables in this library.



for Linux 3 List of Files

## 3. List of Files

Table 3-1 shows the file list of this library.

### Table 3-1 File List

	Directory		File name	Description
R	TM0AC0000X\	CMNE20SL32C		
+	Document	en	RTM0AC0000XVCMNE20SL32E.pdf	Product Manual(This document)
			omx_users_manual_vecmn_en.pdf	User's Manual
			RTM0AC0000XVCMNE20SL32C_Relea	Release Note
			seNote.txt	
	-	_	Software.tar.gz	See Table 3-2

Table 3-2 Files included in Software.tar.gz

				iabic	5-2 i lies iliciadea ili ooliw	rai oitai ig=
			Dire	ctory	File name	Description
Software					-	
+	ON	/IXR			-	
	+	conf	fig		omxr_config_vecmn.txt	Configuration file
		include			OMXR_Extension_vecmn.h	Renesas OMX Extension header
					OMXR_Extension_video.h	Renesas OMX Extension header
		lib			-	
		+	linu	X	-	
			+	linaro_4_7_3	libomxr_mc_vcmn.so.2.0.0	Library for Linux
					libomxr_mc_vecmn.so.2.0.0	Library for Linux
					libvcp3_mcve.so.1.0.0	Library for Linux
					libuvcs_enc.so.1.0.0	Library for Linux
	UD	F_Lir	านx		-	
	+	- modules			-	
		+	om	r_uvcs_udf	Makefile.am	Makefile for UDF sample source code
					omxr_uvcs_udf.c	UDF sample source code
					omxr_uvcs_udf.h	UDF sample source code
					omxr_uvcs_udf_osal.h	UDF sample source code
					omxr_uvcs_udf_osal_linux.c	UDF sample source code
					uvcs_ioctl.h	UDF sample source code

Product Manual Specific

Specifications in this document are tentative and subject to change.

**OMX Media Component Encoder Common Library** 

for Linux 4 Dependent Products

# 4. Dependent Products

Table 4-1 lists the dependent products of this library.

**Table 4-1 Dependent Products** 

Product Number	Product Name
RTM0AC0000XCMCTL20SL32C	OMX Media Component Common Library for Linux
RTM0AC0000UVCSCMN1SL32C	UVCS Adapted for Linux Common Engine Library



## 5. User Defined Functions (UDF)

This library requires User Defined Functions (UDF) to operate the function. UDF contains OS and hardware abstraction for the OMX libraries. A user of this library needs to implement UDF part to adapt the library to user's platform. UDF for this library shall have the following functions:

- Interfacing between this library and UVCS Adapted for Linux Common Engine Library (kernel module)

UDF sample source code is available in the deliverable of this library. The UDF sample source code is out of warranty. The UDF sample source code has been confirmed by using Renesas R-Car H2/M2 Linux Board Support Package and R-Car H2/M2 Series MMP Reference Library for Linux.

For the details of implementation and integration of UDF, see related document [2].



Under development Preliminary document Specifications in this document are tentative and subject to change.

OMX Media Component Encoder Common Library

for Linux 6 Installation

## 6. Installation

See related document [2].



	Product Manual:
REVISION HISTORY	OMX Media Component Encoder Common Library
	for Linux

D	Date	Description		
Rev.		Page	Summary	
0.01	Mar. 27, 2014	-	Draft version	



#### **SALES OFFICES**

# Renesas Electronics Corporation

http://www.renesas.com

Refer to "http://www.renesas.com/" for the latest and detailed information.

Renesas Electronics America Inc. 2880 Scott Boulevard Santa Clara, CA 95050-2554, U.S.A. Tel: +1-408-588-6000, Fax: +1-408-588-6130

Tel: +1-406-306-0000, Fax: +1-406-306-0130

Renesas Electronics Canada Limited
1101 Nicholson Road, Newmarket, Ontario L3Y 9C3, Canada
Tel: +1-905-898-5441, Fax: +1-905-898-3220

Renesas Electronics Europe Limited
Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K
Tel: +44-1628-651-700, Fax: +44-1628-651-804

Renesas Electronics Europe GmbH Arcadiastrasse 10, 40472 Düsseldorf, Germany Tel: +49-211-65030, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd.
7th Floor, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100083, P.R.China Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd. Unit 204, 205, AZIA Center, No.1233 Lijiazui Ring Rd., Pudong District, Shanghai 200120, China Tel: +86-21-5877-1818, Fax: +86-21-6887-7858 / -7898

Renesas Electronics Hong Kong Limited
Unit 1601-1613, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong
Tel: +852-2886-9318, Fax: +852 2886-9022/9044

Renesas Electronics Taiwan Co., Ltd. 13F, No. 363, Fu Shing North Road, Taipei, Taiwan Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd. 80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre Singapore 339949 Tel: +65-6213-0200, Fax: +65-6213-0300

Renesas Electronics Malaysia Sdn.Bhd.
Unit 906, Block B, Menara Amoorp, Amocorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia Tei: +60-3-7955-9951, Fax: +60-3-7955-99510

Renesas Electronics Korea Co., Ltd. 11F., Samik Lavied' or Bidg., 720-2 Yeoksam-Dong, Kangnam-Ku, Seoul 135-080, Korea Tel: +82-2-558-3737, Fax: +82-2-558-5141

OMX Media Component
Product Manual:
OMX Media Component Encoder Common Library
for Linux

Publication Date: Rev. 0.01 Mar. 27, 2014

Published by: Renesas Electronics Corporation

© 2014 Renesas Electronics Corporation. All rights reserved.

# **OMX Media Component**

**Product Manual:** 

OMX Media Component Encoder Common Library

for Linux

