


# Chapter 8 Nonlinear Systems Theory

- 8.1 Overview of Nonlinear Systems
- 8.2 Typical Nonlinear Characteristics and Mathematical Description
- 8.3 Describing Function Approach
- 8.4 Phase Plane Analysis




## **Interesting Examples of Nonlinearity**



Lorenz Chaotic Attractor




## **Interesting Examples of Nonlinearity**



**Acrobot Robots** 





**Biomimetic robots** 



#### § 8.1 Overview of Nonlinear Systems

$$y^{(n)} + a_{n-1}y^{(n-1)} + \dots + a_1y' + a_0y + \varepsilon \cdot f(y, y', \dots y^{(n)}) = x$$

if  $\varepsilon \to 0$ , Linear Systems

if  $\varepsilon$  can't be ignored, Nonlinear systems

Such as: 
$$\ddot{y} + \dot{y}\dot{y} + y = \sin \omega t$$

$$(\ddot{y})^2 + 3\dot{y} + y = e^t$$

$$\ddot{y} + 3\dot{y} + y^2 = x$$
Thinking: How to distinguish nonlinearity?





## 1 Significance of Studying Non-linear Systems

1) There are no systems without nonlinearity.

(Dead-zone characteristics of measurement element, saturation characteristics of amplification element, Dead-zone and saturation characteristics of actuator, Gap Characteristics of actuating unit and so on).

- 2) The *intrinsic nonlinearities* make the linear system theory cannot be applied in analyzing the actual systems. The influences of nonlinear factors can not be explained by linear system theory.
- 3) The nonlinear characteristics do not always have negative impacts on systems. *Optimal control laws are often nonlinear laws*, such as the relay and waveform generator.

## 2. Features of Nonlinear Systems

Comparing with linear control systems, non-linear systems have many *new* features:

- 1. A linear systems satisfies the *principle of superposition*, while a non-linear system does not.
  - (1) additivity: y = f(x)

$$f(x_1 + x_2) = f(x_1) + f(x_2)$$
 additivity

$$f(x) = ax$$
 A linear function satisfies the principle of superposition obviously



Thinking: 
$$f(x) = ax + b$$

## **Superposition Theorem**

## • (2) multiplicativity :

$$f(ax) = af(x)$$

Nonlinear systems may be additive, but it is not multiplicative.




Fig. 8-1 Nonlinear systems with filters

$$X_1 o Y_1, \ X_2 o Y_2$$
 additivity:  $X_1 + X_2 o Y_1 + Y_2$  multiplicativity :  $nX_1 o nY_1$ 7



### 2. The stabilities of non-linear systems depend on not only the inherent structure and parameters of control systems, but also the initial conditions and the inputs.

**Example:** An nonlinear systems described by the non-linear  $\dot{x} = -x(1-x)$ differential equation:

> have two equilibrium points obviously, x1=0 and x2=1. The equation equals x'=0 to

$$\frac{dx}{x(1-x)} = -dt$$

Integrating both sides:  $\ln \frac{cx}{1-x} = -t$   $\therefore \frac{cx}{1-x} = e^{-t}$ 

$$\therefore \frac{cx}{1-x} = e^{-t}$$

Set the initial state of the system be  $x_0$ if t = 0, then:

$$c = \frac{1 - x_0}{x_0}$$



$$\therefore x(t) = \frac{x_0 e^{-t}}{1 - x_0 + x_0 e^{-t}}$$




Fig. 8–2 First-order non-linear systems

If 
$$x_0 < 1$$
,  $t \to \infty$ , then  $x \to 0$ 


Initial conditions affect stability of the system!

If 
$$x_0 > 1$$
, when  $t = \ln \frac{x_0}{x_0 - 1}$ , we have  $x \to \infty$ 



 The initial conditions can be even used as a key to the encryption of transmission signals in Chaotic systems







- 3. *Periodic oscillation* does not exist in an actual physical linear systems, while it may occur in a nonlinear system.
- 4. A stable linear system under a *periodic input* → output with the same frequency; A nonlinear system under a periodic input → many complex cases of the outputs




Fig. 8-3 Amplitude frequency characteristic of output of non-linear spring

11



(2) subharmonic oscillation and harmonic oscillation 旅游波振荡

Steady-state outputs of non-linear systems can be divided into subharmonic oscillation and harmonic oscillation. When the input signal is sinusoidal, showed in Fig. 8-4




Fig. 8-4 subharmonic oscillation and harmonic oscillation

#### 3. Methods of Studying Nonlinear Systems

- BJto Phase-Plane Analysis is the graphical method used to analyze first-order and second-order Nonlinear systems. It analyzes the features of Nonlinear systems through drawing phase portrait to find all the solutions of the differential equations in any initial condition. It is the generalization and application of time-domain analyzing method in non-linear systems. It can only be used in the first- and second-order nonlinear systems.
- Describing Function Approach is a kind of method for analyzing nonlinear systems inspired by frequency method of linear systems. It is the generalization of frequency method in nonlinear systems, and is not restricted by the system order. 文章 以及转动的
- Numerical Solution is a kind of numerical methods to solve the nonlinear differential equation using high-speed computers. It is almost the only effective method for analyzing and designing complex nonlinear systems.

一對教之門



#### Note:

- It should be pointed out that, the above methods aim at solving the "analysis" problems of nonlinear systems based on analyzing the system stability.
- The achievement of "synthesis" methods in nonlinear systems is much less than stability problem. There are NO general approaches can be used to design arbitrary nonlinear systems so far.



## § 8.2 Typical Nonlinear characteristics and Their Mathematical Description

- **8.2.1** Saturation characteristics
- **8.2.2** Dead-zone characteristics
- 8.2.3 Gap characteristics

**8.2.4** Relay characteristics



### 1. Saturation

#### A common nonlinearity in electronic amplifiers

**Mathematical description of saturation features:** 

$$x(t) = \begin{cases} ke(t), & |e(t)| < e_0 \\ ke_0 sign[e(t)], & |e(t)| \ge e_0 \end{cases}$$

$$sign[e(t)] \text{ is the } sign \text{ function}$$

$$sign[e(t)] = \begin{cases} 1, & e(t) \ge 0 \\ -1, & e(t) < 0 \end{cases}$$




Fig. 8-5 Saturation characteristics

## 2. Dead-zone

Dead-zone can be also called neutral zone, its mathematical description is:

$$x(t) = \begin{cases} 0, & |e(t)| \le e_0 \\ k[e(t) - e_0 sign[e(t)]], & |e(t)| > e_0 \end{cases}$$

$$x(t) \xrightarrow{e_0} \xrightarrow{e_0} e(t)$$

Fig. 8-6 Dead-zone characteristics

## 3. Gap

Mechanical transmission devices are based on gears, there must exist some gaps for sliding and reversing transmission, that means the gears have to pass a few distances when reversing transmission is needed.

#### **Its mathematical description is:**

$$x(t) = \begin{cases} k[e(t) - e_0], & \dot{x}(t) > 0 \\ k[e(t) + e_0], & \dot{x}(t) < 0 \\ bsign[e(t)], & \dot{x}(t) = 0 \end{cases}$$





Fig. 8-7 Gap characteristics





Input x is the rotation angle of the driven gear Output y is the rotation angle of the passive gear



## 4. Relay




图1 电磁式继电器原理图

1- 铁心 2-旋转棱角 3-释放弹簧 4-调节螺母 5--衔铁 6-动触点 7-静触点 8-非磁性垫片 9-线圈


#### Principle of relay:

Input voltage → Current in coil → generates the electromagnetic force → Close the relay contact

If the input voltage is  $e_0$ , the electromagnetic force generated by current in coil is enough to make the switch to be closed, then  $e_0$  is called *Operation Voltage*.

强种电压






The relay contact will not release when the input voltage is reduced to  $e_0$  because of the influence of Hysteresis.

When it is further reduced to  $me_0$  (m < 1), the relay contact will be released. Then  $me_0$  is called Release Voltage.

释放电几

图1 电磁式继电器原理图 1- 铁心 2-旋转棱角 3-释放弹簧 4-调节螺母 5--衔铁 6-动触点 7-静触点 8-非磁性垫片 9-线圈



There are four forms of relay characteristics:



#### 1. Ideal relay characteristics

$$x(t) = \begin{cases} M, & e > 0 \\ -M, & e < 0 \end{cases}$$




Fig. 8-8(a) Perfect relay characteristics



#### 2. Relay characteristics with Dead-zone

$$x(t) = \begin{cases} M, & e(t) > e_0 \\ 0, & -e_0 \le e(t) \le e_0 \\ -M, & e(t) < -e_0 \end{cases}$$

$$0 \quad e_0 \quad e(t)$$

Fig. 8-8(b) Relay characteristics with Dead-zone



## 3. Relay characteristics Hysteresis loop

$$x(t) = \begin{cases} M, & \dot{e} > 0, e > e_0 \\ & \dot{e} < 0, e > -e_0 \end{cases}$$
$$-M, & \dot{e} < 0, e < e_0 \\ & \dot{e} < 0, e < -e_0 \end{cases}$$




Fig. 8-8 (c) Relay characteristics with Hysteresis loop

# -

#### 4. Relay characteristics with Deadzone and Hysteresis loop

$$x(t) = \begin{cases} M, & \dot{e} > 0, e \ge e_0 \\ \dot{e} < 0, e > me_0 \end{cases}$$

$$\dot{e} > 0, -me_0 < e < e_0 \\ \dot{e} < 0, -e_0 < e < me_0 \end{cases}$$

$$-M, & \dot{e} > 0, e < -me_0 \\ \dot{e} < 0, e \le -e_0 \end{cases}$$




Fig. 8-8(d) Relay characteristics with Dead-zone and Hysteresis loop