


ROS INTRODUCTION

What is ROS?

ROS = Robot Operating System









ros.org

Plumbing

- Process management
- Inter-process communication
- Device drivers

Tools

- Simulation
- Visualization
- Graphical user interface
- Data logging

Capabilities

- Control
- Planning
- Perception
- Mapping
- Manipulation

Ecosystem

- Package organization
- Software distribution
- Documentation
- Tutorials

ROS Architecture & Philosophy

Peer to peer

Individual programs communicate over defined API (ROS messages, services, etc.).

Distributed

Programs can be run on multiple computers and communicate over the network.

Multi-lingual

ROS modules can be written in any language for which a client library exists (C++, Python, MATLAB, Java, etc.).

Light-weight

Stand-alone libraries are wrapped around with a thin ROS layer.

Free and open-source

Most ROS software is open-source and free to use.

ROS Master

- Manages the communication between nodes
- Every node registers at startup with the master

Start a master with

> roscore



More info http://wiki.ros.org/Master



ROS Nodes

- Single-purpose, executable program
- Individually compiled, executed, and managed
- Organized in packages

Run a node with


> rosrun package_name node_name

See active nodes with

> rosnode list

Retrieve information about a node with

> rosnode info node_name



More info http://wiki.ros.org/rosnode

ROS Topics

- Nodes communicate over topics
 - Nodes can publish or subscribe to a topic
 - Typically, 1 publisher and n subscribers
- Topic is a name for a stream of messages

List active topics with


> rostopic list

Subscribe and print the contents of a topic with

> rostopic echo /topic

Show information about a topic with

> rostopic info /topic



More info http://wiki.ros.org/rostopic

ROS Messages


- Data structure defining the type of a topic
- Compromised of a nested structure of integers, floats, booleans, strings etc. and arrays of objects
- Defined in *.msg files

See the type of a topic

> rostopic type /topic

Publish a message to a topic

> rostopic pub /topic type args



ROS Messages

Pose Stamped Example

geometry msgs/Point.msg

```
float64 x
float64 y
float64 z
```

sensor msgs/lmage.msg

```
std_msgs/Header header
uint32 seq
time stamp
string frame_id
uint32 height
uint32 width
string encoding
uint8 is_bigendian
uint32 step
uint8[] data
```

geometry msgs/PoseStamped.msg

```
std_msgs/Header header
uint32 seq
time stamp
string frame_id
geometry_msgs/Pose pose
geometry_msgs/Point position
float64 x
float64 y
float64 z
geometry_msgs/Quaternion orientation
float64 x
float64 x
float64 x
float64 y
float64 y
float64 z
float64 w
```

ROS Launch

- launch is a tool for launching multiple nodes (as well as setting parameters)
- Are written in XML as *.launch files
- If not yet running, launch automatically starts a roscore

Browse to the folder and start a launch file with

> roslaunch file_name.launch

Start a launch file from a package with

> roslaunch package_name file_name.launch

More info

http://wiki.ros.org/roslaunch

Example console output for roslaunch roscpp_tutorials talker_listener.launch

```
tudent@ubuntu:~/catkin ws$ roslaunch roscpp tutorials talker listener.launch
   logging to /home/student/.ros/log/794321aa-e950-11e6-95db-000c297bd368/ros
thecking log directory for disk usage. This may take awhile.
 ress Ctrl-C to interrupt
 one checking log file disk usage. Usage is <1GB.
started roslaunch server http://ubuntu:37592/
 UMMARY
 -----
 ARAMETERS
  /rosdistro: indigo
 * /rosversion: 1.11.20
 ODES
   listener (roscpp tutorials/listener)
   talker (roscpp tutorials/talker)
 uto-starting new master
process[master]: started with pid [5772]
ROS_MASTER_URI=http://localhost:11311
setting /run id to 794321aa-e950-11e6-95db-000c297bd368
process[rosout-1]: started with pid [5785]
started core service [/rosout]
process[listener-2]: started with pid [5788]
process[talker-3]: started with pid [5795]
 INFO] [1486044252.537801350]: hello world 0
 INFO] [1486844252.638886584]: hello world 1
 INFO] [1486044252.738279674]: hello world 2
```

ROS Launch

File Structure

Attention when copy & pasting code from the internet

talker listener.launch

Notice the syntax difference for self-closing tags: <tag>< dag</tag>

- launch: Root element of the launch file
- node: Each <node> tag specifies a node to be launched
- name: Name of the node (free to choose)
- pkg: Package containing the node
- type: Type of the node, there must be a corresponding executable with the same name
- output: Specifies where to output log messages (screen: console, log: log file)

More info

http://wiki.ros.org/roslaunch/XML

http://wiki.ros.org/roslaunch/Tutorials/Roslaunch%20tips%20for%20larger%20projects

ROS Launch

Arguments

Create re-usable launch files with <arg> tag, __
 which works like a parameter (default optional)

<arg name="arg_name" default="default_value"/>

Use arguments in launch file with

\$(arg arg_name)

When launching, arguments can be set with

```
> roslaunch Launch_file.Launch arg_name:=value
```

```
range world.launch (simplified)
```

```
<?xml version="1.0"?>
<launch>
 <arg name="use sim time" default="true"/>
  <arg name="world" default="gazebo_ros_range"/>
  <arg name="debug" default="false"/>
  <arg name="physics" default="ode"/>
  <group if="$(arg use sim time)">
    <param name="/use sim time" value="true" />
  </group>
  <include file="$(find gazebo ros)</pre>
                               /launch/empty world.launch">
    <arg name="world_name" value="$(find gazebo_plugins)/</pre>
                     test/test worlds/$(arg world).world"/>
    <arg name="debug" value="$(arg debug)"/>
    <arg name="physics" value="$(arg physics)"/>
 </include>
</launch>
```

More info

http://wiki.ros.org/roslaunch/XML/arg



ROS Launch

Including Other Launch Files

Include other launch files with <include> tag to organize large projects

```
<include file="package_name"/>
```

- Find the system path to other packages with \$(find package_name)
- Pass arguments to the included file

```
<arg name="arg_name" value="value"/>
```

```
range world.launch (simplified)
```

```
<?xml version="1.0"?>
<launch>
 <arg name="use sim time" default="true"/>
  <arg name="world" default="gazebo_ros_range"/>
  carg name="debug" default="false"/>
  carg name="physics" default="ode"/>
  <group if="$(arg use sim time)">
   <param name="/use sim time" value="true" />
  </group>
  cinclude file="$(find gazebo_ros)
                               /launch/empty world.launch">
   carg name="world_name" value="$(find gazebo plugins)/
                     test/test worlds/$(arg world).world"/>
   <arg name="debug" value="$(arg debug)"/>
   carg name="physics" value="$(arg physics)"/>
  </include>
</launch>
```

More info

http://wiki.ros.org/roslaunch/XML/include




Gazebo Simulator

Gazebo Simulator

- Simulate 3d rigid-body dynamics
- Simulate a variety of sensors including noise
- 3d visualization and user interaction
- Includes a database of many robots and environments (Gazebo worlds)
- Provides a ROS interface
- Extensible with plugins

Run Gazebo with

> rosrun gazebo_ros gazebo



More info http://gazebosim.org/ http://gazebosim.org/tutorials

ROS Introduction

- ROS package structure
- ROS C++ client library (roscpp)
- RViz visualization
- TF Transformation System
- rqt User Interface
- Robot models (URDF)
- Simulation descriptions (SDF)
- ROS time
- ROS bags

ROS Introduction

- ROS publishers and subscribers
- ROS parameter server
- ROS services
- ROS actions (actionlib)