DIYINO PRIME V1.0 USER MANUAL

1 Introduction

DIYino Prime is an Arduino compatible integrated circuit board for all projects implementing Light/Sound/Motion. Its main field of application is to control lightsaber electronics. It is compatible to Arduino, i.e. it can be programmed using Arduino compatible IDE's (Arduino IDE, Eclipse etc.)




2 GENERAL PRODUCT CHARACTERISTICS

2.1 CIRCUIT OVERVIEW (SIZE, SHORT FEATURE OVERVIEW)

- Very compact size, dimensions: 22 mm(W)x 60 mm(L)x 8 mm(H)
- Arduino Compatible
- Gapless Wav-audio playback
- 3W audio amplifier (supports $8\Omega/4\Omega$ speakers up to 3W)
- Built in high-end gesture detection sensor (6-axis accelerometer and gyro)
- Includes FTDI USB2Serial chipset for plug-and-play programming using Arduino IDE or similar
- 6 PWM controlled build-in low-side drivers as power extenders with up to 1.1A current capability
- Input voltage range 3.3V-5V or 6V-20V



2.2 CIRCUIT PINOUT



Pin	Functionality	Comment
VIN	Voltage-in pin. Connect to Battery(+)/power source(+).	Input voltage must stay between 6V and 20V for correct
	Input to 5V LDO.	operation.
NC	Non-connected pin. Can be used on the PCB for signal routing.	
VIN	Voltage-in pin. Connect to Battery(+)/power source(+). Input to 5V LDO.	Input voltage must stay between 6V and 20V for correct operation.
RX	D0 digital I/0 of Atmega328P. RX pin of Serial UART.	



TX	D1 digital I/O of Atmega328P. TX pin of Serial UART.	
D2	D2 digital I/O of Atmega328P. INT capable pin.	
D4	D4 digital I/O of Atmega328P.	
D7	D7 digital I/O of Atmega328P.	Connected to YX5200-24SS TX pin. Used for communication between Atmega328P and wavdecoder.
D8	D8 digital I/O of Atmega328P.	Connected to YX5200-24SS RX pin. Used for communication between Atmega328P and wavdecoder.
RST	Reset pin of the Atmega328P, with pull-up to 5V.	
D11	D11 digital I/O of Atmega328P, PWM capable, connected to Gate of LS6 Low-Side driver, with $100k\Omega$ pull-down to GND. MOSI pin for ICP.	
D12	D12 digital I/O of Atmega328P. MISO pin for ICP.	
D13	D13 digital I/O of Atmega328P. SCK pin for ICP.	
5V	Output of the 5V LDO (type 7805). Supply pin for Atmega328P, FTDI, YX5200-24SS chipsets.	
GND	Board(-) or GND. Connected to GND plane of the PCB.	
SPK1	Speaker terminal 1. Connect to speaker directly. Other speaker	



	terminal to SPK2.	
GND	Board(-) or GND. Connected to GND plane of the PCB.	
NC	Non-connected pin. Can be used on the PCB for signal routing.	
GND	Board(-) or GND. Connected to GND plane of the PCB.	
A0	A0 digital I/O of Atmega328P with input 10-bit ADC.	
A1	A1 digital I/O of Atmega328P with input 10-bit ADC.	
A2	A2 digital I/O of Atmega328P with input 10-bit ADC.	
A3	A3 digital I/O of Atmega328P with input 10-bit ADC.	
A4	A4 digital I/O of Atmega328P with input 10-bit ADC.	SDA I2C signal for communication with MPU6050. Connected to auxiliary signal MSDA.
A5	A5 digital I/O of Atmega328P with input 10-bit ADC.	SCL I2C signal for communication with MPU6050. Connected to auxiliary signal MSCL.
A6	A6 analog input pin with 10-bit ADC.	Only analog input, cannot be used as digital I/O.
A7	A7 analog input pin with 10-bit ADC.	Only analog input, cannot be used as digital I/O.
GND	Board(-) or GND. Connected to GND plane of the PCB.	
3V3	Output of the 3.3V LDO of the FTDI (FT232RL) chip.	



INT output pin of the MPU6050.	
Board(-) or GND. Connected to GND plane of the PCB.	
Speaker terminal 2. Connect to speaker directly. Other speaker terminal to SPK1.	
Drain of the Low-Side switch 1	
Drain of the Low-Side switch 2	
Drain of the Low-Side switch 3	
Drain of the Low-Side switch 4	
Drain of the Low-Side switch 5	
Drain of the Low-Side switch 6	
D3 digital I/O of Atmega328P, PWM capable, INT capable, connected to Gate of LS1 Low- Side driver, with 100kΩ pull- down to GND	Auxiliary signals, see Chapter 4.4
D5 digital I/O of Atmega328P, PWM capable, connected to Gate of LS2 Low-Side driver, with 100kΩ pull-down to GND	Auxiliary signals, see Chapter 4.4
D6 digital I/O of Atmega328P, PWM capable, connected to Gate of LS3 Low-Side driver, with 100kΩ pull-down to GND	Auxiliary signals, see Chapter 4.4
D9 digital I/O of Atmega328P, PWM capable, connected to Gate of LS4 Low-Side driver, with 100kΩ pull-down to GND	Auxiliary signals, see Chapter 4.4
D10 digital I/O of Atmega328P, PWM capable, connected to	Auxiliary signals, see Chapter 4.4
	Board(-) or GND. Connected to GND plane of the PCB. Speaker terminal 2. Connect to speaker directly. Other speaker terminal to SPK1. Drain of the Low-Side switch 1 Drain of the Low-Side switch 2 Drain of the Low-Side switch 3 Drain of the Low-Side switch 4 Drain of the Low-Side switch 5 Drain of the Low-Side switch 6 D3 digital I/O of Atmega328P, PWM capable, INT capable, connected to Gate of LS1 Low-Side driver, with 100kΩ pull-down to GND D5 digital I/O of Atmega328P, PWM capable, connected to Gate of LS2 Low-Side driver, with 100kΩ pull-down to GND D6 digital I/O of Atmega328P, PWM capable, connected to Gate of LS3 Low-Side driver, with 100kΩ pull-down to GND D9 digital I/O of Atmega328P, PWM capable, connected to Gate of LS3 Low-Side driver, with 100kΩ pull-down to GND D9 digital I/O of Atmega328P, PWM capable, connected to Gate of LS4 Low-Side driver, with 100kΩ pull-down to GND



	Gate of LS5 Low-Side driver, with $100 k\Omega$ pull-down to GND	
SDS	Shut-down pin of the LM4871 3W audio-amplifier.	Auxiliary signals, see Chapter 4.4
MSDA	SDA I2C signal of MPU6050	Auxiliary signals, see Chapter 4.4
MSCL	SCL I2C signal of MPU6050	Auxiliary signals, see Chapter 4.4
DBUSY	Busy signal of the YX5200-24SS wav decoder.	Auxiliary signals, see Chapter 4.4
DRX	RX line of the YX5200-24SS wav decoder, connected to D8.	Auxiliary signals, see Chapter 4.4
DTX	RX line of the YX5200-24SS wav decoder, connected to D7.	Auxiliary signals, see Chapter 4.4
D3V3	Output of the 3.3V LDO of the YX5200-24SS chip.	Auxiliary signals, see Chapter 4.4

2.3 MODULE DESCRIPTION

2.3.1 Low-side drivers

In order to control High-Power LEDs or LED strings consisting or multiple LEDs, the DIYino Prime board implements so called Low-Side drivers to connect the negative side of loads (i.e. cathode of LEDs) to the GND. A Low-Side driver consists of an n-channel type MOS transistor with its source connected to GND of the board, the drain is connected to an LS terminals (LS1 to LS6), and the gate is controlled via PWM by PWM capable pins of the Atmega328 uController.

Therefore code-wise still the PWM capable pins have to be addressed; the mapping is shown in the next table:

LS pin on DIYino Prime	Corresponding PWM capable pin
LS1	D3
LS2	D5
LS3	D6
LS4	D9
LS5	D10
LS6	D11

TABLE 1: MAPPING OF PWM CAPABLE ATMEGA328 PINS TO THE LOW-SIDE DRIVER PINS



Wiring of loads via the LS pins is depicted in Figure 1, using as example a RGB(W) HP-LED setup., but the concept is the same using LED strings or serially connected LEDs in general.




FIGURE 1: CONNECTION OF THE LOAD TO THE LOW-SIDE DRIVER PINS (LS1...LS6). EXAMPLE SHOWS WIRING OF AN RGB(W) HIGH-POWER LED MODULE ON STAR PCB. CURRENT LIMITING RESISTORS ARE NOT SHOWN FOR SIMPLICITY'S SAKE.

Warning: DIYino Prime is an electronic board containing parts sensitive to ESD. Final wiring & assembly is under the responsibility of the user with the appropriate tools and ESD protection. If you're not familiar with ESD, please visit: http://en.wikipedia.org/wiki/Electrostatic_discharge
The manufacturer cannot be held responsible for improper use or assembly of the DIYino Prime board.

3 BOARD SUPPLY CONCEPTS

Warning: Please note that the DIYino Prime board does not implement a reverse polarity protection. Reversing the polarity of the supply might lead to board damage!

3.1 STANDARD SUPPLY SCHEME



The DIYino Prime board shall be supplied from the VIN pin (similar to the Arduino Nano on which the DIYino design is based on). Due to the fact that the DIYino Prime board implements an 5V LDO between VIN and 5V pins, the voltage of the VIN pin has to be between 6V(min) and 20V(max).

Figure 2 shows wiring of the voltage source used to supply the board. This wiring scheme can be used if the voltage source has an output voltage between 6V(min) and 20V(max). The integrated LDO will regulate the input voltage on VIN to 5V and supply the rest of the components on the board. Please note that any VIN pin can be used to connect the voltage source to. The two VIN pins are connected together on the board.

If the USB cable is plugged in, i.e. as during sketch upload, the circuit will auto-select the higher voltage between the one supplied by the USB and the on board 5V LDO.




FIGURE 2: STANDARD SUPPLY WIRING

3.2 ALTERNATE SUPPLY CONCEPTS

The standard supply scheme is explained in Chapter 3 The supply schemes introduced in the current Chapter are considered technically feasible to supply the DIYino Prime board, but due to the nominal



supply requirements of certain circuit components and the uncertainty arising from static/dynamic behavior of the used external components (for instance DC/DC supply, battery etc.), the manufacturer does not take any liability nor does he guarantee performance of the board if the below described supply schemes are used. What does it mean in simpler terms?

- In both cases the on-board LDO is bypassed and external components are directly wired to the supply node of sensitive IC's (5V pin), without the LDO regulating this voltage to 5V.
 Glitches/transients on the external components might cause irreversible damage to the circuit components.
- 2. Some of the components are nominally rated for supply voltages close to 5V. Supplying them with a voltage below 5V might degrade their performance.
- 3. The board is not fully characterized for operation with less than 5V. Early results indicate the board works down to 3.1V, but it strongly depends on factors like contact resistances, IR-drop, parasitic effects etc.

3.2.1 SUB-5V SUPPLY

Due to the

- limited space in the application builds: i.e. prop lightsaber hilts
- the capacity requirements of used batteries: typically >3000mAh, otherwise the saber might shut-off prematurely during a show/presentation
- supply requirements of LEDs: except for serially connected LED-strings, other type of lightsaber light sources require a voltage source between 2V (Vth_typ of red LEDs) and 4V (Vth_max of Blue/Green LEDs).

Li-Ion batteries with a nominal voltage of 3.7V are the most commonly used voltage sources. They can be used to fully supply the DIYino Prime board, the wiring is shown in Figure 3. Instead of connecting the voltage source to VIN, it has to be connected directly to the 5V pin, which is the output of the 5V LDO. All parts directly supplied by the LDO (Atmega328 and FTDI chips) will be supplied now from the external voltage source. VIN can be left unconnected or if necessary it can be connected to the voltage source as well.

Warning: in case this supply scheme is implemented, please ensure to disconnect the power source from the DIYino Prime board before connecting the board via the USB cable to PC. Reason is, that the USB in this case will overforce the voltage of the power source, thus acting as a battery charger, which — depending on the battery type and electrical characteristics, such as charging curve — can lead to battery damage.






FIGURE 3: SUPPLY OF THE DIYINO BOARD WITH A VOLTAGE SOURCE BELOW 5V

3.2.2 SUPPLY USING 5V DC/DC BOOST

As mentioned at the beginning of Chapter 3.2, supplying the DIYino Prime circuitry with less than 5V on the 5V pin/node might lead to performance and/or premature undervoltage reset condition. For this reason, a hybrid supply scheme is introduced here, which used a voltage source with a nominal voltage below 5V but still can supply the board circuitry with 5V. This scheme uses a so called DC/DC boost converter. A boost converter regulates ("boosts") the voltage from a lower input voltage to a higher input voltage. Please use a DC/DC boost converter with a 5V output.

Warning: DC/DC boost modules which are not rated at 5V output voltage usually have an adjustable voltage output, which can far exceed 5V. Using such a DC/DC boost module could cause board damage if the output voltage is not adjusted to 5V (or below) prior to connecting it to the board!



The clear advantage of this supply scheme is that the board is supplied with the required 5V for best performance, while the lower source voltage can be used to power the LEDs/other external circuits with nominal voltages below 5V.




FIGURE 4: SUPPLY SCHEME USING 5V DC/DC BOOST CONVERTER

4 BASIC WIRINGS OF EXTERNAL COMPONENTS

4.1 WIRING BUTTONS AND SPEAKER

Figure 5 shows wiring of the switches and that of the speaker.

The speaker has to be connected between the SPK1 and SPK2 terminals/pins of the board. $4\Omega/8\Omega$ speaker can be used, up to 3W output power. It does not matter which terminal of the speaker you connect to which pin.

Switches – latching or momentary, although mostly momentary switches are supported by Arduino libraries – are connected with one terminal connected to GND and the other terminal to a digital I/O. Please note that although in the Figure 5 the Main and Aux. switches are connected to D12 and D4 respectively, any digital I/O of the DIYino Prime board can be used from D2 to D13 and A0 to A5. Please note that certain pins have pre-defined functionality, please refer to the DIYino Prime schematics (A4



and A5, as well as D7 and D8 are used for communication between Atmega328 and the YX5200/MPU6050; A6 and A7 are analog inputs only. D2 is interrupt capable)




FIGURE 5: WIRING SWITCHES AND THE SPEAKER

4.2 IN-HILT RECHARGE

It is very convenient if the battery does not have to be removed from the hilt every time it needs recharging. Therefore so called in-hilt recharge ports found a wide-spread use in saber hilts together with rechargeable batteries (most common type being the 3.7V type 18650). The wiring of the recharge port is depicted on Figure 6, showing the wiring only for the Standard Supply Scheme introduced in Chapter 3.1. The commonly used 2.1mm DC sockets have 3 terminals, one is wired to the rechargeable voltage source (~battery) negative labelled *Battery(-)*, one to the Board GND labelled *Board(-)*, and the third one labelled *Battery(+)* and *Board(+)* to both the rechargeable voltage source positive lead and to the Board. The exact connection of *Battery(+)* and *Board(+)* to the Board depends on the supply scheme used, described in the Chapter 3.






FIGURE 6: IN-HILT RECHARGE USING A 2.1MM DC SOCKET

- 4.3 AUDIO CONTROLLED FLICKER
- 4.4 AUXILIARY SIGNAL WIRING
- 4.5 SD-CARD AND SOUND FONT PREPARATION
 - 1. Format your SDCard. I insist! (go read HOW TO MANAGE YOUR SDRCARD section for further explanation)
 - Select all the files from this folder and "Drag and Drop" them to your SDCard. NO COPY AND
 PASTE !!!: We need to have this file copied in the same order as their filename order. On
 Microsoft Windows, Copy/paste produce an anarchic copy order, but Drag and Drop produce an
 ordered copy...

4.6 UPLOAD SOFTWARE USING ARDUINO IDE

Please visit the Arduino Home Page for instructions how to install the Arduino IDE and upload code using it to your DIYino Prime board:

https://www.arduino.cc/en/Guide/Windows (instructions are also available for Mac OS X and Linux)



The DIYino Prime boards are configured as an Arduino Nano compatible boards, so when choosing your board please select Arduino Nano:




FIGURE 7: SELECTING THE BOARD TYPE IN THE ARDUING IDE

5 ELECTRICAL CHARACTERISTICS

6 APPLICATION EXAMPLES

Warning: High-power LEDs (such as the Luxeon, Cree atc. Brand LED) and strings/stripes of LEDs (such as LED strings composed of many single LEDs or neopixel LED moduls such as WS2812B) are extremely bright. Especially High-power LEDs are considered "class 2 lasers"! You should neither look directly to the beam nor point someone with it when the light source is not diffused/blocked, just like a powerful lamp or flashlight. Manufacturer of the DIYino Prime board could not be held responsible for any bad use of high-power or other type of LEDs/LED modules. To avoid injuries and retina damage due to the high brightness of LEDs, always use protective googles or other means to avoid looking directly into the light



source and also take care to protect others (like children) from being able to look directly into the light source.

In this Chapter the most common lighting options of saber designs will be discussed with application notes and wiring diagrams showing how these options can be interfaced to the DIYino Prime board.

Caution: in case of a High-Power LED or LED-string setups, you can use the LS pins to adjust the current flowing through the LEDs using PWM control (Pulse Width Modulation) of the transistor gates. The transistors connecting the cathode (-) of the LEDs to the GND can act as voltage controlled variable resistors, thus limiting the current through the LED. For those LEDs having a Vth above the battery voltage, this intrinsic current limiting is sufficient to ensure no overvoltage/overcurrent to the LED, while still offering the full dynamic range of brightness control. But in case the LED has a Vth below (or even far below) the nominal battery voltage (i.e. for red/amber/yellow LEDs), depending on the electrical characteristic of the LED, this intrinsic limiting might not be enough to ensure no overvoltage to the LED, which in turn can lead to damage or degradation of the life time of the LED. Even if the limiting through the transistors is deemed sufficient, during debug the PWM level can be set accidentally to a level which causes overvoltage. Last but not least, if only a small portion of the available PWM range can be used to control the brightness, it can lead to less smooth color transitions. Therefore in doubt please include a limiting series resistor, which can be calculated using the following formula:

$$Rseries = \frac{Vbattery - Vth_LED}{I_LED}$$

Example: suppose you use a Red LED with Vth_LED=2V and you want the current to be I_LED=700mA, you use a Vbattery=3.7V, type 18650 battery. The value of the resistor you need to wire in series to the LED is:

$$\frac{3,7V - 2,0V}{0.7A} = 2.4\Omega$$

Please check the power rating of the resistor you intend to use.

6.1 HIGH-POWER RGB(W) LED SETUP

Figure 1 depicts connection of a High-Power LED module to the DIYino Prime. It depicts a 4-color LED module consisting of 4 LED dies in colors Red, Green, Blue and White. The same wiring can be extended to all different variants of HP-LEDs, like RGB, in which case only 3 of the available 6 Low-side drivers are used, or even for a single die HP-LED which can be controlled with a single Low-side driver.

Please note that that maximum DC current which can be switched by the LS pins is 1.1A. If the HP-LED used in the design involves LED dies with a max current above this rating, you must connect the cathode of the LED die to multiple of these LS pins to avoid violating the maximum rating of the transistors.



Suitable supply schemes:

Sub-5V supply
Supply using 5V DC/DC boost
Standard supply scheme

6.2 LED-STRING SETUP

The original Master Replicas/Hasbro lightsabers used a ladder or string of LEDs clustered in segments to light them up/down successively thus imitating the ignition and retraction of the blade seen in the movies (also called scrolling FX). Although these commercially available LED string sabers have very high quality hilts, they had a number of shortcomings:

- their LED string brightness is toned down
- the PCB used to hold the LEDs is prone to break or LEDs might fall out after moderate impacts
- due to the LED type used not available commercially, replacing broken LEDs became an issue, because replacement LEDs tended to have a different brightness which was visible as a spot in the blade
- the blade material was optimized for diffusion at the set working point of the LEDs and if LEDs were replaced/limiting resistors removed to increase brightness, the blade easily became "pixely"

Thus people started to build their own LED strings, optimizing them for endurance, but mostly for brightness. Pros and cons of LED string blades are:

Pros:

- without doubt the brightest blades out there are built with this technique
- homogenous brightness along the whole length of the blade (as opposed to HP-LEDs whose brightness diminishes towards the tip of the blade)
- most movie accurate ignition/retraction FX with scrolling effect

Cons:

- not recommended for full contact dueling as individual LEDs/strings are prone to break
- no color changing possible only for the dedicated!!!
- special diffusion layers and blade tubes needed
- major effort to build (not really a con though for those who like 'em!)

There are a number of very good tutorials in the web showing how LED strings can be assembled: Wayne Schmidt's Ligthsaber Blade Research Page: http://www.waynesthisandthat.com/lightsaber.html LED String blade for Hampton's Hand-crafted Lightsabers: <a href="https://www.youtube.com/watch?v="https://www.watch?v="https://www.youtube.c

Most LED string blades have 6 segments which can be controlled individually, it's on one hand side owing to the original Master Replicas blades having 6 segments, on the other hand sound boards mostly use microcontrollers having up to 6 PWM-capable channels.

The Figure 8 depicts the most commonly used LED string wiring techniques (only one segment is shown, each segment is wired identically). The Serial I. is a straightforward full parallel wiring of all LEDs, i.e. connect all anodes(+) together and all cathodes(-) together. The Master Replicas/Hasbro sabers use this



technique as they use 3xAA/AAA batteries as voltage supply, resulting in 3x1.5V=4.5V max. To lower the voltage to the Vth of the used LEDs, small SMD resistors in series to the individual LEDs are used. Due to the large number of LEDs used in LED string blades (usually between 60 and 100, but more can be added, depending on the LED length etc.) the current consumption of a Serial I. string can reach several Amps. To lower the overall current but still drive the LEDs at the same working point, LEDs can be connected in series, resulting in half the current in comparison with a parallel connected LEDs, of course the trade-off is, that in order to supply the same power, the voltage has to be increased accordingly. In the Serial II. technique two times N LEDs connected in parallel are connected in series in turn. This technique has been developed for blades supplied with a 7.4V battery setup and green or blue LEDs, as their Vth of typical 3.4V is close to the voltage of the battery (2x3.4V=6.8V, 600mV below the nominal battery voltage). The Serial III. technique is similar to the Serial III. but it connects one additional group of N LEDs connected in parallel serially to the rest. It is ideal if the Vth of the used LEDs is lower i.e. warmer colors like red, amber or yellow LEDs with a typical Vth of ~2V. Connected in series 3x2V=6V is close to 7.2V.

In the Chapter 7.1 a full wiring diagram of a Serial II. wired blade with the DIYino Prime is shown as reference (see Figure 11).




FIGURE 8: LED STRING WIRING TECHNIQUES - SERIAL I., II. AND III.

The number of LEDs in a LED string blade can be chosen according to individual taste, target brightness, LED dimensions etc. Most commonly used blades are ~30" long (~80cm), i.e. if 5mm LEDs are used, a maximum of 160 can be squeezed in theoretically. Practically the LEDs cannot be pressed together so tightly and the wiring/assembling will leave small gaps between the LEDs. Based on personal experience



the recommendation is to use max. ~100 LEDs. Of course the final number must be divisible by 6, closest number is 96, with Serial II. wiring it gives 6 segments x 2 serial x 8 parallel=96. In case Serial III. wiring is used (e.g. red blade) the total number must be also divisible by 3. A good number would be 6 segments x 3 serial x 6 in parallel=108 (as red LEDs tend to be less bright, more LEDs give a better result).

6.3 NEOPIXELS SETUP

"NeoPixel" is Adafruit's brand for individually-addressable RGB color pixels and strips based on the **WS2812**, **WS2811** and **SK6812** LED/drivers, using a single-wire control protocol. Commonly used neopixels stripes are composed of individual LED segments connected together to form a ladder similar to LED-strings. The stripes can be cut at any joint and multiple striped can be connected together at these joints as well.

Neopixel LED modules integrate RGB LEDs and a control circuit which uses PWM (Pulse Width Modulation) to control the brightness of each individually. For that purpose each LED module has a shift register composed of 24-bits, 8-bits belonging to each color Red, Green and Blue. The shift registers are connected between the DI (Data-In) and DO (Data-Out) pins of the individual segments. In a stripe configuration one segment shift register is connected serially to the shift register of the next segment. If a blade has a stripe with 100LEDs, it means during programming 100x24=240bits of data have to be transmitted to the stripe using neopixels own serial protocol to fill up all PWM registers, which in turn determine the brightness of the LEDs. This takes only a few us, so programming can happen so fast, that transitions seem smooth to the eye.

A neopixel stripe has only 3+1 signals:

5V: supply of the stripe

DI: Data-In for the single-line serial protocol

GND: Ground or negative of the stripe

DO: Data-out, this signal has to be used only of you want to connect several stripes together which are not continuous (back-to-back stripes or think about the cross guard of a Kylo Ren style saber) The specification of the neopixel LED segments defines 5V as nominal voltage for the stripes, however the module can work with a much lower voltage as well. A lower voltage is even necessary to minimize power loss during operation, because any excess voltage above the voltage threshold of the used LEDs (Red ~2V, Green and Blue ~3.5V) is "wasted" over protection circuits in the control logic. Therefore a voltage source around the LED Vth is ideal to power neopixel strings.

Neopixel striped can be wired to the DIYino Prime board in two different ways, illustrated in the following two Chapters.

6.3.1 BASIC NEOPIXELS WIRING

The simplest way to connect neopixel stripe to the DIYino is to connect the Battery(+) of a 3.7V supply to the 5V terminal of the first segment of the stripe, the Battery(-) to the GND terminal of the first segment and a digital I/O (in this example D13 is used, as depicted on Figure 9) to the DI (Digital-In) terminal of the first segment.

Connection of the GND signal can be realized over the DIYino Prime GND pins as well. Please note that if you use in-hilt recharge, you connect the recharge port to the GND of the board and the stripe as in Figure 6.

Suitable supply schemes:

Sub-5V supply



Supply using 5V DC/DC boost




FIGURE 9: WIRING OF A NEOPIXELS STRIPE USING 3.7V VOLTAGE SOURCE

6.3.2 Neopixels wiring with programmable kill key

Neopixels chips consume power even when all the LEDs are switched off (all 0's). This static current consumption amounts to 1mA per LED. You can quickly calculate what this means to your battery charge if you use – let's say – 60LED/m type of neopixels, back to back, in a 80cm blade. There will be 100 LEDs in your blade, drawing 100mA even if all LEDs are switched off. It will even discharge the best battery in less than one day. It is not hard to predict, that with the introduction of the 144LED/m type neopixel striped, some blades will include much more than 100 LEDs, which will lead to an even quicker discharging of the battery. Killing power to the circuitry using a kill-key is a good method to lengthen the shelf life of your saber, but quite annoying during a show if you have to keep plugging in/out the kill key. Therefore I invented a unique method using the existing DIYino Prime architecture. If the GND pin of the



neopixels stripe is connected to the LS pins instead of the GND of the battery/DIYino Prime, the transistors of the LS pins can be used to cut power to the neopixels stripe. If the blade is activated, the transistors have to be fully switched on (using the digitalWrite function) to connect the GND of the neopixels to the Battery(-), therefore powering the stripe. If the blade is retracted/switched off, the transistors have to be fully switched off in order to avoid the static current consumption of the stripes discharging the battery.

Connection of the GND signal can be realized over the DIYino Prime GND pins as well. Please note that if you use in-hilt recharge, you connect the recharge port to the GND of the board and the stripe as in Figure 6.

Suitable supply schemes:

Sub-5V supply
Supply using 5V DC/DC boost




FIGURE 10: NEOPIXELS WIRING USING 3.7V VOLTAGE SOURCE, "KILL-KEY" OF LEDS THRU LS PINS

7 FULL WIRING EXAMPLES

7.1 7.4V SUPPLY LED-STRING SETUP WITH SERIAL-II TECHNIQUE



The wiring diagram on Figure 11 shows a LED String blade wiring using Serial II. LED wiring (please see Chapter 6.2). It features:

- 2x3.7V batteries connected in series to give 7.4V
- 6 segments of green/blue LEDs
- A main and aux. switches
- Speaker
- Connections for Audio controlled flicker
- an in-hilt recharge port

The common anode of the Serial II. segments are connected directly to the battery+ (or alternatively to VIN pin of the DIYino Prime board). The individual cathodes of the Serial II. segments are connected to an LSx pin each and controlled using PWM. The Battery+ is connected to the VIN input of the board, which is regulated to 5V by the on-board LDO, thus supplying the on-board electronics.




FIGURE 11: FULL WIRING DIAGRAM FOR SABERS BUILT WITH SERIAL II. LED STRING BLADE

7.2 RGBW HIGH-POWER LED SETUP WITH 3.7V SUPPLY AND 5V DC/DC

The Figure 12 shows the full wiring diagram of a HP-LED saber using a single 3.7V Li-Ion battery as supply, boosting the voltage to 5V with the help of a 5V DC/DC boost converter. The HP-LED module is directly supplied from the Battery+.






FIGURE 12: FULL WIRING DIAGRAM OF A HIGH-POWER LED (RGBW) SABER

7.3 Neopixels setup with programmable kill-key and 3.7V supply

On Figure 13 the full saber wiring diagram can be seen. It includes

- an in-hilt recharge port
- 3.7V Li-Ion battery as voltage source (for instance 18650)
- A neopixels LED-stripe of (theoretically [⊙]) any length
- Programmable neopixels stripe kill-key setup
- A main and aux. switches
- Speaker
- Connections for Audio controlled flicker

When connecting the programmable neopixels stripe kill-key, you have to calculate max. current consumption of your LED stripe and connect the LSx pins accordingly, i.e. if you anticipate 2A-3A's, connect 3 of the LS pins to the GND terminal of the stripe. Up to max. 3A over all LSx pins due to limited heat dissipation on the board!!!

All considerations in the Chapters describing the individual parts of this circuit diagram apply here as well. Please read them carefully. These are:



Chapter 3.2.1 Chapter 4.1

Chapter 4.2

Chapter 4.3





FIGURE 13: FULL WIRING DIAGRAM OF A NEOPIXEL STRIPE BASED SABER

8 CIRCUIT SCHEMATICS







9 RELATED LINKS

LSOS: https://github.com/neskweek/LightSaberOS
USaber: https://github.com/JakeSOft/USaber

Demo videos

