

PSA Cryptography API 1.1 PAKE Extension

Document number: AES 0058

Release Quality: Beta

Issue Number: 0

Confidentiality: Non-confidential

Date of Issue: 10/02/2022

Copyright $\ @$ 2022, Arm Limited. All rights reserved.

BETA RELEASE

This is a proposed update to the IHI 0086 PSA Cryptography API 1.1 specification.

This is a BETA release in order to enable wider review and feedback on the changes proposed to be included in a future version of the specification.

At this quality level, the proposed changes and interfaces are complete, and suitable for initial product development. However, the specification is still subject to change.

Abstract

This document is part of the PSA family of specifications. It defines an extension to the PSA Cryptography API, to introduce support for Password-authenticated key exchange (PAKE) algorithms.

Contents

Abo	out this document	i
	Release information	i
	Arm Non-Confidential Document Licence ("Licence")	iii
	References	V
	Terms and abbreviations	V
	Conventions Typographical conventions Numbers	vi vi vii
	Current status and anticipated changes	vii
	Feedback Feedback on this book	vii vii
1 Intro	oduction	9
1.1 1.1.1 1.1.2		9 9 10
2 Pass	sword-authenticated key exchange (PAKE)	12
2.1 2.1.1	Algorithm encoding PAKE algorithm encoding	12 12
2.2.1 2.2.2 2.2.3 2.2.4 2.2.5 2.2.6 2.2.7	PAKE cipher suites	12 12 16 18 22 23 24 34
A Exa	mple header file	36
В Еха	mple macro implementations	38
Inde	ex of API elements	39

About this document

Release information

The change history table lists the changes that have been made to this document.

Date	Version	Confidentiality	Change
February 2022	Beta 0	Non-confidential	Initial release of the 1.1 PAKE Extension specification

PSA Cryptography API

Copyright © 2022, Arm Limited or its affiliates. All rights reserved. The copyright statement reflects the fact that some draft issues of this document have been released, to a limited circulation.

Arm Non-Confidential Document Licence ("Licence")

This Licence is a legal agreement between you and Arm Limited ("Arm") for the use of Arm's intellectual property (including, without limitation, any copyright) embodied in the document accompanying this Licence ("Document"). Arm licenses its intellectual property in the Document to you on condition that you agree to the terms of this Licence. By using or copying the Document you indicate that you agree to be bound by the terms of this Licence.

"Subsidiary" means any company the majority of whose voting shares is now or hereafter owner or controlled, directly or indirectly, by you. A company shall be a Subsidiary only for the period during which such control exists.

This Document is **NON-CONFIDENTIAL** and any use by you and your Subsidiaries ("Licensee") is subject to the terms of this Licence between you and Arm.

Subject to the terms and conditions of this Licence, Arm hereby grants to Licensee under the intellectual property in the Document owned or controlled by Arm, a non-exclusive, non-transferable, non-sub-licensable, royalty-free, worldwide licence to:

- (i) use and copy the Document for the purpose of designing and having designed products that comply with the Document;
- (ii) manufacture and have manufactured products which have been created under the licence granted in (i) above; and
- (iii) sell, supply and distribute products which have been created under the licence granted in (i) above.

Licensee hereby agrees that the licences granted above shall not extend to any portion or function of a product that is not itself compliant with part of the Document.

Except as expressly licensed above, Licensee acquires no right, title or interest in any Arm technology or any intellectual property embodied therein.

THE DOCUMENT IS PROVIDED "AS IS". ARM PROVIDES NO REPRESENTATIONS AND NO WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE DOCUMENT. Arm may make changes to the Document at any time and without notice. For the avoidance of doubt, Arm makes no representation with respect to, and has undertaken no analysis to identify or understand the scope and content of, third party patents, copyrights, trade secrets, or other rights.

NOTWITHSTANDING ANYTHING TO THE CONTRARY CONTAINED IN THIS LICENCE, TO THE FULLEST EXTENT PERMITTED BY LAW, IN NO EVENT WILL ARM BE LIABLE FOR ANY DAMAGES, IN CONTRACT, TORT OR OTHERWISE, IN CONNECTION WITH THE SUBJECT MATTER OF THIS LICENCE (INCLUDING WITHOUT LIMITATION) (I) LICENSEE'S USE OF THE DOCUMENT; AND (II) THE IMPLEMENTATION OF THE DOCUMENT IN ANY PRODUCT CREATED BY LICENSEE UNDER THIS LICENCE). THE EXISTENCE OF MORE THAN ONE CLAIM OR SUIT WILL NOT ENLARGE OR EXTEND THE LIMIT. LICENSEE RELEASES ARM FROM ALL OBLIGATIONS, LIABILITY, CLAIMS OR DEMANDS IN EXCESS OF THIS LIMITATION.

This Licence shall remain in force until terminated by Licensee or by Arm. Without prejudice to any of its other rights, if Licensee is in breach of any of the terms and conditions of this Licence then Arm may terminate this Licence immediately upon giving written notice to Licensee. Licensee may terminate this Licence at any time. Upon termination of this Licence by Licensee or by Arm, Licensee shall stop using the Document and destroy all copies of the Document in its possession. Upon termination of this Licence, all terms shall survive except for the licence grants.

Any breach of this Licence by a Subsidiary shall entitle Arm to terminate this Licence as if you were the party in breach. Any termination of this Licence shall be effective in respect of all Subsidiaries. Any rights granted to any Subsidiary hereunder shall automatically terminate upon such Subsidiary ceasing to be a Subsidiary.

The Document consists solely of commercial items. Licensee shall be responsible for ensuring that any use, duplication or disclosure of the Document complies fully with any relevant export laws and regulations to assure that the Document or any portion thereof is not exported, directly or indirectly, in violation of such export laws.

This Licence may be translated into other languages for convenience, and Licensee agrees that if there is any conflict between the English version of this Licence and any translation, the terms of the English version of this Licence shall prevail.

The Arm corporate logo and words marked with ® or ™ are registered trademarks or trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. All rights reserved. Other brands and names mentioned in this document may be the

trademarks of their respective owners. No licence, express, implied or otherwise, is granted to Licensee under this Licence, to use the Arm trade marks in connection with the Document or any products based thereon. Visit Arm's website at https://www.arm.com/company/policies/trademarks for more information about Arm's trademarks.

The validity, construction and performance of this Licence shall be governed by English Law.

Copyright © 2022, Arm Limited or its affiliates. All rights reserved.

Arm Limited. Company 02557590 registered in England. 110 Fulbourn Road, Cambridge, England CB1 9NJ.

Arm document reference: LES-PRE-21585 version 4.0

References

This document refers to the following documents.

Ref	Document Number	Title
[PSA-CRYPT]	IHI 0086	PSA Cryptography API. https://developer.arm.com/documentation/ihi0086/latest
[MBED-TLS]		Arm Ltd, Mbed TLS. https://github.com/ARMmbed/mbedtls
[SEC1]		Standards for Efficient Cryptography, SEC 1: Elliptic Curve Cryptography, May 2009. https://www.secg.org/sec1-v2.pdf
[RFC8235]		IETF, Schnorr Non-interactive Zero-Knowledge Proof, September 2017. https://tools.ietf.org/html/rfc8235.html
[RFC8236]		IETF, J-PAKE: Password-Authenticated Key Exchange by Juggling, September 2017. https://tools.ietf.org/html/rfc8236.html

Terms and abbreviations

This document uses the following terms and abbreviations.

Term	Meaning
AEAD	See Authenticated Encryption with Associated Data.
Algorithm	A finite sequence of steps to perform a particular operation. In this specification, an algorithm is a <i>cipher</i> or a related function. Other texts call this a cryptographic mechanism.
API	Application Programming Interface.
Asymmetric	See Public-key cryptography.
Authenticated Encryption with Associated Data (AEAD)	A type of encryption that provides confidentiality and authenticity of data using <i>symmetric</i> keys.
Byte	In this specification, a unit of storage comprising eight bits, also called an octet.
Cipher	An algorithm used for encryption or decryption with a <i>symmetric</i> key.
Cryptoprocessor	The component that performs cryptographic operations. A cryptoprocessor might contain a <i>keystore</i> and countermeasures against a range of physical and timing attacks.
Hash	A cryptographic hash function, or the value returned by such a function.
	Continued on next page

Table 2 - continued from previous page

Term Meaning

HMAC A type of MAC that uses a cryptographic key with a hash function.

IMPLEMENTATION DEFINED Behavior that is not defined by the architecture, but is defined and

documented by individual implementations.

Initialization vector (IV) An additional input that is not part of the message. It is used to prevent an

attacker from making any correlation between cipher text and plain text.

This specification uses the term for such initial inputs in all contexts. For

example, the initial counter in CTR mode is called the IV.

IV See Initialization vector.

KDF See Key Derivation Function.

Key agreement An algorithm for two or more parties to establish a common secret key.

Key Derivation Function (KDF)

Key Derivation Function. An algorithm for deriving keys from secret material.

Key identifier A reference to a cryptographic key. Key identifiers in the PSA Crypto API are

32-bit integers.

Key policy Key metadata that describes and restricts what a key can be used for.

Key size The size of a key as defined by common conventions for each key type. For

keys that are built from several numbers of strings, this is the size of a

particular one of these numbers or strings.
This specification expresses key sizes in bits.

Key type Key metadata that describes the structure and content of a key.

Keystore A hardware or software component that protects, stores, and manages

cryptographic keys.

Lifetime Key metadata that describes when a key is destroyed.

MAC See Message Authentication Code.

Message

Authentication Code

(MAC)

A short piece of information used to authenticate a message. It is created

and verified using a symmetric key.

Message digest A hash of a message. Used to determine if a message has been tampered.

Multi-part operation An API which splits a single cryptographic operation into a sequence of

separate steps.

Non-extractable key A key with a key policy that prevents it from being read by ordinary means.

Nonce Used as an input for certain AEAD algorithms. Nonces must not be reused

with the same key because this can break a cryptographic protocol.

PAKE See Password-authenticated key exchange.

Continued on next page

Table 2 - continued from previous page

Term	Meaning
Password- authenticated key	An interactive method for two or more parties to establish cryptographic keys based on knowledge of a low entropy secret, such as a password.
exchange (PAKE)	This can provide strong security for communication from a weak password, because the password is not directly communicated as part of the key exchange.
Persistent key	A key that is stored in protected non-volatile memory.
PSA	Platform Security Architecture
Public-key cryptography	A type of cryptographic system that uses key pairs. A keypair consists of a (secret) private key and a public key (not secret). A public key cryptographic algorithm can be used for key distribution and for digital signatures.
Salt	Used as an input for certain algorithms, such as key derivations.
Signature	The output of a digital signature scheme that uses an <i>asymmetric</i> keypair. Used to establish who produced a message.
Single-part function	An API that implements the cryptographic operation in a single function call.
SPECIFICATION DEFINED	Behavior that is defined by this specification.
Symmetric	A type of cryptographic algorithm that uses a single key. A symmetric key can be used with a block cipher or a stream cipher.
Volatile key	A key that has a short lifespan and is guaranteed not to exist after a restart of an application instance.

Conventions

Typographical conventions

The typographical conventions are:

italic Introduces special terminology, and denotes citations.

monospace Used for assembler syntax descriptions, pseudocode, and source code examples.

Also used in the main text for instruction mnemonics and for references to other items appearing in assembler syntax descriptions, pseudocode, and source code examples.

SMALL CAPITALS

Used for some common terms such as IMPLEMENTATION DEFINED.

Used for a few terms that have specific technical meanings, and are included in the *Terms*

and abbreviations.

Red text Indicates an open issue.

Blue text Indicates a link. This can be

- A cross-reference to another location within the document
- A URL, for example http://infocenter.arm.com

Numbers

Numbers are normally written in decimal. Binary numbers are preceded by 0b, and hexadecimal numbers by θx .

In both cases, the prefix and the associated value are written in a monospace font, for example <code>0xFFFF0000</code>. To improve readability, long numbers can be written with an underscore separator between every four characters, for example <code>0xFFFF_0000_0000_0000</code>. Ignore any underscores when interpreting the value of a number.

Current status and anticipated changes

This document is at Beta quality status which has a particular meaning to Arm of which the recipient must be aware. A Beta quality specification will be sufficiently stable & committed for initial product development, however all aspects of the architecture described herein remain SUBJECT TO CHANGE. Please ensure that you have the latest revision.

Feedback

Arm welcomes feedback on its documentation.

Feedback on this book

If you have comments on the content of this book, send an e-mail to arm.psa-feedback@arm.com. Give:

- The title (PSA Cryptography API).
- The number and issue (AES 0058 1.1 PAKE Extension Beta (Issue 0)).
- The page numbers to which your comments apply.
- The rule identifiers to which your comments apply, if applicable.
- A concise explanation of your comments.

Arm also welcomes general suggestions for additions and improvements.

1 Introduction

This document introduces an extension to the PSA Cryptography API [PSA-CRYPT] specification, to provide support for *Password-authenticated key exchange* (PAKE) algorithms, and specifically for the J-PAKE algorithm.

When the proposed extension is sufficiently stable to be classed as Final, it will be integrated into a future version of [PSA-CRYPT].

This specification must be read and implemented in conjunction with [PSA-CRYPT]. All of the conventions, design considerations, and implementation considerations that are described in [PSA-CRYPT] apply to this specification.

Note:

This extension has been developed in conjunction with the *Mbed TLS* [MBED-TLS] project, which is developing an implementation of the PSA Cryptography API.

Note

This version of the document includes *Rationale* commentary that provides background information relating to the design decisions that led to the current proposal. This enables the reader to understand the wider context and alternative approaches that have been considered.

The rationale is presented in green boxes, as this note is.

1.1 Objectives for the PAKE Extension

1.1.1 Scheme review

There are a number of PAKE protocols in circulation, but none of them are used widely in practice, and they are very different in scope and mechanics. The API proposed for the PSA Cryptography API focuses on schemes that are most likely to be needed by users. A number of factors are used to identify important PAKE algorithms.

Wide deployment

Considering PAKE schemes with already wide deployment allows users with existing applications to migrate to PSA. Currently there is only one scheme with non-negligible success in the industry: Secure Remote Password (SRP).

Requests

Some PAKE schemes have been requested by the community and need to be supported. Currently, these are SPAKE2+ and J-PAKE (in particular the Elliptic Curve based variant, sometimes known as ECJPAKE)

Standardization

There are PAKE schemes that are being standardized and will be recommended for use in future protocols. To ensure that the API is future proof, we need to consider these. The CFRG recommends CPace and OPAQUE for use in IETF protocols. These are also recommended for use in TLS and IKE in the future.

Applications

Some of these schemes are used in popular protocols. This information confirms the choices already made and can help to extend the list in future:

J-PAKE TLS, THREAD v1

SPAKE2+ CHIP

SRP TLS

OPAQUE TLS, IKE

CPace TLS, IKE

Dragonfly WPA3 (Before including the Dragonblood attack should be considered as well.)

SPAKE Kerberos 5 v1.17

PACE IKEv2
AugPAKE IKEv2

1.1.2 Scope of the PAKE Extension

The following PAKE schemes are considered in the PSA Crypto API design:

Balanced	Augmented
J-PAKE	SRP
SPAKE2	SPAKE2+
CPace	OPAQUE

Scope of this specification

The current API proposal provides the general interface for PAKE algorithms, and the specific interface for J-PAKE.

Out of scope

PAKE protocols that do not fit into any of the above categories are not taken into consideration in the proposed API. Some schemes like that are:

PAKE scheme Specification

AMP IEEE 1363.2, ISO/IEC 11770-4

BSPEKE2 IEEE 1363.2
PAKZ IEEE 1363.2
PPK IEEE 1363.2
SPEKE IEEE 1363.2
WSPEKE IEEE 1363.2

PAK IEEE 1363.2, X.1035, RFC 5683

IEEE 1363.2

EAP-PWD RFC 5931
EAP-EKE RFC 6124
IKE-PSK RFC 6617
PACE for IKEv2 RFC 6631
AugPAKE for IKEv2 RFC 6628

PAR IEEE 1363.2

SESPAKE RFC 8133

ITU-T X.1035

SPAKE1

SPEKE

Dragonfly

B-SPEKE

PKEX

EKE

Augmented-EKE

PAK-X

PAKE

The exception is SPAKE2, because of it is related to SPAKE2+.

2 Password-authenticated key exchange (PAKE)

This is a proposed PAKE interface for PSA Cryptography API [PSA-CRYPT]. It is not part of the official PSA Cryptography API yet.

Note:

The content of this specification is not part of the stable PSA Cryptography API and may change substantially from version to version.

2.1 Algorithm encoding

A new algorithm category is added for PAKE algorithms. The algorithm category table in [PSA-CRYPT] Appendix B is extended with the information in Table 1.

Table 2.1 New algorithm ide

Algorithm category CAT Category details

PAKE 0x0A See PAKE algorithm encoding

2.1.1 PAKE algorithm encoding

The algorithm identifier for PAKE algorithms defined in this specification are encoded as shown in Figure 2.1.




Figure 2.1 PAKE algorithm encoding

The defined values for PAKE-TYPE are shown in Table 5.

0x01

PAKE algorithm PAKE-TYPE Algorithm identifier Algorithm value

PSA_ALG_JPAKE

0x0A000100

2.2 Changes and additions to the Programming API

2.2.1 PAKE algorithms

PSA_ALG_IS_PAKE (macro)

Whether the specified algorithm is a password-authenticated key exchange.

#define PSA_ALG_IS_PAKE(alg) /* specification-defined value */

J-PAKE

Table 2.2 PAKE algorithm

Parameters

alg

An algorithm identifier: a value of type psa_algorithm_t.

Returns

1 if alg is a password-authenticated key exchange (PAKE) algorithm, 0 otherwise. This macro can return either 0 or 1 if alg is not a supported algorithm identifier.

PSA_ALG_JPAKE (macro)

The Password-authenticated key exchange by juggling (J-PAKE) algorithm.

```
#define PSA_ALG_JPAKE ((psa_algorithm_t)0x0a000100)
```

This is J-PAKE as defined by *J-PAKE*: *Password-Authenticated Key Exchange by Juggling* [RFC8236], instantiated with the following parameters:

- The group can be either an elliptic curve or defined over a finite field.
- Schnorr NIZK proof as defined by *Schnorr Non-interactive Zero-Knowledge Proof* [RFC8235], using the same group as the J-PAKE algorithm.
- A cryptographic hash function.

To select these parameters and set up the cipher suite, initialize a psa_pake_cipher_suite_t object, and call the following functions in any order:

More information on selecting a specific Elliptic curve or Diffie-Hellman field is provided with the PSA_PAKE_PRIMITIVE_TYPE_ECC and PSA_PAKE_PRIMITIVE_TYPE_DH constants.

The J-PAKE operation follows the protocol shown in Figure 2.2 on page 14.




Figure 2.2 The J-PAKE protocol.

The variable names x1, g1, and so on, are taken from the finite field implementation of J-PAKE in [RFC8236] §2. Details of the computation for the key shares and zero-knowledge proofs are in [RFC8236] and [RFC8235].

J-PAKE does not assign roles to the participants, so it is not necessary to call psa_pake_set_role().

J-PAKE requires both an application and a peer identity. If the peer identity provided to psa_pake_set_peer() does not match the data received from the peer, then the call to psa_pake_input() for the PSA_PAKE_STEP_ZK_PROOF step will fail with PSA_ERROR_INVALID_SIGNATURE.

The following steps demonstrate the application code for 'User' in Figure 2.2. The input and output steps must be carried out in exactly the same sequence as shown.

1. To prepare a J-Pake operation, initialize and set up a psa_pake_operation_t object by calling the following functions:

```
psa_pake_operation_t jpake = PSA_PAKE_OPERATION_INIT;

psa_pake_setup(&jpake, &cipher_suite);
psa_pake_set_user(&jpake, ...);
psa_pake_set_peer(&jpake, ...);
psa_pake_set_password_key(&jpake, ...);
```

The password is provided as a key. This can be the password text itself, in an agreed character encoding, or some value derived from the password as required by a higher level protocol.

The key material is used as an array of bytes, which is converted to an integer as described in SEC 1: Elliptic Curve Cryptography [SEC1] §2.3.8, before reducing it modulo q. Here, q is the order of the group defined by the cipher-suite primitive. psa_pake_set_password_key() will return an error if the result of the conversion and reduction is 0.

After setup, the key exchange flow for J-PAKE is as follows:

2. To get the first round data that needs to be sent to the peer, call:

```
// Get g1
psa_pake_output(&jpake, PSA_PAKE_STEP_KEY_SHARE, ...);
// Get V1, the ZKP public key for x1
psa_pake_output(&jpake, PSA_PAKE_STEP_ZK_PUBLIC, ...);
// Get r1, the ZKP proof for x1
psa_pake_output(&jpake, PSA_PAKE_STEP_ZK_PROOF, ...);
// Get g2
psa_pake_output(&jpake, PSA_PAKE_STEP_KEY_SHARE, ...);
// Get V2, the ZKP public key for x2
psa_pake_output(&jpake, PSA_PAKE_STEP_ZK_PUBLIC, ...);
// Get r2, the ZKP proof for x2
psa_pake_output(&jpake, PSA_PAKE_STEP_ZK_PROOF, ...);
```

3. To provide the first round data received from the peer to the operation, call:

```
// Set g3
psa_pake_input(&jpake, PSA_PAKE_STEP_KEY_SHARE, ...);
// Set V3, the ZKP public key for x3
psa_pake_input(&jpake, PSA_PAKE_STEP_ZK_PUBLIC, ...);
// Set r3, the ZKP proof for x3
psa_pake_input(&jpake, PSA_PAKE_STEP_ZK_PROOF, ...);
// Set g4
psa_pake_input(&jpake, PSA_PAKE_STEP_KEY_SHARE, ...);
// Set V4, the ZKP public key for x4
psa_pake_input(&jpake, PSA_PAKE_STEP_ZK_PUBLIC, ...);
// Set r4, the ZKP proof for x4
psa_pake_input(&jpake, PSA_PAKE_STEP_ZK_PROOF, ...);
```

4. To get the second round data that needs to be sent to the peer, call:

```
// Get A
psa_pake_output(&jpake, PSA_PAKE_STEP_KEY_SHARE, ...);
// Get V5, the ZKP public key for x2*s
psa_pake_output(&jpake, PSA_PAKE_STEP_ZK_PUBLIC, ...);
// Get r5, the ZKP proof for x2*s
psa_pake_output(&jpake, PSA_PAKE_STEP_ZK_PROOF, ...);
```

5. To provide the second round data received from the peer to the operation call:

```
// Set B
psa_pake_input(&jpake, PSA_PAKE_STEP_KEY_SHARE, ...);
// Set V6, the ZKP public key for x4*s
psa_pake_input(&jpake, PSA_PAKE_STEP_ZK_PUBLIC, ...);
// Set r6, the ZKP proof for x4*s
psa_pake_input(&jpake, PSA_PAKE_STEP_ZK_PROOF, ...);
```

6. To use the shared secret, set up a key derivation operation and transfer the computed value:

```
// Set up the KDF
psa_key_derivation_operation_t kdf = PSA_KEY_DERIVATION_OPERATION_INIT;
psa_key_derivation_setup(&kdf, ...);
psa_key_derivation_input_bytes(&kdf, PSA_KEY_DERIVATION_INPUT_CONTEXT, ...);
psa_key_derivation_input_bytes(&kdf, PSA_KEY_DERIVATION_INPUT_LABEL, ...);
// Get Ka=Kb=K
psa_pake_get_implicit_key(&jpake, &kdf)
```

For more information about the format of the values which are passed for each step, see *PAKE step types* on page 23.

If the verification of a Zero-knowledge proof provided by the peer fails, then the corresponding call to psa_pake_input() for the PSA_PAKE_STEP_ZK_PROOF step will return PSA_ERROR_INVALID_SIGNATURE.

Warning: At the end of this sequence there is a cryptographic guarantee that only a peer that used the same password is able to compute the same key. But there is no guarantee that the peer is the participant it claims to be, or that the peer used the same password during the exchange.

At this point, authentication is implicit — material encrypted or authenticated using the computed key can only be decrypted or verified by someone with the same key. The peer is not authenticated at this point, and no action should be taken by the application which assumes that the peer is authenticated, for example, by accessing restricted files.

To make the authentication explicit, there are various methods to confirm that both parties have the same key. See [RFC8236] §5 for two examples.

Compatible key types

```
PSA_KEY_TYPE_PASSWORD
PSA_KEY_TYPE_PASSWORD_HASH
```

2.2.2 PAKE primitives

A PAKE algorithm specifies a sequence of interactions between the participants. Many PAKE algorithms are designed to allow different cryptographic primitives to be used for the key establishment operation, so long as all the participants are using the same underlying cryptography.

The cryptographic primitive for a PAKE operation is specified using a psa_pake_primitive_t value, which can be constructed using the PSA_PAKE_PRIMITIVE() macro, or can be provided as a numerical constant value.

A PAKE primitive is required when constructing a PAKE cipher-suite object, psa_pake_cipher_suite_t, which fully specifies the PAKE operation to be carried out.

psa_pake_primitive_type_t (type)

Encoding of the type of the PAKE's primitive.

```
typedef uint8_t psa_pake_primitive_type_t;
```

The range of PAKE primitive type values is divided as follows:

0x00		Reserved as an invalid primitive type.
0x01	0x7f	Specification-defined primitive type. Primitive types defined by this standard always have bit 7 clear. Unallocated primitive type values in this range are reserved for future use.
0x80	0xff	Implementation-defined primitive type. Implementations that define additional primitive types must use an encoding with bit 7 set.

For specification-defined primitive types, see the documentation of individual PSA_PAKE_PRIMITIVE_TYPE_XXX constants.

PSA_PAKE_PRIMITIVE_TYPE_ECC (macro)

The PAKE primitive type indicating the use of elliptic curves.

```
#define PSA_PAKE_PRIMITIVE_TYPE_ECC ((psa_pake_primitive_type_t)0x01)
```

The values of the family and bits components of the PAKE primitive identify a specific elliptic curve, using the same mapping that is used for ECC keys. See the definition of psa_ecc_family_t. Here family and bits refer to the values used to construct the PAKE primitive using PSA_PAKE_PRIMITIVE().

Input and output during the operation can involve group elements and scalar values:

- The format for group elements is the same as that for public keys on the specific Elliptic curve. For more information, consult the documentation of psa_export_public_key().
- The format for scalars is the same as that for private keys on the specific Elliptic curve. For more information, consult the documentation of psa_export_key().

PSA_PAKE_PRIMITIVE_TYPE_DH (macro)

The PAKE primitive type indicating the use of Diffie-Hellman groups.

```
#define PSA_PAKE_PRIMITIVE_TYPE_DH ((psa_pake_primitive_type_t)0x02)
```

The values of the family and bits components of the PAKE primitive identify a specific Diffie-Hellman group, using the same mapping that is used for Diffie-Hellman keys. See the definition of psa_dh_family_t. Here family and bits refer to the values used to construct the PAKE primitive using PSA_PAKE_PRIMITIVE().

Input and output during the operation can involve group elements and scalar values:

- The format for group elements is the same as that for public keys in the specific Diffie-Hellman group. For more information, consult the documentation of psa_export_public_key().
- The format for scalars is the same as that for private keys in the specific Diffie-Hellman group. For more information, consult the documentation of psa_export_key().

psa_pake_family_t (type)

Encoding of the family of the primitive associated with the PAKE.

```
typedef uint8_t psa_pake_family_t;
```

For more information see the documentation of individual PSA_PAKE_PRIMITIVE_TYPE_XXX constants.

psa_pake_primitive_t (type)

Encoding of the primitive associated with the PAKE.

```
typedef uint32_t psa_pake_primitive_t;
```

PAKE primitive values are constructed using PSA_PAKE_PRIMITIVE().

Rationale

An integral type is required for psa_pake_primitive_t to enable values of this type to be compile-time-constants. This allows them to be used in case statements, and used to calculate static buffer sizes with PSA_PAKE_OUTPUT_SIZE() and PSA_PAKE_INPUT_SIZE().

PSA_PAKE_PRIMITIVE (macro)

Construct a PAKE primitive from type, family and bit-size.

```
#define PSA_PAKE_PRIMITIVE(pake_type, pake_family, pake_bits) \
    /* specification-defined value */
```

Parameters

pake_type	The type of the primitive: a value of type psa_pake_primitive_type_t.
pake_family	The family of the primitive. The type and interpretation of this parameter depends on pake_type. For more information, consult the documentation of individual psa_pake_primitive_type_t constants.
pake_bits	The bit-size of the primitive: a value of type size_t. The interpretation of this parameter depends on family. For more information, consult the documentation of individual psa_pake_primitive_type_t constants.

Returns: psa_pake_primitive_t

The constructed primitive value. Return 0 if the requested primitive can't be encoded as psa_pake_primitive_t.

2.2.3 PAKE cipher suites

A PAKE algorithm uses a specific cryptographic primitive for key establishment, specified using a PAKE primitive. PAKE algorithms also require a cryptographic hash algorithm, which is agreed between the participants.

The psa_pake_cipher_suite_t object is used to fully specify a PAKE operation, combining the PAKE algorithm, the PAKE primitive, the hash or any other algorithm that parametrises the PAKE in question.

A PAKE cipher suite is required when setting up a PAKE operation in psa_pake_setup().

psa_pake_cipher_suite_t (type)

The type of an object describing a PAKE cipher suite.

```
typedef /* implementation-defined type */ psa_pake_cipher_suite_t;
```

This is the object that represents the cipher suite used for a PAKE algorithm. The PAKE cipher suite specifies the PAKE algorithm, and the options selected for that algorithm. The cipher suite includes the following attributes:

- The PAKE algorithm itself.
- The PAKE primitive, which identifies the prime order group used for the key exchange operation. See *PAKE primitives* on page 16.
- The hash algorithm to use in the operation.

Note:

Implementations are recommended to define the cipher-suite object as a simple data structure, with fields corresponding to the individual cipher suite attributes. In such an implementation, each function psa_pake_cs_set_xxx() sets a field and the corresponding function psa_pake_cs_get_xxx() retrieves the value of the field.

An implementations can report attribute values that are equivalent to the original one, but have a different encoding. For example, an implementation can use a more compact representation for attributes where many bit-patterns are invalid or not supported, and store all values that it does not support as a special marker value. In such an implementation, after setting an invalid value, the corresponding get function returns an invalid value which might not be the one that was originally stored.

This is an implementation-defined type. Applications that make assumptions about the content of this object will result in in implementation-specific behavior, and are non-portable.

Before calling any function on a PAKE cipher suite object, the application must initialize it by any of the following means:

• Set the object to all-bits-zero, for example:

```
psa_pake_cipher_suite_t cipher_suite;
memset(&cipher_suite, 0, sizeof(cipher_suite));
```

• Initialize the object to logical zero values by declaring the object as static or global without an explicit initializer, for example:

```
static psa_pake_cipher_suite_t cipher_suite;
```

• Initialize the object to the initializer PSA_PAKE_CIPHER_SUITE_INIT, for example: psa_pake_cipher_suite_t cipher_suite = PSA_PAKE_CIPHER_SUITE_INIT;

• Assign the result of the function psa_pake_cipher_suite_init() to the object, for example:

```
psa_pake_cipher_suite_t cipher_suite;
cipher_suite = psa_pake_cipher_suite_init();
```

PSA_PAKE_CIPHER_SUITE_INIT (macro)

This macro returns a suitable initializer for a PAKE cipher suite object of type psa_pake_cipher_suite_t.

```
#define PSA_PAKE_CIPHER_SUITE_INIT /* implementation-defined value */
```

psa_pake_cipher_suite_init (function)

Return an initial value for a PAKE cipher suite object.

```
psa_pake_cipher_suite_t psa_pake_cipher_suite_init(void);
```

Returns: psa_pake_cipher_suite_t

psa_pake_cs_get_algorithm (function)

Retrieve the PAKE algorithm from a PAKE cipher suite.

```
psa_algorithm_t psa_pake_cs_get_algorithm(const psa_pake_cipher_suite_t* cipher_suite);
```

Parameters

cipher_suite

The cipher suite object to query.

Returns: psa_algorithm_t

The PAKE algorithm stored in the cipher suite object.

Description

Implementation note

This is a simple accessor function that is not required to validate its inputs. It can be efficiently implemented as a static inline function or a function-like macro.

psa_pake_cs_set_algorithm (function)

Declare the PAKE algorithm for the cipher suite.

Parameters

cipher_suite

The cipher suite object to write to.

alg

The PAKE algorithm to write: a value of type psa_algorithm_t such

that PSA_ALG_IS_PAKE(alg) is true.

Returns: void

Description

This function overwrites any PAKE algorithm previously set in cipher_suite.

Implementation note

This is a simple accessor function that is not required to validate its inputs. It can be efficiently implemented as a static inline function or a function-like macro.

psa_pake_cs_get_primitive (function)

Retrieve the primitive from a PAKE cipher suite.

```
psa_pake_primitive_t psa_pake_cs_get_primitive(const psa_pake_cipher_suite_t* cipher_suite);
```

Parameters

cipher_suite

The cipher suite object to query.

Returns: psa_pake_primitive_t

The primitive stored in the cipher suite object.

Description

Implementation note

This is a simple accessor function that is not required to validate its inputs. It can be efficiently implemented as a static inline function or a function-like macro.

psa_pake_cs_set_primitive (function)

Declare the primitive for a PAKE cipher suite.

Parameters

cipher_suite The cipher suite object to write to.

primitive The PAKE primitive to write: a value of type psa_pake_primitive_t. If

this is 0, the primitive type in cipher_suite becomes unspecified.

Returns: void

Description

This function overwrites any primitive previously set in cipher_suite.

Implementation note

This is a simple accessor function that is not required to validate its inputs. It can be efficiently implemented as a static inline function or a function-like macro.

psa_pake_cs_get_hash (function)

Retrieve the hash algorithm from a PAKE cipher suite.

```
psa_pake_primitive_t psa_pake_cs_get_hash(const psa_pake_cipher_suite_t* cipher_suite);
```

Parameters

cipher_suite

The cipher suite object to query.

Returns: psa_pake_primitive_t

The hash algorithm stored in the cipher suite object. The return value is PSA_ALG_NONE if the PAKE is not parametrized by a hash algorithm, or if the hash algorithm is not set.

Description

Implementation note

This is a simple accessor function that is not required to validate its inputs. It can be efficiently implemented as a static inline function or a function-like macro.

psa_pake_cs_set_hash (function)

Declare the hash algorithm for a PAKE cipher suite.

Parameters

cipher_suite The cipher suite object to write to.

hash_alg The hash algorithm to write: a value of type psa_algorithm_t such

that PSA_ALG_IS_HASH(hash_alg) is true. If this is PSA_ALG_NONE, the hash

algorithm in cipher_suite becomes unspecified.

Returns: void Description

This function overwrites any hash algorithm previously set in cipher_suite.

The documentation of individual PAKE algorithms specifies which hash algorithms are compatible, or if no hash algorithm is required.

Implementation note

This is a simple accessor function that is not required to validate its inputs. It can be efficiently implemented as a static inline function or a function-like macro.

2.2.4 PAKE roles

Some PAKE algorithms need to know which role each participant is taking in the algorithm. For example:

- Augmented PAKE algorithms typically have a client and a server participant.
- Some symmetric PAKE algorithms need to assign an order to the participants.

psa_pake_role_t (type)

Encoding of the application role in a PAKE algorithm.

```
typedef uint8_t psa_pake_role_t;
```

This type is used to encode the application's role in the algorithm being executed. For more information see the documentation of individual PAKE role constants.

PSA_PAKE_ROLE_NONE (macro)

A value to indicate no role in a PAKE algorithm.

```
#define PSA_PAKE_ROLE_NONE ((psa_pake_role_t)0x00)
```

This value can be used in a call to psa_pake_set_role() for symmetric PAKE algorithms which do not assign roles.

PSA_PAKE_ROLE_FIRST (macro)

The first peer in a balanced PAKE.

```
#define PSA_PAKE_ROLE_FIRST ((psa_pake_role_t)0x01)
```

Although balanced PAKE algorithms are symmetric, some of them need the peers to be ordered for the transcript calculations. If the algorithm does not need a specific ordering, then either do not call psa_pake_set_role(), or use PSA_PAKE_ROLE_NONE as the role parameter.

PSA_PAKE_ROLE_SECOND (macro)

The second peer in a balanced PAKE.

```
#define PSA_PAKE_ROLE_SECOND ((psa_pake_role_t)0x02)
```

Although balanced PAKE algorithms are symmetric, some of them need the peers to be ordered for the transcript calculations. If the algorithm does not need a specific ordering, then either do not call psa_pake_set_role(), or use PSA_PAKE_ROLE_NONE as the role parameter.

PSA_PAKE_ROLE_CLIENT (macro)

The client in an augmented PAKE.

```
#define PSA_PAKE_ROLE_CLIENT ((psa_pake_role_t)0x11)
```

Augmented PAKE algorithms need to differentiate between client and server.

PSA_PAKE_ROLE_SERVER (macro)

The server in an augmented PAKE.

```
#define PSA_PAKE_ROLE_SERVER ((psa_pake_role_t)0x12)
```

Augmented PAKE algorithms need to differentiate between client and server.

2.2.5 PAKE step types

psa_pake_step_t (type)

Encoding of input and output steps for a PAKE algorithm.

```
typedef uint8_t psa_pake_step_t;
```

Some PAKE algorithms need to exchange more data than a single key share. This type encodes additional input and output steps for such algorithms.

PSA_PAKE_STEP_KEY_SHARE (macro)

The key share being sent to or received from the peer.

```
#define PSA_PAKE_STEP_KEY_SHARE ((psa_pake_step_t)0x01)
```

The format for both input and output using this step is the same as the format for public keys on the group specified by the PAKE operation's primitive.

The public key formats are defined in the documentation for psa_export_public_key().

For information regarding how the group is determined, consult the documentation PSA_PAKE_PRIMITIVE().

PSA_PAKE_STEP_ZK_PUBLIC (macro)

A Schnorr NIZKP public key.

```
#define PSA_PAKE_STEP_ZK_PUBLIC ((psa_pake_step_t)0x02)
```

This is the ephemeral public key in the Schnorr Non-Interactive Zero-Knowledge Proof, this is the value denoted by V in [RFC8235].

The format for both input and output at this step is the same as that for public keys on the group specified by the PAKE operation's primitive.

For more information on the format, consult the documentation of psa_export_public_key().

For information regarding how the group is determined, consult the documentation PSA_PAKE_PRIMITIVE().

PSA_PAKE_STEP_ZK_PROOF (macro)

A Schnorr NIZKP proof.

```
#define PSA_PAKE_STEP_ZK_PROOF ((psa_pake_step_t)0x03)
```

This is the proof in the Schnorr Non-Interactive Zero-Knowledge Proof, this is the value denoted by *r* in [RFC8235].

Both for input and output, the value at this step is an integer less than the order of the group specified by the PAKE operation's primitive. The format depends on the group as well:

- For Montgomery curves, the encoding is little endian.
- For other Elliptic curves, and for Diffie-Hellman groups, the encoding is big endian. See [SEC1] §2.3.8.

In both cases leading zeroes are allowed as long as the length in bytes does not exceed the byte length of the group order.

For information regarding how the group is determined, consult the documentation PSA_PAKE_PRIMITIVE().

2.2.6 Multi-part PAKE operations

psa_pake_operation_t (type)

The type of the state object for PAKE operations.

```
typedef /* implementation-defined type */ psa_pake_operation_t;
```

Before calling any function on a PAKE operation object, the application must initialize it by any of the following means:

• Set the object to all-bits-zero, for example:

```
psa_pake_operation_t operation;
memset(&operation, 0, sizeof(operation));
```

• Initialize the object to logical zero values by declaring the object as static or global without an explicit initializer, for example:

```
static psa_pake_operation_t operation;
```

• Initialize the object to the initializer PSA_PAKE_OPERATION_INIT, for example: psa_pake_operation_t operation = PSA_PAKE_OPERATION_INIT;

 Assign the result of the function psa_pake_cipher_suite_init() to the object, for example: psa_pake_operation_t operation; operation = psa_pake_operation_init();

This is an implementation-defined type. Applications that make assumptions about the content of this object will result in in implementation-specific behavior, and are non-portable.

PSA_PAKE_OPERATION_INIT (macro)

This macro returns a suitable initializer for a PAKE operation object of type psa_pake_operation_t.

```
#define PSA_PAKE_OPERATION_INIT /* implementation-defined value */
```

psa_pake_operation_init (function)

Return an initial value for a PAKE operation object.

```
psa_pake_operation_t psa_pake_operation_init(void);
```

Returns: psa_pake_operation_t

psa_pake_setup (function)

Set the session information for a password-authenticated key exchange.

Parameters

operation The operation object to set up. It must have been initialized as per

the documentation for psa_pake_operation_t and not yet in use.

cipher_suite The cipher suite to use. A PAKE cipher suite fully characterizes a

PAKE algorithm, including the PAKE algorithm.

Returns: psa_status_t

PSA_SUCCESS Success.

PSA_ERROR_BAD_STATE The following conditions can result in this error:

• The operation state is not valid: it must be inactive.

• The library requires initializing by a call to psa_crypto_init().

PSA_ERROR_INVALID_ARGUMENT The following conditions can result in this error:

• The algorithm in cipher_suite is not a PAKE algorithm.

- The PAKE primitive in cipher_suite is not compatible with the PAKE algorithm.
- The hash algorithm in cipher_suite is invalid, or not compatible with the PAKE algorithm and primitive.

PSA_ERROR_NOT_SUPPORTED

The following conditions can result in this error:

- The algorithm in cipher_suite is not a supported PAKE algorithm.
- The PAKE primitive in cipher_suite is not supported or not compatible with the PAKE algorithm.
- The hash algorithm in cipher_suite is not supported, or not compatible with the PAKE algorithm and primitive.

PSA_ERROR_COMMUNICATION_FAILURE PSA_ERROR_CORRUPTION_DETECTED

Description

The sequence of operations to set up a password-authenticated key exchange operation is as follows:

- 1. Allocate an operation object which will be passed to all the functions listed here.
- 2. Initialize the operation object with one of the methods described in the documentation for psa_pake_operation_t. For example, using PSA_PAKE_OPERATION_INIT.
- 3. Call psa_pake_setup() to specify the cipher suite.
- 4. Call psa_pake_set_xxx() functions on the operation to complete the setup. The exact sequence of psa_pake_set_xxx() functions that needs to be called depends on the algorithm in use.

A typical sequence of calls to perform a password-authenticated key exchange:

- 1. Call psa_pake_output(operation, PSA_PAKE_STEP_KEY_SHARE, ...) to get the key share that needs to be sent to the peer.
- 2. Call psa_pake_input(operation, PSA_PAKE_STEP_KEY_SHARE, ...) to provide the key share that was received from the peer.
- 3. Depending on the algorithm additional calls to psa_pake_output() and psa_pake_input() might be necessary.
- 4. Call psa_pake_get_implicit_key() for accessing the shared secret.

Refer to the documentation of individual PAKE algorithms for details on the required set up and operation for each algorithm. See PAKE algorithms on page 12.

If an error occurs at any step after a call to psa_pake_setup(), the operation will need to be reset by a call to psa_pake_abort(). The application may call psa_pake_abort() at any time after the operation has been initialized.

After a successful call to psa_pake_setup(), the application must eventually terminate the operation. The following events terminate an operation:

- A call to psa_pake_abort().
- A successful call to psa_pake_get_implicit_key().

psa_pake_set_password_key (function)

Set the password for a password-authenticated key exchange using a key.

Parameters

operation Active PAKE operation.

password Identifier of the key holding the password or a value derived from the

password. It must remain valid until the operation terminates. It must be of type PSA_KEY_TYPE_PASSWORD or PSA_KEY_TYPE_PASSWORD_HASH. It

must allow the usage PSA_KEY_USAGE_DERIVE.

Returns: psa_status_t

PSA_SUCCESS Success.

PSA_ERROR_BAD_STATE The following conditions can result in this error:

• The operation state is not valid: it must be active, and psa_pake_set_password_key(), psa_pake_input(), and psa_pake_output() must not have been called yet.

The library requires initializing by a call to psa_crypto_init().

PSA_ERROR_INVALID_HANDLE password is not a valid key identifier.

PSA_ERROR_NOT_PERMITTED The key does not have the PSA_KEY_USAGE_DERIVE flag, or it does not

permit the operation's algorithm.

PSA_ERROR_INVALID_ARGUMENT The following conditions can result in this error:

• The key type for password is not PSA_KEY_TYPE_PASSWORD or

PSA_KEY_TYPE_PASSWORD_HASH.

password is not compatible with the operation's cipher suite.

The key type or key size of password is not supported with the

operation's cipher suite.

PSA_ERROR_COMMUNICATION_FAILURE

PSA_ERROR_CORRUPTION_DETECTED

PSA_ERROR_STORAGE_FAILURE

PSA_ERROR_NOT_SUPPORTED

PSA_ERROR_DATA_CORRUPT

PSA_ERROR_DATA_INVALID

Description

Refer to the documentation of individual PAKE algorithms for constraints on the format and content of valid passwords. See *PAKE algorithms* on page 12.

psa_pake_set_user (function)

Set the user ID for a password-authenticated key exchange.

psa_status_t psa_pake_set_user(psa_pake_operation_t *operation,

const uint8_t *user_id,
size_t user_id_len);

Parameters

operation Active PAKE operation.

user_id The user ID to authenticate with.
user_id_len Size of the user_id buffer in bytes.

Returns: psa_status_t

PSA_SUCCESS Success.

PSA_ERROR_BAD_STATE The following conditions can result in this error:

 The operation state is not valid: it must be active, and psa_pake_set_user(), psa_pake_input(), and psa_pake_output() must not have been called yet.

The library requires initializing by a call to psa_crypto_init().

user_id is not valid for the operation's algorithm and cipher suite.

The value of user_id is not supported by the implementation.

PSA_ERROR_NOT_SUPPORTED
PSA_ERROR_INSUFFICIENT_MEMORY

PSA_ERROR_INVALID_ARGUMENT

PSA_ERROR_COMMUNICATION_FAILURE PSA_ERROR_CORRUPTION_DETECTED

Description

Call this function to set the user ID. For PAKE algorithms that associate a user identifier with both participants in the session, also call psa_pake_set_peer() with the peer ID. For PAKE algorithms that associate a single user identifier with the session, call psa_pake_set_user() only.

Refer to the documentation of individual PAKE algorithms for more information. See *PAKE algorithms* on page 12.

psa_pake_set_peer (function)

Set the peer ID for a password-authenticated key exchange.

Parameters

operation Active PAKE operation.

peer_id The peer's ID to authenticate.

peer_id_len Size of the peer_id buffer in bytes.

Returns: psa_status_t

PSA_SUCCESS Success.

PSA_ERROR_BAD_STATE The following conditions can result in this error:

- The operation state is not valid: it must be active, and psa_pake_set_peer(), psa_pake_input(), and psa_pake_output() must not have been called yet.
- Calling psa_pake_set_peer() is invalid with the operation's algorithm.
- The library requires initializing by a call to psa_crypto_init().

peer_id is not valid for the operation's algorithm and cipher suite.

The value of peer_id is not supported by the implementation.

PSA_ERROR_INVALID_ARGUMENT

PSA_ERROR_NOT_SUPPORTED

PSA_ERROR_NOT_SUPPORTED

PSA_ERROR_INSUFFICIENT_MEMORY

PSA_ERROR_COMMUNICATION_FAILURE

PSA_ERROR_CORRUPTION_DETECTED

Description

Call this function in addition to psa_pake_set_user() for PAKE algorithms that associate a user identifier with both participants in the session. For PAKE algorithms that associate a single user identifier with the session, call psa_pake_set_user() only.

Refer to the documentation of individual PAKE algorithms for more information. See *PAKE algorithms* on page 12.

psa_pake_set_role (function)

Set the application role for a password-authenticated key exchange.

Parameters

operation Active PAKE operation.

role A value of type psa_pake_role_t indicating the application role in the

PAKE algorithm. See *PAKE roles* on page 22.

Returns: psa_status_t

PSA_SUCCESS Success.

PSA_ERROR_BAD_STATE The following conditions can result in this error:

 The operation state is not valid: it must be active, and psa_pake_set_role(), psa_pake_input(), and psa_pake_output() must not have been called yet.

• The library requires initializing by a call to psa_crypto_init().

PSA_ERROR_INVALID_ARGUMENT role is not a valid PAKE role in the operation's algorithm.

role is not a valid PAKE role, or is not supported for the operation's algorithm.

PSA_ERROR_COMMUNICATION_FAILURE PSA_ERROR_CORRUPTION_DETECTED

AES 0058

PSA_ERROR_NOT_SUPPORTED

Description

Not all PAKE algorithms need to differentiate the communicating participants. For PAKE algorithms that do not require a role to be specified, the application can do either of the following:

- Not call psa_pake_set_role() on the PAKE operation.
- Call psa_pake_set_role() with the PSA_PAKE_ROLE_NONE role.

Refer to the documentation of individual PAKE algorithms for more information. See *PAKE algorithms* on page 12.

psa_pake_output (function)

Get output for a step of a password-authenticated key exchange.

Parameters

operation Active PAKE operation.

step The step of the algorithm for which the output is requested.

output

Buffer where the output is to be written. The format of the output

depends on the step, see PAKE step types on page 23.

output_size Size of the output buffer in bytes. This must be appropriate for the

cipher suite and output step:

 A sufficient output size is PSA_PAKE_OUTPUT_SIZE(alg, primitive, step) where alg and primitive are the PAKE algorithm and primitive in the operation's cipher suite, and step is the output step.

• PSA_PAKE_OUTPUT_MAX_SIZE evaluates to the maximum output size of any supported PAKE algorithm, primitive and step.

On success, the number of bytes of the returned output.

output_length

Returns: psa_status_t

PSA_SUCCESS Success. The first (*output_length) bytes of output contain the

output.

PSA_ERROR_BAD_STATE The following conditions can result in this error:

 The operation state is not valid: it must be active and fully set up, and this call must conform to the algorithm's requirements for ordering of input and output steps.

• The library requires initializing by a call to psa_crypto_init().

DOWN EDDOD BLIEFED TOO SMALL The size of the output huff

The size of the output buffer is too small. PSA_PAKE_OUTPUT_SIZE() or PSA_PAKE_OUTPUT_MAX_SIZE can be used to determine a sufficient buffer size.

PSA_ERROR_BUFFER_TOO_SMALL

```
PSA_ERROR_INVALID_ARGUMENT step is not compatible with the operation's algorithm.

PSA_ERROR_NOT_SUPPORTED step is not supported with the operation's algorithm.

PSA_ERROR_INSUFFICIENT_ENTROPY

PSA_ERROR_INSUFFICIENT_MEMORY

PSA_ERROR_COMMUNICATION_FAILURE

PSA_ERROR_CORRUPTION_DETECTED

PSA_ERROR_STORAGE_FAILURE

PSA_ERROR_DATA_CORRUPT

PSA_ERROR_DATA_INVALID
```

Description

Depending on the algorithm being executed, you might need to call this function several times or you might not need to call this at all.

The exact sequence of calls to perform a password-authenticated key exchange depends on the algorithm in use. Refer to the documentation of individual PAKE algorithms for more information. See PAKE algorithms on page 12.

If this function returns an error status, the operation enters an error state and must be aborted by calling psa_pake_abort().

psa_pake_input (function)

Provide input for a step of a password-authenticated key exchange.

Parameters

operation Active PAKE operation.

step The step for which the input is provided.

input Buffer containing the input. The format of the input depends on the

step, see PAKE step types on page 23.

input_length Size of the input buffer in bytes.

Returns: psa_status_t

PSA_SUCCESS Success.

PSA_ERROR_BAD_STATE The following conditions can result in this error:

- The operation state is not valid: it must be active and fully set up, and this call must conform to the algorithm's requirements for ordering of input and output steps.
- The library requires initializing by a call to psa_crypto_init().

PSA_ERROR_INVALID_SIGNATURE

The verification fails for a PSA_PAKE_STEP_ZK_PROOF input step.

PSA ERROR INVALID ARGUMENT

The following conditions can result in this error:

- step is not compatible with the operation's algorithm.
- The input is not valid for the operation's algorithm, cipher suite or step.

PSA_ERROR_NOT_SUPPORTED

The following conditions can result in this error:

- step is not supported with the operation's algorithm.
- The input is not supported for the operation's algorithm, cipher suite or step.

PSA_ERROR_INSUFFICIENT_MEMORY
PSA_ERROR_COMMUNICATION_FAILURE
PSA_ERROR_CORRUPTION_DETECTED
PSA_ERROR_STORAGE_FAILURE
PSA_ERROR_DATA_CORRUPT
PSA_ERROR_DATA_INVALID

Description

Depending on the algorithm being executed, you might need to call this function several times or you might not need to call this at all.

The exact sequence of calls to perform a password-authenticated key exchange depends on the algorithm in use. Refer to the documentation of individual PAKE algorithms for more information. See *PAKE* algorithms on page 12.

PSA_PAKE_INPUT_SIZE() or PSA_PAKE_INPUT_MAX_SIZE can be used to allocate buffers of sufficient size to transfer inputs that are received from the peer into the operation.

If this function returns an error status, the operation enters an error state and must be aborted by calling psa_pake_abort().

psa_pake_get_implicit_key (function)

Pass the implicitly confirmed shared secret from a PAKE into a key derivation operation.

Parameters

operation Active PAKE operation.

output A key derivation operation that is ready for an input step of type

PSA_KEY_DERIVATION_INPUT_SECRET.

Returns: psa_status_t

PSA_SUCCESS Success. Use the output key derivation operation to continue with

derivation of keys or data.

PSA_ERROR_BAD_STATE The following conditions can result in this error:

• The state of PAKE operation operation is not valid: it must be active, with all setup, input, and output steps complete.

• The state of key derivation operation output is not valid for the PSA_KEY_DERIVATION_INPUT_SECRET step.

• The library requires initializing by a call to psa_crypto_init().

PSA_ERROR_INVALID_ARGUMENT

PSA_KEY_DERIVATION_INPUT_SECRET is not compatible with the algorithm in the output key derivation operation.

PSA_ERROR_NOT_SUPPORTED

Input from a PAKE is not supported by the algorithm in the output key derivation operation.

PSA_ERROR_INSUFFICIENT_MEMORY

PSA_ERROR_COMMUNICATION_FAILURE

PSA_ERROR_CORRUPTION_DETECTED

PSA_ERROR_STORAGE_FAILURE

PSA_ERROR_DATA_CORRUPT

PSA_ERROR_DATA_INVALID

Description

At this step in the PAKE operation there is a cryptographic guarantee that only an authenticated participant who used the same password is able to compute the key. But there is no guarantee that the peer is the participant it claims to be, and was able to compute the same key.

In this situation, the authentication is only implicit. Since the peer is not authenticated, no action should be taken that assumes that the peer is who it claims to be For example, do not access restricted files on the peer's behalf until an explicit authentication has succeeded.

This function can be called after the key exchange phase of the operation has completed. It injects the shared secret output of the PAKE into the provided key derivation operation. The input step PSA_KEY_DERIVATION_INPUT_SECRET is used to input the shared key material into the key derivation operation.

The exact sequence of calls to perform a password-authenticated key exchange depends on the algorithm in use. Refer to the documentation of individual PAKE algorithms for more information. See *PAKE algorithms* on page 12.

When this function returns successfully, operation becomes inactive. If this function returns an error status, both the operation and the key_derivation operations enter an error state and must be aborted by calling psa_pake_abort() and psa_key_derivation_abort() respectively.

psa_pake_abort (function)

Abort a PAKE operation.

psa_status_t psa_pake_abort(psa_pake_operation_t * operation);

Parameters

operation Initialized PAKE operation.

Returns: psa_status_t

PSA_SUCCESS Success. The operation object can now be discarded or reused.

PSA_ERROR_BAD_STATE The library requires initializing by a call to psa_crypto_init().

PSA_ERROR_COMMUNICATION_FAILURE

Description

Aborting an operation frees all associated resources except for the operation object itself. Once aborted, the operation object can be reused for another operation by calling psa_pake_setup() again.

This function can be called any time after the operation object has been initialized as described in psa_pake_operation_t.

In particular, calling psa_pake_abort() after the operation has been terminated by a call to psa_pake_abort() or psa_pake_get_implicit_key() is safe and has no effect.

2.2.7 Support macros

PSA_PAKE_OUTPUT_SIZE (macro)

Sufficient output buffer size for psa_pake_output(), in bytes.

```
#define PSA_PAKE_OUTPUT_SIZE(alg, primitive, output_step) \
   /* implementation-defined value */
```

Parameters

alg A PAKE algorithm: a value of type psa_algorithm_t such that

PSA_ALG_IS_PAKE(alg) is true.

primitive A primitive of type psa_pake_primitive_t that is compatible with

algorithm alg.

output_step A value of type psa_pake_step_t that is valid for the algorithm alg.

Returns

A sufficient output buffer size for the specified PAKE algorithm, primitive, and output step. An implementation can return either 0 or a correct size for a PAKE algorithm, primitive, and output step that it recognizes, but does not support. If the parameters are not valid, the return value is unspecified.

Description

If the size of the output buffer is at least this large, it is guaranteed that psa_pake_output() will not fail due to an insufficient buffer size. The actual size of the output might be smaller in any given call.

See also PSA_PAKE_OUTPUT_MAX_SIZE

PSA_PAKE_OUTPUT_MAX_SIZE (macro)

Sufficient output buffer size for psa_pake_output() for any of the supported PAKE algorithms, primitives and output steps.

```
#define PSA_PAKE_OUTPUT_MAX_SIZE /* implementation-defined value */
```

If the size of the output buffer is at least this large, it is guaranteed that psa_pake_output() will not fail due to an insufficient buffer size.

See also PSA_PAKE_OUTPUT_SIZE().

PSA_PAKE_INPUT_SIZE (macro)

Sufficient buffer size for inputs to psa_pake_input().

```
#define PSA_PAKE_INPUT_SIZE(alg, primitive, input_step) \
   /* implementation-defined value */
```

Parameters

alg A PAKE algorithm: a value of type psa_algorithm_t such that

PSA_ALG_IS_PAKE(alg) is true.

primitive A primitive of type psa_pake_primitive_t that is compatible with

algorithm alg.

input_step A value of type psa_pake_step_t that is valid for the algorithm alg.

Returns

A sufficient buffer size for the specified PAKE algorithm, primitive, and input step. An implementation can return either 0 or a correct size for a PAKE algorithm, primitive, and output step that it recognizes, but does not support. If the parameters are not valid, the return value is unspecified.

Description

The value returned by this macro is guaranteed to be large enough for any valid input to psa_pake_input() in an operation with the specified parameters.

This macro can be useful when transferring inputs from the peer into the PAKE operation.

See also PSA_PAKE_INPUT_MAX_SIZE

PSA_PAKE_INPUT_MAX_SIZE (macro)

Sufficient buffer size for inputs to psa_pake_input() for any of the supported PAKE algorithms, primitives and input steps.

```
#define PSA_PAKE_INPUT_MAX_SIZE /* implementation-defined value */
```

This macro can be useful when transferring inputs from the peer into the PAKE operation.

See also PSA_PAKE_INPUT_SIZE().

Appendix A: Example header file

The API elements in this specification, once finalized, will be defined in psa/crypto.h.

This is an example of the header file definition of the PAKE API elements. This can be used as a starting point or reference for an implementation.

Note:

Not all of the API elements are fully defined. An implementation must provide the full definition.

The header will not compile without these missing definitions, and might require reordering to satisfy C compilation rules.

psa/crypto.h

```
typedef /* implementation-defined type */ psa_pake_cipher_suite_t;
typedef uint8_t psa_pake_family_t;
typedef /* implementation-defined type */ psa_pake_operation_t;
typedef uint32_t psa_pake_primitive_t;
typedef uint8_t psa_pake_primitive_type_t;
typedef uint8_t psa_pake_role_t;
typedef uint8_t psa_pake_step_t;
#define PSA_ALG_IS_PAKE(alg) /* specification-defined value */
#define PSA_ALG_JPAKE ((psa_algorithm_t)0x0a000100)
#define PSA_PAKE_CIPHER_SUITE_INIT /* implementation-defined value */
#define PSA_PAKE_INPUT_MAX_SIZE /* implementation-defined value */
#define PSA_PAKE_INPUT_SIZE(alg, primitive, input_step) \
    /* implementation-defined value */
#define PSA_PAKE_OPERATION_INIT /* implementation-defined value */
#define PSA_PAKE_OUTPUT_MAX_SIZE /* implementation-defined value */
#define PSA_PAKE_OUTPUT_SIZE(alg, primitive, output_step) \
    /* implementation-defined value */
#define PSA_PAKE_PRIMITIVE(pake_type, pake_family, pake_bits) \
    /* specification-defined value */
#define PSA_PAKE_PRIMITIVE_TYPE_DH ((psa_pake_primitive_type_t)0x02)
#define PSA_PAKE_PRIMITIVE_TYPE_ECC ((psa_pake_primitive_type_t)0x01)
#define PSA_PAKE_ROLE_CLIENT ((psa_pake_role_t)0x11)
#define PSA_PAKE_ROLE_FIRST ((psa_pake_role_t)0x01)
#define PSA_PAKE_ROLE_NONE ((psa_pake_role_t)0x00)
#define PSA_PAKE_ROLE_SECOND ((psa_pake_role_t)0x02)
#define PSA_PAKE_ROLE_SERVER ((psa_pake_role_t)0x12)
#define PSA_PAKE_STEP_KEY_SHARE ((psa_pake_step_t)0x01)
#define PSA_PAKE_STEP_ZK_PROOF ((psa_pake_step_t)0x03)
#define PSA_PAKE_STEP_ZK_PUBLIC ((psa_pake_step_t)0x02)
psa_status_t psa_pake_abort(psa_pake_operation_t * operation);
psa_pake_cipher_suite_t psa_pake_cipher_suite_init(void);
psa_algorithm_t psa_pake_cs_get_algorithm(const psa_pake_cipher_suite_t* cipher_suite);
psa_pake_primitive_t psa_pake_cs_get_hash(const psa_pake_cipher_suite_t* cipher_suite);
psa_pake_primitive_t psa_pake_cs_get_primitive(const psa_pake_cipher_suite_t* cipher_suite);
```

```
void psa_pake_cs_set_algorithm(psa_pake_cipher_suite_t* cipher_suite,
                               psa_algorithm_t alg);
void psa_pake_cs_set_hash(psa_pake_cipher_suite_t* cipher_suite,
                          psa_algorithm_t hash_alg);
void psa_pake_cs_set_primitive(psa_pake_cipher_suite_t* cipher_suite,
                               psa_pake_primitive_t primitive);
psa_status_t psa_pake_get_implicit_key(psa_pake_operation_t *operation,
                                       psa_key_derivation_operation_t *output);
psa_status_t psa_pake_input(psa_pake_operation_t *operation,
                            psa_pake_step_t step,
                            const uint8_t *input,
                            size_t input_length);
psa_pake_operation_t psa_pake_operation_init(void);
psa_status_t psa_pake_output(psa_pake_operation_t *operation,
                             psa_pake_step_t step,
                             uint8_t *output,
                             size_t output_size,
                             size_t *output_length);
psa_status_t psa_pake_set_password_key(psa_pake_operation_t *operation,
                                       psa_key_id_t password);
psa_status_t psa_pake_set_peer(psa_pake_operation_t *operation,
                               const uint8_t *peer_id,
                               size_t peer_id_len);
psa_status_t psa_pake_set_role(psa_pake_operation_t *operation,
                               psa_pake_role_t role);
psa_status_t psa_pake_set_user(psa_pake_operation_t *operation,
                               const uint8_t *user_id,
                               size_t user_id_len);
psa_status_t psa_pake_setup(psa_pake_operation_t *operation,
                            const psa_pake_cipher_suite_t *cipher_suite);
```

Appendix B: Example macro implementations

This section provides example implementations of the function-like macros that have specification-defined values.

Note:

In a future version of this specification, these example implementations will be replaced with a pseudo-code representation of the macro's computation in the macro description.

The examples here provide correct results for the valid inputs defined by each API, for an implementation that supports all of the defined algorithms and key types. An implementation can provide alternative definitions of these macros:

Index of API elements

```
PSA A
PSA_ALG_IS_PAKE, 12
PSA_ALG_JPAKE, 13
PSA PAKE A
psa_pake_abort, 33
PSA PAKE C
PSA_PAKE_CIPHER_SUITE_INIT, 19
psa_pake_cipher_suite_init, 20
psa_pake_cipher_suite_t, 19
psa_pake_cs_get_algorithm, 20
psa_pake_cs_get_hash, 21
psa_pake_cs_get_primitive, 21
psa_pake_cs_set_algorithm, 20
psa_pake_cs_set_hash, 22
psa_pake_cs_set_primitive, 21
PSA PAKE F
psa_pake_family_t, 18
PSA PAKE G
psa_pake_get_implicit_key, 32
PSA PAKE I
PSA_PAKE_INPUT_MAX_SIZE, 35
PSA_PAKE_INPUT_SIZE, 35
psa_pake_input, 31
PSA PAKE O
PSA_PAKE_OPERATION_INIT, 25
PSA_PAKE_OUTPUT_MAX_SIZE, 34
PSA_PAKE_OUTPUT_SIZE, 34
psa_pake_operation_init, 25
psa_pake_operation_t, 24
psa_pake_output, 30
PSA PAKE P
PSA_PAKE_PRIMITIVE, 18
PSA_PAKE_PRIMITIVE_TYPE_DH, 17
```

```
psa_pake_primitive_t, 18
psa_pake_primitive_type_t, 17
PSA PAKE R
PSA_PAKE_ROLE_CLIENT, 23
PSA_PAKE_ROLE_FIRST, 23
PSA_PAKE_ROLE_NONE, 23
PSA_PAKE_ROLE_SECOND, 23
PSA_PAKE_ROLE_SERVER, 23
psa_pake_role_t, 22
PSA PAKE S
PSA_PAKE_STEP_KEY_SHARE, 24
PSA_PAKE_STEP_ZK_PROOF, 24
PSA_PAKE_STEP_ZK_PUBLIC, 24
psa_pake_set_password_key, 27
psa_pake_set_peer, 28
psa_pake_set_role, 29
psa_pake_set_user, 27
psa_pake_setup, 25
psa_pake_step_t, 23
```

PSA_PAKE_PRIMITIVE_TYPE_ECC, 17