The GPS Toolkit

A User's Guide for Scientists, Engineers and Students

Tracie Conn, Tom Gaussiran, R. Benjamin Harris, Jon Little
Richard Mach, David Munton, Brent Renfro, Brian Tolman
Timothy Craddock

Applied Research Laboratories, The University of Texas at Austin

Martin Vermeer

Department of Surveying, Helsinki University of Technology

August 8, 2011
GPSTk Revision 1038

Contents

The goal of the GPSTk project is to provide a world class, open source computing suite to the satellite navigation community. It is our hope that the GPSTk will empower its users to perform new research and to create new applications.

GPS users employ practically every computational architecture and operating system. Therefore the design of the GPSTk suite is as platform-independent as possible. Platform independence is achieved through use of the ANSI-standard C++ programming language. The principles of object-oriented programming are used throughout the GPSTk code base in order to ensure that the code is modular, extensible, and maintainable.

The GPSTk suite consists of a core library and a set of applications. The library provides a wide array of functions that solve processing problems associated with GPS such as processing or using RINEX. The library is the basis for the more advanced applications distributed as part of the GPSTk suite.

The GPSTk is sponsored by Space and Geophysics Laboratory, within the Applied Research Laboratories at the University of Texas at Austin (ARL:UT). GPSTk is the by-product of GPS research conducted at ARL:UT since before the first satellite launched in 1978; it is the combined effort of many software engineers and scientists. In 2003 the research staff at ARL:UT decided to open source much of their basic GPS processing software as the GPSTk.

Part I

Theory

Chapter 1

The Global Positioning System in a Nutshell

The Global Positioning System is actually a U.S. government satellite navigation system that provides a civilian signal. As of this writing, the signal is broadcast simultaneously by a constellation of 29 satellites each with a 12 hour orbit. From any given position on the Earth, 8 to 12 satellites are usually visible at a time.

1.1 GPS in a Nutshell

Each satellite broadcasts spread spectrum signals at 1575.42 and 1227.6 MHz, also known as L1 and L2, respectively. Currently the civil signal is broadcast only on L1. The signal contains two components: a time code and a navigation message. By differencing the received time code with an internal time code, the receiver can determine the distance, or range, that the signal has traveled. This range observation is offset by errors in the (imperfect) receiver clock; therefore it is called a pseudorange. The navigation message contains the satellite ephemeris, which is a numerical model of the satellite's orbit.

GPS receivers record, besides the pseudorange, a measurement called the carrier phase (or just phase); it is also a range observation like the pseudorange, except (1) it has an unknown constant added to it (the phase ambiguity) and (2) it is much smoother (about 100 times less measurement noise than the pseudorange!), which makes it useful for precise positioning. Because of the way it is measured, the phase is subject to random, sudden jumps; these discrete changes always come in multiples of the wavelength of the GPS signal, and are called cycle slips.

1.1.1 The Position Solution

The standard solution for the user location requires a pseudorange measurement and an ephemeris for each satellite in view. At least four measurements are

required as there are four unknowns: 3 coordinates of position plus the receiver clock offset. The basic algorithm for the solution is described in the official GPS Interface Control Document, or ICD-GPS-200. The position solution is corrupted due to two sources of error: errors in the observations and errors in the ephemeris.

Reducing Measurement Errors

The GPS signal travels through every layer of the Earth's atmosphere. Each layers affects the signal differently. The ionosphere, which is the high-altitude, electrically charged part of the atmosphere, introduces a delay, and therefore a range error, into the signal. The ionosphere delay can be predicted using a model. However, the accuracy of ionosphere models is limited. A better alternative is to measure and remove the ionosphere delay. Measurement of the ionosphere delay is possible by taking advantage of the fact that the delay is frequency dependent. It can be directly computed if you have data on both the GPS frequencies. There is also a delay due to the troposphere, the lower part of the atmosphere. Like the ionosphere delay, the atmosphere delay can be either predicted or derived from measurements. There are many other errors associated with the GPS signal: multipath reflections and relativistic effects are two examples.

More precise applications reduce the effect of error sources by a technique referred to as differential GPS (DGPS). By differencing measurements simultaneously collected by the user and a nearby reference receiver, the errors that are common to both receivers (most of them) are removed. The result of DGPS positioning is a position relative to the reference receiver; adding the reference position to the DGPS solution results in the absolute user position.

The alternative to DGPS is to explicitly model and remove errors. Creating new and robust models of phenomena that effects the GPS signal is an area of active research at ARL:UT and other laboratories. The positioning algorithm can be used to explore such models. Essentially, the basic approach is to turn the positioning algorithm inside out to look at the corrections themselves. For example, observations from a network of receivers can create a global map or model of the ionosphere.

Improved Ephemeredes

The GPS position solution can be directly improved by using an improved satellite ephemeris. The U.S National Geospatial-Intelligence Agency (NGA) generates and makes publicly available a number of precise ephemeredes, which are more accurate satellite orbits [**?**], [**?**]. Satellite orbits described by the broadcast navigation message have an error on the order of meters; the precise ephemeris has decimeter accuracy. The International GPS Service (IGS) is a global, civil cooperative effort that also provides free precise ephemeris products [**?**]. Global networks of tracking stations produce the observations that make generation of the precise ephemeredes possible.

1.2 GPS Data Sources

GPS observation data from many tracking stations are freely available on the Internet. Many such stations contribute their data to the IGS. In addition, many networks of stations also post their data to the Internet; for example the Australian Regional GPS Network (ARGN) [**?**] and global cooperatives such as NASA's Crust Dynamics Data Information System (CDDIS) [**?**].

1.2.1 GPS File Formats

Typically GPS observations are recorded in a standardized format developed by and for researchers. Fundamental to this format is the idea that the data should be independent of the type of receiver that collected it. For this reason the format is called Receiver INdependent Exchange, or RINEX. Another format associated with GPS is SP-3, which records the precise ephemeris. The GPSTk supports both RINEX and SP-3 formats.

1.2.2 Receiver Protocols

GPS receivers have become less expensive and more capable over the years, in particular handheld and mobile GPS receivers. The receivers have many features in common. All of the receivers output a position solution every few seconds. All receivers store a list of positions, called waypoints. Many can display maps that can be uploaded. Many can communicate with a PC or handheld to store information or provide position estimates to plotting software.

Typically communication with a PC and other system follows a standard provided by the National Marine Electronics Association called NMEA-0183. NMEA-0183 defines an ASCII based format for communication of position solutions, waypoints and a variety of receiver diagnostics. Here is an example of a line of NMEA data, or sentence:

```
$GPGLL,5133.81,N,00042.25,W*75
```

The data here is a latitude, longitude fix at 51 deg 33.81 min North, 0 deg 42.25 min West; the last part is a checksum.

As a public standard, the NMEA-0183 format has given the user of GPS freedom of choice. NMEA-0183 is the format most typically used by open source applications that utilize receiver-generated positions.

Closed standards are also common. SiRF is a proprietary protocol that is licensed to receiver manufacturers. Many receiver manufacturers implement their own binary protocols. While some of these protocols have been opened to the public, some have been reverse engineered.

Chapter 2

GPS File Formats

A variety of file formats are supported within the GPSTk. The file formats generally store GPS observation data or data related to processing of GPS observables. In this section, a summary of the file formats supported within the GPSTk is presented along with a brief rationale of why each format is supporting within the GPSTk and where to find additional information on the format.

2.1 RINEX

The Receiver INdependent EXchange (RINEX) format was developed by the National Geodetic Survey (NGS) in the U.S. and the University of Berne in Switzerland. RINEX is actually three format definitions that allow storage of GPS observations, GPS navigation message information, and meteorological data associated with GPS observations. GPSTk contains classes to both read and write RINEX V2.1 data files of all types (observation, navigation message, and meteorological). RINEX has undergone a number of revisions since its inception. Each revision is defined using a standard [**?**], [**?**], [**?**], [**?**].

2.2 FIC

The Floating, Integer, Charater (FIC) format was developed in the mid-80s as a relatively machine-independent way to store GPS observation and navigation message data while retaining receiver specific characteristics. Over time, the RINEX format (see above) proved more popular with users and use of the observation records within the FIC format faded away. However, the FIC records associated with GPS navigation message data are still supported within the GPSTk because these records retain some data quantities that are not contained within the RINEX navigation message file. For example, RINEX makes few provisions for storing the almanac data contained in Subframe 4 and Subframe 5. Like RINEX, a standards document defines FIC [**?**].

2.3 SP-3

The SP-3 format stores ephemeris information for satellites. Usually SP-3 is used for storage of GPS precise ephemerides. GPSTk supports both SP-3a and SP3-c formats. SP-3 was originally designed by NGS. Standards documents describe the specific details of the SP-3 formats [**?**], [**?**].

Part II

Usage, Examples & Notes

	Tool	Description	Execution Example
Transforms	calgps	generates a GPS calendar	`calgps -Y 2004`
	poscvt	converts a given input position to other position formats	`poscvt --geodetic="30.28 262.26700 167.64"`
	timeconvert	converts given input time to other time formats	`timeconvert --calendar="07 04 2006"`
	wheresat	outputs expected location of a satellite	`wheresat -b arl2100.06n -p 3`
Collecting & Converting	rtAshtech	records observations from an Ashtech receiver	`rtAshtech -p /dev/ttyS1 -o "minute%03j%02H%02m.%06yo"`
	ficfica ficafic fic2rin	convert fic files between ASCII, binary, and RINEX formats	`fic2rin fic2100.06 rin121.06n`
	mdp2fic mdp2rinex	convert MDP files to FIC or RINEX files	`mdp2rinex -i mdpfile -o arl2100.06o`
	novaRinex	convert Novatel files to RINEX	`novaRinex --input nova2100.06 --obstype L1`
	navdmp	dumps information from nav files to human readable formats	`navdmp -i arl2100.06n -o arl2100.06.dmp`
	RinexDump	dumps observation data for specified satellites from a RINEX file	`RinexDump arl2100.06o 3 4 L1 L2`
Comparing & Validating	ephdiff	compares the satellite positions from two ephemeris sources	`ephdiff arl2100.06n fic2100.06`
	ficdiff	compares contents of two FIC files	`ficidff fic12100.06 fic22100.06`
	ficcheck ficacheck	reads a FIC file and checks it for errors reporting the first found	`ficcheck fic2100.06 -t "07/20/2006 11:00:00"`
	rowdiff rnwdiff rmwdiff	compares contents of two RINEX files	`rowdiff arl1210.06o arl22100.06o`
	rowcheck rnwcheck rmwcheck	read Rinex files and checks it for errors reporting the first found	`rnwcheck arl210.06n -e "07/20/2006 11:00:00"`
	navsum RinSum	summarizes the contents of nav/Rinex files	`RinSum -i arl2100.06o --EpochBeg 2006,07,20,13,20,00`
	mdptool	summarizes MDP data	`mdptool -i mdpfile --pvt --obs`
	reszilla	computes range residuals or zero baseline differences	`reszilla -o arl210.06o -e arl2100.06n`
Editing Data	mergeFIC	sorts and merges input FIC files into a single file	`mergeFIC -i fic12100.06 -i fic22100.06 -o ficmerge2100.06`
	mergeRinObs, -Nav, -Met	sorts and merges RINEX files	`mergeRinNav -i arl2100.06n -i arl2110.06n arl210-211.06n`
	NavMerge	merges RINEX nav files into a single file	`NavMerge -oarlnavs.06n arl2100.06n arl2110.06n`
	rinexthin	decimates an input RINEX observation files to desired data rate	`rinexthin -f arl2100.06o -s 30 -o arl2100thin.06n`
	ResCor	edits RINEX files and computes corrections	`ResCor -IFarl2100.06o -OFarl2100mod.06o -DS12,12:00:00`
	DiscFix	cycle slip corrector	`DiscFix --inputfile arl2100.06o --dt 1.5`
Iono	IonoBias	solves interfrequency biases and a simple ionosphere model	`IonoBias --input arl2100.06o --nav arl2100.06n --XSat 3`
	TECMaps	creates maps of Total Electron Content (TEC)	`TECMaps --input arl2100.06o --nav arl2100.06n --LinearFit`
Positioning	PRSolve	generates autonomous position solution	`PRSolve -o arl2100.06o -n arl2100.06nn --XPRN 12`
	rinexpvt	generates autonomous position solution	`rinexpvt -o alr2100.06o -n arl2100.06n`
	DDBase	computes a network solution using carrier phase	`DDBase ... --ObsFile arl2100.06o --PosXYZ x,y,z,1 --Fix`
	vecsol	estimates short baseline using range or carrier phase	`vecsol station12100.06o station22100.06o`

Table 2.1: GPSTk Applications, categorized, with execution examples.

2.4 *ash2mdp ash2xyz*

2.4.1 Overview

These applications process Ashtech Z(Y)-12 observation and ephemeris data and output satellite positions and ionospheric corrections in either MDP or XYZ format.

2.4.2 Usage

Optional Arguments

Short Arg.	Long Arg.	Description
-i		Where to get data from. The default is to use stdin.
-o		Where to send the output. The default is to use stdout.
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-w	–week=NUM	The full GPS week in which this data starts. Use this option when the start time of the data being processed is not during this week.
-s	–offset=NUM	Output SV positions at a time offset from the current time. Give a positive or negative integer of seconds.
-n	–num_points=NUM	Width of the exponential filter moving window, in number of points. Default is 36.

2.4.3 Notes

Input is on the command line, or of the same format in a file (-f<file>).

2.5 *ats2mdp*

2.5.1 Overview

This application converts ATS binary format data to MDP format.

2.5.2 Usage

ats2mdp

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-i	–input=ARG	A file from which to take the input. The default is stdin.
-o	–output=ARG	A file from which to receive the output. The default is stdout.

2.6 *bc2sp3*

2.6.1 Overview

This application reads RINEX navigation file(s) and writes to SP3 (a or c) file(s).

2.6.2 Usage

bc2sp3

Optional Arguments

Short Arg.	Long Arg.	Description
	–in	Read the input file (repeatable).
	–out	Name the output file. Default is sp3.out.
	–tb	Output beginning epoch; <time> = week, sec-of-week (earliest in input).
	–te	Output ending epoch; <time> = week, sec-of-week (latest in input).
	–outputC	Output version c (no correlation) (otherwise a).
	-msg	Add message as a comment to the output header (repeatable).
	–verbose	Output to screen: dump headers, data, etc.
	–help	Print this message and quit.

2.7 *CalcDOPs*

2.7.1 Overview

This application reads SV almanac data (one file per day of observation) from a FIC, FICA or a RINEX Nav file, then computes and displays visibility information. Dilution of precision values from that data are calculated using standard methods. See for example:

- AIAA GPS Theory and Applications vol. 1, Ed. Parkinson & Spilker, pp. 414.
- GPS Signals, Measurements, and Performance, 2ed., Misra & Enge, pp. 203.

2.7.2 Usage

CalcDOPs

Required Arguments

Short Arg.	Long Arg.	Description
-i<inputfile>		Input file for day to be calculated.

Optional Arguments

-p <inputfile>		Input file for previous day (ephemeris mode only).
-o <outputfile>		Grid output file (default DOPs.out).
-sf <outputfile>		Stats output file (default DOPs.stat).
-tf <outputfile>		Time steps output file (default DOPS.times).
-l <outputfile>		Log output file (default DOPS.log).
-rs		Read from stats file.
-a		Work in almanac mode (ephemeris mode is default).
-w -s <week> <sow>		Starting time tag.
-x <prn>		Exclude satellite PRN.
-t <dt>		Time spacing.
-na		North America only.
-d		Dump grid results at each time step (time-intensive).
-h	–help	Output options info and exit.
-v		Print version info and exit.

2.7.3 Notes

* Abort/failure error codes given on return:

-1	could not open input data file
-2	could not identify input data file type
-3	fewer than 4 satellite almanacs available
-4	could not allocate GridStats data types
-5	could not open input stats file
-6	could not open output grid file
-7	could not open output stats file
-8	could not open output log file

Essential variables not documented below at declaration:

NtrofN	number of cells/times with < 5 SVs visible during the time period
NpeakH	number cells/times w/ HDOP > 10
NpeakP	number cells/times w/ PDOP > 10
IworstN	index in Grid[] of cell with worst nsvs (number of satellites)
IworstH	index in Grid[] of cell with worst HDOP
IworstP	index in Grid[] of cell with worst PDOP
WorstN	value of nsvs at IworstN
WorstH	value of HDOP at IworstH
WorstP	value of PDOP at IworstP
TworstN	time tag (CommonTime class) of WorstN
TworstH	time tag (CommonTime class) of WorstH
TworstP	time tag (CommonTime class) of WorstP

1. GPS only, using PRNs hard-wired to SV numbers 1-32.
2. Elevation limit is hard-wired to 5 degrees above horizion.
3. "North America" means the northern half-hemisphere: -180 to 0 deg long., 0 to 90N latitude.
4. Ephemeris mode is default, almanac mode is optional. Ephemeris mode is preferred, because it excludes unhealthy satellites for any time when they transmitted an unhealthy flag. Almanac mode will generally not exclude SVs when they were unhealthy (typical), or may erroneously exclude them for an entire day (rarely).
5. If 2 input files are given, the default start time is midnight on the day to be calculated. A previous-day input file can be given only in ephemeris mode, not almanac.
6. The code uses geodetic coordinates for all calculations.
7. The -d option is useful for e.g. making movies of DOPs throughout a day.

2.8 *calgps*

2.8.1 Overview

This application generates a dual GPS and Julian calendar to either the command line or to a graphics file. The arguments and format are inspired by the UNIX 'cal' utility. With no arguments, the current argument is printed. The last and next month can also be printed. Also, the current or any given year can be printed.

2.8.2 Usage

calgps

Optional Arguments

Short Arg.	Long Arg.	Description
-h	–help	Generates help output.
-3	–three-months	Prints a GPS calendar for the previous, current, and next month.
-y	–year	Prints a GPS calendar for the entire current year.
-Y	–specific-year=NUM	Prints a GPS calendar for the entire specified year.
-p	–postscript=ARG	Generates a postscript file.
-s	–svg=ARG	Generates an SVG file.
-e	–eps=ARG	Generates an encapsulated postscript file.
-v	–view	Try to launch an appropriate viewer for the file.
-n	–no-blurb	Suppress GPSTk reference in graphic output.

2.8.3 Examples

```
> calgps -3

                      Jun 2011
1638                        1-152  2-153  3-154  4-155
1639   5-156  6-157  7-158  8-159  9-160 10-161 11-162
1640  12-163 13-164 14-165 15-166 16-167 17-168 18-169
1641  19-170 20-171 21-172 22-173 23-174 24-175 25-176
1642  26-177 27-178 28-179 29-180 30-181

                      Jul 2011
1642                                      1-182  2-183
1643   3-184  4-185  5-186  6-187  7-188  8-189  9-190
1644  10-191 11-192 12-193 13-194 14-195 15-196 16-197
1645  17-198 18-199 19-200 20-201 21-202 22-203 23-204
1646  24-205 25-206 26-207 27-208 28-209 29-210 30-211
1647  31-212

. . .
```

2.8.4 Notes

If multiple options are given only the first is considered.

2.9 *daa*

2.9.1 Overview

This application performs a data availability analysis of the input data. In general, availability is determined by station and satellite position.

2.9.2 Usage

daa

Required Arguments

Short Arg.	Long Arg.	Description
-e	–eph=ARG	Where to get the ephemeris data. Acceptable formats include RINEX nav, FIC, MDP, SP3, YUMA, and SEM. Repeat for multiple files.
-o	–obs=ARG	Where to get the observation data. Acceptable formats include RINEX obs, MDP, smooth, Novatel, and raw Ashtech. Repeat for multiple files. If a RINEX obs file is provided, the position will be taken from the header unless otherwise specified.

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
	–ouput=ARG	Output location (default is stdout).
-x	–independent=ARG	The independent variable in the analysis. The default is time.
-c	–msc=ARG	Station coordinates file.
-m	–msid=ARG	Station for which to process data. Used to select a station position from the msc file.
-t	–time-format=ARG	CommonTime format specifier used for times in the output. The default is “%Y %j %02H:%02M:%04.1f”.
	–mask-angle=ARG	Ignore anomalies on SVs below this elevation. The default is 10 degrees.
	–track-angle=ARG	Assume the receiver starts tracking at this elevation. The default is 10 degrees.
	–time-mask=ARG	Ignore anomalies on SVs that haven’t been above the mask angle for this number of seconds. The default is 0 seconds.
	–snr=ARG	Discard data with an SNR less than this value. The default is 20 dB-Hz.
-p	–position=ARG	Receiver antenna position in Position (x,y,z) coordinates. Format as a string: “X Y Z”.
-l	–time-span=ARG	How much data to process, in seconds.
	–ignore-prn=ARG	Specify the PRN of an SV to not report on in the output. Repeat to specify multiple SVs.
	–obs-interval=ARG	Specify the time interval, in seconds, between observations. The default is to scan the file to discover this via examination of the file.
-b	–bad-health	Ignore anomalies associated with SVs that are marked unhealthy.
-s	–smash-adjacent	Combine adjacent lines from the same PRN.

–start-time=TIME	Ignore data before this time. %4Y/%03j/%02H:%02M:%05.2f
–stop-time=TIME	Ignore any data after this time.

2.10 *DiscFix*

2.10.1 Overview

This application reads a RINEX observation data file containing GPS dual-frequency pseudorange and carrier phase measurements, divides the data into 'satellite passes', and finds and fixes discontinuities in the phases for each pass.

Output is a list of editing commands for use with program RinexEdit. DiscFix will (optionally) write the corrected pseudorange and phase data to a new RINEX observation file. Other options will also smooth the pseudorange and/or debias the corrected phase.

DiscFix calls the GPSTk Discontinuity Corrector (GDC vers 5.3 7/14/2008).

2.10.2 Usage

DiscFix

Required Arguments

Short Arg.	Long Arg.	Description
	–inputdir	File containing more options.
	–dt	Time space in seconds of the data.

Optional Arguments

Short Arg.	Long Arg.	Description
-f	–file	File containing more options.
	–beginTime	Start time of processing (BOF).
	–endTime	End time of processing (EOF).
	–decimate	Decimate data to specified time interval, in seconds.
	–forceCA	Use C/A code range, NOT P code. Default only if P absent.
	–gap	Minimum data gap in seconds separating satellite passes (600).
	–onlySat	Process only satellite (GPS SatID, e.g. G21).
	–exSat	Exclude satellite(s) (GPSSatID).
	–smoothPR	Smooth pseudorange and output in place of raw pseudorange.
	–smoothPH	Debias phase and output in place of raw phase.
	–smooth	Same as –smoothPR AND –smoothPH.
	–DClabel	Set Discontinuity Corrector parameter 'label' to 'value'.
	–DChelp	Print a list of GDC parameters and their defaults, then quit.
	–logOut	Output log file name (df.log).
	–cmdOut	Output file name, for editing commands (df.out).
	–format	Output time format (gpstk::CommonTime) (%4F %10.3g).
	–RinexFile	RINEX (obs) file name for output of corrected data.
	–RunBy	RINEX header 'RUN BY' string for output.
	–Observer	RINEX header 'OBSERVER' string for output.
	–Agency	RINEX header 'AGENCY' string for output.
	–Marker	RINEX header 'MARKER' string for output.

	–Number	RINEX header 'NUMBER' string for output.
-h	–help	Print this syntax page and quit.
	–verbose	Print extended output to the log file.

2.10.3 Examples

```
> DiscFix --dt 1.5 --inputfile ar12800.06o

DiscFix, part of the GPS ToolKit, Ver 5.0 8/20/07, Run 2011/07/22 11:17:25
DiscFix is writing to log file df.log
DiscFix is writing to output file df.out
DiscFix timing: 0.960 seconds.
```

2.11 *DOPcalc*

2.11.1 Overview

This application computes position, time, and geometric dilution of precision (DOP) parameters.

2.11.2 Usage

DOPcalc

Required Arguments		
Short Arg.	Long Arg.	Description
-e	–eph=ARG	Where to get the ephemeris data. Acceptable formats include RINEX nav, FIC, MDP, SP3, YUMA, and SEM. Repeat for multiple files.
-o	–obs=ARG	Where to get the observation data. Acceptable formats include RINEX obs, MDP, smooth, Novatel, and raw Ashtech. Repeat for multiple files. If a RINEX obs file is provided, the position will be taken from the header unless otherwise specified.
Optional Arguments		
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-p	–position=ARG	User position in ECEF (x,y,z) coordinates. Format as a string: "X Y Z".
	–el-mask=ARG	Elevation mask to apply, in degrees. The default is 0.
-c	–msc=ARG	Station coordinate file.
-m	–msid=ARG	Monitor station ID number.

2.12 *EditRinex*

2.12.1 Overview

This application will open and read one RINEX file, apply editing commands, and write the modified RINEX data to another RINEX file(s). Input is on the command line, or of the same format in a file (-f<file>).

2.12.2 Usage

EditRinex

Optional Arguments

Short Arg.	Long Arg.	Description
-f	–file <file>	File containing more options.
-l	–log <file>	Output log file name.
-h	–help	Print syntax and quit.
-d	–debug	Print extended output info.
-v	–verbose	Print extended output info.
	<REC>	Rinex editing commands - following:

```
Rinex Editor commands:
 ================================================================================
 Commands consist of an identifier and a comma-delimited data field; they may be
 separated by space(s) '--id <data>' (two minuses) or not '-id<data>' (one minus).
 Examples are '--IF myFile' or '-IFmyFile'; '--HDc msg' or '--HD cmsg' or '-HDcmsg';
 --BZ or -BZ; '--DD +<SV,OT,t>' or '--DD+ <SV,OT,t>' or '-DD+<SV,OT,t>'.
 The data field contains no whitespace and sub-fields are comma-delimited.
 <SV> is a RINEX 'system and id' identifier, e.g. G27 (= GPS PRN 27);
   satellite system alone denotes 'all satellites this system', e.g. 'R' (GLONASS).
 <OT> is a RINEX observation type, e.g. L1 or P2, and is case sensitive.
 <time> is either <GPSweek,GPSsecOfWeek> or <year,mon,day,hour,min,second>.

 File I/O:
 ---------
 -IF<file>       Input RINEX observation file name [may be repeated] (required)
 -ID<dir>        Directory in which to find input file
 -OF<file>       Output RINEX file name (required, or -OF<file>,<time>)
 -OF<f>,<time>   At RINEX epoch <time>, close output file and open another named <f>
 -OD<dir>        Directory in which to put output file(s)

 Output RINEX header:
 --------------------
 -HDf            If present, fill optional records in the output RINEX header
 -HDp<program>   Set output RINEX header 'program' field
 -HDr<run_by>    Set output RINEX header 'run by' field
 -HDo<observer>  Set output RINEX header 'observer' field
 -HDa<agency>    Set output RINEX header 'agency' field
 -HDx<x,y,z>     Set output RINEX header 'position' field to ECEF position (x,y,z)
 -HDm<marker>    Set output RINEX header 'marker' field
 -HDn<number>    Set output RINEX header 'number' field
 -HDc<comment>   Add comment to output RINEX header (more than one allowed).
 -HDdc           Delete all comments in output RINEX header
          (NB -HDdc cannot delete comments created by *subsequent* -HDc commands)
```

```
Output RINEX observation types (also see 'Specific edit commands' below):
-------------------------------------------------------------------------
-AO<OT>         Add observation type OT to header and observation data
-DO<OT>         Delete observation type OT entirely (including in header)

Time-related edit commands:
---------------------------
-TB<time>       Begin time: reject data before this time (also used for decimation)
-TE<time>       End   time: reject data after this time
-TT<dt>         Tolerance in comparing times, in seconds (default=1ms)
-TN<dt>         Decimate data to epochs = Begin + integer*dt (within tolerance)

Specific edit commands:
-----------------------
(Generally each '+' command (e.g DA+<time>) has a corresponding '-' command,
    and vice-versa; if not, end-of-file or beginning-of-file is assumed.
 Note that one-time commands are applied AFTER other commands of the same type.)

    Delete commands:
-DA+<time>      Delete all data beginning at this time
-DA-<time>      Stop deleting data at this time
-DO<OT>         Delete observation type OT entirely (including in header)
-DS<SV>         Delete all data for satellite SV entirely (SV may be system only)
-DS<SV>,<time>  Delete all data for satellite SV at this single time only
-DS+<SV>,<time> Delete all data for satellite SV beginning at this time
-DS-<SV>,<time> Stop deleting all data for satellite SV at this time
-DD<SV,OT,t>    Delete a single RINEX datum(SV,OT,t) at time <t>
-DD+<SV,OT,t>   Delete all (SV,OT) data, beginning at time <t>
-DD-<SV,OT,t>   Stop deleting all (SV,OT) data at time <t>
    (NB deleting data for one OT means setting it to zero - as RINEX requires)

    Set commands:
-SD<SV,OT,t,d>  Set data(SV,OT,t) to <d> at time <t>
-SS<SV,OT,t,s>  Set ssi(SV,OT,t) to <s> at time <t>
-SL+<SV,OT,t,l> Set all lli(SV,OT,t) to <l> at time <t>
-SL-<SV,OT,t,l> Stop setting lli(SV,OT,t) to <l> at time <t> (',<l>' is optional)
-SL<SV,OT,t,l>  Set lli(SV,OT,t) to <l> at the single time <t> only

    Bias commands:
  (NB. BD commands apply only when data is non-zero, unless -BZ appears)
-BZ             Apply BD commands even when data is zero (i.e. 'missing')
-BD<SV,OT,t,d>  Add the value of <d> to data(SV,OT,t) at time <t>
-BD+<SV,OT,t,d> Add value <d> to data(SV,OT) beginning at time <t>
-BD-<SV,OT,t,d> Stop adding <d> to data(SV,OT) at time <t> (',<d>' optional)
-BS<SV,OT,t,s>  Add the value of <s> to ssi(SV,OT,t) at time <t>
-BL<SV,OT,t,l>  Add the value of <l> to lli(SV,OT,t) at time <t>
```

2.12.3 Examples

Changing the APPROX position in the file acor1480.08o to the center of the Earth. Writes a new file called acor1480.08o.mod

```
user@host:~$ EditRinex -IFacor1480.08o -OFacor1480.08o.mod -HDx0,0,0
```

Removing a satelite, PRN 29, from an observation file, onsa2240.05o. Creates a new file, temp.o

```
EditRinex -IFonsa2240.05o -OFtemp.o
```

2.13 *ephdiff*

2.13.1 Overview

The application compares the contents of two files containing ephemeris data.

2.13.2 Usage

ephdiff

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-f	–fic=ARG	Name of an input FIC file.
-r	–rinex=ARG	Name of an input RINEX NAV file.

2.13.3 Examples

```
> ephdiff -f fic06.187 -r arl2800.06n

Broadcast Ephemeris (Engineering Units)

PRN : 11

               Week(10bt)     SOW     DOW   UTD     SOD   MM/DD/YYYY   HH:MM:SS
Clock Epoch:  1382( 358)  417600   Thu-4   187   72000   07/06/2006   20:00:00
Eph Epoch:    1382( 358)  417600   Thu-4   187   72000   07/06/2006   20:00:00
Transmit Week:1382
Fit interval flag :  0

          SUBFRAME OVERHEAD

                SOW    DOW:HH:MM:SS     IOD    ALERT   A-S
SF1 HOW:     411426  Thu-4:18:17:06   0x17D      0      on
SF2 HOW:     411432  Thu-4:18:17:12    0x7D      0      on
SF3 HOW:     411438  Thu-4:18:17:18    0x7D      0      on

           CLOCK
. . .
```

2.13.4 Notes

Both files can either be a RINEX or a FIC file.

2.14 *ephsum*

2.14.1 Overview

This application summarizes contents of a navigation message file. EphSum works on either RINEX navigation message files or FIC files. The summary is in a text output file. The summary contains the transmit time, time of effectivity, end of effectivity,IODC, and health as a one-line-per ephemeris summary. The number of ephemerides found per SV is also provided. The number of ephemerides per SV is also summarized at the end. The default is to summarize all SVs found. If a specific PRN ID is provided, only data for that PRN ID will be sumarized.

2.14.2 Usage

ephsum

Required Arguments

Short Arg.	Long Arg.	Description
-i	–input-file=ARG	Input file name(s)
-o	–output-file=ARG	Output file name

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-p	–PRNID=ARG	The PRN ID of the SV to process (default is all SVs).
-x	–xmit	List in order of transmission (default is TOE).

2.15 *fic2rin*

2.15.1 Overview

This application converts navigation messages between the FIC format, a format for GPS observations established by ARL:UT, and the RINEX format.

2.15.2 Usage

```
fic2rin usage: fic2rin <input FIC file> <output RINEX file name>
```

2.15.3 Examples

File Snippets

Binary FIC File

```
0000000
*
0000020                                   B   L   K       m  \0  \0  \0
0000030  \0  \0  \0  \0      \0  \0  \0  \0  \0  \0  \0   f 005  \0  \0
0000040 022  \0  \0  \0   >   f 301   " 260   i   {   !   f  \0   d 026
0000050 335 344   8  \t 002   b   C 035 205   7   4 027 241 372 210 006
0000060 006   }   Y   / 301 374   ?  \0   \   S 021   8   >   f 301   "
 . . .
```

RINEX NAV File

```
     2.10           NAVIGATION                            RINEX VERSION / TYPE
fic2rin                                 07/13/2006 11:48:58 PGM / RUN BY / DATE
                                                            END OF HEADER
 5 06  7  6 19 59 44.0  .199091155082D-03  .356976670446D-10  .000000000000D+00
     .118000000000D+03 -.656250000000D+00  .538879589355D-08  .997594152841D+00
    -.409781932831D-07  .710751442239D-02  .655464828014D-05  .515355578804D+04
     .417584000000D+06 -.104308128357D-06 -.249936238139D+01  .707805156708D-07
     .938194464982D+00  .241750000000D+03  .105751234129D+01 -.843570852398D-08
     .600024993449D-10  .100000000000D+01  .138200000000D+04  .000000000000D+00
     .240000000000D+01  .000000000000D+00 -.419095158577D-08  .118000000000D+03
     .411426000000D+06  .400000000000D+01
 . . .
```

2.16 *ficacheck ficcheck*

2.16.1 Overview

These applications read input ASCII or binary FIC and check them for errors. *ficcheck* checks binary files and *ficacheck* checks ASCII files.

2.16.2 Usage

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-t	–time=TIME	Time of first record to count (default BOT).
-e	–end-time=TIME	End of time range to compare (default EOT).

```
ficacheck usage: ficacheck [options] <FICA file>
ficcheck usage:  ficcheck [options] <FIC file>
```

2.16.3 Examples

```
>ficcheck fic06.187

Checking fic06.187
Read 252 records.


> ficacheck brokenfica

Checking brokenfica
text 0:Bad block header, record=2 location=484
text 1:blkHdr=[    ]
text 2:In record 2
text 3:In file brokenfica
text 4:Near file line 10
location 0:src/FICData.cpp:963
location 1:src/FFStream.cpp:159
location 2:src/FFStream.hpp:208
location 3:src/FFStream.hpp:208
```

2.16.4 Notes

Only the first error in each file is reported. The entire file is always checked regardless of time options.

2.17 *ficafic ficfica*

2.17.1 Overview

These applications convert navigation message data between variations of the FICformat, a format for GPS observations established by ARL:UT. *ficacheck* works with ASCII FIC files and *ficcheck* works with binary FIC files.

2.17.2 Usage

```
ficafic usage: ficafic <input fica file> <output fic file name>
ficfica usage: ficfica <input fic file> <output fica file name>
```

2.17.3 Examples

```
File Snippets

Binary FIC File

0000000
*
0000020                                   B   L   K       m  \0  \0  \0
0000030  \0  \0  \0  \0      \0  \0  \0  \0  \0  \0  \0   f 005  \0  \0
0000040 022  \0  \0  \0   >   f 301   " 260   i   {   !   f  \0   d 026
0000050 335 344   8  \t 002   b   C 035 205   7   4 027 241 372 210 006
0000060 006   }   Y   / 301 374   ?  \0   \   S 021   8   >   f 301   "
 . . .

ASCII FIC File

BLK    109    0   32    0
        1382          18   583099966   561736112   375652454   154723549
   490955266   389298053   109640353   794393862     4193473   940659548
   583099966   561744492   792779231   218793822   800301952    12009725
   793943984    14182503    56922219   427630416   583099966   561753060
  1073203199   309077037     1329639    15188054   182084772   733918588
  1072216082   792738524
BLK      9   60    0    0
 .13900000000000D+03 .35800000000000D+03 .41142600000000D+06 .10000000000000D+01
 .10000000000000D+01 .13820000000000D+04 .10000000000000D+01 .00000000000000D+00
 .00000000000000D+00 .91136000000000D+06 .00000000000000D+00-.10244548320770D-07
 .41760000000000D+06 .00000000000000D+00-.14779288903810D-11-.24207541719079D-03
 .00000000000000D+00 .00000000000000D+00 .00000000000000D+00 .18000000000000D+02
 . . .
```

2.18 *ficdiff*

2.18.1 Overview

The application compares the contents of two FIC files containing ephemeris data.

2.18.2 Usage

ficdiff

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-t	–time=TIME	Start of time range to compare (default BOT).
-e	–end-time=TIME	End of time range to compare (default EOT).

```
ephdiff usage: ficdiff [options] fic1 fic2
```

2.18.3 Examples

```
> ficdiff -t "08/01/2006 12:00:00" fic1 fic2
<FIC BlockNumber: 9
 floats:  139 362 172806 1 1 1386 1 0 0 55296 0 -4.19095e-09 180000 0 . . .
 integers:
 chars:

<FIC BlockNumber: 9
 floats:  139 362 172806 1 1 1386 1 0 0 59392 0 -6.98492e-09 179984 0 . . .
 integers:
 chars:
 . . .
```

2.19 *findMoreThan12*

2.19.1 Overview

This application finds when there are simultaneously more than 12 SVs above a given elevation.

2.19.2 Usage

findMoreThan12

Required Arguments		
Short Arg.	Long Arg.	Description
-e	–eph-files=ARG	Ephemeris source file(s). Can be RINEX nav, SP3, or FIC.
-p	–position=ARG	Antenna position in ECEF (x,y,z) coordinates. Format as a string: "X Y Z".
-m	–min-elev=NUM	Give an integer for the elevation (degrees) above which you want to find more than 12 SVs at a given time.
Optional Arguments		
-h	–help	Print help usage.
-v	–verbose	Increase verbosity.

2.20 *IonoBias*

2.20.1 Overview

The application will open and read several preprocessed RINEX obs files (containing obs types EL,LA,LO,SR or SS) and use the data to estimate satellite and receiver biases and to compute a simple ionospheric model using least squares and the slant TEC values.

2.20.2 Usage

IonoBias

Required Arguments

Short Arg.	Long Arg.	Description
	–input	Input RINEX obs file name(s).

Optional Arguments

Short Arg.	Long Arg.	Description
-f		File containing more options
	–inputdir	Path for input file(s).

Ephemeris Input

Short Arg.	Long Arg.	Description
	–navdir	Path of navigation file(s).
	–nav	Navigation (RINEX (nav) OR SP3) file(s).

Output

Short Arg.	Long Arg.	Description
	–datafile	Data (AT) file name, for output and/or input.
	–log	Output log file name.
	–biasout	Output satellite+receiver biases file name.

Time Limits

Short Arg.	Long Arg.	Description
	–BeginTime	Start time, arg is of the form YYYY,MM,DD,HH,Min,Sec.
	–BeginGPSTime	Start time, arg is of the form GPSweek,GPSsow.
	–EndTime	End time, arg is of the form YYYY,MM,DD,HH,Min,Sec.
	–EndGPSTime	End time, arg is of the form GPSweek,GPSsow.

Processing

Short Arg.	Long Arg.	Description
	–NoEstimation	Do NOT perform the estimation (default=false).
	–NoPreprocess	Skip preprocessing; read (existing) AT file (false).
	–NoSatBiases	Compute Receiver biases ONLY (not Rx+Sat biases) (false).
	–Model	Ionospheric model: type is linear, quadratic or cubic.
	–MinPoints	Minimum points per satellite required.
	–MinTimeSpan	Minimum timespan per satellite required (minutes).

	–MinElevation	Minimum elevation angle (degrees).
	–MinLatitude	Minimum latitude (degrees).
	–MaxLatitude	Maximum latitude (degrees).
	–MinLongitude	Minimum longitude (degrees).
	–MaxLongitude	Maximum longitude (degrees).
	–TimeSector	Time sector (day — night — both).
	–TerminOffset	Terminator offset (minutes).
	–IonoHeight	Ionosphere height (km).

Other Options

Short Arg.	Long Arg.	Description
	–XSat	Exclude this satellite (<sat> may be <system> only).
-v	–verbose	Print extended output info.
-d	–debug	Increase debug level.
-h	–help	Print syntax and quit.

2.20.3 Examples

```
> IonoBias --inputdir data_set --navdir data_set --input s081213a.99o --input s081214a.99o
--input s081215a.99o --nav s081213a.99n --nav s081214a.99n --nav s081215a.99n --datafile output}
IonoBias, built on the GPSTK ToolKit, Ver 1.0 6/25/04, Run 2006/08/17 09:50:59
IonoBias output directed to log file IonoBias.log
IonoBias timing: 6.210 seconds.
```

```
Output File Snippet

    3     3 Number (max, good) stations in this file
01010110110000111111010111011101110
01010110110000111111010111011101110
01010010110000111111010111011101110
Npt  9737 Sta 85408 LLH    30.2160   262.2746   163.4226
1021      0.0   0.00000 -463513.64930 0.32    0.000      1  1   1
1021      0.0   0.00000 -463513.64930 0.32    0.000      1 14   1
1021      0.0   0.00000 -463513.64930 0.32    0.000      1 15   1
1021      0.0   0.00000 -463513.64930 0.32    0.000      1 21   1
1021      0.0   0.00000 -463513.64930 0.32    0.000      1 22   1
1021      0.0   0.00000 -463513.64930 0.32    0.000      1 25   1
1021      0.0   0.00000 -463513.64930 0.32    0.000      1 29   1
1021      0.0   0.00000 -463513.64930 0.32    0.000      1 30   1
1021     30.0   0.00000 -463513.52430 0.32    0.000      1  1   1
1021     30.0   0.00000 -463513.52430 0.32    0.000      1 14   1
```

2.20.4 Notes

Input can be either on the command line or put in a file and then input using the -f option. The file is formatted just as if it were the command line.

2.21 *mdp2fic mdp2rinex*

2.21.1 Overview

The applications convert a variety of GPS related observations from the MDP format to FIC and RINEX formats. MDP is a format for network receiver interfaces derived by ARL:UT that can be used to serve observations over networks.

2.21.2 Usage

mdp2fic

Required Arguments

Short Arg.	Long Arg.	Description
-i	–mdp-input=ARG	Filename to read MDP data from. The filename of '-' means to use stdin.
-n	–nav=ARG	Filename to which FIC nav data will be written.

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-l	–log=ARG	Filename for (optional) output log file.

mdp2rinex

Required Arguments

Short Arg.	Long Arg.	Description
-i	–mdp-input=ARG	Filename to read MDP data from. The filename of '-' means to use stdin.
-n	–obs=ARG	Filename to write RINEX obs data to. The filename of '-' means to use stdout.

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-n	–nav=ARG	Filename to write RINEX nav data.
-p	–pos=ARG	Antenna position to write into obs file header. Format as string: "X Y Z"
-t	–thinning=ARG	A thinning factor for the data, specified in seconds between points.
-c	–12c	Enable output of L2C data in C2.
-a	–any-nav-source	Accept subframes from any code/carrier.

2.21.3 Examples

```
> mdp2fic -i mdp183.06 -o fic183.06 -l mdp2ficlog183.06
```

```
> mdp2rinex -i mdp183.06 -o rin183.06o -n rin183.06n -t 60
```

2.22 *mdptool*

2.22.1 Overview

The application performs various functions on a stream of MDP data.

2.22.2 Usage

mdptool

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-i	–input=ARG	Where to get the MDP data from. The default is to use stdin. If the file name begins with "tcp:" the remainder is assumed to be a hostname[:port] and the source is taken from a tcp socket at this address. If the port number is not specified a default of 8910 is used.
	–output=ARG	Where to send the output. The default is stdout.
-p	–pvt	Enable pvt output.
-o	–obs	Enable obs output.
-n	–nav	Enable nav output.
-t	–test	Enable selftest output.
-x	–hex	Dump all messages in hex.
-b	–bad	Try to process bad messages also.
-a	–almanac	Build and process almanacs. Only applies to the nav style.
-e	–ephemeris	Build and process engineering ephemerides. Only applies to the nav style.
	–min-alm	This allows a complete almanac to be constructed from fewer than 50 pages. It is required for Ashtech Z(Y)-12. The default is to require all 50 pages.
-f	–follow	Follow the input file as it grows.
-s	–output-style=ARG	What type of output to produce from the MDP stream. Valid styles are: brief, verbose, table, track, null, mdp, nav, and summary. The default is summary. Some modes aren't quite complete. Sorry.
-l	–timeSpan=NUM	How much data to process, in seconds.
-m	–bug-mask=NUM	What RX bugs: 1 SV count, 2 nav parity/fmt, 4 HOW/hdr time equal.
	–startTime=TIME	Ignore data before this time. (%4Y/%03j/%02H:%02M:%05.2f).
	–stopTime=TIME	Ignore any data after this time.
	–time-format=ARG	CommonTime format specifier used for times in the output. The default is %4Y %3j %02H:%02M:%04.1f.

2.22.3 Notes

In the summary mode, the default is to only summarize the obsservation data above 10 degrees. Increasing the verbosity level will also summarize the data below 10 degrees.

2.23 *mergeFic*

2.23.1 Overview

This application merges multiple FIC files into a single FIC file.

2.23.2 Usage

mergeFIC

Required Arguments

Short Arg.	Long Arg.	Description
-i	–input=ARG	An input RINEX observation file, can be repeated as many times as needed.
-o	–output=ARG	Name for the merged output RINEX observation file. Any existing file with that name will be overwritten.

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.

2.23.3 Examples

```
> mergeFIC -i fic1 -i fic2 -o ficm
```

2.24 *mergeRinObs mergeRinNav mergeRinMet*

2.24.1 Overview

These applications merge multiple RINEX observation, navigation, or meterological data files into a single coherent RINEX obs/nav/met file, respectively.

2.24.2 Usage

mergeRinObs

Required Arguments

Short Arg.	Long Arg.	Description
-i	–input=ARG	An input RINEX Obs file, can be repeated as many times as needed.
-o	–output=ARG	Name for the merged output RINEX Obs file. Any existing file with that name will be overwritten.

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.

mergeRinNav and *mergeRinMet* have the same usage.

2.24.3 Examples

```
> mergeRinObs -i arl280.06o -i arl2810.06o -o arl280-10.06o

> mergeRinNav -i arl280.06n -i arl2810.06n -o arl280-10.06n

> mergeRinMet -i arl280.06m -i arl2810.06m -o arl280-10.06m
```

2.25 *navdmp*

2.25.1 Overview

The application prints the contents of an FIC or RINEX navigation file into a human readable file and allows filtering of the data.

2.25.2 Usage

navdmp

Required Arguments

Short Arg.	Long Arg.	Description
-i	–input=ARG	Name of an input navigation message file.
-o	–output=ARG	Name of an output file.

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-a	–all-records	Unless otherwise specified, use default values for record filtration.
-t	–time=TIME	Start time (of data) for processing.
-e	–end-time=TIME	End time (of data) for processing.
-p	–prn=NUM	PRN(s) to include.
-b	–block=NUM	FIC block number(s) to process ((9)109 (Engineering) ephemerides, (62)162 (engineering) almanacs).
-r	–RINEX	Assume input file is a RINEX navigation message file.

2.25.3 Examples

```
> navdmp -i data_set/s081213a.99n -o summary --RINEX

Current filtering options:
       Start time:    01/06/1980 00:00:00
       End time:      01/01/4713 00:00:00
       PRNs:          using all PRNs

Choose an option by number then push enter:
       1) Change the start time
       2) Change the end time
       3) Select specific PRNs
       5) Process the file
use ctrl-c to exit
? 5

processing...
```

```
Summary File Snippet

*******************************************************************************
```

```
Broadcast Ephemeris (Engineering Units)

PRN : 14

              Week(10bt)     SOW     DOW   UTD     SOD   MM/DD/YYYY   HH:MM:SS
Clock Epoch:  1021(1021)    7200   Sun-0   213    7200   08/01/1999   02:00:00
Eph Epoch:    1021(1021)    7200   Sun-0   213    7200   08/01/1999   02:00:00
Transmit Week:1021
Fit interval flag :  0

          SUBFRAME OVERHEAD

               SOW    DOW:HH:MM:SS     IOD    ALERT   A-S
SF1 HOW:         6  Sun-0:00:00:06   0x023      0     off
SF2 HOW:         6  Sun-0:00:00:06    0x23      0     off
SF3 HOW:         6  Sun-0:00:00:06    0x23      0     off

           CLOCK

Bias T0:       2.82567926E-05 sec
Drift:         1.02318154E-12 sec/sec
Drift rate:    0.00000000E+00 sec/(sec**2)
Group delay:  -2.32830644E-09 sec

           ORBIT PARAMETERS

Semi-major axis:         5.15359685E+03 m**.5
Motion correction:       4.44732811E-09 rad/sec
Eccentricity:            8.10711295E-04
Arg of perigee:          2.16661714E+00 rad
Mean anomaly at epoch:   1.75307843E-01 rad
Right ascension:         2.02857661E+00 rad     -8.31963226E-09 rad/sec
Inclination:             9.77089255E-01 rad      2.20723480E-10 rad/sec

           HARMONIC CORRECTIONS

Radial        Sine:   1.31875000E+01 m    Cosine:   3.31593750E+02 m
Inclination   Sine:   5.77419996E-08 rad  Cosine:  -1.86264515E-08 rad
In-track      Sine:   2.74367630E-06 rad  Cosine:   6.27711415E-07 rad

           SV STATUS

Health bits:   0x00      URA index:    7
Code on L2:    P only      L2 P Nav data:          on

********************************************************************************
```

2.26 *NavMerge*

2.26.1 Overview

The application merges RINEX navigation files into a single file.

2.26.2 Usage

NavMerge

Optional Arguments

Short Arg.	Long Arg.	Description
-o		Write all data to an output RINEX nav file. If omitted, a data summary is written to the screen.
-tb		Output only if epoch is within 4 hours of the interval (tb,te).
-te		If te or tb is missing, they are made equal. Time tags have the form year,mon,day,HH,min,sec OR GPSweek,sow.

```
NavMerge usage: NavMerge [options] <RINEX nav file> <RINEX nav file>
```

2.26.3 Examples

```
> NavMerge -o s081213-214.99n s081213a.99n s081214a.99n

Output file name is
Exception: text 0:Unexpected EOF
text 1:In record 0
text 2:In file s081213-214.99n
text 3:Near file line 0
location 0:src/FFTextStream.hpp:244
location 1:src/FFStream.cpp:159
location 2:src/FFStream.hpp:208
location 3:src/FFStream.hpp:208

Read    0 ephemerides from file s081213-214.99n
Read  200 ephemerides from file s081213a.99n
Read  197 ephemerides from file s081214a.99n
Read  397 total ephemerides.
```

2.26.4 Notes

NavMerge corrects data for output when the GPS full week number is inconsistent with the epoch time.

2.27 *navsum*

2.27.1 Overview

This application lists the block contents of a FIC file and prints summary count information.

2.27.2 Usage

navsum

Required Arguments

Short Arg.	Long Arg.	Description
-i	–input=ARG	Name of an input FIC file.
-o	–output=ARG	Name of an output file.

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-a	–all-records	Unless otherwise specified, use default values for record filtration.
-t	–time=TIME	Start time (of data) for processing.
-e	–end-time=TIME	End time (of data) for processing.
-p	–prn=NUM	PRN(s) to include.
-b	–block=NUM	FIC block number(s) to process ((9)109 (Engineering) ephemerides, (62)162 (engineering) almanacs).
-f	–use-alternate-format	Use alternate output format.

2.27.3 Examples

```
> navsum -i s081213a.99n -o summary --RINEX

Current filtering options:
       Start time:    01/06/1980 00:00:00
       End time:      01/01/4713 00:00:00
       PRNs:          using all PRNs

Choose an option by number then push enter:
       1) Change the start time
       2) Change the end time
       3) Select specific PRNs
       5) Process the file
use ctrl-c to exit
? 5

processing...

Summary of data processed
Block Type Summary
Type   # Blocks Found
   9              0
```

```
 109              0
  62              0
 162              0

Ephemeris Blocks by PRN
PRN Block       Num
 01     9          0
 01   109          0
 02     9          0
 02   109          0
 03     9          0
 03   109          0
 04     9          0
 04   109          0
 05     9          0
 . . .
```

2.28 *novaRinex*

2.28.1 Overview

The application will open and read a binary Novatel file (OEM2 and OEM4 receivers are supported), and convert the data to RINEX format observation and navigation files. The RINEX header is filled using user input (see below), and optional records are filled.

2.28.2 Usage

novaRinex

Required Arguments

Short Arg.	Long Arg.	Description
	–input	Novatel binary input file.

Optional Arguments

Short Arg.	Long Arg.	Description
-f		Name of file containing more options ('#' to EOL : comment).
	–dir	Directory in which to find input file (default ./).
	–obs	RINEX observation output file (RnovaRINEX.obs).
	–nav	RINEX navigation output file (RnovaRINEX.nav).

Output RINEX Header Fields

Short Arg.	Long Arg.	Description
	–noHDopt	If present, do not fill optional records in the output RINEX header.
	–HDp	Set output RINEX header 'program' field ('novaRINEX v2.1 9/07').
	–HDr	Set output RINEX header 'run by' field ('ARL:UT/GPSTk').
	–HDo <obser>	Set output RINEX header 'observer' field.
	–HDa <agency>	Set output RINEX header 'agency' field ('ARL:UT/GPSTk').
	–HDm <marker>	Set output RINEX header 'marker' field.
	–HDn <number>	Set output RINEX header 'number' field.
	–HDrn <number>	Set output RINEX header 'Rx number' field.
	–HDrt <type>	Set output RINEX header 'Rx type' field ('Novatel').
	–HDrv <vers>	Set output RINEX header 'Rx version' field ('OEM2/4').
	–HDan <number>	Set output RINEX header 'antenna number' field.
	–HDat <type>	Set output RINEX header 'antenna type' field.
	–HDc <comment>	Add comment to output RINEX header (>1 allowed).

Output RINEX Observation Data

Short Arg.	Long Arg.	Description
	–obstype <OT>	Output this RINEX (standard) obs type (i.e. <OT> is one of L1,L2,C1,P1,P2,D1,D2,S1,or S2); repeat for each type. NB default is ALL std. types that have data.

Output Configuration

Short Arg.	Long Arg.	Description
	–begin <arg>	Start time, arg is of the form YYYY,MM,DD,HH,Min,Sec.
	–beginGPS <arg>	Start time, arg is of the form GPSweek,GPSsow.
	–end <arg>	End time, arg is of the form YYYY,MM,DD,HH,Min,Sec.
	–endGPS <arg>	End time, arg is of the form GPSweek,GPSsow
	–week <week>	GPS Week number of this data, NB: this is for OEM2; this command serves two functions, resolving the ambiguity in the 10-bit week (default uses –begin, –end, or the current system time) and ensuring that ephemeris records that precede any obs records are not lost.
	–debias	Remove an initial bias from the phase.
-h	–help	Print this message and quit.
	–verbose	Print more information.
-d	–debug	Print extended output info.

2.28.3 Notes

Input is on the command line, or of the same format in a file (-f<file>).

2.29 *poscvt*

2.29.1 Overview

This application allows the user to convert among different coordinate systems on the command line. Coordinate systems handled include Cartesian, geocentric, and geodetic.

2.29.2 Usage

poscvt

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
	–ecef=POSITION	ECEF “X Y Z” in meters.
	–geodetic=POSITION	Geodetic “lat lon alt” in deg, deg, meters.
	–geocentric=POSITION	Geocentric “lat lon radius” in deg, deg, meters.
	–spherical=POSITION	Spherical “theta, pi, radius” in deg, deg, meters.
-l	–list-formats	List the available format codes for use by the input and output format options.
-F	–output-format=ARG	Write the position with the given format.

2.29.3 Examples

```
> poscvt --ecef="4345070.59253 45619878.26297 803.598856837"

    ECEF (x,y,z) in meters              4345070.5925 45619878.2630 803.5989
    Geodetic (llh) in deg, deg, m       0.00100566 84.55926933 39448197.4795
    Geocentric (llr) in deg, deg, m     0.00100472 84.55926933 45826334.4795
    Spherical (tpr) in deg, deg, m      89.99899528 84.55926933 45826334.4795
```

2.29.4 Notes

If no options are given *poscvt* assumes XYZ 0 0 0.

2.30 *PRSolve*

2.30.1 Overview

The application reads one or more RINEX observation files, plus one or more navigation (ephemeris) files, and computes an autonomous pseudorange position solution, using a RAIM-like algorithm to eliminate outliers. Output is to the log file, and also optionally to a RINEX obs file with the position solutions in auxiliary header blocks.

2.30.2 Usage

PRSolve

Required Arguments

Short Arg.	Long Arg.	Description
-o	–obs	Input RINEX observation file(s).
-n	–nav	Input navigation (ephemeris) file(s) (RINEX or SP3).

Optional Arguments: Input

Short Arg.	Long Arg.	Description
-f		File containing more options.
	–obsdir	Directory of input observation file(s).
	–navdir	Directory of input navigation file(s).
	–metdir	Directory of input meteorological file(s).
-m	–met	Input RINEX meteorological file(s).
	–decimate	Decimate data to time interval dt.
	–BeginTime	Start time: arg is 'GPSweek,sow' OR 'YYYY,MM,DD,HH,Min,Sec'.
	–EndTime	End time: arg is 'GPSweek,sow' OR 'YYYY,MM,DD,HH,Min,Sec'.
	–useCA	Use C/A code pseudorange if P1 is not available.
	–forceCA	Use C/A code pseudorange regardless of P1 availability.

Optional Arguments: Configuration

Short Arg.	Long Arg.	Description
	–Freq	Frequency to process: 1, 2, or 3 for L1, L2, of iono-free combination.
	–MinElev	Minimum elevation angle in degrees (only if –PosXYZ).
	–exSat	Exclude this satellite.
	–Trop	Trop model, one of ZR, BL, SA, NB, NL, GG, GGH (gpstk::TropModel), with optional weather T(c), P(mb),RH(%).

Optional Arguments: PRSolution Configuration

Short Arg.	Long Arg.	Description
	–RMSlimit	Upper limit on RMS post-fit residuals (m) for a good solution.
	–SlopeLimit	Upper limit on RAIM 'slope' for a good solution.
	–Algebra	Use algebraic algorithm (otherwise linearized LS).
	–DistanceCriterion	Use distance from a priori as convergence criterion (else RMS).

	–ReturnAtOnce	Return as soon as a good solution is found.
	–NReject	Maximum number of satellites to reject.
	–NIter	Maximum iteration count (linearized LS algorithm).
	–Conv	Minimum convergence criterion (m) (LLS algorithm).

Optional Arguments: Output

Short Arg.	Long Arg.	Description
	–Log	Output log file name (prs.log).
	–PosXYZ <X,Y,Z>	Known position (ECEF,m), used to compute output residuals.
	–APSout	Output autonomous pseudorange solution (APS - no RAIM).
	–TimeFormat	Output time format (ala CommonTime) (default: %4F %10.3g).

Optional Arguments: RINEX Output

Short Arg.	Long Arg.	Description
	–outRinex	Output RINEX observation file name.
	–RunBy	Output RINEX header 'RUN BY' string.
	–Observer	Output RINEX header 'OBSERVER' string.
	–Agency	Output RINEX header 'AGENCY' string.
	–Marker	Output RINEX header 'MARKER' string.
	–Number	Output RINEX header 'NUMBER' string.

Optional Arguments: Help

Short Arg.	Long Arg.	Description
	–verbose	Print extended output.
	–debug	Print very extended output.
	–helpRetCodes	Print return codes (implies –help).
-h	–help	Print syntax and quit.

2.30.3 Examples

```
> PRSolve -o arl2800.06o -n arl2800.06n

PRSolve, part of the GPS ToolKit, Ver 2.3 11/09, Run 2011/07/22 11:39:15
Opened log file prs.log

Weighted average RAIM solution for file: arl2800.06o
 (2880 total epochs, with 2880 good, 0 rejected.)
    918129.266960  -4346070.850055   4561977.615781
Covariance of RAIM solution for file: arl2800.06o
         0.000150        -0.000061         0.000058
        -0.000061         0.000427        -0.000248
         0.000058        -0.000248         0.000493
```

2.30.4 Notes

In the log file, results appear one epoch per line with the format:
TAG Nrej week sow Nsat X Y Z T RMS slope nit conv sat sat .. (code) [N]V
TAG denotes solution (X Y Z T) type:

- RPF Final RAIM ECEF XYZ solution
- RPR Final RAIM ECEF XYZ solution residuals [only if –PosXYZ given]
- RNE Final RAIM North-East-Up solution residuals [only if –PosXYZ]
- APS Autonomous ECEF XYZ solution [only if –APSout given]
- APR Autonomous ECEF XYZ solution residuals [only if both –APS –Pos]
- ANE Autonomous North-East-Up solution residuals [only if –APS –Pos]

Where:

- Nrej = number of rejected sats
- (week,sow) = GPS time tag
- Nsat = sats used
- XYZT = position+time solution(or residuals)
- RMS = RMS residual of fit
- slope = RAIM slope
- nit = of iterations
- conv = convergence factor
- 'sat sat ...' lists all sat. PRNs (- : rejected)
- code = return value from PRSolution::RAIMCompute()
- NV means NOT valid

2.31 *ResCor*

2.31.1 Overview

The application will open and read a single RINEX observation file, apply editing commands using the RinexEditor package, compute any of several residuals and corrections and register extended RINEX observation types for them, and then write the edited data, along with the new extended observation types, to an output RINEX observation file.

2.31.2 Usage

ResCor

Required Arguments

Short Arg.	Long Arg.	Description
-IF		Input RINEX observation file.
-OF		Name of ouput RINEX observation file.

Configuration Arguments

Short Arg.	Long Arg.	Description
-f<file>		File containing more options.
	–nav <file>	Navigation (RINEX Nav OR SP3) file(s).
	–navdir <dir>	Directory of navigation file(s).

Reference Position Input

Short Arg.	Long Arg.	Description
	–RxLLH <l,l,h>	1.Receiver position (static) in geodetic lat, lon(E), ht (deg,deg,m).
	–RxXYZ <x,y,z>	2.Receiver position (static) in ECEF coordinates (m).
	–Rxhere	3.Reference site positions(time) from this file (i.e. -IF<RINEXFile>).
	–RxRinex <fn>	4.Reference site positions(time) from another RINEX file named <fn>.
	–RxFlat <fn>	5.Reference site positions and times given in a flat file named <fn>.
	–Rxhelp	(Enter –Rxhelp for a description of the -RxFlat file format).
	–RAIM	6.Reference site positions computed via RAIM (requires P1,P2,EP). NB the following two options apply only if –RAIM is found.
	–noRAIMedit	Do not edit data based on RAIM solution.
	–RAIMhead	Output average RAIM solution to RINEX header (if -HDf also appears).
	–noRefout	Do not output reference solution to RINEX.
	–MinElev	Minimum satellite elevation in degrees for output.

Residual/Correction Computation

Short Arg.	Long Arg.	Description
	–debias <OT,l>	Debias new output type <OT>; trigger a bias reset with limit <l>.
	–Callow	Allow C1 to replace P1 when P1 is not available.

	–Cforce	Force C/A code pseudorange C1 to replace P1.
	–IonoHt <ht>	Height of ionosphere in km (default 400) (needed for LA,LO,VR,VP).
	–Tgd	Apply the Tgd from BC ephemeris to SR,SP,VR, and VP.
	–SVonly <prn>	Process this satellite ONLY.

Output Files

Short Arg.	Long Arg.	Description
	–Log <file>	Output log file name (rc.log)

Help

Short Arg.	Long Arg.	Description
	–verbose	Print extended output
	–debug	Print debugging information.
-h	–help	Print syntax and quit.
	–REChelp	Print syntax of RINEXEditor commands and quit.
	–ROThelp	Print list of extended RINEX observation types and quit.

```
The list of available extended Rinex obs types:
  OT Description          Units     Required input (EP=ephemeris,PS=Rx Position)
  ER Ephemeris range      meters                EP PS
  RI Iono Delay, Range    meters             P1
  PI Iono Delay, Phase    meters     L1 L2
  TR Tropospheric Delay   meters                EP PS
  RL Relativity Correct.  meters                EP
  SC SV Clock Bias        meters                EP
  EL Elevation Angle      degrees               EP PS
  AZ Azimuth Angle        degrees               EP PS
  SR Slant TEC (PR)       TECU               P1
  SP Slant TEC (Ph)       TECU       L1 L2
  VR Vertical TEC (PR)    TECU               P1 EP PS
  VP Vertical TEC (Ph)    TECU       L1 L2       EP PS
  LA Lat Iono Intercept   degrees               EP PS
  LO Lon Iono Intercept   degrees               EP PS
  P3 TFC(IF) Pseudorange  meters             P1
  L3 TFC(IF) Phase        meters     L1 L2
  P4 GeoFree Pseudorange  meters             P1
  L4 GeoFree Phase        meters     L1 L2
  P5 WideLane Pseudorange meters             P1
  L5 WideLane Phase       meters     L1 L2
  MP Multipath (=M3)      meters     L1 L2    P1
  M1 L1 Range minus Phase meters     L1       P1
  M2 L2 Range minus Phase meters        L2
  M3 IF Range minus Phase meters     L1 L2    P1
  M4 GF Range minus Phase meters     L1 L2    P1
  M5 WL Range minus Phase meters     L1 L2    P1
  XR Non-dispersive Range meters     L1 L2    P1
  XI Ionospheric delay    meters     L1 L2    P1
  X1 Range Error L1       meters     L1 L2    P1
  X2 Range Error L2       meters     L1 L2    P1
  SX Satellite ECEF-X     meters                EP
  SY Satellite ECEF-Y     meters                EP
  SZ Satellite ECEF-Z     meters                EP
```

2.32 *reszilla*

2.32.1 Overview

Reszilla is an application that computes various residuals from GPS pseudorange, phase and doppler data. These data are often refered to as raw observations. The two types of residuals that are currently computed are an Observed Range Deviation (ORD), and a double difference (DD). Once these residuals are computed, statistical summaries of these differences are computed and output to the user. Optionally, the residuals themselves may be output.

2.32.2 Observed Range Deviations

An ORD is basically the observed range to an SV differenced from the estimated range to that SV. There are many terms that go into computing the estimated range and/or correcting the observed range for known effects. When all of these effects are accounted for (as reszilla is capable of doing) ORDs can be in the 10-30 cm range for a geodetic quality GPS receiver. Pretty impressive when you consider that the range to the SV is somewhere between 20 to 26 million meters.

For many GPS receivers, the most significant effect to account for is the receiver clock offset. This is the difference between the receivers internal time and true GPS time. This parameter is often computed as part of a PVT solution. This is not how reszilla works. Reszilla is provided a surveyed position of the receiver antenna, and it makes a more accurate estimate of the receiver clock offset by averaging the residuals of all SVs in track.

2.32.3 Usage

OrdApp

OrdApp

Required Arguments

Short Arg.	Long Arg.	Description
-i	–input	Where to read the ord data. The default is stdin.
-r	–output	Where to write the output. The default is stdout.
-t	–time-format	CommonTime format specifier used for times in the output.

Optional Arguments

Short Arg.	Long Arg.	Description
	–ns	Report the clock in ns, not meters.

ordClock

ordClock generates clock estimates for each epoch of ORDs.

ordClock

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-w	–use-warts	Use warts in the clock solution. The default is to not use warts.
-e	–estimate-only	Only compute the receiver clock bias. Don't remove this bias from the ords. The default is to both estimate the bias and remove the it from the ords.
-c	–clock-source=ARG	An ord file to read the receiver clock offsets from.
-i	–input=ARG	Where to read the ord data. The default is stdin.
-r	–output=ARG	Where to write the output. The default is stdout.
-t	–time-format=ARG	CommonTime format specifier used for times in the output. The default is "%4Y %3j %02H:%02M:%04.1f".
	–ns	Report the clock in ns, not meters.

ordEdit

ordEdit edits an ORD file based on various criteria.

ordEdit

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-k	–clock-est	Remove ORDs that do not have corresponding clock estimates.
-c	–no-clock	Remove all clock offset estimate warts. Give this option twice to remove all clock data.
-m	–elev=NUM	Remove data for SVs below a given elevation mask.
-p	–PRN=NUM	Filter data by PRN number. Repeat option for multiple satellites. Negative PRN numbers mean exclude these PRNs. Positive PRN numbers mean only include these satellites. Zero removes all.
-w	–warts=NUM	Include/Exclude warts from the indicated PRN. Repeat option for multiple PRNs. Negative numbers exclude, positive numbers include, zero excludes warts from all PRNs. The default is to include all warts.

-e	–be-file=ARG	Remove data for unhealthy SVs by providing broadcast ephemeris source: RINEX nav or FIC file.
	–start=ARG	Throw out data before this time. Format as string: "yyyy ddd HH:MM:SS".
	–end=ARG	Throw out data after this time. Format as string: "yyyy ddd HH:MM:SS".
-s	–size=ARG	Remove clock residuals with absolute values greater than this size (meters).
-l	–ord-limit=ARG	Remove ords with absolute valies greater than this size (meters).
-i	–input=ARG	Where to read the ord data. The default is stdin.
-r	–output=ARG	Where to write the output. The default is stdout.
-t	–time-format=ARG	CommonTime format specifier used for times in the output. The default is "%4Y %3j %02H:%02M:%04.1f".
	–ns	Report the clock in ns, not meters.

ordGen

ordGen generates observed range deviations.

ordGen

Required Arguments

Short Arg.	Long Arg.	Description
-o	–obs=ARG	Where to get the obs data.
-e	–eph=ARG	Where to get the ephemeris data. Acceptable formats include RINEX (nav), FIC, MDP, SP3, YUMA, and SEM.

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-w	–weather=ARG	Weather data file name (RINEX met format only).
-c	–msc=ARG	Station coordinate file.
	–omode=ARG	Specifies what observations are used to compute the ORDs. Valid values are:p1p2, z1z2, c1p2, c1c2, c1y2, c1z2, y1y2, c1, p1, y1, z1, c2, p2, y2, z2, smo, dynamic, and smart. The default is smart.
	–trop-model=ARG	Specify the trop model to use. Options are zero, simple, nb, and gg. The default is nb.
-p	–pos=ARG	Location of the antenna in meters ECEF.
-m	–msid=NUM	Station to process data for. Used to select a station position from the msc file or data from a SMODF file.
-n	–near	Allows the program to select an ephemeris that is not strictly in the future. Only affects the selection of which broadcast ephemeris to use.
	–sv-time	Assume that the data is time-tagged according to each SV's clock, not a common receiver clock. The is set by default only for omode=smo.

-i	–input=ARG	Where to read the ord data. The default is stdin.
-r	–output=ARG	Where to write the output. The default is stdout.
-t	–time-format=ARG	CommonTime format specifier used for times in the output. The default is "%4Y %3j %02H:%02M:%04.1f".
	–ns	Report the clock in ns, not meters.

ordLinEst

ordLinEst computes a linear clock estimate.

ordLinEst

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-m	–max-rate=ARG	Rate used to detect a clock jump. Default is 10,000 m/day.
-i	–input=ARG	Where to read the ord data. The default is stdin.
-r	–output=ARG	Where to write the output. The default is stdout.
-t	–time-format=ARG	CommonTime format specifier used for times in the output. The default is "%4Y %3j %02H:%02M:%04.1f".
	–ns	Report the clock in ns, not meters.

ordStats

ordStats computes ORD statistics.

ordStats

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-b	–elev-bin=ARG	A range of elevations, used in computing the statistical summaries. Repeat to specify multiple bins. The default is "-b 0-10 -b 10-20 -b 20-60 -b 10-90".
-s	–sigma=NUM	Multiplier for sigma stripping used in statistical computations. The default value is 6.
-w	–wonky	Use wonky data in stats computation. The default is to not use such data.

	–stats-only	Only output stats to stdout.
-i	–input=ARG	Where to read the ord data. The default is stdin.
-r	–output=ARG	Where to write the output. The default is stdout.
-t	–time-format=ARG	CommonTime format specifier used for times in the output. The default is "%4Y %3j %02H:%02M:%04.1f".
	–ns	Report the clock in ns, not meters.

2.32.4 Double Difference Residuals

While many double differences exist, reszilla computes an the first difference to a master SV and the second difference to a second receiver. This double difference removes receiver clock error, iono, trop, and SV clock errors. When the two receivers are connected to a common antenna (often referred to as a zero-baseline setup) and are of the same type, even the multipath is differenced out. What is left is basically receiver tracking noise and receiver tracking errors.

One complicating factor in computing this DD is that while the clock errors in the receivers cancel out, there is still an error associated with the motion of the satellite during the interval between when the two receivers computing their observation. To remove this error, an estimate of the clock offset between the two receivers is need. Reszilla can get this estimate in one of two ways; estimates this by computing a clock estimate for each receiver as described under the ORD section or reading the estimates from the rinex obs data files. These two estimates are then differenced to get the offset between the two receivers.

Another complicating factor is that the phase observations normally have an "integer ambiguity" associated with them. When the DD phase observation is computed, it will have the difference between the two receivers ambiguity. Often this number can be quite big. Removing this ambiguity is often referred to as debiasing the data. This process involves much black magic and slight of hand. Do not delve into this or even look too closely at the details or you will be sullied.

2.32.5 Usage

ddGen

ddGen computes double-difference residuals from raw observations.

ddGen

Required Arguments

Short Arg.	Long Arg.	Description
-1	–obs1=ARG	Where to get the first receiver's obs data.
-2	–obs2=ARG	Where to get the second receiver's obs data.
-e	–eph=ARG	Where to get the ephemeris data. Acceptable formats include RINEX nav, FIC, MDP, SP3, YUMA, and SEM.

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
	–ddmode=ARG	Specifies what observations are used to compute the double difference residuals. Valid values are: all, phase. The default is all.
	–omode=ARG	Specifies what observations to use to compute the ORDs. Valid values are: p1p2, z1z2, c1p2, c1y2, c1z2, y1y2, c1, p1, y1, z1, c2, p2, y2, z2 smo, dynamic, and smart. The default is smart.
	–min-arc-time=ARG	The minimum length of time (in seconds) that a sequence of observations must span to be considered as an arc. The default value is 60.0 seconds.
	–min-arc-gap=ARG	The minimum length of time (in seconds) between two arcs for them to be considered separate arcs. The default value is 60.0 seconds.
	–min-arc-length=ARG	The minimum number of epochs that can be considered an arc. The default value is 5 epochs.
	–noise=ARG	The noise threshold used in finding discontinuitites. The default is 0.1000 cycles.
-b	–elev-bin=ARG	Range of elevations to use in computing the statistical summaries. Repeat to specify multiple bins. The default is "-b 0-10 -b 10-20 -b 20-60 -b 10-90".
-c	–msc=ARG	Station coordinate file.
-p	–pos=ARG	Location of the antenna in meters ECEF.
-E	–health-src=ARG	Do not use data from unhealthy SVs as determined using this ephemeris source. Can be RINEX navigation or FIC file(s).
	–strip=ARG	Factor used in stripping data prior to computing descriptive statistics. The default value is 3.2.
	–phase=ARG	Only compute phase double differences.
	-S	Only included observables with a raw signal strength, or SNR, of at least th
3 -m	–msid=NUM	Station to process data for. Used to select a station position from the msc file or data from a SMODF file.
-w	–window=NUM	Compute mean values of the double differences over this time span (seconds). (15 min = 900)
-r	–raw	Output the raw double differences in addition to the descriptive statistics.
-a	–all-combos	Compute all combinations, don't just use one master SV.
-n	–near	Allow the program to select an ephemeris that is not strictly in the future. Only affects the selection of which broadcast ephemeris to use. i.e. use a close ephemeris.
	–zero-trop	Disables trop corrections.

2.32.6 Data Input

Several different types of data are required to compute these residuals; the raw observations, the receiver antenna position, the satellite position, and optionally weather observations. The raw observations may be supplied to reszilla in one of several formats; rinex obs (see RinexObsData class), smodf (see SMODFData class), and MDP (see MDPObsEpoch class in apps/MDPtools). The reciever antenna postion may be specified in the rinex obs header or via a station coordinates file (see MSCData class).

2.32.7 Output

There are two general types of output that reszilla produces - statistical summaries and the raw residuals. The mean, standard deviation, and maximum value of the residuals are calculated as a function of specified elevation ranges and are output in a statistics table. Looking at the results for each elevation bin is useful as ORDs tend to be much a higher when satellites are lower on the horizon. For a more thorough analysis, the ORD or DD residuals calculated by reszilla may be output in a matrix format to a file with columns for time, PRN, elevation, ORD or clock residual, IODC, satellite health, and a flag for the residual type. The flag specifies exactly which of the 13 possible residual types the data on that row represent, depending on the method used for calculation.

One benefit of this output feature is that residuals can be looked at for particular time periods or PRNs. Fortunately there is a companion plotting tool that makes this simple. Given a reszilla output file, the dplot program will plot residuals and, if specified, receiver clock estimates versus time using gnuplot. A user may specify the time range, stripping value, and PRN(s) to use in the plot, as well as a filename for saving the result.

```
Types in the raw output files:
   0 - c1p2 observed range deviation
   50 - computed clock, difference from estimate, strip
   51 - linear clock estimate, abdev
Double difference types:
   10 - c1     20 - c2
   11 - p1     21 - p2
   12 - l1     22 - l2
   13 - d1     23 - d2
   14 - s1     24 - s2
```

2.32.8 Notes

The criteria min-arc-time and min-arc-length are both required to be met for a arc to be valid in double difference mode. All output quantities (stddev, min, max, ord, clock, double differnce, ...) are in meters.

2.33 *rmwcheck rnwcheck rowcheck*

2.33.1 Overview

These applications read a RINEX observation (*rowcheck*), navigation(*rnwcheck*), or meteorological (*rmwcheck*) data file and check it for errors.

2.33.2 Usage

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-l	–quit-on-first-error	Quit on the first error encountered.
-t	–time=TIME	Time of first record to count (Default = BOT).
-e	–end-time=TIME	End of time range to compare (Default = EOT).

rmwcheck usage: rmwcheck [options] <RINEX Met file>
rnwcheck usage: rnwcheck [options] <RINEX Nav file>
rowcheck usage: rowcheck [options] <RINEX Obs file>

2.33.3 Examples

```
> rnwcheck -t "08/01/2006 12:00:00" -e "08/01/2006 15:00:00" s081214a.99n

Checking s081213a.99n
Read 200 records.
```

2.33.4 Notes

Only the first error in each file is reported. The entire file is always checked regardless of time options.

2.34 *rmwdiff rnwdiff rowdiff*

2.34.1 Overview

These applications difference RINEX observation, navigation, and meteorological data files.

2.34.2 Usage

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-l	–quit-on-first-error	Quit on the first error encountered.
-t	–time=TIME	Start of time range to compare (Default = BOT)
-e	–end-time=TIME	End of time range to compare (Default = EOT)

rmwdiff usage: rmwdiff [options] <RINEX Met file> <RINEX Met file>
rnwdiff usage: rnwdiff [options] <RINEX Nav file> <RINEX Nav file>
rowdiff usage: rowdiff [options] <RINEX Obs file> <RINEX Obs file>

2.34.3 Notes

Only the first error in each file is reported. The entire file is always checked regardless of time options.

2.35 *RinexDump*

2.35.1 Overview

The application reads a RINEX file and dumps the obervation types in columns. Output is to the screen, with one time tag and one satellite per line.

2.35.2 Usage

RinexDump

Optional Arguments

Short Arg.	Long Arg.	Description
	–pos	Output only positions from aux headers; sat and obs are ignored.
-n	–num	Make output purely numeric (no header, no system char on sats).
	–format <file>	Output times in CommonTime format (Default: %4F %10.3g).
	–file <file>	RINEX observation file; this option may be repeated.
	–obs <obs>	RINEX observation type, found in file header.
	–sat <sat>	RINEX satellite ID (e.g. G31 for GPS PRN 31).
-h	–help	Print this and quit.

```
RinexDump usage: RinexDump [-n] <rinex obs file> [<satellite(s)> <obstype(s)>]

The optional argument -n tells RinexDump its output should be purely numeric.
```

2.35.3 Examples

```
> RinexDump algo1580.06o 3 4 5

# Rinexdump file: algo1580.06o Satellites: G03 G04 G05 Observations: ALL
# Week GPS_sow Sat          L1 L S          L2 L S          C1 L S
1378 259200.000 G03 -3843024.647 0 3 -2994560.443 0 1 23796436.087 0 0
1378 259230.000 G03 -3954052.735 0 3 -3081075.654 0 2 23775308.750 0 0
1378 259260.000 G03 -4064994.465 0 2 -3167523.561 0 3 23754197.617 0 0

 . . .

         P2 L S          P1 L S          S1 L S          S2 L S
23796439.457 0 0 23796436.350 0 0     21.100 0 0      11.000 0 0
23775311.168 0 0 23775308.182 0 0     22.100 0 0      17.800 0 0
23754199.648 0 0 23754196.550 0 0     17.000 0 0      18.600 0 0

 . . .
```

2.35.4 Notes

MATLAB and Octave can read the purely numeric output.

2.36 *Rinex3Dump*

2.36.1 Overview

The application reads a RINEX3 file and dumps the obervation data for the given satellite(s) to the standard output.

2.36.2 Usage

Rinex3Dump

Optional Arguments

Short Arg.	Long Arg.	Description
-f	–file <file>	Input file is a RINEX observation file. This option may be repeated. Optional, but may be needed in case of ambiguity.
	–format <format>	The format of the time output. Default is %4F %10.3g.
-h	–help	Prints out this help and exits.
-n	–num	Make output purely numeric, ie. no header, no system char on satellites.
-o	–obs <obs>	RINEX observation type (eg. C1C) found in the file header. Optional, but may be needed in case of ambiguity.
-p	–pos	Only output positions from aux headers, ie. sat and obs are ignored.
-s	–sat <sat>	RINEX satellite ID (eg. For GPS PRN 31, <sat> = G01). Optional, but may be needed in case of ambiguity.
-v	–verbose	Prints out verbose output.

```
Rinex3Dump usage: Rinex3Dump [-n] <rinex obs file> [<satellite(s)> <obstype(s)>]

The optional argument -n tells Rinex3Dump its output should be purely numeric.
```

2.36.3 Notes

MATLAB and Octave can read the purely numeric output.

2.37 *rinexpvt*

2.37.1 Overview

The application generates a user position based on RINEX observation data with the option of including navigation and meteorological data to aid error correction.

2.37.2 Usage

rinexpvt

Required Arguments

Short Arg.	Long Arg.	Description
-o	–obs-file=ARG	RINEX obs file.

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-n	–nav-file=ARG	RINEX Nav file. Required for single frequency ionosphere correction.
-p	–pe-file=ARG	SP3 Precise Ephemeris File. Repeat this for each input file.
-m	–met-file=ARG	RINEX Met File.
-t	–time-format=ARG	Alternate time format string.
-e	–enu=ARG	Use the following as origin to solve for East/North/Up coordinates, formatted as a string: ”X Y Z”.
-l	–elevation-mask=ARG	Elevation mask (degrees).
-g	–logfile=ARG	Write logfile to this file.
-r	–rate=ARG	Observation interval (Default = 30 seconds or Rinex Header specification).
-y	-yuma=ARG	Yuma almanac file.
-a	–sem=ARG	SEM almanac file.
-s	–single-frequency	Use only C1 (SPS).
-f	–dual-frequency	Use only P1 and P2 (PPS)
-i	–no-ionosphere	Do NOT correct for ionosphere delay.
-x	–no-closest-ephemeris	Allow ephemeris use outside of fit interval.
-c	–no-carrier-smoothing	Do NOT use carrier phase smoothing.
-z	–no-glonass	Exclude GLONASS Satellites from PVT solution.

2.37.3 Examples

```
> rinexpvt -o arl2800.06o -n arl2800.06n
2006 1 1 09 41 00 918130.968492 -4346073.94224 4561982.02123 333.303358692
2006 1 1 09 41 30 918130.956684 -4346073.91529 4561982.01659 333.317002144
2006 1 1 09 42 00 918130.924146 -4346073.83279 4561982.01338 333.279239604
```

2.37.4 Notes

Though not stated in the required options lists, either a RINEX navigation file or an SP3 Precise Ephemeris File is needed, using the -n or -p option respectively. When using precise ephemeris, three files must be included: the previous day, the current day and the next day.

Although -z argument appears as optional, in this release, it is always turned on, but implementation will occur in a later release.

2.38 *RinSum*

2.38.1 Overview

The application reads a RINEX file and summarizes it content.

2.38.2 Usage

RinSum

Optional Arguments

Short Arg.	Long Arg.	Description
-i	–input	Input file name(s).
-f		File containing more options.
-o	–output	Output file name.
-p	–path	Path for input file(s).
-R	–Replace	Replace header with full one.
-s	–sort	Sort the PRN/Obs table on begin time.
-g	–gps	Print times in the PRN/Obs table as GPS times.
	–gaps	Print a table of gaps in the data, assuming specified interval dt.
	–start	Start time: <time> is 'GPSweek,sow' OR 'YYYY,MM,DD,HH,Min,Sec'.
	–stop	Stop time: <time> is 'GPSweek,sow' OR 'YYYY,MM,DD,HH,Min,Sec'.
-b	–brief	Produce a brief (6-line) summary.
-h	–help	Print syntax and quit.
-d	–debug	Print debugging information.

2.38.3 Examples

```
> RinSum -i data_set/s081213a.99o --EpochBeg 2006,08,1,12,0,0'

++++++++++++++ RinSum summary of Rinex obs file data_set/s081213a.99o ++++++++++++++
Rinex header:
---------------------------------- REQUIRED ----------------------------------
Rinex Version 2.10, File type Observation, System G (GPS).
Prgm: RinexObsWriter, Run: 11-14-01 10:04:27, By: NIMA
Marker name: 85408.
Obs'r : Monitor Station, Agency: NIMA
Rec#: 1, Type: ZY12, Vers:
Antenna # : 85408, Type : AshTech Geodetic 3
Position (XYZ,m) : (-740289.7851, -5457071.6555, 3207245.8294).
Antenna offset (ENU,m) : (0.0000, 0.0000, 0.0000).
Wavelength factors (default) L1:1, L2: 1.
Observation types (7) :
 Type #0 = L1 L1 Carrier Phase (L1 cycles).
 Type #1 = L2 L2 Carrier Phase (L2 cycles).
 Type #2 = C1 C/A-code pseudorange (meters).
 Type #3 = P1 Pcode L1 pseudorange (meters).
 Type #4 = P2 Pcode L2 pseudorange (meters).
 Type #5 = D1 Doppler Frequency L1 (Hz).
 Type #6 = D2 Doppler Frequency L2 (Hz).
```

```
Time of first obs 1999/08/01 00:00:00.0000000 GPS
(This header is VALID 2.1 Rinex.)
--------------------------------- OPTIONAL ----------------------------------
Comments (3) :
The AS bit flag is set if receiver is in Z mode
Signal to Noise ratio information is omitted
This file contains SMOOTHED obs data
------------------------------- END OF HEADER -------------------------------

 WARNING: Computed first time does not agree with header

 Computed interval is 0.00
 Computed first epoch is -4713/01/01 00:00:00.0000000
 Computed last epoch is 1999/08/01 23:59:30.0000000
 There were 0 epochs (-0.00% of -2147483647 possible epochs in this timespan) and 0 inline header blocks.

         Summary of data available in this file: (Totals are based on times and interval)
PRN/OT:    L1    L2    C1    P1    P2    D1    D2 Total Begin - End time
TOTAL       0     0     0     0     0     0     0

 WARNING: ObsType L1 should be deleted from header.

 WARNING: ObsType L2 should be deleted from header.

 WARNING: ObsType C1 should be deleted from header.

 WARNING: ObsType P1 should be deleted from header.

 WARNING: ObsType P2 should be deleted from header.

 WARNING: ObsType D1 should be deleted from header.

 WARNING: ObsType D2 should be deleted from header.

++++++++++++++ End of RinSum summary of data_set/s081213a.99o ++++++++++++++
```

2.39 *Rin3Sum*

2.39.1 Overview

The application reads a RINEX3 file and summarizes it content.

2.39.2 Usage

Rin3Sum

Optional Arguments

Short Arg.	Long Arg.	Description
-i	–input	Input file name(s).
-f		file containing more options.
-o	–output	Output file name.
-p	–path	Path for input file(s).
-R	–Replace	Replace header with full one.
-s	–sort	Sort the PRN/Obs table on begin time.
-g	–gps	Print times in the PRN/Obs table as GPS times.
	–EpochBeg	Start time, arg is of the form YYYY,MM,DD,HH,Min,Sec
	–GPSBeg	Start time, arg is of the form GPSweek,GPSsow
	–EpochEnd	End time, arg is of the form YYYY,MM,DD,HH,Min,Sec
	–GPSEnd	End time, arg is of the form GPSweek,GPSsow
-h	–help	Print syntax and quit.
-d	–debug	Print debugging info.

2.40 *rtAshtech*

2.40.1 Overview

This application logs observations from an Ashtech Z-XII receiver. It records observations directly into the RINEX format. A number of optional outputs are possible. The raw messages from a receiver can be recorded. Observations can also be recorded in a format that is easily imported into numerical packages.

2.40.2 Usage

rtAshtech

Optional Arguments

Short Arg.	Long Arg.	Description
-h	–help	Print help usage.
-v	–verbose	Increased diagnostic messages.
-r	–raw	Record raw observations.
-l	–log	Record log entries.
-t	–text	Record observations as simple text files.
-o	–rinex-obs=ARG	Naming convention for RINEX obs files.
-n	–rinex-nav=ARG	Naming convention for RINEX nav message files.
-T	–text-obs=ARG	Naming convention for obs in simple text files.
-i	–input	Where to read ashTech data. Can be a file or a serial device (ser:/dev/ttyS0), a tcp port (tcp:hostname:port), or standard input (the default).

2.40.3 Examples

```
> rtAshtech -p /dev/ttyS1
```

```
> rtAshtech -o "minute\%03j\%02H\%02M.\%02yo"
```

2.40.4 Notes

rtAshtech only works on UNIX systems with POSIX compliant serial ports.

2.41 *sp3version*

2.41.1 Overview

This application reads an SP3 file (either a or c format) and writes it to another file (also either in a or c format).

2.41.2 Usage

sp3version

Optional Arguments

Short Arg.	Long Arg.	Description
	–in	A file from which to take the input. The default is stdin.
	–out	A file into which to write the output. The default is sp3.out.
	–outputC	Output version c (otherwise a).
	–msg	Add message as a comment to the output header.
	–verbose	Output to screen: dump headers, data, etc.

2.42 *svvis*

2.42.1 Overview

This application computes when satellites are visible at a given point on the earth.

2.42.2 Usage

svvis

Required Arguments

Short Arg.	Long Arg.	Description
-e	–eph=ARG	Where to get the ephemeris data. Can be RINEX, nav, FIC, MDP, SP3, YUMA, and SEM.

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
	–elevation-mask=ARG	The elevation above which an SV is visible. The default is 0 degrees.
-p	–position=ARG	Receiver antenna position in ECEF (x,y,z) coordinates. Format as string: "X Y Z".
-c	–msc=ARG	Station coordinate file.
-m	–msid=ARG	Station number to use from the msc file.
	–graph-elev=ARG	Output data at the specified interval. Interval is in seconds.
-l	–time-span=ARG	How much data to process, in seconds. Default is 86400.
	–start-time=TIME	When to start computing positions. The default is the start of the ephemeris data.
	–stop-time=TIME	When to stop computing positions. The default is one day after the start time.
	–print-elev	Print the elevation of the sv at each change in tracking. The default is just to ouput the PRN of the sv.
	–rise-set	Print the visibility data by PRN in rise-set pairs.
	–tabular	Print the visibility data in a tabular format.
	–recent-eph	Use this if the ephemeris data provided uses 10-bit GPS weeks and it should be converted to the current epoch or to the epoch current to the "start-time", if specified.

2.43 *TECMaps*

2.43.1 Overview

Program TECMaps reads RINEX data files containing extended RINEX observation types EL, AZ and SR or VR from several sites and at each epoch fits the vertical TEC data to a model of the ionosphere on a two-dimensional grid surface. Hardware TEC measurement biases are corrected, using input from the program IonoBias. The user can specify the type of grid, the type of TEC data and the model to be used. Output is in the form of files, one per epoch, which can be used to plot the 2D ionospheric TEC surface.

2.43.2 Usage

TECMaps

Required Arguments

Short Arg.	Long Arg.	Description
	–input	Input RINEX obs file name(s).

Optional Arguments

Short Arg.	Long Arg.	Description
-f		File containing more options.

Reference Station Position (One Required)

Short Arg.	Long Arg.	Description
	–RxLLH <l,l,h>	Reference site position in geodetic lat, lon (E), ht (deg,deg,m).
	–RxXYZ <x,y,z>	Reference site position in ECEF coordinates (m).
	–inputdir	Path for input file(s).

Ephemeris Input

Short Arg.	Long Arg.	Description
	–navdir	Path of navigation file(s).
	–nav	Navigation (RINEX navigation OR SP3) file(s).

Output

Short Arg.	Long Arg.	Description
	–log	Output log file name.

Time Limits

Short Arg.	Long Arg.	Description
	–BeginTime	Start time, arg is of the form YYYY,MM,DD,HH,Min,Sec.
	–BeginGPSTime	Start time, arg is of the form GPSweek,GPSsow.
	–EndTime	End time, arg is of the form YYYY,MM,DD,HH,Min,Sec.
	–EndGPSTime	End time, arg is of the form GPSweek,GPSsow.

Processing

Short Arg.	Long Arg.	Description
	–noVTECmap	Do NOT create the VTEC map.
	–MUFmap	Create MUF map as well as VTEC map.
	–F0F2map	Create F0F2 map as well as VTEC map.

	–Title1 <title>	Title information.
	–Title2 <title>	Second title information.
	–BaseName <name>	Base name for output files.
	–DecorrError <de>	Decorrelation error rate in TECU/1000km (3).
	–Biases <file>	File containing estimated sat+rx biases (Prgm IonoBias).
	–ElevThresh <ele>	Minimum elevation (6 degrees).
	–MinAcqTime<t>	Minimum acquisition time (0 seconds).
	–FlatFit	Flat fit type (default).
	–LinearFit	Linear fit type.
	–IonoHeight <n>	Ionosphere height (km).
	–Offset <tec>	Overall bias to add to data (TECU).

Grid

Short Arg.	Long Arg.	Description
	–UniformSpacing	Grid uniform in space (XYZ) (default).
	–UniformGrid	Grid uniform in Lat and Lon.
	–OutputGrid	Output the grid to file <basename.LL>.
	–GnuplotOutput	Write the grid file for gnuplot (default: for Matlab).
	–NumLat <n>	Number of latitude grid points (40).
	–NumLon <n>	Number of longitude grid points (40)
	–BeginLat <lat>	Beginning latitude (21 degrees).
	–BeginLon <lon>	Beginning longitude (230 degrees E).
	–DeltaLat <del>	Grid spacing in latitude (0.25 degrees).
	–DeltaLon <del>	Grid spacing in longitude (1.0 degrees).

Other Options

Short Arg.	Long Arg.	Description
	–XSat	Exclude this satellite (<sat> may be <system> only).

Help

Short Arg.	Long Arg.	Description
-v	–verbose	Print extended output info.
-d	–debug	Increase debug level.
-h	–help	Print syntax and summary of input, then quit.

2.43.3 Notes

Input is on the command line, or of the same format in a file (-f<file>).

2.44 *timeconvert*

2.44.1 Overview

This application allows the user to convert between time formats associated with GPS. Time formats include: civilian time, Julian day of year and year, GPS week and seconds of week, Z counts, and Modified Julian Date (MJD).

2.44.2 Usage

timeconvert

Optional Arguments

Short Arg.	Long Arg.	Description
-d	–debug	Increase debug level.
-v	–verbose	Increase verbosity.
-h	–help	Print help usage.
-A	–ansi=TIME	“ANSI-Second”.
-c	–civil=TIME	“Month(numeric) DayOfMonth Year Hour:Minute:Second
-R	–rinex-file=TIME	“Year(2-digit) Month(numeric) DayOfMonth Hour Minute Second”.
-o	–ews=TIME	“GPSEpoch 10bitGPSweek SecondOfWeek”.
-f	–ws=TIME	“FullGPSWeek SecondOfWeek”.
-w	–wz=TIME	“FullGPSWeek Zcount”.
	–z29=TIME	“29bitZcount”.
-Z	–z32=TIME	“32bitZcount”.
-j	–julian=TIME	“JulianDate”.
-m	–mjd=TIME	“ModifiedJulianDate”.
-u	–unixtime=TIME	“UnixSeconds UnixMicroseconds”.
-y	–doy=TIME	“Year DayOfYear SecondsOfDay”.
	–input-format=ARG	Time format to use on input.
	–input-time=ARG	Time to be parsed by ”input-format” option.
-F	–format=ARG	Time format to use on output.
-a	–add-offset=NUM	Add NUM seconds to specified time.
-s	–sub-offset=NUM	Subtract NUM seconds from specified time.

2.44.3 Examples

Convert RINEX file time.

```
> timeconvert -R "05 06 1985 13:50:02"

        Month/Day/Year H:M:S            11/06/2010 13:00:00
        Modified Julian Date            55506.541666667
        GPSweek DayOfWeek SecOfWeek     584 6  565200.000000
        FullGPSweek Zcount              1608 376800
        Year DayOfYear SecondOfDay      2010 310  46800.000000
        Unix: Second Microsecond        1289048400      0
        Zcount: 29-bit (32-bit)         306560992 (843431904)
```

Convert ews time.

```
timeconvert -o "01 1379 500"
```

```
Month/Day/Year                  1/25/2026
Hour:Min:Sec                    00:08:20
Modified Julian Date            61065.005787037
GPSweek DayOfWeek SecOfWeek     355 0 500.000000
FullGPSweek Zcount              2403 333
Year DayOfYear SecondOfDay      2026 25 500.000000
Unix_sec Unix_usec              1769299700 0
Zcount: 29-bit (32-bit)         186122573 (1259864397)
```

2.44.4 Notes

If no arguments are given it will convert the current time to all formats. When inputting time values, include quotation marks.

2.45 *vecsol*

2.45.1 Overview

The application computes a 3D vector solution using dual-frequency carrier phases. A double difference algorithm is applied with properly computed weights (elevation sine weighting) and correlations. The program iterates to convergence and attempts to resolve ambiguities to integer values if close enough. Crude outlier rejection is provided based on a triple-difference test. Ephemerides used are either broadcast or precise (SP3).

Alternatively, P code processing is additionally provided. The solution is computed using either the ionosphere-free linear combination, or the average of L1 and L2. The ionospheric model included in broadcast ephemeris may be used. A standard tropospheric correction is applied, or tropospheric parameters (zenith delays) may be estimated for the first station (vector mode) or both.

2.45.2 Usage

vecsol usage: vecsol <RINEX Obs file 1> <RINEX Obs file 2>

RINEX Observation Files

The two arguments are names of RINEX observation files. They contain the observations collected at the two end points 1 and 2 of the baseline. They must contain a sufficient set of simultaneous observations to the same satellites.

If no separate station coordinate files are provided, the initial station coordinates are taken from the RINEX headers. Upon finishing, vecsol creates or updates the coordinate file of the first station (vector mode) or both.

Configuration File vecsol.conf

The file vecsol.conf contains the input options for the program, one per line.

Options	Value	Meaning
obsMode	3/2/1/0	If 1 or 3, process carrier phase data (instead of P code data). If 0 or 1, iterate on ionosphere-free vector (not L1 + L2).
truecov	1/0	If 1, use true double difference covariances. If 0, ignore any possible correlations.
precise	1/0	If 1, use precise ephemeris, if 0, use broadcast ephemeris.
iono	1/0	If 1, use the 8-parameter ionospheric model that comes with the broadcast ephemeris (.nav) files.
tropo	1/0	If 1, estimate troposphere parameters (zenith delays relative to the standard value, which is always applied).
vecmode	1/0	If 1, solve the vector, i.e. the three coordinate differences between the baseline end points. If 0, solve for the absolute co-ordinates of both end points.
debug	1/0	If 1, produce lots of gory debugging output. See the source for what it all means.

refsat elev	number	Minimum elevation (degs) of the reference satellite used for computing inter-satellite differences. Good initial choice: 30.0.
cutoff elev	number	Cut-off elevation (degs). Good initial choice: 10.0 - 20.0.
rej TP, rej TC	two numbers	Phase, code triple differences rejection limit (m).
reduce	1/0	Apply post-reduction to combine dependent unknowns.

Ephemeris File Lists

The file vecsol.nav contains the names of the navigation RINEX files ("nav files", extension). Good navigation RINEX files that are globally valid can be found from the CORS website at http://www.ngs.noaa.gov/CORS/.

The file vecsol.eph contains the names of the precise ephemeris SP3 files (extension .sp3) to be used. These should cover the time span of the observations, with time to spare on both ends. Note that the date in the filenames of the SP3 files is given as GPS week + weekday, not year + day of year, as in the observation and nav files.

In the .nav and .eph files, comment lines have # in the first position.

2.45.3 Notes

Currently, vecsol does not recover from cycle slips, so the RINEX observation files used have to be fairly clean.

2.46 *WhereSat*

2.46.1 Overview

This application uses input ephemeris to compute the predicted location of a satellite. The Earth-centered, Earth-fixed (ECEF) position of the satellite is reported. Optionally, the topocentric coordinates–azimuth, elevation, and range–can be generated. The user can specify the time interval between successive predictions. Also the output can generated in a format easily imported into numerical packages.

2.46.2 Usage

WhereSat

Required Arguments

Short Arg.	Long Arg.	Description
-e	–eph-files=ARG	Ephemeris source file(s). Can be RINEX nav, SP3, or FIC.

Optional Arguments

Short Arg.	Long Arg.	Description
-h	–help	Print help usage.
-u	–position=ARG	Antenna position in ECEF (x,y,z) coordinates. Format as string: “X Y Z”. used to give user-centered data (SV range, azimuth, and elevation) when SV is in view.
	–start=ARG	Ignore data before this time. Format as string: “MO/DD/YYYY HH:MM:SS”.
	–end=ARG	Ignore data after this time. Format as string: “MO/DD/YYYY HH:MM:SS”.
-f	–time-format=ARG	CommonTime format specifier used for times in the output. The default is “%4Y %3j %02H:%02M:%4.1f”.
-p	–prn=NUM	Which SVs to analyze. Repeat option for multiple satellites. If this option is not specified, all ephemeris data will be processed.
-t	–time=NUM	Time increment in seconds for ephemeris calculation. Default is 900 seconds (15 minutes).

2.46.3 Examples

```
> WhereSat -b aira1720.06n -p 2 -u "918129.01 -4346070.45 803.18"
  -s "06/21/2006 17:00:00" -e "06/21/2006 20:00:00" -t 1800

Antenna Position: 918129 -4.34607e+06 803.18
Navigation File: aira1720.06n
Start Time:      06/21/2006 17:00:00
End Time:        06/21/2006 20:00:00
PRN:             2

Prn 2 Earth-fixed position and clock information:

Date      Time(UTC)  X (meters)        Y (meters)        Z (meters)
```

```
================================================================================
06/21/2006 18:00:00 12758891.971859   18901201.616227    -14049016.596144
06/21/2006 18:30:00 12847888.097031   21541501.416411    -9315422.851798
06/21/2006 19:00:00 12843576.989405   23087218.618683    -3957280.515764
06/21/2006 19:30:00 12450313.769289   23516935.034029    1667186.089065

 . . .

   Clock Correc (s)
==================
    0.000007
    0.000007
    0.000007
    0.000007



Data for user reference frame:

Date      Time(UTC)  Azimuth       Elevation     Range to SV (m)
=====================================================================
06/21/2006 18:00:00 130.596202   -43.242769     29627531.177821
06/21/2006 18:30:00 118.680085   -49.681012     29983796.522429
06/21/2006 19:00:00 102.845663   -53.888528     30169796.433699
06/21/2006 19:30:00 84.400419    -55.459042     30197072.648367

Calculated 4 increments for prn 2 .
```