libDaisy

Generated by Doxygen 1.8.13

## **Contents**

1	libda	aisy	1
	1.1	Using libdaisy	1
		1.1.1 daisy.h	2
		1.1.2 daisy_seed.h	2
		1.1.3 daisy_platform.h	2
2	Mod	dule Index	3
	2.1	Modules	3
3	Clas	ss Index	5
	3.1	Class List	5
4	File	Index	7
	4.1	File List	7
5	Mod	dule Documentation	9
	5.1	LIBDAISY	9
		5.1.1 Detailed Description	9
	5.2	HUMAN_INTERFACE	10
		5.2.1 Detailed Description	10
	5.3	AUDIO	11
		5.3.1 Detailed Description	11
	5.4	CONTROLS	12
		5.4.1 Detailed Description	12
	5.5	PERIPHERALS	13

ii CONTENTS

5.6	USBD	_CDC_IF
	5.6.1	Detailed Description
5.7	USBD	_CDC_IF_Exported_Defines
5.8	USBD_	_CDC_IF_Exported_Types
	5.8.1	Detailed Description
	5.8.2	Typedef Documentation
		5.8.2.1 CDC_ReceiveCallback
5.9	USBD_	_CDC_IF_Exported_Macros
5.10	USBD_	_CDC_IF_Exported_Variables
	5.10.1	Detailed Description
	5.10.2	Variable Documentation
		5.10.2.1 USBD_Interface_fops_FS
		5.10.2.2 USBD_Interface_fops_HS
5.11	USBD_	_CDC_IF_Exported_FunctionsPrototype
	5.11.1	Detailed Description
	5.11.2	Function Documentation
		5.11.2.1 CDC_Set_Rx_Callback_FS()
		5.11.2.2 CDC_Transmit_FS()
		5.11.2.3 CDC_Transmit_HS()
5.12	USBD	_CONF
	5.12.1	Detailed Description
5.13	USBD	_CONF_Exported_Variables
5.14	USBD_	_CONF_Exported_Defines
	5.14.1	Detailed Description
	5.14.2	Macro Definition Documentation
		5.14.2.1 DEVICE_FS
		5.14.2.2 DEVICE_HS
		5.14.2.3 USBD_DEBUG_LEVEL
		5.14.2.4 USBD_LPM_ENABLED
		5.14.2.5 USBD_MAX_NUM_CONFIGURATION

5.14.2.6 USBD_MAX_NUM_INTERFACES	23
5.14.2.7 USBD_MAX_STR_DESC_SIZ	23
5.14.2.8 USBD_SELF_POWERED	23
5.14.2.9 USBD_SUPPORT_USER_STRING	23
5.15 USBD_CONF_Exported_Macros	24
5.15.1 Detailed Description	24
5.15.2 Macro Definition Documentation	24
5.15.2.1 USBD_DbgLog	24
5.15.2.2 USBD_Delay	24
5.15.2.3 USBD_ErrLog	25
5.15.2.4 USBD_free	25
5.15.2.5 USBD_malloc	25
5.15.2.6 USBD_memcpy	25
5.15.2.7 USBD_memset	25
5.15.2.8 USBD_UsrLog	25
5.16 USBD_CONF_Exported_Types	26
5.17 USBD_CONF_Exported_FunctionsPrototype	27
5.18 USBD_DESC	28
5.18.1 Detailed Description	28
5.19 USBD_DESC_Exported_Constants	29
5.19.1 Detailed Description	29
5.19.2 Macro Definition Documentation	29
5.19.2.1 DEVICE_ID1	29
5.19.2.2 DEVICE_ID2	29
5.19.2.3 DEVICE_ID3	29
5.19.2.4 USB_SIZ_STRING_SERIAL	29
5.20 USBD_DESC_Exported_Defines	30
5.21 USBD_DESC_Exported_TypesDefinitions	31
5.22 USBD_DESC_Exported_Macros	32
5.23 USBD_DESC_Exported_Variables	33
5.23.1 Detailed Description	33
5.23.2 Variable Documentation	33
5.23.2.1 FS_Desc	33
5.23.2.2 HS_Desc	33
5.24 USBD_DESC_Exported_FunctionsPrototype	34
5.25 STM32_USB_OTG_DEVICE_LIBRARY	35
5.25.1 Detailed Description	35
5.26 USBD_OTG_DRIVER	36
5.26.1 Detailed Description	36

iv CONTENTS

6	Clas	s Docu	mentation	37
	6.1	daisy::	AdcChannelConfig Struct Reference	37
		6.1.1	Detailed Description	37
		6.1.2	Member Enumeration Documentation	37
			6.1.2.1 MuxPin	37
		6.1.3	Member Function Documentation	38
			6.1.3.1 InitMux()	38
			6.1.3.2 InitSingle()	38
		6.1.4	Member Data Documentation	39
			6.1.4.1 mux_channels	39
			6.1.4.2 mux_pin	39
			6.1.4.3 pin	39
	6.2	daisy::	AdcHandle Class Reference	39
		6.2.1	Detailed Description	40
		6.2.2	Member Enumeration Documentation	40
			6.2.2.1 OverSampling	40
		6.2.3	Member Function Documentation	40
			6.2.3.1 Get()	40
			6.2.3.2 GetFloat()	41
			6.2.3.3 GetMux()	41
			6.2.3.4 GetMuxFloat()	41
			6.2.3.5 GetMuxPtr()	42
			6.2.3.6 GetPtr()	42
			6.2.3.7 Init()	43
			6.2.3.8 Start()	43
			6.2.3.9 Stop()	43
	6.3	daisy::	AnalogControl Class Reference	43
		6.3.1	Detailed Description	44
		6.3.2	Constructor & Destructor Documentation	44
			6.3.2.1 AnalogControl()	44

		6.3.2.2 ~AnalogControl()	 44
	6.3.3	Member Function Documentation	 44
		6.3.3.1 Init()	 44
		6.3.3.2 InitBipolarCv()	 45
		6.3.3.3 Process()	 45
		6.3.3.4 Value()	 45
6.4	codec_	_frame_t Struct Reference	 45
	6.4.1	Detailed Description	 46
	6.4.2	Member Data Documentation	 46
		6.4.2.1 I	 46
		6.4.2.2 r	 46
6.5	color S	Struct Reference	 46
	6.5.1	Detailed Description	 46
	6.5.2	Member Data Documentation	 47
		6.5.2.1 blue	 47
		6.5.2.2 green	 47
		6.5.2.3 red	 47
6.6	daisy::	Color Class Reference	 47
	6.6.1	Detailed Description	 48
	6.6.2	Member Enumeration Documentation	 48
		6.6.2.1 PresetColor	 48
	6.6.3	Member Function Documentation	 48
		6.6.3.1 Blue()	 48
		6.6.3.2 Green()	 48
		6.6.3.3 Init() [1/2]	 48
		6.6.3.4 Init() [2/2]	 49
		6.6.3.5 Red()	 49
6.7	daisy::	ControlChangeEvent Struct Reference	 49
	6.7.1	Detailed Description	 49
	6.7.2	Member Data Documentation	 50

vi

		6.7.2.1	channel	. 50
		6.7.2.2	control_number	. 50
		6.7.2.3	value	. 50
6.8	daisy::	daisy_field	d Struct Reference	. 50
	6.8.1	Detailed	Description	. 50
	6.8.2	Member	Data Documentation	. 51
		6.8.2.1	cvs	. 51
		6.8.2.2	gate_in	. 51
		6.8.2.3	gate_out	. 51
		6.8.2.4	keyboard_sr	. 51
		6.8.2.5	knobs	. 51
		6.8.2.6	seed	. 51
		6.8.2.7	switches	. 51
6.9	daisy::	DaisyPatc	ch Class Reference	. 52
	6.9.1	Detailed	Description	. 52
	6.9.2	Member	Enumeration Documentation	. 53
		6.9.2.1	Ctrl	. 53
		6.9.2.2	GateInput	. 53
	6.9.3	Construc	ctor & Destructor Documentation	. 53
		6.9.3.1	DaisyPatch()	. 53
		6.9.3.2	~DaisyPatch()	. 53
	6.9.4	Member	Function Documentation	. 53
		6.9.4.1	AudioBlockSize()	. 53
		6.9.4.2	AudioCallbackRate()	. 54
		6.9.4.3	AudioSampleRate()	. 54
		6.9.4.4	ChangeAudioCallback()	. 54
		6.9.4.5	DebounceControls()	. 54
		6.9.4.6	DelayMs()	. 54
		6.9.4.7	DisplayControls()	. 54
		6.9.4.8	GetCtrlValue()	. 55

CONTENTS vii

		6.9.4.9	Init()	55
		6.9.4.10	SetAudioBlockSize()	55
		6.9.4.11	StartAdc()	55
		6.9.4.12	StartAudio()	55
		6.9.4.13	UpdateAnalogControls()	56
	6.9.5	Member	Data Documentation	56
		6.9.5.1	controls	56
		6.9.5.2	display	56
		6.9.5.3	encoder	56
		6.9.5.4	gate_input	56
		6.9.5.5	gate_output	56
		6.9.5.6	midi	57
		6.9.5.7	seed	57
6.10	daisy::I	DaisyPetal	Class Reference	57
	6.10.1	Detailed	Description	58
	6.10.2	Member	Enumeration Documentation	58
		6.10.2.1	FootswitchLed	58
		6.10.2.2	Knob	58
		6.10.2.3	RingLed	59
		6.10.2.4	Sw	59
	6.10.3	Construc	tor & Destructor Documentation	59
		6.10.3.1	DaisyPetal()	59
		6.10.3.2	~DaisyPetal()	60
	6.10.4	Member	Function Documentation	60
		6.10.4.1	AudioBlockSize()	60
		6.10.4.2	AudioCallbackRate()	60
		6.10.4.3	AudioSampleRate()	60
		6.10.4.4	ChangeAudioCallback()	60
		6.10.4.5	ClearLeds()	60
		6.10.4.6	DebounceControls()	61

viii CONTENTS

		6.10.4.7	DelayMs()	 61
		6.10.4.8	GetExpression()	 61
		6.10.4.9	GetKnobValue()	 61
		6.10.4.10	Init()	 61
		6.10.4.11	SetAudioBlockSize()	 62
		6.10.4.12	SetFootswitchLed()	 62
		6.10.4.13	SetRingLed()	 62
		6.10.4.14	StartAdc()	 63
		6.10.4.15	StartAudio()	 63
		6.10.4.16	UpdateAnalogControls()	 63
		6.10.4.17	UpdateLeds()	 63
	6.10.5	Member D	Data Documentation	 63
		6.10.5.1	encoder	 63
		6.10.5.2	expression	 63
		6.10.5.3	footswitch_led	 64
		6.10.5.4	knob	 64
		6.10.5.5	ring_led	 64
		6.10.5.6	seed	 64
		6.10.5.7	switches	 64
6.11	daisy::[	DaisyPod C	Class Reference	 64
	6.11.1	Detailed D	Description	 65
	6.11.2	Member E	Enumeration Documentation	 65
		6.11.2.1	Knob	 65
		6.11.2.2	Sw	 66
	6.11.3	Member F	Function Documentation	 66
		6.11.3.1	AudioBlockSize()	 66
		6.11.3.2	AudioCallbackRate()	 66
		6.11.3.3	AudioSampleRate()	 66
		6.11.3.4	ChangeAudioCallback()	 66
		6.11.3.5	ClearLeds()	 67

		6.11.3.6	DebounceControls()	 67
		6.11.3.7	DelayMs()	 67
		6.11.3.8	GetKnobValue()	 67
		6.11.3.9	Init()	 67
		6.11.3.10	SetAudioBlockSize()	 67
		6.11.3.11	StartAdc()	 68
		6.11.3.12	StartAudio()	 68
		6.11.3.13	UpdateAnalogControls()	 68
		6.11.3.14	UpdateLeds()	 68
	6.11.4	Member D	Data Documentation	 68
		6.11.4.1	button1	 68
		6.11.4.2	button2	 69
		6.11.4.3	buttons	 69
		6.11.4.4	encoder	 69
		6.11.4.5	knob1	 69
		6.11.4.6	knob2	 69
		6.11.4.7	knobs	 69
		6.11.4.8	led1	 69
		6.11.4.9	led2	 69
		6.11.4.10	seed	 70
6.12	daisy::[	DaisySeed	Class Reference	 70
	6.12.1	Detailed D	Description	 70
	6.12.2	Member F	Function Documentation	 70
		6.12.2.1	AudioSampleRate()	 71
		6.12.2.2	Configure()	 71
		6.12.2.3	GetPin()	 71
		6.12.2.4	Init()	 71
		6.12.2.5	SetAudioBlockSize()	 71
		6.12.2.6	SetLed()	 71
		6.12.2.7	SetTestPoint()	 72

	6.12.2.8	StartAudio()		 	 	 	 	 . 72
6.12	2.3 Member	Data Documen	tation	 	 	 	 	 . 72
	6.12.3.1	adc		 	 	 	 	 . 72
	6.12.3.2	audio_handle		 	 	 	 	 . 72
	6.12.3.3	dac_handle .		 	 	 	 	 . 72
	6.12.3.4	i2c1_handle		 	 	 	 	 . 72
	6.12.3.5	i2c2_handle		 	 	 	 	 . 73
	6.12.3.6	qspi_handle		 	 	 	 	 . 73
	6.12.3.7	sai_handle .		 	 	 	 	 . 73
	6.12.3.8	sdram_handle	э	 	 	 	 	 . 73
	6.12.3.9	usb_handle .		 	 	 	 	 . 73
6.13 dsy	_audio_hand	le Struct Refere	ence	 	 	 	 	 . 73
6.13	3.1 Detailed	Description .		 	 	 	 	 . 74
6.13	3.2 Member	Data Documen	tation	 	 	 	 	 . 74
	6.13.2.1	block_size .		 	 	 	 	 . 74
	6.13.2.2	dev0_i2c		 	 	 	 	 . 74
	6.13.2.3	dev1_i2c		 	 	 	 	 . 74
	6.13.2.4	sai		 	 	 	 	 . 74
6.14 dsy	_dac_handle	Struct Referen	ce	 	 	 	 	 . 74
6.14	4.1 Detailed	Description .		 	 	 	 	 . 75
6.14	4.2 Member	Data Documen	tation	 	 	 	 	 . 75
	6.14.2.1	bitdepth		 	 	 	 	 . 75
	6.14.2.2	mode		 	 	 	 	 . 75
	6.14.2.3	pin_config .		 	 	 	 	 . 75
6.15 dsy	_gpio Struct	Reference		 	 	 	 	 . 75
6.18	5.1 Detailed	Description .		 	 	 	 	 . 75
6.15	5.2 Member	Data Documen	tation	 	 	 	 	 . 76
	6.15.2.1	mode		 	 	 	 	 . 76
	6.15.2.2	pin		 	 	 	 	 . 76
	6.15.2.3	pull		 	 	 	 	 . 76

CONTENTS xi

6.16	dsy_gp	io_pin Str	ruct	Refere	ence					 	 		 	 		 	 76
	6.16.1	Detailed	Des	criptic	n .					 	 		 	 		 	 76
	6.16.2	Member	Dat	a Doc	umer	ntatio	on .			 	 		 	 		 	 76
		6.16.2.1	pir	١						 	 		 	 		 	 77
		6.16.2.2	ро	rt						 	 		 	 		 	 77
6.17	dsy_i2d	c_handle S	Stru	ct Ref	erend	ce .				 	 		 	 		 	 77
	6.17.1	Detailed	Des	criptic	n .					 	 		 	 		 	 77
	6.17.2	Member	Dat	a Doc	umer	ntatio	on .			 	 		 	 		 	 77
		6.17.2.1	pe	riph						 	 		 	 		 	 77
		6.17.2.2	pir	n_conf	fig .					 	 		 	 		 	 77
		6.17.2.3	sp	eed						 	 		 	 		 	 78
6.18	dsy_qs	pi_handle	Str	uct Re	eferer	псе				 	 		 	 		 	 78
	6.18.1	Detailed	Des	criptic	on .					 	 		 	 		 	 78
	6.18.2	Member	Dat	a Doc	umer	ntatio	on .			 	 		 	 		 	 78
		6.18.2.1	de	vice						 	 		 	 		 	 78
		6.18.2.2	mo	ode .						 	 		 	 		 	 78
		6.18.2.3	pir	n_conf	fig .					 	 		 	 		 	 79
6.19	dsy_sa	i_handle S	Stru	ct Ref	erend	ce .				 	 		 	 		 	 79
	6.19.1	Detailed	Des	criptic	on .					 	 		 	 		 	 79
	6.19.2	Member	Dat	a Doc	umer	ntatio	on .			 	 		 	 		 	 79
		6.19.2.1	a_	direct	ion .					 	 		 	 		 	 79
		6.19.2.2	b_	direct	ion .					 	 		 	 		 	 79
		6.19.2.3	bit	depth						 	 		 	 		 	 80
		6.19.2.4	de	vice						 	 		 	 		 	 80
		6.19.2.5	ini	t						 	 		 	 		 	 80
		6.19.2.6	sa	i1_pin	ı_con	ıfig				 	 		 	 		 	 80
		6.19.2.7	sa	i2_pin	ı_con	ıfig				 	 		 	 		 	 80
		6.19.2.8	sa	mplera	ate .					 	 		 	 		 	 80
		6.19.2.9	sy	nc_co	nfig					 	 		 	 		 	 80
6.20	DSY_S	SD_CardIn	nfoTy	/peDe	f Stru	uct R	Refer	enc	е.	 	 		 	 		 	81

xii CONTENTS

	6.20.1	Detailed Description	81
	6.20.2	Member Data Documentation	81
		6.20.2.1 BlockNbr	81
		6.20.2.2 BlockSize	81
		6.20.2.3 CardSpeed	81
		6.20.2.4 CardType	82
		6.20.2.5 CardVersion	82
		6.20.2.6 Class	82
		6.20.2.7 LogBlockNbr	82
		6.20.2.8 LogBlockSize	82
		6.20.2.9 RelCardAdd	82
6.21	dsy_sd	ram_handle Struct Reference	82
	6.21.1	Detailed Description	83
	6.21.2	Member Data Documentation	83
		6.21.2.1 pin_config	83
		6.21.2.2 state	83
6.22	dsy_sr_	_4021_handle Struct Reference	83
	6.22.1	Detailed Description	84
	6.22.2	Member Data Documentation	84
		6.22.2.1 clk	84
		6.22.2.2 cs	84
		6.22.2.3 data	84
		6.22.2.4 num_daisychained	84
		6.22.2.5 num_parallel	84
		6.22.2.6 pin_config	84
		6.22.2.7 states	85
6.23	daisy::E	Encoder Class Reference	85
	6.23.1	Detailed Description	85
	6.23.2	Member Function Documentation	85
		6.23.2.1 Debounce()	86

CONTENTS xiii

		6.23.2.2 FallingEdge()	86
		6.23.2.3 Increment()	86
		6.23.2.4 Init()	86
		6.23.2.5 Pressed()	86
		6.23.2.6 RisingEdge()	86
		6.23.2.7 TimeHeldMs()	86
6.24 F	ontDe	f Struct Reference	87
6	5.24.1	Detailed Description	87
6	5.24.2	Member Data Documentation	87
		6.24.2.1 data	87
		6.24.2.2 FontHeight	87
		6.24.2.3 FontWidth	87
6.25 d	laisy::0	GateIn Class Reference	88
6	5.25.1	Detailed Description	88
6	5.25.2	Constructor & Destructor Documentation	88
		6.25.2.1 GateIn()	88
		6.25.2.2 ~GateIn()	88
6	5.25.3	Member Function Documentation	88
		6.25.3.1 Init()	89
		6.25.3.2 Trig()	89
6.26 d	laisy::L	ed Class Reference	89
6	5.26.1	Detailed Description	89
6	5.26.2	Member Function Documentation	89
		6.26.2.1 Init()	89
		6.26.2.2 Set()	90
		6.26.2.3 Update()	90
6.27 d	laisy::N	MidiEvent Struct Reference	90
6	5.27.1	Detailed Description	91
6	5.27.2	Member Function Documentation	91
		6.27.2.1 AsControlChange()	91

xiv CONTENTS

		6.27.2.2 AsNoteOn()	91
	6.27.3	Member Data Documentation	91
		6.27.3.1 channel	91
		6.27.3.2 data	91
		6.27.3.3 type	91
6.28	daisy::N	MidiHandler Class Reference	92
	6.28.1	Detailed Description	92
	6.28.2	Member Enumeration Documentation	92
		6.28.2.1 MidiInputMode	92
		6.28.2.2 MidiOutputMode	93
	6.28.3	Member Function Documentation	93
		6.28.3.1 HasEvents()	93
		6.28.3.2 Init()	93
		6.28.3.3 Listen()	94
		6.28.3.4 Parse()	94
		6.28.3.5 PopEvent()	94
		6.28.3.6 StartReceive()	94
6.29	daisy::	NoteOnEvent Struct Reference	95
	6.29.1	Detailed Description	95
	6.29.2	Member Data Documentation	95
		6.29.2.1 channel	95
		6.29.2.2 note	95
		6.29.2.3 velocity	95
6.30	daisy::0	OledDisplay Class Reference	95
	6.30.1	Detailed Description	96
	6.30.2	Member Enumeration Documentation	96
		6.30.2.1 Pins	96
	6.30.3	Member Function Documentation	96
		6.30.3.1 DrawPixel()	96
		6.30.3.2 Fill()	98

CONTENTS xv

		6.30.3.3 Init()
		6.30.3.4 SetCursor()
		6.30.3.5 Update()
		6.30.3.6 WriteChar()
		6.30.3.7 WriteString()
6.31	daisy::F	Parameter Class Reference
	6.31.1	Detailed Description
	6.31.2	Member Enumeration Documentation
		6.31.2.1 Curve
	6.31.3	Constructor & Destructor Documentation
		6.31.3.1 Parameter()
		6.31.3.2 ~Parameter()
	6.31.4	Member Function Documentation
		6.31.4.1 Init()
		6.31.4.2 Process()
		6.31.4.3 Value()
6.32	daisy::F	RgbLed Class Reference
	6.32.1	Detailed Description
	6.32.2	Member Function Documentation
		6.32.2.1 Init()
		6.32.2.2 Set()
		6.32.2.3 SetColor()
		6.32.2.4 Update()
6.33	daisy::F	RingBuffer< T, size > Class Template Reference
	6.33.1	Detailed Description
	6.33.2	Member Function Documentation
		6.33.2.1 capacity()
		6.33.2.2 Flush()
		6.33.2.3 ImmediateRead() [1/2]
		6.33.2.4 ImmediateRead() [2/2]

xvi CONTENTS

		6.33.2.5 Init()	05
		6.33.2.6 Overwrite() [1/2]	05
		6.33.2.7 Overwrite() [2/2]	06
		6.33.2.8 Read()	06
		6.33.2.9 readable()	06
		6.33.2.10 Swallow()	06
		6.33.2.11 writable()	07
		6.33.2.12 Write()	07
6.34	daisy::I	RingBuffer< T, 0 > Class Template Reference	07
	6.34.1	Detailed Description	80
	6.34.2	Member Function Documentation	08
		6.34.2.1 capacity()	80
		6.34.2.2 Flush()	80
		6.34.2.3 ImmediateRead() [1/2]	80
		6.34.2.4 ImmediateRead() [2/2]	80
		6.34.2.5 Init()	09
		6.34.2.6 Overwrite() [1/2]	09
		6.34.2.7 Overwrite() [2/2]	09
		6.34.2.8 Read()	09
		6.34.2.9 readable()	10
		6.34.2.10 writable()	10
		6.34.2.11 Write()	10
6.35	daisy::	SdmmcHandler Class Reference	10
	6.35.1	Detailed Description	11
	6.35.2	Member Function Documentation	11
		6.35.2.1 Init()	11
6.36	daisy::	SdmmcHandlerInit Struct Reference	11
	6.36.1	Detailed Description	11
	6.36.2	Member Data Documentation	11
		6.36.2.1 bitdepth	11

CONTENTS xvii

		6.36.2.2 speed	12
6.37	ShiftRe	gister595 Class Reference	12
	6.37.1	Detailed Description	12
	6.37.2	Member Enumeration Documentation	12
		6.37.2.1 Pins	12
	6.37.3	Member Function Documentation	13
		6.37.3.1 Init()	13
		6.37.3.2 Set()	13
		6.37.3.3 Write()	13
6.38	daisy::8	SpiHandle Class Reference	14
	6.38.1	Detailed Description	14
	6.38.2	Member Function Documentation	14
		6.38.2.1 BlockingTransmit()	14
		6.38.2.2 Init()	14
6.39	daisy::S	Switch Class Reference	14
	6.39.1	Detailed Description	15
	6.39.2	Member Enumeration Documentation	15
		6.39.2.1 Polarity	15
		6.39.2.2 Pull	16
		6.39.2.3 Type	16
	6.39.3	Member Function Documentation	16
		6.39.3.1 Debounce()	16
		6.39.3.2 FallingEdge()	16
		6.39.3.3 Init() [1/2]	17
		6.39.3.4 Init() [2/2]	17
		6.39.3.5 Pressed()	17
		6.39.3.6 RisingEdge()	18
		6.39.3.7 TimeHeldMs()	18
6.40	daisy::l	JartHandler Class Reference	18
	6.40.1	Detailed Description	18
		·	

xviii CONTENTS

	6.40.2	Member F	Function Documentation		 	 	 	 	 119
		6.40.2.1	CheckError()		 	 	 	 	 119
		6.40.2.2	FlushRx()		 	 	 	 	 119
		6.40.2.3	Init()		 	 	 	 	 119
		6.40.2.4	PollReceive()		 	 	 	 	 119
		6.40.2.5	PollTx()		 	 	 	 	 120
		6.40.2.6	PopRx()		 	 	 	 	 120
		6.40.2.7	Readable()		 	 	 	 	 120
		6.40.2.8	RxActive()		 	 	 	 	 121
		6.40.2.9	StartRx()		 	 	 	 	 121
6.41	daisy::l	UsbHandle	Class Reference		 	 	 	 	 121
	6.41.1	Detailed I	Description		 	 	 	 	 122
	6.41.2	Member <sup>-</sup>	Typedef Documentation .		 	 	 	 	 122
		6.41.2.1	ReceiveCallback		 	 	 	 	 122
	6.41.3	Member I	Enumeration Documentat	ion .	 	 	 	 	 122
		6.41.3.1	UsbPeriph		 	 	 	 	 122
	6.41.4	Member F	Function Documentation		 	 	 	 	 122
		6.41.4.1	Init()		 	 	 	 	 123
		6.41.4.2	SetReceiveCallback() .		 	 	 	 	 123
		6.41.4.3	TransmitExternal()		 	 	 	 	 123
		6.41.4.4	TransmitInternal()		 	 	 	 	 123
6.42	WAV_F	ormatType	eDef Struct Reference		 	 	 	 	 124
	6.42.1	Detailed I	Description		 	 	 	 	 124
	6.42.2	Member I	Data Documentation		 	 	 	 	 124
		6.42.2.1	AudioFormat		 	 	 	 	 124
		6.42.2.2	BitPerSample		 	 	 	 	 125
		6.42.2.3	BlockAlign		 	 	 	 	 125
		6.42.2.4	ByteRate		 	 	 	 	 125
		6.42.2.5	Chunkld		 	 	 	 	 125
		6.42.2.6	FileFormat		 	 	 	 	 125

CONTENTS xix

|      |          | 6.42.2.7    | FileSize  | э        |        |      | <br> | 125 |
|------|----------|-------------|-----------|----------|--------|------|------|------|------|------|------|------|------|-----|
|      |          | 6.42.2.8    | NbrCha    | annels   |        |      | <br> | 125 |
|      |          | 6.42.2.9    | Sample    | Rate     |        |      | <br> | 125 |
|      |          | 6.42.2.10   | SubChi    | unk1ID   |        |      | <br> | 126 |
|      |          | 6.42.2.11   | SubChi    | unk1Si   | ze .   |      | <br> | 126 |
|      |          | 6.42.2.12   | SubChi    | unk2ID   | )      |      | <br> | 126 |
|      |          | 6.42.2.13   | SubCH     | unk2S    | ize .  |      | <br> | 126 |
| 6.43 | daisy::\ | WavFileInfo | Struct    | Refere   | nce    |      | <br> | 126 |
|      | 6.43.1   | Detailed D  | )escripti | ion .    |        |      | <br> | 126 |
|      | 6.43.2   | Member D    | )ata Do   | cument   | tation |      | <br> | 126 |
|      |          | 6.43.2.1    | name .    |          |        |      | <br> | 127 |
|      |          | 6.43.2.2    | raw_da    | .ta      |        |      | <br> | 127 |
| 6.44 | daisy::\ | WavPlayer ( | Class R   | eferen   | ce .   |      | <br> | 127 |
|      | 6.44.1   | Detailed D  | )escripti | on .     |        |      | <br> | 127 |
|      | 6.44.2   | Member F    | unction   | Docur    | nentat | tion | <br> | 127 |
|      |          | 6.44.2.1    | Close()   |          |        |      | <br> | 128 |
|      |          | 6.44.2.2    | GetCur    | rentFile | e() .  |      | <br> | 128 |
|      |          | 6.44.2.3    | GetLoo    | ping()   |        |      | <br> | 128 |
|      |          | 6.44.2.4    | GetNur    | nberFil  | les()  |      | <br> | 128 |
|      |          | 6.44.2.5    | Init() .  |          |        |      | <br> | 128 |
|      |          | 6.44.2.6    | Open()    |          |        |      | <br> | 128 |
|      |          | 6.44.2.7    | Prepare   | ∍()      |        |      | <br> | 129 |
|      |          | 6.44.2.8    | Restart   | .()      |        |      | <br> | 129 |
|      |          | 6.44.2.9    | SetLoo    | ping()   |        |      | <br> | 129 |
|      |          | 6.44.2.10   | Stream    | ()       |        |      | <br> | 129 |

7	File	Docum	entation		131
	7.1	src/dai	sy.h File R	Reference	131
		7.1.1	Macro D	efinition Documentation	132
			7.1.1.1	F2S16_SCALE	132
			7.1.1.2	F2S24_SCALE	132
			7.1.1.3	FBIPMAX	132
			7.1.1.4	FBIPMIN	132
			7.1.1.5	S162F_SCALE	133
			7.1.1.6	S242F_SCALE	133
			7.1.1.7	S24SIGN	133
		7.1.2	Function	Documentation	133
			7.1.2.1	f2s16()	133
			7.1.2.2	f2s24()	133
			7.1.2.3	s162f()	133
			7.1.2.4	s242f()	134
	7.2	src/dai	sy_core.h	File Reference	134
		7.2.1	Macro D	efinition Documentation	135
			7.2.1.1	DMA_BUFFER_MEM_SECTION	135
			7.2.1.2	DSY_CORE_HW_H	135
			7.2.1.3	DTCM_MEM_SECTION	135
		7.2.2	Enumera	ation Type Documentation	135
			7.2.2.1	dsy_gpio_port	135
		7.2.3	Function	Documentation	136
			7.2.3.1	cube()	136
			7.2.3.2	dsy_pin()	136
			7.2.3.3	dsy_pin_cmp()	136
	7.3	src/dai	sy_field.h	File Reference	136
		7.3.1	Detailed	Description	138
		7.3.2	Macro D	efinition Documentation	138
			7.3.2.1	CV1_ADC_PIN	138

CONTENTS xxi

		7.3.2.2	CV2_ADC_PIN	138
		7.3.2.3	CV3_ADC_PIN	138
		7.3.2.4	CV4_ADC_PIN	138
		7.3.2.5	DSY_FIELD_BSP_H	138
		7.3.2.6	GATE_IN_PIN	138
		7.3.2.7	GATE_OUT_PIN	139
		7.3.2.8	KB_SW_SR_CLK_PIN	139
		7.3.2.9	KB_SW_SR_CS_PIN	139
		7.3.2.10	KB_SW_SR_D1_PIN	139
		7.3.2.11	KB_SW_SR_D2_PIN	139
		7.3.2.12	LED_DRIVER_I2C	139
		7.3.2.13	MIDI_IN_PIN	139
		7.3.2.14	MIDI_OUT_PIN	139
		7.3.2.15	MUX_ADC_PIN	140
		7.3.2.16	MUX_SEL_0_PIN	140
		7.3.2.17	MUX_SEL_1_PIN	140
		7.3.2.18	MUX_SEL_2_PIN	140
		7.3.2.19	SAMPLE_RATE	140
		7.3.2.20	SW_1_PIN	140
		7.3.2.21	SW_2_PIN	140
		7.3.2.22	SW_3_PIN	140
	7.3.3	Enumera	tion Type Documentation	140
		7.3.3.1	anonymous enum	140
		7.3.3.2	anonymous enum	141
		7.3.3.3	anonymous enum	141
		7.3.3.4	anonymous enum	141
	7.3.4	Function	Documentation	142
		7.3.4.1	daisy_field_init()	142
7.4	src/dai:	sy_patch.h	File Reference	143
7.5	src/dai:	sy_petal.h	File Reference	144

xxii CONTENTS

	7.5.1	Macro Definition Documentation
		7.5.1.1 DSY_PETAL_H
7.6	src/dais	sy_pod.h File Reference
7.7	src/dais	sy_seed.h File Reference
7.8	src/dev	codec_ak4556.h File Reference
	7.8.1	Detailed Description
	7.8.2	Function Documentation
		7.8.2.1 codec_ak4556_init()
7.9	src/dev	_codec_pcm3060.h File Reference
	7.9.1	Detailed Description
	7.9.2	Function Documentation
		7.9.2.1 codec_pcm3060_init()
7.10	src/dev	codec_wm8731.h File Reference
	7.10.1	Detailed Description
	7.10.2	Function Documentation
		7.10.2.1 codec_wm8731_enter_bypass()
		7.10.2.2 codec_wm8731_exit_bypass()
		7.10.2.3 codec_wm8731_init()
7.11	src/dev	codec_wm8731_frame.h File Reference
	7.11.1	Detailed Description
	7.11.2	Typedef Documentation
		7.11.2.1 sa_audio_callback
7.12	src/dev	flash_IS25LP064A.h File Reference
	7.12.1	Detailed Description
	7.12.2	Macro Definition Documentation
		7.12.2.1 BLOCK_ERASE_32K_CMD
		7.12.2.2 CLEAR_FLAG_STATUS_REG_CMD
		7.12.2.3 DIE_ERASE_CMD
		7.12.2.4 DUAL_IN_FAST_PROG_CMD
		7.12.2.5 DUAL_INOUT_FAST_READ_4_BYTE_ADDR_CMD

CONTENTS xxiii

7.12.2.6 DUAL_INOUT_FAST_READ_CMD	151
7.12.2.7 DUAL_INOUT_FAST_READ_DTR_CMD	152
7.12.2.8 DUAL_OUT_FAST_READ_4_BYTE_ADDR_CMD	152
7.12.2.9 DUAL_OUT_FAST_READ_CMD	152
7.12.2.10 DUAL_OUT_FAST_READ_DTR_CMD	152
7.12.2.11 ENTER_4_BYTE_ADDR_MODE_CMD	152
7.12.2.12 ENTER_QUAD_CMD	152
7.12.2.13 EXIT_4_BYTE_ADDR_MODE_CMD	152
7.12.2.14 EXIT_QUAD_CMD	152
7.12.2.15 EXT_DUAL_IN_FAST_PROG_CMD	153
7.12.2.16 EXT_QUAD_IN_FAST_PROG_CMD	153
7.12.2.17 FAST_READ_4_BYTE_ADDR_CMD	153
7.12.2.18 FAST_READ_CMD	153
7.12.2.19 FAST_READ_DTR_CMD	153
7.12.2.20 IS25LP064A_DIE_ERASE_MAX_TIME	153
7.12.2.21 IS25LP064A_DUMMY_CYCLES_READ	153
7.12.2.22 IS25LP064A_DUMMY_CYCLES_READ_DTR	153
7.12.2.23 IS25LP064A_DUMMY_CYCLES_READ_QUAD	154
7.12.2.24 IS25LP064A_DUMMY_CYCLES_READ_QUAD_DTR	154
7.12.2.25 IS25LP064A_EAR_HIGHEST_SE	154
7.12.2.26 IS25LP064A_EAR_LOWEST_SEG	154
7.12.2.27 IS25LP064A_EAR_SECOND_SEG	154
7.12.2.28 IS25LP064A_EAR_THIRD_SEG	154
7.12.2.29 IS25LP064A_EVCR_DTRP	154
7.12.2.30 IS25LP064A_EVCR_DUAL	154
7.12.2.31 IS25LP064A_EVCR_ODS	155
7.12.2.32 IS25LP064A_EVCR_QUAD	155
7.12.2.33 IS25LP064A_EVCR_RH	155
7.12.2.34 IS25LP064A_FLASH_SIZE	155
7.12.2.35 IS25LP064A_FSR_ERERR	155

xxiv CONTENTS

7.12.2.36 IS25LP064A_FSR_ERSUS
7.12.2.37 IS25LP064A_FSR_NBADDR
7.12.2.38 IS25LP064A_FSR_PGERR
7.12.2.39 IS25LP064A_FSR_PGSUS
7.12.2.40 IS25LP064A_FSR_PRERR
7.12.2.41 IS25LP064A_FSR_READY
7.12.2.42 IS25LP064A_H
7.12.2.43 IS25LP064A_NVCR_DTRP
7.12.2.44 IS25LP064A_NVCR_DUAL
7.12.2.45 IS25LP064A_NVCR_NB_DUMMY
7.12.2.46 IS25LP064A_NVCR_NBADDR
7.12.2.47 IS25LP064A_NVCR_ODS
7.12.2.48 IS25LP064A_NVCR_QUAB
7.12.2.49 IS25LP064A_NVCR_RH
7.12.2.50 IS25LP064A_NVCR_SEGMENT
7.12.2.51 IS25LP064A_NVCR_XIP
7.12.2.52 IS25LP064A_PAGE_SIZE
7.12.2.53 IS25LP064A_SECTOR_ERASE_MAX_TIME
7.12.2.54 IS25LP064A_SECTOR_SIZE
7.12.2.55 IS25LP064A_SR_QE
7.12.2.56 IS25LP064A_SR_SRWREN
7.12.2.57 IS25LP064A_SR_WIP
7.12.2.58 IS25LP064A_SR_WREN
7.12.2.59 IS25LP064A_SUBSECTOR_ERASE_MAX_TIME
7.12.2.60 IS25LP064A_SUBSECTOR_SIZE
7.12.2.61 IS25LP064A_VCR_NB_DUMMY
7.12.2.62 IS25LP064A_VCR_WRAP
7.12.2.63 IS25LP064A_VCR_XIP
7.12.2.64 MULTIPLE_IO_READ_ID_CMD
7.12.2.65 PAGE_PROG_4_BYTE_ADDR_CMD

CONTENTS xxv

7.12.2.66 PAGE_PROG_CMD	 159
7.12.2.67 PROG_ERASE_RESUME_CMD	 159
7.12.2.68 PROG_ERASE_SUSPEND_CMD	 159
7.12.2.69 PROG_OTP_ARRAY_CMD	 159
7.12.2.70 QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD	 160
7.12.2.71 QUAD_IN_FAST_PROG_CMD	 160
7.12.2.72 QUAD_INOUT_FAST_READ_4_BYTE_ADDR_CMD	 160
7.12.2.73 QUAD_INOUT_FAST_READ_CMD	 160
7.12.2.74 QUAD_INOUT_FAST_READ_DTR_CMD	 160
7.12.2.75 QUAD_OUT_FAST_READ_4_BYTE_ADDR_CMD	 160
7.12.2.76 QUAD_OUT_FAST_READ_CMD	 160
7.12.2.77 QUAD_OUT_FAST_READ_DTR_CMD	 160
7.12.2.78 READ_4_BYTE_ADDR_CMD	 161
7.12.2.79 READ_CMD	 161
7.12.2.80 READ_ENHANCED_VOL_CFG_REG_CMD	 161
7.12.2.81 READ_EXT_ADDR_REG_CMD	 161
7.12.2.82 READ_FLAG_STATUS_REG_CMD	 161
7.12.2.83 READ_ID_CMD	 161
7.12.2.84 READ_ID_CMD2	 161
7.12.2.85 READ_LOCK_REG_CMD	 161
7.12.2.86 READ_NONVOL_CFG_REG_CMD	 162
7.12.2.87 READ_OTP_ARRAY_CMD	 162
7.12.2.88 READ_READ_PARAM_REG_CMD	 162
7.12.2.89 READ_SERIAL_FLASH_DISCO_PARAM_CMD	 162
7.12.2.90 READ_STATUS_REG_CMD	 162
7.12.2.91 RESET_ENABLE_CMD	 162
7.12.2.92 RESET_MEMORY_CMD	 162
7.12.2.93 SECTOR_ERASE_4_BYTE_ADDR_CMD	 162
7.12.2.94 SECTOR_ERASE_CMD	 163
7.12.2.95 SUBSECTOR_ERASE_4_BYTE_ADDR_CMD	 163

xxvi CONTENTS

	7.12.2.96 SUBSECTOR_ERASE_CMD	163
	7.12.2.97 SUBSECTOR_ERASE_QPI_CMD	163
	7.12.2.98 WRITE_DISABLE_CMD	163
	7.12.2.99 WRITE_ENABLE_CMD	163
	7.12.2.100WRITE_ENHANCED_VOL_CFG_REG_CMD	163
	7.12.2.101WRITE_EXT_ADDR_REG_CMD	163
	7.12.2.102WRITE_LOCK_REG_CMD	164
	7.12.2.103WRITE_NONVOL_CFG_REG_CMD	164
	7.12.2.104WRITE_READ_PARAM_REG_CMD	164
	7.12.2.105WRITE_STATUS_REG_CMD	164
7.13 src/dev	v_flash_IS25LP080D.h File Reference	164
7.13.1	Detailed Description	166
7.13.2	Macro Definition Documentation	166
	7.13.2.1 BLOCK_ERASE_32K_CMD	166
	7.13.2.2 CLEAR_FLAG_STATUS_REG_CMD	167
	7.13.2.3 DIE_ERASE_CMD	167
	7.13.2.4 DUAL_IN_FAST_PROG_CMD	167
	7.13.2.5 DUAL_INOUT_FAST_READ_4_BYTE_ADDR_CMD	167
	7.13.2.6 DUAL_INOUT_FAST_READ_CMD	167
	7.13.2.7 DUAL_INOUT_FAST_READ_DTR_CMD	167
	7.13.2.8 DUAL_OUT_FAST_READ_4_BYTE_ADDR_CMD	167
	7.13.2.9 DUAL_OUT_FAST_READ_CMD	167
	7.13.2.10 DUAL_OUT_FAST_READ_DTR_CMD	168
	7.13.2.11 ENTER_4_BYTE_ADDR_MODE_CMD	168
	7.13.2.12 ENTER_QUAD_CMD	168
	7.13.2.13 EXIT_4_BYTE_ADDR_MODE_CMD	168
	7.13.2.14 EXIT_QUAD_CMD	168
	7.13.2.15 EXT_DUAL_IN_FAST_PROG_CMD	168
	7.13.2.16 EXT_QUAD_IN_FAST_PROG_CMD	168
	7.13.2.17 FAST_READ_4_BYTE_ADDR_CMD	168

CONTENTS xxvii

7.13.2.18 FAST_READ_CMD	
7.13.2.19 FAST_READ_DTR_CMD	169
7.13.2.20 IS25LP080D_DIE_ERASE_MAX_TIME	169
7.13.2.21 IS25LP080D_DUMMY_CYCLES_READ	169
7.13.2.22 IS25LP080D_DUMMY_CYCLES_READ_DTR	169
7.13.2.23 IS25LP080D_DUMMY_CYCLES_READ_QUAD	169
7.13.2.24 IS25LP080D_DUMMY_CYCLES_READ_QUAD_DTR	169
7.13.2.25 IS25LP080D_EAR_HIGHEST_SE	169
7.13.2.26 IS25LP080D_EAR_LOWEST_SEG	170
7.13.2.27 IS25LP080D_EAR_SECOND_SEG	170
7.13.2.28 IS25LP080D_EAR_THIRD_SEG	170
7.13.2.29 IS25LP080D_EVCR_DTRP	170
7.13.2.30 IS25LP080D_EVCR_DUAL	170
7.13.2.31 IS25LP080D_EVCR_ODS	170
7.13.2.32 IS25LP080D_EVCR_QUAD	170
7.13.2.33 IS25LP080D_EVCR_RH	170
7.13.2.34 IS25LP080D_FLASH_SIZE	171
7.13.2.35 IS25LP080D_FSR_ERERR	171
7.13.2.36 IS25LP080D_FSR_ERSUS	171
7.13.2.37 IS25LP080D_FSR_NBADDR	171
7.13.2.38 IS25LP080D_FSR_PGERR	171
7.13.2.39 IS25LP080D_FSR_PGSUS	171
7.13.2.40 IS25LP080D_FSR_PRERR	171
7.13.2.41 IS25LP080D_FSR_READY	171
7.13.2.42 IS25LP080D_NVCR_DTRP	172
7.13.2.43 IS25LP080D_NVCR_DUAL	172
7.13.2.44 IS25LP080D_NVCR_NB_DUMMY	172
7.13.2.45 IS25LP080D_NVCR_NBADDR	172
7.13.2.46 IS25LP080D_NVCR_ODS	172
7.13.2.47 IS25LP080D_NVCR_QUAB	172

xxviii CONTENTS

7.13.2.48 IS25LP080D_NVCR_RH	172
7.13.2.49 IS25LP080D_NVCR_SEGMENT	172
7.13.2.50 IS25LP080D_NVCR_XIP	173
7.13.2.51 IS25LP080D_PAGE_SIZE	173
7.13.2.52 IS25LP080D_SECTOR_ERASE_MAX_TIME	173
7.13.2.53 IS25LP080D_SECTOR_SIZE	173
7.13.2.54 IS25LP080D_SR_QE	173
7.13.2.55 IS25LP080D_SR_SRWREN	173
7.13.2.56 IS25LP080D_SR_WIP	173
7.13.2.57 IS25LP080D_SR_WREN	174
7.13.2.58 IS25LP080D_SUBSECTOR_ERASE_MAX_TIME	174
7.13.2.59 IS25LP080D_SUBSECTOR_SIZE	174
7.13.2.60 IS25LP080D_VCR_NB_DUMMY	174
7.13.2.61 IS25LP080D_VCR_WRAP	174
7.13.2.62 IS25LP080D_VCR_XIP	174
7.13.2.63 MULTIPLE_IO_READ_ID_CMD	174
7.13.2.64 PAGE_PROG_4_BYTE_ADDR_CMD	174
7.13.2.65 PAGE_PROG_CMD	175
7.13.2.66 PROG_ERASE_RESUME_CMD	175
7.13.2.67 PROG_ERASE_SUSPEND_CMD	175
7.13.2.68 PROG_OTP_ARRAY_CMD	175
7.13.2.69 QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD	175
7.13.2.70 QUAD_IN_FAST_PROG_CMD	175
7.13.2.71 QUAD_INOUT_FAST_READ_4_BYTE_ADDR_CMD	175
7.13.2.72 QUAD_INOUT_FAST_READ_CMD	175
7.13.2.73 QUAD_INOUT_FAST_READ_DTR_CMD	176
7.13.2.74 QUAD_OUT_FAST_READ_4_BYTE_ADDR_CMD	176
7.13.2.75 QUAD_OUT_FAST_READ_CMD	176
7.13.2.76 QUAD_OUT_FAST_READ_DTR_CMD	176
7.13.2.77 READ_4_BYTE_ADDR_CMD	176
	7.13.2.49 IS25LP080D_NVCR_XIP 7.13.2.50 IS25LP080D_PAGE_SIZE 7.13.2.51 IS25LP080D_PAGE_SIZE 7.13.2.52 IS25LP080D_SECTOR_ERASE_MAX_TIME 7.13.2.53 IS25LP080D_SECTOR_SIZE 7.13.2.54 IS25LP080D_SR_QE 7.13.2.55 IS25LP080D_SR_QE 7.13.2.56 IS25LP080D_SR_WIP 7.13.2.57 IS25LP080D_SR_WIP 7.13.2.58 IS25LP080D_SR_WIP 7.13.2.59 IS25LP080D_SUBSECTOR_ERASE_MAX_TIME 7.13.2.59 IS25LP080D_SUBSECTOR_SIZE 7.13.2.60 IS25LP080D_VCR_NB_DUMMY 7.13.2.61 IS25LP080D_VCR_WRAP 7.13.2.62 IS25LP080D_VCR_WRAP 7.13.2.63 MULTIPLE_IO_READ_ID_CMD 7.13.2.64 PAGE_PROG_4_BYTE_ADDR_CMD 7.13.2.65 PAGE_PROG_CMD 7.13.2.66 PROG_ERASE_RESUME_CMD 7.13.2.67 PROG_ERASE_SUSPEND_CMD 7.13.2.68 PROG_OTP_ARRAY_CMD 7.13.2.69 QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD 7.13.2.70 QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD 7.13.2.71 QUAD_INOUT_FAST_READ_4_BYTE_ADDR_CMD 7.13.2.72 QUAD_INOUT_FAST_READ_CMD 7.13.2.73 QUAD_INOUT_FAST_READ_CMD 7.13.2.74 QUAD_OUT_FAST_READ_LTR_CMD 7.13.2.75 QUAD_OUT_FAST_READ_LTR_CMD 7.13.2.75 QUAD_OUT_FAST_READ_LTR_CMD 7.13.2.76 QUAD_OUT_FAST_READ_LTR_CMD 7.13.2.75 QUAD_OUT_FAST_READ_LTR_CMD

CONTENTS xxix

		7.13.2.78 READ_CMD	176
		7.13.2.79 READ_ENHANCED_VOL_CFG_REG_CMD	176
		7.13.2.80 READ_EXT_ADDR_REG_CMD	176
		7.13.2.81 READ_FLAG_STATUS_REG_CMD	177
		7.13.2.82 READ_ID_CMD	177
		7.13.2.83 READ_ID_CMD2	177
		7.13.2.84 READ_LOCK_REG_CMD	177
		7.13.2.85 READ_NONVOL_CFG_REG_CMD	177
		7.13.2.86 READ_OTP_ARRAY_CMD	177
		7.13.2.87 READ_READ_PARAM_REG_CMD	177
		7.13.2.88 READ_SERIAL_FLASH_DISCO_PARAM_CMD	177
		7.13.2.89 READ_STATUS_REG_CMD	178
		7.13.2.90 RESET_ENABLE_CMD	178
		7.13.2.91 RESET_MEMORY_CMD	178
		7.13.2.92 SECTOR_ERASE_4_BYTE_ADDR_CMD	178
		7.13.2.93 SECTOR_ERASE_CMD	178
		7.13.2.94 SUBSECTOR_ERASE_4_BYTE_ADDR_CMD	178
		7.13.2.95 SUBSECTOR_ERASE_CMD	178
		7.13.2.96 SUBSECTOR_ERASE_QPI_CMD	178
		7.13.2.97 WRITE_DISABLE_CMD	179
		7.13.2.98 WRITE_ENABLE_CMD	179
		7.13.2.99 WRITE_ENHANCED_VOL_CFG_REG_CMD	179
		7.13.2.100WRITE_EXT_ADDR_REG_CMD	179
		7.13.2.101WRITE_LOCK_REG_CMD	179
		7.13.2.102WRITE_NONVOL_CFG_REG_CMD	179
		7.13.2.103WRITE_READ_PARAM_REG_CMD	179
		7.13.2.104WRITE_STATUS_REG_CMD	179
7.14	src/dev	_leddriver.h File Reference	180
	7.14.1	Detailed Description	180
	7.14.2	Macro Definition Documentation	180

	7.14.2.1 DSY_LED_DRIVER_MAX_DRIVERS
	7.14.2.2 SA_LED_DRIVER_H
7.14.3	Enumeration Type Documentation
	7.14.3.1 anonymous enum
7.14.4	Function Documentation
	7.14.4.1 dsy_led_driver_color_by_name()
	7.14.4.2 dsy_led_driver_init()
	7.14.4.3 dsy_led_driver_set_led()
	7.14.4.4 dsy_led_driver_update()
7.15 src/dev	v_sdram.h File Reference
7.15.1	Macro Definition Documentation
	7.15.1.1 DSY_SDRAM_BSS
	7.15.1.2 DSY_SDRAM_DATA
	7.15.1.3 RAM_AS4C16M16SA_H
7.15.2	Enumeration Type Documentation
	7.15.2.1 anonymous enum
	7.15.2.2 dsy_sdram_pin
	7.15.2.3 dsy_sdram_state
7.15.3	Function Documentation
	7.15.3.1 dsy_sdram_init()
7.16 src/dev	v_sr_4021.h File Reference
7.16.1	Detailed Description
7.16.2	Macro Definition Documentation
	7.16.2.1 DEV_SR_4021_H
	7.16.2.2 SR_4021_MAX_DAISYCHAIN
	7.16.2.3 SR_4021_MAX_PARALLEL
7.16.3	Enumeration Type Documentation
	7.16.3.1 anonymous enum
7.16.4	Function Documentation
	7.16.4.1 dsy_sr_4021_init()

CONTENTS xxxi

	7.16.4.2 dsy_sr_4021_state()	188
	7.16.4.3 dsy_sr_4021_update()	188
7.17 src/dev	v_sr_595.h File Reference	188
7.17.1	Variable Documentation	189
	7.17.1.1 kMaxSr595DaisyChain	189
7.18 src/fatf	s.h File Reference	189
7.18.1	Detailed Description	189
7.18.2	Macro Definition Documentation	189
	7.18.2.1fatfs_H	190
7.18.3	Function Documentation	190
	7.18.3.1 dsy_fatfs_init()	190
7.18.4	Variable Documentation	190
	7.18.4.1 retSD	190
	7.18.4.2 SDFatFS	190
	7.18.4.3 SDFile	190
	7.18.4.4 SDPath	190
7.19 src/ffcc	onf.h File Reference	191
7.19.1	Detailed Description	191
7.19.2	Macro Definition Documentation	192
	7.19.2.1 _CODE_PAGE	192
	7.19.2.2 _FFCONF	192
	7.19.2.3 _FS_EXFAT	192
	7.19.2.4 _FS_LOCK	192
	7.19.2.5 _FS_MINIMIZE	193
	7.19.2.6 _FS_NOFSINFO	193
	7.19.2.7 _FS_NORTC	193
	7.19.2.8 _FS_READONLY	193
	7.19.2.9 _FS_REENTRANT	193
	7.19.2.10 _FS_RPATH	193
	7.19.2.11 _FS_TIMEOUT	194

xxxii CONTENTS

		7.19.2.12 _FS_TINY	194
		7.19.2.13 _LFN_UNICODE	194
		7.19.2.14 _MAX_LFN	194
		7.19.2.15 _MAX_SS	194
		7.19.2.16 _MIN_SS	194
		7.19.2.17 _MULTI_PARTITION	195
		7.19.2.18 _NORTC_MDAY	195
		7.19.2.19 _NORTC_MON	195
		7.19.2.20 _NORTC_YEAR	195
		7.19.2.21 _STR_VOLUME_ID	195
		7.19.2.22 _STRF_ENCODE	195
		7.19.2.23 _SYNC_t	196
		7.19.2.24 _USE_CHMOD	196
		7.19.2.25 _USE_EXPAND	196
		7.19.2.26 _USE_FASTSEEK	196
		7.19.2.27 _USE_FIND	196
		7.19.2.28 _USE_FORWARD	196
		7.19.2.29 _USE_LABEL	197
		7.19.2.30 _USE_LFN	197
		7.19.2.31 _USE_MKFS	197
		7.19.2.32 _USE_STRFUNC	197
		7.19.2.33 _USE_TRIM	197
		7.19.2.34 _VOLUME_STRS	197
		7.19.2.35 _VOLUMES	198
		7.19.2.36 ff_free	198
		7.19.2.37 ff_malloc	198
7.20	src/hid_	_audio.h File Reference	198
	7.20.1	Detailed Description	199
	7.20.2	Macro Definition Documentation	199
		7.20.2.1 DSY_AUDIO_BLOCK_SIZE_MAX	199

CONTENTS xxxiii

		7.20.2.2 DSY_AUDIO_CHANNELS_MAX	99
		7.20.2.3 DSY_AUDIO_H	99
		7.20.2.4 DSY_AUDIO_SAMPLE_RATE	99
	7.20.3	Typedef Documentation	99
		7.20.3.1 dsy_audio_callback	99
		7.20.3.2 dsy_audio_mc_callback	00
	7.20.4	Enumeration Type Documentation	00
		7.20.4.1 anonymous enum	00
	7.20.5	Function Documentation	00
		7.20.5.1 dsy_audio_enter_bypass()	00
		7.20.5.2 dsy_audio_exit_bypass()	00
		7.20.5.3 dsy_audio_init()	01
		7.20.5.4 dsy_audio_passthru()	01
		7.20.5.5 dsy_audio_set_blocksize()	01
		7.20.5.6 dsy_audio_set_callback()	01
		7.20.5.7 dsy_audio_set_mc_callback()	01
		7.20.5.8 dsy_audio_silence()	02
		7.20.5.9 dsy_audio_start()	02
		7.20.5.10 dsy_audio_stop()	02
7.21	src/hid_	_ctrl.h File Reference	02
	7.21.1	Macro Definition Documentation	02
		7.21.1.1 DSY_KNOB_H	03
7.22	src/hid_	_encoder.h File Reference	03
7.23	src/hid_	gatein.h File Reference	03
7.24	src/hid_	_led.h File Reference	03
7.25	src/hid_	_midi.h File Reference	04
	7.25.1	Enumeration Type Documentation	04
		7.25.1.1 MidiMessageType	04
7.26	src/hid_	oled_display.h File Reference	05
	7.26.1	Macro Definition Documentation	05

		7.26.1.1	DSY_C	)LED_D	ISPLA	Y_H .		 	 	 	 	 	 205
		7.26.1.2	SSD13	09_HEI	GHT			 	 	 	 	 	 205
		7.26.1.3	SSD13	09_WID	TH .			 	 	 	 	 	 205
7.27	src/hid_	_paramete	er.h File I	Reference	ce			 	 	 	 	 	 205
7.28	src/hid_	_rgb_led.h	r File Re	ference				 	 	 	 	 	 206
7.29	src/hid_	_switch.h l	File Refe	rence .				 	 	 	 	 	 206
7.30	src/hid_	_usb.h File	e Referei	nce				 	 	 	 	 	 206
7.31	src/hid_	_wavplaye	r.h File F	Referenc	ce			 	 	 	 	 	 206
	7.31.1	Macro De	efinition l	Docume	entation	١		 	 	 	 	 	 207
		7.31.1.1	DSY_V	VAVPLA	AYER_I	н		 	 	 	 	 	 207
		7.31.1.2	WAV_F	FILENAI	ME_MA	ΑX .		 	 	 	 	 	 207
7.32	src/per_	_adc.h File	e Refere	nce				 	 	 	 	 	 207
	7.32.1	Macro De	efinition l	Docume	ntation	١		 	 	 	 	 	 208
		7.32.1.1	DSY_A	.DC_H .				 	 	 	 	 	 208
		7.32.1.2	DSY_A	.DC_MA	AX_CH	ANNE	LS.	 	 	 	 	 	 208
7.33	src/per_	_dac.h File	e Refere	nce				 	 	 	 	 	 208
	7.33.1	Enumera	tion Type	e Docun	nentatio	on .		 	 	 	 	 	 208
		7.33.1.1	dsy_da	.c_bitde	pth .			 	 	 	 	 	 208
		7.33.1.2	dsy_da	.c_chan	nel .			 	 	 	 	 	 209
		7.33.1.3	dsy_da	.c_mode	<b>.</b>			 	 	 	 	 	 209
	7.33.2	Function	Docume	ntation				 	 	 	 	 	 209
		7.33.2.1	dsy_da	.c_init()				 	 	 	 	 	 209
		7.33.2.2	dsy_da	.c_start(	)			 	 	 	 	 	 210
		7.33.2.3	dsy_da	.c_write	()			 	 	 	 	 	 210
7.34	src/per_	_gpio.h Fil	le Refere	ence				 	 	 	 	 	 210
	7.34.1	Detailed	Descript	ion				 	 	 	 	 	 211
	7.34.2	Enumera	tion Type	e Docun	nentatio	on .		 	 	 	 	 	 211
		7.34.2.1	dsy_gp	io_mod	е			 	 	 	 	 	 211
		7.34.2.2	dsy_gp	io_pull				 	 	 	 	 	 211
	7.34.3	Function	Docume	ntation				 	 	 	 	 	 212

CONTENTS XXXV

	7.34.3.1 dsy_gpio_deinit()
	7.34.3.2 dsy_gpio_init()
	7.34.3.3 dsy_gpio_read()
	7.34.3.4 dsy_gpio_toggle()
	7.34.3.5 dsy_gpio_write()
7.35 src/per	_i2c.h File Reference
7.35.1	Macro Definition Documentation
	7.35.1.1 DSY_I2C_H
7.35.2	Enumeration Type Documentation
	7.35.2.1 dsy_i2c_periph
	7.35.2.2 dsy_i2c_pin
	7.35.2.3 dsy_i2c_speed
7.35.3	Function Documentation
	7.35.3.1 dsy_i2c_init()
7.36 src/per	r_qspi.h File Reference
7.36.1	Macro Definition Documentation
	7.36.1.1 DSY_MEMORY_ERROR
	7.36.1.2 DSY_MEMORY_OK
	7.36.1.3 DSY_QSPI
	7.36.1.4 DSY_QSPI_BSS
	7.36.1.5 DSY_QSPI_DATA
	7.36.1.6 DSY_QSPI_TEXT
7.36.2	Enumeration Type Documentation
	7.36.2.1 dsy_qspi_device
	7.36.2.2 dsy_qspi_mode
	7.36.2.3 dsy_qspi_pin
7.36.3	Function Documentation
	7.36.3.1 dsy_qspi_deinit()
	7.36.3.2 dsy_qspi_erase()
	7.36.3.3 dsy_qspi_erasesector()

xxxvi CONTENTS

	7.36.3.4	dsy_qspi_init()	220
	7.36.3.5	dsy_qspi_write()	220
	7.36.3.6	dsy_qspi_writepage()	220
7.37 src/per	_sai.h File	Reference	221
7.37.1	Enumera	tion Type Documentation	221
	7.37.1.1	anonymous enum	221
	7.37.1.2	dsy_audio_bitdepth	222
	7.37.1.3	dsy_audio_device	222
	7.37.1.4	dsy_audio_dir	222
	7.37.1.5	dsy_audio_sai	223
	7.37.1.6	dsy_audio_samplerate	223
	7.37.1.7	dsy_audio_sync	223
	7.37.1.8	dsy_sai_pin	224
7.37.2	Function	Documentation	224
	7.37.2.1	dsy_sai_init()	224
	7.37.2.2	dsy_sai_init_from_handle()	224
7.38 src/per	_sdmmc.h	File Reference	226
7.38.1	Macro De	efinition Documentation	226
	7.38.1.1	DSY_SD_ERROR	226
	7.38.1.2	DSY_SD_OK	226
	7.38.1.3	DSY_SDMMC_H	227
7.38.2	Enumera	tion Type Documentation	227
	7.38.2.1	SdmmcBitWidth	227
	7.38.2.2	SdmmcMode	227
	7.38.2.3	SdmmcSpeed	227
7.39 src/per	_spi.h File	Reference	228
7.39.1	Enumera	tion Type Documentation	228
	7.39.1.1	SpiPeriph	228
	7.39.1.2	SpiPin	228
7.40 src/per	_tim.h File	Reference	229

CONTENTS xxxvii

	7.40.1	Function I	Documentat	ion		 	 	 	 	 	229
		7.40.1.1	dsy_tim_de	lay_ms()		 	 	 	 	 	229
		7.40.1.2	dsy_tim_de	lay_tick()		 	 	 	 	 	229
		7.40.1.3	dsy_tim_de	lay_us()		 	 	 	 	 	230
		7.40.1.4	dsy_tim_ge	t_ms() .		 	 	 	 	 	230
		7.40.1.5	dsy_tim_ge	t_tick() .		 	 	 	 	 	230
		7.40.1.6	dsy_tim_ge	t_us()		 	 	 	 	 	230
		7.40.1.7	dsy_tim_ini	t()		 	 	 	 	 	231
		7.40.1.8	dsy_tim_sta	art()		 	 	 	 	 	231
7.41	src/per_	_uart.h File	e Reference			 	 	 	 	 	231
	7.41.1	Macro De	finition Docu	ımentation	١	 	 	 	 	 	231
		7.41.1.1	DSY_UAR	Г_Н		 	 	 	 	 	231
	7.41.2	Variable D	Oocumentati	on		 	 	 	 	 	231
		7.41.2.1	kUartMaxB	ufferSize		 	 	 	 	 	232
7.42	src/sys	_dma.h Fil	e Reference			 	 	 	 	 	232
	7.42.1	Function I	Documentat	ion		 	 	 	 	 	232
		7.42.1.1	dsy_dma_ii	nit()		 	 	 	 	 	232
7.43	src/sys	_system.h	File Referer	ice		 	 	 	 	 	232
	7.43.1	Detailed [	Description			 	 	 	 	 	232
	7.43.2	Function I	Documentat	ion		 	 	 	 	 	232
		7.43.2.1	dsy_system	ı_delay()		 	 	 	 	 	232
		7.43.2.2	dsy_system	ı_getnow()	)	 	 	 	 	 	233
		7.43.2.3	dsy_system	n_init() .		 	 	 	 	 	233
		7.43.2.4	dsy_system	ı_jumpto()		 	 	 	 	 	233
		7.43.2.5	dsy_system	ı_jumptoq	spi() .	 	 	 	 	 	233
7.44	src/usb	d_cdc_if.h	File Referer	nce		 	 	 	 	 	234
	7.44.1	Detailed [	Description			 	 	 	 	 	234
7.45	src/usb	d_conf.h F	ile Referenc	e		 	 	 	 	 	235
	7.45.1	Detailed [	Description			 	 	 	 	 	235
7.46	src/usb	d_desc.h F	File Referen	ce		 	 	 	 	 	236

xxxviii CONTENTS

7.47       src/util_bsp_sd_diskio.h File Reference       2         7.47.1       Macro Definition Documentation       2         7.47.1.1       BSP_SD_CardInfo       2         7.47.1.2       DSY_BSP_SD_DISKIO_H       2         7.47.1.3       MSD_ERROR       2         7.47.1.4       MSD_ERROR_SD_NOT_PRESENT       2         7.47.1.5       MSD_OK       2         7.47.1.6       SD_DATATIMEOUT       2         7.47.1.7       SD_NOT_PRESENT       2	236
7.47.1.1 BSP_SD_CardInfo       2         7.47.1.2 DSY_BSP_SD_DISKIO_H       2         7.47.1.3 MSD_ERROR       2         7.47.1.4 MSD_ERROR_SD_NOT_PRESENT       2         7.47.1.5 MSD_OK       2         7.47.1.6 SD_DATATIMEOUT       2	236
7.47.1.2 DSY_BSP_SD_DISKIO_H       2         7.47.1.3 MSD_ERROR       2         7.47.1.4 MSD_ERROR_SD_NOT_PRESENT       2         7.47.1.5 MSD_OK       2         7.47.1.6 SD_DATATIMEOUT       2	237
7.47.1.3 MSD_ERROR       2         7.47.1.4 MSD_ERROR_SD_NOT_PRESENT       2         7.47.1.5 MSD_OK       2         7.47.1.6 SD_DATATIMEOUT       2	237
7.47.1.4 MSD_ERROR_SD_NOT_PRESENT       2         7.47.1.5 MSD_OK       2         7.47.1.6 SD_DATATIMEOUT       2	237
7.47.1.5 MSD_OK	238
7.47.1.6 SD_DATATIMEOUT	238
	238
7.47.1.7 SD_NOT_PRESENT	238
	238
7.47.1.8 SD_PRESENT	238
7.47.1.9 SD_TRANSFER_BUSY	238
7.47.1.10 SD_TRANSFER_OK	238
7.47.2 Function Documentation	239
7.47.2.1 BSP_SD_AbortCallback()	239
7.47.2.2 BSP_SD_Erase()	239
7.47.2.3 BSP_SD_GetCardInfo()	239
7.47.2.4 BSP_SD_GetCardState()	240
7.47.2.5 BSP_SD_Init()	240
7.47.2.6 BSP_SD_IsDetected()	240
7.47.2.7 BSP_SD_ITConfig()	240
7.47.2.8 BSP_SD_ReadBlocks()	240
7.47.2.9 BSP_SD_ReadBlocks_DMA()	241
7.47.2.10 BSP_SD_ReadCpltCallback()	241
7.47.2.11 BSP_SD_WriteBlocks()	241
7.47.2.12 BSP_SD_WriteBlocks_DMA()	242
7.47.2.13 BSP_SD_WriteCpltCallback()	242
7.48 src/util_color.h File Reference	242
7.48.1 Macro Definition Documentation	243
7.48.1.1 DSY_COLOR_H	

CONTENTS xxxix

7.49	src/util_	_hal_map.	h File Refer	ence		 	 	 	 	 	 	 243
	7.49.1	Function	Documenta	tion		 	 	 	 	 	 	 243
		7.49.1.1	dsy_hal_m	ap_get_i	2c()	 	 	 	 	 	 	 243
		7.49.1.2	dsy_hal_m	ap_get_p	oin()	 	 	 	 	 	 	 244
		7.49.1.3	dsy_hal_m	ıap_get_p	oort()	 	 	 	 	 	 	 244
	7.49.2	Variable I	Documentat	ion		 	 	 	 	 	 	 244
		7.49.2.1	hi2c1			 	 	 	 	 	 	 244
		7.49.2.2	hi2c2			 	 	 	 	 	 	 245
		7.49.2.3	hi2c3			 	 	 	 	 	 	 245
		7.49.2.4	hi2c4			 	 	 	 	 	 	 245
7.50	src/util_	_ringbuffer	.h File Refe	rence .		 	 	 	 	 	 	 245
7.51	src/util_	_unique_ic	I.h File Refe	rence .		 	 	 	 	 	 	 245
	7.51.1	Function	Documenta	tion		 	 	 	 	 	 	 245
		7.51.1.1	dsy_get_u	nique_id(	<u> </u>	 	 	 	 	 	 	 246
7.52	src/util_	_wav_form	at.h File Re	ference		 	 	 	 	 	 	 246
Index												247

## **Chapter 1**

## libdaisy

Multi-layer hardware abstraction library for Daisy Product family

On STM32H7 MCUs

Lower-levels use STM32 HAL (local copy w/ modifications in Drivers/)

Prefixes and their meanings:

- sys System level configuration (clocks, dma, etc.)
- per Peripheral level, internal to MCU (i2c, spi, etc.)
- · dev External device support (external flash chips, DACs, codecs, etc.)
- hid User level interface elements (encoders, switches, audio, etc.)
- util library level elements used within the library (not included via daisy.h)
- daisy core API files (specific boards, platforms have extended user APIs that configure libdaisy more below).

Also included is a core/ folder containing:

- a generic Makefile that can be included in a project Makefile to simplify getting started
- · a linker script for defining the sections of memory used by the firmware
- core files for starting the hardware (system\_stm32h7xx.c, startup\_stm32h750xx.s, etc.)

#### 1.1 Using libdaisy

Due to the amount of hardware configuration and flexibility of the daisy platform, (in the present, and the future), a user can use libdaisy to define their own custom hardware, or include one of our supported board files to jumpstart the creativity, and hack on an existing piece of hardware.

If you are getting started, and have one of the Daisy Family Products, you can skip ahead to that section below.

2 libdaisy

#### 1.1.1 daisy.h

The base-level include file. This is all you need to include to create your own custom hardware that uses libdaisy.

daisy\_seed.h is an example of a board level file that utilizes libdaisy to define some hardware, and provide flexible access.

#### 1.1.2 daisy\_seed.h

The SOM-level include file. This can be used with any boards that use the Daisy Seed hardware.

Additional configuration files, with more specific hardware access are provided below for our supported hardware platforms.

#### 1.1.3 daisy\_platform.h

Several other pairs of files exist in the repo for each of the supported hardware platforms that work with Daisy Seed.

These are:

- · daisy\_field
- · daisy\_patch
- · daisy\_petal
- · daisy\_pod

With these files a number of additional initialization, and configuration is done by the library.

This allows a user to jump right into their new product with a simple api to do things without having a full understanding of what's going on under the hood.

With this flexible approach to the hardware configuration, we hope to promote a lot of fantastic hardware along with code to go with it.

# Chapter 2

# **Module Index**

## 2.1 Modules

Here is a list of all modules:

LIBDAISY	. 9
HUMAN_INTERFACE	. 10
AUDIO	. 11
CONTROLS	
PERIPHERALS	. 13
STM32_USB_OTG_DEVICE_LIBRARY	. 35
USBD_CDC_IF	. 14
USBD_CDC_IF_Exported_Defines	. 15
USBD_CDC_IF_Exported_Types	
USBD_CDC_IF_Exported_Macros	
USBD_CDC_IF_Exported_Variables	
USBD_CDC_IF_Exported_FunctionsPrototype	
USBD_DESC	
USBD_DESC_Exported_Constants	
USBD_DESC_Exported_Defines	
USBD_DESC_Exported_TypesDefinitions	
USBD_DESC_Exported_Macros	
USBD_DESC_Exported_Variables	
USBD_DESC_Exported_FunctionsPrototype	
USBD_OTG_DRIVER	
USBD_CONF	
USBD_CONF_Exported_Variables	
USBD_CONF_Exported_Defines	
USBD_CONF_Exported_Macros	
USBD_CONF_Exported_Types	
USBD_CONF_Exported_FunctionsPrototype	. 21

4 Module Index

# **Chapter 3**

# **Class Index**

### 3.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

,	37 39
Hardware Interface for control inputs	
Primarily designed for ADC input controls such as	
potentiometers, and control voltage.	
43	
codec_frame_t	45
color	46
daisy::Color	47
daisy::ControlChangeEvent	49
daisy::daisy_field	50
daisy::DaisyPatch	
Class that handles initializing all of the hardware specific to the Daisy Patch Board.	
Helper funtions are also in place to provide easy access to built-in controls and peripherals	52
daisy::DaisyPetal	
Helpers and hardware definitions for daisy petal	57
daisy::DaisyPod	
Class that handles initializing all of the hardware specific to the Daisy Patch Board.	
Helper funtions are also in place to provide easy access to built-in controls and peripherals	64
Helper funtions are also in place to provide easy access to built-in controls and peripherals daisy::DaisySeed	64
· · · · · · · · · · · · · · · · · · ·	64
daisy::DaisySeed  This is the higher-level interface for the Daisy board.	64 70
daisy::DaisySeed  This is the higher-level interface for the Daisy board.  All basic peripheral configuration/initialization is setup here	
daisy::DaisySeed  This is the higher-level interface for the Daisy board.  All basic peripheral configuration/initialization is setup here	70
daisy::DaisySeed  This is the higher-level interface for the Daisy board.  All basic peripheral configuration/initialization is setup here	70 73
daisy::DaisySeed  This is the higher-level interface for the Daisy board.  All basic peripheral configuration/initialization is setup here  dsy_audio_handle  dsy_dac_handle  dsy_gpio	70 73 74
daisy::DaisySeed  This is the higher-level interface for the Daisy board.  All basic peripheral configuration/initialization is setup here  dsy_audio_handle  dsy_dac_handle  dsy_gpio  dsy_gpio_pin	70 73 74 75
daisy::DaisySeed  This is the higher-level interface for the Daisy board.  All basic peripheral configuration/initialization is setup here  dsy_audio_handle  dsy_dac_handle  dsy_gpio  dsy_gpio_pin  dsy_i2c_handle	70 73 74 75 76
daisy::DaisySeed  This is the higher-level interface for the Daisy board.  All basic peripheral configuration/initialization is setup here  dsy_audio_handle  dsy_dac_handle  dsy_gpio  dsy_gpio_pin  dsy_i2c_handle  dsy_qspi_handle	70 73 74 75 76 77
daisy::DaisySeed  This is the higher-level interface for the Daisy board.  All basic peripheral configuration/initialization is setup here  dsy_audio_handle  dsy_dac_handle  dsy_gpio  dsy_gpio_pin  dsy_i2c_handle  dsy_qspi_handle  dsy_sai_handle	70 73 74 75 76 77
daisy::DaisySeed  This is the higher-level interface for the Daisy board.  All basic peripheral configuration/initialization is setup here  dsy_audio_handle  dsy_dac_handle  dsy_gpio  dsy_gpio_pin  dsy_i2c_handle  dsy_qspi_handle  dsy_sai_handle  DSY_SD_CardInfoTypeDef	70 73 74 75 76 77 78
daisy::DaisySeed  This is the higher-level interface for the Daisy board.  All basic peripheral configuration/initialization is setup here  dsy_audio_handle  dsy_dac_handle  dsy_gpio  dsy_gpio_pin  dsy_i2c_handle  dsy_aspi_handle  dsy_sai_handle  DSY_SD_CardInfoTypeDef  dsy_sdram_handle	70 73 74 75 76 77 78 79
daisy::DaisySeed  This is the higher-level interface for the Daisy board.  All basic peripheral configuration/initialization is setup here  dsy_audio_handle  dsy_dac_handle  dsy_gpio  dsy_gpio_pin  dsy_i2c_handle  dsy_aspi_handle  dsy_sai_handle  DSY_SD_CardInfoTypeDef  dsy_sdram_handle	70 73 74 75 76 77 78 81 82
daisy::DaisySeed This is the higher-level interface for the Daisy board. All basic peripheral configuration/initialization is setup here dsy_audio_handle dsy_dac_handle dsy_gpio dsy_gpio_pin dsy_i2c_handle dsy_qspi_handle dsy_qspi_handle dsy_sai_handle DSY_SD_CardInfoTypeDef dsy_sdram_handle dsy_sr_4021_handle	70 73 74 75 76 77 78 81 82

6 Class Index

FontDef	87
daisy::GateIn	
Generic Class for handling gate inputs through GPIO	88
daisy::Led	
LED Class providing simple Software PWM ability, etc	
Eventually this will work with hardware PWM, and external LED Driver devices as well	89
daisy::MidiEvent	90
daisy::MidiHandler	
Simple MIDI Handler	
Parses bytes from an input into valid MidiEvents.	
The MidiEvents fill a FIFO queue that the user can pop messages from	92
daisy::NoteOnEvent	95
daisy::OledDisplay	95
daisy::Parameter	100
daisy::RgbLed	102
daisy::RingBuffer< T, size >	
daisy::RingBuffer $<$ T, 0 $>$	107
daisy::SdmmcHandler	110
daisy::SdmmcHandlerInit	111
ShiftRegister595	
Device Driver for 8-bit shift register.	
CD74HC595 - 8-bit serial to parallel output shift	
daisy::SpiHandle	114
daisy::Switch	114
daisy::UartHandler	118
daisy::UsbHandle	
Interface for initializing and using the USB Peripherals on the daisy	121
WAV_FormatTypeDef	124
daisy::WavFileInfo	
daisy::WavPlayer	127

# **Chapter 4**

# File Index

## 4.1 File List

Here is a list of all documented files with brief descriptions:

<del></del>	131
src/daisy_core.h	134
src/daisy_field.h	
Hardware defines and helpers for daisy field platform	136
src/daisy_patch.h	143
src/daisy_petal.h	144
src/daisy_pod.h	144
src/daisy_seed.h	144
src/dev_codec_ak4556.h	
Driver for the AK4556 Stereo Codec	145
src/dev_codec_pcm3060.h	
Driver for the PCM3060 Codec	145
src/dev_codec_wm8731.h	
Driver for the WM8731 Codec	146
src/dev_codec_wm8731_frame.h	
WM8731 Codec framework	148
src/dev_flash_IS25LP064A.h	
IS25LP08D Commands	148
src/dev_flash_IS25LP080D.h	
IS25LP08D Commands	164
src/dev_leddriver.h	
Device driver for PCA9685 16-channel 12-bit PWM generator	180
src/dev_sdram.h	182
src/dev_sr_4021.h	
Device driver for the CD4021. Bit-banged serial shift input	185
src/dev_sr_595.h	188
src/fatfs.h	
Fatfs support	189
src/ffconf.h	191
src/hid_audio.h	
Audio Driver	
Configures Audio Device and provides callback for signal processing.	
Many of the hard-coded values here will change (increase), and/or	
be replaced by configurable options	198
src/hid_ctrl.h	

8 File Index

src/hid_encoder.h
src/hid_gatein.h
src/hid_led.h
src/hid_midi.h
src/hid_oled_display.h
src/hid_parameter.h
src/hid_rgb_led.h
src/hid_switch.h
src/hid_usb.h
src/hid_wavplayer.h
src/per_adc.h
src/per_dac.h
src/per_gpio.h
src/per_i2c.h
src/per_qspi.h
src/per_sai.h
src/per_sdmmc.h
src/per_spi.h
src/per_tim.h
src/per_uart.h
src/stm32h7xx_hal_conf.h
src/sys_dma.h
src/sys_system.h
src/usbd_cdc_if.h
: Header for usbd_cdc_if.c file
src/usbd_conf.h
: Header for usbd_conf.c file
src/usbd_desc.h
: Header for usbd_conf.c file
src/util_bsp_sd_diskio.h
src/util_color.h
src/util_hal_map.h
src/util_oled_fonts.h
src/util_ringbuffer.h
src/util_sd_diskio.h
src/util_unique_id.h
src/util_wav_format.h

# **Chapter 5**

## **Module Documentation**

#### 5.1 LIBDAISY

The daisy library.

#### **Modules**

• HUMAN\_INTERFACE

Interface with the world.

• PERIPHERALS

Peripheral devices, not meant for human interaction.

#### 5.1.1 Detailed Description

The daisy library.

## 5.2 HUMAN\_INTERFACE

Interface with the world.

#### Modules

• AUDIO

Embedded Audio Engine.

• CONTROLS

Hardware Controls.

#### 5.2.1 Detailed Description

Interface with the world.

5.3 AUDIO 11

#### 5.3 AUDIO

Embedded Audio Engine.

#### **Files**

• file hid\_audio.h

Audio Driver Configures Audio Device and provides callback for signal processing. Many of the hard-coded values here will change (increase), and/or be replaced by configurable options.

#### 5.3.1 Detailed Description

Embedded Audio Engine.

## 5.4 CONTROLS

Hardware Controls.

#### **Files**

- file hid\_ctrl.h
- file hid\_encoder.h
- file hid\_parameter.h
- file hid\_switch.h

### 5.4.1 Detailed Description

Hardware Controls.

5.5 PERIPHERALS 13

## 5.5 PERIPHERALS

Peripheral devices, not meant for human interaction.

Peripheral devices, not meant for human interaction.

## 5.6 USBD\_CDC\_IF

Usb VCP device module.

#### **Modules**

• USBD\_CDC\_IF\_Exported\_Defines

Defines.

• USBD\_CDC\_IF\_Exported\_Types

Types.

• USBD\_CDC\_IF\_Exported\_Macros

Aliases.

• USBD\_CDC\_IF\_Exported\_Variables

Public variables.

• USBD\_CDC\_IF\_Exported\_FunctionsPrototype

Public functions declaration.

#### 5.6.1 Detailed Description

Usb VCP device module.

## 5.7 USBD\_CDC\_IF\_Exported\_Defines

Defines.

Defines.

## 5.8 USBD\_CDC\_IF\_Exported\_Types

Types.

### **Typedefs**

• typedef void(\* CDC\_ReceiveCallback) (uint8\_t \*buf, uint32\_t \*size)

#### 5.8.1 Detailed Description

Types.

#### 5.8.2 Typedef Documentation

#### 5.8.2.1 CDC\_ReceiveCallback

typedef void(\* CDC\_ReceiveCallback) (uint8\_t \*buf, uint32\_t \*size)

#### **Parameters**

buf	buffer
size	buffer size

## 5.9 USBD\_CDC\_IF\_Exported\_Macros

Aliases.

Aliases.

## 5.10 USBD\_CDC\_IF\_Exported\_Variables

Public variables.

#### **Variables**

- USBD\_CDC\_ItfTypeDef USBD\_Interface\_fops\_FS
- USBD\_CDC\_ItfTypeDef USBD\_Interface\_fops\_HS

#### 5.10.1 Detailed Description

Public variables.

#### 5.10.2 Variable Documentation

5.10.2.1 USBD\_Interface\_fops\_FS

USBD\_CDC\_ItfTypeDef USBD\_Interface\_fops\_FS

CDC Interface callback.

5.10.2.2 USBD\_Interface\_fops\_HS

USBD\_CDC\_ItfTypeDef USBD\_Interface\_fops\_HS

CDC Interface callback.

### 5.11 USBD\_CDC\_IF\_Exported\_FunctionsPrototype

Public functions declaration.

#### **Functions**

```
• void CDC_Set_Rx_Callback_FS (CDC_ReceiveCallback cb)
```

- uint8\_t CDC\_Transmit\_FS (uint8\_t \*Buf, uint16\_t Len)
- uint8\_t CDC\_Transmit\_HS (uint8\_t \*Buf, uint16\_t Len)

#### 5.11.1 Detailed Description

Public functions declaration.

#### 5.11.2 Function Documentation

```
5.11.2.1 CDC_Set_Rx_Callback_FS()
```

&

#### 5.11.2.2 CDC\_Transmit\_FS()

&

#### 5.11.2.3 CDC\_Transmit\_HS()

&

## 5.12 USBD\_CONF

Configuration file for Usb otg low level driver.

#### **Modules**

• USBD\_CONF\_Exported\_Variables

Public variables.

• USBD\_CONF\_Exported\_Defines

Defines for configuration of the Usb device.

• USBD\_CONF\_Exported\_Macros

Aliases.

• USBD\_CONF\_Exported\_Types

Types.

• USBD\_CONF\_Exported\_FunctionsPrototype

Declaration of public functions for Usb device.

#### 5.12.1 Detailed Description

Configuration file for Usb otg low level driver.

## 5.13 USBD\_CONF\_Exported\_Variables

Public variables.

Public variables.

#### 5.14 USBD\_CONF\_Exported\_Defines

Defines for configuration of the Usb device.

#### **Macros**

- #define USBD\_MAX\_NUM\_INTERFACES 1U
- #define USBD\_MAX\_NUM\_CONFIGURATION 1U
- #define USBD\_MAX\_STR\_DESC\_SIZ 512U
- #define USBD\_SUPPORT\_USER\_STRING 0U
- #define USBD\_DEBUG\_LEVEL 3U
- #define USBD\_LPM\_ENABLED 0U
- #define USBD SELF POWERED 1U
- #define DEVICE\_FS 0
- #define DEVICE\_HS 1

#### 5.14.1 Detailed Description

Defines for configuration of the Usb device.

#### 5.14.2 Macro Definition Documentation

```
5.14.2.1 DEVICE_FS
```

#define DEVICE\_FS 0

FS and HS identification

5.14.2.2 DEVICE\_HS

#define DEVICE\_HS 1

ጴ

5.14.2.3 USBD\_DEBUG\_LEVEL

#define USBD\_DEBUG\_LEVEL 3U

&

#### 5.14.2.4 USBD\_LPM\_ENABLED

#define USBD\_LPM\_ENABLED 0U

8

#### 5.14.2.5 USBD\_MAX\_NUM\_CONFIGURATION

#define USBD\_MAX\_NUM\_CONFIGURATION 1U

&

#### 5.14.2.6 USBD\_MAX\_NUM\_INTERFACES

#define USBD\_MAX\_NUM\_INTERFACES 1U

&

#### 5.14.2.7 USBD\_MAX\_STR\_DESC\_SIZ

#define USBD\_MAX\_STR\_DESC\_SIZ 512U

&

#### 5.14.2.8 USBD\_SELF\_POWERED

#define USBD\_SELF\_POWERED 1U

&

#### 5.14.2.9 USBD\_SUPPORT\_USER\_STRING

 $\verb|#define USBD_SUPPORT_USER_STRING 0U|\\$ 

&

### 5.15 USBD\_CONF\_Exported\_Macros

Aliases.

#### **Macros**

- #define USBD\_malloc malloc
- #define USBD\_free free
- #define USBD\_memset memset
- #define USBD\_memcpy memcpy
- #define USBD\_Delay HAL\_Delay
- #define USBD\_UsrLog(...)
- #define USBD\_ErrLog(...)
- #define USBD\_DbgLog(...)

#### 5.15.1 Detailed Description

Aliases.

#### 5.15.2 Macro Definition Documentation

```
5.15.2.1 USBD_DbgLog
```

#### Value:

```
printf("DEBUG : "); \
    printf(__VA_ARGS__); \
    printf("\n");
```

&

#### 5.15.2.2 USBD\_Delay

#define USBD\_Delay HAL\_Delay

Alias for delay.

```
5.15.2.3 USBD_ErrLog
```

#### Value:

```
printf("ERROR: "); \
   printf(__VA_ARGS__); \
   printf("\n");
```

&

#### 5.15.2.4 USBD\_free

```
#define USBD_free free
```

Alias for memory release.

#### 5.15.2.5 USBD\_malloc

```
#define USBD_malloc malloc
```

Alias for memory allocation.

#### 5.15.2.6 USBD\_memcpy

```
#define USBD_memcpy memcpy
```

Alias for memory copy.

#### 5.15.2.7 USBD\_memset

```
#define USBD_memset memset
```

Alias for memory set.

#### 5.15.2.8 USBD\_UsrLog

#### Value:

```
\begin{array}{c} \text{printf}(\underline{\hspace{0.1cm}} \text{VA\_ARGS}\underline{\hspace{0.1cm}}); \ \backslash \\ \text{printf}("\n"); \end{array}
```

&

5.16 USBD CONF Exported Ty	pes
----------------------------	-----

Types.

Types.

## 5.17 USBD\_CONF\_Exported\_FunctionsPrototype

Declaration of public functions for Usb device.

Declaration of public functions for Usb device.

#### 5.18 USBD\_DESC

Usb device descriptors module.

#### **Modules**

• USBD\_DESC\_Exported\_Constants

Constants.

• USBD\_DESC\_Exported\_Defines

Defines.

• USBD\_DESC\_Exported\_TypesDefinitions

Types.

• USBD\_DESC\_Exported\_Macros

Aliases.

• USBD\_DESC\_Exported\_Variables

Public variables.

• USBD\_DESC\_Exported\_FunctionsPrototype

Public functions declaration.

#### 5.18.1 Detailed Description

Usb device descriptors module.

### 5.19 USBD\_DESC\_Exported\_Constants

Constants.

#### **Macros**

- #define DEVICE\_ID1 (UID\_BASE)
- #define DEVICE\_ID2 (UID\_BASE + 0x4)
- #define DEVICE\_ID3 (UID\_BASE + 0x8)
- #define USB\_SIZ\_STRING\_SERIAL 0x1A

#### 5.19.1 Detailed Description

Constants.

#### 5.19.2 Macro Definition Documentation

```
5.19.2.1 DEVICE_ID1
```

#define DEVICE\_ID1 (UID\_BASE)

&

#### 5.19.2.2 DEVICE\_ID2

#define DEVICE\_ID2 (UID\_BASE + 0x4)

&

#### 5.19.2.3 DEVICE\_ID3

#define DEVICE\_ID3 (UID\_BASE + 0x8)

ጲ

#### 5.19.2.4 USB\_SIZ\_STRING\_SERIAL

#define USB\_SIZ\_STRING\_SERIAL 0x1A

&

## 5.20 USBD\_DESC\_Exported\_Defines

Defines.

Defines.

# 5.21 USBD\_DESC\_Exported\_TypesDefinitions

Types.

Types.

32 Module Documentation

# 5.22 USBD\_DESC\_Exported\_Macros

Aliases.

Aliases.

# 5.23 USBD\_DESC\_Exported\_Variables

Public variables.

## **Variables**

- USBD\_DescriptorsTypeDef HS\_Desc
- USBD\_DescriptorsTypeDef FS\_Desc

# 5.23.1 Detailed Description

Public variables.

# 5.23.2 Variable Documentation

## 5.23.2.1 FS\_Desc

USBD\_DescriptorsTypeDef FS\_Desc

Descriptor for the Usb device.

## 5.23.2.2 HS\_Desc

USBD\_DescriptorsTypeDef HS\_Desc

Descriptor for the Usb device.

34 Module Documentation

# 5.24 USBD\_DESC\_Exported\_FunctionsPrototype

Public functions declaration.

Public functions declaration.

# 5.25 STM32\_USB\_OTG\_DEVICE\_LIBRARY

For Usb device.

# **Modules**

- USBD\_CDC\_IF
  - Usb VCP device module.
- USBD\_DESC

Usb device descriptors module.

# 5.25.1 Detailed Description

For Usb device.

< Define to prevent recursive inclusion -----

36 Module Documentation

# 5.26 USBD\_OTG\_DRIVER

# Modules

• USBD\_CONF

Configuration file for Usb otg low level driver.

# 5.26.1 Detailed Description

# **Chapter 6**

# **Class Documentation**

# 6.1 daisy::AdcChannelConfig Struct Reference

```
#include <per_adc.h>
```

# **Public Types**

enum MuxPin { MUX\_SEL\_0, MUX\_SEL\_1, MUX\_SEL\_2, MUX\_SEL\_LAST }

## **Public Member Functions**

- void InitSingle (dsy\_gpio\_pin pin)
- void InitMux (dsy\_gpio\_pin adc\_pin, dsy\_gpio\_pin mux\_0, dsy\_gpio\_pin mux\_1, dsy\_gpio\_pin mux\_2, size
   \_t channels)

# **Public Attributes**

- dsy\_gpio pin\_
- dsy\_gpio mux\_pin\_ [MUX\_SEL\_LAST]
- uint8\_t mux\_channels\_

# 6.1.1 Detailed Description

Configuration Structure for a given channel

# 6.1.2 Member Enumeration Documentation

#### 6.1.2.1 MuxPin

enum daisy::AdcChannelConfig::MuxPin

Which pin to use for multiplexing

# Enumerator

MUX_SEL_0	&
MUX_SEL_1	&
MUX_SEL_2	&
MUX_SEL_LAST	&

#### 6.1.3 Member Function Documentation

#### 6.1.3.1 InitMux()

Initializes a single ADC pin as a Multiplexed ADC. Requires a CD4051 Multiplexor connected to the pin Internal Callbacks handle the pin addressing.

### **Parameters**

channels	must be 1-8
mux_0	First mux pin
mux_1	Second mux pin
mux_2	Third mux pin
adc_pin	&

## 6.1.3.2 InitSingle()

Initializes a single ADC pin as an ADC.

## **Parameters**

pin	Pin to init.

## 6.1.4 Member Data Documentation

```
6.1.4.1 mux_channels_
uint8_t daisy::AdcChannelConfig::mux_channels_
&
6.1.4.2 mux_pin_
dsy_gpio daisy::AdcChannelConfig::mux_pin_[MUX_SEL_LAST]
&
6.1.4.3 pin_
dsy_gpio daisy::AdcChannelConfig::pin_
```

The documentation for this struct was generated from the following file:

• src/per\_adc.h

# 6.2 daisy::AdcHandle Class Reference

```
#include <per_adc.h>
```

# **Public Types**

```
    enum OverSampling {
        OVS_NONE, OVS_4, OVS_8, OVS_16,
        OVS_32, OVS_64, OVS_128, OVS_256,
        OVS_512, OVS_1024, OVS_LAST }
```

#### **Public Member Functions**

```
• void Init (AdcChannelConfig *cfg, size_t num_channels, OverSampling ovs=OVS_32)
```

- void Start ()
- void Stop ()
- uint16\_t Get (uint8\_t chn)
- uint16\_t \* GetPtr (uint8\_t chn)
- float GetFloat (uint8\_t chn)
- uint16\_t GetMux (uint8\_t chn, uint8\_t idx)
- uint16\_t \* GetMuxPtr (uint8\_t chn, uint8\_t idx)
- float GetMuxFloat (uint8\_t chn, uint8\_t idx)

# 6.2.1 Detailed Description

Handler for analog to digital conversion

# 6.2.2 Member Enumeration Documentation

# 6.2.2.1 OverSampling

```
enum daisy::AdcHandle::OverSampling
```

Supported oversampling amounts

#### Enumerator

OVS_NONE	&
OVS_4	&
OVS_8	&
OVS_16	&
OVS_32	&
OVS_64	&
OVS_128	&
OVS_256	&
OVS_512	&
OVS_1024	&
OVS_LAST	&

# 6.2.3 Member Function Documentation

# 6.2.3.1 Get()

Single channel getter

# **Parameters**

chn	channel to get

#### Returns

Converted value

# 6.2.3.2 GetFloat()

```
float daisy::AdcHandle::GetFloat ( \label{eq:continuous} \mbox{uint8\_t} \ \ chn \ )
```

Get floating point from single channel

#### **Parameters**

```
chn Channel to get from
```

## Returns

Floating point converted value

# 6.2.3.3 GetMux()

Getters for multiplexed inputs on a single channel (up to 8 per ADC input).

#### **Parameters**

chn	Channel to get from
idx	&

## Returns

data

#### 6.2.3.4 GetMuxFloat()

Getters for multiplexed inputs on a single channel (up to 8 per ADC input).

## **Parameters**

chn	Channel to get from
idx	&

# Returns

Floating point data

# 6.2.3.5 GetMuxPtr()

Getters for multiplexed inputs on a single channel. (Max 8 per chan)

## **Parameters**

chn	Channel to get from
idx	&

# Returns

Pointer to data

## 6.2.3.6 GetPtr()

Get pointer to a value from a single channel

# **Parameters**

chn

#### **Returns**

Pointer to converted value

#### 6.2.3.7 Init()

```
void daisy::AdcHandle::Init (
         AdcChannelConfig * cfg,
         size_t num_channels,
         OverSampling ovs = OVS_32 )
```

Initializes the ADC with the pins passed in.

#### **Parameters**

*cfg	an array of AdcChannelConfig of the desired channel
num_channels	number of ADC channels to initialize
ovs	Oversampling amount - Defaults to OVS_32

#### 6.2.3.8 Start()

```
void daisy::AdcHandle::Start ( )
```

Starts reading from the ADC

#### 6.2.3.9 Stop()

```
void daisy::AdcHandle::Stop ( )
```

# Stops reading from the ADC

The documentation for this class was generated from the following file:

• src/per\_adc.h

# 6.3 daisy::AnalogControl Class Reference

Hardware Interface for control inputs Primarily designed for ADC input controls such as potentiometers, and control voltage.

#include <hid\_ctrl.h>

#### **Public Member Functions**

- AnalogControl ()
- ∼AnalogControl ()
- void Init (uint16\_t \*adcptr, float sr, bool flip=false, bool invert=false, float slew\_seconds=0.002f)
- void InitBipolarCv (uint16\_t \*adcptr, float sr)
- float Process ()
- float Value () const

# 6.3.1 Detailed Description

Hardware Interface for control inputs Primarily designed for ADC input controls such as potentiometers, and control voltage.

.

**Author** 

Stephen Hensley

Date

November 2019

## 6.3.2 Constructor & Destructor Documentation

```
6.3.2.1 AnalogControl()
```

```
daisy::AnalogControl::AnalogControl ( ) [inline]
```

Constructor

# 6.3.2.2 $\sim$ AnalogControl()

```
daisy::AnalogControl::~AnalogControl ( ) [inline]
```

destructor

# 6.3.3 Member Function Documentation

## 6.3.3.1 Init()

Initializes the control

#### **Parameters**

*adcptr	is a pointer to the raw adc read value – This can be acquired with dsy_adc_get_rawptr(), or dsy_adc_get_mux_rawptr()
sr	is the samplerate in Hz that the Process function will be called at.
flip	determines whether the input is flipped (i.e. 1.f - input) or not before being processed.1
invert	determines whether the input is inverted (i.e1.f * input) or note before being processed.
slew_seconds	is the slew time in seconds that it takes for the control to change to a new value.

## 6.3.3.2 InitBipolarCv()

```
void daisy::AnalogControl::InitBipolarCv (  \mbox{uint16\_t} \ * \ adcptr,   \mbox{float} \ sr \ )
```

This Initializes the AnalogControl for a -5V to 5V inverted input All of the Init details are the same otherwise

#### **Parameters**

*adcptr	Pointer to analog digital converter
sr	Audio engine sample rate

#### 6.3.3.3 Process()

```
float daisy::AnalogControl::Process ( )
```

Filters, and transforms a raw ADC read into a normalized range. this should be called at the rate of specified by samplerate at Init time. Default Initializations will return 0.0 -> 1.0 Bi-polar CV inputs will return -1.0 -> 1.0

#### 6.3.3.4 Value()

```
float daisy::AnalogControl::Value ( ) const [inline]
```

Returns the current stored value, without reprocessing

The documentation for this class was generated from the following file:

• src/hid\_ctrl.h

# 6.4 codec\_frame\_t Struct Reference

```
#include <dev_codec_wm8731_frame.h>
```

# **Public Attributes**

- short I
- short r

# 6.4.1 Detailed Description

&

# 6.4.2 Member Data Documentation

The documentation for this struct was generated from the following file:

• src/dev\_codec\_wm8731\_frame.h

# 6.5 color Struct Reference

```
#include <dev_leddriver.h>
```

# **Public Attributes**

- uint16\_t red
- uint16\_t green
- uint16\_t blue

# 6.5.1 Detailed Description

Simple color struct Different from util\_color only in type (0-4095 vs 0-1) This could easily be migrated to work with those instead.

# 6.5.2 Member Data Documentation

```
6.5.2.1 blue

uint16_t color::blue

&

6.5.2.2 green

uint16_t color::green

&

6.5.2.3 red

uint16_t color::red

&
```

The documentation for this struct was generated from the following file:

• src/dev\_leddriver.h

# 6.6 daisy::Color Class Reference

```
#include <util_color.h>
```

# **Public Types**

enum PresetColor {
 RED, GREEN, BLUE, WHITE,
 PURPLE, CYAN, GOLD, OFF,
 LAST }

# **Public Member Functions**

- void Init (PresetColor c)
- void Init (float red, float green, float blue)
- float Red () const
- float Green () const
- float Blue () const

# 6.6.1 Detailed Description

Class for handling simple colors

## 6.6.2 Member Enumeration Documentation

# 6.6.2.1 PresetColor

```
enum daisy::Color::PresetColor
```

List of colors that have a preset RGB value

#### Enumerator

RED	&
GREEN	&
BLUE	&
WHITE	&
PURPLE	&
CYAN	&
GOLD	&
OFF	&
LAST	&

# 6.6.3 Member Function Documentation

```
6.6.3.1 Blue()
```

```
float daisy::Color::Blue ( ) const [inline]
```

Returns the 0-1 value for Blue

# 6.6.3.2 Green()

```
float daisy::Color::Green ( ) const [inline]
```

Returns the 0-1 value for Green

```
6.6.3.3 Init() [1/2]
```

Initializes the Color with a given preset.

#### **Parameters**

```
c Color to init to
```

Initializes the Color with a specific RGB value red, green, and blue should be floats between 0 and 1

#### **Parameters**

red	Red value
green	Green value
blue	Blue value

# 6.6.3.5 Red()

```
float daisy::Color::Red ( ) const [inline]
```

Returns the 0-1 value for Red

The documentation for this class was generated from the following file:

• src/util\_color.h

# 6.7 daisy::ControlChangeEvent Struct Reference

```
#include <hid_midi.h>
```

#### **Public Attributes**

- int channel
- uint8\_t control\_number
- uint8\_t value

# 6.7.1 Detailed Description

Struct containing control number, and value for a given channel. Can be made from MidiEvent

# 6.7.2 Member Data Documentation

# 6.7.2.1 channel int daisy::ControlChangeEvent::channel & 6.7.2.2 control\_number

uint8\_t daisy::ControlChangeEvent::control\_number

&

## 6.7.2.3 value

uint8\_t daisy::ControlChangeEvent::value

ጴ

The documentation for this struct was generated from the following file:

src/hid\_midi.h

# 6.8 daisy::daisy\_field Struct Reference

```
#include <daisy_field.h>
```

# **Public Attributes**

- daisy::DaisySeed seed
- daisy::Switch switches [SW\_LAST]
- dsy\_gpio gate\_in
- dsy\_gpio gate\_out
- dsy\_sr\_4021\_handle keyboard\_sr
- AnalogControl knobs [KNOB\_LAST]
- AnalogControl cvs [CV\_LAST]

# 6.8.1 Detailed Description

Struct containing hardware defines and daisy seed

## 6.8.2 Member Data Documentation

```
6.8.2.1 cvs
AnalogControl daisy::daisy_field::cvs[CV_LAST]
Array of cv ins
6.8.2.2 gate_in
dsy_gpio daisy::daisy_field::gate_in
Gate input.
6.8.2.3 gate_out
dsy_gpio daisy::daisy_field::gate_out
Gate output
6.8.2.4 keyboard_sr
dsy_sr_4021_handle daisy::daisy_field::keyboard_sr
Keyboard shift register
6.8.2.5 knobs
AnalogControl daisy::daisy_field::knobs[KNOB_LAST]
Array of hardware knobs
6.8.2.6 seed
daisy::DaisySeed daisy::daisy_field::seed
Daisy seed
6.8.2.7 switches
daisy::Switch daisy::daisy_field::switches[SW_LAST]
Array of hardware switches
```

The documentation for this struct was generated from the following file:

• src/daisy\_field.h

# 6.9 daisy::DaisyPatch Class Reference

Class that handles initializing all of the hardware specific to the Daisy Patch Board. Helper funtions are also in place to provide easy access to built-in controls and peripherals.

```
#include <daisy_patch.h>
```

# **Public Types**

```
    enum Ctrl {
        CTRL_1, CTRL_2, CTRL_3, CTRL_4,
        CTRL_LAST }
    enum GateInput { GATE_IN_1, GATE_IN_2, GATE_IN_LAST }
```

#### **Public Member Functions**

```
• DaisyPatch ()
```

- ∼DaisyPatch ()
- void Init ()
- void DelayMs (size\_t del)
- void SetAudioBlockSize (size\_t size)
- void StartAudio (dsy\_audio\_mc\_callback cb)
- void ChangeAudioCallback (dsy audio callback cb)
- void StartAdc ()
- float AudioSampleRate ()
- size\_t AudioBlockSize ()
- float AudioCallbackRate ()
- void UpdateAnalogControls ()
- float GetCtrlValue (Ctrl k)
- · void DebounceControls ()
- void DisplayControls (bool invert=true)

# **Public Attributes**

- · DaisySeed seed
- · Encoder encoder
- AnalogControl controls [CTRL\_LAST]
- GateIn gate\_input [GATE\_IN\_LAST]
- · MidiHandler midi
- · OledDisplay display
- dsy\_gpio gate\_output

## 6.9.1 Detailed Description

Class that handles initializing all of the hardware specific to the Daisy Patch Board. Helper funtions are also in place to provide easy access to built-in controls and peripherals.

#### Author

Stephen Hensley

Date

November 2019

## 6.9.2 Member Enumeration Documentation

```
6.9.2.1 Ctrl
```

```
enum daisy::DaisyPatch::Ctrl
```

Enum of Ctrls to represent the four CV/Knob combos on the Patch

## 6.9.2.2 GateInput

```
enum daisy::DaisyPatch::GateInput
```

Daisy patch gate inputs

Enumerator

```
GATE_IN_LAST <
```

## 6.9.3 Constructor & Destructor Documentation

## 6.9.3.1 DaisyPatch()

```
daisy::DaisyPatch::DaisyPatch ( ) [inline]
```

Constructor

# 6.9.3.2 $\sim$ DaisyPatch()

```
daisy::DaisyPatch::~DaisyPatch ( ) [inline]
```

Destructor

# 6.9.4 Member Function Documentation

# 6.9.4.1 AudioBlockSize()

```
size_t daisy::DaisyPatch::AudioBlockSize ( )
```

Get block size

#### 6.9.4.2 AudioCallbackRate()

```
float daisy::DaisyPatch::AudioCallbackRate ( )
```

Get callback rate

## 6.9.4.3 AudioSampleRate()

```
float daisy::DaisyPatch::AudioSampleRate ( )
```

Get sample rate

## 6.9.4.4 ChangeAudioCallback()

```
void daisy::DaisyPatch::ChangeAudioCallback ( {\tt dsy\_audio\_callback}\ cb\ )
```

Change to a different callback function.

#### **Parameters**

cb New callback function.

## 6.9.4.5 DebounceControls()

```
void daisy::DaisyPatch::DebounceControls ( )
```

Debounce analog controls. Call at same rate as reading controls.

# 6.9.4.6 DelayMs()

Wait some ms before going on.

## **Parameters**

```
del Delay time in ms.
```

## 6.9.4.7 DisplayControls()

```
void daisy::DaisyPatch::DisplayControls (
```

```
bool invert = true )
```

Control the display

## 6.9.4.8 GetCtrlValue()

Get value for a partiular control

#### **Parameters**

```
k Which control to get
```

## 6.9.4.9 Init()

```
void daisy::DaisyPatch::Init ( )
```

Initializes the daisy seed, and patch hardware.

#### 6.9.4.10 SetAudioBlockSize()

Audio Block size defaults to 48. Change it using this function before StartingAudio

# **Parameters**

```
size Audio block size.
```

#### 6.9.4.11 StartAdc()

```
void daisy::DaisyPatch::StartAdc ( )
```

Start analog to digital conversion.

## 6.9.4.12 StartAudio()

Start audio output.

#### **Parameters**

cb Audio callback function

```
6.9.4.13 UpdateAnalogControls()
```

```
void daisy::DaisyPatch::UpdateAnalogControls ( )
```

Call at same rate as reading controls for good reads.

#### 6.9.5 Member Data Documentation

```
6.9.5.1 controls
```

```
AnalogControl daisy::DaisyPatch::controls[CTRL_LAST]
```

Array of controls

## 6.9.5.2 display

```
OledDisplay daisy::DaisyPatch::display
```

&

# 6.9.5.3 encoder

```
Encoder daisy::DaisyPatch::encoder
```

**Encoder** object

# 6.9.5.4 gate\_input

```
GateIn daisy::DaisyPatch::gate_input[GATE_IN_LAST]
```

Gate inputs

# 6.9.5.5 gate\_output

```
dsy_gpio daisy::DaisyPatch::gate_output
```

&

```
6.9.5.6 midi
MidiHandler daisy::DaisyPatch::midi
Handles midi
6.9.5.7 seed
```

DaisySeed daisy::DaisyPatch::seed

Seed object

The documentation for this class was generated from the following file:

· src/daisy\_patch.h

# 6.10 daisy::DaisyPetal Class Reference

Helpers and hardware definitions for daisy petal.

```
#include <daisy_petal.h>
```

# **Public Types**

```
enum Sw {
    SW_1, SW_2, SW_3, SW_4,
    SW_5, SW_6, SW_7, SW_LAST }
enum Knob {
    KNOB_1, KNOB_2, KNOB_3, KNOB_4,
    KNOB_5, KNOB_6, KNOB_LAST }
enum RingLed {
    RING_LED_1, RING_LED_2, RING_LED_3, RING_LED_4,
    RING_LED_5, RING_LED_6, RING_LED_7, RING_LED_8,
    RING_LED_LAST }
enum FootswitchLed {
    FOOTSWITCH_LED_1, FOOTSWITCH_LED_2, FOOTSWITCH_LED_3, FOOTSWITCH_LED_4,
    FOOTSWITCH_LED_LAST }
```

#### **Public Member Functions**

- · DaisyPetal ()
- $\sim$ DaisyPetal ()
- void Init ()
- void DelayMs (size\_t del)
- void SetAudioBlockSize (size\_t size)
- void StartAudio (dsy\_audio\_callback cb)
- void ChangeAudioCallback (dsy\_audio\_callback cb)
- void StartAdc ()
- float AudioSampleRate ()
- size\_t AudioBlockSize ()
- float AudioCallbackRate ()
- void UpdateAnalogControls ()
- float GetKnobValue (Knob k)
- float GetExpression ()
- void DebounceControls ()
- void ClearLeds ()
- void UpdateLeds ()
- void SetRingLed (RingLed idx, float r, float g, float b)
- void SetFootswitchLed (FootswitchLed idx, float bright)

# **Public Attributes**

- DaisySeed seed
- · Encoder encoder
- AnalogControl knob [KNOB\_LAST]
- AnalogControl expression
- Switch switches [SW\_LAST]
- RgbLed ring\_led [8]
- Led footswitch\_led [4]

# 6.10.1 Detailed Description

Helpers and hardware definitions for daisy petal.

## 6.10.2 Member Enumeration Documentation

#### 6.10.2.1 FootswitchLed

enum daisy::DaisyPetal::FootswitchLed

## footswitch leds

#### Enumerator

FOOTSWITCH_LED_1	&
FOOTSWITCH_LED_2	&
FOOTSWITCH_LED_3	&
FOOTSWITCH_LED_4	&
FOOTSWITCH_LED_LAST	&

#### 6.10.2.2 Knob

enum daisy::DaisyPetal::Knob

#### Knobs

# Enumerator

KNOB_1	&
KNOB_2	&
KNOB_3	&
KNOB_4	&
KNOB_5	&
KNOB_6	&
KNOR LAST	- χ.

# 6.10.2.3 RingLed

enum daisy::DaisyPetal::RingLed

# Leds in ringled

# Enumerator

RING_LED_1	&
RING_LED_2	&
RING_LED_3	&
RING_LED_4	&
RING_LED_5	&
RING_LED_6	&
RING_LED_7	&
RING_LED_8	&
RING_LED_LAST	&

## 6.10.2.4 Sw

enum daisy::DaisyPetal::Sw

# Switches

## Enumerator

SW_1	Footswitch
SW_2	Footswitch
SW_3	Footswitch
SW_4	Footswitch
SW_5	Toggle
SW_6	Toggle
SW_7	Toggle
SW_LAST	Last enum item

## 6.10.3 Constructor & Destructor Documentation

# 6.10.3.1 DaisyPetal()

daisy::DaisyPetal::DaisyPetal ( ) [inline]

# Constructor

```
6.10.3.2 \sim DaisyPetal()
daisy::DaisyPetal::~DaisyPetal ( ) [inline]
Destructor
6.10.4 Member Function Documentation
6.10.4.1 AudioBlockSize()
size_t daisy::DaisyPetal::AudioBlockSize ( )
Get audio block size
6.10.4.2 AudioCallbackRate()
float daisy::DaisyPetal::AudioCallbackRate ( )
Get callback rate
6.10.4.3 AudioSampleRate()
float daisy::DaisyPetal::AudioSampleRate ( )
Device audio sample rate.
6.10.4.4 ChangeAudioCallback()
void daisy::DaisyPetal::ChangeAudioCallback (
              dsy_audio_callback cb )
Change callback function
Parameters
 cb | New callback function.
6.10.4.5 ClearLeds()
void daisy::DaisyPetal::ClearLeds ( )
```

Turn all leds off

## 6.10.4.6 DebounceControls()

```
void daisy::DaisyPetal::DebounceControls ( )
```

Debounce inputs.

# 6.10.4.7 DelayMs()

Wait before moving on.

#### **Parameters**

```
del Delay time in ms.
```

## 6.10.4.8 GetExpression()

```
float daisy::DaisyPetal::GetExpression ( )
```

&

# 6.10.4.9 GetKnobValue()

Get value per knob.

# **Parameters**

```
k Which knob to get
```

# Returns

Floating point knob position.

# 6.10.4.10 Init()

```
void daisy::DaisyPetal::Init ( )
```

# Initialize daisy petal

# 6.10.4.11 SetAudioBlockSize()

```
void daisy::DaisyPetal::SetAudioBlockSize ( {\tt size\_t \ size} \ )
```

Set size of audio blocks.

# **Parameters**

```
size Audio block size
```

#### 6.10.4.12 SetFootswitchLed()

Set footswitch LED

## **Parameters**

idx	Led Index
bright	Brightness

## 6.10.4.13 SetRingLed()

```
void daisy::DaisyPetal::SetRingLed (
    RingLed idx,
    float r,
    float g,
    float b)
```

Set ring LED colors

# **Parameters**

idx	Index to set
r	Red value
g	Green value
b	Blue value

```
6.10.4.14 StartAdc()
void daisy::DaisyPetal::StartAdc ( )
Start analog to digital conversion.
6.10.4.15 StartAudio()
void daisy::DaisyPetal::StartAudio (
              dsy_audio_callback cb )
Start audio callback
Parameters
 cb Callback function.
6.10.4.16 UpdateAnalogControls()
void daisy::DaisyPetal::UpdateAnalogControls ( )
Call at the same frequency as controls are read for stable readings.
6.10.4.17 UpdateLeds()
void daisy::DaisyPetal::UpdateLeds ( )
Update Leds to values you had set.
6.10.5 Member Data Documentation
6.10.5.1 encoder
Encoder daisy::DaisyPetal::encoder
&
6.10.5.2 expression
```

&

AnalogControl daisy::DaisyPetal::expression

```
6.10.5.3 footswitch_led
Led daisy::DaisyPetal::footswitch_led[4]
6.10.5.4 knob
AnalogControl daisy::DaisyPetal::knob[KNOB_LAST]
&
6.10.5.5 ring_led
RgbLed daisy::DaisyPetal::ring_led[8]
&
6.10.5.6 seed
DaisySeed daisy::DaisyPetal::seed
6.10.5.7 switches
Switch daisy::DaisyPetal::switches[SW_LAST]
< &
```

The documentation for this class was generated from the following file:

• src/daisy\_petal.h

# 6.11 daisy::DaisyPod Class Reference

Class that handles initializing all of the hardware specific to the Daisy Patch Board. Helper funtions are also in place to provide easy access to built-in controls and peripherals.

```
#include <daisy_pod.h>
```

# **Public Types**

```
• enum Sw { BUTTON_1, BUTTON_2, BUTTON_LAST }
```

enum Knob { KNOB\_1, KNOB\_2, KNOB\_LAST }

#### **Public Member Functions**

- void Init ()
- void DelayMs (size\_t del)
- void SetAudioBlockSize (size\_t size)
- void StartAudio (dsy\_audio\_callback cb)
- void ChangeAudioCallback (dsy audio callback cb)
- void StartAdc ()
- float AudioSampleRate ()
- size\_t AudioBlockSize ()
- float AudioCallbackRate ()
- void UpdateAnalogControls ()
- float GetKnobValue (Knob k)
- void DebounceControls ()
- void ClearLeds ()
- void UpdateLeds ()

#### **Public Attributes**

- · DaisySeed seed
- · Encoder encoder
- · AnalogControl knob1
- AnalogControl knob2
- AnalogControl \* knobs [KNOB\_LAST]
- Switch button1
- Switch button2
- Switch \* buttons [BUTTON\_LAST]
- · RgbLed led1
- RgbLed led2

# 6.11.1 Detailed Description

Class that handles initializing all of the hardware specific to the Daisy Patch Board. Helper funtions are also in place to provide easy access to built-in controls and peripherals.

**Author** 

Stephen Hensley

Date

November 2019

# 6.11.2 Member Enumeration Documentation

6.11.2.1 Knob

enum daisy::DaisyPod::Knob

Knobs

## Enumerator

KNOB_2	&
KNOB_LAST	&

6.11.2.2 Sw

enum daisy::DaisyPod::Sw

Switches

Enumerator

BUTTON_2	&
BUTTON_LAST	&

## 6.11.3 Member Function Documentation

```
6.11.3.1 AudioBlockSize()
```

```
size_t daisy::DaisyPod::AudioBlockSize ( )
```

Get block size

# 6.11.3.2 AudioCallbackRate()

```
float daisy::DaisyPod::AudioCallbackRate ( )
```

Get callback rate

# 6.11.3.3 AudioSampleRate()

```
float daisy::DaisyPod::AudioSampleRate ( )
```

Get sample rate

# 6.11.3.4 ChangeAudioCallback()

Switch callback functions

```
Parameters
```

```
cb New callback function.
```

#### 6.11.3.8 GetKnobValue()

del Time to wait in ms.

**Parameters** 

Audio Block size defaults to 48. Change it using this function before StartingAudio.

#### **Parameters**

```
size Block size to set.
```

```
6.11.3.11 StartAdc()
```

```
void daisy::DaisyPod::StartAdc ( )
```

Start analog to digital conversion.

## 6.11.3.12 StartAudio()

Start audio callback

#### **Parameters**

cb Callback function.

## 6.11.3.13 UpdateAnalogControls()

```
void daisy::DaisyPod::UpdateAnalogControls ( )
```

Call at same rate as analog reads for smooth reading.

## 6.11.3.14 UpdateLeds()

```
void daisy::DaisyPod::UpdateLeds ( )
```

Update Leds to set colors

#### 6.11.4 Member Data Documentation

## 6.11.4.1 button1

```
Switch daisy::DaisyPod::button1
```

&

```
6.11.4.2 button2
Switch daisy::DaisyPod::button2
&
6.11.4.3 buttons
Switch * daisy::DaisyPod::buttons[BUTTON_LAST]
6.11.4.4 encoder
Encoder daisy::DaisyPod::encoder
&
6.11.4.5 knob1
AnalogControl daisy::DaisyPod::knob1
6.11.4.6 knob2
AnalogControl daisy::DaisyPod::knob2
&
6.11.4.7 knobs
AnalogControl * daisy::DaisyPod::knobs[KNOB_LAST]
&
6.11.4.8 led1
RgbLed daisy::DaisyPod::led1
&
6.11.4.9 led2
RgbLed daisy::DaisyPod::led2
&
```

#### 6.11.4.10 seed

DaisySeed daisy::DaisyPod::seed

#### Public Members #

The documentation for this class was generated from the following file:

• src/daisy\_pod.h

## 6.12 daisy::DaisySeed Class Reference

This is the higher-level interface for the Daisy board.

All basic peripheral configuration/initialization is setup here.

```
#include <daisy_seed.h>
```

#### **Public Member Functions**

- void Configure ()
- void Init ()
- dsy\_gpio\_pin GetPin (uint8\_t pin\_idx)
- void StartAudio (dsy\_audio\_callback cb)
- void SetLed (bool state)
- void SetTestPoint (bool state)
- float AudioSampleRate ()
- void SetAudioBlockSize (size\_t blocksize)

## **Public Attributes**

- · dsy\_sdram\_handle sdram\_handle
- dsy\_qspi\_handle qspi\_handle
- dsy\_audio\_handle audio\_handle
- dsy\_sai\_handle sai\_handle
- dsy\_i2c\_handle i2c1\_handle
- dsy\_i2c\_handle i2c2\_handle
- · AdcHandle adc
- · dsy dac handle dac handle
- UsbHandle usb\_handle

## 6.12.1 Detailed Description

This is the higher-level interface for the Daisy board.
All basic peripheral configuration/initialization is setup here.

#### 6.12.2 Member Function Documentation

#### 6.12.2.1 AudioSampleRate()

```
float daisy::DaisySeed::AudioSampleRate ( )
```

Returns the audio sample rate in Hz as a floating point number.

#### 6.12.2.2 Configure()

```
void daisy::DaisySeed::Configure ( )
```

Configures the settings for all internal peripherals, but does not initialize them. This allows for modification of the configuration handles prior to initialization.&

#### 6.12.2.3 GetPin()

Returns the gpio\_pin corresponding to the index 0-31. For the given GPIO on the Daisy Seed (labeled 1-32 in docs).

#### 6.12.2.4 Init()

```
void daisy::DaisySeed::Init ( )
```

Initializes the Daisy Seed and the following peripherals: SDRAM, QSPI, 24-bit 48kHz Audio via AK4556, Internal USB, as well as the built-in LED and Testpoint.

ADCs, DACs, and other special peripherals (such as I2C, SPI, etc.) can be initialized using their specific initializers within libdaisy for a specific application.

#### 6.12.2.5 SetAudioBlockSize()

Sets the number of samples processed per channel by the audio callback.

#### 6.12.2.6 SetLed()

Sets the state of the built in LED

## 6.12.2.7 SetTestPoint()

Sets the state of the test point near pin 10

#### 6.12.2.8 StartAudio()

Begins the audio for the seeds builtin audio. the specified callback will get called whenever new data is ready to be prepared.

## 6.12.3 Member Data Documentation

```
6.12.3.1 adc
```

AdcHandle daisy::DaisySeed::adc

&

## 6.12.3.2 audio\_handle

```
dsy_audio_handle daisy::DaisySeed::audio_handle
```

&

## 6.12.3.3 dac\_handle

```
dsy_dac_handle daisy::DaisySeed::dac_handle
```

&

## 6.12.3.4 i2c1\_handle

```
dsy_i2c_handle daisy::DaisySeed::i2c1_handle
```

&

```
6.12.3.5 i2c2_handle
dsy_i2c_handle daisy::DaisySeed::i2c2_handle
6.12.3.6 qspi_handle
dsy_qspi_handle daisy::DaisySeed::qspi_handle
&
6.12.3.7 sai_handle
dsy_sai_handle daisy::DaisySeed::sai_handle
&
6.12.3.8 sdram_handle
dsy_sdram_handle daisy::DaisySeed::sdram_handle
&
6.12.3.9 usb_handle
UsbHandle daisy::DaisySeed::usb_handle
&
The documentation for this class was generated from the following file:
    • src/daisy_seed.h
```

# 6.13 dsy\_audio\_handle Struct Reference

```
#include <hid_audio.h>
```

## **Public Attributes**

- size\_t block\_size
- dsy\_sai\_handle \* sai
- dsy\_i2c\_handle \* dev0\_i2c
- dsy\_i2c\_handle \* dev1\_i2c

## 6.13.1 Detailed Description

Simple config struct that holds peripheral drivers.

## 6.13.2 Member Data Documentation

```
6.13.2.1 block_size

size_t dsy_audio_handle::block_size

&
6.13.2.2 dev0_i2c

dsy_i2c_handle* dsy_audio_handle::dev0_i2c

&
6.13.2.3 dev1_i2c

dsy_i2c_handle* dsy_audio_handle::dev1_i2c

&
6.13.2.4 sai

dsy_sai_handle* dsy_audio_handle::sai

&
```

The documentation for this struct was generated from the following file:

• src/hid\_audio.h

## 6.14 dsy\_dac\_handle Struct Reference

```
#include <per_dac.h>
```

## **Public Attributes**

- dsy\_dac\_mode mode
- dsy\_dac\_bitdepth bitdepth
- dsy\_gpio\_pin pin\_config [DSY\_DAC\_CHN\_LAST]

## 6.14.1 Detailed Description

Configuration structure for DAC initialization and settings. pin\_config must be filled out. However, the DACs are pretty consistently on pins PA4, and PA5 across all STM32 MCUs that I've used.

#### 6.14.2 Member Data Documentation

```
6.14.2.1 bitdepth
dsy_dac_bitdepth dsy_dac_handle::bitdepth
&
6.14.2.2 mode
dsy_dac_mode dsy_dac_handle::mode
&
6.14.2.3 pin_config
dsy_gpio_pin dsy_dac_handle::pin_config[DSY_DAC_CHN_LAST]
```

The documentation for this struct was generated from the following file:

• src/per\_dac.h

# 6.15 dsy\_gpio Struct Reference

```
#include <per_gpio.h>
```

## **Public Attributes**

- dsy\_gpio\_pin pin
- dsy\_gpio\_mode mode
- dsy\_gpio\_pull pull

## 6.15.1 Detailed Description

Struct for holding the pin, and configuration

## 6.15.2 Member Data Documentation

```
6.15.2.1 mode

dsy_gpio_mode dsy_gpio::mode

&

6.15.2.2 pin

dsy_gpio_pin dsy_gpio::pin

&

6.15.2.3 pull

dsy_gpio_pull dsy_gpio::pull

&
```

The documentation for this struct was generated from the following file:

• src/per\_gpio.h

# 6.16 dsy\_gpio\_pin Struct Reference

```
#include <daisy_core.h>
```

## **Public Attributes**

- dsy\_gpio\_port port
- uint8\_t pin

## 6.16.1 Detailed Description

Hardware define pins

### 6.16.2 Member Data Documentation

```
6.16.2.1 pin

uint8_t dsy_gpio_pin::pin

number 0-15

6.16.2.2 port

dsy_gpio_port dsy_gpio_pin::port

o
```

The documentation for this struct was generated from the following file:

• src/daisy\_core.h

# 6.17 dsy\_i2c\_handle Struct Reference

```
#include <per_i2c.h>
```

## **Public Attributes**

- dsy\_i2c\_periph periph
- dsy\_gpio\_pin pin\_config [DSY\_I2C\_PIN\_LAST]
- dsy\_i2c\_speed speed

## 6.17.1 Detailed Description

this object will be used to initialize the I2C interface, and can be passed to dev\_drivers that require I2C.

## 6.17.2 Member Data Documentation

```
6.17.2.1 periph

dsy_i2c_periph dsy_i2c_handle::periph

&

6.17.2.2 pin_config

dsy_gpio_pin dsy_i2c_handle::pin_config[DSY_I2C_PIN_LAST]

&
```

Generated by Doxygen

## 6.17.2.3 speed

```
dsy_i2c_speed dsy_i2c_handle::speed
```

&

The documentation for this struct was generated from the following file:

• src/per\_i2c.h

# 6.18 dsy\_qspi\_handle Struct Reference

```
#include <per_qspi.h>
```

## **Public Attributes**

- dsy\_qspi\_mode mode
- dsy\_qspi\_device device
- dsy\_gpio\_pin pin\_config [DSY\_QSPI\_PIN\_LAST]

## 6.18.1 Detailed Description

Configuration structure for interfacing with QSPI Driver

## 6.18.2 Member Data Documentation

```
6.18.2.1 device
```

```
dsy_qspi_device dsy_qspi_handle::device
```

&

## 6.18.2.2 mode

dsy\_qspi\_mode dsy\_qspi\_handle::mode

&

#### 6.18.2.3 pin\_config

```
dsy_gpio_pin dsy_qspi_handle::pin_config[DSY_QSPI_PIN_LAST]
```

&

The documentation for this struct was generated from the following file:

· src/per\_qspi.h

## 6.19 dsy\_sai\_handle Struct Reference

```
#include <per_sai.h>
```

#### **Public Attributes**

- · dsy\_audio\_sai init
- dsy\_audio\_samplerate samplerate [DSY\_SAI\_LAST]
- dsy\_audio\_bitdepth bitdepth [DSY\_SAI\_LAST]
- dsy audio dir a direction [DSY SAI LAST]
- dsy\_audio\_dir b\_direction [DSY\_SAI\_LAST]
- dsy\_audio\_sync sync\_config [DSY\_SAI\_LAST]
- dsy\_audio\_device device [DSY\_SAI\_LAST]
- dsy\_gpio\_pin sai1\_pin\_config [DSY\_SAI\_PIN\_LAST]
- dsy\_gpio\_pin sai2\_pin\_config [DSY\_SAI\_PIN\_LAST]

## 6.19.1 Detailed Description

Configuration structure for SAI contains all above settings, and passes them to internal structure for hardware initialization.

## 6.19.2 Member Data Documentation

```
6.19.2.1 a_direction

dsy_audio_dir dsy_sai_handle::a_direction[DSY_SAI_LAST]

&
6.19.2.2 b_direction

dsy_audio_dir dsy_sai_handle::b_direction[DSY_SAI_LAST]
```

&

```
6.19.2.3 bitdepth
dsy_audio_bitdepth dsy_sai_handle::bitdepth[DSY_SAI_LAST]
6.19.2.4 device
dsy_audio_device dsy_sai_handle::device[DSY_SAI_LAST]
&
6.19.2.5 init
dsy_audio_sai dsy_sai_handle::init
&
6.19.2.6 sai1_pin_config
dsy_gpio_pin dsy_sai_handle::sail_pin_config[DSY_SAI_PIN_LAST]
&
6.19.2.7 sai2_pin_config
dsy_gpio_pin dsy_sai_handle::sai2_pin_config[DSY_SAI_PIN_LAST]
&
6.19.2.8 samplerate
dsy_audio_samplerate dsy_sai_handle::samplerate[DSY_SAI_LAST]
&
6.19.2.9 sync_config
dsy_audio_sync dsy_sai_handle::sync_config[DSY_SAI_LAST]
&
The documentation for this struct was generated from the following file:
    src/per_sai.h
```

## 6.20 DSY\_SD\_CardInfoTypeDef Struct Reference

#include <util\_bsp\_sd\_diskio.h>

## **Public Attributes**

- uint32\_t CardType
- uint32\_t CardVersion
- uint32\_t Class
- uint32\_t RelCardAdd
- uint32\_t BlockNbr
- uint32\_t BlockSize
- uint32\_t LogBlockNbr
- uint32\_t LogBlockSize
- uint32\_t CardSpeed

## 6.20.1 Detailed Description

Functions for handling DisklO via SDMMC These are usually configured through the FatFS driver/interface, and won't need to be accessed directly often.

## 6.20.2 Member Data Documentation

## 6.20.2.1 BlockNbr

uint32\_t DSY\_SD\_CardInfoTypeDef::BlockNbr

Specifies the Card Capacity in blocks

## 6.20.2.2 BlockSize

uint32\_t DSY\_SD\_CardInfoTypeDef::BlockSize

## Specifies one block size in bytes

## 6.20.2.3 CardSpeed

uint32\_t DSY\_SD\_CardInfoTypeDef::CardSpeed

## Specifies the card Speed

## 6.20.2.4 CardType

uint32\_t DSY\_SD\_CardInfoTypeDef::CardType

Specifies the card Type

#### 6.20.2.5 CardVersion

uint32\_t DSY\_SD\_CardInfoTypeDef::CardVersion

Specifies the card version

#### 6.20.2.6 Class

uint32\_t DSY\_SD\_CardInfoTypeDef::Class

Specifies the class of the card class

## 6.20.2.7 LogBlockNbr

uint32\_t DSY\_SD\_CardInfoTypeDef::LogBlockNbr

Specifies the Card logical Capacity in blocks

## 6.20.2.8 LogBlockSize

uint32\_t DSY\_SD\_CardInfoTypeDef::LogBlockSize

Specifies logical block size in bytes

## 6.20.2.9 RelCardAdd

uint32\_t DSY\_SD\_CardInfoTypeDef::RelCardAdd

## Specifies the Relative Card Address

The documentation for this struct was generated from the following file:

• src/util\_bsp\_sd\_diskio.h

## 6.21 dsy\_sdram\_handle Struct Reference

#include <dev\_sdram.h>

## **Public Attributes**

- dsy\_sdram\_state state
- dsy\_gpio\_pin pin\_config [DSY\_SDRAM\_PIN\_LAST]

## 6.21.1 Detailed Description

Configuration struct for passing to initialization

#### 6.21.2 Member Data Documentation

```
6.21.2.1 pin_config

dsy_gpio_pin dsy_sdram_handle::pin_config[DSY_SDRAM_PIN_LAST]
&
6.21.2.2 state

dsy_sdram_state dsy_sdram_handle::state
```

The documentation for this struct was generated from the following file:

· src/dev sdram.h

&

## 6.22 dsy\_sr\_4021\_handle Struct Reference

```
#include <dev_sr_4021.h>
```

## **Public Attributes**

- dsy\_gpio\_pin pin\_config [DSY\_SR\_4021\_PIN\_LAST]
- uint8\_t num\_parallel
- uint8\_t num\_daisychained
- dsy\_gpio cs
- dsy\_gpio clk
- dsy\_gpio data [2]
- uint8\_t states [8 \*1 \*2]

## 6.22.1 Detailed Description

configuration strucutre for 4021 pin config is used to initialize the dsy\_gpio num\_parallel is the number of devices connected that share the same clk/cs, etc. but have independent data num\_daisychained is the number of devices in a daisy-chain configuration

## 6.22.2 Member Data Documentation

```
6.22.2.1 clk
dsy_gpio dsy_sr_4021_handle::clk
clk pin
6.22.2.2 cs
dsy_gpio dsy_sr_4021_handle::cs
cs pin
6.22.2.3 data
dsy_gpio dsy_sr_4021_handle::data[2]
array of data pins
6.22.2.4 num_daisychained
uint8_t dsy_sr_4021_handle::num_daisychained
Number of devices daisy chained
6.22.2.5 num_parallel
uint8_t dsy_sr_4021_handle::num_parallel
number of devices connected
6.22.2.6 pin_config
dsy_gpio_pin dsy_sr_4021_handle::pin_config[DSY_SR_4021_PIN_LAST]
used to initialize the dsy_gpio
```

#### 6.22.2.7 states

```
uint8_t dsy_sr_4021_handle::states[8 * 1 * 2]
```

array of states

The documentation for this struct was generated from the following file:

src/dev\_sr\_4021.h

## 6.23 daisy::Encoder Class Reference

Generic Class for handling Quadrature Encoders Inspired/influenced by Mutable Instruments (pichenettes) Encoder classes.

```
#include <hid_encoder.h>
```

## **Public Member Functions**

- void Init (dsy\_gpio\_pin a, dsy\_gpio\_pin b, dsy\_gpio\_pin click, float update\_rate)
- void Debounce ()
- int32\_t Increment () const
- bool RisingEdge () const
- bool FallingEdge () const
- bool Pressed () const
- float TimeHeldMs () const

## 6.23.1 Detailed Description

Generic Class for handling Quadrature Encoders
Inspired/influenced by Mutable Instruments (pichenettes) Encoder classes.

Author

Stephen Hensley

Date

December 2019

## 6.23.2 Member Function Documentation

#### 6.23.2.1 Debounce()

```
void daisy::Encoder::Debounce ( )
```

Called at update\_rate to debounce and handle timing for the switch. In order for events not to be missed, its important that the Edge/Pressed checks be made at the same rate as the debounce function is being called.

#### 6.23.2.2 FallingEdge()

```
bool daisy::Encoder::FallingEdge ( ) const [inline]
```

Returns true if the encoder was just released.

#### 6.23.2.3 Increment()

```
int32_t daisy::Encoder::Increment ( ) const [inline]
```

Returns +1 if the encoder was turned clockwise, -1 if it was turned counter-clockwise, or 0 if it was not just turned.

#### 6.23.2.4 Init()

Initializes the encoder with the specified hardware pins. Update rate should be the rate at which Debounce() gets called in Hertz.

#### 6.23.2.5 Pressed()

```
bool daisy::Encoder::Pressed ( ) const [inline]
```

Returns true while the encoder is held down.

#### 6.23.2.6 RisingEdge()

```
bool daisy::Encoder::RisingEdge ( ) const [inline]
```

Returns true if the encoder was just pressed.

#### 6.23.2.7 TimeHeldMs()

```
float daisy::Encoder::TimeHeldMs ( ) const [inline]
```

Returns the time in milliseconds that the encoder has been held down.

The documentation for this class was generated from the following file:

src/hid\_encoder.h

## 6.24 FontDef Struct Reference

```
#include <util_oled_fonts.h>
```

## **Public Attributes**

- const uint8\_t FontWidth
- uint8\_t FontHeight
- const uint16\_t \* data

## 6.24.1 Detailed Description

Utility for displaying fonts on OLED displays Migrated to work with libdaisy from stm32-ssd1306

**Author** 

afiskon on github. Font struct

#### 6.24.2 Member Data Documentation

#### 6.24.2.1 data

```
const uint16_t* FontDef::data
```

Pointer to data font data array

## 6.24.2.2 FontHeight

uint8\_t FontDef::FontHeight

Font height in pixels

## 6.24.2.3 FontWidth

```
const uint8_t FontDef::FontWidth
```

Font width in pixels

The documentation for this struct was generated from the following file:

src/util\_oled\_fonts.h

# 6.25 daisy::GateIn Class Reference

Generic Class for handling gate inputs through GPIO.

```
#include <hid_gatein.h>
```

## **Public Member Functions**

- GateIn ()
- ∼GateIn ()
- void Init (dsy\_gpio\_pin \*pin\_cfg)
- bool Trig ()

## 6.25.1 Detailed Description

Generic Class for handling gate inputs through GPIO.

Author

Stephen Hensley

Date

March 2020

#### 6.25.2 Constructor & Destructor Documentation

```
6.25.2.1 GateIn()

daisy::GateIn::GateIn ( ) [inline]

GateIn Constructor

6.25.2.2 ~GateIn()

daisy::GateIn::~GateIn ( ) [inline]
```

### 6.25.3 Member Function Documentation

GateIn $\sim$  Destructor

Init Initializes the gate input with specified hardware pin

```
6.25.3.2 Trig()
```

```
bool daisy::GateIn::Trig ( )
```

Trig Checks current state of gate input.

Returns

FALSE if pin is low, and TRUE if high

The documentation for this class was generated from the following file:

· src/hid gatein.h

## 6.26 daisy::Led Class Reference

LED Class providing simple Software PWM ability, etc

Eventually this will work with hardware PWM, and external LED Driver devices as well.

```
#include <hid_led.h>
```

#### **Public Member Functions**

- void Init (dsy gpio pin pin, bool invert, float samplerate=1000.0f)
- · void Set (float val)
- void Update ()

#### 6.26.1 Detailed Description

LED Class providing simple Software PWM ability, etc

Eventually this will work with hardware PWM, and external LED Driver devices as well.

Author

shensley

Date

March 2020

## 6.26.2 Member Function Documentation

```
6.26.2.1 Init()
```

Initializes an LED using the specified hardware pin.

#### **Parameters**

pin chooses LED pin		
	invert	will set whether to internally invert the brightness due to hardware config.
	samplerate	sets the rate at which 'Update()' will be called (used for software PWM)

## 6.26.2.2 Set()

```
void daisy::Led::Set (
          float val )
```

Sets the brightness of the Led.

#### **Parameters**

val

will be cubed for gamma correction, and then quantized to 8-bit values for Software PWM 8-bit is for more flexible update rate options, as 12-bit or more would require faster update rates.

#### 6.26.2.3 Update()

```
void daisy::Led::Update ( )
```

This processes the pwm of the LED sets the hardware accordingly.

The documentation for this class was generated from the following file:

• src/hid\_led.h

## 6.27 daisy::MidiEvent Struct Reference

```
#include <hid_midi.h>
```

#### **Public Member Functions**

- NoteOnEvent AsNoteOn ()
- ControlChangeEvent AsControlChange ()

## **Public Attributes**

- MidiMessageType type
- int channel
- uint8\_t data [2]

## 6.27.1 Detailed Description

Simple MidiEvent with message type, channel, and data[2] members.

## 6.27.2 Member Function Documentation

## 6.27.2.1 AsControlChange()

```
ControlChangeEvent daisy::MidiEvent::AsControlChange ( ) [inline]
```

Returns the data within the MidiEvent as a NoteOnEvent struct.

## 6.27.2.2 AsNoteOn()

```
NoteOnEvent daisy::MidiEvent::AsNoteOn ( ) [inline]
```

Returns the data within the MidiEvent as a NoteOnEvent struct

#### 6.27.3 Member Data Documentation

#### 6.27.3.1 channel

```
int daisy::MidiEvent::channel
```

&

#### 6.27.3.2 data

```
uint8_t daisy::MidiEvent::data[2]
```

ጲ

## 6.27.3.3 type

```
MidiMessageType daisy::MidiEvent::type
```

&

The documentation for this struct was generated from the following file:

• src/hid\_midi.h

## 6.28 daisy::MidiHandler Class Reference

Simple MIDI Handler

Parses bytes from an input into valid MidiEvents.

The MidiEvents fill a FIFO queue that the user can pop messages from.

```
#include <hid midi.h>
```

## **Public Types**

- enum MidiInputMode { INPUT\_MODE\_NONE = 0x00, INPUT\_MODE\_UART1 = 0x01, INPUT\_MODE\_US

  B\_INT = 0x02, INPUT\_MODE\_USB\_EXT = 0x04 }
- enum MidiOutputMode { OUTPUT\_MODE\_NONE = 0x00, OUTPUT\_MODE\_UART1 = 0x01, OUTPUT\_M
  ODE\_USB\_INT = 0x02, OUTPUT\_MODE\_USB\_EXT = 0x04 }

#### **Public Member Functions**

- void Init (MidiInputMode in\_mode, MidiOutputMode out\_mode)
- void StartReceive ()
- void Listen ()
- void Parse (uint8\_t byte)
- bool HasEvents () const
- MidiEvent PopEvent ()

## 6.28.1 Detailed Description

Simple MIDI Handler

Parses bytes from an input into valid MidiEvents.

The MidiEvents fill a FIFO queue that the user can pop messages from.

Author

shensley

Date

March 2020

#### 6.28.2 Member Enumeration Documentation

## 6.28.2.1 MidiInputMode

enum daisy::MidiHandler::MidiInputMode

Input and Output can be configured separately Multiple Input modes can be selected by OR'ing the values.

## Enumerator

INPUT_MODE_NONE	&
INPUT_MODE_UART1	&
INPUT_MODE_USB_INT	
INPUT_MODE_USB_EXT	

## 6.28.2.2 MidiOutputMode

enum daisy::MidiHandler::MidiOutputMode

## Output mode

#### Enumerator

OUTPUT_MODE_NONE	
OUTPUT_MODE_UART1	
OUTPUT_MODE_USB_INT	
OUTPUT_MODE_USB_EXT	&

## 6.28.3 Member Function Documentation

## 6.28.3.1 HasEvents()

```
bool daisy::MidiHandler::HasEvents ( ) const [inline]
```

Checks if there are unhandled messages in the queue

## Returns

True if there are events to be handled, else false.

## 6.28.3.2 Init()

Initializes the MidiHandler

#### **Parameters**

in_mode	Input mode
out_mode	Output mode

## 6.28.3.3 Listen()

```
void daisy::MidiHandler::Listen ( )
```

Start listening

#### 6.28.3.4 Parse()

Feed in bytes to state machine from a queue. Populates internal FIFO queue with MIDI Messages For example with uart: midi.Parse(uart.PopRx());

#### **Parameters**



## 6.28.3.5 PopEvent()

```
MidiEvent daisy::MidiHandler::PopEvent ( ) [inline]
```

Pops the oldest unhandled MidiEvent from the internal queue

Returns

The event to be handled

## 6.28.3.6 StartReceive()

```
void daisy::MidiHandler::StartReceive ( )
```

Starts listening on the selected input mode(s). MidiEvent Queue will begin to fill, and can be checked with

The documentation for this class was generated from the following file:

• src/hid\_midi.h

# 6.29 daisy::NoteOnEvent Struct Reference

```
#include <hid_midi.h>
```

## **Public Attributes**

- int channel
- uint8 t note
- uint8\_t velocity

## 6.29.1 Detailed Description

Struct containing note, and velocity data for a given channel. Can be made from MidiEvent

## 6.29.2 Member Data Documentation

### 6.29.2.1 channel

int daisy::NoteOnEvent::channel

&

## 6.29.2.2 note

uint8\_t daisy::NoteOnEvent::note

&

## 6.29.2.3 velocity

uint8\_t daisy::NoteOnEvent::velocity

&

The documentation for this struct was generated from the following file:

• src/hid\_midi.h

# 6.30 daisy::OledDisplay Class Reference

#include <hid\_oled\_display.h>

## **Public Types**

enum Pins { DATA\_COMMAND, RESET, NUM\_PINS }

#### **Public Member Functions**

- void Init (dsy\_gpio\_pin \*pin\_cfg)
- void Fill (bool on)
- void DrawPixel (uint8\_t x, uint8\_t y, bool on)
- char WriteChar (char ch, FontDef font, bool on)
- char WriteString (char \*str, FontDef font, bool on)
- void SetCursor (uint8\_t x, uint8\_t y)
- void Update ()

## 6.30.1 Detailed Description

Human Interface Driver for using an OLED Display (SSD1309) For all bool on arguments: true is on, false is off. Credit to Aleksander Alekseev (github.com/afiskon/stm32-ssd1306) on github for a great starting point. adapted for SSD1309 and H7 by shensley, 2020

#### 6.30.2 Member Enumeration Documentation

## 6.30.2.1 Pins

```
enum daisy::OledDisplay::Pins
```

GPIO Pins that need to be used independent of peripheral used.

## Enumerator

DATA_COMMAND	Data command pin.
RESET	Reset pin
NUM_PINS	Num pins

## 6.30.3 Member Function Documentation

#### 6.30.3.1 DrawPixel()

Sets the pixel at the specified coordinate to be on/off.

## **Parameters**

X	x Coordinate
У	y coordinate
on	on or off

## 6.30.3.2 Fill()

```
void daisy::OledDisplay::Fill (
          bool on )
```

Fills the entire display with either on/off.

## **Parameters**

```
on Sets on or off.
```

## 6.30.3.3 Init()

Takes an argument for the pin cfg

## **Parameters**

pin\_cfg should be a pointer to an array of OledDisplay::NUM\_PINS dsy\_gpio\_pins

## 6.30.3.4 SetCursor()

```
void daisy::OledDisplay::SetCursor (  \mbox{uint8\_t } x, \\ \mbox{uint8\_t } y \; )
```

Moves the 'Cursor' position used for WriteChar, and WriteStr to the specified coordinate.

#### **Parameters**

Х	x pos
У	y pos

#### 6.30.3.5 Update()

```
void daisy::OledDisplay::Update ( )
```

Writes the current display buffer to the OLED device using SPI or I2C depending on how the object was initialized.

## 6.30.3.6 WriteChar()

Writes the character with the specific FontDef to the display buffer at the current Cursor position.

#### **Parameters**

ch character to be writte	
font	font to be written in
on	on or off

## Returns

&

## 6.30.3.7 WriteString()

Similar to WriteChar, except it will handle an entire String. Wrapping does not happen automatically, so the width of the string must be kept within the dimensions of the screen.

#### **Parameters**

str	string to be written
font font to use	
on	on or off

## Returns

&

The documentation for this class was generated from the following file:

• src/hid\_oled\_display.h

# 6.31 daisy::Parameter Class Reference

```
#include <hid_parameter.h>
```

## **Public Types**

```
    enum Curve {
        LINEAR, EXPONENTIAL, LOGARITHMIC, CUBE,
        LAST }
```

## **Public Member Functions**

- Parameter ()
- ∼Parameter ()
- void Init (AnalogControl input, float min, float max, Curve curve)
- float Process ()
- float Value ()

## 6.31.1 Detailed Description

Simple parameter mapping tool that takes a 0-1 input from an hid\_ctrl.

## 6.31.2 Member Enumeration Documentation

## 6.31.2.1 Curve

```
enum daisy::Parameter::Curve
```

Curves are applied to the output signal

#### Enumerator

LINEAR	Linear curve
EXPONENTIAL	Exponential curve
LOGARITHMIC	Logarithmic curve
CUBE	Cubic curve
LAST	Final enum element.

## 6.31.3 Constructor & Destructor Documentation

```
6.31.3.1 Parameter()

daisy::Parameter::Parameter ( ) [inline]

Constructor

6.31.3.2 ~Parameter()

daisy::Parameter::~Parameter ( ) [inline]
```

## 6.31.4 Member Function Documentation

## 6.31.4.1 Init()

Destructor

initialize a parameter using an hid\_ctrl object.

#### **Parameters**

input	- object containing the direct link to a hardware control source.	
min	- bottom of range. (when input is 0.0)	
max	- top of range (when input is 1.0)	
curve	- the scaling curve for the input->output transformation.	

## 6.31.4.2 Process()

```
float daisy::Parameter::Process ( )
```

processes the input signal, this should be called at the samplerate of the hid\_ctrl passed in.

#### Returns

a float with the specified transformation applied.

#### 6.31.4.3 Value()

```
float daisy::Parameter::Value ( ) [inline]
```

#### Returns

the current value from the parameter without processing another sample. this is useful if you need to use the value multiple times, and don't store the output of process in a local variable.

The documentation for this class was generated from the following file:

• src/hid\_parameter.h

## 6.32 daisy::RgbLed Class Reference

```
#include <hid_rgb_led.h>
```

### **Public Member Functions**

- void Init (dsy\_gpio\_pin red, dsy\_gpio\_pin green, dsy\_gpio\_pin blue, bool invert)
- void Set (float r, float g, float b)
- void SetColor (Color c)
- void Update ()

## 6.32.1 Detailed Description

3x LEDs configured as an RGB for ease of use.

## 6.32.2 Member Function Documentation

## 6.32.2.1 Init()

Initializes 3x GPIO Pins as red, green, and blue elements of an RGB LED

#### **Parameters**

red	Red element
green	Green element
blue	Blue element
invert	Flips led polarity

## 6.32.2.2 Set()

Sets each element of the LED with a floating point number 0-1

#### **Parameters**

r	Red element	
g	Green element	
b	Blue element	

## 6.32.2.3 SetColor()

```
void daisy::RgbLed::SetColor ( {	t Color}\ c )
```

Sets the RGB using a Color object.

## **Parameters**

```
c Color object to set.
```

## 6.32.2.4 Update()

```
void daisy::RgbLed::Update ( )
```

Updates the PWM of the LED based on the current values. Should be called at a regular interval. (i.e. 1kHz/1ms)

The documentation for this class was generated from the following file:

```
• src/hid_rgb_led.h
```

# 6.33 daisy::RingBuffer < T, size > Class Template Reference

```
#include <util_ringbuffer.h>
```

## **Public Member Functions**

- void Init ()
- size\_t capacity () const
- size\_t writable () const
- size\_t readable () const
- void Write (T v)
- void Overwrite (T v)
- T Read ()
- T ImmediateRead ()
- void Flush ()
- void Swallow (size\_t n)
- void ImmediateRead (T \*destination, size\_t num\_elements)
- void Overwrite (const T \*source, size\_t num\_elements)

## 6.33.1 Detailed Description

```
template<typename T, size_t size> class daisy::RingBuffer< T, size >
```

Utility Ring Buffer imported from pichenettes/stmlib

## 6.33.2 Member Function Documentation

## 6.33.2.1 capacity()

```
template<typename T, size_t size>
size_t daisy::RingBuffer< T, size >::capacity ( ) const [inline]
```

## Returns

The total size of the ring buffer

## 6.33.2.2 Flush()

```
template<typename T, size_t size>
void daisy::RingBuffer< T, size >::Flush ( ) [inline]
```

Flushes unread elements from the ring buffer

#### 6.33.2.3 ImmediateRead() [1/2]

```
template<typename T, size_t size>
T daisy::RingBuffer< T, size >::ImmediateRead ( ) [inline]
```

Reads next element from ring buffer immediately

Returns

read value

#### 6.33.2.4 ImmediateRead() [2/2]

Reads a number of elements into a buffer immediately

#### **Parameters**

destination	buffer to write to
num_elements	number of elements in buffer

## 6.33.2.5 Init()

```
template<typename T, size_t size>
void daisy::RingBuffer< T, size >::Init ( ) [inline]
```

Initializes the Ring Buffer

## **6.33.2.6** Overwrite() [1/2]

Writes the new element to the ring buffer, overwriting unread data if necessary.

#### **Parameters**

```
v Value to overwrite
```

#### 6.33.2.7 Overwrite() [2/2]

Overwrites a number of elements using the source buffer as input.

#### **Parameters**

source	Input buffer
num_elements	Number of elements in source

## 6.33.2.8 Read()

```
template<typename T, size_t size>
T daisy::RingBuffer< T, size >::Read ( ) [inline]
```

Reads the first available element from the ring buffer

#### Returns

read value

## 6.33.2.9 readable()

```
template<typename T, size_t size>
size_t daisy::RingBuffer< T, size >::readable ( ) const [inline]
```

## Returns

number of unread elements in ring buffer

## 6.33.2.10 Swallow()

Read enough samples to make it possible to read 1 sample.

#### **Parameters**

```
n | Size of T?
```

#### 6.33.2.11 writable()

```
template<typename T, size_t size>
size_t daisy::RingBuffer< T, size >::writable ( ) const [inline]
```

## Returns

the number of samples that can be written to ring buffer without overwriting unread data.

## 6.33.2.12 Write()

Writes the value to the next available position in the ring buffer

#### **Parameters**

```
v Value to write
```

The documentation for this class was generated from the following file:

· src/util\_ringbuffer.h

# 6.34 daisy::RingBuffer< T, 0 > Class Template Reference

```
#include <util_ringbuffer.h>
```

#### **Public Member Functions**

- void Init ()
- size\_t capacity () const
- size\_t writable () const
- size\_t readable () const
- void Write (T v)
- void Overwrite (T v)
- T Read ()
- T ImmediateRead ()
- void Flush ()
- void ImmediateRead (T \*destination, size\_t num\_elements)
- void Overwrite (const T \*source, size\_t num\_elements)

## 6.34.1 Detailed Description

```
template < typename T> class daisy::RingBuffer < T, 0 >
```

Utility Ring Buffer imported from pichenettes/stmlib

## 6.34.2 Member Function Documentation

```
6.34.2.1 capacity()
```

```
template<typename T >
size_t daisy::RingBuffer< T, 0 >::capacity ( ) const [inline]
```

#### Returns

0

## 6.34.2.2 Flush()

```
template<typename T >
void daisy::RingBuffer< T, 0 >::Flush () [inline]
```

Flush the buffer

## **6.34.2.3** ImmediateRead() [1/2]

```
template<typename T >
T daisy::RingBuffer< T, 0 >::ImmediateRead ( ) [inline]
```

## Returns

Read value

## **6.34.2.4** ImmediateRead() [2/2]

#### **Parameters**

destination	&
num_elements	&

## 6.34.2.5 Init()

```
template<typename T >
void daisy::RingBuffer< T, 0 >::Init () [inline]
```

#### Initialize ringbuffer

## **6.34.2.6** Overwrite() [1/2]

#### **Parameters**

```
Value to overwrite
```

## **6.34.2.7 Overwrite()** [2/2]

## **Parameters**

source	3
num elements	&

## 6.34.2.8 Read()

```
template<typename T >
T daisy::RingBuffer< T, 0 >::Read ( ) [inline]
```

#### Returns

Read value

## 6.34.2.9 readable()

```
template<typename T >
size_t daisy::RingBuffer< T, 0 >::readable ( ) const [inline]
```

#### Returns

0

## 6.34.2.10 writable()

```
template<typename T >
size_t daisy::RingBuffer< T, 0 >::writable ( ) const [inline]
```

## Returns

0

## 6.34.2.11 Write()

#### **Parameters**

v Value to write

The documentation for this class was generated from the following file:

• src/util\_ringbuffer.h

# 6.35 daisy::SdmmcHandler Class Reference

```
#include <per_sdmmc.h>
```

## **Public Member Functions**

• void Init ()

## 6.35.1 Detailed Description

Configuration for interfacing with SD cards. Currently only supports operation using FatFS filesystem

## 6.35.2 Member Function Documentation

## 6.35.2.1 Init()

```
void daisy::SdmmcHandler::Init ( )
```

Initializes the SD Card Interface For now all settings are fixed (See todo at top of section)

The documentation for this class was generated from the following file:

· src/per\_sdmmc.h

## 6.36 daisy::SdmmcHandlerInit Struct Reference

```
#include <per_sdmmc.h>
```

## **Public Attributes**

- SdmmcBitWidth bitdepth
- SdmmcSpeed speed

## 6.36.1 Detailed Description

Structure for setting the options above. Used to intiailize SdmmcHandler

## 6.36.2 Member Data Documentation

## 6.36.2.1 bitdepth

SdmmcBitWidth daisy::SdmmcHandlerInit::bitdepth

&

## 6.36.2.2 speed

```
SdmmcSpeed daisy::SdmmcHandlerInit::speed
```

&

The documentation for this struct was generated from the following file:

• src/per\_sdmmc.h

# 6.37 ShiftRegister595 Class Reference

```
Device Driver for 8-bit shift register.
CD74HC595 - 8-bit serial to parallel output shift.
```

```
#include <dev_sr_595.h>
```

## **Public Types**

enum Pins { PIN\_LATCH, PIN\_CLK, PIN\_DATA, NUM\_PINS }

#### **Public Member Functions**

- void Init (dsy\_gpio\_pin \*pin\_cfg, size\_t num\_daisy\_chained=1)
- void Set (uint8\_t idx, bool state)
- void Write ()

## 6.37.1 Detailed Description

Device Driver for 8-bit shift register. CD74HC595 - 8-bit serial to parallel output shift.

**Author** 

shensley

Date

May 2020

## 6.37.2 Member Enumeration Documentation

## 6.37.2.1 Pins

```
enum ShiftRegister595::Pins
```

The following pins correspond to the hardware connections to the 595.

#### Enumerator

PIN_CLK	LATCH corresonds to Pin 12 "RCLK"
PIN_DATA	CLK corresponds to Pin 11 "SRCLK"
NUM_PINS	DATA corresponds to Pin 14 "SER"

## 6.37.3 Member Function Documentation

#### 6.37.3.1 Init()

Initializes the GPIO, and data for the ShiftRegister

#### **Parameters**

pin_cfg	is an array of dsy_gpio_pin corresponding the the Pins enum above.
num_daisy_chained	(default = 1) is the number of 595 devices daisy chained together.

## 6.37.3.2 Set()

Sets the state of the specified output.

## **Parameters**

idx	The index starts with QA on the first device and ends with QH on the last device.
state	A true state will set the output HIGH, while a false state will set the output LOW.

## 6.37.3.3 Write()

```
void ShiftRegister595::Write ( )
```

Writes the states of shift register out to the connected devices.

The documentation for this class was generated from the following file:

```
• src/dev_sr_595.h
```

# 6.38 daisy::SpiHandle Class Reference

```
#include <per_spi.h>
```

#### **Public Member Functions**

- void Init ()
- void BlockingTransmit (uint8\_t \*buff, size\_t size)

## 6.38.1 Detailed Description

Handler for serial peripheral interface

#### 6.38.2 Member Function Documentation

#### 6.38.2.1 BlockingTransmit()

## Blocking transmit

#### **Parameters**

*buff	input buffer
size	buffer size

## 6.38.2.2 Init()

```
void daisy::SpiHandle::Init ( )
```

## Initializes handler

The documentation for this class was generated from the following file:

```
• src/per_spi.h
```

# 6.39 daisy::Switch Class Reference

```
#include <hid_switch.h>
```

## **Public Types**

- enum Type { TYPE\_TOGGLE, TYPE\_MOMENTARY }
- enum Polarity { POLARITY\_NORMAL, POLARITY\_INVERTED }
- enum Pull { PULL\_UP, PULL\_DOWN, PULL\_NONE }

## **Public Member Functions**

- void Init (dsy\_gpio\_pin pin, float update\_rate, Type t, Polarity pol, Pull pu)
- void Init (dsy\_gpio\_pin pin, float update\_rate)
- void Debounce ()
- bool RisingEdge () const
- bool FallingEdge () const
- bool Pressed () const
- float TimeHeldMs () const

## 6.39.1 Detailed Description

Generic Class for handling momentary/latching switches Inspired/influenced by Mutable Instruments (pichenettes) Switch classes

Author

Stephen Hensley

Date

December 2019

#### 6.39.2 Member Enumeration Documentation

6.39.2.1 Polarity

enum daisy::Switch::Polarity

Specifies whether the pressed is HIGH or LOW.

Enumerator

POLARITY_NORMAL	
POLARITY INVERTED	&

#### 6.39.2.2 Pull

```
enum daisy::Switch::Pull
```

Specifies whether to use built-in Pull Up/Down resistors to hold button at a given state when not engaged.

#### Enumerator

PULL_UP	&
PULL_DOWN	&
PULL_NONE	&

## 6.39.2.3 Type

```
enum daisy::Switch::Type
```

Specifies the expected behavior of the switch

#### Enumerator

TYPE_TOGGLE	&
TYPE_MOMENTARY	&

## 6.39.3 Member Function Documentation

#### 6.39.3.1 Debounce()

```
void daisy::Switch::Debounce ( )
```

Called at update\_rate to debounce and handle timing for the switch. In order for events not to be missed, its important that the Edge/Pressed checks be made at the same rate as the debounce function is being called.

## 6.39.3.2 FallingEdge()

```
bool daisy::Switch::FallingEdge ( ) const [inline]
```

#### **Returns**

true if the button was just released

Initializes the switch object with a given port/pin combo.

#### **Parameters**

pin	port/pin object to tell the switch which hardware pin to use.
update_rate	the rate at which the Debounce() function will be called. (used for timing).
t	switch type – Default: TYPE_MOMENTARY
pol	switch polarity – Default: POLARITY_INVERTED
ри	switch pull up/down – Default: PULL_UP

## Simplified Init.

## **Parameters**

pin	port/pin object to tell the switch which hardware pin to use.
update_rate	the rate at which the Debounce() function will be called. (used for timing).

## 6.39.3.5 Pressed()

```
bool daisy::Switch::Pressed ( ) const [inline]
```

## Returns

true if the button is held down (or if the toggle is on)

## 6.39.3.6 RisingEdge()

```
bool daisy::Switch::RisingEdge ( ) const [inline]
```

#### Returns

true if a button was just pressed.

## 6.39.3.7 TimeHeldMs()

```
float daisy::Switch::TimeHeldMs ( ) const [inline]
```

#### Returns

the time in milliseconds that the button has been held (or toggle has been on)

The documentation for this class was generated from the following file:

• src/hid switch.h

## 6.40 daisy::UartHandler Class Reference

```
#include <per_uart.h>
```

## **Public Member Functions**

- void Init ()
- int PollReceive (uint8\_t \*buff, size\_t size, uint32\_t timeout)
- int StartRx (size\_t size)
- bool RxActive ()
- int FlushRx ()
- int PollTx (uint8\_t \*buff, size\_t size)
- uint8\_t PopRx ()
- size\_t Readable ()
- int CheckError ()

## 6.40.1 Detailed Description

**Uart Peripheral** 

**Author** 

shensley

Date

March 2020

## 6.40.2 Member Function Documentation

## 6.40.2.1 CheckError()

```
int daisy::UartHandler::CheckError ( )
```

## Returns

the result of HAL\_UART\_GetError() to the user.

## 6.40.2.2 FlushRx()

```
int daisy::UartHandler::FlushRx ( )
```

Flushes the Receive Queue

#### Returns

OK or ERROR

## 6.40.2.3 Init()

```
void daisy::UartHandler::Init ( )
```

Initializes the UART Peripheral

## 6.40.2.4 PollReceive()

Reads the amount of bytes in blocking mode with a 10ms timeout.

#### **Parameters**

*buff	Buffer to read to
size	Buff size
timeout	How long to timeout for (10ms?)

## Returns

Data received

## 6.40.2.5 PolITx()

Sends an amount of data in blocking mode.

## **Parameters**

*buff	Buffer of data to send
size	Buffer size

#### Returns

OK or ERROR

## 6.40.2.6 PopRx()

```
uint8_t daisy::UartHandler::PopRx ( )
```

Pops the oldest byte from the FIFO.

## Returns

Popped byte

## 6.40.2.7 Readable()

```
size_t daisy::UartHandler::Readable ( )
```

Checks if there are any unread bytes in the FIFO

## Returns

1 or 0 ??

#### 6.40.2.8 RxActive()

```
bool daisy::UartHandler::RxActive ( )
```

#### Returns

whether Rx DMA is listening or not.

#### 6.40.2.9 StartRx()

Starts a DMA Receive callback to fill a buffer of specified size. Data is populated into a FIFO queue, and can be queried with the functions below. Maximum Buffer size is defined above. If a value outside of the maximum is specified, the size will be set to the maximum.

#### **Parameters**

size	Queue size
------	------------

#### Returns

OK or ERROR

The documentation for this class was generated from the following file:

· src/per\_uart.h

## 6.41 daisy::UsbHandle Class Reference

Interface for initializing and using the USB Peripherals on the daisy.

```
#include <hid_usb.h>
```

## **Public Types**

- enum UsbPeriph { FS\_INTERNAL, FS\_EXTERNAL, FS\_BOTH }
- typedef void(\* ReceiveCallback) (uint8\_t \*buff, uint32\_t \*len)

## **Public Member Functions**

- void Init (UsbPeriph dev)
- void TransmitInternal (uint8\_t \*buff, size\_t size)
- void TransmitExternal (uint8\_t \*buff, size\_t size)
- void SetReceiveCallback (ReceiveCallback cb)

## 6.41.1 Detailed Description

Interface for initializing and using the USB Peripherals on the daisy.

Author

Stephen Hensley

Date

December 2019

## 6.41.2 Member Typedef Documentation

## 6.41.2.1 ReceiveCallback

```
typedef void(* daisy::UsbHandle::ReceiveCallback) (uint8_t *buff, uint32_t *len)
```

Function called upon reception of a buffer

## 6.41.3 Member Enumeration Documentation

## 6.41.3.1 UsbPeriph

```
enum daisy::UsbHandle::UsbPeriph
```

Specified which of the two USB Peripherals to initialize.

## Enumerator

FS_INTERNAL	Internal pin
FS_EXTERNAL	FS External D+ pin is Pin 38 (GPIO32). FS External D- pin is Pin 37 (GPIO31)
FS_BOTH	Both

#### 6.41.4 Member Function Documentation

## 6.41.4.1 Init()

Initializes the specified peripheral(s) as USB CDC Devices

## **Parameters**

```
dev Device to initialize
```

## 6.41.4.2 SetReceiveCallback()

sets the callback to be called upon reception of new data

#### **Parameters**

```
cb Function to serve as callback
```

## 6.41.4.3 TransmitExternal()

Transmits a buffer of 'size' bytes from a USB port connected to the external USB Pins of the daisy seed.

## **Parameters**

buff	Buffer to transmit
size	Buffer size

## 6.41.4.4 TransmitInternal()

Transmits a buffer of 'size' bytes from the on board USB FS port.

#### **Parameters**

buff	Buffer to transmit
size	Buffer size

The documentation for this class was generated from the following file:

• src/hid\_usb.h

# 6.42 WAV\_FormatTypeDef Struct Reference

#include <util\_wav\_format.h>

## **Public Attributes**

- uint32\_t Chunkld
- uint32\_t FileSize
- uint32\_t FileFormat
- uint32\_t SubChunk1ID
- uint32\_t SubChunk1Size
- uint16\_t AudioFormat
- uint16\_t NbrChannels
- uint32\_t SampleRate
- uint32\_t ByteRate
- uint16\_t BlockAlign
- uint16\_t BitPerSample
- uint32\_t SubChunk2ID
- uint32\_t SubCHunk2Size

## 6.42.1 Detailed Description

Helper struct for handling the WAV file format

## 6.42.2 Member Data Documentation

#### 6.42.2.1 AudioFormat

uint16\_t WAV\_FormatTypeDef::AudioFormat

&

# 6.42.2.2 BitPerSample uint16\_t WAV\_FormatTypeDef::BitPerSample 6.42.2.3 BlockAlign uint16\_t WAV\_FormatTypeDef::BlockAlign 6.42.2.4 ByteRate uint32\_t WAV\_FormatTypeDef::ByteRate 6.42.2.5 Chunkld uint32\_t WAV\_FormatTypeDef::ChunkId 6.42.2.6 FileFormat uint32\_t WAV\_FormatTypeDef::FileFormat & 6.42.2.7 FileSize uint32\_t WAV\_FormatTypeDef::FileSize & 6.42.2.8 NbrChannels uint16\_t WAV\_FormatTypeDef::NbrChannels &

## Generated by Doxygen

&

6.42.2.9 SampleRate

uint32\_t WAV\_FormatTypeDef::SampleRate

## 6.42.2.10 SubChunk1ID

```
uint32_t WAV_FormatTypeDef::SubChunk1ID
```

&

#### 6.42.2.11 SubChunk1Size

```
uint32_t WAV_FormatTypeDef::SubChunk1Size
```

&

#### 6.42.2.12 SubChunk2ID

```
uint32_t WAV_FormatTypeDef::SubChunk2ID
```

&

#### 6.42.2.13 SubCHunk2Size

```
uint32_t WAV_FormatTypeDef::SubCHunk2Size
```

&

The documentation for this struct was generated from the following file:

• src/util\_wav\_format.h

# 6.43 daisy::WavFileInfo Struct Reference

```
#include <hid_wavplayer.h>
```

## **Public Attributes**

- WAV\_FormatTypeDef raw\_data
- char name [256]

## 6.43.1 Detailed Description

Struct containing details of Wav File.

## 6.43.2 Member Data Documentation

#### 6.43.2.1 name

```
char daisy::WavFileInfo::name[256]
```

#### Wav filename

## 6.43.2.2 raw\_data

```
WAV_FormatTypeDef daisy::WavFileInfo::raw_data
```

#### Raw wav data

The documentation for this struct was generated from the following file:

• src/hid\_wavplayer.h

# 6.44 daisy::WavPlayer Class Reference

```
#include <hid_wavplayer.h>
```

## **Public Member Functions**

- void Init ()
- int Open (size\_t sel)
- int Close ()
- int16 t Stream ()
- void Prepare ()
- void Restart ()
- void SetLooping (bool loop)
- bool GetLooping () const
- size\_t GetNumberFiles () const
- size\_t GetCurrentFile () const

## 6.44.1 Detailed Description

Wav Player that will load .wav files from an SD Card, and then provide a method of accessing the samples with double-buffering.

## 6.44.2 Member Function Documentation

```
6.44.2.1 Close()
int daisy::WavPlayer::Close ( )
Closes whatever file is currently open.
```

Returns

&

```
6.44.2.2 GetCurrentFile()
```

```
size_t daisy::WavPlayer::GetCurrentFile ( ) const [inline]
```

Returns

currently selected file.

## 6.44.2.3 GetLooping()

```
bool daisy::WavPlayer::GetLooping ( ) const [inline]
```

## Returns

Whether the WavPlayer is looping or not.

## 6.44.2.4 GetNumberFiles()

```
size_t daisy::WavPlayer::GetNumberFiles ( ) const [inline]
```

#### Returns

The number of files loaded by the WavPlayer

## 6.44.2.5 Init()

```
void daisy::WavPlayer::Init ( )
```

Initializes the WavPlayer, loading up to max\_files of wav files from an SD Card.

## 6.44.2.6 Open()

Opens the file at index sel for reading.

#### **Parameters**

```
sel File to open
```

## 6.44.2.7 Prepare()

```
void daisy::WavPlayer::Prepare ( )
```

Collects buffer for playback when needed.

## 6.44.2.8 Restart()

```
void daisy::WavPlayer::Restart ( )
```

Resets the playback position to the beginning of the file immediately

## 6.44.2.9 SetLooping()

Sets whether or not the current file will repeat after completing playback.

#### **Parameters**

```
loop To loop or not to loop.
```

## 6.44.2.10 Stream()

```
int16_t daisy::WavPlayer::Stream ( )
```

## Returns

The next sample if playing, otherwise returns 0

The documentation for this class was generated from the following file:

• src/hid\_wavplayer.h

# **Chapter 7**

# **File Documentation**

## 7.1 src/daisy.h File Reference

```
#include <stdint.h>
#include "daisy_core.h"
#include "sys_system.h"
#include "per_qspi.h"
#include "per_dac.h"
#include "per_gpio.h"
#include "per_i2c.h"
#include "per_sai.h"
#include "per_tim.h"
#include "dev_leddriver.h"
#include "dev_sdram.h"
#include "dev_sr_4021.h"
#include "hid_audio.h"
#include "util_unique_id.h"
#include "per_adc.h"
#include "per_uart.h"
#include "hid_midi.h"
#include "hid_encoder.h"
#include "hid_switch.h"
#include "hid ctrl.h"
#include "hid_gatein.h"
#include "hid_parameter.h"
#include "hid_usb.h"
#include "per_sdmmc.h"
#include "per_spi.h"
#include "hid_oled_display.h"
#include "hid_wavplayer.h"
#include "hid led.h"
#include "hid_rgb_led.h"
#include "dev_sr_595.h"
```

## Macros

- #define FBIPMAX 0.999985f
- #define FBIPMIN (-FBIPMAX)

132 File Documentation

```
• #define S162F_SCALE 3.0517578125e-05f
```

- #define F2S16\_SCALE 32767.0f
- #define F2S24\_SCALE 8388608.0f
- #define S242F SCALE 1.192092896e-07f
- #define S24SIGN 0x800000

## **Functions**

- FORCE\_INLINE float s162f (int16\_t x)
- FORCE\_INLINE int16\_t f2s16 (float x)
- FORCE\_INLINE float s242f (int32\_t x)
- FORCE\_INLINE int32\_t f2s24 (float x)

#### 7.1.1 Macro Definition Documentation

## 7.1.1.1 F2S16\_SCALE

```
#define F2S16_SCALE 32767.0f
```

(2 \*\* 15) - 1

## 7.1.1.2 F2S24\_SCALE

#define F2S24\_SCALE 8388608.0f

2 \*\* 23

## 7.1.1.3 FBIPMAX

#define FBIPMAX 0.999985f

close to 1.0f-LSB at 16 bit

## 7.1.1.4 FBIPMIN

#define FBIPMIN (-FBIPMAX)

• (1 - LSB)

```
7.1.1.5 S162F_SCALE
#define S162F_SCALE 3.0517578125e-05f
1 / (2** 15)
7.1.1.6 S242F_SCALE
#define S242F_SCALE 1.192092896e-07f
1 / (2 ** 23)
7.1.1.7 S24SIGN
#define S24SIGN 0x800000
2 ** 23
7.1.2 Function Documentation
7.1.2.1 f2s16()
FORCE_INLINE int16_t f2s16 (
              float x )
& < close to 1.0f-LSB at 16 bit
< - (1 - LSB)
< close to 1.0f-LSB at 16 bit
< - (1 - LSB)
< close to 1.0f-LSB at 16 bit
< close to 1.0f-LSB at 16 bit
< (2 ** 15) - 1
7.1.2.2 f2s24()
FORCE_INLINE int32_t f2s24 (
              float x )
& < close to 1.0f-LSB at 16 bit
< - (1 - LSB)
< close to 1.0f-LSB at 16 bit
< - (1 - LSB)
< close to 1.0f-LSB at 16 bit
< close to 1.0f-LSB at 16 bit
< 2 ** 23
7.1.2.3 s162f()
FORCE_INLINE float s162f (
              int16_t x )
```

Scales float by 1/(2 \(^15\)

134 File Documentation

#### **Parameters**

```
x Number to be scaled.
```

#### Returns

Scaled number.

```
< 1 / (2** 15)
```

## 7.1.2.4 s242f()

# 7.2 src/daisy\_core.h File Reference

```
#include <stdint.h>
#include <stdlib.h>
```

## **Classes**

• struct dsy\_gpio\_pin

## **Macros**

- #define DSY\_CORE\_HW\_H
- #define DMA\_BUFFER\_MEM\_SECTION \_\_attribute\_\_((section(".sram1\_bss")))
- #define DTCM\_MEM\_SECTION \_\_attribute\_\_((section(".dtcmram\_bss")))

## **Enumerations**

```
    enum dsy_gpio_port {
        DSY_GPIOA, DSY_GPIOB, DSY_GPIOC, DSY_GPIOD,
        DSY_GPIOE, DSY_GPIOF, DSY_GPIOG, DSY_GPIOH,
        DSY_GPIOI, DSY_GPIOJ, DSY_GPIOK,
        DSY_GPIO_LAST }
```

#### **Functions**

- FORCE\_INLINE float cube (float x)
- FORCE\_INLINE dsy\_gpio\_pin dsy\_pin (dsy\_gpio\_port port, uint8\_t pin)
- FORCE\_INLINE uint8\_t dsy\_pin\_cmp (dsy\_gpio\_pin \*a, dsy\_gpio\_pin \*b)

## 7.2.1 Macro Definition Documentation

## 7.2.1.1 DMA\_BUFFER\_MEM\_SECTION

```
#define DMA_BUFFER_MEM_SECTION __attribute__((section(".sram1_bss")))
```

Macro for area of memory that is configured as cacheless This should be used primarily for DMA buffers, and the like

#### 7.2.1.2 DSY\_CORE\_HW\_H

```
#define DSY_CORE_HW_H
```

&

## 7.2.1.3 DTCM\_MEM\_SECTION

```
#define DTCM_MEM_SECTION __attribute__((section(".dtcmram_bss")))
```

THE DTCM RAM section is also non-cached. However, is not suitable for DMA transfers. Performance is on par with internal SRAM w/ cache enabled.

## 7.2.2 Enumeration Type Documentation

## 7.2.2.1 dsy\_gpio\_port

```
enum dsy_gpio_port
```

Enums and a simple struct for defining a hardware pin on the MCU These correlate with the stm32 datasheet, and are used to configure the hardware.

## Enumerator

DSY_GPIOA	&
DSY_GPIOB	&
DSY_GPIOC	&
DSY_GPIOD	&
Generated BSB ox GPIOE	&
DSY_GPIOF	&
DSY_GPIOG	&
DSY GPIOH	&

136 File Documentation

## 7.2.3 Function Documentation

## 7.2.3.1 cube()

```
FORCE_INLINE float cube ( float x )
```

Computes cube.

**Parameters** 

```
x Number to be cubed
```

Returns

x ^ 3

## 7.2.3.2 dsy\_pin()

Helper for creating pins from port/pin combos easily

## 7.2.3.3 dsy\_pin\_cmp()

Helper for testing sameness of two dsy\_gpio\_pins

Returns

1 if same, 0 if different

# 7.3 src/daisy\_field.h File Reference

Hardware defines and helpers for daisy field platform.

```
#include "daisy_seed.h"
```

#### **Classes**

· struct daisy::daisy\_field

#### **Macros**

```
• #define DSY FIELD BSP H
```

- #define SAMPLE RATE DSY AUDIO SAMPLE RATE
- #define SW\_1\_PIN 29
- #define SW\_2\_PIN 28
- #define SW 3 PIN 27
- #define GATE\_OUT\_PIN 0
- #define GATE\_IN\_PIN 1
- #define KB SW SR CS PIN 8
- #define KB\_SW\_SR\_CLK\_PIN 9
- #define KB\_SW\_SR\_D1\_PIN 10
- #define KB SW SR D2 PIN 11
- #define MIDI\_OUT\_PIN 14
- #define MIDI\_IN\_PIN 15
- #define MUX SEL 0 PIN 21
- #define MUX\_SEL\_1\_PIN 20
- #define MUX\_SEL\_2\_PIN 19
- #define MUX ADC PIN 16
- #define CV1\_ADC\_PIN 17
- #define CV2\_ADC\_PIN 18
- #define CV3\_ADC\_PIN 23
- #define CV4 ADC PIN 22
- #define LED\_DRIVER\_I2C i2c1\_handle

#### **Enumerations**

```
enum { daisy::SW_2, daisy::SW_1, daisy::SW_3, daisy::SW_LAST }
enum {
    daisy::KNOB_1, daisy::KNOB_3, daisy::KNOB_5, daisy::KNOB_2,
    daisy::KNOB_4, daisy::KNOB_6, daisy::KNOB_7, daisy::KNOB_8,
    daisy::KNOB_LAST }
enum {
    CV_1, daisy::CV_2, daisy::CV_3, daisy::CV_4,
    daisy::CV_LAST }
enum {
    daisy::LED_KEY_A8, daisy::LED_KEY_A7, daisy::LED_KEY_A6, daisy::LED_KEY_A5,
    daisy::LED_KEY_A4, daisy::LED_KEY_A3, daisy::LED_KEY_A2, daisy::LED_KEY_A1,
    daisy::LED_KEY_B1, daisy::LED_KEY_B2, daisy::LED_KEY_B3, daisy::LED_KEY_B4,
    daisy::LED_KEY_B5, daisy::LED_KEY_B6, daisy::LED_KEY_B7, daisy::LED_KEY_B8,
    daisy::LED_KNOB_1, daisy::LED_KNOB_2, daisy::LED_KNOB_3, daisy::LED_KNOB_4,
    daisy::LED_SW_1, daisy::LED_SW_2, daisy::LED_LAST }
```

#### **Functions**

FORCE\_INLINE void daisy::daisy\_field\_init (daisy\_field \*p)

138 File Documentation

## 7.3.1 Detailed Description

Hardware defines and helpers for daisy field platform.

## 7.3.2 Macro Definition Documentation

```
7.3.2.1 CV1_ADC_PIN
```

#define CV1\_ADC\_PIN 17

&

## 7.3.2.2 CV2\_ADC\_PIN

#define CV2\_ADC\_PIN 18

&

## 7.3.2.3 CV3\_ADC\_PIN

#define CV3\_ADC\_PIN 23

&

## 7.3.2.4 CV4\_ADC\_PIN

#define CV4\_ADC\_PIN 22

&

## 7.3.2.5 DSY\_FIELD\_BSP\_H

#define DSY\_FIELD\_BSP\_H

&

## 7.3.2.6 GATE\_IN\_PIN

#define GATE\_IN\_PIN 1

&

```
7.3.2.7 GATE_OUT_PIN
#define GATE_OUT_PIN 0
7.3.2.8 KB_SW_SR_CLK_PIN
#define KB_SW_SR_CLK_PIN 9
7.3.2.9 KB_SW_SR_CS_PIN
#define KB_SW_SR_CS_PIN 8
7.3.2.10 KB_SW_SR_D1_PIN
#define KB_SW_SR_D1_PIN 10
7.3.2.11 KB_SW_SR_D2_PIN
#define KB_SW_SR_D2_PIN 11
&
7.3.2.12 LED DRIVER I2C
#define LED_DRIVER_I2C i2c1_handle
&
7.3.2.13 MIDI_IN_PIN
#define MIDI_IN_PIN 15
&
7.3.2.14 MIDI_OUT_PIN
#define MIDI_OUT_PIN 14
```

```
7.3.2.15 MUX_ADC_PIN
#define MUX_ADC_PIN 16
&
7.3.2.16 MUX_SEL_0_PIN
#define MUX_SEL_0_PIN 21
7.3.2.17 MUX_SEL_1_PIN
#define MUX_SEL_1_PIN 20
7.3.2.18 MUX_SEL_2_PIN
#define MUX_SEL_2_PIN 19
7.3.2.19 SAMPLE_RATE
#define SAMPLE_RATE DSY_AUDIO_SAMPLE_RATE
7.3.2.20 SW_1_PIN
#define SW_1_PIN 29
7.3.2.21 SW_2_PIN
#define SW_2_PIN 28
7.3.2.22 SW_3_PIN
#define SW_3_PIN 27
&
7.3.3 Enumeration Type Documentation
7.3.3.1 anonymous enum
```

anonymous enum

enums for controls, etc.

# Enumerator

SW_2	tactile switch
SW_1	tactile switch
SW_3	toggle
SW_LAST	&

# 7.3.3.2 anonymous enum

anonymous enum

All knobs connect to ADC1\_INP10 via CD4051 mux

#### Enumerator

KNOB_1	&
KNOB_3	&
KNOB_5	&
KNOB_2	&
KNOB_4	&
KNOB_6	&
KNOB_7	&
KNOB_8	&
KNOB_LAST	&

# 7.3.3.3 anonymous enum

anonymous enum

#### Enumerator

CV_2	Connected to ADC1_INP17
CV_3	Connected to ADC1_INP15
CV_4	Connected to ADC1_INP4
CV_LAST	Connected to ADC1_INP11 &

# 7.3.3.4 anonymous enum

anonymous enum

# Enumerator

LED_KEY_A8	&
LED_KEY_A7	&
LED_KEY_A6	&
LED_KEY_A5	&
LED_KEY_A4	&
LED_KEY_A3	&
LED_KEY_A2	&
LED_KEY_A1	&
LED_KEY_B1	&
LED_KEY_B2	&
LED_KEY_B3	&
LED_KEY_B4	&
LED_KEY_B5	&
LED_KEY_B6	&
LED_KEY_B7	&
LED_KEY_B8	&
LED_KNOB↔	&
_1	
LED_KNOB↔	&
	&
LED_KNOB↔ _2	
LED_KNOB↔ _2  LED_KNOB↔ _3  LED_KNOB↔	&
LED_KNOB← _2 LED_KNOB← _3 LED_KNOB← _4	&
LED_KNOB↔ _2  LED_KNOB↔ _3  LED_KNOB↔ _4  LED_KNOB↔ _5  LED_KNOB↔	& & &
LED_KNOB↔ _2  LED_KNOB↔ _3  LED_KNOB↔ _4  LED_KNOB↔ _5  LED_KNOB↔ _6  LED_KNOB↔ _7  LED_KNOB↔ _7  LED_KNOB↔ _8	& & & &
LED_KNOB↔ _2  LED_KNOB↔ _3  LED_KNOB↔ _4  LED_KNOB↔ _5  LED_KNOB↔ _6  LED_KNOB↔ _7  LED_KNOB↔	& & & & &
LED_KNOB↔ _2  LED_KNOB↔ _3  LED_KNOB↔ _4  LED_KNOB↔ _5  LED_KNOB↔ _6  LED_KNOB↔ _7  LED_KNOB↔ _7  LED_KNOB↔ _8	& & & & & & & & & & & & & & & & & & &

# 7.3.4 Function Documentation

# 7.3.4.1 daisy\_field\_init()

```
FORCE_INLINE void daisy::daisy_field_init ( \label{eq:daisy_field} {\tt daisy\_field} \, * \, p \, )
```

# Initializes daisy field

# **Parameters**

p daisy_field struct to initialize		
< &		
< &		
< &		
< &		
< &		
< &		
< &		
< &		
< &		
< &		
< &		
< &		
< &		
< &		
< &		
< &		
< &		
< &		

# 7.4 src/daisy\_patch.h File Reference

#include "daisy\_seed.h"

# Classes

• class daisy::DaisyPatch

Class that handles initializing all of the hardware specific to the Daisy Patch Board. Helper funtions are also in place to provide easy access to built-in controls and peripherals.

# 7.5 src/daisy\_petal.h File Reference

```
#include "daisy_seed.h"
```

#### Classes

· class daisy::DaisyPetal

Helpers and hardware definitions for daisy petal.

#### Macros

• #define DSY\_PETAL\_H

#### 7.5.1 Macro Definition Documentation

#### 7.5.1.1 DSY\_PETAL\_H

```
#define DSY_PETAL_H
```

&

# 7.6 src/daisy\_pod.h File Reference

```
#include "daisy_seed.h"
```

# Classes

· class daisy::DaisyPod

Class that handles initializing all of the hardware specific to the Daisy Patch Board. Helper funtions are also in place to provide easy access to built-in controls and peripherals.

# 7.7 src/daisy\_seed.h File Reference

```
#include "daisy.h"
```

#### Classes

· class daisy::DaisySeed

This is the higher-level interface for the Daisy board.
All basic peripheral configuration/initialization is setup here.

# 7.8 src/dev\_codec\_ak4556.h File Reference

Driver for the AK4556 Stereo Codec.

```
#include "daisy_core.h"
```

#### **Functions**

• void codec\_ak4556\_init (dsy\_gpio\_pin reset\_pin)

#### 7.8.1 Detailed Description

Driver for the AK4556 Stereo Codec.

### 7.8.2 Function Documentation

```
7.8.2.1 codec_ak4556_init()
```

#### Resets the AK4556

#### **Parameters**

reset\_pin | should be a dsy\_gpio\_pin that is connected to the RST pin of the AK4556

# 7.9 src/dev\_codec\_pcm3060.h File Reference

Driver for the PCM3060 Codec.

```
#include "per_i2c.h"
```

# **Functions**

void codec\_pcm3060\_init (dsy\_i2c\_handle \*hi2c)

# 7.9.1 Detailed Description

Driver for the PCM3060 Codec.

#### 7.9.2 Function Documentation

# 7.9.2.1 codec\_pcm3060\_init()

#### Resets the PCM060

#### **Parameters**

```
*hi2c array of pins handling i2c?
```

# 7.10 src/dev\_codec\_wm8731.h File Reference

Driver for the WM8731 Codec.

```
#include <stddef.h>
#include "per_sai.h"
#include "per_i2c.h"
```

#### **Functions**

- uint8\_t codec\_wm8731\_init (dsy\_i2c\_handle \*hi2c, uint8\_t mcu\_is\_master, int32\_t sample\_rate, uint8\_←
  t bitdepth)
- uint8\_t codec\_wm8731\_enter\_bypass (dsy\_i2c\_handle \*hi2c)
- uint8\_t codec\_wm8731\_exit\_bypass (dsy\_i2c\_handle \*hi2c)

# 7.10.1 Detailed Description

Driver for the WM8731 Codec.

# 7.10.2 Function Documentation

# 7.10.2.1 codec\_wm8731\_enter\_bypass()

Put codec into bypass mode

#### **Parameters**

```
*hi2c pins handling i2c
```

#### 7.10.2.2 codec\_wm8731\_exit\_bypass()

```
\label{eq:codec_wm8731_exit_bypass (} $$ dsy_i2c_handle * hi2c )
```

Take codec out of bypass mode

#### **Parameters**

```
*hi2c pins handling i2c
```

# 7.10.2.3 codec\_wm8731\_init()

#### Resets the WM8731

#### **Parameters**

*hi2c	array of pins handling i2c?
mcu_is_master	&
sample_rate	Sample rate to run codec at
bitdepth	Bit depth to run codec at

# 7.11 src/dev\_codec\_wm8731\_frame.h File Reference

WM8731 Codec framework.

```
#include <stddef.h>
```

#### **Classes**

• struct codec\_frame\_t

# **Typedefs**

• typedef void(\* sa\_audio\_callback) (codec\_frame\_t \*, codec\_frame\_t \*, size\_t)

# 7.11.1 Detailed Description

WM8731 Codec framework.

# 7.11.2 Typedef Documentation

```
7.11.2.1 sa_audio_callback
```

```
typedef void(* sa_audio_callback) (codec_frame_t *, codec_frame_t *, size_t)
```

&

# 7.12 src/dev\_flash\_IS25LP064A.h File Reference

IS25LP08D Commands.

#### **Macros**

- #define IS25LP064A H
- #define IS25LP064A FLASH SIZE 0x800000
- #define IS25LP064A SECTOR SIZE 0x10000
- #define IS25LP064A SUBSECTOR SIZE 0x1000
- #define IS25LP064A\_PAGE\_SIZE 0x100
- #define IS25LP064A DUMMY CYCLES READ QUAD 8
- #define IS25LP064A\_DUMMY\_CYCLES\_READ 8
- #define IS25LP064A\_DUMMY\_CYCLES\_READ\_DTR 6
- #define IS25LP064A DUMMY CYCLES READ QUAD DTR 6
- #define IS25LP064A DIE ERASE MAX TIME 460000
- #define IS25LP064A\_SECTOR\_ERASE\_MAX\_TIME 1000
- #define IS25LP064A\_SUBSECTOR\_ERASE\_MAX\_TIME 400
- #define RESET ENABLE CMD 0x66
- #define RESET\_MEMORY\_CMD 0x99
- #define READ ID CMD 0x9E
- #define READ\_ID\_CMD2 0x9F
- #define MULTIPLE\_IO\_READ\_ID\_CMD 0xAF
- #define READ\_SERIAL\_FLASH\_DISCO\_PARAM\_CMD 0x5A
- #define READ\_CMD 0x03
- #define READ\_4\_BYTE\_ADDR\_CMD 0x13
- #define FAST READ CMD 0x0B
- #define FAST READ DTR CMD 0x0D
- #define FAST READ 4 BYTE ADDR CMD 0x0C
- #define DUAL OUT FAST READ CMD 0x3B
- #define DUAL\_OUT\_FAST\_READ\_DTR\_CMD 0x3D
- #define DUAL OUT FAST READ 4 BYTE ADDR CMD 0x3C
- #define DUAL INOUT FAST READ CMD 0xBB
- #define DUAL\_INOUT\_FAST\_READ\_DTR\_CMD 0xBD
- #define DUAL\_INOUT\_FAST\_READ\_4\_BYTE\_ADDR\_CMD 0xBC
- #define QUAD\_OUT\_FAST\_READ\_CMD 0x6B
- #define QUAD\_OUT\_FAST\_READ\_DTR\_CMD 0x0D
- #define QUAD\_OUT\_FAST\_READ\_4\_BYTE\_ADDR\_CMD 0x6C
- #define QUAD\_INOUT\_FAST\_READ\_CMD 0xEB
- #define QUAD INOUT FAST READ DTR CMD 0xED
- #define QUAD\_INOUT\_FAST\_READ\_4\_BYTE\_ADDR\_CMD 0xEC
- #define WRITE ENABLE CMD 0x06
- #define WRITE\_DISABLE\_CMD 0x04
- #define READ STATUS REG CMD 0x05
- #define WRITE\_STATUS\_REG\_CMD 0x01
- #define READ\_LOCK\_REG\_CMD 0xE8
- #define WRITE LOCK REG CMD 0xE5
- #define READ\_FLAG\_STATUS\_REG\_CMD 0x70
- #define CLEAR FLAG STATUS REG CMD 0x50
- #define READ\_NONVOL\_CFG\_REG\_CMD 0xB5
- #define WRITE\_NONVOL\_CFG\_REG\_CMD 0xB1
- #define READ\_READ\_PARAM\_REG\_CMD 0x61
- #define WRITE\_READ\_PARAM\_REG\_CMD 0xC0#define READ\_ENHANCED\_VOL\_CFG\_REG\_CMD 0x81
- #define WRITE\_ENHANCED\_VOL\_CFG\_REG\_CMD 0x85
- #define READ EXT ADDR REG CMD 0xC8
- #define WRITE EXT ADDR REG CMD 0xC5
- #define PAGE PROG CMD 0x02
- #define PAGE\_PROG\_4\_BYTE\_ADDR\_CMD 0x12

- #define DUAL IN FAST PROG CMD 0xA2
- #define EXT\_DUAL\_IN\_FAST\_PROG\_CMD 0xD2
- #define QUAD IN FAST PROG\_CMD 0x32
- #define EXT\_QUAD\_IN\_FAST\_PROG\_CMD 0x38
- #define QUAD IN FAST PROG 4 BYTE ADDR CMD 0x34
- #define SUBSECTOR ERASE CMD 0xd7
- #define SUBSECTOR ERASE QPI CMD 0x20
- #define SUBSECTOR ERASE 4 BYTE ADDR CMD 0x21
- #define SECTOR ERASE CMD 0xD8
- #define SECTOR ERASE 4 BYTE ADDR CMD 0xDC
- #define BLOCK ERASE 32K CMD 0x52
- #define DIE\_ERASE\_CMD 0xC4
- #define PROG ERASE RESUME CMD 0x7A
- #define PROG ERASE SUSPEND CMD 0x75
- #define READ OTP ARRAY CMD 0x4B
- #define PROG\_OTP\_ARRAY\_CMD 0x42
- #define ENTER\_4\_BYTE\_ADDR\_MODE\_CMD 0xB7
- #define EXIT 4 BYTE ADDR MODE CMD 0xE9
- #define ENTER QUAD CMD 0x35
- #define EXIT QUAD CMD 0xF5
- #define IS25LP064A SR WIP ((uint8 t)0x01)

#### IS25LP08D Registers.

- #define IS25LP064A SR WREN ((uint8 t)0x02)
- #define IS25LP064A SR SRWREN ((uint8 t)0x80)
- #define IS25LP064A\_SR\_QE ((uint8\_t)0x40)
- #define IS25LP064A\_NVCR\_NBADDR ((uint16\_t)0x0001)
- #define IS25LP064A\_NVCR\_SEGMENT ((uint16\_t)0x0002)
- #define IS25LP064A\_NVCR\_DUAL ((uint16\_t)0x0004)
- #define IS25LP064A\_NVCR\_QUAB ((uint16\_t)0x0008)
- #define IS25LP064A\_NVCR\_RH ((uint16\_t)0x0010)
- #define IS25LP064A\_NVCR\_DTRP ((uint16\_t)0x0020)
- #define IS25LP064A\_NVCR\_ODS ((uint16\_t)0x01C0)
- #define IS25LP064A NVCR XIP ((uint16 t)0x0E00)
- #define IS25LP064A NVCR NB DUMMY ((uint16 t)0xF000)
- #define IS25LP064A\_VCR\_WRAP ((uint8\_t)0x03)
- #define IS25LP064A VCR XIP ((uint8 t)0x08)
- #define IS25LP064A VCR NB DUMMY ((uint8 t)0xF0)
- #define IS25LP064A EAR HIGHEST SE ((uint8 t)0x03)
- #define IS25LP064A EAR THIRD SEG ((uint8 t)0x02)
- #define IS25LP064A\_EAR\_SECOND\_SEG ((uint8\_t)0x01)
- #define IS25LP064A EAR LOWEST SEG ((uint8 t)0x00)
- #define 1025E1 00+7/\_E7/11\_E07/E01\_0Ed ((dinto\_t)0x00
- #define IS25LP064A\_EVCR\_ODS ((uint8\_t)0x07)
- #define IS25LP064A\_EVCR\_RH ((uint8\_t)0x10)
- #define IS25LP064A\_EVCR\_DTRP ((uint8\_t)0x20)
- #define IS25LP064A\_EVCR\_DUAL ((uint8\_t)0x40)
- #define IS25LP064A\_EVCR\_QUAD ((uint8\_t)0x80)
- #define IS25LP064A\_FSR\_NBADDR ((uint8\_t)0x01)
- #define IS25LP064A\_FSR\_PRERR ((uint8\_t)0x02)
- #define IS25LP064A\_FSR\_PGSUS ((uint8\_t)0x04)
- #define IS25LP064A\_FSR\_PGERR ((uint8\_t)0x10)
- #define IS25LP064A\_FSR\_ERERR ((uint8\_t)0x20)
- #define IS25LP064A\_FSR\_ERSUS ((uint8\_t)0x40)
- #define IS25LP064A FSR READY ((uint8 t)0x80)

# 7.12.1 Detailed Description

IS25LP08D Commands.

#### 7.12.2 Macro Definition Documentation

#### 7.12.2.1 BLOCK\_ERASE\_32K\_CMD

 ${\tt \#define~BLOCK\_ERASE\_32K\_CMD~0x52}$ 

&

# 7.12.2.2 CLEAR\_FLAG\_STATUS\_REG\_CMD

#define CLEAR\_FLAG\_STATUS\_REG\_CMD 0x50

&

# 7.12.2.3 DIE\_ERASE\_CMD

#define DIE\_ERASE\_CMD 0xC4

&

#### 7.12.2.4 DUAL\_IN\_FAST\_PROG\_CMD

#define DUAL\_IN\_FAST\_PROG\_CMD 0xA2

&

# 7.12.2.5 DUAL\_INOUT\_FAST\_READ\_4\_BYTE\_ADDR\_CMD

#define DUAL\_INOUT\_FAST\_READ\_4\_BYTE\_ADDR\_CMD 0xBC

&

# 7.12.2.6 DUAL\_INOUT\_FAST\_READ\_CMD

#define DUAL\_INOUT\_FAST\_READ\_CMD 0xBB

&

```
7.12.2.7 DUAL_INOUT_FAST_READ_DTR_CMD
#define DUAL_INOUT_FAST_READ_DTR_CMD 0xBD
7.12.2.8 DUAL_OUT_FAST_READ_4_BYTE_ADDR_CMD
#define DUAL_OUT_FAST_READ_4_BYTE_ADDR_CMD 0x3C
7.12.2.9 DUAL_OUT_FAST_READ_CMD
#define DUAL_OUT_FAST_READ_CMD 0x3B
7.12.2.10 DUAL_OUT_FAST_READ_DTR_CMD
#define DUAL_OUT_FAST_READ_DTR_CMD 0x3D
7.12.2.11 ENTER_4_BYTE_ADDR_MODE_CMD
#define ENTER_4_BYTE_ADDR_MODE_CMD 0xB7
4-byte Address Mode Operations
7.12.2.12 ENTER QUAD CMD
#define ENTER_QUAD_CMD 0x35
Quad Operations
7.12.2.13 EXIT_4_BYTE_ADDR_MODE_CMD
#define EXIT_4_BYTE_ADDR_MODE_CMD 0xE9
&
7.12.2.14 EXIT_QUAD_CMD
```

#define EXIT\_QUAD\_CMD 0xF5

&

# 7.12.2.15 EXT\_DUAL\_IN\_FAST\_PROG\_CMD #define EXT\_DUAL\_IN\_FAST\_PROG\_CMD 0xD2 & 7.12.2.16 EXT\_QUAD\_IN\_FAST\_PROG\_CMD #define EXT\_QUAD\_IN\_FAST\_PROG\_CMD 0x38 7.12.2.17 FAST\_READ\_4\_BYTE\_ADDR\_CMD #define FAST\_READ\_4\_BYTE\_ADDR\_CMD 0x0C 7.12.2.18 FAST\_READ\_CMD #define FAST\_READ\_CMD 0x0B 7.12.2.19 FAST\_READ\_DTR\_CMD #define FAST\_READ\_DTR\_CMD 0x0D & 7.12.2.20 IS25LP064A DIE ERASE MAX TIME #define IS25LP064A\_DIE\_ERASE\_MAX\_TIME 460000 & 7.12.2.21 IS25LP064A\_DUMMY\_CYCLES\_READ #define IS25LP064A\_DUMMY\_CYCLES\_READ 8 & 7.12.2.22 IS25LP064A\_DUMMY\_CYCLES\_READ\_DTR

Generated by Doxygen

&

#define IS25LP064A\_DUMMY\_CYCLES\_READ\_DTR 6

```
7.12.2.23 IS25LP064A_DUMMY_CYCLES_READ_QUAD
#define IS25LP064A_DUMMY_CYCLES_READ_QUAD 8
7.12.2.24 IS25LP064A_DUMMY_CYCLES_READ_QUAD_DTR
#define IS25LP064A_DUMMY_CYCLES_READ_QUAD_DTR 6
7.12.2.25 IS25LP064A_EAR_HIGHEST_SE
#define IS25LP064A_EAR_HIGHEST_SE ((uint8_t)0x03)
Select the Highest 128Mb segment
7.12.2.26 IS25LP064A_EAR_LOWEST_SEG
#define IS25LP064A_EAR_LOWEST_SEG ((uint8_t)0x00)
Select the Lowest 128Mb segment (default)
7.12.2.27 IS25LP064A_EAR_SECOND_SEG
#define IS25LP064A_EAR_SECOND_SEG ((uint8_t)0x01)
Select the Second 128Mb segment
7.12.2.28 IS25LP064A EAR THIRD SEG
#define IS25LP064A_EAR_THIRD_SEG ((uint8_t)0x02)
Select the Third 128Mb segment
7.12.2.29 IS25LP064A_EVCR_DTRP
#define IS25LP064A_EVCR_DTRP ((uint8_t)0x20)
Double transfer rate protocol
7.12.2.30 IS25LP064A_EVCR_DUAL
#define IS25LP064A_EVCR_DUAL ((uint8_t)0x40)
```

Dual I/O protocol

```
7.12.2.31 IS25LP064A_EVCR_ODS
#define IS25LP064A_EVCR_ODS ((uint8_t)0x07)
Output driver strength
7.12.2.32 IS25LP064A_EVCR_QUAD
#define IS25LP064A_EVCR_QUAD ((uint8_t)0x80)
Quad I/O protocol
7.12.2.33 IS25LP064A_EVCR_RH
#define IS25LP064A_EVCR_RH ((uint8_t)0x10)
Reset/hold
7.12.2.34 IS25LP064A_FLASH_SIZE
#define IS25LP064A_FLASH_SIZE 0x800000
2 * 8 MBits => 1 * 1MBytes => 1MBytes
7.12.2.35 IS25LP064A_FSR_ERERR
#define IS25LP064A_FSR_ERERR ((uint8_t)0x20)
Erase error
7.12.2.36 IS25LP064A_FSR_ERSUS
#define IS25LP064A_FSR_ERSUS ((uint8_t)0x40)
Erase operation suspended
#define IS25LP064A_FSR_NBADDR ((uint8_t)0x01)
3-bytes or 4-bytes addressing
```

# Program error

7.12.2.38 IS25LP064A\_FSR\_PGERR

#define IS25LP064A\_FSR\_PGERR ((uint8\_t)0x10)

# 7.12.2.39 IS25LP064A\_FSR\_PGSUS #define IS25LP064A\_FSR\_PGSUS ((uint8\_t)0x04) Program operation suspended 7.12.2.40 IS25LP064A\_FSR\_PRERR #define IS25LP064A\_FSR\_PRERR ((uint8\_t)0x02) Protection error #define IS25LP064A\_FSR\_READY ((uint8\_t)0x80) Ready or command in progress 7.12.2.42 IS25LP064A\_H #define IS25LP064A\_H 7.12.2.43 IS25LP064A\_NVCR\_DTRP #define IS25LP064A\_NVCR\_DTRP ((uint16\_t)0x0020) Double transfer rate protocol 7.12.2.44 IS25LP064A\_NVCR\_DUAL #define IS25LP064A\_NVCR\_DUAL ((uint16\_t)0x0004) Dual I/O protocol 7.12.2.45 IS25LP064A\_NVCR\_NB\_DUMMY

#define IS25LP064A\_NVCR\_NB\_DUMMY ((uint16\_t)0xF000)

Number of dummy clock cycles

# 

#define IS25LP064A\_NVCR\_NBADDR ((uint16\_t)0x0001)

### 3-bytes or 4-bytes addressing

#### 7.12.2.47 IS25LP064A\_NVCR\_ODS

#define IS25LP064A\_NVCR\_ODS ((uint16\_t)0x01C0)

Output driver strength

#### 7.12.2.48 IS25LP064A\_NVCR\_QUAB

#define IS25LP064A\_NVCR\_QUAB ((uint16\_t)0x0008)

Quad I/O protocol

# 7.12.2.49 IS25LP064A\_NVCR\_RH

#define IS25LP064A\_NVCR\_RH ((uint16\_t)0x0010)

Reset/hold

#### 7.12.2.50 IS25LP064A\_NVCR\_SEGMENT

#define IS25LP064A\_NVCR\_SEGMENT ((uint16\_t)0x0002)

Upper or lower 128Mb segment selected by default

#### 

#define IS25LP064A\_NVCR\_XIP ((uint16\_t)0x0E00)

XIP mode at power-on reset

#### 

#define IS25LP064A\_PAGE\_SIZE 0x100

2 \* 262144 pages of 256 bytes

#### 7.12.2.53 IS25LP064A\_SECTOR\_ERASE\_MAX\_TIME

#define IS25LP064A\_SECTOR\_ERASE\_MAX\_TIME 1000

&

# 

#define IS25LP064A\_SECTOR\_SIZE 0x10000

### 2 \* 1024 sectors of 64KBytes

```
7.12.2.55 IS25LP064A_SR_QE
#define IS25LP064A_SR_QE ((uint8_t)0x40)
&
7.12.2.56 IS25LP064A_SR_SRWREN
#define IS25LP064A_SR_SRWREN ((uint8_t)0x80)
Status register write enable/disable
7.12.2.57 IS25LP064A_SR_WIP
#define IS25LP064A_SR_WIP ((uint8_t)0x01)
IS25LP08D Registers.
Write in progress
7.12.2.58 IS25LP064A_SR_WREN
#define IS25LP064A_SR_WREN ((uint8_t)0x02)
Write enable latch
7.12.2.59 IS25LP064A_SUBSECTOR_ERASE_MAX_TIME
#define IS25LP064A_SUBSECTOR_ERASE_MAX_TIME 400
&
7.12.2.60 IS25LP064A_SUBSECTOR_SIZE
#define IS25LP064A_SUBSECTOR_SIZE 0x1000
2 * 16384 subsectors of 4kBytes
7.12.2.61 IS25LP064A_VCR_NB_DUMMY
#define IS25LP064A_VCR_NB_DUMMY ((uint8_t)0xF0)
```

Number of dummy clock cycles

```
7.12.2.62 IS25LP064A_VCR_WRAP
#define IS25LP064A_VCR_WRAP ((uint8_t)0x03)
Wrap
7.12.2.63 IS25LP064A_VCR_XIP
\#define IS25LP064A_VCR_XIP ((uint8_t)0x08)
XIP
7.12.2.64 MULTIPLE_IO_READ_ID_CMD
#define MULTIPLE_IO_READ_ID_CMD 0xAF
7.12.2.65 PAGE_PROG_4_BYTE_ADDR_CMD
#define PAGE_PROG_4_BYTE_ADDR_CMD 0x12
7.12.2.66 PAGE_PROG_CMD
#define PAGE_PROG_CMD 0x02
Program Operations
7.12.2.67 PROG_ERASE_RESUME_CMD
#define PROG_ERASE_RESUME_CMD 0x7A
&
7.12.2.68 PROG_ERASE_SUSPEND_CMD
#define PROG_ERASE_SUSPEND_CMD 0x75
&
7.12.2.69 PROG_OTP_ARRAY_CMD
#define PROG_OTP_ARRAY_CMD 0x42
&
```

```
7.12.2.70 QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD
#define QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD 0x34
7.12.2.71 QUAD_IN_FAST_PROG_CMD
#define QUAD_IN_FAST_PROG_CMD 0x32
7.12.2.72 QUAD_INOUT_FAST_READ_4_BYTE_ADDR_CMD
#define QUAD_INOUT_FAST_READ_4_BYTE_ADDR_CMD 0xEC
7.12.2.73 QUAD_INOUT_FAST_READ_CMD
#define QUAD_INOUT_FAST_READ_CMD 0xEB
7.12.2.74 QUAD_INOUT_FAST_READ_DTR_CMD
#define QUAD_INOUT_FAST_READ_DTR_CMD 0xED
&
7.12.2.75 QUAD_OUT_FAST_READ_4_BYTE_ADDR_CMD
#define QUAD_OUT_FAST_READ_4_BYTE_ADDR_CMD 0x6C
&
7.12.2.76 QUAD_OUT_FAST_READ_CMD
#define QUAD_OUT_FAST_READ_CMD 0x6B
&
7.12.2.77 QUAD_OUT_FAST_READ_DTR_CMD
```

#define QUAD\_OUT\_FAST\_READ\_DTR\_CMD 0x0D

&

# 7.12.2.78 READ\_4\_BYTE\_ADDR\_CMD #define READ\_4\_BYTE\_ADDR\_CMD 0x13 7.12.2.79 READ\_CMD #define READ\_CMD 0x03 **Read Operations** 7.12.2.80 READ\_ENHANCED\_VOL\_CFG\_REG\_CMD #define READ\_ENHANCED\_VOL\_CFG\_REG\_CMD 0x81 7.12.2.81 READ\_EXT\_ADDR\_REG\_CMD #define READ\_EXT\_ADDR\_REG\_CMD 0xC8 7.12.2.82 READ\_FLAG\_STATUS\_REG\_CMD #define READ\_FLAG\_STATUS\_REG\_CMD 0x70 & 7.12.2.83 READ\_ID\_CMD #define READ\_ID\_CMD 0x9E **Identification Operations** 7.12.2.84 READ\_ID\_CMD2 #define READ\_ID\_CMD2 0x9F & 7.12.2.85 READ\_LOCK\_REG\_CMD

#### Generated by Doxygen

&

#define READ\_LOCK\_REG\_CMD 0xE8

```
7.12.2.86 READ_NONVOL_CFG_REG_CMD
#define READ_NONVOL_CFG_REG_CMD 0xB5
7.12.2.87 READ_OTP_ARRAY_CMD
#define READ_OTP_ARRAY_CMD 0x4B
One-Time Programmable Operations
7.12.2.88 READ_READ_PARAM_REG_CMD
#define READ_READ_PARAM_REG_CMD 0x61
7.12.2.89 READ_SERIAL_FLASH_DISCO_PARAM_CMD
#define READ_SERIAL_FLASH_DISCO_PARAM_CMD 0x5A
7.12.2.90 READ_STATUS_REG_CMD
#define READ_STATUS_REG_CMD 0x05
Register Operations
7.12.2.91 RESET ENABLE CMD
#define RESET_ENABLE_CMD 0x66
Reset Operations
7.12.2.92 RESET_MEMORY_CMD
#define RESET_MEMORY_CMD 0x99
```

# 7.12.2.93 SECTOR\_ERASE\_4\_BYTE\_ADDR\_CMD

#define SECTOR\_ERASE\_4\_BYTE\_ADDR\_CMD 0xDC

&

&

# 7.12.2.94 SECTOR\_ERASE\_CMD #define SECTOR\_ERASE\_CMD 0xD8 & 7.12.2.95 SUBSECTOR\_ERASE\_4\_BYTE\_ADDR\_CMD #define SUBSECTOR\_ERASE\_4\_BYTE\_ADDR\_CMD 0x21 7.12.2.96 SUBSECTOR\_ERASE\_CMD #define SUBSECTOR\_ERASE\_CMD 0xd7 **Erase Operations** 7.12.2.97 SUBSECTOR\_ERASE\_QPI\_CMD #define SUBSECTOR\_ERASE\_QPI\_CMD 0x20 7.12.2.98 WRITE\_DISABLE\_CMD #define WRITE\_DISABLE\_CMD 0x04 & 7.12.2.99 WRITE\_ENABLE\_CMD #define WRITE\_ENABLE\_CMD 0x06 Write Operations 7.12.2.100 WRITE\_ENHANCED\_VOL\_CFG\_REG\_CMD #define WRITE\_ENHANCED\_VOL\_CFG\_REG\_CMD 0x85 &

Generated by Doxygen

&

7.12.2.101 WRITE\_EXT\_ADDR\_REG\_CMD

#define WRITE\_EXT\_ADDR\_REG\_CMD 0xC5

#### 7.12.2.102 WRITE\_LOCK\_REG\_CMD

#define WRITE\_LOCK\_REG\_CMD 0xE5

&

#### 7.12.2.103 WRITE\_NONVOL\_CFG\_REG\_CMD

#define WRITE\_NONVOL\_CFG\_REG\_CMD 0xB1

8

#### 7.12.2.104 WRITE\_READ\_PARAM\_REG\_CMD

#define WRITE\_READ\_PARAM\_REG\_CMD 0xC0

&

#### 7.12.2.105 WRITE\_STATUS\_REG\_CMD

#define WRITE\_STATUS\_REG\_CMD 0x01

&

# 7.13 src/dev\_flash\_IS25LP080D.h File Reference

IS25LP08D Commands.

#### **Macros**

- #define IS25LP080D\_FLASH\_SIZE 0x100000
- #define IS25LP080D\_SECTOR\_SIZE 0x10000
- #define IS25LP080D\_SUBSECTOR\_SIZE 0x1000
- #define IS25LP080D\_PAGE\_SIZE 0x100
- #define IS25LP080D\_DUMMY\_CYCLES\_READ\_QUAD 8
- #define IS25LP080D\_DUMMY\_CYCLES\_READ 8
- #define IS25LP080D\_DUMMY\_CYCLES\_READ\_DTR 6
- #define IS25LP080D\_DUMMY\_CYCLES\_READ\_QUAD\_DTR 6
- #define IS25LP080D DIE ERASE MAX TIME 460000
- #define IS25LP080D\_SECTOR\_ERASE\_MAX\_TIME 1000
- #define IS25LP080D\_SUBSECTOR\_ERASE\_MAX\_TIME 400
- #define RESET\_ENABLE\_CMD 0x66
- #define RESET\_MEMORY\_CMD 0x99
- #define READ ID CMD 0x9E
- #define READ\_ID\_CMD2 0x9F
- #define MULTIPLE IO READ ID CMD 0xAF
- #define READ\_SERIAL\_FLASH\_DISCO\_PARAM\_CMD 0x5A

- #define READ CMD 0x03
- #define READ\_4\_BYTE\_ADDR\_CMD 0x13
- #define FAST\_READ\_CMD 0x0B
- #define FAST\_READ\_DTR\_CMD 0x0D
- #define FAST READ 4 BYTE ADDR CMD 0x0C
- #define DUAL\_OUT\_FAST\_READ\_CMD 0x3B
- #define DUAL OUT FAST READ DTR CMD 0x3D
- #define DUAL\_OUT\_FAST\_READ\_4\_BYTE\_ADDR\_CMD 0x3C
- #define DUAL\_INOUT\_FAST\_READ\_CMD 0xBB
- #define DUAL INOUT FAST READ DTR CMD 0xBD
- #define DUAL\_INOUT\_FAST\_READ\_4\_BYTE\_ADDR\_CMD 0xBC
- #define QUAD OUT FAST READ CMD 0x6B
- #define QUAD\_OUT\_FAST\_READ\_DTR\_CMD 0x0D
- #define QUAD OUT FAST READ 4 BYTE ADDR CMD 0x6C
- #define QUAD\_INOUT\_FAST\_READ\_CMD 0xEB
- #define QUAD INOUT FAST READ DTR CMD 0xED
- #define QUAD INOUT FAST READ 4 BYTE ADDR CMD 0xEC
- #define WRITE ENABLE CMD 0x06
- #define WRITE DISABLE CMD 0x04
- #define READ\_STATUS\_REG\_CMD 0x05
- #define WRITE\_STATUS\_REG\_CMD 0x01
- #define READ\_LOCK\_REG\_CMD 0xE8
- #define WRITE LOCK REG CMD 0xE5
- #define READ\_FLAG\_STATUS\_REG\_CMD 0x70
- #define CLEAR FLAG STATUS REG CMD 0x50
- #define READ\_NONVOL\_CFG\_REG\_CMD 0xB5
- #define WRITE\_NONVOL\_CFG\_REG\_CMD 0xB1
- #define READ\_READ\_PARAM\_REG\_CMD 0x61
- #define WRITE\_READ\_PARAM\_REG\_CMD 0xC0
- #define READ\_ENHANCED\_VOL\_CFG\_REG\_CMD 0x81
- #define WRITE\_ENHANCED\_VOL\_CFG\_REG\_CMD 0x85
- #define READ EXT ADDR REG CMD 0xC8
- #define WRITE\_EXT\_ADDR\_REG\_CMD 0xC5
- #define PAGE\_PROG\_CMD 0x02
- #define PAGE\_PROG\_4\_BYTE\_ADDR\_CMD 0x12
- #define DUAL\_IN\_FAST\_PROG\_CMD 0xA2
- #define EXT\_DUAL\_IN\_FAST\_PROG\_CMD 0xD2
- #define QUAD\_IN\_FAST\_PROG\_CMD 0x32
- #define EXT\_QUAD\_IN\_FAST\_PROG\_CMD 0x38
- #define QUAD\_IN\_FAST\_PROG\_4\_BYTE\_ADDR\_CMD 0x34
- #define SUBSECTOR ERASE CMD 0xd7
- #define SUBSECTOR\_ERASE\_QPI\_CMD 0x20
- #define SUBSECTOR\_ERASE\_4\_BYTE\_ADDR\_CMD 0x21
- #define SECTOR\_ERASE\_CMD 0xD8
- #define SECTOR\_ERASE\_4\_BYTE\_ADDR\_CMD 0xDC
- #define BLOCK ERASE 32K CMD 0x52
- #define DIE ERASE CMD 0xC4
- #define PROG\_ERASE\_RESUME\_CMD 0x7A
- #define PROG\_ERASE\_SUSPEND\_CMD 0x75
- #define READ\_OTP\_ARRAY\_CMD 0x4B
- #define PROG OTP ARRAY CMD 0x42
- #define ENTER\_4\_BYTE\_ADDR\_MODE\_CMD 0xB7
- #define EXIT\_4\_BYTE\_ADDR\_MODE\_CMD 0xE9
- #define ENTER\_QUAD\_CMD 0x35
- #define EXIT\_QUAD\_CMD 0xF5

- #define IS25LP080D\_SR\_WIP ((uint8\_t)0x01)
   IS25LP08D Registers.
- #define IS25LP080D\_SR\_WREN ((uint8\_t)0x02)
- #define IS25LP080D\_SR\_SRWREN ((uint8\_t)0x80)
- #define IS25LP080D\_SR\_QE ((uint8\_t)0x40)
- #define IS25LP080D\_NVCR\_NBADDR ((uint16\_t)0x0001)
- #define IS25LP080D NVCR SEGMENT ((uint16 t)0x0002)
- #define IS25LP080D NVCR DUAL ((uint16 t)0x0004)
- #define IS25LP080D\_NVCR\_QUAB ((uint16\_t)0x0008)
- #define IS25LP080D\_NVCR\_RH ((uint16\_t)0x0010)
- #define IS25LP080D\_NVCR\_DTRP ((uint16\_t)0x0020)
- #define IS25LP080D\_NVCR\_ODS ((uint16\_t)0x01C0)
- #define IS25LP080D\_NVCR\_XIP ((uint16\_t)0x0E00)
- #define IS25LP080D\_NVCR\_NB\_DUMMY ((uint16\_t)0xF000)
- #define IS25LP080D\_VCR\_WRAP ((uint8\_t)0x03)
- #define IS25LP080D VCR XIP ((uint8 t)0x08)
- #define IS25LP080D VCR NB DUMMY ((uint8 t)0xF0)
- #define IS25LP080D\_EAR\_HIGHEST\_SE ((uint8\_t)0x03)
- #define IS25LP080D\_EAR\_THIRD\_SEG ((uint8\_t)0x02)
- #define IS25LP080D\_EAR\_SECOND\_SEG ((uint8\_t)0x01)
- #define IS25LP080D\_EAR\_LOWEST\_SEG ((uint8\_t)0x00)
- #define IS25LP080D\_EVCR\_ODS ((uint8\_t)0x07)
- #define IS25LP080D EVCR RH ((uint8 t)0x10)
- #define IS25LP080D EVCR DTRP ((uint8 t)0x20)
- #define IS25LP080D EVCR DUAL ((uint8 t)0x40)
- #define IS25LP080D\_EVCR\_QUAD ((uint8\_t)0x80)
- #define IS25LP080D\_FSR\_NBADDR ((uint8\_t)0x01)
- #define IS25LP080D FSR PRERR ((uint8 t)0x02)
- #define IS25LP080D\_FSR\_PGSUS ((uint8\_t)0x04)
- #define IS25LP080D FSR PGERR ((uint8 t)0x10)
- #define IS25LP080D\_FSR\_ERERR ((uint8\_t)0x20)
- #define IS25LP080D FSR ERSUS ((uint8 t)0x40)
- #define IS25LP080D\_FSR\_READY ((uint8\_t)0x80)

# 7.13.1 Detailed Description

IS25LP08D Commands.

#### 7.13.2 Macro Definition Documentation

#### 7.13.2.1 BLOCK ERASE 32K CMD

#define BLOCK\_ERASE\_32K\_CMD 0x52

#### 7.13.2.2 CLEAR\_FLAG\_STATUS\_REG\_CMD

#define CLEAR\_FLAG\_STATUS\_REG\_CMD 0x50

&

#### 7.13.2.3 DIE\_ERASE\_CMD

#define DIE\_ERASE\_CMD 0xC4

ጴ

# 7.13.2.4 DUAL\_IN\_FAST\_PROG\_CMD

#define DUAL\_IN\_FAST\_PROG\_CMD 0xA2

&

#### 7.13.2.5 DUAL\_INOUT\_FAST\_READ\_4\_BYTE\_ADDR\_CMD

#define DUAL\_INOUT\_FAST\_READ\_4\_BYTE\_ADDR\_CMD 0xBC

ጴ

#### 7.13.2.6 DUAL\_INOUT\_FAST\_READ\_CMD

#define DUAL\_INOUT\_FAST\_READ\_CMD 0xBB

&

#### 7.13.2.7 DUAL\_INOUT\_FAST\_READ\_DTR\_CMD

#define DUAL\_INOUT\_FAST\_READ\_DTR\_CMD 0xBD

&

# 7.13.2.8 DUAL\_OUT\_FAST\_READ\_4\_BYTE\_ADDR\_CMD

#define DUAL\_OUT\_FAST\_READ\_4\_BYTE\_ADDR\_CMD 0x3C

&

#### 7.13.2.9 DUAL\_OUT\_FAST\_READ\_CMD

#define DUAL\_OUT\_FAST\_READ\_CMD 0x3B

&

```
7.13.2.10 DUAL_OUT_FAST_READ_DTR_CMD
#define DUAL_OUT_FAST_READ_DTR_CMD 0x3D
7.13.2.11 ENTER_4_BYTE_ADDR_MODE_CMD
#define ENTER_4_BYTE_ADDR_MODE_CMD 0xB7
4-byte Address Mode Operations
7.13.2.12 ENTER_QUAD_CMD
#define ENTER_QUAD_CMD 0x35
Quad Operations
7.13.2.13 EXIT_4_BYTE_ADDR_MODE_CMD
#define EXIT_4_BYTE_ADDR_MODE_CMD 0xE9
7.13.2.14 EXIT_QUAD_CMD
#define EXIT_QUAD_CMD 0xF5
&
7.13.2.15 EXT_DUAL_IN_FAST_PROG_CMD
#define EXT_DUAL_IN_FAST_PROG_CMD 0xD2
&
7.13.2.16 EXT_QUAD_IN_FAST_PROG_CMD
#define EXT_QUAD_IN_FAST_PROG_CMD 0x38
&
7.13.2.17 FAST_READ_4_BYTE_ADDR_CMD
```

#define FAST\_READ\_4\_BYTE\_ADDR\_CMD 0x0C

&

Generated by Doxygen

```
7.13.2.18 FAST_READ_CMD
#define FAST_READ_CMD 0x0B
&
7.13.2.19 FAST_READ_DTR_CMD
#define FAST_READ_DTR_CMD 0x0D
7.13.2.20 IS25LP080D_DIE_ERASE_MAX_TIME
#define IS25LP080D_DIE_ERASE_MAX_TIME 460000
&
7.13.2.21 IS25LP080D_DUMMY_CYCLES_READ
#define IS25LP080D_DUMMY_CYCLES_READ 8
7.13.2.22 IS25LP080D_DUMMY_CYCLES_READ_DTR
#define IS25LP080D_DUMMY_CYCLES_READ_DTR 6
&
7.13.2.23 IS25LP080D_DUMMY_CYCLES_READ_QUAD
#define IS25LP080D_DUMMY_CYCLES_READ_QUAD 8
&
7.13.2.24 IS25LP080D_DUMMY_CYCLES_READ_QUAD_DTR
#define IS25LP080D_DUMMY_CYCLES_READ_QUAD_DTR 6
&
7.13.2.25 IS25LP080D_EAR_HIGHEST_SE
#define IS25LP080D_EAR_HIGHEST_SE ((uint8_t)0x03)
Select the Highest 128Mb segment
```

```
7.13.2.26 IS25LP080D_EAR_LOWEST_SEG
#define IS25LP080D_EAR_LOWEST_SEG ((uint8_t)0x00)
Select the Lowest 128Mb segment (default)
7.13.2.27 IS25LP080D_EAR_SECOND_SEG
#define IS25LP080D_EAR_SECOND_SEG ((uint8_t)0x01)
Select the Second 128Mb segment
7.13.2.28 IS25LP080D_EAR_THIRD_SEG
#define IS25LP080D_EAR_THIRD_SEG ((uint8_t)0x02)
Select the Third 128Mb segment
7.13.2.29 IS25LP080D_EVCR_DTRP
#define IS25LP080D_EVCR_DTRP ((uint8_t)0x20)
Double transfer rate protocol
7.13.2.30 IS25LP080D_EVCR_DUAL
#define IS25LP080D_EVCR_DUAL ((uint8_t)0x40)
Dual I/O protocol
7.13.2.31 IS25LP080D_EVCR_ODS
#define IS25LP080D_EVCR_ODS ((uint8_t)0x07)
Output driver strength
7.13.2.32 IS25LP080D_EVCR_QUAD
#define IS25LP080D_EVCR_QUAD ((uint8_t)0x80)
Quad I/O protocol
7.13.2.33 IS25LP080D_EVCR_RH
#define IS25LP080D_EVCR_RH ((uint8_t)0x10)
```

Reset/hold

```
7.13.2.34 IS25LP080D_FLASH_SIZE
#define IS25LP080D_FLASH_SIZE 0x100000
2 * 8 \text{ MBits} => 1 * 1 \text{MBytes} => 1 \text{MBytes}
#define IS25LP080D_FSR_ERERR ((uint8_t)0x20)
Erase error
7.13.2.36 IS25LP080D_FSR_ERSUS
#define IS25LP080D_FSR_ERSUS ((uint8_t)0x40)
Erase operation suspended
#define IS25LP080D_FSR_NBADDR ((uint8_t)0x01)
3-bytes or 4-bytes addressing
7.13.2.38 IS25LP080D_FSR_PGERR
#define IS25LP080D_FSR_PGERR ((uint8_t)0x10)
Program error
#define IS25LP080D_FSR_PGSUS ((uint8_t)0x04)
Program operation suspended
#define IS25LP080D_FSR_PRERR ((uint8_t)0x02)
Protection error
```

#### Generated by Doxygen

Ready or command in progress

#define IS25LP080D\_FSR\_READY ((uint8\_t)0x80)

# 7.13.2.42 IS25LP080D\_NVCR\_DTRP #define IS25LP080D\_NVCR\_DTRP ((uint16\_t)0x0020) Double transfer rate protocol 7.13.2.43 IS25LP080D\_NVCR\_DUAL #define IS25LP080D\_NVCR\_DUAL ((uint16\_t)0x0004) Dual I/O protocol 7.13.2.44 IS25LP080D\_NVCR\_NB\_DUMMY #define IS25LP080D\_NVCR\_NB\_DUMMY ((uint16\_t)0xF000) Number of dummy clock cycles #define IS25LP080D\_NVCR\_NBADDR ((uint16\_t)0x0001) 3-bytes or 4-bytes addressing 7.13.2.46 IS25LP080D\_NVCR\_ODS #define IS25LP080D\_NVCR\_ODS ((uint16\_t)0x01C0) Output driver strength 7.13.2.47 IS25LP080D\_NVCR\_QUAB

#define IS25LP080D\_NVCR\_QUAB ((uint16\_t)0x0008)

Quad I/O protocol

# 7.13.2.48 IS25LP080D\_NVCR\_RH

#define IS25LP080D\_NVCR\_RH ((uint16\_t)0x0010)

Reset/hold

### 7.13.2.49 IS25LP080D\_NVCR\_SEGMENT

#define IS25LP080D\_NVCR\_SEGMENT ((uint16\_t)0x0002)

Upper or lower 128Mb segment selected by default

```
#define IS25LP080D_NVCR_XIP ((uint16_t)0x0E00)
XIP mode at power-on reset
#define IS25LP080D_PAGE_SIZE 0x100
2 * 262144 pages of 256 bytes
7.13.2.52 IS25LP080D_SECTOR_ERASE_MAX_TIME
#define IS25LP080D_SECTOR_ERASE_MAX_TIME 1000
&
#define IS25LP080D_SECTOR_SIZE 0x10000
2 * 1024 sectors of 64KBytes
7.13.2.54 IS25LP080D_SR_QE
#define IS25LP080D_SR_QE ((uint8_t)0x40)
&
7.13.2.55 IS25LP080D_SR_SRWREN
#define IS25LP080D_SR_SRWREN ((uint8_t)0x80)
Status register write enable/disable
7.13.2.56 IS25LP080D_SR_WIP
#define IS25LP080D_SR_WIP ((uint8_t)0x01)
IS25LP08D Registers.
Status Register Write in progress
```

```
#define IS25LP080D_SR_WREN ((uint8_t)0x02)
Write enable latch
7.13.2.58 IS25LP080D_SUBSECTOR_ERASE_MAX_TIME
#define IS25LP080D_SUBSECTOR_ERASE_MAX_TIME 400
7.13.2.59 IS25LP080D_SUBSECTOR_SIZE
#define IS25LP080D_SUBSECTOR_SIZE 0x1000
2 * 16384 subsectors of 4kBytes
7.13.2.60 IS25LP080D_VCR_NB_DUMMY
#define IS25LP080D_VCR_NB_DUMMY ((uint8_t)0xF0)
Number of dummy clock cycles
#define IS25LP080D_VCR_WRAP ((uint8_t)0x03)
Wrap
7.13.2.62 IS25LP080D_VCR_XIP
#define IS25LP080D_VCR_XIP ((uint8_t)0x08)
XIP
7.13.2.63 MULTIPLE_IO_READ_ID_CMD
#define MULTIPLE_IO_READ_ID_CMD 0xAF
&
7.13.2.64 PAGE_PROG_4_BYTE_ADDR_CMD
#define PAGE_PROG_4_BYTE_ADDR_CMD 0x12
```

&

## 7.13.2.65 PAGE\_PROG\_CMD #define PAGE\_PROG\_CMD 0x02 **Program Operations** 7.13.2.66 PROG\_ERASE\_RESUME\_CMD #define PROG\_ERASE\_RESUME\_CMD 0x7A 7.13.2.67 PROG\_ERASE\_SUSPEND\_CMD #define PROG\_ERASE\_SUSPEND\_CMD 0x75 7.13.2.68 PROG\_OTP\_ARRAY\_CMD #define PROG\_OTP\_ARRAY\_CMD 0x42 7.13.2.69 QUAD\_IN\_FAST\_PROG\_4\_BYTE\_ADDR\_CMD #define QUAD\_IN\_FAST\_PROG\_4\_BYTE\_ADDR\_CMD 0x34 & 7.13.2.70 QUAD IN FAST\_PROG\_CMD #define QUAD\_IN\_FAST\_PROG\_CMD 0x32 & 7.13.2.71 QUAD\_INOUT\_FAST\_READ\_4\_BYTE\_ADDR\_CMD #define QUAD\_INOUT\_FAST\_READ\_4\_BYTE\_ADDR\_CMD 0xEC & 7.13.2.72 QUAD\_INOUT\_FAST\_READ\_CMD

Generated by Doxygen

&

#define QUAD\_INOUT\_FAST\_READ\_CMD 0xEB

```
7.13.2.73 QUAD_INOUT_FAST_READ_DTR_CMD
#define QUAD_INOUT_FAST_READ_DTR_CMD 0xED
&
7.13.2.74 QUAD_OUT_FAST_READ_4_BYTE_ADDR_CMD
#define QUAD_OUT_FAST_READ_4_BYTE_ADDR_CMD 0x6C
7.13.2.75 QUAD_OUT_FAST_READ_CMD
#define QUAD_OUT_FAST_READ_CMD 0x6B
7.13.2.76 QUAD_OUT_FAST_READ_DTR_CMD
#define QUAD_OUT_FAST_READ_DTR_CMD 0x0D
7.13.2.77 READ_4_BYTE_ADDR_CMD
#define READ_4_BYTE_ADDR_CMD 0x13
&
7.13.2.78 READ_CMD
#define READ_CMD 0x03
Read Operations
7.13.2.79 READ_ENHANCED_VOL_CFG_REG_CMD
#define READ_ENHANCED_VOL_CFG_REG_CMD 0x81
&
7.13.2.80 READ_EXT_ADDR_REG_CMD
#define READ_EXT_ADDR_REG_CMD 0xC8
```

# 7.13.2.81 READ\_FLAG\_STATUS\_REG\_CMD #define READ\_FLAG\_STATUS\_REG\_CMD 0x70

ŏ

#### 7.13.2.82 READ\_ID\_CMD

#define READ\_ID\_CMD 0x9E

Identification Operations

## 7.13.2.83 READ\_ID\_CMD2

#define READ\_ID\_CMD2 0x9F

&

#### 7.13.2.84 READ\_LOCK\_REG\_CMD

#define READ\_LOCK\_REG\_CMD 0xE8

&

## 7.13.2.85 READ\_NONVOL\_CFG\_REG\_CMD

#define READ\_NONVOL\_CFG\_REG\_CMD 0xB5

&

#### 7.13.2.86 READ\_OTP\_ARRAY\_CMD

#define READ\_OTP\_ARRAY\_CMD 0x4B

One-Time Programmable Operations

## 7.13.2.87 READ\_READ\_PARAM\_REG\_CMD

#define READ\_READ\_PARAM\_REG\_CMD 0x61

&

#### 7.13.2.88 READ\_SERIAL\_FLASH\_DISCO\_PARAM\_CMD

#define READ\_SERIAL\_FLASH\_DISCO\_PARAM\_CMD 0x5A

#### 7.13.2.89 READ\_STATUS\_REG\_CMD

#define READ\_STATUS\_REG\_CMD 0x05

**Register Operations** 

#### 7.13.2.90 RESET\_ENABLE\_CMD

#define RESET\_ENABLE\_CMD 0x66

**Reset Operations** 

## 7.13.2.91 RESET\_MEMORY\_CMD

#define RESET\_MEMORY\_CMD 0x99

&

#### 7.13.2.92 SECTOR\_ERASE\_4\_BYTE\_ADDR\_CMD

#define SECTOR\_ERASE\_4\_BYTE\_ADDR\_CMD 0xDC

&

#### 7.13.2.93 SECTOR\_ERASE\_CMD

#define SECTOR\_ERASE\_CMD 0xD8

&

#### 7.13.2.94 SUBSECTOR\_ERASE\_4\_BYTE\_ADDR\_CMD

#define SUBSECTOR\_ERASE\_4\_BYTE\_ADDR\_CMD 0x21

&

## 7.13.2.95 SUBSECTOR\_ERASE\_CMD

#define SUBSECTOR\_ERASE\_CMD 0xd7

**Erase Operations** 

## 7.13.2.96 SUBSECTOR\_ERASE\_QPI\_CMD

#define SUBSECTOR\_ERASE\_QPI\_CMD 0x20

#### 7.13.2.97 WRITE\_DISABLE\_CMD

#define WRITE\_DISABLE\_CMD 0x04

8

#### 7.13.2.98 WRITE\_ENABLE\_CMD

#define WRITE\_ENABLE\_CMD 0x06

Write Operations

## 7.13.2.99 WRITE\_ENHANCED\_VOL\_CFG\_REG\_CMD

#define WRITE\_ENHANCED\_VOL\_CFG\_REG\_CMD 0x85

&

#### 7.13.2.100 WRITE\_EXT\_ADDR\_REG\_CMD

#define WRITE\_EXT\_ADDR\_REG\_CMD 0xC5

ጴ

## 7.13.2.101 WRITE\_LOCK\_REG\_CMD

#define WRITE\_LOCK\_REG\_CMD 0xE5

&

#### 7.13.2.102 WRITE\_NONVOL\_CFG\_REG\_CMD

#define WRITE\_NONVOL\_CFG\_REG\_CMD 0xB1

&

## 7.13.2.103 WRITE\_READ\_PARAM\_REG\_CMD

#define WRITE\_READ\_PARAM\_REG\_CMD 0xC0

&

#### 7.13.2.104 WRITE\_STATUS\_REG\_CMD

#define WRITE\_STATUS\_REG\_CMD 0x01

## 7.14 src/dev\_leddriver.h File Reference

Device driver for PCA9685 16-channel 12-bit PWM generator.

```
#include <stdint.h>
#include "per_i2c.h"
```

#### **Classes**

· struct color

#### **Macros**

- #define SA\_LED\_DRIVER\_H
- #define DSY\_LED\_DRIVER\_MAX\_DRIVERS 8

#### **Enumerations**

enum {
 LED\_COLOR\_RED, LED\_COLOR\_GREEN, LED\_COLOR\_BLUE, LED\_COLOR\_WHITE,
 LED\_COLOR\_PURPLE, LED\_COLOR\_CYAN, LED\_COLOR\_GOLD, LED\_COLOR\_OFF,
 LED\_COLOR\_LAST }

## **Functions**

- void dsy\_led\_driver\_init (dsy\_i2c\_handle \*dsy\_i2c, uint8\_t \*addr, uint8\_t addr\_cnt)
- void dsy\_led\_driver\_update ()
- void dsy\_led\_driver\_set\_led (uint8\_t idx, float bright)
- color \* dsy\_led\_driver\_color\_by\_name (uint8\_t name)

## 7.14.1 Detailed Description

Device driver for PCA9685 16-channel 12-bit PWM generator.

#### 7.14.2 Macro Definition Documentation

#### 7.14.2.1 DSY\_LED\_DRIVER\_MAX\_DRIVERS

```
#define DSY_LED_DRIVER_MAX_DRIVERS 8
```

#### Maximum number of drivers

## 7.14.2.2 SA\_LED\_DRIVER\_H

```
#define SA_LED_DRIVER_H
```

Q.

## 7.14.3 Enumeration Type Documentation

## 7.14.3.1 anonymous enum

anonymous enum

## Different Led colors

#### Enumerator

LED_COLOR_RED	&
LED_COLOR_GREEN	&
LED_COLOR_BLUE	&
LED_COLOR_WHITE	&
LED_COLOR_PURPLE	&
LED_COLOR_CYAN	&
LED_COLOR_GOLD	&
LED_COLOR_OFF	&
LED_COLOR_LAST	&

## 7.14.4 Function Documentation

## 7.14.4.1 dsy\_led\_driver\_color\_by\_name()

Passing in one of the preset colors will return a pointer to a color struct

#### **Parameters**

name	Preset color

#### 7.14.4.2 dsy\_led\_driver\_init()

Initializes the LED Driver(s) on the specified I2C Bus

#### **Parameters**

*dsy_i2c	should be any dsy_i2c_handle with pins and speed configured.
addr	is either a pointer to 1 device address, or an array of addresses for multiple devices
addr_cnt	is the number of addresses passed in (use '1' for a single device)

#### 7.14.4.3 dsy\_led\_driver\_set\_led()

sets the LED at the index to the specified brightness (0-1) Index is sequential so device 0 will have idx 0-15, while device 1 will have idx 16-31, etc.

#### **Parameters**

idx	Index
bright	Brightness

#### 7.14.4.4 dsy\_led\_driver\_update()

```
void dsy_led_driver_update ( )
```

Updates the LED Driver with the values set using the set function Currently only updates one driver at a time due to the time it takes to update all of the devices. This can likely be set up to use DMA so that the function doesn't block for so long.

## 7.15 src/dev\_sdram.h File Reference

```
#include <stdint.h>
#include "daisy_core.h"
```

#### Classes

· struct dsy\_sdram\_handle

#### **Macros**

- #define RAM AS4C16M16SA H
- #define DSY\_SDRAM\_DATA \_\_attribute\_\_((section(".sdram\_data")))
- #define DSY\_SDRAM\_BSS \_\_attribute\_\_((section(".sdram\_bss")))

#### **Enumerations**

- enum { DSY\_SDRAM\_OK, DSY\_SDRAM\_ERR }
- enum dsy\_sdram\_state { DSY\_SDRAM\_STATE\_ENABLE, DSY\_SDRAM\_STATE\_DISABLE, DSY\_SDR → AM STATE LAST }
- enum dsy\_sdram\_pin { DSY\_SDRAM\_PIN\_SDNWE, DSY\_SDRAM\_PIN\_LAST }

#### **Functions**

• uint8\_t dsy\_sdram\_init (dsy\_sdram\_handle \*dsy\_hsdram)

#### 7.15.1 Macro Definition Documentation

```
7.15.1.1 DSY_SDRAM_BSS
#define DSY_SDRAM_BSS __attribute__((section(".sdram_bss")))
Variables placed here will not be initialized.
Usage
E.g. int DSY_SDRAM_BSS uninitialized_var;

7.15.1.2 DSY_SDRAM_DATA
#define DSY_SDRAM_DATA __attribute__((section(".sdram_data")))
Usage:
E.g. int DSY_SDRAM_DATA initialized_var = 1;

7.15.1.3 RAM_AS4C16M16SA_H
#define RAM_AS4C16M16SA_H
```

SDRAM for 32MB AS4C16M16SA (and 64MB equivalent). Thanks to whoever this awesome person is: http-://main.lv/writeup/stm32f4\_sdram\_configuration.md The Init function is basically a copy and paste. He has references to timing, etc. RAM is configured at 100MHz (fastest possible on the MCU). To use these the .sdram\_data/\_bss sections must be configured correctly in the LINKER SCRIPT. using BSS is advised for most things, since the DATA section must also fit in flash in order to be initialized. Data section init not properly set up, as SDRAM is not initialized until after startup code.&

## 7.15.2 Enumeration Type Documentation

## 7.15.2.1 anonymous enum

anonymous enum

#### Enumerator

DSY_SDRAM_OK	&
DSY_SDRAM_ERR	&

## 7.15.2.2 dsy\_sdram\_pin

enum dsy\_sdram\_pin

## This is PH5 on Daisy

## Enumerator

DSY_SDRAM_PIN_SDNWE	&
DSY_SDRAM_PIN_LAST	&

## 7.15.2.3 dsy\_sdram\_state

enum dsy\_sdram\_state

Determines whether chip is initialized, and activated.

#### Enumerator

DSY_SDRAM_STATE_ENABLE	&
DSY_SDRAM_STATE_DISABLE	&
DSY_SDRAM_STATE_LAST	&

#### 7.15.3 Function Documentation

#### 7.15.3.1 dsy\_sdram\_init()

Initializes the SDRAM peripheral

## 7.16 src/dev\_sr\_4021.h File Reference

Device driver for the CD4021. Bit-banged serial shift input.

```
#include "per_gpio.h"
```

## Classes

• struct dsy\_sr\_4021\_handle

#### **Macros**

- #define DEV\_SR\_4021\_H
- #define SR 4021 MAX PARALLEL 2
- #define SR\_4021\_MAX\_DAISYCHAIN 1

#### **Enumerations**

```
    enum {
        DSY_SR_4021_PIN_CS, DSY_SR_4021_PIN_CLK, DSY_SR_4021_PIN_DATA, DSY_SR_4021_PIN_D →
        ATA2,
        DSY_SR_4021_PIN_LAST }
```

## **Functions**

- void dsy\_sr\_4021\_init (dsy\_sr\_4021\_handle \*sr)
- void dsy\_sr\_4021\_update (dsy\_sr\_4021\_handle \*sr)
- uint8\_t dsy\_sr\_4021\_state (dsy\_sr\_4021\_handle \*sr, uint8\_t idx)

#### 7.16.1 Detailed Description

Device driver for the CD4021. Bit-banged serial shift input.

#### 7.16.2 Macro Definition Documentation

#### 7.16.2.1 DEV\_SR\_4021\_H

```
#define DEV_SR_4021_H
```

&

#### 7.16.2.2 SR\_4021\_MAX\_DAISYCHAIN

```
#define SR_4021_MAX_DAISYCHAIN 1
```

fixed maximum for daisychained use

#### 7.16.2.3 SR\_4021\_MAX\_PARALLEL

```
#define SR_4021_MAX_PARALLEL 2
```

Fixed maximums for parallel/daisychained use These could be expanded, but haven't been tested beyond this

## 7.16.3 Enumeration Type Documentation

#### 7.16.3.1 anonymous enum

```
anonymous enum
```

Pins that need to be configured to use. DATA2 only needs to be set if num\_parallel is > 1

#### Enumerator

DSY_SR_4021_PIN_CS	CS Pin
DSY_SR_4021_PIN_CLK	CLK Pin
DSY_SR_4021_PIN_DATA	DATA pin
DSY_SR_4021_PIN_DATA2	DATA2 Pin, optional
DSY_SR_4021_PIN_LAST	Enum Last

#### 7.16.4 Function Documentation

#### 7.16.4.1 dsy\_sr\_4021\_init()

Initialize CD4021 with settings from sr\_4021\_handle

#### **Parameters**

```
sr handle to initialize
```

#### 7.16.4.2 dsy\_sr\_4021\_state()

Returns the state of a pin at a given index.

#### **Parameters**

*sr	Handle containing desired pin
idx	Pin index

#### 7.16.4.3 dsy\_sr\_4021\_update()

Fills internal states with CD4021 data states.

#### **Parameters**

\*sr Handle to update

## 7.17 src/dev\_sr\_595.h File Reference

```
#include "daisy_core.h"
#include "per_gpio.h"
```

#### **Classes**

• class ShiftRegister595

Device Driver for 8-bit shift register. CD74HC595 - 8-bit serial to parallel output shift.

#### **Variables**

• const size\_t kMaxSr595DaisyChain = 16

## 7.17.1 Variable Documentation

#### 7.17.1.1 kMaxSr595DaisyChain

```
const size_t kMaxSr595DaisyChain = 16
```

Maximum Number of chained devices Connect device's QH' pin to the next chips serial input

## 7.18 src/fatfs.h File Reference

#### fatfs support.

```
#include "ff.h"
#include "ff_gen_drv.h"
#include "util_sd_diskio.h"
```

## **Macros**

• #define \_\_fatfs\_H

## **Functions**

• void dsy\_fatfs\_init (void)

## **Variables**

- uint8\_t retSD
- char SDPath [4]
- FATFS SDFatFS
- FIL SDFile

## 7.18.1 Detailed Description

fatfs support.

## 7.18.2 Macro Definition Documentation

```
7.18.2.1 __fatfs_H
#define ___fatfs_H
7.18.3 Function Documentation
7.18.3.1 dsy_fatfs_init()
void dsy_fatfs_init (
            void )
&
7.18.4 Variable Documentation
7.18.4.1 retSD
uint8_t retSD
&
7.18.4.2 SDFatFS
FATES SDFatES
7.18.4.3 SDFile
FIL SDFile
&
7.18.4.4 SDPath
char SDPath[4]
```

#### 7.19 src/ffconf.h File Reference

```
#include "util_bsp_sd_diskio.h"
#include <stdlib.h>
```

#### **Macros**

- #define FFCONF 68300
- #define \_FS\_READONLY 0
- #define \_FS\_MINIMIZE 0
- #define \_USE\_STRFUNC 2
- #define \_USE\_FIND 0
- #define \_USE\_MKFS 1
- #define \_USE\_FASTSEEK 1
- #define USE EXPAND 0
- #define USE CHMOD 0
- #define \_USE\_LABEL 0
- #define \_USE\_FORWARD 0
- #define CODE PAGE 850
- #define USE LFN 1
- #define \_MAX\_LFN 255
- #define \_LFN\_UNICODE 0
- #define \_STRF\_ENCODE 3
- #define \_FS\_RPATH 0
- #define \_VOLUMES 1
- #define \_STR\_VOLUME\_ID 0
- #define \_VOLUME\_STRS
- #define \_MULTI\_PARTITION 0
- #define \_MIN\_SS 512
- #define \_MAX\_SS 512
- #define \_USE\_TRIM 0
- #define \_FS\_NOFSINFO 0
- #define \_FS\_TINY 0
- #define \_FS\_EXFAT 0
- #define \_FS\_NORTC 0
- #define \_NORTC\_MON 6
- #define \_NORTC\_MDAY 4
- #define \_NORTC\_YEAR 2015
- #define \_FS\_LOCK 2
- #define \_FS\_REENTRANT 0
- #define \_FS\_TIMEOUT 1000
- #define \_SYNC\_t osSemaphoreId
- #define ff\_malloc malloc
- #define ff\_free free

#### 7.19.1 Detailed Description

Further fatfs support.

#### 7.19.2 Macro Definition Documentation

7.19.2.1 \_CODE\_PAGE

#define \_CODE\_PAGE 850

This option specifies the OEM code page to be used on the target system. / Incorrect setting of the code page can cause a file open failure. // 1 - ASCII (No extended character. Non-LFN cfg. only) / 437 - U.S. / 720 - Arabic / 737 - Greek / 771 - KBL / 775 - Baltic / 850 - Latin 1 / 852 - Latin 2 / 855 - Cyrillic / 857 - Turkish / 860 - Portuguese / 861 - Icelandic / 862 - Hebrew / 863 - Canadian French / 864 - Arabic / 865 - Nordic / 866 - Russian / 869 - Greek 2 / 932 - Japanese (DBCS) / 936 - Simplified Chinese (DBCS) / 949 - Korean (DBCS) / 950 - Traditional Chinese (DBCS)

7.19.2.2 \_FFCONF

#define \_FFCONF 68300

FatFs - Generic FAT file system module R0.12c (C)ChaN, 2017

Attention

© Copyright (c) 2019 STMicroelectronics. All rights reserved.

This software component is licensed by ST under Ultimate Liberty license SLA0044, the "License"; You may not use this file except in compliance with the License. You may obtain a copy of the License at: www.st.com/SLA0044← Revision ID

7.19.2.3 \_FS\_EXFAT

#define \_FS\_EXFAT 0

This option switches support of exFAT file system. (0:Disable or 1:Enable) / When enable exFAT, also LFN needs to be enabled. ( $\_$ USE $\_$ LFN >= 1) / Note that enabling exFAT discards C89 compatibility.

7.19.2.4 \_FS\_LOCK

#define \_FS\_LOCK 2

0:Disable or >=1:Enable The option \_FS\_LOCK switches file lock function to control duplicated file open / and illegal operation to open objects. This option must be 0 when \_FS\_READONLY / is 1. // 0: Disable file lock function. To avoid volume corruption, application program / should avoid illegal open, remove and rename to the open objects. / >0: Enable file lock function. The value defines how many files/sub-directories / can be opened simultaneously under file lock control. Note that the file / lock control is independent of re-entrancy.

#### 7.19.2.5 \_FS\_MINIMIZE

```
#define _FS_MINIMIZE 0
```

0 to 3 This option defines minimization level to remove some basic API functions. // 0: All basic functions are enabled. / 1: f\_stat(), f\_getfree(), f\_unlink(), f\_mkdir(), f\_truncate() and f\_rename() / are removed. / 2: f\_opendir(), f\_readdir() and f\_closedir() are removed in addition to 1. / 3: f\_lseek() function is removed in addition to 2.

#### 7.19.2.6 \_FS\_NOFSINFO

```
#define _FS_NOFSINFO 0
```

0,1,2 or 3 If you need to know correct free space on the FAT32 volume, set bit 0 of this / option, and f\_getfree() function at first time after volume mount will force / a full FAT scan. Bit 1 controls the use of last allocated cluster number. // bit0=0: Use free cluster count in the FSINFO if available. / bit0=1: Do not trust free cluster count in the FSINFO. / bit1=0: Use last allocated cluster number in the FSINFO if available. / bit1=1: Do not trust last allocated cluster number in the FSINFO.

#### 7.19.2.7 \_FS\_NORTC

```
#define _FS_NORTC 0
```

&

## 7.19.2.8 \_FS\_READONLY

```
#define _FS_READONLY 0
```

0:Read/Write or 1:Read only This option switches read-only configuration. (0:Read/Write or 1:Read-only) / Read-only configuration removes writing API functions, f\_write(), f\_sync(), / f\_unlink(), f\_mkdir(), f\_chmod(), f\_rename(), f\_truncate(), f\_getfree() / and optional writing functions as well.

## 7.19.2.9 \_FS\_REENTRANT

```
#define _FS_REENTRANT 0
```

0:Disable or 1:Enable

#### 7.19.2.10 \_FS\_RPATH

```
#define _FS_RPATH 0
```

0 to 2 This option configures support of relative path. // 0: Disable relative path and remove related functions. / 1: Enable relative path. f\_chdir() and f\_chdrive() are available. / 2: f\_getcwd() function is available in addition to 1.

7.19.2.11 \_FS\_TIMEOUT

#define \_FS\_TIMEOUT 1000

Timeout period in unit of time ticks

7.19.2.12 \_FS\_TINY

#define \_FS\_TINY 0

0:Normal or 1:Tiny This option switches tiny buffer configuration. (0:Normal or 1:Tiny) / At the tiny configuration, size of file object (FIL) is reduced \_MAX\_SS bytes. / Instead of private sector buffer eliminated from the file object, common sector / buffer in the file system object (FATFS) is used for the file data transfer.

7.19.2.13 \_LFN\_UNICODE

#define \_LFN\_UNICODE 0

0:ANSI/OEM or 1:Unicode This option switches character encoding on the API. (0:ANSI/OEM or 1:UTF-16) / To use Unicode string for the path name, enable LFN and set \_LFN\_UNICODE = 1. / This option also affects behavior of string I/O functions.

7.19.2.14 MAX\_LFN

#define \_MAX\_LFN 255

Maximum LFN length to handle (12 to 255) The \_USE\_LFN switches the support of long file name (LFN). // 0: Disable support of LFN. \_MAX\_LFN has no effect. / 1: Enable LFN with static working buffer on the BSS. Always NOT thread-safe. / 2: Enable LFN with dynamic working buffer on the STACK. / 3: Enable LFN with dynamic working buffer on the HEAP. // To enable the LFN, Unicode handling functions (option/unicode.c) must be added / to the project. The working buffer occupies (\_MAX\_LFN + 1) \* 2 bytes and / additional 608 bytes at exFAT enabled. \_MAX\_LFN can be in range from 12 to 255. / It should be set 255 to support full featured LFN operations. / When use stack for the working buffer, take care on stack overflow. When use heap / memory for the working buffer, memory management functions, ff\_memalloc() and / ff\_memfree(), must be added to the project.

7.19.2.15 \_MAX\_SS

#define \_MAX\_SS 512

512, 1024, 2048 or 4096 These options configure the range of sector size to be supported. (512, 1024, / 2048 or 4096) Always set both 512 for most systems, all type of memory cards and / harddisk. But a larger value may be required for on-board flash memory and some / type of optical media. When \_MAX\_SS is larger than \_MIN\_SS, FatFs is configured / to variable sector size and GET\_SECTOR\_SIZE command must be implemented to the / disk ioctl() function.

7.19.2.16 \_MIN\_SS

#define \_MIN\_SS 512

512, 1024, 2048 or 4096

#### 7.19.2.17 \_MULTI\_PARTITION

```
#define _MULTI_PARTITION 0
```

0:Single partition, 1:Multiple partition This option switches support of multi-partition on a physical drive. / By default (0), each logical drive number is bound to the same physical drive / number and only an FAT volume found on the physical drive will be mounted. / When multi-partition is enabled (1), each logical drive number can be bound to / arbitrary physical drive and partition listed in the VolToPart[]. Also f fdisk() / function will be available.

#### 7.19.2.18 NORTC\_MDAY

```
#define _NORTC_MDAY 4
```

&

#### 7.19.2.19 NORTC\_MON

```
#define _NORTC_MON 6
```

&

#### 7.19.2.20 \_NORTC\_YEAR

```
#define _NORTC_YEAR 2015
```

The option \_FS\_NORTC switches timestamp function. If the system does not have / any RTC function or valid timestamp is not needed, set \_FS\_NORTC = 1 to disable / the timestamp function. All objects modified by FatFs will have a fixed timestamp / defined by \_NORTC\_MON, \_NORTC\_MDAY and \_NORTC\_YEAR in local time. / To enable timestamp function (\_FS\_NORTC = 0), get\_fattime() function need to be / added to the project to get current time form real-time clock. \_NORTC\_MON, / \_NORTC\_MDAY and \_NORTC\_YEAR have no effect. / These options have no effect at read-only configuration (\_FS\_READONLY = 1).

#### 7.19.2.21 \_STR\_VOLUME\_ID

```
#define _STR_VOLUME_ID 0
```

0:Use only 0-9 for drive ID, 1:Use strings for drive ID

#### 7.19.2.22 STRF\_ENCODE

```
#define _STRF_ENCODE 3
```

When  $\_$ LFN $\_$ UNICODE == 1, this option selects the character encoding ON THE FILE to / be read/written via string I/O functions, f $\_$ gets(), f $\_$ putc(), f $\_$ puts and f $\_$ printf(). // 0: ANSI/OEM / 1: UTF-16LE / 2: UTF-16BE / 3: UTF-8 // This option has no effect when  $\_$ LFN $\_$ UNICODE == 0.

```
7.19.2.23 _SYNC_t
```

```
#define _SYNC_t osSemaphoreId
```

The option \_FS\_REENTRANT switches the re-entrancy (thread safe) of the FatFs / module itself. Note that regardless of this option, file access to different / volume is always re-entrant and volume control functions, f\_mount(), f\_mkfs() / and f\_fdisk() function, are always not re-entrant. Only file/directory access / to the same volume is under control of this function. // 0: Disable re-entrancy. \_FS\_TIMEOUT and \_SYNC\_t have no effect. / 1: Enable re-entrancy. Also user provided synchronization handlers, / ff\_req\_grant(), ff\_rel\_grant(), ff\_del\_syncobj() and ff\_cre\_syncobj() / function, must be added to the project. Samples are available in / option/syscall.c. // The \_FS \_ \_TIMEOUT defines timeout period in unit of time tick. / The \_SYNC\_t defines O/S dependent sync object type. e.g. HANDLE, ID, OS\_EVENT\*, / SemaphoreHandle\_t and etc.. A header file for O/S definitions needs to be / included somewhere in the scope of ff.h.

```
7.19.2.24 _USE_CHMOD
```

```
#define _USE_CHMOD 0
```

This option switches attribute manipulation functions,  $f_chmod()$  and  $f_utime()$ . / (0:Disable or 1:Enable) Also  $_F \leftarrow S_READONLY$  needs to be 0 to enable this option.

```
7.19.2.25 USE EXPAND
```

```
#define _USE_EXPAND 0
```

This option switches f\_expand function. (0:Disable or 1:Enable)

```
7.19.2.26 _USE_FASTSEEK
```

```
#define _USE_FASTSEEK 1
```

This option switches fast seek feature. (0:Disable or 1:Enable)

7.19.2.27 \_USE\_FIND

```
#define _USE_FIND 0
```

This option switches filtered directory read functions, f\_findfirst() and / f\_findnext(). (0:Disable, 1:Enable 2:Enable with matching altname[] too)

7.19.2.28 \_USE\_FORWARD

```
#define _USE_FORWARD 0
```

This option switches f\_forward() function. (0:Disable or 1:Enable)

This option switches volume label functions, f\_getlabel() and f\_setlabel(). / (0:Disable or 1:Enable)

```
7.19.2.30 _USE_LFN  
#define _USE_LFN  1
0 to 3
```

```
7.19.2.31 _USE_MKFS
```

```
#define _USE_MKFS 1
```

This option switches f\_mkfs() function. (0:Disable or 1:Enable)

```
7.19.2.32 _USE_STRFUNC
```

```
#define _USE_STRFUNC 2
```

0:Disable or 1-2:Enable This option switches string functions,  $f_gets()$ ,  $f_putc()$ ,  $f_putc()$ , and  $f_printf()$ . // 0: Disable string functions. / 1: Enable without LF-CRLF conversion.

```
7.19.2.33    _USE_TRIM
#define _USE_TRIM 0
```

This option switches support of ATA-TRIM. (0:Disable or 1:Enable) / To enable Trim function, also CTRL\_TRIM command should be implemented to the / disk\_ioctl() function.

```
7.19.2.34 _VOLUME_STRS
```

```
#define _VOLUME_STRS
```

#### Value:

```
"RAM", "NAND", "CF", "SD1", "SD2", "USB1", "USB2", \
"USB3"
```

\_STR\_VOLUME\_ID switches string support of volume ID. / When \_STR\_VOLUME\_ID is set to 1, also pre-defined strings can be used as drive / number in the path name. \_VOLUME\_STRS defines the drive ID strings for each / logical drives. Number of items must be equal to \_VOLUMES. Valid characters for / the drive ID strings are: A-Z and 0-9.

## 7.20 src/hid audio.h File Reference

#### Audio Driver

Configures Audio Device and provides callback for signal processing. Many of the hard-coded values here will change (increase), and/or be replaced by configurable options.

```
#include <stddef.h>
#include <stdint.h>
#include "per_sai.h"
#include "per_i2c.h"
```

#### Classes

· struct dsy audio handle

#### **Macros**

- #define DSY\_AUDIO\_H
- #define DSY\_AUDIO\_BLOCK\_SIZE\_MAX 128
- #define DSY\_AUDIO\_CHANNELS\_MAX 2
- #define DSY\_AUDIO\_SAMPLE\_RATE 48014.0f
- enum { DSY\_AUDIO\_INTERNAL, DSY\_AUDIO\_EXTERNAL, DSY\_AUDIO\_LAST }
- typedef void(\* dsy\_audio\_callback) (float \*, float \*, size\_t)
- typedef void(\* dsy\_audio\_mc\_callback) (float \*\*, float \*\*, size\_t)
- void dsy\_audio\_init (dsy\_audio\_handle \*handle)
- void dsy\_audio\_set\_callback (uint8\_t intext, dsy\_audio\_callback cb)
- void dsy\_audio\_set\_mc\_callback (dsy\_audio\_mc\_callback cb)
- void dsy\_audio\_set\_blocksize (uint8\_t intext, size\_t blocksize)
- void dsy\_audio\_start (uint8\_t intext)
- void dsy\_audio\_stop (uint8\_t intext)
- void dsy\_audio\_enter\_bypass (uint8\_t intext)
- void dsy audio exit bypass (uint8 t intext)
- void dsy\_audio\_passthru (float \*in, float \*out, size\_t size)
- void dsy\_audio\_silence (float \*in, float \*out, size\_t size)

#### 7.20.1 Detailed Description

**Audio Driver** 

Configures Audio Device and provides callback for signal processing. Many of the hard-coded values here will change (increase), and/or be replaced by configurable options.

#### 7.20.2 Macro Definition Documentation

## 7.20.2.1 DSY\_AUDIO\_BLOCK\_SIZE\_MAX

```
#define DSY_AUDIO_BLOCK_SIZE_MAX 128
```

Defines for generic maximums While 'Audio Channels Max' is set to 2, this is per-SAI 4x4 Audio I/O is possible using the dsy\_audio\_mc\_callback Hard-coded samplerate is calculated from original clock tree. The new clock tree has less than 0.01% error for all supported sampleratesMax block size

#### 7.20.2.2 DSY\_AUDIO\_CHANNELS\_MAX

```
#define DSY_AUDIO_CHANNELS_MAX 2
```

Max number of audio channels

#### 7.20.2.3 DSY\_AUDIO\_H

#define DSY\_AUDIO\_H

&

#### 7.20.2.4 DSY\_AUDIO\_SAMPLE\_RATE

```
#define DSY_AUDIO_SAMPLE_RATE 48014.0f
```

Default sample rate

#### 7.20.3 Typedef Documentation

#### 7.20.3.1 dsy\_audio\_callback

```
typedef void(* dsy_audio_callback) (float *, float *, size_t)
```

These are user-defineable callbacks that are called when audio data is ready to be received/transmitted. Function to define for using a single Stereo device for I/O audio is packed as: { LEFT | RIGHT | LEFT | RIGHT }

#### 7.20.3.2 dsy\_audio\_mc\_callback

```
typedef void(* dsy_audio_mc_callback) (float **, float **, size_t)

Defaults to 4 channels, and is fixed for now.
(still works for stereo, but will still fill buffers)
audio is packed as:
{ LEFT | LEFT + 1 | ... | LEFT + SIZE | RIGHT | RIGHT + 1 | ... | RIGHT + SIZE }
```

## 7.20.4 Enumeration Type Documentation

#### 7.20.4.1 anonymous enum

```
anonymous enum
```

Internally, there are two separate 'audio blocks' that can be configured together or separately

#### Enumerator

DSY_AUDIO_INTERNAL	&
DSY_AUDIO_EXTERNAL	&
DSY_AUDIO_LAST	&

#### 7.20.5 Function Documentation

#### 7.20.5.1 dsy\_audio\_enter\_bypass()

If the device supports hardware bypass, enter that mode.

#### 7.20.5.2 dsy\_audio\_exit\_bypass()

If the device supports hardware bypass, exit that mode.

#### 7.20.5.3 dsy\_audio\_init()

Initializes the Audio Engine using configurations set to the sai\_handle i2c\_handles can be set to NULL if not needed.

#### 7.20.5.4 dsy\_audio\_passthru()

```
void dsy_audio_passthru (
          float * in,
           float * out,
           size_t size )
```

A few useful stereo-interleaved callbacks Passes the input to the output

#### 7.20.5.5 dsy\_audio\_set\_blocksize()

Sets the number of samples (per-channel) to be handled in a single audio frame.

#### 7.20.5.6 dsy\_audio\_set\_callback()

Sets the user defined, interleaving callback to be called when audio data is ready. intext is a specifier for DSY\_AUDIO\_INT/EXT (which audio peripheral to use). When using this, each 'audio block' can have completely independent callbacks.

#### 7.20.5.7 dsy\_audio\_set\_mc\_callback()

Sets the user defined, non-interleaving callback to be called when audio data is ready. This will always use both DSY\_AUDIO\_INT and DSY\_AUDIO\_EXT blocks together. To ensure clean audio you'll want to make sure the two SAIs are set to the same samplerate

#### 7.20.5.8 dsy\_audio\_silence()

sets outputs to 0 without stopping the Audio Engine

#### 7.20.5.9 dsy\_audio\_start()

Starts Audio Engine, callbacks will begin getting called.

When using with dsy\_audio\_mc\_callback (for 4 channels), this function should be called for both audio blocks

#### 7.20.5.10 dsy\_audio\_stop()

Stops transmitting/receiving audio on the specified audio block.

## 7.21 src/hid\_ctrl.h File Reference

```
#include <stdint.h>
```

#### Classes

· class daisy::AnalogControl

Hardware Interface for control inputs Primarily designed for ADC input controls such as potentiometers, and control voltage.

#### **Macros**

• #define DSY\_KNOB\_H

## 7.21.1 Macro Definition Documentation

```
7.21.1.1 DSY_KNOB_H
#define DSY_KNOB_H
```

## 7.22 src/hid\_encoder.h File Reference

```
#include "daisy_core.h"
#include "per_gpio.h"
#include "hid_switch.h"
```

#### **Classes**

· class daisy::Encoder

Generic Class for handling Quadrature Encoders Inspired/influenced by Mutable Instruments (pichenettes) Encoder classes.

## 7.23 src/hid\_gatein.h File Reference

```
#include "per_gpio.h"
```

#### Classes

• class daisy::GateIn

Generic Class for handling gate inputs through GPIO.

## 7.24 src/hid\_led.h File Reference

```
#include "daisy_core.h"
#include "per_gpio.h"
```

#### **Classes**

· class daisy::Led

LED Class providing simple Software PWM ability, etc Eventually this will work with hardware PWM, and external LED Driver devices as well.

## 7.25 src/hid\_midi.h File Reference

```
#include <stdint.h>
#include <stdlib.h>
#include "per_uart.h"
#include "util_ringbuffer.h"
```

#### Classes

- struct daisy::NoteOnEvent
- · struct daisy::ControlChangeEvent
- struct daisy::MidiEvent
- · class daisy::MidiHandler

Simple MIDI Handler

Parses bytes from an input into valid MidiEvents.

The MidiEvents fill a FIFO queue that the user can pop messages from.

#### **Enumerations**

enum daisy::MidiMessageType {
 daisy::NoteOff, daisy::NoteOn, daisy::PolyphonicKeyPressure, daisy::ControlChange,
 daisy::ProgramChange, daisy::ChannelPressure, daisy::PitchBend, daisy::MessageLast }

## 7.25.1 Enumeration Type Documentation

## 7.25.1.1 MidiMessageType

```
enum daisy::MidiMessageType
```

Parsed from the Status Byte, these are the common Midi Messages that can be handled. At this time only 3-byte messages are correctly parsed into MidiEvents.

## Enumerator

NoteOff	&
NoteOn	&
PolyphonicKeyPressure	&
ControlChange	&
ProgramChange	&
ChannelPressure	&
PitchBend	&
MessageLast	&

## 7.26 src/hid\_oled\_display.h File Reference

```
#include <stdlib.h>
#include <stdint.h>
#include "util_oled_fonts.h"
#include "daisy_core.h"
```

#### **Classes**

· class daisy::OledDisplay

#### **Macros**

```
• #define DSY_OLED_DISPLAY_H
```

- #define SSD1309\_HEIGHT 64
- #define SSD1309\_WIDTH 128

#### 7.26.1 Macro Definition Documentation

```
7.26.1.1 DSY_OLED_DISPLAY_H
```

```
#define DSY_OLED_DISPLAY_H
```

Macro

#### 7.26.1.2 SSD1309\_HEIGHT

```
#define SSD1309_HEIGHT 64
```

SSD1309 height in pixels

#### 7.26.1.3 SSD1309\_WIDTH

```
#define SSD1309_WIDTH 128
```

SSD1309 width in pixels

## 7.27 src/hid\_parameter.h File Reference

```
#include <stdint.h>
#include "hid_ctrl.h"
```

## Classes

· class daisy::Parameter

## 7.28 src/hid\_rgb\_led.h File Reference

```
#include "hid_led.h"
#include "util_color.h"
```

## **Classes**

· class daisy::RgbLed

## 7.29 src/hid\_switch.h File Reference

```
#include "daisy_core.h"
#include "per_gpio.h"
```

## **Classes**

· class daisy::Switch

## 7.30 src/hid\_usb.h File Reference

```
#include <stdint.h>
#include <stdlib.h>
```

#### **Classes**

• class daisy::UsbHandle

Interface for initializing and using the USB Peripherals on the daisy.

## 7.31 src/hid\_wavplayer.h File Reference

```
#include "daisy_core.h"
#include "util_wav_format.h"
```

#### Classes

- struct daisy::WavFileInfo
- · class daisy::WavPlayer

#### **Macros**

- #define DSY\_WAVPLAYER\_H
- #define WAV\_FILENAME\_MAX 256

#### 7.31.1 Macro Definition Documentation

```
7.31.1.1 DSY_WAVPLAYER_H
```

```
#define DSY_WAVPLAYER_H
```

Macro

## 7.31.1.2 WAV\_FILENAME\_MAX

```
#define WAV_FILENAME_MAX 256
```

Maximum LFN (set to same in FatFs (ffconf.h)

## 7.32 src/per\_adc.h File Reference

```
#include <stdint.h>
#include <stdlib.h>
#include "daisy_core.h"
#include "per_gpio.h"
```

## Classes

- struct daisy::AdcChannelConfig
- class daisy::AdcHandle

#### Macros

- #define DSY\_ADC\_H
- #define DSY\_ADC\_MAX\_CHANNELS 14

#### 7.32.1 Macro Definition Documentation

7.32.1.1 DSY\_ADC\_H

#define DSY\_ADC\_H

Macro

7.32.1.2 DSY\_ADC\_MAX\_CHANNELS

#define DSY\_ADC\_MAX\_CHANNELS 14

Maximum number of ADC channels

## 7.33 src/per\_dac.h File Reference

```
#include "daisy_core.h"
```

#### Classes

• struct dsy\_dac\_handle

#### **Enumerations**

- enum dsy\_dac\_mode { DSY\_DAC\_MODE\_POLLING, DSY\_DAC\_MODE\_LAST }
- enum dsy\_dac\_bitdepth { DSY\_DAC\_BITS\_8, DSY\_DAC\_BITS\_12, DSY\_DAC\_BITS\_LAST }

#### **Functions**

- void dsy\_dac\_init (dsy\_dac\_handle \*dsy\_hdac, dsy\_dac\_channel channel)
- void dsy\_dac\_start (dsy\_dac\_channel channel)
- void dsy\_dac\_write (dsy\_dac\_channel channel, uint16\_t val)

## 7.33.1 Enumeration Type Documentation

7.33.1.1 dsy\_dac\_bitdepth

enum dsy\_dac\_bitdepth

Sets the bit depth of the DAC output This can be set independently for each channel.

#### Enumerator

DSY_DAC_BITS_8	&
DSY_DAC_BITS_12	&
DSY_DAC_BITS_LAST	&

#### 7.33.1.2 dsy\_dac\_channel

```
enum dsy_dac_channel
```

Sets which channel(s) are initialized with the settings chosen.

#### Enumerator

DSY DAC CHN1	&
DSY_DAC_CHN2	&
DSY_DAC_CHN_LAST   8	
DSY_DAC_CHN_BOTH	&

## 7.33.1.3 dsy\_dac\_mode

```
enum dsy_dac_mode
```

Driver for the built in DAC on the STM32 The STM32 has 2 Channels of independently configurable DACs, with up to 12-bit resolution. Currently only Polling is supported.

#### Enumerator

DSY_DAC_MODE_POLLING	Polling mode
DSY_DAC_MODE_LAST	3

## 7.33.2 Function Documentation

## 7.33.2.1 dsy\_dac\_init()

Initializes the specified channel(s) of the DAC

#### **Parameters**

*dsy_hdac	Dac to initialize
channel	Channels to init

#### 7.33.2.2 dsy\_dac\_start()

Turns on the DAC and turns on any internal timer if necessary.

#### **Parameters**

channel	Channel to start
---------	------------------

#### 7.33.2.3 dsy\_dac\_write()

Sets the specified channel of the dac to the value (within bitdepth) resolution. When set to 8-bit, val should be 0-255 When set to 12-bit, val should be 0-4095

#### **Parameters**

channel	Channel to write to
val	Value to write

## 7.34 src/per\_gpio.h File Reference

```
#include "daisy_core.h"
```

#### Classes

• struct dsy\_gpio

#### **Enumerations**

- enum dsy\_gpio\_mode {
   DSY\_GPIO\_MODE\_INPUT, DSY\_GPIO\_MODE\_OUTPUT\_PP, DSY\_GPIO\_MODE\_OUTPUT\_OD, DSY
   \_GPIO\_MODE\_ANALOG,
   DSY\_GPIO\_MODE\_LAST }
- enum dsy\_gpio\_pull { DSY\_GPIO\_NOPULL, DSY\_GPIO\_PULLUP, DSY\_GPIO\_PULLDOWN }

### **Functions**

- void dsy\_gpio\_init (dsy\_gpio \*p)
- void dsy\_gpio\_deinit (dsy\_gpio \*p)
- uint8\_t dsy\_gpio\_read (dsy\_gpio \*p)
- void dsy\_gpio\_write (dsy\_gpio \*p, uint8\_t state)
- void dsy\_gpio\_toggle (dsy\_gpio \*p)

### 7.34.1 Detailed Description

General Purpose IO driver

### 7.34.2 Enumeration Type Documentation

7.34.2.1 dsy\_gpio\_mode

enum dsy\_gpio\_mode

Sets the mode of the GPIO

#### Enumerator

DSY_GPIO_MODE_INPUT	&
DSY_GPIO_MODE_OUTPUT_PP	Push-Pull
DSY_GPIO_MODE_OUTPUT_OD	Open-Drain
DSY_GPIO_MODE_ANALOG	&
DSY_GPIO_MODE_LAST	&

7.34.2.2 dsy\_gpio\_pull

enum dsy\_gpio\_pull

Configures whether an internal Pull up or Pull down resistor is used

### Enumerator

DSY_GPIO_NOPULL	&
DSY_GPIO_PULLUP	&
DSY_GPIO_PULLDOWN	&

### 7.34.3 Function Documentation

# 7.34.3.1 dsy\_gpio\_deinit()

Deinitializes the gpio pin

#### **Parameters**

```
*p Pin pointer
```

# 7.34.3.2 dsy\_gpio\_init()

Initializes the gpio with the settings configured.

#### **Parameters**

\*p Pin pointer

### 7.34.3.3 dsy\_gpio\_read()

Reads the state of the gpio pin

### **Parameters**

\*p Pin pointer

#### Returns

1 if the pin is HIGH, and 0 if the pin is LOW

### 7.34.3.4 dsy\_gpio\_toggle()

```
void dsy_gpio_toggle ( {\tt dsy\_gpio} \, * \, p \, )
```

Toggles the state of the pin so that it is not at the same state as it was previously.

#### **Parameters**

```
*p Pin pointer
```

### 7.34.3.5 dsy\_gpio\_write()

Writes the state to the gpio pin Pin will be set to 3v3 when state is 1, and 0V when state is 0

#### **Parameters**

*p	Pin pointer
state	State to write

# 7.35 src/per\_i2c.h File Reference

```
#include "daisy_core.h"
```

#### **Classes**

• struct dsy\_i2c\_handle

#### **Macros**

• #define DSY\_I2C\_H

### **Enumerations**

- enum dsy\_i2c\_periph { DSY\_I2C\_PERIPH\_1, DSY\_I2C\_PERIPH\_2, DSY\_I2C\_PERIPH\_3, DSY\_I2C\_PE
   RIPH\_4 }
- enum dsy\_i2c\_pin { DSY\_I2C\_PIN\_SCL, DSY\_I2C\_PIN\_SDA, DSY\_I2C\_PIN\_LAST }
- enum dsy\_i2c\_speed { DSY\_I2C\_SPEED\_100KHZ, DSY\_I2C\_SPEED\_400KHZ, DSY\_I2C\_SPEED\_1MHZ, DSY\_I2C\_SPEED\_LAST }

### **Functions**

• void dsy\_i2c\_init (dsy\_i2c\_handle \*dsy\_hi2c)

### 7.35.1 Macro Definition Documentation

7.35.1.1 DSY\_I2C\_H

#define DSY\_I2C\_H

Macro

# 7.35.2 Enumeration Type Documentation

7.35.2.1 dsy\_i2c\_periph

enum dsy\_i2c\_periph

Driver for controlling I2C devices Specifices the internal peripheral to use (these are mapped to different pins on the hardware).

### **Enumerator**

DSY_I2C_PERIPH↔	&
_1	
DSY_I2C_PERIPH↔	&
_2	
DSY_I2C_PERIPH ↔	&
_3	
DSY_I2C_PERIPH ↔	&
_4	

### 7.35.2.2 dsy\_i2c\_pin

```
enum dsy_i2c_pin
```

List of pins associated with the peripheral. These must be set in the handle's pin\_config.

#### Enumerator

DSY_I2C_PIN_SCL	&
DSY_I2C_PIN_SDA	&
DSY_I2C_PIN_LAST	&

### 7.35.2.3 dsy\_i2c\_speed

```
enum dsy_i2c_speed
```

Rate at which the clock/data will be sent/received. The device being used will have maximum speeds. 1MHZ Mode is currently 886kHz\*\*

#### Enumerator

DSY_I2C_SPEED_100KHZ	&
DSY_I2C_SPEED_400KHZ	&
DSY_I2C_SPEED_1MHZ	&
DSY_I2C_SPEED_LAST	&

#### 7.35.3 Function Documentation

### 7.35.3.1 dsy\_i2c\_init()

Initializes an I2C peripheral with the data given from the handle.

## **Parameters**

*dsy hi2c	Required to initialize.

# 7.36 src/per\_qspi.h File Reference

```
#include <stdint.h>
#include "daisy_core.h"
```

#### Classes

· struct dsy\_qspi\_handle

#### **Macros**

- #define DSY QSPI
- #define DSY MEMORY OK ((uint32 t)0x00)
- #define DSY MEMORY ERROR ((uint32 t)0x01)
- #define DSY QSPI TEXT
- #define DSY\_QSPI\_DATA
- #define DSY\_QSPI\_BSS

#### **Enumerations**

- enum dsy\_qspi\_pin {
   DSY\_QSPI\_PIN\_IO0, DSY\_QSPI\_PIN\_IO1, DSY\_QSPI\_PIN\_IO2, DSY\_QSPI\_PIN\_IO3,
   DSY\_QSPI\_PIN\_CLK, DSY\_QSPI\_PIN\_NCS, DSY\_QSPI\_PIN\_LAST }
- enum dsy\_qspi\_mode { DSY\_QSPI\_MODE\_DSY\_MEMORY\_MAPPED, DSY\_QSPI\_MODE\_INDIRECT\_  $\hookleftarrow$  POLLING, DSY\_QSPI\_MODE\_LAST }
- enum dsy\_qspi\_device { DSY\_QSPI\_DEVICE\_IS25LP080D, DSY\_QSPI\_DEVICE\_IS25LP064A, DSY\_Q
   SPI\_DEVICE\_LAST }

#### **Functions**

- int dsy\_qspi\_init (dsy\_qspi\_handle \*hqspi)
- int dsy\_qspi\_deinit ()
- int dsy\_qspi\_writepage (uint32\_t adr, uint32\_t sz, uint8\_t \*buf)
- int dsy\_qspi\_write (uint32\_t address, uint32\_t size, uint8\_t \*buffer)
- int dsy\_qspi\_erase (uint32\_t start\_adr, uint32\_t end\_adr)
- int dsy\_qspi\_erasesector (uint32\_t addr)

### 7.36.1 Macro Definition Documentation

### 7.36.1.1 DSY\_MEMORY\_ERROR

```
\#define DSY_MEMORY_ERROR ((uint32_t)0x01)
```

&

```
7.36.1.2 DSY_MEMORY_OK

#define DSY_MEMORY_OK ((uint32_t)0x00)
&

7.36.1.3 DSY_QSPI

#define DSY_QSPI

Macro

7.36.1.4 DSY_QSPI_BSS

#define DSY_QSPI_BSS

Value:
__attribute__((section()
__r.gspiflash_bss")))
```

used for reading memory in memory\_mapped mode.

```
7.36.1.5 DSY_QSPI_DATA
```

```
#define DSY_QSPI_DATA
```

#### Value:

```
__attribute__((section(\
".qspiflash_data")))
```

used for reading memory in memory mapped mode.

```
7.36.1.6 DSY_QSPI_TEXT
```

```
#define DSY_QSPI_TEXT
```

### Value:

```
__attribute__((section(\
    ".qspiflash_text")))
```

used for reading memory in memory\_mapped mode.

## 7.36.2 Enumeration Type Documentation

```
7.36.2.1 dsy_qspi_device
```

```
enum dsy_qspi_device
```

Flash Devices supported. (Both of these are more-or-less the same, just different sizes).

#### Enumerator

DSY_QSPI_DEVICE_IS25LP080D	&
DSY_QSPI_DEVICE_IS25LP064A	&
DSY_QSPI_DEVICE_LAST	&

7.36.2.2 dsy\_qspi\_mode

 $\verb"enum dsy_qspi_mode"$ 

Modes of operation. Memory Mapped mode: QSPI configured so that the QSPI can be read from starting address 0x90000000. Writing is not possible in this mode.

Indirect Polling mode: Device driver enabled. Read/Write possible via dsy\_qspi\_\* functions

#### Enumerator

DSY_QSPI_MODE_DSY_MEMORY_MAPPED	&
DSY_QSPI_MODE_INDIRECT_POLLING	&
DSY_QSPI_MODE_LAST	&

7.36.2.3 dsy\_qspi\_pin

enum dsy\_qspi\_pin

Driver for QSPI peripheral to interface with external flash memory. Currently supported QSPI Devices: IS25LP080DList of Pins used in QSPI (passed in during Init)

### Enumerator

DSY_QSPI_PIN_IO0	&
DSY_QSPI_PIN_IO1	&
DSY_QSPI_PIN_IO2	&
DSY_QSPI_PIN_IO3	&
DSY_QSPI_PIN_CLK	&
DSY_QSPI_PIN_NCS	&
DSY_QSPI_PIN_LAST	&

### 7.36.3 Function Documentation

### 7.36.3.1 dsy\_qspi\_deinit()

```
int dsy_qspi_deinit ( )
```

Deinitializes the peripheral This should be called before reinitializing QSPI in a different mode.

#### Returns

```
DSY_MEMORY_OK or DSY_MEMORY_ERROR
```

### 7.36.3.2 dsy\_qspi\_erase()

Erases the area specified on the chip. Erasures will happen by 4K, 32K or 64K increments. Smallest erase possible is 4kB at a time. (on IS25LP\*)

### **Parameters**

start_adr	Address to begin erasing from
end_adr	Address to stop erasing at

#### Returns

```
DSY_MEMORY_OK or DSY_MEMORY_ERROR
```

### 7.36.3.3 dsy\_qspi\_erasesector()

Erases a single sector of the chip. TODO: Document the size of this function.

#### **Parameters**

addr Addres	ss of sector to erase
-------------	-----------------------

### Returns

DSY\_MEMORY\_OK or DSY\_MEMORY\_ERROR

### 7.36.3.4 dsy\_qspi\_init()

Initializes QSPI peripheral, and Resets, and prepares memory for access.

### **Parameters**

hqspi should be populated with the mode, device and pin\_config before calling this function.

#### Returns

```
DSY_MEMORY_OK or DSY_MEMORY_ERROR
```

### 7.36.3.5 dsy\_qspi\_write()

Writes data in buffer to to the QSPI. Starting at address to address+size

#### **Parameters**

address	Address to write to	
size	Buffer size	
buffer	Buffer to write	

### Returns

```
DSY_MEMORY_OK or DSY_MEMORY_ERROR
```

### 7.36.3.6 dsy\_qspi\_writepage()

Writes a single page to to the specified address on the QSPI chip. For IS25LP\* page size is 256 bytes.

#### **Parameters**

adr	Address to write to
SZ	Buff size
buf	Buffer to write

#### Returns

DSY\_MEMORY\_OK or DSY\_MEMORY\_ERROR

# 7.37 src/per\_sai.h File Reference

```
#include "daisy_core.h"
```

#### Classes

• struct dsy\_sai\_handle

#### **Enumerations**

- enum dsy\_audio\_sai {
   DSY\_AUDIO\_INIT\_SAI1, DSY\_AUDIO\_INIT\_SAI2, DSY\_AUDIO\_INIT\_BOTH, DSY\_AUDIO\_INIT\_NONE,
   DSY\_AUDIO\_INIT\_LAST }
- enum dsy\_audio\_bitdepth { DSY\_AUDIO\_BITDEPTH\_16, DSY\_AUDIO\_BITDEPTH\_24, DSY\_AUDIO\_BI

  TDEPTH\_LAST }
- enum dsy\_audio\_sync { DSY\_AUDIO\_SYNC\_MASTER, DSY\_AUDIO\_SYNC\_SLAVE, DSY\_AUDIO\_SY NC\_LAST }
- enum dsy\_audio\_dir { DSY\_AUDIO\_RX, DSY\_AUDIO\_TX }
- enum dsy\_sai\_pin {

DSY\_SAI\_PIN\_MCLK, DSY\_SAI\_PIN\_FS, DSY\_SAI\_PIN\_SCK, DSY\_SAI\_PIN\_SIN, DSY\_SAI\_PIN\_SOUT, DSY\_SAI\_PIN\_LAST }

• enum dsy\_audio\_device {

DSY\_AUDIO\_NONE, DSY\_AUDIO\_DEVICE\_PCM3060, DSY\_AUDIO\_DEVICE\_WM8731, DSY\_AUDIO\_ 
DEVICE\_AK4556,

DSY\_AUDIO\_DEVICE\_LAST }

enum { DSY\_SAI\_1, DSY\_SAI\_2, DSY\_SAI\_LAST }

#### **Functions**

- void dsy\_sai\_init (dsy\_audio\_sai init, dsy\_audio\_samplerate sr[2], dsy\_audio\_bitdepth bitdepth[2], dsy\_\iff audio sync sync config[2], dsy gpio pin \*sai1 pin list, dsy gpio pin \*sai2 pin list)
- void dsy\_sai\_init\_from\_handle (dsy\_sai\_handle \*hsai)

### 7.37.1 Enumeration Type Documentation

#### 7.37.1.1 anonymous enum

anonymous enum

Index for the several arrays in the sai handle struct below.

### Enumerator

DSY_SAI_1	&
DSY_SAI_2	&
DSY_SAI_LAST	&

### 7.37.1.2 dsy\_audio\_bitdepth

 $\verb"enum dsy_audio_bitdepth"$ 

Specifies the bitdepth of the hardware connected to the SAI peripheral

#### Enumerator

DSY_AUDIO_BITDEPTH_16	&
DSY_AUDIO_BITDEPTH_24	&
DSY_AUDIO_BITDEPTH_LAST	&

# 7.37.1.3 dsy\_audio\_device

enum dsy\_audio\_device

List of devices with built in support. Devices not listed here, will need to have initialization done externally.

### Enumerator

DSY_AUDIO_NONE	For unsupported, or custom devices.
DSY_AUDIO_DEVICE_PCM3060	&
DSY_AUDIO_DEVICE_WM8731	&
DSY_AUDIO_DEVICE_AK4556	&
DSY_AUDIO_DEVICE_LAST	&

### 7.37.1.4 dsy\_audio\_dir

enum dsy\_audio\_dir

Each SAI has two datalines, they can independently be configured as inputs or outputs.

### Enumerator

DSY_AUDIO_RX	&
DSY_AUDIO_TX	&

### 7.37.1.5 dsy\_audio\_sai

enum dsy\_audio\_sai

Driver for the SAI peripheral Supports SAI1 and SAI2 with several configuration options selects which SAI (or both/none) to initialize

#### Enumerator

DSY_AUDIO_INIT_SAI1	&
DSY_AUDIO_INIT_SAI2	&
DSY_AUDIO_INIT_BOTH	&
DSY_AUDIO_INIT_NONE	&
DSY_AUDIO_INIT_LAST	&

### 7.37.1.6 dsy\_audio\_samplerate

enum dsy\_audio\_samplerate

Currently Sample Rates are not correctly supported. All audio is currently run at 48kHz

#### Enumerator

DSY_AUDIO_SAMPLERATE_32K	&
DSY_AUDIO_SAMPLERATE_48K	&
DSY_AUDIO_SAMPLERATE_96K	&
DSY_AUDIO_SAMPLERATE_LAST	&

### 7.37.1.7 dsy\_audio\_sync

enum dsy\_audio\_sync

Setting for each SAI that sets whether the processor is generating the MCLK signal or not.

### Enumerator

DSY_AUDIO_SYNC_MASTER	No Crystal
DSY_AUDIO_SYNC_SLAVE	Crystal
DSY_AUDIO_SYNC_LAST	&

### 7.37.1.8 dsy\_sai\_pin

```
enum dsy_sai_pin
```

List of the pins that need to be initialized SIN/SOUT is a bit misleading, and should be turned into A/B since it is possible to configure two inputs or two outputs on a single SAI.

### Enumerator

DSY_SAI_PIN_MCLK	&
DSY_SAI_PIN_FS	&
DSY_SAI_PIN_SCK	&
DSY_SAI_PIN_SIN	&
DSY_SAI_PIN_SOUT	&
DSY_SAI_PIN_LAST	&

#### 7.37.2 Function Documentation

### 7.37.2.1 dsy\_sai\_init()

Intializes the SAI peripheral(s) with the specified settings. Pinlists should be arrays of DSY\_SAI\_PIN\_LAST elements

#### **Parameters**

init	&
sr[]	Sample rate per chan: 0, 1
bitdepth[]	Bitdepth per chan: 0, 1
sync_config[]	& sync config per chan: 0, 1
*sai1_pin_list	&
*sai2_pin_list	&

### 7.37.2.2 dsy\_sai\_init\_from\_handle()

Uses the data within \*hsai to initialize the peripheral(s)

#### **Parameters**



# 7.38 src/per\_sdmmc.h File Reference

```
#include <stdint.h>
```

# Classes

- struct daisy::SdmmcHandlerInit
- class daisy::SdmmcHandler

### **Macros**

- #define DSY SDMMC H
- #define DSY\_SD\_OK 0
- #define DSY\_SD\_ERROR 1

### **Enumerations**

- enum daisy::SdmmcMode { daisy::SDMMC\_MODE\_FATFS }
- enum daisy::SdmmcBitWidth { daisy::SDMMC\_BITS\_1, daisy::SDMMC\_BITS\_4 }
- enum daisy::SdmmcSpeed { daisy::SDMMC\_SPEED\_400KHZ, daisy::SDMMC\_SPEED\_12MHZ }

### 7.38.1 Macro Definition Documentation

```
7.38.1.1 DSY_SD_ERROR
```

#define DSY\_SD\_ERROR 1

### ERROR return

7.38.1.2 DSY\_SD\_OK

#define DSY\_SD\_OK 0

### OK return

7.38.1.3 DSY\_SDMMC\_H

#define DSY\_SDMMC\_H

macro

# 7.38.2 Enumeration Type Documentation

### 7.38.2.1 SdmmcBitWidth

enum daisy::SdmmcBitWidth

Sets whether 4-bit mode or 1-bit mode is used for the SDMMC

#### Enumerator

SDMMC_BITS↔	&
_1	
SDMMC_BITS↔	&
4	

#### 7.38.2.2 SdmmcMode

enum daisy::SdmmcMode

Operating Mode. Currently only FatFS is supported.

Enumerator

SDMMC\_MODE\_FATFS &

### 7.38.2.3 SdmmcSpeed

enum daisy::SdmmcSpeed

Sets the desired clock speed of the SD card bus. Initialization is always done at or below 400kHz, and then the user speed is set.

### Enumerator

SDMMC_SPEED_400KHZ	&
SDMMC_SPEED_12MHZ	&

Generated by Doxygen

# 7.39 src/per\_spi.h File Reference

```
#include "daisy_core.h"
```

### **Classes**

• class daisy::SpiHandle

### **Enumerations**

- enum daisy::SpiPeriph { daisy::SPI\_PERIPH\_1, daisy::SPI\_PERIPH\_3, daisy::SPI\_PERIPH\_6 }
- enum daisy::SpiPin { daisy::SPI\_PIN\_CS, daisy::SPI\_PIN\_SCK, daisy::SPI\_PIN\_MOSI, daisy::SPI\_PIN\_← MISO }

# 7.39.1 Enumeration Type Documentation

### 7.39.1.1 SpiPeriph

enum daisy::SpiPeriph

### SPI peripheral enum

### Enumerator

SPI_PERIPH↔	SPI peripheral 1
_1	
SPI_PERIPH↔	SPI peripheral 3
_3	
SPI_PERIPH↔	SPI peripheral 3
_6	

# 7.39.1.2 SpiPin

enum daisy::SpiPin

### SPI pins

### Enumerator

SPI_PIN_CS	CS pin
SPI_PIN_SCK	SCK pin
SPI_PIN_MOSI	MOSI pin
SPI_PIN_MISO	MISO pin

# 7.40 src/per\_tim.h File Reference

```
#include <stdint.h>
```

### **Functions**

- void dsy\_tim\_init ()
- void dsy\_tim\_start ()
- uint32\_t dsy\_tim\_get\_tick ()
- void dsy\_tim\_delay\_tick (uint32\_t cnt)
- uint32\_t dsy\_tim\_get\_ms ()
- void dsy\_tim\_delay\_ms (uint32\_t cnt)
- uint32\_t dsy\_tim\_get\_us ()
- void dsy\_tim\_delay\_us (uint32\_t cnt)

### 7.40.1 Function Documentation

### 7.40.1.1 dsy\_tim\_delay\_ms()

blocking delay of cnt milliseconds.

#### **Parameters**

```
cnt Delay time in ms
```

### 7.40.1.2 dsy\_tim\_delay\_tick()

blocking delay of cnt timer ticks.

## **Parameters**

cnt Number of ticks

### 7.40.1.3 dsy\_tim\_delay\_us()

blocking delay of cnt microseconds.

### **Parameters**

```
cnt Delay time in us
```

#### 7.40.1.4 dsy\_tim\_get\_ms()

```
uint32_t dsy_tim_get_ms ( )
```

These functions are converted to use milliseconds as their time base.

#### Returns

the number of milliseconds through the timer period.

### 7.40.1.5 dsy\_tim\_get\_tick()

```
uint32_t dsy_tim_get_tick ( )
```

These functions are specific to the actual clock ticks at the timer frequency which is currently fixed at 200MHz

### Returns

a number 0x00000000-0xffffffff of the current tick

### 7.40.1.6 dsy\_tim\_get\_us()

```
uint32_t dsy_tim_get_us ( )
```

These functions are converted to use microseconds as their time base.

### Returns

the number of microseconds through the timer period.

```
7.40.1.7 dsy_tim_init()
void dsy_tim_init ( )
```

General purpose timer for delays and general timing. initializes the TIM2 peripheral with maximum counter autoreload, and no prescalers.

```
7.40.1.8 dsy_tim_start()
void dsy_tim_start ( )
```

Starts the timer ticking.

src/per\_uart.h File Reference

```
#include "daisy_core.h"
```

#### Classes

7.41

• class daisy::UartHandler

#### **Macros**

• #define DSY\_UART\_H

### **Variables**

• const size\_t daisy::kUartMaxBufferSize = 32

### 7.41.1 Macro Definition Documentation

```
7.41.1.1 DSY_UART_H
#define DSY_UART_H
macro
```

### 7.41.2 Variable Documentation

#### 7.41.2.1 kUartMaxBufferSize

```
const size_t daisy::kUartMaxBufferSize = 32
```

Maximum Queue buffer size

# 7.42 src/sys\_dma.h File Reference

### **Functions**

void dsy\_dma\_init (void)

#### 7.42.1 Function Documentation

### 7.42.1.1 dsy\_dma\_init()

```
void dsy_dma_init (
     void )
```

Initializes the Direct Memory Access Peripheral used by many internal elements of libdaisy. Initializes the DMA (specifically for the modules used within the library)

# 7.43 src/sys\_system.h File Reference

```
#include <stdint.h>
```

### **Functions**

- void dsy system init ()
- void dsy\_system\_jumpto (uint32\_t addr)
- void dsy\_system\_jumptoqspi ()
- uint32\_t dsy\_system\_getnow ()
- void dsy\_system\_delay (uint32\_t delay\_ms)

## 7.43.1 Detailed Description

Low level System Configuration

### 7.43.2 Function Documentation

### 7.43.2.1 dsy\_system\_delay()

Blocking Delay that uses the SysTick (1ms callback) to wait.

#### **Parameters**

delay_ms	Time to delay in ms
----------	---------------------

### 7.43.2.2 dsy\_system\_getnow()

```
uint32_t dsy_system_getnow ( )
```

#### Returns

a uint32\_t value of milliseconds since the SysTick started Note! This is a HAL\_GetTick()

#### 7.43.2.3 dsy\_system\_init()

```
void dsy_system_init ( )
```

Initializes Clock tree, MPU, and internal memories voltage regulators. This function *must* be called at the beginning of any program using libdaisy Higher level daisy\_files call this through the DaisySeed object.

### 7.43.2.4 dsy\_system\_jumpto()

```
void dsy_system_jumpto ( \mbox{uint32\_t } \mbox{\it addr} \mbox{\it )}
```

Jump to an address within the internal memory

This may not work correctly, and may not be very useful with the single sector of memory on the stm32h750\*\*

#### **Parameters**

```
addr Address to jump to
```

#### 7.43.2.5 dsy\_system\_jumptoqspi()

```
void dsy_system_jumptoqspi ( )
```

Jumps to the first address of the external flash chip (0x9000000) If there is no code there, the chip will likely fall through to the while() loop TODO: Documentation/Loader for using external flash coming soon.

# 7.44 src/usbd\_cdc\_if.h File Reference

```
: Header for usbd_cdc_if.c file.
#include "usbd_cdc.h"
```

### **Typedefs**

• typedef void(\* CDC\_ReceiveCallback) (uint8\_t \*buf, uint32\_t \*size)

### **Functions**

- void CDC\_Set\_Rx\_Callback\_FS (CDC\_ReceiveCallback cb)
- uint8\_t CDC\_Transmit\_FS (uint8\_t \*Buf, uint16\_t Len)
- uint8\_t CDC\_Transmit\_HS (uint8\_t \*Buf, uint16\_t Len)

### **Variables**

- USBD\_CDC\_ltfTypeDef USBD\_Interface\_fops\_FS
- USBD\_CDC\_ItfTypeDef USBD\_Interface\_fops\_HS

### 7.44.1 Detailed Description

: Header for usbd\_cdc\_if.c file.

### Version

: v1.0\_Cube

Attention

© Copyright (c) 2019 STMicroelectronics. All rights reserved.

This software component is licensed by ST under Ultimate Liberty license SLA0044, the "License"; You may not use this file except in compliance with the License. You may obtain a copy of the License at: www.st.com/SLA0044

# 7.45 src/usbd\_conf.h File Reference

```
: Header for usbd_conf.c file.
```

```
#include <stdio.h>
#include <stdlib.h>
#include <string.h>
#include "stm32h7xx.h"
#include "stm32h7xx_hal.h"
```

#### Macros

- #define USBD\_MAX\_NUM\_INTERFACES 1U
- #define USBD MAX NUM CONFIGURATION 1U
- #define USBD\_MAX\_STR\_DESC\_SIZ 512U
- #define USBD\_SUPPORT\_USER\_STRING 0U
- #define USBD\_DEBUG\_LEVEL 3U
- #define USBD LPM ENABLED 0U
- #define USBD SELF POWERED 1U
- #define DEVICE\_FS 0
- #define DEVICE HS 1
- #define USBD\_malloc malloc
- #define USBD free free
- #define USBD\_memset memset
- #define USBD\_memcpy memcpy
- #define USBD Delay HAL Delay
- #define USBD\_UsrLog(...)
- #define USBD ErrLog(...)
- #define USBD\_DbgLog(...)

### 7.45.1 Detailed Description

: Header for usbd\_conf.c file.

Version

: v1.0\_Cube

Attention

© Copyright (c) 2019 STMicroelectronics. All rights reserved.

This software component is licensed by ST under Ultimate Liberty license SLA0044, the "License"; You may not use this file except in compliance with the License. You may obtain a copy of the License at: www.st.com/SLA0044

# 7.46 src/usbd\_desc.h File Reference

```
: Header for usbd_conf.c file.
#include "usbd_def.h"
```

#### **Macros**

- #define DEVICE\_ID1 (UID\_BASE)
- #define DEVICE\_ID2 (UID\_BASE + 0x4)
- #define DEVICE\_ID3 (UID\_BASE + 0x8)
- #define USB\_SIZ\_STRING\_SERIAL 0x1A

### Variables

- USBD\_DescriptorsTypeDef HS\_Desc
- USBD DescriptorsTypeDef FS Desc

### 7.46.1 Detailed Description

: Header for usbd\_conf.c file.

Version

: v1.0\_Cube

Attention

© Copyright (c) 2019 STMicroelectronics. All rights reserved.

This software component is licensed by ST under Ultimate Liberty license SLA0044, the "License"; You may not use this file except in compliance with the License. You may obtain a copy of the License at: www.st.com/SLA0044

# 7.47 src/util\_bsp\_sd\_diskio.h File Reference

#include <stdint.h>

#### **Classes**

struct DSY\_SD\_CardInfoTypeDef

#### **Macros**

- #define DSY BSP SD DISKIO H
- #define BSP\_SD\_CardInfo DSY\_SD\_CardInfoTypeDef
- #define MSD\_OK ((uint8\_t)0x00)
- #define MSD ERROR ((uint8 t)0x01)
- #define MSD\_ERROR\_SD\_NOT\_PRESENT ((uint8\_t)0x02)
- #define SD TRANSFER OK ((uint8 t)0x00)
- #define SD\_TRANSFER\_BUSY ((uint8\_t)0x01)
- #define SD PRESENT ((uint8 t)0x01)
- #define SD\_NOT\_PRESENT ((uint8\_t)0x00)
- #define SD\_DATATIMEOUT ((uint32\_t)100000000)

#### **Functions**

- uint8\_t BSP\_SD\_Init (void)
- uint8\_t BSP\_SD\_ITConfig (void)
- uint8\_t BSP\_SD\_ReadBlocks (uint32\_t \*pData, uint32\_t ReadAddr, uint32\_t NumOfBlocks, uint32\_t Timeout)
- uint8 t BSP SD WriteBlocks (uint32 t \*pData, uint32 t WriteAddr, uint32 t NumOfBlocks, uint32 t Timeout)
- uint8\_t BSP\_SD\_ReadBlocks\_DMA (uint32\_t \*pData, uint32\_t ReadAddr, uint32\_t NumOfBlocks)
- uint8\_t BSP\_SD\_WriteBlocks\_DMA (uint32\_t \*pData, uint32\_t WriteAddr, uint32\_t NumOfBlocks)
- uint8\_t BSP\_SD\_Erase (uint32\_t StartAddr, uint32\_t EndAddr)
- uint8\_t BSP\_SD\_GetCardState (void)
- void BSP\_SD\_GetCardInfo (DSY\_SD\_CardInfoTypeDef \*CardInfo)
- uint8\_t BSP\_SD\_IsDetected (void)
- · void BSP SD AbortCallback (void)
- · void BSP SD WriteCpltCallback (void)
- · void BSP SD ReadCpltCallback (void)

#### 7.47.1 Macro Definition Documentation

### 7.47.1.1 BSP\_SD\_CardInfo

#define BSP\_SD\_CardInfo DSY\_SD\_CardInfoTypeDef

&

#### 7.47.1.2 DSY\_BSP\_SD\_DISKIO\_H

#define DSY\_BSP\_SD\_DISKIO\_H

&

```
7.47.1.3 MSD_ERROR
#define MSD_ERROR ((uint8_t)0x01)
7.47.1.4 MSD_ERROR_SD_NOT_PRESENT
\#define MSD_ERROR_SD_NOT_PRESENT ((uint8_t)0x02)
7.47.1.5 MSD_OK
#define MSD_OK ((uint8_t)0x00)
7.47.1.6 SD_DATATIMEOUT
#define SD_DATATIMEOUT ((uint32_t)100000000)
7.47.1.7 SD_NOT_PRESENT
#define SD_NOT_PRESENT ((uint8_t)0x00)
&
7.47.1.8 SD_PRESENT
#define SD_PRESENT ((uint8_t)0x01)
&
7.47.1.9 SD_TRANSFER_BUSY
#define SD_TRANSFER_BUSY ((uint8_t)0x01)
&
7.47.1.10 SD_TRANSFER_OK
#define SD_TRANSFER_OK ((uint8_t)0x00)
&
```

### 7.47.2 Function Documentation

### 7.47.2.1 BSP\_SD\_AbortCallback()

These functions can be modified in case the current settings (e.g. DMA stream) need to be changed for specific application needs /n

Abort the callback

### 7.47.2.2 BSP\_SD\_Erase()

Erase a section of memory

#### **Parameters**

StartAddr	Address to start erasing at
EndAddr	Address to stop erasing at

### Returns

card state, ERROR, etc.

### 7.47.2.3 BSP\_SD\_GetCardInfo()

#### **Parameters**

### **Parameters**

CardInfo &

```
7.47.2.4 BSP_SD_GetCardState()
```

Returns

card state, ERROR, etc.

### 7.47.2.5 BSP\_SD\_Init()

Returns

card state, ERROR, etc.

### 7.47.2.6 BSP\_SD\_IsDetected()

Returns

Is card detected

### 7.47.2.7 BSP\_SD\_ITConfig()

Returns

card state, ERROR, etc.

### 7.47.2.8 BSP\_SD\_ReadBlocks()

### **Parameters**

*pData	&
ReadAddr	Address to read from
NumOfBlocks	Number of blocks to be read
Timeout	Timeout len in ms

#### Returns

OK ERROR, etc.

### 7.47.2.9 BSP\_SD\_ReadBlocks\_DMA()

#### No timeout

#### **Parameters**

*pData	&
ReadAddr	Address to read from
NumOfBlocks	Number of blocks to be read

#### Returns

card state, ERROR, etc.

### 7.47.2.10 BSP\_SD\_ReadCpltCallback()

Write complete callback

### 7.47.2.11 BSP\_SD\_WriteBlocks()

### **Parameters**

*pData	&
WriteAddr	Address to write to
NumOfBlocks	Number of blocks to be written
Timeout	Timeout len in ms

#### Returns

card state, ERROR, etc.

### 7.47.2.12 BSP\_SD\_WriteBlocks\_DMA()

### No timeout

### **Parameters**

*pData	&
WriteAddr	Address to write to
NumOfBlocks	Number of blocks to be read

#### Returns

card state, ERROR, etc.

### 7.47.2.13 BSP\_SD\_WriteCpltCallback()

Read complete callback

# 7.48 src/util\_color.h File Reference

#include <stdint.h>

### Classes

· class daisy::Color

### **Macros**

• #define DSY\_COLOR\_H

#### 7.48.1 Macro Definition Documentation

### 7.48.1.1 DSY\_COLOR\_H

```
#define DSY_COLOR_H
```

I'd like for it to be easy and not Color::PresetColor::Foo-There's no way to change a color once its been created (without unintuitively reiniting it).

# 7.49 src/util\_hal\_map.h File Reference

```
#include "stm32h7xx_hal.h"
#include "daisy_core.h"
#include "per_i2c.h"
```

### **Functions**

- GPIO\_TypeDef \* dsy\_hal\_map\_get\_port (dsy\_gpio\_pin \*p)
- uint16\_t dsy\_hal\_map\_get\_pin (dsy\_gpio\_pin \*p)
- I2C\_HandleTypeDef \* dsy\_hal\_map\_get\_i2c (dsy\_i2c\_handle \*p)

### **Variables**

- I2C\_HandleTypeDef hi2c1
- I2C HandleTypeDef hi2c2
- I2C\_HandleTypeDef hi2c3
- I2C\_HandleTypeDef hi2c4

#### 7.49.1 Function Documentation

# 7.49.1.1 dsy\_hal\_map\_get\_i2c()

#### **Parameters**

```
*p dsy_i2c_handle to get
```

### Returns

The I2C\_HandleTypeDef for the given \*p

#### 7.49.1.2 dsy\_hal\_map\_get\_pin()

#### **Parameters**

```
*p Pin pin to get
```

#### Returns

HAL GPIO Pin as used in the HAL from a dsy\_gpio\_pin input.

#### 7.49.1.3 dsy\_hal\_map\_get\_port()

#### **Parameters**

\*p Pin pin to get

#### Returns

HAL GPIO\_TypeDef as used in the HAL from a dsy\_gpio\_pin input.

#### 7.49.2 Variable Documentation

#### 7.49.2.1 hi2c1

```
I2C_HandleTypeDef hi2c1
```

global structs, and helper functions for interfacing with the stm32 HAL library while it remains a dependancy. This file should only be included from source files (c/cpp) Including it from a header within libdaisy would expose the entire HAL to the users. This should be an option for users, but should not be required externs of HAL handles...

# 7.49.2.2 hi2c2

I2C\_HandleTypeDef hi2c2

externs of HAL handles...

#### 7.49.2.3 hi2c3

I2C\_HandleTypeDef hi2c3

externs of HAL handles...

#### 7.49.2.4 hi2c4

I2C\_HandleTypeDef hi2c4

externs of HAL handles...

# 7.50 src/util\_ringbuffer.h File Reference

```
#include <algorithm>
```

### Classes

- class daisy::RingBuffer< T, size >
- class daisy::RingBuffer< T, 0 >

# 7.51 src/util\_unique\_id.h File Reference

```
#include "daisy_core.h"
```

# **Functions**

void dsy\_get\_unique\_id (uint32\_t \*w0, uint32\_t \*w1, uint32\_t \*w2)

### 7.51.1 Function Documentation

### 7.51.1.1 dsy\_get\_unique\_id()

Returns 96-bit Unique ID of the MCU

Author

shensley

Date

May 2020 fills the three pointer arguments with the unique ID of the MCU.

### **Parameters**

*w0	First pointer
*W1	Second pointer
* <i>w2</i>	Third pointer

# 7.52 src/util\_wav\_format.h File Reference

```
#include <stdint.h>
```

### Classes

struct WAV\_FormatTypeDef

## Index

_CODE_PAGE	ffconf.h, 196
ffconf.h, 192	_USE_FASTSEEK
FFCONF	ffconf.h, 196
ffconf.h, 192	USE FIND
FS EXFAT	ffconf.h, 196
ffconf.h, 192	USE FORWARD
FS LOCK	ffconf.h, 196
ffconf.h, 192	USE LABEL
FS MINIMIZE	ffconf.h, 196
	USE LFN
ffconf.h, 192	ffconf.h, 197
_FS_NOFSINFO	USE MKFS
ffconf.h, 193	
_FS_NORTC	ffconf.h, 197
ffconf.h, 193	_USE_STRFUNC
_FS_READONLY	ffconf.h, 197
ffconf.h, 193	_USE_TRIM
_FS_REENTRANT	ffconf.h, 197
ffconf.h, 193	_VOLUMES
_FS_RPATH	ffconf.h, 197
ffconf.h, 193	_VOLUME_STRS
FS TIMEOUT	ffconf.h, 197
ffconf.h, 193	fatfs_H
FS TINY	fatfs.h, 189
ffconf.h, 194	$\sim$ AnalogControl
LFN UNICODE	daisy::AnalogControl, 44
	$\sim$ DaisyPatch
ffconf.h, 194	daisy::DaisyPatch, 53
_MAX_LFN	$\sim$ DaisyPetal
ffconf.h, 194	daisy::DaisyPetal, 59
_MAX_SS	$\sim$ GateIn
ffconf.h, 194	daisy::GateIn, 88
_MIN_SS	~Parameter
ffconf.h, 194	daisy::Parameter, 101
_MULTI_PARTITION	aciej ili alametel, i e
ffconf.h, 194	a_direction
_NORTC_MDAY	dsy_sai_handle, 79
ffconf.h, 195	AUDIO, 11
_NORTC_MON	adc
ffconf.h, 195	daisy::DaisySeed, 72
NORTC YEAR	AnalogControl
ffconf.h, 195	daisy::AnalogControl, 44
_STRF_ENCODE	AsControlChange
ffconf.h, 195	<u> </u>
STR VOLUME ID	daisy::MidiEvent, 91 AsNoteOn
ffconf.h, 195	daisy::MidiEvent, 91
_SYNC_t	audio_handle
ffconf.h, 195	daisy::DaisySeed, 72
_USE_CHMOD	AudioBlockSize
ffconf.h, 196	daisy::DaisyPatch, 53
_USE_EXPAND	daisy::DaisyPetal, 60

daisy::DaisyPod, 66	DSY_SD_CardInfoTypeDef, 81
AudioCallbackRate	BlockingTransmit
daisy::DaisyPatch, 53	daisy::SpiHandle, 114
daisy::DaisyPetal, 60	Blue
daisy::DaisyPod, 66	daisy::Color, 48
AudioFormat	blue
WAV_FormatTypeDef, 124	color, 47
AudioSampleRate	button1
daisy::DaisyPatch, 54	daisy::DaisyPod, 68
daisy::DaisyPetal, 60	button2
daisy::DaisyPod, 66	daisy::DaisyPod, 68
daisy::DaisySeed, 70	buttons
	daisy::DaisyPod, 69
b_direction	ByteRate
dsy_sai_handle, 79	WAV_FormatTypeDef, 125
BLOCK_ERASE_32K_CMD	_ ,,
dev_flash_IS25LP064A.h, 151	CDC_ReceiveCallback
dev_flash_IS25LP080D.h, 166	USBD_CDC_IF_Exported_Types, 16
BSP_SD_AbortCallback	CDC_Set_Rx_Callback_FS
util_bsp_sd_diskio.h, 239	USBD_CDC_IF_Exported_FunctionsPrototype, 19
BSP_SD_CardInfo	CDC_Transmit_FS
util_bsp_sd_diskio.h, 237	USBD_CDC_IF_Exported_FunctionsPrototype, 19
BSP_SD_Erase	CDC_Transmit_HS
util_bsp_sd_diskio.h, 239	USBD_CDC_IF_Exported_FunctionsPrototype, 19
BSP_SD_GetCardInfo	CLEAR_FLAG_STATUS_REG_CMD
util_bsp_sd_diskio.h, 239	dev_flash_IS25LP064A.h, 151
BSP_SD_GetCardState	dev_flash_IS25LP080D.h, 166
util_bsp_sd_diskio.h, 239	CONTROLS, 12
BSP_SD_ITConfig	CV1_ADC_PIN
util_bsp_sd_diskio.h, 240	daisy_field.h, 138
BSP_SD_Init	CV2_ADC_PIN
util_bsp_sd_diskio.h, 240	daisy_field.h, 138
BSP SD IsDetected	CV3 ADC PIN
util_bsp_sd_diskio.h, 240	daisy field.h, 138
BSP_SD_ReadBlocks	CV4 ADC PIN
util bsp sd diskio.h, 240	daisy field.h, 138
BSP_SD_ReadBlocks_DMA	capacity
util_bsp_sd_diskio.h, 241	daisy::RingBuffer, 104
BSP SD ReadCpltCallback	daisy::RingBuffer< T, 0 >, 108
util_bsp_sd_diskio.h, 241	CardSpeed
BSP_SD_WriteBlocks	DSY SD CardInfoTypeDef, 81
util_bsp_sd_diskio.h, 241	CardType
BSP_SD_WriteBlocks_DMA	DSY SD CardInfoTypeDef, 81
util_bsp_sd_diskio.h, 242	CardVersion
BSP_SD_WriteCpltCallback	DSY SD CardInfoTypeDef, 82
util_bsp_sd_diskio.h, 242	ChangeAudioCallback
BitPerSample	daisy::DaisyPatch, 54
WAV FormatTypeDef, 124	daisy::DaisyPetal, 60
bitdepth	daisy::DaisyPod, 66
daisy::SdmmcHandlerInit, 111	channel
dsy_dac_handle, 75	daisy::ControlChangeEvent, 50
dsy_sai_handle, 79	daisy::MidiEvent, 91
block_size	daisy::NoteOnEvent, 95
dsy_audio_handle, 74	CheckError
BlockAlign	daisy::UartHandler, 119
WAV_FormatTypeDef, 125	Chunkld
BlockNbr	WAV_FormatTypeDef, 125
DSY_SD_CardInfoTypeDef, 81	Class
BlockSize	DSY_SD_CardInfoTypeDef, 82
<del></del>	· - · = · · · · · · / P · - · · · · · ·

ClearLeds	per_adc.h, 208
daisy::DaisyPetal, 60	DSY_ADC_H
daisy::DaisyPod, 67	per_adc.h, 208
clk	DSY_AUDIO_BLOCK_SIZE_MAX
dsy_sr_4021_handle, 84	hid_audio.h, 199
Close	DSY_AUDIO_CHANNELS_MAX
daisy::WavPlayer, 127	hid_audio.h, 199
codec_ak4556_init	DSY_AUDIO_SAMPLE_RATE
dev_codec_ak4556.h, 145	hid_audio.h, 199
codec_frame_t, 45	DSY_AUDIO_H
I, 46	hid_audio.h, 199
r, 46	DSY_BSP_SD_DISKIO_H
codec_pcm3060_init	util_bsp_sd_diskio.h, 237
dev_codec_pcm3060.h, 146	DSY COLOR H
codec_wm8731_enter_bypass	
dev codec wm8731.h, 147	util_color.h, 243
codec_wm8731_exit_bypass	DSY_CORE_HW_H
dev_codec_wm8731.h, 147	daisy_core.h, 135
codec_wm8731_init	DSY_FIELD_BSP_H
dev_codec_wm8731.h, 147	daisy_field.h, 138
	DSY_I2C_H
color, 46	per_i2c.h, <mark>214</mark>
blue, 47	DSY_KNOB_H
green, 47	hid_ctrl.h, 202
red, 47	DSY_LED_DRIVER_MAX_DRIVERS
Configure	dev_leddriver.h, 180
daisy::DaisySeed, 71	DSY_MEMORY_ERROR
control_number	per_qspi.h, 216
daisy::ControlChangeEvent, 50	DSY_MEMORY_OK
controls	per_qspi.h, 216
daisy::DaisyPatch, 56	DSY_OLED_DISPLAY_H
CS	hid_oled_display.h, 205
dsy_sr_4021_handle, 84	DSY PETAL H
Ctrl	daisy_petal.h, 144
daisy::DaisyPatch, 53	DSY_QSPI_BSS
cube	per_qspi.h, 217
daisy_core.h, 136	DSY QSPI DATA
Curve	per_qspi.h, 217
daisy::Parameter, 100	
cvs	DSY_QSPI_TEXT
daisy::daisy_field, 51	per_qspi.h, 217
	DSY_QSPI
DEV_SR_4021_H	per_qspi.h, 217
dev_sr_4021.h, 185	DSY_SD_CardInfoTypeDef, 81
DEVICE_FS	BlockNbr, 81
USBD_CONF_Exported_Defines, 22	BlockSize, 81
DEVICE_HS	CardSpeed, 81
USBD_CONF_Exported_Defines, 22	CardType, 81
DEVICE_ID1	CardVersion, 82
USBD_DESC_Exported_Constants, 29	Class, 82
DEVICE_ID2	LogBlockNbr, 82
USBD_DESC_Exported_Constants, 29	LogBlockSize, 82
DEVICE_ID3	RelCardAdd, 82
USBD_DESC_Exported_Constants, 29	DSY_SD_ERROR
DIE_ERASE_CMD	per_sdmmc.h, 226
dev_flash_IS25LP064A.h, 151	DSY SD OK
dev_flash_IS25LP080D.h, 167	per_sdmmc.h, 226
DMA_BUFFER_MEM_SECTION	DSY_SDMMC_H
daisy_core.h, 135	per_sdmmc.h, 226
DSY ADC MAX CHANNELS	DSY SDRAM BSS

dev_sdram.h, 183	Init, 42
DSY_SDRAM_DATA	OverSampling, 40
dev_sdram.h, 183	Start, 43
DSY_UART_H	Stop, 43
per_uart.h, 231	daisy::AnalogControl, 43
DSY_WAVPLAYER_H	~AnalogControl, 44
hid_wavplayer.h, 207	AnalogControl, 44
DTCM_MEM_SECTION	Init, 44
daisy_core.h, 135	InitBipolarCv, 45
DUAL_IN_FAST_PROG_CMD	Process, 45
dev_flash_IS25LP064A.h, 151	Value, 45
dev_flash_IS25LP080D.h, 167	daisy::Color, 47
DUAL_INOUT_FAST_READ_4_BYTE_ADDR_CMD	Blue, 48
dev_flash_IS25LP064A.h, 151	Green, 48
dev_flash_IS25LP080D.h, 167	Init, 48, 49
DUAL_INOUT_FAST_READ_CMD	PresetColor, 48
dev_flash_IS25LP064A.h, 151	Red, 49
dev_flash_IS25LP080D.h, 167	daisy::ControlChangeEvent, 49
DUAL_INOUT_FAST_READ_DTR_CMD	channel, 50
dev_flash_IS25LP064A.h, 151	control_number, 50 value, 50
dev_flash_IS25LP080D.h, 167 DUAL_OUT_FAST_READ_4_BYTE_ADDR_CMD	daisy::DaisyPatch, 52
dev_flash_IS25LP064A.h, 152	~DaisyPatch, 53
dev_liash_lS25LP064A.fi, 152 dev_flash_lS25LP080D.h, 167	AudioBlockSize, 53
DUAL_OUT_FAST_READ_CMD	AudioCallbackRate, 53
dev_flash_IS25LP064A.h, 152	AudioSampleRate, 54
dev_flash_f325LP080D.h, 167	ChangeAudioCallback, 54
DUAL_OUT_FAST_READ_DTR_CMD	controls, 56
dev_flash_IS25LP064A.h, 152	Ctrl, 53
dev_flash_IS25LP080D.h, 167	DaisyPatch, 53
dac handle	DebounceControls, 54
daisy::DaisySeed, 72	DelayMs, 54
daisy.h	display, 56
F2S16_SCALE, 132	DisplayControls, 54
F2S24_SCALE, 132	encoder, 56
f2s16, 133	gate_input, 56
f2s24, 133	gate_output, 56
FBIPMAX, 132	GateInput, 53
FBIPMIN, 132	GetCtrlValue, 55
S162F_SCALE, 132	Init, 55
s162f, 133	midi, 56
S242F_SCALE, 133	seed, 57
s242f, 134	SetAudioBlockSize, 55
S24SIGN, 133	StartAdc, 55
daisy::AdcChannelConfig, 37	StartAudio, 55
InitMux, 38	UpdateAnalogControls, 56
InitSingle, 38	daisy::DaisyPetal, 57
mux_channels_, 39	$\sim$ DaisyPetal, 59
mux_pin_, 39	AudioBlockSize, 60
MuxPin, 37	AudioCallbackRate, 60
pin_, 39	AudioSampleRate, 60
daisy::AdcHandle, 39	ChangeAudioCallback, 60
Get, 40	ClearLeds, 60
GetFloat, 41	DaisyPetal, 59
GetMux, 41	DebounceControls, 60
GetMuxFloat, 41	DelayMs, 61
GetMuxPtr, 42	encoder, 63
GetPtr, 42	expression, 63

footswitch_led, 63	sdram_handle, 73
FootswitchLed, 58	SetAudioBlockSize, 71
GetExpression, 61	SetLed, 71
GetKnobValue, 61	SetTestPoint, 71
Init, 61	StartAudio, 72
Knob, 58	usb_handle, 73
knob, 64	daisy::Encoder, 85
	Debounce, 85
ring_led, 64	•
RingLed, 59	FallingEdge, 86
seed, 64	Increment, 86
SetAudioBlockSize, 61	Init, 86
SetFootswitchLed, 62	Pressed, 86
SetRingLed, 62	RisingEdge, 86
StartAdc, 62	TimeHeldMs, 86
StartAudio, 63	daisy::GateIn, 88
Sw, 59	$\sim$ GateIn, 88
switches, 64	GateIn, 88
UpdateAnalogControls, 63	Init, 88
UpdateLeds, 63	Trig, 89
daisy::DaisyPod, 64	daisy::Led, 89
AudioBlockSize, 66	Init, 89
AudioCallbackRate, 66	Set, 90
AudioSampleRate, 66	Update, 90
•	•
button1, 68	daisy::MidiEvent, 90
button2, 68	AsControlChange, 91
buttons, 69	AsNoteOn, 91
ChangeAudioCallback, 66	channel, 91
ClearLeds, 67	data, 91
DebounceControls, 67	type, 91
DelayMs, 67	daisy::MidiHandler, 92
encoder, 69	HasEvents, 93
GetKnobValue, 67	Init, 93
Init, 67	Listen, 94
Knob, 65	MidiInputMode, 92
knob1, 69	MidiOutputMode, 93
knob2, 69	Parse, 94
knobs, 69	PopEvent, 94
led1, 69	StartReceive, 94
led2, 69	daisy::NoteOnEvent, 95
seed, 69	channel, 95
	, ,
SetAudioBlockSize, 67	note, 95
StartAdc, 68	velocity, 95
StartAudio, 68	daisy::OledDisplay, 95
Sw, 66	DrawPixel, 96
UpdateAnalogControls, 68	Fill, 98
UpdateLeds, 68	Init, 98
daisy::DaisySeed, 70	Pins, 96
adc, 72	SetCursor, 98
audio_handle, 72	Update, 99
AudioSampleRate, 70	WriteChar, 99
Configure, 71	WriteString, 99
dac_handle, 72	daisy::Parameter, 100
GetPin, 71	~Parameter, 101
i2c1 handle, 72	Curve, 100
i2c2_handle, 72	Init, 101
Init, 71	Parameter, 101
qspi_handle, 73	Process, 101
sai_handle, 73	Value, 102

daisy::RgbLed, 102	SetReceiveCallback, 123
Init, 102	TransmitExternal, 123
Set, 103	TransmitInternal, 123
SetColor, 103	UsbPeriph, 122
Update, 103	daisy::WavFileInfo, 126
daisy::RingBuffer	name, 126
capacity, 104	raw_data, 127
Flush, 104	daisy::WavPlayer, 127
ImmediateRead, 104, 105	Close, 127
Init, 105	GetCurrentFile, 128
Overwrite, 105, 106	GetLooping, 128
Read, 106	GetNumberFiles, 128
readable, 106	Init, 128
Swallow, 106	Open, 128
writable, 107	Prepare, 129
Write, 107	Restart, 129
daisy::RingBuffer< T, 0 >, 107	SetLooping, 129
capacity, 108	Stream, 129
Flush, 108	daisy::daisy_field, 50
	• •
ImmediateRead, 108	cvs, 51
Init, 109	gate_in, 51
Overwrite, 109	gate_out, 51
Read, 109	keyboard_sr, 51
readable, 109	knobs, 51
writable, 110	seed, 51
Write, 110	switches, 51
daisy::RingBuffer< T, size >, 104	daisy_core.h
daisy::SdmmcHandler, 110	cube, 136
Init, 111	DMA_BUFFER_MEM_SECTION, 135
daisy::SdmmcHandlerInit, 111	DSY_CORE_HW_H, 135
bitdepth, 111	DTCM_MEM_SECTION, 135
speed, 111	dsy_gpio_port, 135
daisy::SpiHandle, 114	dsy_pin, 136
BlockingTransmit, 114	dsy_pin_cmp, 136
Init, 114	daisy_field.h
daisy::Switch, 114	CV1_ADC_PIN, 138
Debounce, 116	CV2_ADC_PIN, 138
FallingEdge, 116	CV3_ADC_PIN, 138
Init, 116, 117	CV4_ADC_PIN, 138
Polarity, 115	DSY_FIELD_BSP_H, 138
Pressed, 117	daisy field init, 142
Pull, 115	GATE IN PIN, 138
RisingEdge, 117	GATE_OUT_PIN, 138
TimeHeldMs, 118	KB SW SR CLK PIN, 139
Type, 116	KB SW SR CS PIN, 139
daisy::UartHandler, 118	KB_SW_SR_D1_PIN, 139
CheckError, 119	KB SW SR D2 PIN, 139
FlushRx, 119	LED DRIVER I2C, 139
Init, 119	MIDI_IN_PIN, 139
PollReceive, 119	MIDI OUT PIN, 139
PollTx, 120	MUX ADC PIN, 139
	:
PopRx, 120	MUX_SEL_0_PIN, 140
Readable, 120	MUX_SEL_1_PIN, 140
RxActive, 120	MUX_SEL_2_PIN, 140
StartRx, 121	SAMPLE_RATE, 140
daisy::UsbHandle, 121	SW_1_PIN, 140
Init, 122	SW_2_PIN, 140
ReceiveCallback, 122	SW_3_PIN, 140

daisy_field_init daisy_field.h, 142	FAST_READ_DTR_CMD, 153 IS25LP064A DIE ERASE MAX TIME, 153
• —	IS25LP064A DUMMY CYCLES READ DTR,
daisy_petal.h	
DSY_PETAL_H, 144	153
DaisyPatch	IS25LP064A_DUMMY_CYCLES_READ_QUAD ←
daisy::DaisyPatch, 53	_DTR, 154
DaisyPetal	IS25LP064A_DUMMY_CYCLES_READ_QUAD,
daisy::DaisyPetal, 59	153
data	IS25LP064A_DUMMY_CYCLES_READ, 153
daisy::MidiEvent, 91	IS25LP064A_EAR_HIGHEST_SE, 154
dsy_sr_4021_handle, 84	IS25LP064A_EAR_LOWEST_SEG, 154
FontDef, 87	IS25LP064A_EAR_SECOND_SEG, 154
Debounce	IS25LP064A_EAR_THIRD_SEG, 154
daisy::Encoder, 85	IS25LP064A_EVCR_DTRP, 154
daisy::Switch, 116	IS25LP064A_EVCR_DUAL, 154
DebounceControls	IS25LP064A_EVCR_ODS, 154
daisy::DaisyPatch, 54	IS25LP064A_EVCR_QUAD, 155
daisy::DaisyPetal, 60	IS25LP064A_EVCR_RH, 155
daisy::DaisyPod, 67	IS25LP064A_FLASH_SIZE, 155
DelayMs	IS25LP064A_FSR_ERERR, 155
daisy::DaisyPatch, 54	IS25LP064A_FSR_ERSUS, 155
daisy::DaisyPetal, 61	IS25LP064A_FSR_NBADDR, 155
daisy::DaisyPod, 67	IS25LP064A FSR PGERR, 155
dev0_i2c	IS25LP064A_FSR_PGSUS, 155
dsy_audio_handle, 74	IS25LP064A FSR PRERR, 156
dev1_i2c	IS25LP064A FSR READY, 156
dsy_audio_handle, 74	IS25LP064A_NVCR_DTRP, 156
dev_codec_ak4556.h	IS25LP064A NVCR DUAL, 156
codec_ak4556_init, 145	IS25LP064A NVCR NB DUMMY, 156
dev_codec_pcm3060.h	IS25LP064A NVCR NBADDR, 156
codec_pcm3060_init, 146	IS25LP064A NVCR ODS, 156
dev_codec_wm8731.h	IS25LP064A NVCR QUAB, 157
codec_wm8731_enter_bypass, 147	IS25LP064A NVCR RH, 157
codec_wm8731_exit_bypass, 147	IS25LP064A NVCR SEGMENT, 157
codec wm8731 init, 147	IS25LP064A NVCR XIP, 157
dev_codec_wm8731_frame.h	IS25LP064A_PAGE_SIZE, 157
sa audio callback, 148	IS25LP064A_SECTOR_ERASE_MAX_TIME, 157
dev_flash_IS25LP064A.h	IS25LP064A_SECTOR_SIZE, 157
BLOCK_ERASE_32K_CMD, 151	IS25LP064A_SR_QE, 157
CLEAR_FLAG_STATUS_REG_CMD, 151	IS25LP064A_SR_SRWREN, 158
DIE_ERASE_CMD, 151	IS25LP064A_SR_WIP, 158
DUAL_IN_FAST_PROG_CMD, 151	IS25LP064A_SR_WREN, 158
DUAL_INOUT_FAST_READ_4_BYTE_ADDR_←	IS25LP064A_SUBSECTOR_ERASE_MAX_TIME,
CMD, 151	158
DUAL_INOUT_FAST_READ_CMD, 151	IS25LP064A SUBSECTOR SIZE, 158
DUAL_INOUT_FAST_READ_DTR_CMD, 151	IS25LP064A_VCR_NB_DUMMY, 158
DUAL OUT FAST READ 4 BYTE ADDR C↔	IS25LP064A_VCR_WRAP, 158
MD, 152	IS25LP064A_VCR_XIP, 159
DUAL_OUT_FAST_READ_CMD, 152	IS25LP064A_H, 156
DUAL_OUT_FAST_READ_DTR_CMD, 152	MULTIPLE_IO_READ_ID_CMD, 159
ENTER_4_BYTE_ADDR_MODE_CMD, 152	PAGE_PROG_4_BYTE_ADDR_CMD, 159
ENTER_QUAD_CMD, 152	PAGE_PROG_CMD, 159
EXIT_4_BYTE_ADDR_MODE_CMD, 152	PROG ERASE RESUME CMD, 159
EXIT QUAD CMD, 152	PROG_ERASE_SUSPEND_CMD, 159
EXT_DUAL_IN_FAST_PROG_CMD, 152	PROG_OTP_ARRAY_CMD, 159
EXT_QUAD_IN_FAST_PROG_CMD, 153	QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD,
FAST_READ_4_BYTE_ADDR_CMD, 153	159
FAST_READ_CMD, 153	QUAD_IN_FAST_PROG_CMD, 160
,,	,

	QUAD_INOUT_FAST_READ_4_BYTE_ADDR_←	FAST_READ_CMD, 168
	CMD, 160	FAST_READ_DTR_CMD, 169
	QUAD_INOUT_FAST_READ_CMD, 160	IS25LP080D_DIE_ERASE_MAX_TIME, 169
	QUAD_INOUT_FAST_READ_DTR_CMD, 160	IS25LP080D_DUMMY_CYCLES_READ_DTR,
	QUAD_OUT_FAST_READ_4_BYTE_ADDR_C↔	169
	MD, 160	IS25LP080D_DUMMY_CYCLES_READ_QUAD↔
	QUAD_OUT_FAST_READ_CMD, 160	_DTR, 169
	QUAD_OUT_FAST_READ_DTR_CMD, 160	IS25LP080D_DUMMY_CYCLES_READ_QUAD,
	READ_4_BYTE_ADDR_CMD, 160	169
	READ_CMD, 161	IS25LP080D_DUMMY_CYCLES_READ, 169
	READ_ENHANCED_VOL_CFG_REG_CMD, 161	IS25LP080D_EAR_HIGHEST_SE, 169
	READ_EXT_ADDR_REG_CMD, 161	IS25LP080D_EAR_LOWEST_SEG, 169
	READ_FLAG_STATUS_REG_CMD, 161	IS25LP080D_EAR_SECOND_SEG, 170
	READ_ID_CMD2, 161	IS25LP080D EAR THIRD SEG, 170
	READ ID CMD, 161	IS25LP080D_EVCR_DTRP, 170
	READ_LOCK_REG_CMD, 161	IS25LP080D_EVCR_DUAL, 170
	READ_NONVOL_CFG_REG_CMD, 161	IS25LP080D_EVCR_ODS, 170
	READ_OTP_ARRAY_CMD, 162	IS25LP080D_EVCR_QUAD, 170
	READ_READ_PARAM_REG_CMD, 162	IS25LP080D_EVCR_RH, 170
	READ_SERIAL_FLASH_DISCO_PARAM_CMD,	IS25LP080D_FLASH_SIZE, 170
	162	IS25LP080D_FSR_ERERR, 171
	READ STATUS REG CMD, 162	IS25LP080D FSR ERSUS, 171
	RESET_ENABLE_CMD, 162	IS25LP080D FSR NBADDR, 171
	RESET_MEMORY_CMD, 162	IS25LP080D FSR PGERR, 171
	SECTOR_ERASE_4_BYTE_ADDR_CMD, 162	IS25LP080D FSR PGSUS, 171
	SECTOR_ERASE_CMD, 162	IS25LP080D_FSR_PRERR, 171
	SUBSECTOR_ERASE_4_BYTE_ADDR_CMD,	IS25LP080D_FSR_READY, 171
	163	IS25LP080D_NVCR_DTRP, 171
	SUBSECTOR_ERASE_CMD, 163	IS25LP080D_NVCR_DUAL, 172
	SUBSECTOR_ERASE_QPI_CMD, 163	IS25LP080D_NVCR_NB_DUMMY, 172
	WRITE_DISABLE_CMD, 163	IS25LP080D_NVCR_NBADDR, 172
	WRITE ENABLE CMD, 163	IS25LP080D_NVCR_ODS, 172
	WRITE ENHANCED VOL CFG REG CMD, 163	IS25LP080D_NVCR_QUAB, 172
	WRITE EXT ADDR REG CMD, 163	IS25LP080D NVCR RH, 172
	WRITE LOCK REG CMD, 163	IS25LP080D_NVCR_SEGMENT, 172
	WRITE_NONVOL_CFG_REG_CMD, 164	IS25LP080D_NVCR_XIP, 172
	WRITE_READ_PARAM_REG_CMD, 164	IS25LP080D_PAGE_SIZE, 173
	WRITE_STATUS_REG_CMD, 164	IS25LP080D_SECTOR_ERASE_MAX_TIME, 173
dev_	_flashIS25LP080D.h	IS25LP080D_SECTOR_SIZE, 173
	BLOCK_ERASE_32K_CMD, 166	IS25LP080D_SR_QE, 173
	CLEAR_FLAG_STATUS_REG_CMD, 166	IS25LP080D_SR_SRWREN, 173
	DIE_ERASE_CMD, 167	IS25LP080D_SR_WIP, 173
	DUAL IN FAST PROG CMD, 167	IS25LP080D_SR_WREN, 173
	DUAL_INOUT_FAST_READ_4_BYTE_ADDR_←	IS25LP080D SUBSECTOR ERASE MAX TIME,
	CMD, 167	174
	DUAL_INOUT_FAST_READ_CMD, 167	IS25LP080D_SUBSECTOR_SIZE, 174
	DUAL_INOUT_FAST_READ_DTR_CMD, 167	IS25LP080D_VCR_NB_DUMMY, 174
	DUAL_OUT_FAST_READ_4_BYTE_ADDR_C↔	IS25LP080D_VCR_WRAP, 174
	MD, 167	IS25LP080D_VCR_XIP, 174
	DUAL_OUT_FAST_READ_CMD, 167	MULTIPLE_IO_READ_ID_CMD, 174
	DUAL_OUT_FAST_READ_DTR_CMD, 167	PAGE_PROG_4_BYTE_ADDR_CMD, 174
	ENTER_4_BYTE_ADDR_MODE_CMD, 168	PAGE_PROG_CMD, 174
	ENTER_QUAD_CMD, 168	PROG_ERASE_RESUME_CMD, 175
	EXIT_4_BYTE_ADDR_MODE_CMD, 168	PROG_ERASE_SUSPEND_CMD, 175
	EXIT_QUAD_CMD, 168	PROG_OTP_ARRAY_CMD, 175
	EXT_DUAL_IN_FAST_PROG_CMD, 168	QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD,
	EXT_QUAD_IN_FAST_PROG_CMD, 168	175
	FAST_READ_4_BYTE_ADDR_CMD, 168	QUAD_IN_FAST_PROG_CMD, 175

(	QUAD_INOUT_FAST_READ_4_BYTE_ADDR_↔ CMD, 175	SR_4021_MAX_PARALLEL, 186 dev_sr_595.h
	QUAD_INOUT_FAST_READ_CMD, 175	kMaxSr595DaisyChain, 189
	QUAD_INOUT_FAST_READ_DTR_CMD, 175	device
	QUAD_OUT_FAST_READ_4_BYTE_ADDR_C↔	dsy_qspi_handle, 78
	MD, 176	dsy_sai_handle, 80
	QUAD_OUT_FAST_READ_CMD, 176	display
	QUAD_OUT_FAST_READ_DTR_CMD, 176	daisy::DaisyPatch, 56
	READ_4_BYTE_ADDR_CMD, 176	DisplayControls
	READ CMD, 176	daisy::DaisyPatch, 54
	READ_ENHANCED_VOL_CFG_REG_CMD, 176	DrawPixel
	READ_EXT_ADDR_REG_CMD, 176	daisy::OledDisplay, 96
	READ_FLAG_STATUS_REG_CMD, 176	dsy_audio_bitdepth
	READ_ID_CMD2, 177	per_sai.h, 222
	READ_ID_CMD, 177	dsy_audio_callback
	READ LOCK REG CMD, 177	hid_audio.h, 199
	READ_NONVOL_CFG_REG_CMD, 177	dsy_audio_device
	READ_OTP_ARRAY_CMD, 177	per_sai.h, 222
	READ READ PARAM REG CMD, 177	dsy_audio_dir
	READ SERIAL FLASH DISCO PARAM CMD,	per_sai.h, 222
	177	dsy_audio_enter_bypass
	READ_STATUS_REG_CMD, 177	hid audio.h, 200
	RESET ENABLE CMD, 178	dsy_audio_exit_bypass
	RESET_MEMORY_CMD, 178	hid_audio.h, 200
	SECTOR_ERASE_4_BYTE_ADDR_CMD, 178	dsy_audio_handle, 73
	SECTOR_ERASE_CMD, 178	block_size, 74
	SUBSECTOR_ERASE_4_BYTE_ADDR_CMD,	dev0_i2c, 74
	178	dev1_i2c, 74
	SUBSECTOR_ERASE_CMD, 178	sai, 74
	SUBSECTOR_ERASE_QPI_CMD, 178	dsy_audio_init
	WRITE_DISABLE_CMD, 178	hid_audio.h, 200
,	WRITE_ENABLE_CMD, 179	dsy_audio_mc_callback
,	WRITE_ENHANCED_VOL_CFG_REG_CMD, 179	hid_audio.h, 199
,	WRITE_EXT_ADDR_REG_CMD, 179	dsy_audio_passthru
,	WRITE_LOCK_REG_CMD, 179	hid_audio.h, 201
,	WRITE_NONVOL_CFG_REG_CMD, 179	dsy_audio_sai
,	WRITE_READ_PARAM_REG_CMD, 179	per_sai.h, 223
,	WRITE_STATUS_REG_CMD, 179	dsy_audio_samplerate
dev_l	leddriver.h	per_sai.h, 223
	DSY_LED_DRIVER_MAX_DRIVERS, 180	dsy_audio_set_blocksize
(	dsy_led_driver_color_by_name, 181	hid_audio.h, 201
(	dsy_led_driver_init, 181	dsy_audio_set_callback
(	dsy_led_driver_set_led, 182	hid_audio.h, 201
(	dsy_led_driver_update, 182	dsy_audio_set_mc_callback
,	SA_LED_DRIVER_H, 180	hid_audio.h, 201
dev_s	sdram.h	dsy_audio_silence
	DSY_SDRAM_BSS, 183	hid_audio.h, 201
	DSY_SDRAM_DATA, 183	dsy_audio_start
	dsy_sdram_init, 184	hid_audio.h, 202
	dsy_sdram_pin, 184	dsy_audio_stop
	dsy_sdram_state, 184	hid_audio.h, 202
	RAM_AS4C16M16SA_H, 183	dsy_audio_sync
	sr_4021.h	per_sai.h, 223
	DEV_SR_4021_H, 185	dsy_dac_bitdepth
	dsy_sr_4021_init, 186	per_dac.h, 208
	dsy_sr_4021_state, 188	dsy_dac_channel
	dsy_sr_4021_update, 188	per_dac.h, 209
;	SR_4021_MAX_DAISYCHAIN, 186	dsy_dac_handle, 74

bitdepth, 75	dsy_led_driver_color_by_name
mode, 75	dev_leddriver.h, 181
pin_config, 75	dsy_led_driver_init
dsy_dac_init	dev_leddriver.h, 181
per_dac.h, 209	dsy_led_driver_set_led
dsy_dac_mode	dev_leddriver.h, 182
per_dac.h, 209	dsy_led_driver_update
dsy_dac_start	dev_leddriver.h, 182
per_dac.h, 210	dsy_pin
dsy_dac_write	daisy_core.h, 136
per_dac.h, 210	dsy_pin_cmp
dsy_dma_init	daisy_core.h, 136
sys_dma.h, 232	dsy_qspi_deinit
dsy_fatfs_init	per_qspi.h, 218
fatfs.h, 190	dsy_qspi_device
dsy_get_unique_id	per_qspi.h, 217
util_unique_id.h, 245	dsy_qspi_erase
dsy_gpio, 75 mode, 76	per_qspi.h, 219
pin, 76	dsy_qspi_erasesector
pull, 76	per_qspi.h, 219 dsy_qspi_handle, 78
dsy_gpio_deinit	device, 78
per_gpio.h, 212	mode, 78
dsy_gpio_init	pin_config, 78
per_gpio.h, 212	dsy_qspi_init
dsy_gpio_mode	per_qspi.h, 219
per_gpio.h, 211	dsy_qspi_mode
dsy_gpio_pin, 76	per_qspi.h, 218
pin, 76	dsy_qspi_pin
port, 77	per_qspi.h, 218
dsy_gpio_port	dsy_qspi_write
daisy core.h, 135	per_qspi.h, 220
dsy_gpio_pull	dsy_qspi_writepage
per_gpio.h, 211	per qspi.h, 220
dsy_gpio_read	dsy_sai_handle, 79
per_gpio.h, 212	a_direction, 79
dsy_gpio_toggle	b_direction, 79
per_gpio.h, 213	bitdepth, 79
dsy_gpio_write	device, 80
per_gpio.h, 213	init, 80
dsy_hal_map_get_i2c	sai1_pin_config, 80
util_hal_map.h, 243	sai2_pin_config, 80
dsy_hal_map_get_pin	samplerate, 80
util_hal_map.h, 244	sync_config, 80
dsy_hal_map_get_port	dsy_sai_init
util_hal_map.h, 244	per_sai.h, <mark>224</mark>
dsy_i2c_handle, 77	dsy_sai_init_from_handle
periph, 77	per_sai.h, <mark>224</mark>
pin_config, 77	dsy_sai_pin
speed, 77	per_sai.h, <mark>223</mark>
dsy_i2c_init	dsy_sdram_handle, 82
per_i2c.h, 215	pin_config, 83
dsy_i2c_periph	state, 83
per_i2c.h, 214	dsy_sdram_init
dsy_i2c_pin	dev_sdram.h, 184
per_i2c.h, 214	dsy_sdram_pin
dsy_i2c_speed	dev_sdram.h, 184
per_i2c.h, 215	dsy_sdram_state

dev_sdram.h, 184	dev_flash_IS25LP080D.h, 168
dsy_sr_4021_handle, 83	encoder
clk, 84	daisy::DaisyPatch, 56
cs, 84	daisy::DaisyPetal, 63
data, 84	daisy::DaisyPod, 69
num daisychained, 84	expression
num_parallel, 84	daisy::DaisyPetal, 63
pin_config, 84	daisyBaisyr olai, oo
states, 84	F2S16_SCALE
dsy_sr_4021_init	daisy.h, 132
dev_sr_4021.h, 186	F2S24_SCALE
dsy_sr_4021_state	daisy.h, 132
dev_sr_4021.h, 188	f2s16
dsy_sr_4021_update	daisy.h, 133
dev_sr_4021.h, 188	f2s24
dsy_system_delay	daisy.h, 133
sys_system.h, 232	FAST_READ_4_BYTE_ADDR_CMD
dsy system getnow	dev_flash_IS25LP064A.h, 153
sys_system.h, 233	dev_flash_IS25LP080D.h, 168
dsy_system_init	FAST_READ_CMD
sys_system.h, 233	dev_flash_IS25LP064A.h, 153
dsy_system_jumpto	dev_flash_IS25LP080D.h, 168
sys_system.h, 233	FAST_READ_DTR_CMD
dsy_system_jumptoqspi	dev_flash_IS25LP064A.h, 153
sys_system.h, 233	dev_flash_IS25LP080D.h, 169
dsy_tim_delay_ms	FBIPMAX
per_tim.h, 229	daisy.h, 132
dsy_tim_delay_tick	FBIPMIN
per_tim.h, 229	daisy.h, 132
dsy_tim_delay_us	FS_Desc
per_tim.h, 229	USBD_DESC_Exported_Variables, 33
dsy_tim_get_ms	FallingEdge
per_tim.h, 230	daisy::Encoder, 86 daisy::Switch, 116
dsy_tim_get_tick	fatfs.h
per_tim.h, 230	fatfs_H, 189
dsy_tim_get_us	dsy_fatfs_init, 190
per_tim.h, 230	retSD, 190
dsy_tim_init	SDFatFS, 190
per_tim.h, 230	SDFile, 190
dsy_tim_start per_tim.h, 231	SDPath, 190
per_um.n, 231	ff free
ENTER_4_BYTE_ADDR_MODE_CMD	ffconf.h, 198
dev flash IS25LP064A.h, 152	ff malloc
dev_flash_IS25LP080D.h, 168	ffconf.h, 198
ENTER_QUAD_CMD	ffconf.h
dev_flash_IS25LP064A.h, 152	_CODE_PAGE, 192
dev_flash_IS25LP080D.h, 168	_FFCONF, 192
EXIT_4_BYTE_ADDR_MODE_CMD	_FS_EXFAT, 192
dev_flash_IS25LP064A.h, 152	_FS_LOCK, 192
dev_flash_IS25LP080D.h, 168	_FS_MINIMIZE, 192
EXIT_QUAD_CMD	_FS_NOFSINFO, 193
dev_flash_IS25LP064A.h, 152	_FS_NORTC, 193
dev_flash_IS25LP080D.h, 168	_FS_READONLY, 193
EXT_DUAL_IN_FAST_PROG_CMD	_FS_REENTRANT, 193
dev_flash_IS25LP064A.h, 152	_FS_RPATH, 193
dev_flash_IS25LP080D.h, 168	_FS_TIMEOUT, 193
EXT_QUAD_IN_FAST_PROG_CMD	_FS_TINY, 194
dev_flash_IS25LP064A.h, 153	_LFN_UNICODE, 194

_MAX_LFN, 194	daisy::DaisyPatch, 56
_MAX_SS, 194	GateIn
_MIN_SS, 194	daisy::GateIn, 88
_MULTI_PARTITION, 194	GateInput
_NORTC_MDAY, 195	daisy::DaisyPatch, 53
_NORTC_MON, 195	Get
_NORTC_YEAR, 195	daisy::AdcHandle, 40
STRF ENCODE, 195	GetCtrlValue
STR VOLUME ID, 195	daisy::DaisyPatch, 55
	GetCurrentFile
USE CHMOD, 196	daisy::WavPlayer, 128
_USE_EXPAND, 196	GetExpression
USE FASTSEEK, 196	daisy::DaisyPetal, 61
USE FIND, 196	GetFloat
USE FORWARD, 196	daisy::AdcHandle, 41
USE LABEL, 196	GetKnobValue
USE LFN, 197	daisy::DaisyPetal, 61
USE MKFS, 197	daisy::DaisyPod, 67
USE STRFUNC, 197	GetLooping
USE TRIM, 197	daisy::WavPlayer, 128
VOLUMES, 197	GetMux
<del>-</del>	daisy::AdcHandle, 41
_VOLUME_STRS, 197 ff_free, 198	GetMuxFloat
<del>-</del> · · ·	
ff_malloc, 198	daisy::AdcHandle, 41
FileFormat	GetMuxPtr
WAV_FormatTypeDef, 125	daisy::AdcHandle, 42
FileSize	GetNumberFiles
WAV_FormatTypeDef, 125	daisy::WavPlayer, 128
Fill	GetPin
daisy::OledDisplay, 98	daisy::DaisySeed, 71
Flush	GetPtr
daisy::RingBuffer, 104	daisy::AdcHandle, 42
daisy::RingBuffer< T, 0 >, 108	Green
daisy::RingBuffer< T, 0 >, 108 FlushRx	•
daisy::RingBuffer< T, 0 >, 108	Green
daisy::RingBuffer< T, 0 >, 108 FlushRx	Green daisy::Color, 48
daisy::RingBuffer< T, 0 >, 108 FlushRx daisy::UartHandler, 119	Green daisy::Color, 48 green color, 47
daisy::RingBuffer< T, 0 >, 108 FlushRx daisy::UartHandler, 119 FontDef, 87	Green daisy::Color, 48 green color, 47  HS_Desc
daisy::RingBuffer< T, 0 >, 108 FlushRx daisy::UartHandler, 119 FontDef, 87 data, 87	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33
daisy::RingBuffer< T, 0 >, 108 FlushRx daisy::UartHandler, 119 FontDef, 87 data, 87 FontHeight, 87	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10
daisy::RingBuffer< T, 0 >, 108 FlushRx daisy::UartHandler, 119 FontDef, 87 data, 87 FontHeight, 87 FontWidth, 87	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents
daisy::RingBuffer< T, 0 >, 108 FlushRx daisy::UartHandler, 119 FontDef, 87 data, 87 FontHeight, 87 FontWidth, 87 FontHeight	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93
daisy::RingBuffer< T, 0 >, 108 FlushRx daisy::UartHandler, 119 FontDef, 87 data, 87 FontHeight, 87 FontWidth, 87 FontHeight FontDef, 87	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents
daisy::RingBuffer< T, 0 >, 108 FlushRx daisy::UartHandler, 119 FontDef, 87 data, 87 FontHeight, 87 FontWidth, 87 FontHeight FontDef, 87 FontDef, 87 FontWidth	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93
daisy::RingBuffer< T, 0 >, 108 FlushRx	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1
daisy::RingBuffer< T, 0 >, 108 FlushRx daisy::UartHandler, 119 FontDef, 87 data, 87 FontHeight, 87 FontWidth, 87 FontDef, 87 FontDef, 87 FontDef, 87	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1 util_hal_map.h, 244
daisy::RingBuffer< T, 0 >, 108 FlushRx	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1 util_hal_map.h, 244 hi2c2
daisy::RingBuffer< T, 0 >, 108 FlushRx	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1 util_hal_map.h, 244 hi2c2 util_hal_map.h, 244
daisy::RingBuffer< T, 0 >, 108 FlushRx	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1 util_hal_map.h, 244 hi2c2 util_hal_map.h, 244 hi2c3
daisy::RingBuffer< T, 0 >, 108  FlushRx	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1 util_hal_map.h, 244 hi2c2 util_hal_map.h, 244 hi2c3 util_hal_map.h, 245
daisy::RingBuffer< T, 0 >, 108 FlushRx	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1 util_hal_map.h, 244 hi2c2 util_hal_map.h, 244 hi2c3 util_hal_map.h, 245 hi2c4
daisy::RingBuffer < T, 0 >, 108  FlushRx	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1 util_hal_map.h, 244 hi2c2 util_hal_map.h, 244 hi2c3 util_hal_map.h, 245 hi2c4 util_hal_map.h, 245
daisy::RingBuffer < T, 0 >, 108  FlushRx	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1 util_hal_map.h, 244 hi2c2 util_hal_map.h, 244 hi2c3 util_hal_map.h, 245 hi2c4 util_hal_map.h, 245 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 199
daisy::RingBuffer < T, 0 >, 108  FlushRx	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1 util_hal_map.h, 244 hi2c2 util_hal_map.h, 244 hi2c3 util_hal_map.h, 245 hi2c4 util_hal_map.h, 245 hi2c4 util_hal_map.h, 245 hid_audio.h
daisy::RingBuffer< T, 0 >, 108 FlushRx	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1 util_hal_map.h, 244 hi2c2 util_hal_map.h, 244 hi2c3 util_hal_map.h, 245 hi2c4 util_hal_map.h, 245 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 199 DSY_AUDIO_SAMPLE_RATE, 199
daisy::RingBuffer< T, 0 >, 108 FlushRx	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1 util_hal_map.h, 244 hi2c2 util_hal_map.h, 244 hi2c3 util_hal_map.h, 245 hi2c4 util_hal_map.h, 245 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 199 DSY_AUDIO_CHANNELS_MAX, 199 DSY_AUDIO_SAMPLE_RATE, 199 DSY_AUDIO_H, 199
daisy::RingBuffer < T, 0 >, 108  FlushRx	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1 util_hal_map.h, 244 hi2c2 util_hal_map.h, 244 hi2c3 util_hal_map.h, 245 hi2c4 util_hal_map.h, 245 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 199 DSY_AUDIO_CHANNELS_MAX, 199 DSY_AUDIO_H, 199 dsy_audio_callback, 199
daisy::RingBuffer < T, 0 >, 108  FlushRx	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1 util_hal_map.h, 244 hi2c2 util_hal_map.h, 244 hi2c3 util_hal_map.h, 245 hi2c4 util_hal_map.h, 245 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 199 DSY_AUDIO_CHANNELS_MAX, 199 DSY_AUDIO_H, 199 dsy_audio_callback, 199 dsy_audio_enter_bypass, 200
daisy::RingBuffer < T, 0 >, 108  FlushRx	Green daisy::Color, 48 green color, 47  HS_Desc USBD_DESC_Exported_Variables, 33 HUMAN_INTERFACE, 10 HasEvents daisy::MidiHandler, 93 hi2c1 util_hal_map.h, 244 hi2c2 util_hal_map.h, 244 hi2c3 util_hal_map.h, 245 hi2c4 util_hal_map.h, 245 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 199 DSY_AUDIO_CHANNELS_MAX, 199 DSY_AUDIO_SAMPLE_RATE, 199 DSY_AUDIO_H, 199 dsy_audio_callback, 199

dsy_audio_mc_callback, 199	dev_flash_IS25LP064A.h, 155
dsy_audio_passthru, 201	IS25LP064A_FSR_PGERR
dsy_audio_set_blocksize, 201	dev_flash_IS25LP064A.h, 155
dsy_audio_set_callback, 201	IS25LP064A_FSR_PGSUS
dsy_audio_set_mc_callback, 201	dev_flash_IS25LP064A.h, 155
dsy_audio_silence, 201	IS25LP064A_FSR_PRERR
dsy_audio_start, 202	dev_flash_IS25LP064A.h, 156
dsy_audio_stop, 202	IS25LP064A_FSR_READY
hid_ctrl.h	dev_flash_IS25LP064A.h, 156
DSY_KNOB_H, 202	IS25LP064A_NVCR_DTRP
hid_midi.h	dev_flash_IS25LP064A.h, 156
MidiMessageType, 204 hid_oled_display.h	IS25LP064A_NVCR_DUAL
DSY_OLED_DISPLAY_H, 205	dev_flash_IS25LP064A.h, 156
	IS25LP064A_NVCR_NB_DUMMY
SSD1309_HEIGHT, 205 SSD1309_WIDTH, 205	dev_flash_IS25LP064A.h, 156
hid wavplayer.h	IS25LP064A_NVCR_NBADDR
DSY_WAVPLAYER_H, 207	dev_flash_IS25LP064A.h, 156
WAV FILENAME MAX, 207	IS25LP064A_NVCR_ODS
VVAV_I ILLIVAIVIL_IVIAA, 207	dev_flash_IS25LP064A.h, 156
i2c1_handle	IS25LP064A_NVCR_QUAB
daisy::DaisySeed, 72	dev_flash_IS25LP064A.h, 157
i2c2 handle	IS25LP064A_NVCR_RH
daisy::DaisySeed, 72	dev_flash_IS25LP064A.h, 157
IS25LP064A_DIE_ERASE_MAX_TIME	IS25LP064A_NVCR_SEGMENT
dev_flash_IS25LP064A.h, 153	dev_flash_IS25LP064A.h, 157
IS25LP064A_DUMMY_CYCLES_READ_DTR	IS25LP064A_NVCR_XIP
dev_flash_IS25LP064A.h, 153	dev_flash_IS25LP064A.h, 157
IS25LP064A_DUMMY_CYCLES_READ_QUAD_DTR	IS25LP064A_PAGE_SIZE
dev_flash_IS25LP064A.h, 154	dev_flash_IS25LP064A.h, 157
IS25LP064A_DUMMY_CYCLES_READ_QUAD	IS25LP064A_SECTOR_ERASE_MAX_TIME
dev_flash_IS25LP064A.h, 153	dev_flash_IS25LP064A.h, 157
IS25LP064A_DUMMY_CYCLES_READ	IS25LP064A_SECTOR_SIZE
dev_flash_IS25LP064A.h, 153	dev_flash_IS25LP064A.h, 157
IS25LP064A_EAR_HIGHEST_SE	IS25LP064A_SR_QE
dev_flash_IS25LP064A.h, 154	dev_flash_IS25LP064A.h, 157
IS25LP064A_EAR_LOWEST_SEG	IS25LP064A_SR_SRWREN
dev_flash_IS25LP064A.h, 154	dev_flash_IS25LP064A.h, 158
IS25LP064A_EAR_SECOND_SEG	IS25LP064A_SR_WIP
dev_flash_IS25LP064A.h, 154	dev_flash_IS25LP064A.h, 158
IS25LP064A_EAR_THIRD_SEG	IS25LP064A_SR_WREN
dev_flash_IS25LP064A.h, 154	dev_flash_IS25LP064A.h, 158
IS25LP064A_EVCR_DTRP	IS25LP064A_SUBSECTOR_ERASE_MAX_TIME
dev_flash_IS25LP064A.h, 154	dev_flash_IS25LP064A.h, 158
IS25LP064A_EVCR_DUAL	IS25LP064A_SUBSECTOR_SIZE
dev_flash_IS25LP064A.h, 154	dev_flash_IS25LP064A.h, 158
IS25LP064A_EVCR_ODS	IS25LP064A_VCR_NB_DUMMY
dev_flash_IS25LP064A.h, 154	dev_flash_IS25LP064A.h, 158
IS25LP064A_EVCR_QUAD	IS25LP064A_VCR_WRAP
dev_flash_IS25LP064A.h, 155	dev_flash_IS25LP064A.h, 158
IS25LP064A_EVCR_RH	IS25LP064A_VCR_XIP
dev_flash_IS25LP064A.h, 155	dev_flash_IS25LP064A.h, 159
IS25LP064A_FLASH_SIZE	IS25LP064A_H
dev_flash_IS25LP064A.h, 155	dev_flash_IS25LP064A.h, 156
IS25LP064A_FSR_ERERR	IS25LP080D_DIE_ERASE_MAX_TIME
dev_flash_IS25LP064A.h, 155	dev_flash_IS25LP080D.h, 169
IS25LP064A_FSR_ERSUS	IS25LP080D_DUMMY_CYCLES_READ_DTR
dev_flash_IS25LP064A.h, 155 IS25LP064A FSR NBADDR	dev_flash_IS25LP080D.h, 169 IS25LP080D DUMMY CYCLES READ QUAD DTR
IOZOLFUU4A_I ON_INDADDN	1959FL000D_DOIMINIT_CTOFE9_WEND_GOND_DIK

day fleeh 19251 P090D h 160	day floob 19251 D000D b 172
dev_flash_IS25LP080D.h, 169	dev_flash_IS25LP080D.h, 173
IS25LP080D_DUMMY_CYCLES_READ_QUAD	IS25LP080D_SECTOR_ERASE_MAX_TIME
dev_flash_IS25LP080D.h, 169	dev_flash_IS25LP080D.h, 173
IS25LP080D_DUMMY_CYCLES_READ	IS25LP080D_SECTOR_SIZE
dev_flash_IS25LP080D.h, 169	dev_flash_IS25LP080D.h, 173
IS25LP080D_EAR_HIGHEST_SE	IS25LP080D_SR_QE
dev_flash_IS25LP080D.h, 169	dev_flash_IS25LP080D.h, 173
IS25LP080D_EAR_LOWEST_SEG	IS25LP080D_SR_SRWREN
dev flash IS25LP080D.h, 169	dev_flash_IS25LP080D.h, 173
IS25LP080D_EAR_SECOND_SEG	IS25LP080D SR WIP
dev flash IS25LP080D.h, 170	dev flash IS25LP080D.h, 173
IS25LP080D_EAR_THIRD_SEG	IS25LP080D_SR_WREN
dev_flash_IS25LP080D.h, 170	dev_flash_IS25LP080D.h, 173
IS25LP080D_EVCR_DTRP	IS25LP080D_SUBSECTOR_ERASE_MAX_TIME
dev_flash_IS25LP080D.h, 170	dev_flash_IS25LP080D.h, 174
IS25LP080D_EVCR_DUAL	IS25LP080D_SUBSECTOR_SIZE
dev_flash_IS25LP080D.h, 170	dev_flash_IS25LP080D.h, 174
IS25LP080D_EVCR_ODS	IS25LP080D_VCR_NB_DUMMY
dev_flash_IS25LP080D.h, 170	dev_flash_IS25LP080D.h, 174
IS25LP080D_EVCR_QUAD	IS25LP080D_VCR_WRAP
dev_flash_IS25LP080D.h, 170	dev_flash_IS25LP080D.h, 174
IS25LP080D_EVCR_RH	IS25LP080D_VCR_XIP
dev_flash_IS25LP080D.h, 170	dev_flash_IS25LP080D.h, 174
IS25LP080D FLASH SIZE	ImmediateRead
dev_flash_IS25LP080D.h, 170	daisy::RingBuffer, 104, 105
	daisy::RingBuffer< T, 0 >, 108
IS25LP080D_FSR_ERERR	-
dev_flash_IS25LP080D.h, 171	Increment
IS25LP080D_FSR_ERSUS	daisy::Encoder, 86
dev_flash_IS25LP080D.h, 171	Init
IS25LP080D_FSR_NBADDR	daisy::AdcHandle, 42
dev_flash_IS25LP080D.h, 171	daisy::AnalogControl, 44
IS25LP080D_FSR_PGERR	daisy::Color, 48, 49
dev_flash_IS25LP080D.h, 171	daisy::DaisyPatch, 55
IS25LP080D_FSR_PGSUS	daisy::DaisyPetal, 61
dev flash IS25LP080D.h, 171	daisy::DaisyPod, 67
IS25LP080D_FSR_PRERR	daisy::DaisySeed, 71
dev flash IS25LP080D.h, 171	daisy::Encoder, 86
IS25LP080D_FSR_READY	daisy::GateIn, 88
dev flash IS25LP080D.h, 171	daisy::Led, 89
IS25LP080D_NVCR_DTRP	daisy::MidiHandler, 93
dev flash IS25LP080D.h, 171	-
	daisy::OledDisplay, 98
IS25LP080D_NVCR_DUAL	daisy::Parameter, 101
dev_flash_IS25LP080D.h, 172	daisy::RgbLed, 102
IS25LP080D_NVCR_NB_DUMMY	daisy::RingBuffer, 105
dev_flash_IS25LP080D.h, 172	daisy::RingBuffer $<$ T, 0 $>$ , 109
IS25LP080D_NVCR_NBADDR	daisy::SdmmcHandler, 111
dev_flash_IS25LP080D.h, 172	daisy::SpiHandle, 114
IS25LP080D_NVCR_ODS	daisy::Switch, 116, 117
dev_flash_IS25LP080D.h, 172	daisy::UartHandler, 119
IS25LP080D_NVCR_QUAB	daisy::UsbHandle, 122
dev_flash_IS25LP080D.h, 172	daisy::WavPlayer, 128
IS25LP080D_NVCR_RH	ShiftRegister595, 113
dev_flash_IS25LP080D.h, 172	init
IS25LP080D_NVCR_SEGMENT	dsy_sai_handle, 80
dev_flash_IS25LP080D.h, 172	InitBipolarCv
	•
IS25LP080D_NVCR_XIP	daisy::AnalogControl, 45
dev_flash_IS25LP080D.h, 172	InitMux
IS25LP080D_PAGE_SIZE	daisy::AdcChannelConfig, 38

InitSingle	MUX_ADC_PIN
daisy::AdcChannelConfig, 38	daisy_field.h, 139
	MUX_SEL_0_PIN
KB_SW_SR_CLK_PIN	daisy_field.h, 140
daisy_field.h, 139	MUX_SEL_1_PIN
KB_SW_SR_CS_PIN	daisy_field.h, 140
daisy_field.h, 139	MUX SEL 2 PIN
KB SW SR D1 PIN	daisy_field.h, 140
daisy field.h, 139	midi
KB SW SR D2 PIN	daisy::DaisyPatch, 56
daisy_field.h, 139	MidiInputMode
kMaxSr595DaisyChain	daisy::MidiHandler, 92
dev_sr_595.h, 189	MidiMessageType
kUartMaxBufferSize	hid_midi.h, 204
per_uart.h, 231	
keyboard_sr	MidiOutputMode
daisy::daisy_field, 51	daisy::MidiHandler, 93
Knob	mode
	dsy_dac_handle, 75
daisy::DaisyPetal, 58	dsy_gpio, 76
daisy::DaisyPod, 65	dsy_qspi_handle, 78
knob	mux_channels_
daisy::DaisyPetal, 64	daisy::AdcChannelConfig, 39
knob1	mux_pin_
daisy::DaisyPod, 69	daisy::AdcChannelConfig, 39
knob2	MuxPin
daisy::DaisyPod, 69	daisy::AdcChannelConfig, 37
knobs	
daisy::DaisyPod, 69	name
daisy::daisy_field, 51	daisy::WavFileInfo, 126
	NbrChannels
1	WAV_FormatTypeDef, 125
codec_frame_t, 46	note
LED_DRIVER_I2C	daisy::NoteOnEvent, 95
daisy_field.h, 139	num daisychained
LIBDAISY, 9	, dsy_sr_4021_handle, 84
led1	num_parallel
daisy::DaisyPod, 69	dsy_sr_4021_handle, 84
led2	
daisy::DaisyPod, 69	Open
Listen	daisy::WavPlayer, 128
daisy::MidiHandler, 94	OverSampling
LogBlockNbr	daisy::AdcHandle, 40
DSY_SD_CardInfoTypeDef, 82	Overwrite
LogBlockSize	daisy::RingBuffer, 105, 106
DSY SD CardInfoTypeDef, 82	daisy::RingBuffer< T, 0 >, 109
D31_3D_Cardinio TypeDet, 62	daisyhiiigbuilei < 1, 0 >, 109
MIDI IN PIN	PAGE PROG 4 BYTE ADDR CMD
daisy field.h, 139	dev_flash_IS25LP064A.h, 159
MIDI OUT PIN	dev flash IS25LP080D.h, 174
<del></del>	PAGE PROG CMD
daisy_field.h, 139	
MSD_ERROR_SD_NOT_PRESENT	dev_flash_IS25LP064A.h, 159
util_bsp_sd_diskio.h, 238	dev_flash_IS25LP080D.h, 174
MSD_ERROR	PERIPHERALS, 13
util_bsp_sd_diskio.h, 237	PROG_ERASE_RESUME_CMD
MSD_OK	dev_flash_IS25LP064A.h, 159
util_bsp_sd_diskio.h, 238	dev_flash_IS25LP080D.h, 175
MULTIPLE_IO_READ_ID_CMD	PROG_ERASE_SUSPEND_CMD
dev_flash_IS25LP064A.h, 159	dev_flash_IS25LP064A.h, 159
dev_flash_IS25LP080D.h, 174	dev_flash_IS25LP080D.h, 175

PROG_OTP_ARRAY_CMD	DSY_SD_ERROR, 226
dev_flash_IS25LP064A.h, 159	DSY_SD_OK, 226
dev_flash_IS25LP080D.h, 175	DSY_SDMMC_H, 226
Parameter	SdmmcBitWidth, 227
daisy::Parameter, 101	SdmmcMode, 227
Parse	SdmmcSpeed, 227
daisy::MidiHandler, 94	per_spi.h
per_adc.h	SpiPeriph, 228
DSY_ADC_MAX_CHANNELS, 208	SpiPin, 228
DSY_ADC_H, 208	per_tim.h
per_dac.h	dsy_tim_delay_ms, 229
dsy_dac_bitdepth, 208	dsy_tim_delay_tick, 229
dsy_dac_channel, 209	dsy_tim_delay_us, 229
dsy_dac_init, 209	dsy_tim_get_ms, 230
dsy_dac_mode, 209	dsy_tim_get_tick, 230
dsy_dac_start, 210	dsy_tim_get_us, 230
dsy_dac_start, 210 dsy_dac_write, 210	dsy_tim_get_us, 200 dsy_tim_init, 230
• — —	dsy_tim_start, 231
per_gpio.h	• — —
dsy_gpio_deinit, 212	per_uart.h
dsy_gpio_init, 212	DSY_UART_H, 231
dsy_gpio_mode, 211	kUartMaxBufferSize, 231
dsy_gpio_pull, 211	periph
dsy_gpio_read, 212	dsy_i2c_handle, 77
dsy_gpio_toggle, 213	pin
dsy_gpio_write, 213	dsy_gpio, 76
per_i2c.h	dsy_gpio_pin, 76
DSY_I2C_H, 214	pin_
dsy_i2c_init, 215	daisy::AdcChannelConfig, 39
dsy_i2c_periph, 214	pin_config
dsy_i2c_pin, 214	dsy_dac_handle, 75
dsy_i2c_speed, 215	dsy_i2c_handle, 77
per_qspi.h	dsy_qspi_handle, 78
DSY_MEMORY_ERROR, 216	dsy_sdram_handle, 83
DSY_MEMORY_OK, 216	dsy_sr_4021_handle, 84
DSY QSPI BSS, 217	Pins
DSY QSPI DATA, 217	daisy::OledDisplay, 96
DSY_QSPI_TEXT, 217	ShiftRegister595, 112
DSY QSPI, 217	Polarity
dsy_qspi_deinit, 218	daisy::Switch, 115
dsy_qspi_device, 217	PollReceive
dsy_qspi_erase, 219	daisy::UartHandler, 119
dsy_qspi_erasesector, 219	PollTx
dsy_qspi_init, 219	daisy::UartHandler, 120
dsy_qspi_mit, 218	PopEvent
dsy_qspi_niode, 216 dsy_qspi_pin, 218	daisy::MidiHandler, 94
dsy_qspi_pin, 210 dsy_qspi_write, 220	PopRx
	daisy::UartHandler, 120
dsy_qspi_writepage, 220	•
per_sai.h	port
dsy_audio_bitdepth, 222	dsy_gpio_pin, 77
dsy_audio_device, 222	Prepare
dsy_audio_dir, 222	daisy::WavPlayer, 129
dsy_audio_sai, 223	PresetColor
dsy_audio_samplerate, 223	daisy::Color, 48
dsy_audio_sync, 223	Pressed
dsy_sai_init, 224	daisy::Encoder, 86
dsy_sai_init_from_handle, 224	daisy::Switch, 117
dsy_sai_pin, 223	Process
per_sdmmc.h	daisy::AnalogControl, 45
por_oao	aaiejiii ii aiegeenii ei, ie

l: D	
daisy::Parameter, 101	dev_flash_IS25LP064A.h, 161
Pull	dev_flash_IS25LP080D.h, 177
daisy::Switch, 115	READ_NONVOL_CFG_REG_CMD
pull	dev_flash_IS25LP064A.h, 161
dsy_gpio, 76	dev_flash_IS25LP080D.h, 177
	READ_OTP_ARRAY_CMD
QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD	dev_flash_IS25LP064A.h, 162
dev_flash_IS25LP064A.h, 159	dev flash IS25LP080D.h, 177
dev_flash_IS25LP080D.h, 175	READ READ PARAM REG CMD
QUAD_IN_FAST_PROG_CMD	
	dev_flash_IS25LP064A.h, 162
dev_flash_IS25LP064A.h, 160	dev_flash_IS25LP080D.h, 177
dev_flash_IS25LP080D.h, 175	READ_SERIAL_FLASH_DISCO_PARAM_CMD
QUAD_INOUT_FAST_READ_4_BYTE_ADDR_CMD	, , ,
dev_flash_IS25LP064A.h, 160	dev_flash_IS25LP080D.h, 177
dev_flash_IS25LP080D.h, 175	READ_STATUS_REG_CMD
QUAD_INOUT_FAST_READ_CMD	dev_flash_IS25LP064A.h, 162
dev_flash_IS25LP064A.h, 160	dev flash IS25LP080D.h, 177
dev flash IS25LP080D.h, 175	RESET_ENABLE_CMD
QUAD_INOUT_FAST_READ_DTR_CMD	dev_flash_IS25LP064A.h, 162
dev_flash_IS25LP064A.h, 160	dev flash IS25LP080D.h, 178
dev flash IS25LP080D.h, 175	RESET MEMORY CMD
QUAD_OUT_FAST_READ_4_BYTE_ADDR_CMD	
	dev_flash_IS25LP064A.h, 162
dev_flash_IS25LP064A.h, 160	dev_flash_IS25LP080D.h, 178
dev_flash_IS25LP080D.h, 176	raw_data
QUAD_OUT_FAST_READ_CMD	daisy::WavFileInfo, 127
dev_flash_IS25LP064A.h, 160	Read
dev_flash_IS25LP080D.h, 176	daisy::RingBuffer, 106
QUAD_OUT_FAST_READ_DTR_CMD	daisy::RingBuffer $<$ T, 0 $>$ , 109
dev_flash_IS25LP064A.h, 160	Readable
dev_flash_IS25LP080D.h, 176	daisy::UartHandler, 120
qspi_handle	readable
daisy::DaisySeed, 73	daisy::RingBuffer, 106
	daisy::RingBuffer< T, 0 >, 109
r	· -
codec_frame_t, 46	ReceiveCallback
RAM_AS4C16M16SA_H	daisy::UsbHandle, 122
dev_sdram.h, 183	Red
	daisy::Color, 49
READ_4_BYTE_ADDR_CMD	red
dev_flash_IS25LP064A.h, 160	color, 47
dev_flash_IS25LP080D.h, 176	RelCardAdd
READ_CMD	DSY_SD_CardInfoTypeDef, 82
dev_flash_IS25LP064A.h, 161	Restart
dev_flash_IS25LP080D.h, 176	daisy::WavPlayer, 129
READ_ENHANCED_VOL_CFG_REG_CMD	retSD
dev_flash_IS25LP064A.h, 161	fatfs.h, 190
dev flash IS25LP080D.h, 176	ring led
READ_EXT_ADDR_REG_CMD	<del>-</del>
dev_flash_IS25LP064A.h, 161	daisy::DaisyPetal, 64
dev flash IS25LP080D.h, 176	RingLed
READ_FLAG_STATUS_REG_CMD	daisy::DaisyPetal, 59
	RisingEdge
dev_flash_IS25LP064A.h, 161	daisy::Encoder, 86
dev_flash_IS25LP080D.h, 176	daisy::Switch, 117
READ_ID_CMD2	RxActive
dev_flash_IS25LP064A.h, 161	daisy::UartHandler, 120
dev_flash_IS25LP080D.h, 177	•
READ_ID_CMD	S162F_SCALE
dev_flash_IS25LP064A.h, 161	daisy.h, 132
dev_flash_IS25LP080D.h, 177	s162f
READ LOCK REG CMD	daisy.h, 133
<del>_</del>	-

S242F_SCALE	sai
daisy.h, 133	dsy_audio_handle, 74
s242f	sai1_pin_config
daisy.h, 134	dsy_sai_handle, 80
S24SIGN	sai2_pin_config
daisy.h, 133	dsy_sai_handle, 80
SA_LED_DRIVER_H	sai_handle
dev_leddriver.h, 180	daisy::DaisySeed, 73
SAMPLE_RATE	SampleRate
daisy_field.h, 140	WAV_FormatTypeDef, 125
SD_DATATIMEOUT	samplerate
util_bsp_sd_diskio.h, 238	dsy_sai_handle, 80
SD_NOT_PRESENT	SdmmcBitWidth
util_bsp_sd_diskio.h, 238	per_sdmmc.h, 227
SD PRESENT	SdmmcMode
util_bsp_sd_diskio.h, 238	per_sdmmc.h, 227
SD_TRANSFER_BUSY	SdmmcSpeed
util_bsp_sd_diskio.h, 238	per_sdmmc.h, 227
SD TRANSFER OK	sdram handle
util_bsp_sd_diskio.h, 238	daisy::DaisySeed, 73
SDFatFS	seed
fatfs.h, 190	daisy::DaisyPatch, 57
SDFile	daisy::DaisyPetal, 64
fatfs.h, 190	daisy::DaisyPod, 69
SDPath	daisy::daisy_field, 51
fatfs.h, 190	Set
SECTOR_ERASE_4_BYTE_ADDR_CMD	daisy::Led, 90
dev_flash_IS25LP064A.h, 162	daisy::RgbLed, 103
dev_flash_IS25LP080D.h, 178	ShiftRegister595, 113
SECTOR_ERASE_CMD	SetAudioBlockSize
dev_flash_IS25LP064A.h, 162	daisy::DaisyPatch, 55
dev_flash_IS25LP080D.h, 178	daisy::DaisyPetal, 61
SR_4021_MAX_DAISYCHAIN	daisy::DaisyPod, 67
dev sr 4021.h, 186	daisy::DaisySeed, 71
SR_4021_MAX_PARALLEL	SetColor
dev_sr_4021.h, 186	daisy::RgbLed, 103
SSD1309 HEIGHT	SetCursor
hid_oled_display.h, 205	daisy::OledDisplay, 98
SSD1309_WIDTH	SetFootswitchLed
hid oled display.h, 205	daisy::DaisyPetal, 62
STM32 USB OTG DEVICE LIBRARY, 35	SetLed
SUBSECTOR_ERASE_4_BYTE_ADDR_CMD	daisy::DaisySeed, 71
dev_flash_IS25LP064A.h, 163	SetLooping
dev_flash_IS25LP080D.h, 178	daisy::WavPlayer, 129
SUBSECTOR ERASE CMD	SetReceiveCallback
dev_flash_IS25LP064A.h, 163	daisy::UsbHandle, 123
dev_flash_IS25LP080D.h, 178	SetRingLed
SUBSECTOR ERASE QPI CMD	daisy::DaisyPetal, 62
dev_flash_IS25LP064A.h, 163	SetTestPoint
dev_flash_IS25LP080D.h, 178	daisy::DaisySeed, 71
SW 1 PIN	ShiftRegister595, 112
daisy_field.h, 140	Init, 113
SW 2 PIN	Pins, 112
daisy_field.h, 140	Set, 113
SW_3_PIN	Write, 113
daisy_field.h, 140	speed
sa_audio_callback	daisy::SdmmcHandlerInit, 111
dev_codec_wm8731_frame.h, 148	dsy_i2c_handle, 77
	<b>,</b> <u></u>

SpiPeriph	StartAdc
per_spi.h, 228	daisy::DaisyPatch, 55
SpiPin	daisy::DaisyPetal, 62
per_spi.h, 228	daisy::DaisyPod, 68
src/daisy.h, 131	StartAudio
src/daisy_core.h, 134	daisy::DaisyPatch, 55
src/daisy_field.h, 136	daisy::DaisyPetal, 63
src/daisy_patch.h, 143	daisy::DaisyPod, 68
src/daisy_petal.h, 144	daisy::DaisySeed, 72
src/daisy_pod.h, 144	StartReceive
src/daisy_seed.h, 144	daisy::MidiHandler, 94
src/dev_codec_ak4556.h, 145	StartRx
src/dev_codec_pcm3060.h, 145	daisy::UartHandler, 121
src/dev_codec_wm8731.h, 146	state
src/dev_codec_wm8731_frame.h, 148	dsy_sdram_handle, 83
src/dev_flash_IS25LP064A.h, 148	states
src/dev_flash_IS25LP080D.h, 164	dsy_sr_4021_handle, 84
src/dev_leddriver.h, 180	Stop
src/dev_sdram.h, 182	daisy::AdcHandle, 43
src/dev_sr_4021.h, 185	Stream
src/dev_sr_595.h, 188	daisy::WavPlayer, 129
src/fatfs.h, 189	SubCHunk2Size
src/ffconf.h, 191	WAV_FormatTypeDef, 126
src/hid_audio.h, 198	SubChunk1ID
src/hid_ctrl.h, 202	WAV_FormatTypeDef, 125
src/hid_encoder.h, 203	SubChunk1Size
src/hid_gatein.h, 203	WAV_FormatTypeDef, 126
src/hid_led.h, 203	SubChunk2ID
src/hid_midi.h, 204	WAV_FormatTypeDef, 126
src/hid_oled_display.h, 205	Sw
src/hid_parameter.h, 205	daisy::DaisyPetal, 59
src/hid_rgb_led.h, 206	daisy::DaisyPod, 66 Swallow
src/hid_switch.h, 206	
src/hid_usb.h, 206	daisy::RingBuffer, 106
src/hid_wavplayer.h, 206	switches
src/per_adc.h, 207	daisy::DaisyPetal, 64
src/per_dac.h, 208	daisy::daisy_field, 51
src/per_gpio.h, 210	sync_config dsy_sai_handle, 80
src/per_i2c.h, 213	sys_dma.h
src/per_qspi.h, 216	dsy_dma_init, 232
src/per_sai.h, 221	sys_system.h
src/per_sdmmc.h, 226	dsy_system_delay, 232
src/per_spi.h, 228	dsy_system_getnow, 233
src/per_tim.h, 229	dsy_system_init, 233
src/per_uart.h, 231	dsy system jumpto, 233
src/sys_dma.h, 232	dsy_system_jumptoqspi, 233
src/sys_system.h, 232	doy_dystem_jamptoqopi, 200
src/usbd_cdc_if.h, 234	TimeHeldMs
src/usbd_conf.h, 235	daisy::Encoder, 86
src/usbd_desc.h, 236	daisy::Switch, 118
src/util_bsp_sd_diskio.h, 236	TransmitExternal
src/util_color.h, 242	daisy::UsbHandle, 123
src/util_hal_map.h, 243	TransmitInternal
src/util_ringbuffer.h, 245	daisy::UsbHandle, 123
src/util_unique_id.h, 245	Trig
src/util_wav_format.h, 246	daisy::GateIn, 89
Start	Туре
daisy::AdcHandle, 43	daisy::Switch, 116
daily in table farials, 10	daily Ovvitori, 110

type	USBD_ErrLog
daisy::MidiEvent, 91	USBD_CONF_Exported_Macros, 24
LICE CIZ CTRING CERIAL	USBD_Interface_fops_FS
USB_SIZ_STRING_SERIAL	USBD_CDC_IF_Exported_Variables, 18
USBD_DESC_Exported_Constants, 29 USBD_CDC_IF_Exported_Defines, 15	USBD_Interface_fops_HS
USBD_CDC_IF_Exported_Defines, 15 USBD_CDC_IF_Exported_FunctionsPrototype, 19	USBD_CDC_IF_Exported_Variables, 18
	USBD_LPM_ENABLED
CDC_Set_Rx_Callback_FS, 19	USBD_CONF_Exported_Defines, 22
CDC_Transmit_FS, 19 CDC_Transmit_HS, 19	USBD_MAX_NUM_CONFIGURATION
	USBD_CONF_Exported_Defines, 23
USBD_CDC_IF_Exported_Macros, 17 USBD_CDC_IF_Exported_Types, 16	USBD_MAX_NUM_INTERFACES
	USBD_CONF_Exported_Defines, 23
CDC_ReceiveCallback, 16 USBD_CDC_IF_Exported_Variables, 18	USBD_MAX_STR_DESC_SIZ
USBD_Interface_fops_FS, 18	USBD_CONF_Exported_Defines, 23
	USBD_OTG_DRIVER, 36
USBD_Interface_fops_HS, 18	USBD_SELF_POWERED
USBD_CDC_IF, 14	USBD_CONF_Exported_Defines, 23
USBD_CONF_Exported_Defines, 22 DEVICE_FS, 22	USBD_SUPPORT_USER_STRING
	USBD_CONF_Exported_Defines, 23
DEVICE_HS, 22	USBD_UsrLog
USBD_DEBUG_LEVEL, 22	USBD_CONF_Exported_Macros, 25
USBD_LPM_ENABLED, 22	USBD_free
USBD_MAX_NUM_CONFIGURATION, 23 USBD_MAX_NUM_INTERFACES, 23	USBD_CONF_Exported_Macros, 25
	USBD_malloc
USBD_MAX_STR_DESC_SIZ, 23	USBD_CONF_Exported_Macros, 25
USBD_SELF_POWERED, 23 USBD_SUPPORT_USER_STRING, 23	USBD_memcpy
USBD_CONF_Exported_FunctionsPrototype, 27	USBD_CONF_Exported_Macros, 25
	USBD_memset
USBD_CONF_Exported_Macros, 24	USBD_CONF_Exported_Macros, 25
USBD_DbgLog, 24	Update
USBD_Delay, 24	daisy::Led, 90
USBD_ErrLog, 24 USBD_UsrLog, 25	daisy::OledDisplay, 99
USBD_free, 25	daisy::RgbLed, 103
USBD_malloc, 25	UpdateAnalogControls
USBD_memcpy, 25	daisy::DaisyPatch, 56
USBD_memset, 25	daisy::DaisyPetal, 63
	daisy::DaisyPod, 68
USBD_CONF_Exported_Types, 26 USBD_CONF_Exported_Variables, 21	UpdateLeds
USBD_CONF, 20	daisy::DaisyPetal, 63
USBD_DEBUG_LEVEL	daisy::DaisyPod, 68
USBD CONF Exported Defines, 22	usb handle
USBD_DESC_Exported_Constants, 29	daisy::DaisySeed, 73
DEVICE_ID1, 29	UsbPeriph
DEVICE_ID2, 29	daisy::UsbHandle, 122
DEVICE_ID3, 29	util_bsp_sd_diskio.h
USB_SIZ_STRING_SERIAL, 29	BSP SD AbortCallback, 239
USBD_DESC_Exported_Defines, 30	BSP_SD_CardInfo, 237
USBD DESC Exported FunctionsPrototype, 34	BSP_SD_Erase, 239
USBD_DESC_Exported_Macros, 32	BSP_SD_GetCardInfo, 239
USBD_DESC_Exported_TypesDefinitions, 31	BSP_SD_GetCardState, 239
USBD_DESC_Exported_Variables, 33	BSP_SD_ITConfig, 240
FS_Desc, 33	BSP_SD_Init, 240
HS_Desc, 33	BSP_SD_IsDetected, 240
USBD_DESC, 28	BSP SD ReadBlocks, 240
USBD_DbgLog	BSP_SD_ReadBlocks_DMA, 241
USBD_CONF_Exported_Macros, 24	BSP_SD_ReadCpltCallback, 241
USBD_Delay	BSP SD WriteBlocks, 241
USBD_CONF_Exported_Macros, 24	BSP_SD_WriteBlocks_DMA, 242
OODD_OOM _Exported_Macros, 24	DOI _OD_VVIILEDIUUN3_DIVIA, 242

DOD OD W. : O I:O III   1 040	WDITE LOOK DEG OMD
BSP_SD_WriteCpltCallback, 242	WRITE_LOCK_REG_CMD
DSY_BSP_SD_DISKIO_H, 237	dev_flash_IS25LP064A.h, 163
MSD_ERROR_SD_NOT_PRESENT, 238	dev_flash_IS25LP080D.h, 179
MSD_ERROR, 237	WRITE_NONVOL_CFG_REG_CMD
MSD_OK, 238	dev_flash_IS25LP064A.h, 164
SD_DATATIMEOUT, 238	dev_flash_IS25LP080D.h, 179
SD_NOT_PRESENT, 238	WRITE_READ_PARAM_REG_CMD
SD_PRESENT, 238	dev_flash_IS25LP064A.h, 164
SD_TRANSFER_BUSY, 238	dev_flash_IS25LP080D.h, 179
SD_TRANSFER_OK, 238	WRITE_STATUS_REG_CMD
util_color.h	dev flash IS25LP064A.h, 164
DSY_COLOR_H, 243	dev_flash_IS25LP080D.h, 179
util_hal_map.h	writable
dsy_hal_map_get_i2c, 243	daisy::RingBuffer, 107
dsy_hal_map_get_pin, 244	daisy::RingBuffer $<$ T, 0 $>$ , 110
dsy_hal_map_get_port, 244	Write
hi2c1, 244	daisy::RingBuffer, 107
hi2c2, 244	daisy::RingBuffer $<$ T, 0 $>$ , 110
hi2c3, 245	ShiftRegister595, 113
hi2c4, 245	WriteChar
util unique id.h	daisy::OledDisplay, 99
dsy_get_unique_id, 245	WriteString
dsy_get_unique_id, 245	daisy::OledDisplay, 99
Value	daisyOledbisplay, 99
daisy::AnalogControl, 45	
daisy::Parameter, 102	
value	
daisy::ControlChangeEvent, 50	
velocity	
daisy::NoteOnEvent, 95	
daisyvoteOnEvent, 33	
WAV_FILENAME_MAX	
hid_wavplayer.h, 207	
WAV_FormatTypeDef, 124	
AudioFormat, 124	
BitPerSample, 124	
BlockAlign, 125	
ByteRate, 125	
Chunkld, 125	
FileFormat, 125	
FileSize, 125	
NbrChannels, 125	
SampleRate, 125	
SubCHunk2Size, 126	
SubChunk1ID, 125	
SubChunk1Size, 126	
SubChunk2ID, 126	
WRITE_DISABLE_CMD	
dev_flash_IS25LP064A.h, 163	
dev_flash_IS25LP080D.h, 178	
WRITE_ENABLE_CMD	
dev_flash_IS25LP064A.h, 163	
dev_flash_IS25LP080D.h, 179	
WRITE_ENHANCED_VOL_CFG_REG_CMD	
dev_flash_IS25LP064A.h, 163	
dev_flash_IS25LP080D.h, 179	
WRITE_EXT_ADDR_REG_CMD	
dev_flash_IS25LP064A.h, 163	
dev_flash_IS25LP080D.h, 179	