libDaisy

Generated by Doxygen 1.8.13

Contents

1	libda	isy	1
	1.1	Using libdaisy	1
		1.1.1 daisy.h	2
		1.1.2 daisy_seed.h	2
		1.1.3 daisy_platform.h	2
2	Mod	ule Index	3
	2.1	Modules	3
3	Clas	s Index	5
	3.1	Class List	5
4	File	ndex	7
	4.1	File List	7
5	Mod	ule Documentation	9
	5.1	USBD_CDC_IF	9
		5.1.1 Detailed Description	9
	5.2	USBD_CDC_IF_Exported_Defines	10
	5.3	USBD_CDC_IF_Exported_Types	11
		5.3.1 Detailed Description	11
		5.3.2 Typedef Documentation	11
		5.3.2.1 CDC_ReceiveCallback	11
	5.4	USBD_CDC_IF_Exported_Macros	12
	5.5	USBD_CDC_IF_Exported_Variables	13

ii CONTENTS

	5.5.1	Detailed Description	13
	5.5.2	Variable Documentation	13
		5.5.2.1 USBD_Interface_fops_FS	13
		5.5.2.2 USBD_Interface_fops_HS	13
5.6	USBD_	_CDC_IF_Exported_FunctionsPrototype	14
	5.6.1	Detailed Description	14
	5.6.2	Function Documentation	14
		5.6.2.1 CDC_Set_Rx_Callback_FS()	14
		5.6.2.2 CDC_Transmit_FS()	14
		5.6.2.3 CDC_Transmit_HS()	14
5.7	USBD_	_CONF	15
	5.7.1	Detailed Description	15
5.8	USBD_	_CONF_Exported_Variables	16
5.9	USBD_	_CONF_Exported_Defines	17
	5.9.1	Detailed Description	17
	5.9.2	Macro Definition Documentation	17
		5.9.2.1 DEVICE_FS	17
		5.9.2.2 DEVICE_HS	17
		5.9.2.3 USBD_DEBUG_LEVEL	17
		5.9.2.4 USBD_LPM_ENABLED	18
		5.9.2.5 USBD_MAX_NUM_CONFIGURATION	18
		5.9.2.6 USBD_MAX_NUM_INTERFACES	18
		5.9.2.7 USBD_MAX_STR_DESC_SIZ	18
		5.9.2.8 USBD_SELF_POWERED	18
		5.9.2.9 USBD_SUPPORT_USER_STRING	18
5.10	USBD_	_CONF_Exported_Macros	19
	5.10.1	Detailed Description	19
	5.10.2	Macro Definition Documentation	19
		5.10.2.1 USBD_DbgLog	19
		5.10.2.2 USBD_Delay	19

5.10.2.3 USBD_ErrLog	20
5.10.2.4 USBD_free	20
5.10.2.5 USBD_malloc	20
5.10.2.6 USBD_memcpy	20
5.10.2.7 USBD_memset	20
5.10.2.8 USBD_UsrLog	20
5.11 USBD_CONF_Exported_Types	21
5.12 USBD_CONF_Exported_FunctionsPrototype	22
5.13 USBD_DESC	23
5.13.1 Detailed Description	23
5.14 USBD_DESC_Exported_Constants	24
5.14.1 Detailed Description	24
5.14.2 Macro Definition Documentation	24
5.14.2.1 DEVICE_ID1	24
5.14.2.2 DEVICE_ID2	24
5.14.2.3 DEVICE_ID3	24
5.14.2.4 USB_SIZ_STRING_SERIAL	24
5.15 USBD_DESC_Exported_Defines	25
5.16 USBD_DESC_Exported_TypesDefinitions	26
5.17 USBD_DESC_Exported_Macros	27
5.18 USBD_DESC_Exported_Variables	28
5.18.1 Detailed Description	28
5.18.2 Variable Documentation	28
5.18.2.1 FS_Desc	28
5.18.2.2 HS_Desc	28
5.19 USBD_DESC_Exported_FunctionsPrototype	29
5.20 STM32_USB_OTG_DEVICE_LIBRARY	30
5.20.1 Detailed Description	30
5.21 USBD_OTG_DRIVER	31
5.21.1 Detailed Description	31

iv CONTENTS

6	Clas	s Docu	mentation	33
	6.1	daisy::	AdcChannelConfig Struct Reference	33
		6.1.1	Detailed Description	33
		6.1.2	Member Enumeration Documentation	33
			6.1.2.1 MuxPin	33
		6.1.3	Member Function Documentation	34
			6.1.3.1 InitMux()	34
			6.1.3.2 InitSingle()	34
		6.1.4	Member Data Documentation	35
			6.1.4.1 mux_channels	35
			6.1.4.2 mux_pin	35
			6.1.4.3 pin	35
	6.2	daisy::	AdcHandle Class Reference	35
		6.2.1	Detailed Description	36
		6.2.2	Member Enumeration Documentation	36
			6.2.2.1 OverSampling	36
		6.2.3	Member Function Documentation	36
			6.2.3.1 Get()	36
			6.2.3.2 GetFloat()	37
			6.2.3.3 GetMux()	37
			6.2.3.4 GetMuxFloat()	37
			6.2.3.5 GetMuxPtr()	38
			6.2.3.6 GetPtr()	38
			6.2.3.7 Init()	39
			6.2.3.8 Start()	39
			6.2.3.9 Stop()	39
	6.3	daisy::	AnalogControl Class Reference	39
		6.3.1	Detailed Description	40
		6.3.2	Constructor & Destructor Documentation	40
			6.3.2.1 AnalogControl()	40

		6.3.2.2 ~AnalogControl()	 	 	 	40
	6.3.3	Member Function Documentation .	 	 	 	40
		6.3.3.1 Init()	 	 	 	40
		6.3.3.2 InitBipolarCv()	 	 	 	41
		6.3.3.3 Process()	 	 	 	41
		6.3.3.4 Value()	 	 	 	41
6.4	codec_	_frame_t Struct Reference	 	 	 	41
	6.4.1	Detailed Description	 	 	 	42
	6.4.2	Member Data Documentation	 	 	 	42
		6.4.2.1 I	 	 	 	42
		6.4.2.2 r	 	 	 	42
6.5	color S	truct Reference	 	 	 	42
	6.5.1	Detailed Description	 	 	 	42
	6.5.2	Member Data Documentation	 	 	 	43
		6.5.2.1 blue	 	 	 	43
		6.5.2.2 green	 	 	 	43
		6.5.2.3 red	 	 	 	43
6.6	daisy::	Color Class Reference	 	 	 	43
	6.6.1	Detailed Description	 	 	 	44
	6.6.2	Member Enumeration Documentation	 	 	 	44
		6.6.2.1 PresetColor	 	 	 	44
	6.6.3	Member Function Documentation .	 	 	 	44
		6.6.3.1 Blue()	 	 	 	44
		6.6.3.2 Green()	 	 	 	44
		6.6.3.3 Init() [1/2]	 	 	 	44
		6.6.3.4 Init() [2/2]	 	 	 	45
		6.6.3.5 Red()	 	 	 	45
6.7	daisy::	ControlChangeEvent Struct Reference	 	 	 	45
	6.7.1	Detailed Description	 	 	 	45
	6.7.2	Member Data Documentation	 	 	 	46

vi

		6.7.2.1	channel	 46
		6.7.2.2	control_number	 46
		6.7.2.3	value	 46
6.8	daisy::	daisy_field	d Struct Reference	 46
	6.8.1	Detailed	Description	 46
	6.8.2	Member	Data Documentation	 47
		6.8.2.1	cvs	 47
		6.8.2.2	gate_in	 47
		6.8.2.3	gate_out	 47
		6.8.2.4	keyboard_sr	 47
		6.8.2.5	knobs	 47
		6.8.2.6	seed	 47
		6.8.2.7	switches	 47
6.9	daisy::	DaisyPatc	ch Class Reference	 48
	6.9.1	Detailed	Description	 48
	6.9.2	Member	Enumeration Documentation	 49
		6.9.2.1	Ctrl	 49
		6.9.2.2	GateInput	 49
	6.9.3	Construc	ctor & Destructor Documentation	 49
		6.9.3.1	DaisyPatch()	 49
		6.9.3.2	~DaisyPatch()	 49
	6.9.4	Member	Function Documentation	 49
		6.9.4.1	AudioBlockSize()	 49
		6.9.4.2	AudioCallbackRate()	 50
		6.9.4.3	AudioSampleRate()	 50
		6.9.4.4	ChangeAudioCallback()	 50
		6.9.4.5	DebounceControls()	 50
		6.9.4.6	DelayMs()	 50
		6.9.4.7	DisplayControls()	 50
		6.9.4.8	GetCtrlValue()	 51

CONTENTS vii

		6.9.4.9	Init()	51
		6.9.4.10	SetAudioBlockSize()	51
		6.9.4.11	StartAdc()	51
		6.9.4.12	StartAudio()	51
		6.9.4.13	UpdateAnalogControls()	52
	6.9.5	Member	Data Documentation	52
		6.9.5.1	controls	52
		6.9.5.2	display	52
		6.9.5.3	encoder	52
		6.9.5.4	gate_input	52
		6.9.5.5	gate_output	52
		6.9.5.6	midi	53
		6.9.5.7	seed	53
6.10	daisy::[DaisyPetal	Class Reference	53
	6.10.1	Detailed	Description	54
	6.10.2	Member	Enumeration Documentation	54
		6.10.2.1	FootswitchLed	54
		6.10.2.2	Knob	54
		6.10.2.3	RingLed	55
		6.10.2.4	Sw	55
	6.10.3	Construc	tor & Destructor Documentation	55
		6.10.3.1	DaisyPetal()	55
		6.10.3.2	~DaisyPetal()	56
	6.10.4	Member	Function Documentation	56
		6.10.4.1	AudioBlockSize()	56
		6.10.4.2	AudioCallbackRate()	56
		6.10.4.3	AudioSampleRate()	56
		6.10.4.4	ChangeAudioCallback()	56
		6.10.4.5	ClearLeds()	56
		6.10.4.6	DebounceControls()	57

viii CONTENTS

		6.10.4.7	DelayMs()	 . 57
		6.10.4.8	GetExpression()	 . 57
		6.10.4.9	GetKnobValue()	 . 57
		6.10.4.10	Init()	 . 57
		6.10.4.11	SetAudioBlockSize()	 . 58
		6.10.4.12	SetFootswitchLed()	 . 58
		6.10.4.13	SetRingLed()	 . 58
		6.10.4.14	StartAdc()	 . 59
		6.10.4.15	StartAudio()	 . 59
		6.10.4.16	UpdateAnalogControls()	 . 59
		6.10.4.17	UpdateLeds()	 . 59
	6.10.5	Member E	Data Documentation	 . 59
		6.10.5.1	encoder	 . 59
		6.10.5.2	expression	 . 59
		6.10.5.3	footswitch_led	 . 60
		6.10.5.4	knob	 . 60
		6.10.5.5	ring_led	 . 60
		6.10.5.6	seed	 . 60
		6.10.5.7	switches	 . 60
6.11	daisy::[DaisyPod C	Class Reference	 . 60
	6.11.1	Detailed D	Description	 . 61
	6.11.2	Member E	Enumeration Documentation	 . 61
		6.11.2.1	Knob	 . 61
		6.11.2.2	Sw	 . 62
	6.11.3	Member F	Function Documentation	 . 62
		6.11.3.1	AudioBlockSize()	 . 62
		6.11.3.2	AudioCallbackRate()	 . 62
		6.11.3.3	AudioSampleRate()	 . 62
		6.11.3.4	ChangeAudioCallback()	 . 62
		6.11.3.5	ClearLeds()	 . 63

		6.11.3.6	DebounceContro	ls()	 	 	 	 	63
		6.11.3.7	DelayMs()		 	 	 	 	63
		6.11.3.8	GetKnobValue()		 	 	 	 	63
		6.11.3.9	Init()		 	 	 	 	63
		6.11.3.10	SetAudioBlockSi:	ze()	 	 	 	 	63
		6.11.3.11	StartAdc()		 	 	 	 	64
		6.11.3.12	StartAudio()		 	 	 	 	64
		6.11.3.13	UpdateAnalogCo	ntrols() .	 	 	 	 	64
		6.11.3.14	UpdateLeds() .		 	 	 	 	64
	6.11.4	Member D	ata Documentati	on	 	 	 	 	64
		6.11.4.1	outton1		 	 	 	 	64
		6.11.4.2	outton2		 	 	 	 	65
		6.11.4.3	outtons		 	 	 	 	65
		6.11.4.4	encoder		 	 	 	 	65
		6.11.4.5	knob1		 	 	 	 	65
		6.11.4.6	knob2		 	 	 	 	65
		6.11.4.7	knobs		 	 	 	 	65
		6.11.4.8	ed1		 	 	 	 	65
		6.11.4.9	ed2		 	 	 	 	65
		6.11.4.10	seed		 	 	 	 	66
6.12	daisy::[DaisySeed	Class Reference		 	 	 	 	66
	6.12.1	Detailed D	escription		 	 	 	 	66
	6.12.2	Member F	unction Documer	ntation .	 	 	 	 	66
		6.12.2.1	AudioSampleRat	e()	 	 	 	 	67
		6.12.2.2	Configure()		 	 	 	 	67
		6.12.2.3	GetPin()		 	 	 	 	67
		6.12.2.4	Init()		 	 	 	 	67
		6.12.2.5	SetAudioBlockSi:	ze()	 	 	 	 	67
		6.12.2.6	SetLed()		 	 	 	 	67
		6.12.2.7	SetTestPoint() .		 	 	 	 	68

	6.12.2.8	StartAudio()		 	 	 	 	 68
6.1	2.3 Member	Data Document	ation	 	 	 	 	 68
	6.12.3.1	adc		 	 	 	 	 68
	6.12.3.2	audio_handle		 	 	 	 	 68
	6.12.3.3	dac_handle .		 	 	 	 	 68
	6.12.3.4	i2c1_handle		 	 	 	 	 68
	6.12.3.5	i2c2_handle		 	 	 	 	 69
	6.12.3.6	qspi_handle		 	 	 	 	 69
	6.12.3.7	sai_handle .		 	 	 	 	 69
	6.12.3.8	sdram_handle		 	 	 	 	 69
	6.12.3.9	usb_handle .		 	 	 	 	 69
6.13 dsy	_audio_hand	le Struct Refere	nce	 	 	 	 	 69
6.1	3.1 Detailed	Description .		 	 	 	 	 70
6.1	3.2 Member	Data Document	ation	 	 	 	 	 70
	6.13.2.1	block_size .		 	 	 	 	 70
	6.13.2.2	dev0_i2c		 	 	 	 	 70
	6.13.2.3	dev1_i2c		 	 	 	 	 70
	6.13.2.4	sai		 	 	 	 	 70
6.14 dsy	_dac_handle	Struct Reference	е	 	 	 	 	 70
6.1	4.1 Detailed	Description .		 	 	 	 	 71
6.1	4.2 Member	Data Document	ation	 	 	 	 	 71
	6.14.2.1	bitdepth		 	 	 	 	 71
	6.14.2.2	mode		 	 	 	 	 71
	6.14.2.3	pin_config .		 	 	 	 	 71
6.15 dsy	_gpio Struct I	Reference		 	 	 	 	 71
6.1	5.1 Detailed	Description .		 	 	 	 	 71
6.1	5.2 Member	Data Document	ation	 	 	 	 	 72
	6.15.2.1	mode		 	 	 	 	 72
	6.15.2.2	pin		 	 	 	 	 72
	6.15.2.3	pull		 	 	 	 	 72

CONTENTS xi

6.16 dsy_gpio_pin Struct Reference	72
6.16.1 Detailed Description	72
6.16.2 Member Data Documentation	72
6.16.2.1 pin	73
6.16.2.2 port	73
6.17 dsy_i2c_handle Struct Reference	73
6.17.1 Detailed Description	73
6.17.2 Member Data Documentation	73
6.17.2.1 periph	73
6.17.2.2 pin_config	73
6.17.2.3 speed	74
6.18 dsy_qspi_handle Struct Reference	74
6.18.1 Detailed Description	74
6.18.2 Member Data Documentation	74
6.18.2.1 device	74
6.18.2.2 mode	74
6.18.2.3 pin_config	75
6.19 dsy_sai_handle Struct Reference	75
6.19.1 Detailed Description	75
6.19.2 Member Data Documentation	75
6.19.2.1 a_direction	75
6.19.2.2 b_direction	75
6.19.2.3 bitdepth	76
6.19.2.4 device	76
6.19.2.5 init	76
6.19.2.6 sai1_pin_config	76
6.19.2.7 sai2_pin_config	76
6.19.2.8 samplerate	76
6.19.2.9 sync_config	76
6.20 DSY_SD_CardInfoTypeDef Struct Reference	77

xii CONTENTS

	6.20.1	Detailed Description	77
	6.20.2	Member Data Documentation	77
		6.20.2.1 BlockNbr	77
		6.20.2.2 BlockSize	77
		6.20.2.3 CardSpeed	77
		6.20.2.4 CardType	78
		6.20.2.5 CardVersion	78
		6.20.2.6 Class	78
		6.20.2.7 LogBlockNbr	78
		6.20.2.8 LogBlockSize	78
		6.20.2.9 RelCardAdd	78
6.21	dsy_sd	am_handle Struct Reference	78
	6.21.1	Detailed Description	79
	6.21.2	Member Data Documentation	79
		6.21.2.1 pin_config	79
		6.21.2.2 state	79
6.22	dsy_sr_	4021_handle Struct Reference	79
	6.22.1	Detailed Description	80
	6.22.2	Member Data Documentation	80
		6.22.2.1 clk	80
		6.22.2.2 cs	80
		6.22.2.3 data	80
		6.22.2.4 num_daisychained	80
		6.22.2.5 num_parallel	80
		6.22.2.6 pin_config	80
		6.22.2.7 states	81
6.23	daisy::E	ncoder Class Reference	81
	6.23.1	Detailed Description	81
	6.23.2	Member Function Documentation	81
		6.23.2.1 Debounce()	82

CONTENTS xiii

6.23.2.2 FallingEdge()	 82
6.23.2.3 Increment()	 82
6.23.2.4 Init()	 82
6.23.2.5 Pressed()	 82
6.23.2.6 RisingEdge()	 82
6.23.2.7 TimeHeldMs()	 82
6.24 FontDef Struct Reference	 83
6.24.1 Detailed Description	 83
6.24.2 Member Data Documentation	 83
6.24.2.1 data	 83
6.24.2.2 FontHeight	 83
6.24.2.3 FontWidth	 83
6.25 daisy::GateIn Class Reference	 84
6.25.1 Detailed Description	 84
6.25.2 Constructor & Destructor Documentation	 84
6.25.2.1 GateIn()	 84
6.25.2.2 ~GateIn()	 84
6.25.3 Member Function Documentation	 84
6.25.3.1 Init()	 85
6.25.3.2 Trig()	 85
6.26 daisy::Led Class Reference	 85
6.26.1 Detailed Description	 85
6.26.2 Member Function Documentation	 85
6.26.2.1 Init()	 85
6.26.2.2 Set()	 86
6.26.2.3 Update()	 86
6.27 daisy::MidiEvent Struct Reference	 86
6.27.1 Detailed Description	 87
6.27.2 Member Function Documentation	 87
6.27.2.1 AsControlChange()	 87

xiv CONTENTS

		6.27.2.2 AsNoteOn()	87
	6.27.3	Member Data Documentation	87
		6.27.3.1 channel	87
		6.27.3.2 data	87
		6.27.3.3 type	87
6.28	daisy::N	MidiHandler Class Reference	88
	6.28.1	Detailed Description	88
	6.28.2	Member Enumeration Documentation	88
		6.28.2.1 MidiInputMode	88
		6.28.2.2 MidiOutputMode	89
	6.28.3	Member Function Documentation	89
		6.28.3.1 HasEvents()	89
		6.28.3.2 Init()	89
		6.28.3.3 Listen()	90
		6.28.3.4 Parse()	90
		6.28.3.5 PopEvent()	90
		6.28.3.6 StartReceive()	90
6.29	daisy::	NoteOnEvent Struct Reference	91
	6.29.1	Detailed Description	91
	6.29.2	Member Data Documentation	91
		6.29.2.1 channel	91
		6.29.2.2 note	91
		6.29.2.3 velocity	91
6.30	daisy::0	OledDisplay Class Reference	91
	6.30.1	Detailed Description	92
	6.30.2	Member Enumeration Documentation	92
		6.30.2.1 Pins	92
	6.30.3	Member Function Documentation	92
		6.30.3.1 DrawPixel()	92
		6.30.3.2 Fill()	94

CONTENTS xv

		6.30.3.3 Init()	94
		6.30.3.4 SetCursor()	94
		6.30.3.5 Update()	95
		6.30.3.6 WriteChar()	95
		6.30.3.7 WriteString()	95
6.31	daisy::I	Parameter Class Reference	96
	6.31.1	Detailed Description	96
	6.31.2	Member Enumeration Documentation	96
		6.31.2.1 Curve	96
	6.31.3	Constructor & Destructor Documentation	97
		6.31.3.1 Parameter()	97
		6.31.3.2 ~Parameter()	97
	6.31.4	Member Function Documentation	97
		6.31.4.1 Init()	97
		6.31.4.2 Process()	97
		6.31.4.3 Value()	98
6.32	daisy::I	RgbLed Class Reference	98
	6.32.1	Detailed Description	98
	6.32.2	Member Function Documentation	98
		6.32.2.1 Init()	98
		6.32.2.2 Set()	99
		6.32.2.3 SetColor()	99
		6.32.2.4 Update()	99
6.33	daisy::I	RingBuffer< T, size > Class Template Reference	100
	6.33.1	Detailed Description	100
	6.33.2	Member Function Documentation	100
		6.33.2.1 capacity()	100
		6.33.2.2 Flush()	100
		6.33.2.3 ImmediateRead() [1/2]	101
		6.33.2.4 ImmediateRead() [2/2]	101

xvi CONTENTS

	6.33.2.5 Init())1
	6.33.2.6 Overwrite() [1/2])1
	6.33.2.7 Overwrite() [2/2])2
	6.33.2.8 Read())2
	6.33.2.9 readable())2
	6.33.2.10 Swallow())2
	6.33.2.11 writable())3
	6.33.2.12 Write())3
6.34 daisy::	RingBuffer< T, 0 > Class Template Reference)3
6.34.1	Detailed Description)4
6.34.2	Member Function Documentation)4
	6.34.2.1 capacity())4
	6.34.2.2 Flush())4
	6.34.2.3 ImmediateRead() [1/2])4
	6.34.2.4 ImmediateRead() [2/2])4
	6.34.2.5 Init())5
	6.34.2.6 Overwrite() [1/2])5
	6.34.2.7 Overwrite() [2/2])5
	6.34.2.8 Read())5
	6.34.2.9 readable())6
	6.34.2.10 writable())6
	6.34.2.11 Write())6
6.35 daisy::	SdmmcHandler Class Reference)6
6.35.1	Detailed Description)7
6.35.2	Member Function Documentation)7
	6.35.2.1 Init())7
6.36 daisy::	SdmmcHandlerInit Struct Reference)7
6.36.1	Detailed Description)7
6.36.2	Member Data Documentation)7
	6.36.2.1 bitdepth)7

CONTENTS xvii

		6.36.2.2 speed	38
6.37	ShiftRe	gister595 Class Reference	38
	6.37.1	Detailed Description	38
	6.37.2	Member Enumeration Documentation	38
		6.37.2.1 Pins	38
	6.37.3	Member Function Documentation	ງ9
		6.37.3.1 Init()	ງ9
		6.37.3.2 Set())9
		6.37.3.3 Write())9
6.38	daisy::S	piHandle Class Reference	10
	6.38.1	Detailed Description	10
	6.38.2	Member Function Documentation	10
		6.38.2.1 BlockingTransmit()	10
		6.38.2.2 Init()	10
6.39	daisy::S	witch Class Reference	10
	6.39.1	Detailed Description	11
	6.39.2	Member Enumeration Documentation	11
		6.39.2.1 Polarity	11
		6.39.2.2 Pull	12
		6.39.2.3 Type	12
	6.39.3	Member Function Documentation	12
		6.39.3.1 Debounce()	12
		6.39.3.2 FallingEdge()	12
		6.39.3.3 Init() [1/2]	13
		6.39.3.4 Init() [2/2]	13
		6.39.3.5 Pressed()	13
		6.39.3.6 RisingEdge()	14
		6.39.3.7 TimeHeldMs()	14
6.40	daisy::l	artHandler Class Reference	14
	6.40.1	Detailed Description	14

xviii CONTENTS

	6.40.2	Member Function Documentation
		6.40.2.1 CheckError()
		6.40.2.2 FlushRx()
		5.40.2.3 Init()
		6.40.2.4 PollReceive()
		6.40.2.5 PollTx()
		6.40.2.6 PopRx()
		5.40.2.7 Readable()
		6.40.2.8 RxActive()
		6.40.2.9 StartRx()
6.41	daisy::l	sbHandle Class Reference
	6.41.1	Detailed Description
	6.41.2	Member Typedef Documentation
		6.41.2.1 ReceiveCallback
	6.41.3	Member Enumeration Documentation
		6.41.3.1 UsbPeriph
	6.41.4	Member Function Documentation
		6.41.4.1 Init()
		6.41.4.2 SetReceiveCallback()
		6.41.4.3 TransmitExternal()
		6.41.4.4 TransmitInternal()
6.42	WAV_F	ormatTypeDef Struct Reference
	6.42.1	Detailed Description
	6.42.2	Member Data Documentation
		6.42.2.1 AudioFormat
		6.42.2.2 BitPerSample
		6.42.2.3 BlockAlign
		5.42.2.4 ByteRate
		3.42.2.5 Chunkld
		5.42.2.6 FileFormat

CONTENTS xix

	6.42.2.7 FileSize
	6.42.2.8 NbrChannels
	6.42.2.9 SampleRate
	6.42.2.10 SubChunk1ID
	6.42.2.11 SubChunk1Size
	6.42.2.12 SubChunk2ID
	6.42.2.13 SubCHunk2Size
6.43 daisy::	WavFileInfo Struct Reference
6.43.1	Detailed Description
6.43.2	Member Data Documentation
	6.43.2.1 name
	6.43.2.2 raw_data
6.44 daisy::	WavPlayer Class Reference
6.44.1	Detailed Description
6.44.2	Member Function Documentation
	6.44.2.1 Close()
	6.44.2.2 GetCurrentFile()
	6.44.2.3 GetLooping()
	6.44.2.4 GetNumberFiles()
	6.44.2.5 Init()
	6.44.2.6 Open()
	6.44.2.7 Prepare()
	6.44.2.8 Restart()
	6.44.2.9 SetLooping()
	6.44.2.10 Stream()

7	File	Docum	entation		127
	7.1	src/dai	sy.h File R	reference	127
		7.1.1	Macro De	efinition Documentation	128
			7.1.1.1	F2S16_SCALE	128
			7.1.1.2	F2S24_SCALE	128
			7.1.1.3	FBIPMAX	128
			7.1.1.4	FBIPMIN	128
			7.1.1.5	S162F_SCALE	129
			7.1.1.6	S242F_SCALE	129
			7.1.1.7	S24SIGN	129
		7.1.2	Function	Documentation	129
			7.1.2.1	f2s16()	129
			7.1.2.2	f2s24()	129
			7.1.2.3	s162f()	129
			7.1.2.4	s242f()	130
	7.2	src/dai	sy_core.h	File Reference	130
		7.2.1	Macro De	efinition Documentation	131
			7.2.1.1	DMA_BUFFER_MEM_SECTION	131
			7.2.1.2	DSY_CORE_HW_H	131
			7.2.1.3	DTCM_MEM_SECTION	131
		7.2.2	Enumera	tion Type Documentation	131
			7.2.2.1	dsy_gpio_port	131
		7.2.3	Function	Documentation	132
			7.2.3.1	cube()	132
			7.2.3.2	dsy_pin()	132
			7.2.3.3	dsy_pin_cmp()	132
	7.3	src/dai	sy_field.h	File Reference	132
		7.3.1	Detailed	Description	134
		7.3.2	Macro De	efinition Documentation	134
			7.3.2.1	CV1_ADC_PIN	134

CONTENTS xxi

		7.3.2.2	CV2_ADC_PIN	134
		7.3.2.3	CV3_ADC_PIN	134
		7.3.2.4	CV4_ADC_PIN	134
		7.3.2.5	DSY_FIELD_BSP_H	134
		7.3.2.6	GATE_IN_PIN	134
		7.3.2.7	GATE_OUT_PIN	135
		7.3.2.8	KB_SW_SR_CLK_PIN	135
		7.3.2.9	KB_SW_SR_CS_PIN	135
		7.3.2.10	KB_SW_SR_D1_PIN	135
		7.3.2.11	KB_SW_SR_D2_PIN	135
		7.3.2.12	LED_DRIVER_I2C	135
		7.3.2.13	MIDI_IN_PIN	135
		7.3.2.14	MIDI_OUT_PIN	135
		7.3.2.15	MUX_ADC_PIN	136
		7.3.2.16	MUX_SEL_0_PIN	136
		7.3.2.17	MUX_SEL_1_PIN	136
		7.3.2.18	MUX_SEL_2_PIN	136
		7.3.2.19	SAMPLE_RATE	136
		7.3.2.20	SW_1_PIN	136
		7.3.2.21	SW_2_PIN	136
		7.3.2.22	SW_3_PIN	136
	7.3.3	Enumera	tion Type Documentation	136
		7.3.3.1	anonymous enum	136
		7.3.3.2	anonymous enum	137
		7.3.3.3	anonymous enum	137
		7.3.3.4	anonymous enum	137
	7.3.4	Function	Documentation	138
		7.3.4.1	daisy_field_init()	138
7.4	src/dai:	sy_patch.h	File Reference	139
7.5	src/dai:	sy_petal.h	File Reference	140

xxii CONTENTS

	7.5.1	Macro Definition Documentation	10
		7.5.1.1 DSY_PETAL_H	10
7.6	src/dais	sy_pod.h File Reference	10
7.7	src/dais	sy_seed.h File Reference	10
7.8	src/dev	v_codec_ak4556.h File Reference	11
	7.8.1	Detailed Description	11
	7.8.2	Function Documentation	11
		7.8.2.1 codec_ak4556_init()	11
7.9	src/dev	v_codec_pcm3060.h File Reference	11
	7.9.1	Detailed Description	12
	7.9.2	Function Documentation	12
		7.9.2.1 codec_pcm3060_init()	12
7.10	src/dev	v_codec_wm8731.h File Reference	12
	7.10.1	Detailed Description	12
	7.10.2	Function Documentation	13
		7.10.2.1 codec_wm8731_enter_bypass()	13
		7.10.2.2 codec_wm8731_exit_bypass()	13
		7.10.2.3 codec_wm8731_init()	13
7.11	src/dev	v_codec_wm8731_frame.h File Reference	14
	7.11.1	Detailed Description	14
	7.11.2	Typedef Documentation	14
		7.11.2.1 sa_audio_callback	14
7.12	src/dev	v_flash_IS25LP064A.h File Reference	14
	7.12.1	Detailed Description	17
	7.12.2	Macro Definition Documentation	17
		7.12.2.1 BLOCK_ERASE_32K_CMD	17
		7.12.2.2 CLEAR_FLAG_STATUS_REG_CMD	17
		7.12.2.3 DIE_ERASE_CMD	17
		7.12.2.4 DUAL_IN_FAST_PROG_CMD	17
		7.12.2.5 DUAL_INOUT_FAST_READ_4_BYTE_ADDR_CMD	17

CONTENTS xxiii

7.12.2.6 DUAL_INOUT_FAST_READ_CMD	47
7.12.2.7 DUAL_INOUT_FAST_READ_DTR_CMD	48
7.12.2.8 DUAL_OUT_FAST_READ_4_BYTE_ADDR_CMD	48
7.12.2.9 DUAL_OUT_FAST_READ_CMD	48
7.12.2.10 DUAL_OUT_FAST_READ_DTR_CMD	48
7.12.2.11 ENTER_4_BYTE_ADDR_MODE_CMD	48
7.12.2.12 ENTER_QUAD_CMD	48
7.12.2.13 EXIT_4_BYTE_ADDR_MODE_CMD	48
7.12.2.14 EXIT_QUAD_CMD	48
7.12.2.15 EXT_DUAL_IN_FAST_PROG_CMD	49
7.12.2.16 EXT_QUAD_IN_FAST_PROG_CMD	49
7.12.2.17 FAST_READ_4_BYTE_ADDR_CMD	49
7.12.2.18 FAST_READ_CMD	49
7.12.2.19 FAST_READ_DTR_CMD	49
7.12.2.20 IS25LP064A_DIE_ERASE_MAX_TIME	49
7.12.2.21 IS25LP064A_DUMMY_CYCLES_READ	49
7.12.2.22 IS25LP064A_DUMMY_CYCLES_READ_DTR	49
7.12.2.23 IS25LP064A_DUMMY_CYCLES_READ_QUAD	50
7.12.2.24 IS25LP064A_DUMMY_CYCLES_READ_QUAD_DTR	50
7.12.2.25 IS25LP064A_EAR_HIGHEST_SE	50
7.12.2.26 IS25LP064A_EAR_LOWEST_SEG	50
7.12.2.27 IS25LP064A_EAR_SECOND_SEG	50
7.12.2.28 IS25LP064A_EAR_THIRD_SEG	50
7.12.2.29 IS25LP064A_EVCR_DTRP	50
7.12.2.30 IS25LP064A_EVCR_DUAL	50
7.12.2.31 IS25LP064A_EVCR_ODS	51
7.12.2.32 IS25LP064A_EVCR_QUAD	51
7.12.2.33 IS25LP064A_EVCR_RH	51
7.12.2.34 IS25LP064A_FLASH_SIZE	51
7.12.2.35 IS25LP064A_FSR_ERERR	51

xxiv CONTENTS

7.12.2.36 IS25LP064A_FSR_ERSUS
7.12.2.37 IS25LP064A_FSR_NBADDR
7.12.2.38 IS25LP064A_FSR_PGERR
7.12.2.39 IS25LP064A_FSR_PGSUS
7.12.2.40 IS25LP064A_FSR_PRERR
7.12.2.41 IS25LP064A_FSR_READY
7.12.2.42 IS25LP064A_H
7.12.2.43 IS25LP064A_NVCR_DTRP
7.12.2.44 IS25LP064A_NVCR_DUAL
7.12.2.45 IS25LP064A_NVCR_NB_DUMMY
7.12.2.46 IS25LP064A_NVCR_NBADDR
7.12.2.47 IS25LP064A_NVCR_ODS
7.12.2.48 IS25LP064A_NVCR_QUAB
7.12.2.49 IS25LP064A_NVCR_RH
7.12.2.50 IS25LP064A_NVCR_SEGMENT
7.12.2.51 IS25LP064A_NVCR_XIP
7.12.2.52 IS25LP064A_PAGE_SIZE
7.12.2.53 IS25LP064A_SECTOR_ERASE_MAX_TIME
7.12.2.54 IS25LP064A_SECTOR_SIZE
7.12.2.55 IS25LP064A_SR_QE
7.12.2.56 IS25LP064A_SR_SRWREN
7.12.2.57 IS25LP064A_SR_WIP
7.12.2.58 IS25LP064A_SR_WREN
7.12.2.59 IS25LP064A_SUBSECTOR_ERASE_MAX_TIME
7.12.2.60 IS25LP064A_SUBSECTOR_SIZE
7.12.2.61 IS25LP064A_VCR_NB_DUMMY
7.12.2.62 IS25LP064A_VCR_WRAP
7.12.2.63 IS25LP064A_VCR_XIP
7.12.2.64 MULTIPLE_IO_READ_ID_CMD
7.12.2.65 PAGE_PROG_4_BYTE_ADDR_CMD

CONTENTS xxv

7.12.2.66 PAGE_PROG_CMD	155
7.12.2.67 PROG_ERASE_RESUME_CMD	155
7.12.2.68 PROG_ERASE_SUSPEND_CMD	155
7.12.2.69 PROG_OTP_ARRAY_CMD	155
7.12.2.70 QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD	156
7.12.2.71 QUAD_IN_FAST_PROG_CMD	156
7.12.2.72 QUAD_INOUT_FAST_READ_4_BYTE_ADDR_CMD	156
7.12.2.73 QUAD_INOUT_FAST_READ_CMD	156
7.12.2.74 QUAD_INOUT_FAST_READ_DTR_CMD	156
7.12.2.75 QUAD_OUT_FAST_READ_4_BYTE_ADDR_CMD	156
7.12.2.76 QUAD_OUT_FAST_READ_CMD	156
7.12.2.77 QUAD_OUT_FAST_READ_DTR_CMD	156
7.12.2.78 READ_4_BYTE_ADDR_CMD	157
7.12.2.79 READ_CMD	157
7.12.2.80 READ_ENHANCED_VOL_CFG_REG_CMD	157
7.12.2.81 READ_EXT_ADDR_REG_CMD	157
7.12.2.82 READ_FLAG_STATUS_REG_CMD	157
7.12.2.83 READ_ID_CMD	157
7.12.2.84 READ_ID_CMD2	157
7.12.2.85 READ_LOCK_REG_CMD	157
7.12.2.86 READ_NONVOL_CFG_REG_CMD	158
7.12.2.87 READ_OTP_ARRAY_CMD	158
7.12.2.88 READ_READ_PARAM_REG_CMD	158
7.12.2.89 READ_SERIAL_FLASH_DISCO_PARAM_CMD	158
7.12.2.90 READ_STATUS_REG_CMD	158
7.12.2.91 RESET_ENABLE_CMD	158
7.12.2.92 RESET_MEMORY_CMD	158
7.12.2.93 SECTOR_ERASE_4_BYTE_ADDR_CMD	158
7.12.2.94 SECTOR_ERASE_CMD	159
7.12.2.95 SUBSECTOR_ERASE_4_BYTE_ADDR_CMD	159

xxvi CONTENTS

	7.12.2.96 SUBSECTOR_ERASE_CMD	159
	7.12.2.97 SUBSECTOR_ERASE_QPI_CMD	159
	7.12.2.98 WRITE_DISABLE_CMD	159
	7.12.2.99 WRITE_ENABLE_CMD	159
	7.12.2.100WRITE_ENHANCED_VOL_CFG_REG_CMD	159
	7.12.2.101WRITE_EXT_ADDR_REG_CMD	159
	7.12.2.102WRITE_LOCK_REG_CMD	160
	7.12.2.103WRITE_NONVOL_CFG_REG_CMD	160
	7.12.2.104WRITE_READ_PARAM_REG_CMD	160
	7.12.2.105WRITE_STATUS_REG_CMD	160
7.13 src/de	v_flash_IS25LP080D.h File Reference	160
7.13.1	Detailed Description	162
7.13.2	Macro Definition Documentation	162
	7.13.2.1 BLOCK_ERASE_32K_CMD	162
	7.13.2.2 CLEAR_FLAG_STATUS_REG_CMD	163
	7.13.2.3 DIE_ERASE_CMD	163
	7.13.2.4 DUAL_IN_FAST_PROG_CMD	163
	7.13.2.5 DUAL_INOUT_FAST_READ_4_BYTE_ADDR_CMD	163
	7.13.2.6 DUAL_INOUT_FAST_READ_CMD	163
	7.13.2.7 DUAL_INOUT_FAST_READ_DTR_CMD	163
	7.13.2.8 DUAL_OUT_FAST_READ_4_BYTE_ADDR_CMD	163
	7.13.2.9 DUAL_OUT_FAST_READ_CMD	163
	7.13.2.10 DUAL_OUT_FAST_READ_DTR_CMD	164
	7.13.2.11 ENTER_4_BYTE_ADDR_MODE_CMD	164
	7.13.2.12 ENTER_QUAD_CMD	164
	7.13.2.13 EXIT_4_BYTE_ADDR_MODE_CMD	164
	7.13.2.14 EXIT_QUAD_CMD	164
	7.13.2.15 EXT_DUAL_IN_FAST_PROG_CMD	164
	7.13.2.16 EXT_QUAD_IN_FAST_PROG_CMD	164
	7.13.2.17 FAST_READ_4_BYTE_ADDR_CMD	164

CONTENTS xxvii

7.13.2.18 FAST_READ_CMD	165
7.13.2.19 FAST_READ_DTR_CMD	165
7.13.2.20 IS25LP080D_DIE_ERASE_MAX_TIME	165
7.13.2.21 IS25LP080D_DUMMY_CYCLES_READ	165
7.13.2.22 IS25LP080D_DUMMY_CYCLES_READ_DTR	165
7.13.2.23 IS25LP080D_DUMMY_CYCLES_READ_QUAD	165
7.13.2.24 IS25LP080D_DUMMY_CYCLES_READ_QUAD_DTR	165
7.13.2.25 IS25LP080D_EAR_HIGHEST_SE	165
7.13.2.26 IS25LP080D_EAR_LOWEST_SEG	166
7.13.2.27 IS25LP080D_EAR_SECOND_SEG	166
7.13.2.28 IS25LP080D_EAR_THIRD_SEG	166
7.13.2.29 IS25LP080D_EVCR_DTRP	166
7.13.2.30 IS25LP080D_EVCR_DUAL	166
7.13.2.31 IS25LP080D_EVCR_ODS	166
7.13.2.32 IS25LP080D_EVCR_QUAD	166
7.13.2.33 IS25LP080D_EVCR_RH	166
7.13.2.34 IS25LP080D_FLASH_SIZE	167
7.13.2.35 IS25LP080D_FSR_ERERR	167
7.13.2.36 IS25LP080D_FSR_ERSUS	167
7.13.2.37 IS25LP080D_FSR_NBADDR	167
7.13.2.38 IS25LP080D_FSR_PGERR	167
7.13.2.39 IS25LP080D_FSR_PGSUS	167
7.13.2.40 IS25LP080D_FSR_PRERR	167
7.13.2.41 IS25LP080D_FSR_READY	167
7.13.2.42 IS25LP080D_NVCR_DTRP	168
7.13.2.43 IS25LP080D_NVCR_DUAL	168
7.13.2.44 IS25LP080D_NVCR_NB_DUMMY	168
7.13.2.45 IS25LP080D_NVCR_NBADDR	168
7.13.2.46 IS25LP080D_NVCR_ODS	168
7.13.2.47 IS25LP080D_NVCR_QUAB	168

xxviii CONTENTS

7.13.2.48 IS25LP080D_NVCR_RH
7.13.2.49 IS25LP080D_NVCR_SEGMENT
7.13.2.50 IS25LP080D_NVCR_XIP
7.13.2.51 IS25LP080D_PAGE_SIZE
7.13.2.52 IS25LP080D_SECTOR_ERASE_MAX_TIME
7.13.2.53 IS25LP080D_SECTOR_SIZE
7.13.2.54 IS25LP080D_SR_QE
7.13.2.55 IS25LP080D_SR_SRWREN
7.13.2.56 IS25LP080D_SR_WIP
7.13.2.57 IS25LP080D_SR_WREN
7.13.2.58 IS25LP080D_SUBSECTOR_ERASE_MAX_TIME
7.13.2.59 IS25LP080D_SUBSECTOR_SIZE
7.13.2.60 IS25LP080D_VCR_NB_DUMMY
7.13.2.61 IS25LP080D_VCR_WRAP
7.13.2.62 IS25LP080D_VCR_XIP
7.13.2.63 MULTIPLE_IO_READ_ID_CMD
7.13.2.64 PAGE_PROG_4_BYTE_ADDR_CMD
7.13.2.65 PAGE_PROG_CMD
7.13.2.66 PROG_ERASE_RESUME_CMD
7.13.2.67 PROG_ERASE_SUSPEND_CMD
7.13.2.68 PROG_OTP_ARRAY_CMD
7.13.2.69 QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD
7.13.2.70 QUAD_IN_FAST_PROG_CMD
7.13.2.71 QUAD_INOUT_FAST_READ_4_BYTE_ADDR_CMD
7.13.2.72 QUAD_INOUT_FAST_READ_CMD
7.13.2.73 QUAD_INOUT_FAST_READ_DTR_CMD
7.13.2.74 QUAD_OUT_FAST_READ_4_BYTE_ADDR_CMD
7.13.2.75 QUAD_OUT_FAST_READ_CMD
7.13.2.76 QUAD_OUT_FAST_READ_DTR_CMD
7.13.2.77 READ_4_BYTE_ADDR_CMD

CONTENTS xxix

		7.13.2.78 READ_CMD	172
		7.13.2.79 READ_ENHANCED_VOL_CFG_REG_CMD	172
		7.13.2.80 READ_EXT_ADDR_REG_CMD	172
		7.13.2.81 READ_FLAG_STATUS_REG_CMD	173
		7.13.2.82 READ_ID_CMD	173
		7.13.2.83 READ_ID_CMD2	173
		7.13.2.84 READ_LOCK_REG_CMD	173
		7.13.2.85 READ_NONVOL_CFG_REG_CMD	173
		7.13.2.86 READ_OTP_ARRAY_CMD	173
		7.13.2.87 READ_READ_PARAM_REG_CMD	173
		7.13.2.88 READ_SERIAL_FLASH_DISCO_PARAM_CMD	173
		7.13.2.89 READ_STATUS_REG_CMD	174
		7.13.2.90 RESET_ENABLE_CMD	174
		7.13.2.91 RESET_MEMORY_CMD	174
		7.13.2.92 SECTOR_ERASE_4_BYTE_ADDR_CMD	174
		7.13.2.93 SECTOR_ERASE_CMD	174
		7.13.2.94 SUBSECTOR_ERASE_4_BYTE_ADDR_CMD	174
		7.13.2.95 SUBSECTOR_ERASE_CMD	174
		7.13.2.96 SUBSECTOR_ERASE_QPI_CMD	174
		7.13.2.97 WRITE_DISABLE_CMD	175
		7.13.2.98 WRITE_ENABLE_CMD	175
		7.13.2.99 WRITE_ENHANCED_VOL_CFG_REG_CMD	175
		7.13.2.100WRITE_EXT_ADDR_REG_CMD	175
		7.13.2.101WRITE_LOCK_REG_CMD	175
		7.13.2.102WRITE_NONVOL_CFG_REG_CMD	175
		7.13.2.103WRITE_READ_PARAM_REG_CMD	175
		7.13.2.104WRITE_STATUS_REG_CMD	175
7.14	src/dev	_leddriver.h File Reference	176
	7.14.1	Detailed Description	176
	7.14.2	Macro Definition Documentation	176

	7.14.2.1 DSY_LED_DRIVER_MAX_DRIVERS
	7.14.2.2 SA_LED_DRIVER_H
7.14.3	Enumeration Type Documentation
	7.14.3.1 anonymous enum
7.14.4	Function Documentation
	7.14.4.1 dsy_led_driver_color_by_name()
	7.14.4.2 dsy_led_driver_init()
	7.14.4.3 dsy_led_driver_set_led()
	7.14.4.4 dsy_led_driver_update()
7.15 src/dev	v_sdram.h File Reference
7.15.1	Macro Definition Documentation
	7.15.1.1 DSY_SDRAM_BSS
	7.15.1.2 DSY_SDRAM_DATA
	7.15.1.3 RAM_AS4C16M16SA_H
7.15.2	Enumeration Type Documentation
	7.15.2.1 anonymous enum
	7.15.2.2 dsy_sdram_pin
	7.15.2.3 dsy_sdram_state
7.15.3	Function Documentation
	7.15.3.1 dsy_sdram_init()
7.16 src/dev	v_sr_4021.h File Reference
7.16.1	Detailed Description
7.16.2	Macro Definition Documentation
	7.16.2.1 DEV_SR_4021_H
	7.16.2.2 SR_4021_MAX_DAISYCHAIN
	7.16.2.3 SR_4021_MAX_PARALLEL
7.16.3	Enumeration Type Documentation
	7.16.3.1 anonymous enum
7.16.4	Function Documentation
	7.16.4.1 dsy_sr_4021_init()

CONTENTS xxxi

	7.16.4.2 dsy_sr_4021_state()
	7.16.4.3 dsy_sr_4021_update()
7.17 src	dev_sr_595.h File Reference
7.1	7.1 Variable Documentation
	7.17.1.1 kMaxSr595DaisyChain
7.18 src	fatfs.h File Reference
7.1	3.1 Detailed Description
7.1	3.2 Macro Definition Documentation
	7.18.2.1fatfs_H
7.1	3.3 Function Documentation
	7.18.3.1 dsy_fatfs_init()
7.1	3.4 Variable Documentation
	7.18.4.1 retSD
	7.18.4.2 SDFatFS
	7.18.4.3 SDFile
	7.18.4.4 SDPath
7.19 src	ffconf.h File Reference
7.1	9.1 Detailed Description
7.1	9.2 Macro Definition Documentation
	7.19.2.1 _CODE_PAGE
	7.19.2.2 _FFCONF
	7.19.2.3 _FS_EXFAT
	7.19.2.4 _FS_LOCK
	7.19.2.5 _FS_MINIMIZE
	7.19.2.6 _FS_NOFSINFO
	7.19.2.7 _FS_NORTC
	7.19.2.8 _FS_READONLY
	7.19.2.9 _FS_REENTRANT
	7.19.2.10 _FS_RPATH
	7.19.2.11 _FS_TIMEOUT

xxxii CONTENTS

		7.19.2.12 _FS_TINY	190
		7.19.2.13 _LFN_UNICODE	190
		7.19.2.14 _MAX_LFN	190
		7.19.2.15 _MAX_SS	190
		7.19.2.16 _MIN_SS	190
		7.19.2.17 _MULTI_PARTITION	191
		7.19.2.18 _NORTC_MDAY	191
		7.19.2.19 _NORTC_MON	191
		7.19.2.20 _NORTC_YEAR	191
		7.19.2.21 _STR_VOLUME_ID	191
		7.19.2.22 _STRF_ENCODE	191
		7.19.2.23 _SYNC_t	192
		7.19.2.24 _USE_CHMOD	192
		7.19.2.25 _USE_EXPAND	192
		7.19.2.26 _USE_FASTSEEK	192
		7.19.2.27 _USE_FIND	192
		7.19.2.28 _USE_FORWARD	192
		7.19.2.29 _USE_LABEL	193
		7.19.2.30 _USE_LFN	193
		7.19.2.31 _USE_MKFS	193
		7.19.2.32 _USE_STRFUNC	193
		7.19.2.33 _USE_TRIM	193
		7.19.2.34 _VOLUME_STRS	193
		7.19.2.35 _VOLUMES	194
		7.19.2.36 ff_free	194
		7.19.2.37 ff_malloc	194
7.20	src/hid_	_audio.h File Reference	194
	7.20.1	Detailed Description	195
	7.20.2	Macro Definition Documentation	195
		7.20.2.1 DSY_AUDIO_BLOCK_SIZE_MAX	195

CONTENTS xxxiii

		7.20.2.2 DSY_AUDIO_CHANNELS_MAX	. 195
		7.20.2.3 DSY_AUDIO_H	. 195
		7.20.2.4 DSY_AUDIO_SAMPLE_RATE	. 196
	7.20.3	Typedef Documentation	. 196
		7.20.3.1 dsy_audio_mc_callback	. 196
	7.20.4	Enumeration Type Documentation	. 196
		7.20.4.1 anonymous enum	. 196
	7.20.5	Function Documentation	. 197
		7.20.5.1 dsy_audio_enter_bypass()	. 197
		7.20.5.2 dsy_audio_exit_bypass()	. 197
		7.20.5.3 dsy_audio_init()	. 197
		7.20.5.4 dsy_audio_passthru()	. 197
		7.20.5.5 dsy_audio_set_blocksize()	. 197
		7.20.5.6 dsy_audio_set_callback()	. 198
		7.20.5.7 dsy_audio_set_mc_callback()	. 198
		7.20.5.8 dsy_audio_silence()	. 198
		7.20.5.9 dsy_audio_start()	. 198
		7.20.5.10 dsy_audio_stop()	. 198
7.21	src/hid_	ctrl.h File Reference	. 198
7.22	src/hid_	encoder.h File Reference	. 199
7.23	src/hid_	gatein.h File Reference	. 199
7.24	src/hid_	led.h File Reference	. 199
7.25	src/hid_	midi.h File Reference	. 200
	7.25.1	Enumeration Type Documentation	. 200
		7.25.1.1 MidiMessageType	. 200
7.26	src/hid_	oled_display.h File Reference	. 201
	7.26.1	Macro Definition Documentation	. 201
		7.26.1.1 DSY_OLED_DISPLAY_H	. 201
		7.26.1.2 SSD1309_HEIGHT	. 201
		7.26.1.3 SSD1309_WIDTH	. 201

7.27	src/hid_	_paramete	er.h I	File Re	feren	ice .				 	 	 	 	 		 	201
7.28	src/hid_	_rgb_led.h	h File	Refer	ence					 	 	 	 	 	. . .	 	202
7.29	src/hid_	_switch.h l	File	Refere	nce					 	 	 	 	 	. . .	 	202
7.30	src/hid_	_usb.h File	e Re	ferenc	е.					 	 	 	 	 		 	202
7.31	src/hid_	_wavplaye	er.h F	-ile Re⁴	feren	ice	 	202
	7.31.1	Macro De	efinit	ion Do	cume	entat	ion			 	 	 	 	 		 	203
		7.31.1.1	DS	SY_WA	\VPL	AYEI	R_H			 	 	 	 	 		 	203
		7.31.1.2	W	AV_FIL	_ENA	ME_	_MAX	(.		 	 	 	 	 	. . .	 	203
7.32	src/per	_adc.h File	le Re	eferenc	е.					 	 	 	 	 	. . .	 	203
	7.32.1	Macro De	efinit	tion Do	cume	entat	ion			 	 	 	 	 	. . .	 	204
		7.32.1.1	DS	SY_AD	C_H					 	 	 	 	 	. . .	 	204
		7.32.1.2	DS	SY_AD	C_M	AX_(AHC	NNE	LS	 	204
7.33	src/per	_dac.h File	le Re	eferenc	:е .					 	 	 	 	 		 	204
	7.33.1	Enumera	ation	Туре [Docui	ment	ation	١.		 	 	 	 	 	. . .	 	204
		7.33.1.1	ds	y_dac_	_bitde	epth				 	 	 	 	 	. . .	 	204
		7.33.1.2	ds	y_dac_	_char	nnel				 	 	 	 	 	. . .	 	205
		7.33.1.3	ds	y_dac_	_mod	e				 	 	 	 	 	. . .	 	205
	7.33.2	Function	Doc	ument	ation	١				 	 	 	 	 		 	205
		7.33.2.1	ds	y_dac_	_init()					 	 	 	 	 		 	205
		7.33.2.2	ds	y_dac_	_start	:()				 	 	 	 	 		 	206
		7.33.2.3	ds	y_dac_	_write	∍() .				 	 	 	 	 		 	206
7.34	src/per	_gpio.h Fil	ile R	eferenc	ce .					 	 	 	 	 		 	206
	7.34.1	Detailed	Des	criptior	ı .					 	 	 	 	 		 	207
	7.34.2	Enumera	ation	Туре [Docui	ment	ation	١.		 	 	 	 	 		 	207
		7.34.2.1	ds	y_gpio	_moc	de .				 	 	 	 	 		 	207
		7.34.2.2	ds	y_gpio	_pull					 	 	 	 	 		 	207
	7.34.3	Function	Doc	ument	ation	١				 	 	 	 	 		 	208
		7.34.3.1	ds	y_gpio	_deir	nit() .				 	 	 	 	 		 	208
		7.34.3.2	ds	y_gpio	_init())				 	 	 	 	 		 	208
		7.34.3.3	ds	y_gpio	_reac	. () b				 	 	 	 			 	208

CONTENTS XXXV

209 209 210 210 210
210 210
210
210
-
210
211
211
211
211
212
212
212
213
213
213
213
213
213
213
214
214
214
215
215
215
216
216
216

xxxvi CONTENTS

7.37 src/per	r_sai.h File Reference
7.37.1	Enumeration Type Documentation
	7.37.1.1 anonymous enum
	7.37.1.2 dsy_audio_bitdepth
	7.37.1.3 dsy_audio_device
	7.37.1.4 dsy_audio_dir
	7.37.1.5 dsy_audio_sai
	7.37.1.6 dsy_audio_samplerate
	7.37.1.7 dsy_audio_sync
	7.37.1.8 dsy_sai_pin
7.37.2	Function Documentation
	7.37.2.1 dsy_sai_init()
	7.37.2.2 dsy_sai_init_from_handle()
7.38 src/pe	r_sdmmc.h File Reference
7.38.1	Macro Definition Documentation
	7.38.1.1 DSY_SD_ERROR
	7.38.1.2 DSY_SD_OK
	7.38.1.3 DSY_SDMMC_H
7.38.2	Enumeration Type Documentation
	7.38.2.1 SdmmcBitWidth
	7.38.2.2 SdmmcMode
	7.38.2.3 SdmmcSpeed
7.39 src/per	r_spi.h File Reference
7.39.1	Enumeration Type Documentation
	7.39.1.1 SpiPeriph
	7.39.1.2 SpiPin
7.40 src/pe	r_tim.h File Reference
7.40.1	Function Documentation
	7.40.1.1 dsy_tim_delay_ms()
	7.40.1.2 dsy_tim_delay_tick()

CONTENTS xxxvii

		7.40.1.3	C	ds	sy_	_tiı	m_	de	lay	/_l	us	()							 					 			 2	226
		7.40.1.4	C	ds	sy_	_tiı	m_	ge	t_r	ns	s()								 					 			 2	226
		7.40.1.5	C	ds	sy_	_tiı	m_	ge	t_t	icl	k()	١.												 			 2	226
		7.40.1.6	c	ds	sy_	_tiı	m_	ge	t_ı	JS	()								 					 			 2	226
		7.40.1.7	c	ds	sy_	_tiı	m_	init	t()										 					 			 2	227
		7.40.1.8	c	ds	Sy_	_tiı	m_	sta	ırt(()									 					 			 2	227
7.41	src/per	_uart.h Fil	ile	R	{ef	er	end	се											 					 			 2	227
	7.41.1	Macro De	efi	in	itio	on	Do	ocu	ım	en	ıta	tic	n						 					 			 2	227
		7.41.1.1	[D	S۱	<u>/_</u>	UA	RT	<u>.</u>	Н														 			 2	227
	7.41.2	Variable I	Do	00	cui	me	ent	atio	on															 			 2	227
		7.41.2.1	ŀ	kl	Ja	rtN	Иa	хВι	uff	er	Si	ze												 			 2	228
7.42	src/sys	_dma.h Fi	ile	e F	₹e	fei	ren	се																 			 2	228
	7.42.1	Function	ı D)o	CU	ım	eni	tati	on	l														 			 2	228
		7.42.1.1	c	ds	sy_	_d	ma	_ir	nit(()														 			 2	228
7.43	src/sys	_system.h	h F	Fil	le	Re	efei	ren	ice	;														 			 2	228
	7.43.1	Detailed	D)es	SC	rip	tio	n																 			 2	228
	7.43.2	Function	ı D)o	CU	ım	eni	tati	on	l														 			 2	228
		7.43.2.1	c	ds	sy_	_S	yst	em	1_C	lek	lay	/()												 			 2	228
		7.43.2.2	c	ds	sy_	_S	yst	em	1_ <u>C</u>	jet	tno	ЭW	/ ()						 					 			 2	229
		7.43.2.3	c	ds	sy_	_S	yst	em	ا <u>ن</u> ا	nit	t()								 					 			 2	229
		7.43.2.4	c	ds	sy_	_S	yst	em	الِـا	un	np	to	()											 			 2	229
		7.43.2.5	c	ds	sy_	_S	yst	em	الِـا	un	np	to	qs	pi	()				 					 			 2	229
7.44	src/usb	od_cdc_if.h	h F	Fil	le	Re	efe	ren	ıce)									 					 			 2	230
	7.44.1	Detailed	D)es	SC	rip	tio	n											 					 			 2	230
7.45	src/usb	d_conf.h F	Fil	ile	R	efe	ere	nc	е										 					 			 2	231
	7.45.1	Detailed	D)es	SC	rip	tio	n																 			 2	231
7.46	src/usb	d_desc.h	Fi	ile	e F	₹et	fere	enc	Э										 					 			 2	232
	7.46.1	Detailed	D)es	SC	rip	tio	n																 			 2	232
7.47	src/util_	_bsp_sd_c	dis	sk	(io	.h	File	e F	}ef	er	er	1CE	9.											 			 2	232
	7.47.1	Macro De)efi	fin	itio	on	Do	ocu	ım	er	ntə	tic	n											 			 2	233

xxxviii CONTENTS

	7.47.1.1	BSP_SD_CardInfo	233
	7.47.1.2	DSY_BSP_SD_DISKIO_H	233
	7.47.1.3	MSD_ERROR	234
	7.47.1.4	MSD_ERROR_SD_NOT_PRESENT	234
	7.47.1.5	MSD_OK	234
	7.47.1.6	SD_DATATIMEOUT	234
	7.47.1.7	SD_NOT_PRESENT	234
	7.47.1.8	SD_PRESENT	234
	7.47.1.9	SD_TRANSFER_BUSY	234
	7.47.1.10	SD_TRANSFER_OK	234
7.47.2	Function	Documentation	235
	7.47.2.1	BSP_SD_AbortCallback()	235
	7.47.2.2	BSP_SD_Erase()	235
	7.47.2.3	BSP_SD_GetCardInfo()	235
	7.47.2.4	BSP_SD_GetCardState()	236
	7.47.2.5	BSP_SD_Init()	236
	7.47.2.6	BSP_SD_lsDetected()	236
	7.47.2.7	BSP_SD_ITConfig()	236
	7.47.2.8	BSP_SD_ReadBlocks()	236
	7.47.2.9	BSP_SD_ReadBlocks_DMA()	237
	7.47.2.10	BSP_SD_ReadCpltCallback()	237
	7.47.2.11	BSP_SD_WriteBlocks()	237
	7.47.2.12	BSP_SD_WriteBlocks_DMA()	238
	7.47.2.13	BSP_SD_WriteCpltCallback()	238
src/util_	_color.h Fil	e Reference	238
7.48.1	Macro De	efinition Documentation	239
	7.48.1.1	DSY_COLOR_H	239
src/util_	_hal_map.l	n File Reference	239
7.49.1	Function	Documentation	239
	7.49.1.1	dsy_hal_map_get_i2c()	239
	7.49.1.2	dsy_hal_map_get_pin()	240
	7.49.1.3	dsy_hal_map_get_port()	240
7.49.2	Variable [Documentation	240
	7.49.2.1	hi2c1	240
	7.49.2.2	hi2c2	241
	7.49.2.3	hi2c3	241
	7.49.2.4	hi2c4	241
src/util_	_ringbuffer	h File Reference	241
src/util_	_unique_id	I.h File Reference	241
7.51.1	Function	Documentation	241
	7.51.1.1	dsy_get_unique_id()	242
src/util_	_wav_form	at.h File Reference	242
	src/util_ 7.48.1 src/util_ 7.49.1 7.49.2 src/util_ src/util_ 7.51.1	7.47.1.2 7.47.1.3 7.47.1.4 7.47.1.5 7.47.1.6 7.47.1.7 7.47.1.8 7.47.1.9 7.47.1.10 7.47.2 Function 7.47.2.1 7.47.2.2 7.47.2.3 7.47.2.4 7.47.2.5 7.47.2.6 7.47.2.7 7.47.2.8 7.47.2.10 7.47.2.11 7.47.2.12 7.47.2.13 src/util_color.h Fill 7.48.1 Macro Defended Tolor.h Fill 7.48.1 Macro Defended Tolor.h Fill 7.49.1.1 src/util_hal_map.l 7.49.1.1 7.49.1.2 7.49.1.3 7.49.2.1 7.49.2.2 7.49.2.3 7.49.2.4 src/util_ringbuffer src/util_unique_id 7.51.1 Function 7.51.1.1	7.47.1.6 SD_DATATIMEOUT 2 7.47.1.7 SD_NOT_PRESENT 2 7.47.1.8 SD_PRESENT 2 7.47.1.9 SD_TRANSFER_BUSY 2 7.47.2.1.10 SD_TRANSFER_OK 2 7.47.2.1 BSP_SD_AbortCallback() 2 7.47.2.1 BSP_SD_Batase() 2 7.47.2.2 BSP_SD_GetCardInfo() 2 7.47.2.3 BSP_SD_GetCardState() 2 7.47.2.4 BSP_SD_Init() 2 7.47.2.5 BSP_SD_Init() 2 7.47.2.6 BSP_SD_Indetected() 2 7.47.2.7 BSP_SD_IneadBlocks() 2 7.47.2.8 BSP_SD_ReadBlocks() 2 7.47.2.10 BSP_SD_ReadBlocks_DMA() 2 7.47.2.10 BSP_SD_ReadCpltCallback() 2 7.47.2.11 BSP_SD_WriteBlocks() 2 7.47.2.11 BSP_SD_WriteBlocks() 2 7.47.2.13 BSP_SD_WriteCpltCallback() 2 7.47.2.13 BSP_SD_WriteCpltCallback() 2 7.48.1 Macro Definition Documentation 2 7.49.1.1

CONTENTS	xxxi
CONTENTS	

Index 243

Chapter 1

libdaisy

Multi-layer hardware abstraction library for Daisy Product family

On STM32H7 MCUs

Lower-levels use STM32 HAL (local copy w/ modifications in Drivers/)

Prefixes and their meanings:

- sys System level configuration (clocks, dma, etc.)
- per Peripheral level, internal to MCU (i2c, spi, etc.)
- · dev External device support (external flash chips, DACs, codecs, etc.)
- hid User level interface elements (encoders, switches, audio, etc.)
- util library level elements used within the library (not included via daisy.h)
- daisy core API files (specific boards, platforms have extended user APIs that configure libdaisy more below).

Also included is a core/ folder containing:

- a generic Makefile that can be included in a project Makefile to simplify getting started
- · a linker script for defining the sections of memory used by the firmware
- core files for starting the hardware (system_stm32h7xx.c, startup_stm32h750xx.s, etc.)

1.1 Using libdaisy

Due to the amount of hardware configuration and flexibility of the daisy platform, (in the present, and the future), a user can use libdaisy to define their own custom hardware, or include one of our supported board files to jumpstart the creativity, and hack on an existing piece of hardware.

If you are getting started, and have one of the Daisy Family Products, you can skip ahead to that section below.

2 libdaisy

1.1.1 daisy.h

The base-level include file. This is all you need to include to create your own custom hardware that uses libdaisy.

daisy_seed.h is an example of a board level file that utilizes libdaisy to define some hardware, and provide flexible access.

1.1.2 daisy_seed.h

The SOM-level include file. This can be used with any boards that use the Daisy Seed hardware.

Additional configuration files, with more specific hardware access are provided below for our supported hardware platforms.

1.1.3 daisy_platform.h

Several other pairs of files exist in the repo for each of the supported hardware platforms that work with Daisy Seed.

These are:

- · daisy_field
- · daisy_patch
- · daisy_petal
- · daisy_pod

With these files a number of additional initialization, and configuration is done by the library.

This allows a user to jump right into their new product with a simple api to do things without having a full understanding of what's going on under the hood.

With this flexible approach to the hardware configuration, we hope to promote a lot of fantastic hardware along with code to go with it.

Chapter 2

Module Index

2.1 Modules

Here is a list of all modules:

STM32_USB_OTG_DEVICE_LIBRARY	30
USBD_CDC_IF	9
USBD_CDC_IF_Exported_Defines	10
USBD_CDC_IF_Exported_Types	11
USBD_CDC_IF_Exported_Macros	12
USBD_CDC_IF_Exported_Variables	13
USBD_CDC_IF_Exported_FunctionsPrototype	14
USBD_DESC	23
USBD_DESC_Exported_Constants	24
USBD_DESC_Exported_Defines	25
USBD_DESC_Exported_TypesDefinitions	26
USBD_DESC_Exported_Macros	27
USBD_DESC_Exported_Variables	
USBD_DESC_Exported_FunctionsPrototype	29
USBD_OTG_DRIVER	31
USBD_CONF	15
USBD_CONF_Exported_Variables	16
USBD_CONF_Exported_Defines	17
USBD_CONF_Exported_Macros	19
USBD_CONF_Exported_Types	21
USBD_CONF_Exported_FunctionsPrototype	22

4 Module Index

Chapter 3

Class Index

3.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

daisy::AdcChannelConfig	33
daisy::AdcHandle	35
daisy::AnalogControl	
Hardware Interface for control inputs	
Primarily designed for ADC input controls such as	
potentiometers, and control voltage.	
39	
codec_frame_t	41
color	42
daisy::Color	43
daisy::ControlChangeEvent	45
daisy::daisy_field	46
daisy::DaisyPatch	
Class that handles initializing all of the hardware specific to the Daisy Patch Board.	
Helper funtions are also in place to provide easy access to built-in controls and peripherals	48
daisy::DaisyPetal	
Helpers and hardware definitions for daisy petal	53
daisy::DaisyPod	
Class that handles initializing all of the hardware specific to the Daisy Patch Board.	
Helper funtions are also in place to provide easy access to built-in controls and peripherals	60
daisy::DaisySeed	
This is the higher-level interface for the Daisy board.	
All basic peripheral configuration/initialization is setup here	66
dsy_audio_handle	69
dsy_dac_handle	70
dsy_gpio	71
dsy_gpio_pin	72
dsy_i2c_handle	73
dsy_qspi_handle	74
dsy_sai_handle	75
DSY_SD_CardInfoTypeDef	77
dsy_sdram_handle	78
dsy_sr_4021_handle	79
daisy::Encoder	
Generic Class for handling Quadrature Encoders	
Inspired/influenced by Mutable Instruments (pichenettes) Encoder classes	81

6 Class Index

FontDef
daisy::GateIn
Generic Class for handling gate inputs through GPIO84
daisy::Led
LED Class providing simple Software PWM ability, etc
Eventually this will work with hardware PWM, and external LED Driver devices as well 85
daisy::MidiEvent
daisy::MidiHandler
Simple MIDI Handler
Parses bytes from an input into valid MidiEvents.
The MidiEvents fill a FIFO queue that the user can pop messages from
daisy::NoteOnEvent
daisy::OledDisplay
daisy::Parameter
daisy::RgbLed
$daisy:: RingBuffer < T, size > \dots $
$daisy::RingBuffer < T, 0 > \dots \dots$
daisy::SdmmcHandler 106
daisy::SdmmcHandlerInit
ShiftRegister595
Device Driver for 8-bit shift register.
CD74HC595 - 8-bit serial to parallel output shift
daisy::SpiHandle
daisy::Switch
daisy::UartHandler
daisy::UsbHandle
Interface for initializing and using the USB Peripherals on the daisy
WAV_FormatTypeDef
daisy::WavFileInfo
daisy::WavPlayer

Chapter 4

File Index

4.1 File List

Here is a list of all documented files with brief descriptions:

be replaced by configurable options

194

src/daisy.h	7
src/daisy_core.h	0
src/daisy_field.h	
Hardware defines and helpers for daisy field platform	2
src/daisy_patch.h	9
src/daisy_petal.h	0
src/daisy_pod.h	0
src/daisy_seed.h	0
src/dev_codec_ak4556.h	
Driver for the AK4556 Stereo Codec	1
src/dev_codec_pcm3060.h	
Driver for the PCM3060 Codec	1
src/dev_codec_wm8731.h	
Driver for the WM8731 Codec	2
src/dev_codec_wm8731_frame.h	
WM8731 Codec framework	4
src/dev_flash_IS25LP064A.h	
IS25LP08D Commands	4
src/dev_flash_IS25LP080D.h	
IS25LP08D Commands	0
src/dev_leddriver.h	
Device driver for PCA9685 16-channel 12-bit PWM generator	6
src/dev_sdram.h	8
src/dev_sr_4021.h	
Device driver for the CD4021. Bit-banged serial shift input	1
src/dev_sr_595.h	4
src/fatfs.h	
Fatfs support	5
src/ffconf.h	7
src/hid_audio.h	
Audio Driver	
Configures Audio Device and provides callback for signal processing.	
Many of the hard-coded values here will change (increase), and/or	

8 File Index

src/hid_ctrl.h
src/hid_encoder.h
src/hid_gatein.h
src/hid_led.h
src/hid_midi.h
src/hid_oled_display.h
src/hid_parameter.h
src/hid_rgb_led.h
src/hid_switch.h
src/hid_usb.h
src/hid_wavplayer.h
src/per_adc.h
src/per_dac.h
src/per_gpio.h
src/per_i2c.h
src/per_qspi.h
src/per_sai.h
src/per_sdmmc.h
src/per_spi.h
src/per_tim.h
src/per_uart.h
src/stm32h7xx_hal_conf.h
src/sys_dma.h
src/sys_system.h
src/usbd_cdc_if.h
: Header for usbd_cdc_if.c file
src/usbd_conf.h
: Header for usbd_conf.c file
src/usbd_desc.h
: Header for usbd_conf.c file
src/util_bsp_sd_diskio.h
src/util_color.h
src/util_hal_map.h
src/util_oled_fonts.h
src/util_ringbuffer.h
src/util_sd_diskio.h
src/util_unique_id.h
src/util_wav_format.h

Chapter 5

Module Documentation

5.1 USBD_CDC_IF

Usb VCP device module.

Modules

- USBD_CDC_IF_Exported_Defines
 - Defines.
- USBD_CDC_IF_Exported_Types

Types.

• USBD_CDC_IF_Exported_Macros

Aliases.

• USBD_CDC_IF_Exported_Variables

Public variables.

• USBD_CDC_IF_Exported_FunctionsPrototype

Public functions declaration.

5.1.1 Detailed Description

Usb VCP device module.

5.2	USBD	CDC	IF	Exported	Defines
-----	------	-----	----	-----------------	----------------

Defines.

Defines.

5.3 USBD_CDC_IF_Exported_Types

Types.

Typedefs

• typedef void(* CDC_ReceiveCallback) (uint8_t *buf, uint32_t *size)

5.3.1 Detailed Description

Types.

5.3.2 Typedef Documentation

5.3.2.1 CDC_ReceiveCallback

typedef void(* CDC_ReceiveCallback) (uint8_t *buf, uint32_t *size)

Parameters

buf	buffer	
size	buffer size	

5.4 USBD_CDC_IF_Exported_Macros

Aliases.

Aliases.

5.5 USBD_CDC_IF_Exported_Variables

Public variables.

Variables

- USBD_CDC_ItfTypeDef USBD_Interface_fops_FS
- USBD_CDC_ltfTypeDef USBD_Interface_fops_HS

5.5.1 Detailed Description

Public variables.

5.5.2 Variable Documentation

5.5.2.1 USBD_Interface_fops_FS

USBD_CDC_ItfTypeDef USBD_Interface_fops_FS

CDC Interface callback.

5.5.2.2 USBD_Interface_fops_HS

USBD_CDC_ItfTypeDef USBD_Interface_fops_HS

CDC Interface callback.

5.6 USBD_CDC_IF_Exported_FunctionsPrototype

Public functions declaration.

Functions

```
• void CDC_Set_Rx_Callback_FS (CDC_ReceiveCallback cb)
```

- uint8_t CDC_Transmit_FS (uint8_t *Buf, uint16_t Len)
- uint8_t CDC_Transmit_HS (uint8_t *Buf, uint16_t Len)

5.6.1 Detailed Description

Public functions declaration.

5.6.2 Function Documentation

```
5.6.2.1 CDC_Set_Rx_Callback_FS()
```

&

5.6.2.2 CDC_Transmit_FS()

&

5.6.2.3 CDC_Transmit_HS()

&

5.7 USBD_CONF 15

5.7 USBD_CONF

Configuration file for Usb otg low level driver.

Modules

• USBD_CONF_Exported_Variables

Public variables.

• USBD_CONF_Exported_Defines

Defines for configuration of the Usb device.

• USBD_CONF_Exported_Macros

Aliases.

• USBD_CONF_Exported_Types

Types.

• USBD_CONF_Exported_FunctionsPrototype

Declaration of public functions for Usb device.

5.7.1 Detailed Description

Configuration file for Usb otg low level driver.

5.8 USBD_CONF_Exported_Variables

Public variables.

Public variables.

5.9 USBD_CONF_Exported_Defines

Defines for configuration of the Usb device.

Macros

- #define USBD_MAX_NUM_INTERFACES 1U
- #define USBD_MAX_NUM_CONFIGURATION 1U
- #define USBD_MAX_STR_DESC_SIZ 512U
- #define USBD_SUPPORT_USER_STRING 0U
- #define USBD_DEBUG_LEVEL 3U
- #define USBD_LPM_ENABLED 0U
- #define USBD SELF POWERED 1U
- #define DEVICE_FS 0
- #define DEVICE_HS 1

5.9.1 Detailed Description

Defines for configuration of the Usb device.

5.9.2 Macro Definition Documentation

```
5.9.2.1 DEVICE_FS
```

#define DEVICE_FS 0

FS and HS identification

5.9.2.2 DEVICE_HS

#define DEVICE_HS 1

ጴ

5.9.2.3 USBD_DEBUG_LEVEL

#define USBD_DEBUG_LEVEL 3U

&

5.9.2.4 USBD_LPM_ENABLED

#define USBD_LPM_ENABLED 0U

8

5.9.2.5 USBD_MAX_NUM_CONFIGURATION

#define USBD_MAX_NUM_CONFIGURATION 1U

&

5.9.2.6 USBD_MAX_NUM_INTERFACES

#define USBD_MAX_NUM_INTERFACES 1U

R.

5.9.2.7 USBD_MAX_STR_DESC_SIZ

#define USBD_MAX_STR_DESC_SIZ 512U

&

5.9.2.8 USBD_SELF_POWERED

#define USBD_SELF_POWERED 1U

&

5.9.2.9 USBD_SUPPORT_USER_STRING

#define USBD_SUPPORT_USER_STRING OU

&

5.10 USBD_CONF_Exported_Macros

Aliases.

Macros

- #define USBD_malloc malloc
- #define USBD_free free
- #define USBD_memset memset
- #define USBD_memcpy memcpy
- #define USBD_Delay HAL_Delay
- #define USBD_UsrLog(...)
- #define USBD_ErrLog(...)
- #define USBD_DbgLog(...)

5.10.1 Detailed Description

Aliases.

5.10.2 Macro Definition Documentation

```
5.10.2.1 USBD_DbgLog
```

Value:

```
printf("DEBUG : "); \
   printf(__VA_ARGS__); \
   printf("\n");
```

&

5.10.2.2 USBD_Delay

#define USBD_Delay HAL_Delay

Alias for delay.

```
5.10.2.3 USBD_ErrLog
```

Value:

```
printf("ERROR: "); \
   printf(__VA_ARGS__); \
   printf("\n");
```

&

```
5.10.2.4 USBD_free
```

```
#define USBD_free free
```

Alias for memory release.

```
5.10.2.5 USBD_malloc
```

```
#define USBD_malloc malloc
```

Alias for memory allocation.

5.10.2.6 USBD_memcpy

```
#define USBD_memcpy memcpy
```

Alias for memory copy.

5.10.2.7 USBD_memset

```
#define USBD_memset memset
```

Alias for memory set.

5.10.2.8 USBD_UsrLog

Value:

```
\begin{array}{c} \text{printf}(\underline{\hspace{0.1cm}} \text{VA\_ARGS}\underline{\hspace{0.1cm}}); \ \backslash \\ \text{printf}("\n"); \end{array}
```

&

5.11 USBD_CONF_Exported_Types

Types.

Types.

5.12 USBD_CONF_Exported_FunctionsPrototype

Declaration of public functions for Usb device.

Declaration of public functions for Usb device.

5.13 USBD_DESC 23

5.13 USBD_DESC

Usb device descriptors module.

Modules

• USBD_DESC_Exported_Constants

Constants.

• USBD_DESC_Exported_Defines

Defines.

• USBD_DESC_Exported_TypesDefinitions

Types.

• USBD_DESC_Exported_Macros

Aliases.

• USBD_DESC_Exported_Variables

Public variables.

• USBD_DESC_Exported_FunctionsPrototype

Public functions declaration.

5.13.1 Detailed Description

Usb device descriptors module.

5.14 USBD_DESC_Exported_Constants

Constants.

Macros

- #define DEVICE_ID1 (UID_BASE)
- #define DEVICE_ID2 (UID_BASE + 0x4)
- #define DEVICE_ID3 (UID_BASE + 0x8)
- #define USB_SIZ_STRING_SERIAL 0x1A

5.14.1 Detailed Description

Constants.

5.14.2 Macro Definition Documentation

```
5.14.2.1 DEVICE_ID1
```

#define DEVICE_ID1 (UID_BASE)

&

5.14.2.2 DEVICE_ID2

```
#define DEVICE_ID2 (UID_BASE + 0x4)
```

&

5.14.2.3 DEVICE_ID3

#define DEVICE_ID3 (UID_BASE + 0x8)

&

5.14.2.4 USB_SIZ_STRING_SERIAL

#define USB_SIZ_STRING_SERIAL 0x1A

&

5.15 USBD_DESC_Exported_Defines

Defines.

Defines.

5.16	USBD	DESC	Exported	TypesDefinitions
------	------	------	----------	-------------------------

Types.

Types.

5.17 USBD_DESC_Exported_Macros

Aliases.

Aliases.

5.18 USBD_DESC_Exported_Variables

Public variables.

Variables

- USBD_DescriptorsTypeDef HS_Desc
- USBD_DescriptorsTypeDef FS_Desc

5.18.1 Detailed Description

Public variables.

5.18.2 Variable Documentation

5.18.2.1 FS_Desc

USBD_DescriptorsTypeDef FS_Desc

Descriptor for the Usb device.

5.18.2.2 HS_Desc

USBD_DescriptorsTypeDef HS_Desc

Descriptor for the Usb device.

5.19 USBD_DESC_Exported_FunctionsPrototype

Public functions declaration.

Public functions declaration.

5.20 STM32_USB_OTG_DEVICE_LIBRARY

For Usb device.

Modules

- USBD_CDC_IF
 - Usb VCP device module.
- USBD_DESC

Usb device descriptors module.

5.20.1 Detailed Description

For Usb device.

< Define to prevent recursive inclusion -----

5.21 USBD_OTG_DRIVER

Modules

• USBD_CONF

Configuration file for Usb otg low level driver.

5.21.1 Detailed Description

32 Module Documentation

Chapter 6

Class Documentation

6.1 daisy::AdcChannelConfig Struct Reference

```
#include <per_adc.h>
```

Public Types

enum MuxPin { MUX_SEL_0, MUX_SEL_1, MUX_SEL_2, MUX_SEL_LAST }

Public Member Functions

- void InitSingle (dsy_gpio_pin pin)
- void InitMux (dsy_gpio_pin adc_pin, dsy_gpio_pin mux_0, dsy_gpio_pin mux_1, dsy_gpio_pin mux_2, size
 _t channels)

Public Attributes

- dsy_gpio pin_
- dsy_gpio mux_pin_ [MUX_SEL_LAST]
- uint8_t mux_channels_

6.1.1 Detailed Description

Configuration Structure for a given channel

6.1.2 Member Enumeration Documentation

6.1.2.1 MuxPin

enum daisy::AdcChannelConfig::MuxPin

Which pin to use for multiplexing

Enumerator

MUX_SEL_0	&
MUX_SEL_1	&
MUX_SEL_2	&
MUX_SEL_LAST	&

6.1.3 Member Function Documentation

6.1.3.1 InitMux()

Initializes a single ADC pin as a Multiplexed ADC. Requires a CD4051 Multiplexor connected to the pin Internal Callbacks handle the pin addressing.

Parameters

channels	must be 1-8
mux_0	First mux pin
mux_1	Second mux pin
mux_2	Third mux pin
adc_pin	&

6.1.3.2 InitSingle()

Initializes a single ADC pin as an ADC.

Parameters

pin	Pin to init.

6.1.4 Member Data Documentation

```
6.1.4.1 mux_channels_
uint8_t daisy::AdcChannelConfig::mux_channels_
&
6.1.4.2 mux_pin_
dsy_gpio daisy::AdcChannelConfig::mux_pin_[MUX_SEL_LAST]
&
6.1.4.3 pin_
dsy_gpio daisy::AdcChannelConfig::pin_
```

The documentation for this struct was generated from the following file:

• src/per_adc.h

6.2 daisy::AdcHandle Class Reference

```
#include <per_adc.h>
```

Public Types

```
    enum OverSampling {
        OVS_NONE, OVS_4, OVS_8, OVS_16,
        OVS_32, OVS_64, OVS_128, OVS_256,
        OVS_512, OVS_1024, OVS_LAST }
```

Public Member Functions

- void Init (AdcChannelConfig *cfg, size_t num_channels, OverSampling ovs=OVS_32)
- void Start ()
- void Stop ()
- uint16_t Get (uint8_t chn)
- uint16_t * GetPtr (uint8_t chn)
- float GetFloat (uint8_t chn)
- uint16_t GetMux (uint8_t chn, uint8_t idx)
- uint16_t * GetMuxPtr (uint8_t chn, uint8_t idx)
- float GetMuxFloat (uint8_t chn, uint8_t idx)

6.2.1 Detailed Description

Handler for analog to digital conversion

6.2.2 Member Enumeration Documentation

6.2.2.1 OverSampling

```
enum daisy::AdcHandle::OverSampling
```

Supported oversampling amounts

Enumerator

OVS_NONE	&
OVS_4	&
OVS_8	&
OVS_16	&
OVS_32	&
OVS_64	&
OVS_128	&
OVS_256	&
OVS_512	&
OVS_1024	&
OVS_LAST	&

6.2.3 Member Function Documentation

6.2.3.1 Get()

Single channel getter

Parameters

chn	channel to get

Returns

Converted value

6.2.3.2 GetFloat()

```
float daisy::AdcHandle::GetFloat ( \label{eq:condition} \mbox{uint8\_t } chn \ )
```

Get floating point from single channel

Parameters

```
chn Channel to get from
```

Returns

Floating point converted value

6.2.3.3 GetMux()

Getters for multiplexed inputs on a single channel (up to 8 per ADC input).

Parameters

chn	Channel to get from
idx	&

Returns

data

6.2.3.4 GetMuxFloat()

Getters for multiplexed inputs on a single channel (up to 8 per ADC input).

Parameters

chn	Channel to get from
idx	&

Returns

Floating point data

6.2.3.5 GetMuxPtr()

Getters for multiplexed inputs on a single channel. (Max 8 per chan)

Parameters

chn	Channel to get from
idx	&

Returns

Pointer to data

6.2.3.6 GetPtr()

Get pointer to a value from a single channel

Parameters

chn

Returns

Pointer to converted value

6.2.3.7 Init()

```
void daisy::AdcHandle::Init (
         AdcChannelConfig * cfg,
         size_t num_channels,
         OverSampling ovs = OVS_32 )
```

Initializes the ADC with the pins passed in.

Parameters

*cfg	an array of AdcChannelConfig of the desired channel	
num_channels number of ADC channels to initialize		
ovs	Oversampling amount - Defaults to OVS_32	

6.2.3.8 Start()

```
void daisy::AdcHandle::Start ( )
```

Starts reading from the ADC

6.2.3.9 Stop()

```
void daisy::AdcHandle::Stop ( )
```

Stops reading from the ADC

The documentation for this class was generated from the following file:

• src/per_adc.h

6.3 daisy::AnalogControl Class Reference

Hardware Interface for control inputs Primarily designed for ADC input controls such as potentiometers, and control voltage.

#include <hid_ctrl.h>

Public Member Functions

- AnalogControl ()
- ∼AnalogControl ()
- void Init (uint16_t *adcptr, float sr, bool flip=false, bool invert=false, float slew_seconds=0.002f)
- void InitBipolarCv (uint16_t *adcptr, float sr)
- float Process ()
- float Value () const

6.3.1 Detailed Description

Hardware Interface for control inputs Primarily designed for ADC input controls such as potentiometers, and control voltage.

.

Author

Stephen Hensley

Date

November 2019

6.3.2 Constructor & Destructor Documentation

```
6.3.2.1 AnalogControl()
```

```
daisy::AnalogControl::AnalogControl ( ) [inline]
```

Constructor

6.3.2.2 \sim AnalogControl()

```
daisy::AnalogControl::~AnalogControl ( ) [inline]
```

destructor

6.3.3 Member Function Documentation

6.3.3.1 Init()

Initializes the control

Parameters

*adcptr	is a pointer to the raw adc read value – This can be acquired with dsy_adc_get_rawptr(), or dsy_adc_get_mux_rawptr()
sr	is the samplerate in Hz that the Process function will be called at.
flip	determines whether the input is flipped (i.e. 1.f - input) or not before being processed.1
invert	determines whether the input is inverted (i.e1.f * input) or note before being processed.
slew_seconds	is the slew time in seconds that it takes for the control to change to a new value.

6.3.3.2 InitBipolarCv()

```
void daisy::AnalogControl::InitBipolarCv (  \mbox{uint16\_t} \ * \ adcptr,   \mbox{float} \ sr \ )
```

This Initializes the AnalogControl for a -5V to 5V inverted input All of the Init details are the same otherwise

Parameters

*adcptr	Pointer to analog digital converter
sr	Audio engine sample rate

6.3.3.3 Process()

```
float daisy::AnalogControl::Process ( )
```

Filters, and transforms a raw ADC read into a normalized range. this should be called at the rate of specified by samplerate at Init time. Default Initializations will return 0.0 -> 1.0 Bi-polar CV inputs will return -1.0 -> 1.0

6.3.3.4 Value()

```
float daisy::AnalogControl::Value ( ) const [inline]
```

Returns the current stored value, without reprocessing

The documentation for this class was generated from the following file:

• src/hid_ctrl.h

6.4 codec_frame_t Struct Reference

```
#include <dev_codec_wm8731_frame.h>
```

Public Attributes

- short I
- short r

6.4.1 Detailed Description

&

6.4.2 Member Data Documentation

The documentation for this struct was generated from the following file:

• src/dev_codec_wm8731_frame.h

6.5 color Struct Reference

```
#include <dev_leddriver.h>
```

Public Attributes

- uint16_t red
- uint16_t green
- uint16_t blue

6.5.1 Detailed Description

Simple color struct Different from util_color only in type (0-4095 vs 0-1) This could easily be migrated to work with those instead.

6.5.2 Member Data Documentation

```
6.5.2.1 blue

uint16_t color::blue

&

6.5.2.2 green

uint16_t color::green

&

6.5.2.3 red

uint16_t color::red

&
```

The documentation for this struct was generated from the following file:

• src/dev_leddriver.h

6.6 daisy::Color Class Reference

```
#include <util_color.h>
```

Public Types

enum PresetColor {
 RED, GREEN, BLUE, WHITE,
 PURPLE, CYAN, GOLD, OFF,
 LAST }

Public Member Functions

- void Init (PresetColor c)
- void Init (float red, float green, float blue)
- float Red () const
- float Green () const
- float Blue () const

6.6.1 Detailed Description

Class for handling simple colors

6.6.2 Member Enumeration Documentation

6.6.2.1 PresetColor

```
enum daisy::Color::PresetColor
```

List of colors that have a preset RGB value

Enumerator

RED	&
GREEN	&
BLUE	&
WHITE	&
PURPLE	&
CYAN	&
GOLD	&
OFF	&
LAST	&

6.6.3 Member Function Documentation

```
6.6.3.1 Blue()
```

```
float daisy::Color::Blue ( ) const [inline]
```

Returns the 0-1 value for Blue

6.6.3.2 Green()

```
float daisy::Color::Green ( ) const [inline]
```

Returns the 0-1 value for Green

```
6.6.3.3 Init() [1/2]
```

Initializes the Color with a given preset.

Parameters

```
c Color to init to
```

Initializes the Color with a specific RGB value red, green, and blue should be floats between 0 and 1

Parameters

red	Red value
green	Green value
blue	Blue value

6.6.3.5 Red()

```
float daisy::Color::Red ( ) const [inline]
```

Returns the 0-1 value for Red

The documentation for this class was generated from the following file:

• src/util_color.h

6.7 daisy::ControlChangeEvent Struct Reference

```
#include <hid_midi.h>
```

Public Attributes

- int channel
- uint8_t control_number
- uint8_t value

6.7.1 Detailed Description

Struct containing control number, and value for a given channel. Can be made from MidiEvent

6.7.2 Member Data Documentation

```
6.7.2.1 channel
int daisy::ControlChangeEvent::channel
&
6.7.2.2 control_number
uint8_t daisy::ControlChangeEvent::control_number
&
6.7.2.3 value
```

The documentation for this struct was generated from the following file:

src/hid_midi.h

6.8 daisy::daisy_field Struct Reference

uint8_t daisy::ControlChangeEvent::value

```
#include <daisy_field.h>
```

Public Attributes

- daisy::DaisySeed seed
- daisy::Switch switches [SW_LAST]
- dsy_gpio gate_in
- dsy_gpio gate_out
- dsy_sr_4021_handle keyboard_sr
- AnalogControl knobs [KNOB_LAST]
- AnalogControl cvs [CV_LAST]

6.8.1 Detailed Description

Struct containing hardware defines and daisy seed

6.8.2 Member Data Documentation

```
6.8.2.1 cvs
AnalogControl daisy::daisy_field::cvs[CV_LAST]
Array of cv ins
6.8.2.2 gate_in
dsy_gpio daisy::daisy_field::gate_in
Gate input.
6.8.2.3 gate_out
dsy_gpio daisy::daisy_field::gate_out
Gate output
6.8.2.4 keyboard_sr
dsy_sr_4021_handle daisy::daisy_field::keyboard_sr
Keyboard shift register
6.8.2.5 knobs
AnalogControl daisy::daisy_field::knobs[KNOB_LAST]
Array of hardware knobs
6.8.2.6 seed
daisy::DaisySeed daisy::daisy_field::seed
Daisy seed
6.8.2.7 switches
daisy::Switch daisy::daisy_field::switches[SW_LAST]
Array of hardware switches
```

The documentation for this struct was generated from the following file:

• src/daisy_field.h

6.9 daisy::DaisyPatch Class Reference

Class that handles initializing all of the hardware specific to the Daisy Patch Board. Helper funtions are also in place to provide easy access to built-in controls and peripherals.

```
#include <daisy_patch.h>
```

Public Types

```
    enum Ctrl {
        CTRL_1, CTRL_2, CTRL_3, CTRL_4,
        CTRL_LAST }
    enum GateInput { GATE_IN_1, GATE_IN_2, GATE_IN_LAST }
```

Public Member Functions

```
• DaisyPatch ()
```

- ∼DaisyPatch ()
- void Init ()
- void DelayMs (size_t del)
- void SetAudioBlockSize (size_t size)
- void StartAudio (dsy_audio_mc_callback cb)
- void ChangeAudioCallback (dsy audio callback cb)
- void StartAdc ()
- float AudioSampleRate ()
- size_t AudioBlockSize ()
- float AudioCallbackRate ()
- void UpdateAnalogControls ()
- float GetCtrlValue (Ctrl k)
- · void DebounceControls ()
- void DisplayControls (bool invert=true)

Public Attributes

- · DaisySeed seed
- · Encoder encoder
- AnalogControl controls [CTRL_LAST]
- GateIn gate_input [GATE_IN_LAST]
- · MidiHandler midi
- · OledDisplay display
- dsy_gpio gate_output

6.9.1 Detailed Description

Class that handles initializing all of the hardware specific to the Daisy Patch Board. Helper funtions are also in place to provide easy access to built-in controls and peripherals.

Author

Stephen Hensley

Date

November 2019

6.9.2 Member Enumeration Documentation

6.9.2.1 Ctrl

enum daisy::DaisyPatch::Ctrl

Enum of Ctrls to represent the four CV/Knob combos on the Patch

6.9.2.2 GateInput

enum daisy::DaisyPatch::GateInput

Daisy patch gate inputs

Enumerator

GATE_IN_LAST <

6.9.3 Constructor & Destructor Documentation

6.9.3.1 DaisyPatch()

daisy::DaisyPatch::DaisyPatch () [inline]

Constructor

6.9.3.2 \sim DaisyPatch()

daisy::DaisyPatch::~DaisyPatch () [inline]

Destructor

6.9.4 Member Function Documentation

6.9.4.1 AudioBlockSize()

size_t daisy::DaisyPatch::AudioBlockSize ()

Get block size

6.9.4.2 AudioCallbackRate()

```
float daisy::DaisyPatch::AudioCallbackRate ( )
```

Get callback rate

6.9.4.3 AudioSampleRate()

```
float daisy::DaisyPatch::AudioSampleRate ( )
```

Get sample rate

6.9.4.4 ChangeAudioCallback()

```
void daisy::DaisyPatch::ChangeAudioCallback ( {\tt dsy\_audio\_callback}\ cb\ )
```

Change to a different callback function.

Parameters

cb New callback function.

6.9.4.5 DebounceControls()

```
void daisy::DaisyPatch::DebounceControls ( )
```

Debounce analog controls. Call at same rate as reading controls.

6.9.4.6 DelayMs()

Wait some ms before going on.

Parameters

```
del Delay time in ms.
```

6.9.4.7 DisplayControls()

```
void daisy::DaisyPatch::DisplayControls (
```

```
bool invert = true )
```

Control the display

6.9.4.8 GetCtrlValue()

Get value for a partiular control

Parameters

```
k Which control to get
```

6.9.4.9 Init()

```
void daisy::DaisyPatch::Init ( )
```

Initializes the daisy seed, and patch hardware.

6.9.4.10 SetAudioBlockSize()

Audio Block size defaults to 48. Change it using this function before StartingAudio

Parameters

```
size Audio block size.
```

6.9.4.11 StartAdc()

```
void daisy::DaisyPatch::StartAdc ( )
```

Start analog to digital conversion.

6.9.4.12 StartAudio()

Start audio output.

```
Parameters
```

```
cb Audio callback function
```

```
6.9.4.13 UpdateAnalogControls()
```

```
void daisy::DaisyPatch::UpdateAnalogControls ( )
```

Call at same rate as reading controls for good reads.

6.9.5 Member Data Documentation

```
6.9.5.1 controls
```

```
AnalogControl daisy::DaisyPatch::controls[CTRL_LAST]
```

Array of controls

6.9.5.2 display

```
OledDisplay daisy::DaisyPatch::display
```

&

6.9.5.3 encoder

```
Encoder daisy::DaisyPatch::encoder
```

Encoder object

6.9.5.4 gate_input

```
GateIn daisy::DaisyPatch::gate_input[GATE_IN_LAST]
```

Gate inputs

6.9.5.5 gate_output

```
dsy_gpio daisy::DaisyPatch::gate_output
```

&

```
6.9.5.6 midi
MidiHandler daisy::DaisyPatch::midi
Handles midi
6.9.5.7 seed
DaisySeed daisy::DaisyPatch::seed
```

Seed object

The documentation for this class was generated from the following file:

· src/daisy_patch.h

6.10 daisy::DaisyPetal Class Reference

Helpers and hardware definitions for daisy petal.

```
#include <daisy_petal.h>
```

Public Types

```
enum Sw {
    SW_1, SW_2, SW_3, SW_4,
    SW_5, SW_6, SW_7, SW_LAST }
enum Knob {
    KNOB_1, KNOB_2, KNOB_3, KNOB_4,
    KNOB_5, KNOB_6, KNOB_LAST }
enum RingLed {
    RING_LED_1, RING_LED_2, RING_LED_3, RING_LED_4,
    RING_LED_5, RING_LED_6, RING_LED_7, RING_LED_8,
    RING_LED_LAST }
enum FootswitchLed {
    FOOTSWITCH_LED_1, FOOTSWITCH_LED_2, FOOTSWITCH_LED_3, FOOTSWITCH_LED_4,
    FOOTSWITCH_LED_LAST }
```

Public Member Functions

- · DaisyPetal ()
- \sim DaisyPetal ()
- void Init ()
- void DelayMs (size_t del)
- void SetAudioBlockSize (size t size)
- void StartAudio (dsy_audio_callback cb)
- void ChangeAudioCallback (dsy_audio_callback cb)
- void StartAdc ()
- float AudioSampleRate ()
- size_t AudioBlockSize ()
- float AudioCallbackRate ()
- void UpdateAnalogControls ()
- float GetKnobValue (Knob k)
- float GetExpression ()
- void DebounceControls ()
- void ClearLeds ()
- void UpdateLeds ()
- void SetRingLed (RingLed idx, float r, float g, float b)
- void SetFootswitchLed (FootswitchLed idx, float bright)

Public Attributes

- · DaisySeed seed
- · Encoder encoder
- AnalogControl knob [KNOB_LAST]
- AnalogControl expression
- Switch switches [SW_LAST]
- RgbLed ring_led [8]
- Led footswitch_led [4]

6.10.1 Detailed Description

Helpers and hardware definitions for daisy petal.

6.10.2 Member Enumeration Documentation

6.10.2.1 FootswitchLed

enum daisy::DaisyPetal::FootswitchLed

footswitch leds

Enumerator

FOOTSWITCH_LED_1	&
FOOTSWITCH_LED_2	&
FOOTSWITCH_LED_3	&
FOOTSWITCH_LED_4	&
FOOTSWITCH_LED_LAST	&

6.10.2.2 Knob

enum daisy::DaisyPetal::Knob

Knobs

Enumerator

KNOB_1	&
KNOB_2	&
KNOB_3	&
KNOB_4	&
KNOB_5	&
KNOB_6	&
KNOR LAST	-&

6.10.2.3 RingLed

enum daisy::DaisyPetal::RingLed

Leds in ringled

Enumerator

RING_LED_1	&
RING_LED_2	&
RING_LED_3	&
RING_LED_4	&
RING_LED_5	&
RING_LED_6	&
RING_LED_7	&
RING_LED_8	&
RING_LED_LAST	&

6.10.2.4 Sw

enum daisy::DaisyPetal::Sw

Switches

Enumerator

SW_1	Footswitch
SW_2	Footswitch
SW_3	Footswitch
SW_4	Footswitch
SW_5	Toggle
SW_6	Toggle
SW_7	Toggle
SW_LAST	Last enum item

6.10.3 Constructor & Destructor Documentation

6.10.3.1 DaisyPetal()

daisy::DaisyPetal::DaisyPetal () [inline]

Constructor

```
6.10.3.2 \sim DaisyPetal()
daisy::DaisyPetal::~DaisyPetal ( ) [inline]
Destructor
6.10.4 Member Function Documentation
6.10.4.1 AudioBlockSize()
size_t daisy::DaisyPetal::AudioBlockSize ( )
Get audio block size
6.10.4.2 AudioCallbackRate()
float daisy::DaisyPetal::AudioCallbackRate ( )
Get callback rate
6.10.4.3 AudioSampleRate()
float daisy::DaisyPetal::AudioSampleRate ( )
Device audio sample rate.
6.10.4.4 ChangeAudioCallback()
void daisy::DaisyPetal::ChangeAudioCallback (
              dsy_audio_callback cb )
Change callback function
Parameters
 cb | New callback function.
6.10.4.5 ClearLeds()
void daisy::DaisyPetal::ClearLeds ( )
```

Turn all leds off

6.10.4.6 DebounceControls()

```
void daisy::DaisyPetal::DebounceControls ( )
```

Debounce inputs.

6.10.4.7 DelayMs()

Wait before moving on.

Parameters

```
del Delay time in ms.
```

6.10.4.8 GetExpression()

```
float daisy::DaisyPetal::GetExpression ( )
```

&

6.10.4.9 GetKnobValue()

Get value per knob.

Parameters

```
k Which knob to get
```

Returns

Floating point knob position.

6.10.4.10 Init()

```
void daisy::DaisyPetal::Init ( )
```

Initialize daisy petal

6.10.4.11 SetAudioBlockSize()

```
void daisy::DaisyPetal::SetAudioBlockSize ( {\tt size\_t~size~)}
```

Set size of audio blocks.

Parameters

```
size Audio block size
```

6.10.4.12 SetFootswitchLed()

Set footswitch LED

Parameters

idx	Led Index
bright	Brightness

6.10.4.13 SetRingLed()

```
void daisy::DaisyPetal::SetRingLed (
    RingLed idx,
    float r,
    float g,
    float b)
```

Set ring LED colors

Parameters

idx	Index to set
r	Red value
g	Green value
b	Blue value

```
6.10.4.14 StartAdc()
void daisy::DaisyPetal::StartAdc ( )
Start analog to digital conversion.
6.10.4.15 StartAudio()
void daisy::DaisyPetal::StartAudio (
              dsy_audio_callback cb )
Start audio callback
Parameters
 cb Callback function.
6.10.4.16 UpdateAnalogControls()
void daisy::DaisyPetal::UpdateAnalogControls ( )
Call at the same frequency as controls are read for stable readings.
6.10.4.17 UpdateLeds()
void daisy::DaisyPetal::UpdateLeds ( )
Update Leds to values you had set.
6.10.5 Member Data Documentation
6.10.5.1 encoder
Encoder daisy::DaisyPetal::encoder
&
6.10.5.2 expression
```

Generated by Doxygen

&

AnalogControl daisy::DaisyPetal::expression

```
6.10.5.3 footswitch_led
Led daisy::DaisyPetal::footswitch_led[4]
6.10.5.4 knob
AnalogControl daisy::DaisyPetal::knob[KNOB_LAST]
&
6.10.5.5 ring_led
RgbLed daisy::DaisyPetal::ring_led[8]
&
6.10.5.6 seed
DaisySeed daisy::DaisyPetal::seed
6.10.5.7 switches
Switch daisy::DaisyPetal::switches[SW_LAST]
< &
```

The documentation for this class was generated from the following file:

· src/daisy_petal.h

6.11 daisy::DaisyPod Class Reference

Class that handles initializing all of the hardware specific to the Daisy Patch Board. Helper funtions are also in place to provide easy access to built-in controls and peripherals.

```
#include <daisy_pod.h>
```

Public Types

```
• enum Sw { BUTTON_1, BUTTON_2, BUTTON_LAST }
```

enum Knob { KNOB_1, KNOB_2, KNOB_LAST }

Public Member Functions

- void Init ()
- void DelayMs (size_t del)
- void SetAudioBlockSize (size_t size)
- void StartAudio (dsy_audio_callback cb)
- void ChangeAudioCallback (dsy audio callback cb)
- void StartAdc ()
- float AudioSampleRate ()
- size_t AudioBlockSize ()
- float AudioCallbackRate ()
- void UpdateAnalogControls ()
- float GetKnobValue (Knob k)
- void DebounceControls ()
- void ClearLeds ()
- void UpdateLeds ()

Public Attributes

- · DaisySeed seed
- · Encoder encoder
- · AnalogControl knob1
- AnalogControl knob2
- AnalogControl * knobs [KNOB_LAST]
- Switch button1
- Switch button2
- Switch * buttons [BUTTON_LAST]
- · RgbLed led1
- RgbLed led2

6.11.1 Detailed Description

Class that handles initializing all of the hardware specific to the Daisy Patch Board. Helper funtions are also in place to provide easy access to built-in controls and peripherals.

Author

Stephen Hensley

Date

November 2019

6.11.2 Member Enumeration Documentation

6.11.2.1 Knob

enum daisy::DaisyPod::Knob

Knobs

Enumerator

KNOB_2	&
KNOB_LAST	&

6.11.2.2 Sw

enum daisy::DaisyPod::Sw

Switches

Enumerator

BUTTON_2	&
BUTTON_LAST	&

6.11.3 Member Function Documentation

```
6.11.3.1 AudioBlockSize()
```

```
size_t daisy::DaisyPod::AudioBlockSize ( )
```

Get block size

6.11.3.2 AudioCallbackRate()

```
float daisy::DaisyPod::AudioCallbackRate ( )
```

Get callback rate

6.11.3.3 AudioSampleRate()

```
float daisy::DaisyPod::AudioSampleRate ( )
```

Get sample rate

6.11.3.4 ChangeAudioCallback()

```
void daisy::DaisyPod::ChangeAudioCallback ( {\tt dsy\_audio\_callback}\ cb\ )
```

Switch callback functions

Parameters

```
cb New callback function.
```

6.11.3.8 GetKnobValue()

del Time to wait in ms.

Audio Block size defaults to 48. Change it using this function before StartingAudio.

Parameters

```
size Block size to set.
```

```
6.11.3.11 StartAdc()
```

```
void daisy::DaisyPod::StartAdc ( )
```

Start analog to digital conversion.

6.11.3.12 StartAudio()

Start audio callback

Parameters

```
cb Callback function.
```

6.11.3.13 UpdateAnalogControls()

```
void daisy::DaisyPod::UpdateAnalogControls ( )
```

Call at same rate as analog reads for smooth reading.

6.11.3.14 UpdateLeds()

```
void daisy::DaisyPod::UpdateLeds ( )
```

Update Leds to set colors

6.11.4 Member Data Documentation

6.11.4.1 button1

```
Switch daisy::DaisyPod::button1
```

&

Generated by Doxygen

```
6.11.4.2 button2
Switch daisy::DaisyPod::button2
&
6.11.4.3 buttons
Switch * daisy::DaisyPod::buttons[BUTTON_LAST]
6.11.4.4 encoder
Encoder daisy::DaisyPod::encoder
&
6.11.4.5 knob1
AnalogControl daisy::DaisyPod::knob1
6.11.4.6 knob2
AnalogControl daisy::DaisyPod::knob2
&
6.11.4.7 knobs
AnalogControl * daisy::DaisyPod::knobs[KNOB_LAST]
&
6.11.4.8 led1
RgbLed daisy::DaisyPod::led1
&
6.11.4.9 led2
RgbLed daisy::DaisyPod::led2
&
```

6.11.4.10 seed

DaisySeed daisy::DaisyPod::seed

Public Members

The documentation for this class was generated from the following file:

• src/daisy_pod.h

6.12 daisy::DaisySeed Class Reference

This is the higher-level interface for the Daisy board.

All basic peripheral configuration/initialization is setup here.

```
#include <daisy_seed.h>
```

Public Member Functions

- void Configure ()
- void Init ()
- dsy_gpio_pin GetPin (uint8_t pin_idx)
- void StartAudio (dsy_audio_callback cb)
- void SetLed (bool state)
- void SetTestPoint (bool state)
- float AudioSampleRate ()
- void SetAudioBlockSize (size_t blocksize)

Public Attributes

- · dsy_sdram_handle sdram_handle
- dsy_qspi_handle qspi_handle
- dsy_audio_handle audio_handle
- dsy_sai_handle sai_handle
- dsy_i2c_handle i2c1_handle
- dsy_i2c_handle i2c2_handle
- · AdcHandle adc
- dsy_dac_handle dac_handle
- UsbHandle usb_handle

6.12.1 Detailed Description

This is the higher-level interface for the Daisy board.
All basic peripheral configuration/initialization is setup here.

6.12.2 Member Function Documentation

6.12.2.1 AudioSampleRate()

```
float daisy::DaisySeed::AudioSampleRate ( )
```

Returns the audio sample rate in Hz as a floating point number.

6.12.2.2 Configure()

```
void daisy::DaisySeed::Configure ( )
```

Configures the settings for all internal peripherals, but does not initialize them. This allows for modification of the configuration handles prior to initialization.&

6.12.2.3 GetPin()

Returns the gpio_pin corresponding to the index 0-31. For the given GPIO on the Daisy Seed (labeled 1-32 in docs).

6.12.2.4 Init()

```
void daisy::DaisySeed::Init ( )
```

Initializes the Daisy Seed and the following peripherals: SDRAM, QSPI, 24-bit 48kHz Audio via AK4556, Internal USB, as well as the built-in LED and Testpoint.

ADCs, DACs, and other special peripherals (such as I2C, SPI, etc.) can be initialized using their specific initializers within libdaisy for a specific application.

6.12.2.5 SetAudioBlockSize()

Sets the number of samples processed per channel by the audio callback.

6.12.2.6 SetLed()

Sets the state of the built in LED

6.12.2.7 SetTestPoint()

Sets the state of the test point near pin 10

6.12.2.8 StartAudio()

Begins the audio for the seeds builtin audio. the specified callback will get called whenever new data is ready to be prepared.

6.12.3 Member Data Documentation

```
6.12.3.1 adc
```

AdcHandle daisy::DaisySeed::adc

&

6.12.3.2 audio_handle

```
dsy_audio_handle daisy::DaisySeed::audio_handle
```

&

6.12.3.3 dac_handle

```
dsy_dac_handle daisy::DaisySeed::dac_handle
```

&

6.12.3.4 i2c1_handle

```
dsy_i2c_handle daisy::DaisySeed::i2c1_handle
```

&

```
6.12.3.5 i2c2_handle
dsy_i2c_handle daisy::DaisySeed::i2c2_handle
6.12.3.6 qspi_handle
dsy_qspi_handle daisy::DaisySeed::qspi_handle
&
6.12.3.7 sai_handle
dsy_sai_handle daisy::DaisySeed::sai_handle
&
6.12.3.8 sdram_handle
dsy_sdram_handle daisy::DaisySeed::sdram_handle
&
6.12.3.9 usb_handle
UsbHandle daisy::DaisySeed::usb_handle
&
```

The documentation for this class was generated from the following file:

• src/daisy_seed.h

6.13 dsy_audio_handle Struct Reference

```
#include <hid_audio.h>
```

Public Attributes

- size_t block_size
- dsy_sai_handle * sai
- dsy_i2c_handle * dev0_i2c
- dsy_i2c_handle * dev1_i2c

6.13.1 Detailed Description

Simple config struct that holds peripheral drivers.

6.13.2 Member Data Documentation

```
6.13.2.1 block_size

size_t dsy_audio_handle::block_size

&
6.13.2.2 dev0_i2c

dsy_i2c_handle* dsy_audio_handle::dev0_i2c

&
6.13.2.3 dev1_i2c

dsy_i2c_handle* dsy_audio_handle::dev1_i2c

&
6.13.2.4 sai

dsy_sai_handle* dsy_audio_handle::sai

&
```

The documentation for this struct was generated from the following file:

• src/hid_audio.h

6.14 dsy_dac_handle Struct Reference

```
#include <per_dac.h>
```

Public Attributes

- dsy_dac_mode mode
- dsy_dac_bitdepth bitdepth
- dsy_gpio_pin pin_config [DSY_DAC_CHN_LAST]

6.14.1 Detailed Description

Configuration structure for DAC initialization and settings. pin_config must be filled out. However, the DACs are pretty consistently on pins PA4, and PA5 across all STM32 MCUs that I've used.

6.14.2 Member Data Documentation

```
6.14.2.1 bitdepth
dsy_dac_bitdepth dsy_dac_handle::bitdepth
&
6.14.2.2 mode
dsy_dac_mode dsy_dac_handle::mode
&
6.14.2.3 pin_config
dsy_gpio_pin dsy_dac_handle::pin_config[DSY_DAC_CHN_LAST]
```

The documentation for this struct was generated from the following file:

• src/per_dac.h

6.15 dsy_gpio Struct Reference

```
#include <per_gpio.h>
```

Public Attributes

- dsy_gpio_pin pin
- dsy_gpio_mode mode
- dsy_gpio_pull pull

6.15.1 Detailed Description

Struct for holding the pin, and configuration

6.15.2 Member Data Documentation

```
6.15.2.1 mode

dsy_gpio_mode dsy_gpio::mode

&

6.15.2.2 pin

dsy_gpio_pin dsy_gpio::pin

&

6.15.2.3 pull

dsy_gpio_pull dsy_gpio::pull

&
```

The documentation for this struct was generated from the following file:

• src/per_gpio.h

6.16 dsy_gpio_pin Struct Reference

```
#include <daisy_core.h>
```

Public Attributes

- dsy_gpio_port port
- uint8_t pin

6.16.1 Detailed Description

Hardware define pins

6.16.2 Member Data Documentation

```
6.16.2.1 pin

uint8_t dsy_gpio_pin::pin

number 0-15

6.16.2.2 port

dsy_gpio_port dsy_gpio_pin::port
```

The documentation for this struct was generated from the following file:

• src/daisy_core.h

6.17 dsy_i2c_handle Struct Reference

```
#include <per_i2c.h>
```

Public Attributes

- dsy_i2c_periph periph
- dsy_gpio_pin pin_config [DSY_I2C_PIN_LAST]
- dsy_i2c_speed speed

6.17.1 Detailed Description

this object will be used to initialize the I2C interface, and can be passed to dev_drivers that require I2C.

6.17.2 Member Data Documentation

```
6.17.2.1 periph

dsy_i2c_periph dsy_i2c_handle::periph

&

6.17.2.2 pin_config

dsy_gpio_pin dsy_i2c_handle::pin_config[DSY_I2C_PIN_LAST]

&
```

6.17.2.3 speed

```
dsy_i2c_speed dsy_i2c_handle::speed
```

&

The documentation for this struct was generated from the following file:

• src/per_i2c.h

6.18 dsy_qspi_handle Struct Reference

```
#include <per_qspi.h>
```

Public Attributes

- dsy_qspi_mode mode
- dsy_qspi_device device
- dsy_gpio_pin pin_config [DSY_QSPI_PIN_LAST]

6.18.1 Detailed Description

Configuration structure for interfacing with QSPI Driver

6.18.2 Member Data Documentation

```
6.18.2.1 device
```

dsy_qspi_device dsy_qspi_handle::device

&

6.18.2.2 mode

dsy_qspi_mode dsy_qspi_handle::mode

&

6.18.2.3 pin_config

```
dsy_gpio_pin dsy_qspi_handle::pin_config[DSY_QSPI_PIN_LAST]
```

&

The documentation for this struct was generated from the following file:

· src/per_qspi.h

6.19 dsy_sai_handle Struct Reference

```
#include <per_sai.h>
```

Public Attributes

- · dsy_audio_sai init
- dsy_audio_samplerate samplerate [DSY_SAI_LAST]
- dsy_audio_bitdepth bitdepth [DSY_SAI_LAST]
- dsy audio dir a direction [DSY SAI LAST]
- dsy_audio_dir b_direction [DSY_SAI_LAST]
- dsy_audio_sync sync_config [DSY_SAI_LAST]
- dsy_audio_device device [DSY_SAI_LAST]
- dsy_gpio_pin sai1_pin_config [DSY_SAI_PIN_LAST]
- dsy_gpio_pin sai2_pin_config [DSY_SAI_PIN_LAST]

6.19.1 Detailed Description

Configuration structure for SAI contains all above settings, and passes them to internal structure for hardware initialization.

6.19.2 Member Data Documentation

```
6.19.2.1 a_direction

dsy_audio_dir dsy_sai_handle::a_direction[DSY_SAI_LAST]

&
6.19.2.2 b_direction

dsy_audio_dir dsy_sai_handle::b_direction[DSY_SAI_LAST]
```

&

```
6.19.2.3 bitdepth
dsy_audio_bitdepth dsy_sai_handle::bitdepth[DSY_SAI_LAST]
6.19.2.4 device
dsy_audio_device dsy_sai_handle::device[DSY_SAI_LAST]
&
6.19.2.5 init
dsy_audio_sai dsy_sai_handle::init
&
6.19.2.6 sai1_pin_config
dsy_gpio_pin dsy_sai_handle::sail_pin_config[DSY_SAI_PIN_LAST]
&
6.19.2.7 sai2_pin_config
dsy_gpio_pin dsy_sai_handle::sai2_pin_config[DSY_SAI_PIN_LAST]
&
6.19.2.8 samplerate
dsy_audio_samplerate dsy_sai_handle::samplerate[DSY_SAI_LAST]
&
6.19.2.9 sync_config
dsy_audio_sync dsy_sai_handle::sync_config[DSY_SAI_LAST]
&
The documentation for this struct was generated from the following file:
    src/per_sai.h
```

6.20 DSY_SD_CardInfoTypeDef Struct Reference

#include <util_bsp_sd_diskio.h>

Public Attributes

- uint32_t CardType
- uint32_t CardVersion
- uint32_t Class
- uint32_t RelCardAdd
- uint32_t BlockNbr
- uint32_t BlockSize
- uint32_t LogBlockNbr
- uint32_t LogBlockSize
- uint32_t CardSpeed

6.20.1 Detailed Description

Functions for handling DisklO via SDMMC These are usually configured through the FatFS driver/interface, and won't need to be accessed directly often.

6.20.2 Member Data Documentation

6.20.2.1 BlockNbr

uint32_t DSY_SD_CardInfoTypeDef::BlockNbr

Specifies the Card Capacity in blocks

6.20.2.2 BlockSize

uint32_t DSY_SD_CardInfoTypeDef::BlockSize

Specifies one block size in bytes

6.20.2.3 CardSpeed

uint32_t DSY_SD_CardInfoTypeDef::CardSpeed

Specifies the card Speed

6.20.2.4 CardType

uint32_t DSY_SD_CardInfoTypeDef::CardType

Specifies the card Type

6.20.2.5 CardVersion

uint32_t DSY_SD_CardInfoTypeDef::CardVersion

Specifies the card version

6.20.2.6 Class

uint32_t DSY_SD_CardInfoTypeDef::Class

Specifies the class of the card class

6.20.2.7 LogBlockNbr

uint32_t DSY_SD_CardInfoTypeDef::LogBlockNbr

Specifies the Card logical Capacity in blocks

6.20.2.8 LogBlockSize

uint32_t DSY_SD_CardInfoTypeDef::LogBlockSize

Specifies logical block size in bytes

6.20.2.9 RelCardAdd

uint32_t DSY_SD_CardInfoTypeDef::RelCardAdd

Specifies the Relative Card Address

The documentation for this struct was generated from the following file:

• src/util_bsp_sd_diskio.h

6.21 dsy_sdram_handle Struct Reference

#include <dev_sdram.h>

Public Attributes

- dsy_sdram_state state
- dsy_gpio_pin pin_config [DSY_SDRAM_PIN_LAST]

6.21.1 Detailed Description

Configuration struct for passing to initialization

6.21.2 Member Data Documentation

```
6.21.2.1 pin_config

dsy_gpio_pin dsy_sdram_handle::pin_config[DSY_SDRAM_PIN_LAST]
&
6.21.2.2 state

dsy_sdram_state dsy_sdram_handle::state
```

The documentation for this struct was generated from the following file:

· src/dev sdram.h

&

6.22 dsy_sr_4021_handle Struct Reference

```
#include <dev_sr_4021.h>
```

Public Attributes

- dsy_gpio_pin pin_config [DSY_SR_4021_PIN_LAST]
- uint8_t num_parallel
- uint8_t num_daisychained
- dsy_gpio cs
- dsy_gpio clk
- dsy_gpio data [2]
- uint8_t states [8 *1 *2]

6.22.1 Detailed Description

configuration strucutre for 4021 pin config is used to initialize the dsy_gpio num_parallel is the number of devices connected that share the same clk/cs, etc. but have independent data num_daisychained is the number of devices in a daisy-chain configuration

6.22.2 Member Data Documentation

6.22.2.1 clk

```
dsy_gpio dsy_sr_4021_handle::clk
clk pin
6.22.2.2 cs
dsy_gpio dsy_sr_4021_handle::cs
cs pin
6.22.2.3 data
dsy_gpio dsy_sr_4021_handle::data[2]
array of data pins
6.22.2.4 num_daisychained
uint8_t dsy_sr_4021_handle::num_daisychained
Number of devices daisy chained
6.22.2.5 num_parallel
uint8_t dsy_sr_4021_handle::num_parallel
number of devices connected
6.22.2.6 pin_config
dsy_gpio_pin dsy_sr_4021_handle::pin_config[DSY_SR_4021_PIN_LAST]
used to initialize the dsy_gpio
```

6.22.2.7 states

```
uint8_t dsy_sr_4021_handle::states[8 * 1 * 2]
```

array of states

The documentation for this struct was generated from the following file:

src/dev_sr_4021.h

6.23 daisy::Encoder Class Reference

Generic Class for handling Quadrature Encoders Inspired/influenced by Mutable Instruments (pichenettes) Encoder classes.

```
#include <hid_encoder.h>
```

Public Member Functions

- void Init (dsy_gpio_pin a, dsy_gpio_pin b, dsy_gpio_pin click, float update_rate)
- void Debounce ()
- int32_t Increment () const
- bool RisingEdge () const
- bool FallingEdge () const
- bool Pressed () const
- float TimeHeldMs () const

6.23.1 Detailed Description

Generic Class for handling Quadrature Encoders
Inspired/influenced by Mutable Instruments (pichenettes) Encoder classes.

Author

Stephen Hensley

Date

December 2019

6.23.2 Member Function Documentation

6.23.2.1 Debounce()

```
void daisy::Encoder::Debounce ( )
```

Called at update_rate to debounce and handle timing for the switch. In order for events not to be missed, its important that the Edge/Pressed checks be made at the same rate as the debounce function is being called.

6.23.2.2 FallingEdge()

```
bool daisy::Encoder::FallingEdge ( ) const [inline]
```

Returns true if the encoder was just released.

6.23.2.3 Increment()

```
int32_t daisy::Encoder::Increment ( ) const [inline]
```

Returns +1 if the encoder was turned clockwise, -1 if it was turned counter-clockwise, or 0 if it was not just turned.

6.23.2.4 Init()

Initializes the encoder with the specified hardware pins. Update rate should be the rate at which Debounce() gets called in Hertz.

6.23.2.5 Pressed()

```
bool daisy::Encoder::Pressed ( ) const [inline]
```

Returns true while the encoder is held down.

6.23.2.6 RisingEdge()

```
bool daisy::Encoder::RisingEdge ( ) const [inline]
```

Returns true if the encoder was just pressed.

6.23.2.7 TimeHeldMs()

```
float daisy::Encoder::TimeHeldMs ( ) const [inline]
```

Returns the time in milliseconds that the encoder has been held down.

The documentation for this class was generated from the following file:

src/hid_encoder.h

6.24 FontDef Struct Reference

```
#include <util_oled_fonts.h>
```

Public Attributes

- const uint8_t FontWidth
- uint8_t FontHeight
- const uint16_t * data

6.24.1 Detailed Description

Utility for displaying fonts on OLED displays Migrated to work with libdaisy from stm32-ssd1306

Author

afiskon on github. Font struct

6.24.2 Member Data Documentation

6.24.2.1 data

```
const uint16_t* FontDef::data
```

Pointer to data font data array

6.24.2.2 FontHeight

uint8_t FontDef::FontHeight

Font height in pixels

6.24.2.3 FontWidth

```
const uint8_t FontDef::FontWidth
```

Font width in pixels

The documentation for this struct was generated from the following file:

src/util_oled_fonts.h

6.25 daisy::GateIn Class Reference

Generic Class for handling gate inputs through GPIO.

```
#include <hid_gatein.h>
```

Public Member Functions

- GateIn ()
- ∼GateIn ()
- void Init (dsy_gpio_pin *pin_cfg)
- bool Trig ()

6.25.1 Detailed Description

Generic Class for handling gate inputs through GPIO.

Author

Stephen Hensley

Date

March 2020

6.25.2.1 GateIn()

GateIn \sim Destructor

6.25.2 Constructor & Destructor Documentation

```
daisy::GateIn::GateIn ( ) [inline]
GateIn Constructor
```

```
6.25.2.2 ~GateIn()
daisy::GateIn::~GateIn ( ) [inline]
```

6.25.3 Member Function Documentation

Init Initializes the gate input with specified hardware pin

```
6.25.3.2 Trig()
```

```
bool daisy::GateIn::Trig ( )
```

Trig Checks current state of gate input.

Returns

FALSE if pin is low, and TRUE if high

The documentation for this class was generated from the following file:

· src/hid gatein.h

6.26 daisy::Led Class Reference

LED Class providing simple Software PWM ability, etc

Eventually this will work with hardware PWM, and external LED Driver devices as well.

```
#include <hid_led.h>
```

Public Member Functions

- void Init (dsy gpio pin pin, bool invert, float samplerate=1000.0f)
- · void Set (float val)
- void Update ()

6.26.1 Detailed Description

LED Class providing simple Software PWM ability, etc

Eventually this will work with hardware PWM, and external LED Driver devices as well.

Author

shensley

Date

March 2020

6.26.2 Member Function Documentation

```
6.26.2.1 Init()
```

Initializes an LED using the specified hardware pin.

Parameters

pin chooses LED pin		chooses LED pin
	invert	will set whether to internally invert the brightness due to hardware config.
	samplerate	sets the rate at which 'Update()' will be called (used for software PWM)

6.26.2.2 Set()

```
void daisy::Led::Set (
          float val )
```

Sets the brightness of the Led.

Parameters

val

will be cubed for gamma correction, and then quantized to 8-bit values for Software PWM 8-bit is for more flexible update rate options, as 12-bit or more would require faster update rates.

6.26.2.3 Update()

```
void daisy::Led::Update ( )
```

This processes the pwm of the LED sets the hardware accordingly.

The documentation for this class was generated from the following file:

• src/hid_led.h

6.27 daisy::MidiEvent Struct Reference

```
#include <hid_midi.h>
```

Public Member Functions

- NoteOnEvent AsNoteOn ()
- ControlChangeEvent AsControlChange ()

Public Attributes

- MidiMessageType type
- int channel
- uint8_t data [2]

6.27.1 Detailed Description

Simple MidiEvent with message type, channel, and data[2] members.

6.27.2 Member Function Documentation

6.27.2.1 AsControlChange()

```
ControlChangeEvent daisy::MidiEvent::AsControlChange ( ) [inline]
```

Returns the data within the MidiEvent as a NoteOnEvent struct.

6.27.2.2 AsNoteOn()

```
NoteOnEvent daisy::MidiEvent::AsNoteOn ( ) [inline]
```

Returns the data within the MidiEvent as a NoteOnEvent struct

6.27.3 Member Data Documentation

6.27.3.1 channel

```
int daisy::MidiEvent::channel
```

&

6.27.3.2 data

```
uint8_t daisy::MidiEvent::data[2]
```

ጲ

6.27.3.3 type

```
MidiMessageType daisy::MidiEvent::type
```

&

The documentation for this struct was generated from the following file:

• src/hid_midi.h

6.28 daisy::MidiHandler Class Reference

Simple MIDI Handler

Parses bytes from an input into valid MidiEvents.

The MidiEvents fill a FIFO queue that the user can pop messages from.

```
#include <hid midi.h>
```

Public Types

- enum MidiInputMode { INPUT_MODE_NONE = 0x00, INPUT_MODE_UART1 = 0x01, INPUT_MODE_US

 B_INT = 0x02, INPUT_MODE_USB_EXT = 0x04 }
- enum MidiOutputMode { OUTPUT_MODE_NONE = 0x00, OUTPUT_MODE_UART1 = 0x01, OUTPUT_M
 ODE_USB_INT = 0x02, OUTPUT_MODE_USB_EXT = 0x04 }

Public Member Functions

- void Init (MidiInputMode in mode, MidiOutputMode out mode)
- void StartReceive ()
- void Listen ()
- void Parse (uint8_t byte)
- bool HasEvents () const
- MidiEvent PopEvent ()

6.28.1 Detailed Description

Simple MIDI Handler

Parses bytes from an input into valid MidiEvents.

The MidiEvents fill a FIFO queue that the user can pop messages from.

Author

shensley

Date

March 2020

6.28.2 Member Enumeration Documentation

6.28.2.1 MidiInputMode

enum daisy::MidiHandler::MidiInputMode

Input and Output can be configured separately Multiple Input modes can be selected by OR'ing the values.

Enumerator

INPUT_MODE_NONE	&
INPUT_MODE_UART1	&
INPUT_MODE_USB_INT	&
INPUT_MODE_USB_EXT	&

6.28.2.2 MidiOutputMode

enum daisy::MidiHandler::MidiOutputMode

Output mode

Enumerator

OUTPUT_MODE_NONE	&
OUTPUT_MODE_UART1	&
OUTPUT_MODE_USB_INT	&
OUTPUT_MODE_USB_EXT	&

6.28.3 Member Function Documentation

6.28.3.1 HasEvents()

```
bool daisy::MidiHandler::HasEvents ( ) const [inline]
```

Checks if there are unhandled messages in the queue

Returns

True if there are events to be handled, else false.

6.28.3.2 Init()

Initializes the MidiHandler

Parameters

in_mode	Input mode
out_mode	Output mode

6.28.3.3 Listen()

```
void daisy::MidiHandler::Listen ( )
```

Start listening

6.28.3.4 Parse()

Feed in bytes to state machine from a queue. Populates internal FIFO queue with MIDI Messages For example with uart: midi.Parse(uart.PopRx());

Parameters



6.28.3.5 PopEvent()

```
MidiEvent daisy::MidiHandler::PopEvent ( ) [inline]
```

Pops the oldest unhandled MidiEvent from the internal queue

Returns

The event to be handled

6.28.3.6 StartReceive()

```
void daisy::MidiHandler::StartReceive ( )
```

Starts listening on the selected input mode(s). MidiEvent Queue will begin to fill, and can be checked with

The documentation for this class was generated from the following file:

• src/hid_midi.h

6.29 daisy::NoteOnEvent Struct Reference

```
#include <hid_midi.h>
```

Public Attributes

- int channel
- uint8 t note
- uint8_t velocity

6.29.1 Detailed Description

Struct containing note, and velocity data for a given channel. Can be made from MidiEvent

6.29.2 Member Data Documentation

6.29.2.1 channel

int daisy::NoteOnEvent::channel

&

6.29.2.2 note

uint8_t daisy::NoteOnEvent::note

&

6.29.2.3 velocity

uint8_t daisy::NoteOnEvent::velocity

&

The documentation for this struct was generated from the following file:

• src/hid_midi.h

6.30 daisy::OledDisplay Class Reference

#include <hid_oled_display.h>

Public Types

enum Pins { DATA_COMMAND, RESET, NUM_PINS }

Public Member Functions

- void Init (dsy_gpio_pin *pin_cfg)
- void Fill (bool on)
- void DrawPixel (uint8_t x, uint8_t y, bool on)
- char WriteChar (char ch, FontDef font, bool on)
- char WriteString (char *str, FontDef font, bool on)
- void SetCursor (uint8_t x, uint8_t y)
- void Update ()

6.30.1 Detailed Description

Human Interface Driver for using an OLED Display (SSD1309) For all bool on arguments: true is on, false is off. Credit to Aleksander Alekseev (github.com/afiskon/stm32-ssd1306) on github for a great starting point. adapted for SSD1309 and H7 by shensley, 2020

6.30.2 Member Enumeration Documentation

6.30.2.1 Pins

```
enum daisy::OledDisplay::Pins
```

GPIO Pins that need to be used independent of peripheral used.

Enumerator

DATA_COMMAND	Data command pin.
RESET	Reset pin
NUM_PINS	Num pins

6.30.3 Member Function Documentation

6.30.3.1 DrawPixel()

Sets the pixel at the specified coordinate to be on/off.

Parameters

Х	x Coordinate
У	y coordinate
on	on or off

6.30.3.2 Fill()

```
void daisy::OledDisplay::Fill (
          bool on )
```

Fills the entire display with either on/off.

Parameters

```
on Sets on or off.
```

6.30.3.3 Init()

Takes an argument for the pin cfg

Parameters

pin_cfg should be a pointer to an array of OledDisplay::NUM_PINS dsy_gpio_pins

6.30.3.4 SetCursor()

```
void daisy::OledDisplay::SetCursor (  \mbox{uint8\_t } x, \\ \mbox{uint8\_t } y \; )
```

Moves the 'Cursor' position used for WriteChar, and WriteStr to the specified coordinate.

Parameters

Х	x pos
У	y pos

6.30.3.5 Update()

```
void daisy::OledDisplay::Update ( )
```

Writes the current display buffer to the OLED device using SPI or I2C depending on how the object was initialized.

6.30.3.6 WriteChar()

Writes the character with the specific FontDef to the display buffer at the current Cursor position.

Parameters

ch	character to be written	
font	font to be written in	
on	on or off	

Returns

&

6.30.3.7 WriteString()

Similar to WriteChar, except it will handle an entire String. Wrapping does not happen automatically, so the width of the string must be kept within the dimensions of the screen.

Parameters

str	string to be written
font	font to use
on	on or off

Returns

&

The documentation for this class was generated from the following file:

• src/hid_oled_display.h

6.31 daisy::Parameter Class Reference

```
#include <hid_parameter.h>
```

Public Types

```
    enum Curve {
        LINEAR, EXPONENTIAL, LOGARITHMIC, CUBE,
        LAST }
```

Public Member Functions

- Parameter ()
- ∼Parameter ()
- void Init (AnalogControl input, float min, float max, Curve curve)
- float Process ()
- float Value ()

6.31.1 Detailed Description

Simple parameter mapping tool that takes a 0-1 input from an hid_ctrl.

6.31.2 Member Enumeration Documentation

6.31.2.1 Curve

```
enum daisy::Parameter::Curve
```

Curves are applied to the output signal

Enumerator

LINEAR	Linear curve
EXPONENTIAL	Exponential curve
LOGARITHMIC	Logarithmic curve
CUBE	Cubic curve
LAST	Final enum element.

6.31.3 Constructor & Destructor Documentation

```
6.31.3.1 Parameter()

daisy::Parameter::Parameter ( ) [inline]

Constructor

6.31.3.2 ~Parameter()

daisy::Parameter::~Parameter ( ) [inline]
```

6.31.4 Member Function Documentation

6.31.4.1 Init()

Destructor

initialize a parameter using an hid_ctrl object.

Parameters

input	- object containing the direct link to a hardware control source.	
min	- bottom of range. (when input is 0.0)	
max	- top of range (when input is 1.0)	
curve - the scaling curve for the input->output transformation.		

6.31.4.2 Process()

```
float daisy::Parameter::Process ( )
```

processes the input signal, this should be called at the samplerate of the hid_ctrl passed in.

Returns

a float with the specified transformation applied.

6.31.4.3 Value()

```
float daisy::Parameter::Value ( ) [inline]
```

Returns

the current value from the parameter without processing another sample. this is useful if you need to use the value multiple times, and don't store the output of process in a local variable.

The documentation for this class was generated from the following file:

• src/hid_parameter.h

6.32 daisy::RgbLed Class Reference

```
#include <hid_rgb_led.h>
```

Public Member Functions

- void Init (dsy_gpio_pin red, dsy_gpio_pin green, dsy_gpio_pin blue, bool invert)
- void Set (float r, float g, float b)
- void SetColor (Color c)
- void Update ()

6.32.1 Detailed Description

 $3x\ LEDs$ configured as an RGB for ease of use.

6.32.2 Member Function Documentation

6.32.2.1 Init()

Initializes 3x GPIO Pins as red, green, and blue elements of an RGB LED

Parameters

red	Red element
green	Green element
blue	Blue element
invert	Flips led polarity

6.32.2.2 Set()

Sets each element of the LED with a floating point number 0-1

Parameters

r	Red element
g	Green element
b	Blue element

6.32.2.3 SetColor()

```
void daisy::RgbLed::SetColor ( {	t Color}\ c )
```

Sets the RGB using a Color object.

Parameters

```
c Color object to set.
```

6.32.2.4 Update()

```
void daisy::RgbLed::Update ( )
```

Updates the PWM of the LED based on the current values. Should be called at a regular interval. (i.e. 1kHz/1ms)

The documentation for this class was generated from the following file:

```
• src/hid_rgb_led.h
```

6.33 daisy::RingBuffer < T, size > Class Template Reference

```
#include <util_ringbuffer.h>
```

Public Member Functions

- void Init ()
- size_t capacity () const
- size_t writable () const
- size_t readable () const
- void Write (T v)
- void Overwrite (T v)
- T Read ()
- T ImmediateRead ()
- void Flush ()
- void Swallow (size_t n)
- void ImmediateRead (T *destination, size_t num_elements)
- void Overwrite (const T *source, size_t num_elements)

6.33.1 Detailed Description

```
template<typename T, size_t size> class daisy::RingBuffer< T, size >
```

Utility Ring Buffer imported from pichenettes/stmlib

6.33.2 Member Function Documentation

6.33.2.1 capacity()

```
template<typename T, size_t size>
size_t daisy::RingBuffer< T, size >::capacity ( ) const [inline]
```

Returns

The total size of the ring buffer

6.33.2.2 Flush()

```
template<typename T, size_t size>
void daisy::RingBuffer< T, size >::Flush ( ) [inline]
```

Flushes unread elements from the ring buffer

6.33.2.3 ImmediateRead() [1/2]

```
template<typename T, size_t size>
T daisy::RingBuffer< T, size >::ImmediateRead ( ) [inline]
```

Reads next element from ring buffer immediately

Returns

read value

6.33.2.4 ImmediateRead() [2/2]

Reads a number of elements into a buffer immediately

Parameters

destination	buffer to write to
num_elements	number of elements in buffer

6.33.2.5 Init()

```
template<typename T, size_t size>
void daisy::RingBuffer< T, size >::Init ( ) [inline]
```

Initializes the Ring Buffer

6.33.2.6 Overwrite() [1/2]

Writes the new element to the ring buffer, overwriting unread data if necessary.

Parameters

```
v Value to overwrite
```

6.33.2.7 Overwrite() [2/2]

Overwrites a number of elements using the source buffer as input.

Parameters

source	Input buffer
num_elements	Number of elements in source

6.33.2.8 Read()

```
template<typename T, size_t size>
T daisy::RingBuffer< T, size >::Read ( ) [inline]
```

Reads the first available element from the ring buffer

Returns

read value

6.33.2.9 readable()

```
template<typename T, size_t size>
size_t daisy::RingBuffer< T, size >::readable ( ) const [inline]
```

Returns

number of unread elements in ring buffer

6.33.2.10 Swallow()

Read enough samples to make it possible to read 1 sample.

Parameters

```
n Size of T?
```

6.33.2.11 writable()

```
template<typename T, size_t size>
size_t daisy::RingBuffer< T, size >::writable ( ) const [inline]
```

Returns

the number of samples that can be written to ring buffer without overwriting unread data.

6.33.2.12 Write()

Writes the value to the next available position in the ring buffer

Parameters

```
v Value to write
```

The documentation for this class was generated from the following file:

· src/util_ringbuffer.h

6.34 daisy::RingBuffer< T, 0 > Class Template Reference

```
#include <util_ringbuffer.h>
```

Public Member Functions

- void Init ()
- size_t capacity () const
- size_t writable () const
- size_t readable () const
- void Write (T v)
- void Overwrite (T v)
- T Read ()
- T ImmediateRead ()
- void Flush ()
- void ImmediateRead (T *destination, size_t num_elements)
- void Overwrite (const T *source, size_t num_elements)

6.34.1 Detailed Description

```
template < typename T> class daisy::RingBuffer < T, 0 >
```

Utility Ring Buffer imported from pichenettes/stmlib

6.34.2 Member Function Documentation

```
6.34.2.1 capacity()
```

```
template<typename T >
size_t daisy::RingBuffer< T, 0 >::capacity ( ) const [inline]
```

Returns

0

6.34.2.2 Flush()

```
template<typename T >
void daisy::RingBuffer< T, 0 >::Flush () [inline]
```

Flush the buffer

6.34.2.3 ImmediateRead() [1/2]

```
template<typename T >
T daisy::RingBuffer< T, 0 >::ImmediateRead ( ) [inline]
```

Returns

Read value

6.34.2.4 ImmediateRead() [2/2]

Parameters

destination	&
num_elements	&

6.34.2.5 Init()

```
template<typename T >
void daisy::RingBuffer< T, 0 >::Init () [inline]
```

Initialize ringbuffer

6.34.2.6 Overwrite() [1/2]

Parameters

```
v Value to overwrite
```

6.34.2.7 Overwrite() [2/2]

Parameters

source	3
num elements	&

6.34.2.8 Read()

```
template<typename T >
T daisy::RingBuffer< T, 0 >::Read ( ) [inline]
```

Returns

Read value

6.34.2.9 readable()

```
template<typename T >
size_t daisy::RingBuffer< T, 0 >::readable ( ) const [inline]
```

Returns

0

6.34.2.10 writable()

```
template<typename T >
size_t daisy::RingBuffer< T, 0 >::writable ( ) const [inline]
```

Returns

0

6.34.2.11 Write()

Parameters

v Value to write

The documentation for this class was generated from the following file:

• src/util_ringbuffer.h

6.35 daisy::SdmmcHandler Class Reference

```
#include <per_sdmmc.h>
```

Public Member Functions

• void Init ()

6.35.1 Detailed Description

Configuration for interfacing with SD cards. Currently only supports operation using FatFS filesystem

6.35.2 Member Function Documentation

6.35.2.1 Init()

```
void daisy::SdmmcHandler::Init ( )
```

Initializes the SD Card Interface For now all settings are fixed (See todo at top of section)

The documentation for this class was generated from the following file:

· src/per_sdmmc.h

6.36 daisy::SdmmcHandlerInit Struct Reference

```
#include <per_sdmmc.h>
```

Public Attributes

- · SdmmcBitWidth bitdepth
- SdmmcSpeed speed

6.36.1 Detailed Description

Structure for setting the options above. Used to intiailize SdmmcHandler

6.36.2 Member Data Documentation

6.36.2.1 bitdepth

SdmmcBitWidth daisy::SdmmcHandlerInit::bitdepth

&

6.36.2.2 speed

```
SdmmcSpeed daisy::SdmmcHandlerInit::speed
```

&

The documentation for this struct was generated from the following file:

• src/per_sdmmc.h

6.37 ShiftRegister595 Class Reference

```
Device Driver for 8-bit shift register.
CD74HC595 - 8-bit serial to parallel output shift.
```

```
#include <dev_sr_595.h>
```

Public Types

enum Pins { PIN_LATCH, PIN_CLK, PIN_DATA, NUM_PINS }

Public Member Functions

- void Init (dsy_gpio_pin *pin_cfg, size_t num_daisy_chained=1)
- void Set (uint8_t idx, bool state)
- void Write ()

6.37.1 Detailed Description

Device Driver for 8-bit shift register. CD74HC595 - 8-bit serial to parallel output shift.

Author

shensley

Date

May 2020

6.37.2 Member Enumeration Documentation

6.37.2.1 Pins

```
enum ShiftRegister595::Pins
```

The following pins correspond to the hardware connections to the 595.

Enumerator

PIN_CLK	LATCH corresonds to Pin 12 "RCLK"
PIN_DATA	CLK corresponds to Pin 11 "SRCLK"
NUM_PINS	DATA corresponds to Pin 14 "SER"

6.37.3 Member Function Documentation

6.37.3.1 Init()

Initializes the GPIO, and data for the ShiftRegister

Parameters

pin_cfg	is an array of dsy_gpio_pin corresponding the the Pins enum above.
num_daisy_chained	(default = 1) is the number of 595 devices daisy chained together.

6.37.3.2 Set()

Sets the state of the specified output.

Parameters

idx	The index starts with QA on the first device and ends with QH on the last de	
state	A true state will set the output HIGH, while a false state will set the output LOW.	

6.37.3.3 Write()

```
void ShiftRegister595::Write ( )
```

Writes the states of shift register out to the connected devices.

The documentation for this class was generated from the following file:

```
• src/dev_sr_595.h
```

6.38 daisy::SpiHandle Class Reference

```
#include <per_spi.h>
```

Public Member Functions

- void Init ()
- void BlockingTransmit (uint8_t *buff, size_t size)

6.38.1 Detailed Description

Handler for serial peripheral interface

6.38.2 Member Function Documentation

6.38.2.1 BlockingTransmit()

Blocking transmit

Parameters

*buff	input buffer
size	buffer size

6.38.2.2 Init()

```
void daisy::SpiHandle::Init ( )
```

Initializes handler

The documentation for this class was generated from the following file:

• src/per_spi.h

6.39 daisy::Switch Class Reference

```
#include <hid_switch.h>
```

Public Types

- enum Type { TYPE_TOGGLE, TYPE_MOMENTARY }
- enum Polarity { POLARITY_NORMAL, POLARITY_INVERTED }
- enum Pull { PULL_UP, PULL_DOWN, PULL_NONE }

Public Member Functions

- void Init (dsy_gpio_pin pin, float update_rate, Type t, Polarity pol, Pull pu)
- void Init (dsy_gpio_pin pin, float update_rate)
- void Debounce ()
- bool RisingEdge () const
- bool FallingEdge () const
- bool Pressed () const
- float TimeHeldMs () const

6.39.1 Detailed Description

Generic Class for handling momentary/latching switches Inspired/influenced by Mutable Instruments (pichenettes) Switch classes

Author

Stephen Hensley

Date

December 2019

6.39.2 Member Enumeration Documentation

6.39.2.1 Polarity

enum daisy::Switch::Polarity

Specifies whether the pressed is HIGH or LOW.

Enumerator

POLARITY_NORMAL	&
POLARITY_INVERTED	&

6.39.2.2 Pull

```
enum daisy::Switch::Pull
```

Specifies whether to use built-in Pull Up/Down resistors to hold button at a given state when not engaged.

Enumerator

PULL_UP	&
PULL_DOWN	&
PULL_NONE	&

6.39.2.3 Type

```
enum daisy::Switch::Type
```

Specifies the expected behavior of the switch

Enumerator

TYPE_TOGGLE	&
TYPE_MOMENTARY	&

6.39.3 Member Function Documentation

6.39.3.1 Debounce()

```
void daisy::Switch::Debounce ( )
```

Called at update_rate to debounce and handle timing for the switch. In order for events not to be missed, its important that the Edge/Pressed checks be made at the same rate as the debounce function is being called.

6.39.3.2 FallingEdge()

```
bool daisy::Switch::FallingEdge ( ) const [inline]
```

Returns

true if the button was just released

Initializes the switch object with a given port/pin combo.

Parameters

pin	port/pin object to tell the switch which hardware pin to use.
update_rate	the rate at which the Debounce() function will be called. (used for timing).
t	switch type – Default: TYPE_MOMENTARY
pol	switch polarity – Default: POLARITY_INVERTED
ри	switch pull up/down – Default: PULL_UP

Simplified Init.

Parameters

pin	port/pin object to tell the switch which hardware pin to use.
update_rate	the rate at which the Debounce() function will be called. (used for timing).

6.39.3.5 Pressed()

```
bool daisy::Switch::Pressed ( ) const [inline]
```

Returns

true if the button is held down (or if the toggle is on)

6.39.3.6 RisingEdge()

```
bool daisy::Switch::RisingEdge ( ) const [inline]
```

Returns

true if a button was just pressed.

6.39.3.7 TimeHeldMs()

```
float daisy::Switch::TimeHeldMs ( ) const [inline]
```

Returns

the time in milliseconds that the button has been held (or toggle has been on)

The documentation for this class was generated from the following file:

• src/hid switch.h

6.40 daisy::UartHandler Class Reference

```
#include <per_uart.h>
```

Public Member Functions

- void Init ()
- int PollReceive (uint8_t *buff, size_t size, uint32_t timeout)
- int StartRx (size_t size)
- bool RxActive ()
- int FlushRx ()
- int PollTx (uint8_t *buff, size_t size)
- uint8_t PopRx ()
- size_t Readable ()
- int CheckError ()

6.40.1 Detailed Description

Uart Peripheral

Author

shensley

Date

March 2020

6.40.2 Member Function Documentation

6.40.2.1 CheckError()

```
int daisy::UartHandler::CheckError ( )
```

Returns

the result of HAL_UART_GetError() to the user.

6.40.2.2 FlushRx()

```
int daisy::UartHandler::FlushRx ( )
```

Flushes the Receive Queue

Returns

OK or ERROR

6.40.2.3 Init()

```
void daisy::UartHandler::Init ( )
```

Initializes the UART Peripheral

6.40.2.4 PollReceive()

Reads the amount of bytes in blocking mode with a 10ms timeout.

Parameters

*buff	Buffer to read to
size	Buff size
timeout	How long to timeout for (10ms?)

Returns

Data received

6.40.2.5 PolITx()

Sends an amount of data in blocking mode.

Parameters

*buff	Buffer of data to send
size	Buffer size

Returns

OK or ERROR

6.40.2.6 PopRx()

```
uint8_t daisy::UartHandler::PopRx ( )
```

Pops the oldest byte from the FIFO.

Returns

Popped byte

6.40.2.7 Readable()

```
size_t daisy::UartHandler::Readable ( )
```

Checks if there are any unread bytes in the FIFO

Returns

1 or 0 ??

6.40.2.8 RxActive()

```
bool daisy::UartHandler::RxActive ( )
```

Returns

whether Rx DMA is listening or not.

6.40.2.9 StartRx()

Starts a DMA Receive callback to fill a buffer of specified size. Data is populated into a FIFO queue, and can be queried with the functions below. Maximum Buffer size is defined above. If a value outside of the maximum is specified, the size will be set to the maximum.

Parameters

size	Queue size
------	------------

Returns

OK or ERROR

The documentation for this class was generated from the following file:

· src/per_uart.h

6.41 daisy::UsbHandle Class Reference

Interface for initializing and using the USB Peripherals on the daisy.

```
#include <hid_usb.h>
```

Public Types

- enum UsbPeriph { FS_INTERNAL, FS_EXTERNAL, FS_BOTH }
- typedef void(* ReceiveCallback) (uint8_t *buff, uint32_t *len)

Public Member Functions

- void Init (UsbPeriph dev)
- void TransmitInternal (uint8_t *buff, size_t size)
- void TransmitExternal (uint8_t *buff, size_t size)
- void SetReceiveCallback (ReceiveCallback cb)

6.41.1 Detailed Description

Interface for initializing and using the USB Peripherals on the daisy.

Author

Stephen Hensley

Date

December 2019

6.41.2 Member Typedef Documentation

6.41.2.1 ReceiveCallback

```
typedef void(* daisy::UsbHandle::ReceiveCallback) (uint8_t *buff, uint32_t *len)
```

Function called upon reception of a buffer

6.41.3 Member Enumeration Documentation

6.41.3.1 UsbPeriph

```
enum daisy::UsbHandle::UsbPeriph
```

Specified which of the two USB Peripherals to initialize.

Enumerator

FS_INTERNAL	Internal pin
FS_EXTERNAL	FS External D+ pin is Pin 38 (GPIO32). FS External D- pin is Pin 37 (GPIO31)
FS_BOTH	Both

6.41.4 Member Function Documentation

6.41.4.1 Init()

Initializes the specified peripheral(s) as USB CDC Devices

Parameters

```
dev Device to initialize
```

6.41.4.2 SetReceiveCallback()

sets the callback to be called upon reception of new data

Parameters

```
cb Function to serve as callback
```

6.41.4.3 TransmitExternal()

Transmits a buffer of 'size' bytes from a USB port connected to the external USB Pins of the daisy seed.

Parameters

buff	Buffer to transmit
size	Buffer size

6.41.4.4 TransmitInternal()

Transmits a buffer of 'size' bytes from the on board USB FS port.

Parameters

buff	Buffer to transmit
size	Buffer size

The documentation for this class was generated from the following file:

• src/hid_usb.h

6.42 WAV_FormatTypeDef Struct Reference

#include <util_wav_format.h>

Public Attributes

- uint32_t Chunkld
- uint32_t FileSize
- uint32_t FileFormat
- uint32_t SubChunk1ID
- uint32_t SubChunk1Size
- uint16_t AudioFormat
- uint16_t NbrChannels
- uint32_t SampleRate
- uint32_t ByteRate
- uint16_t BlockAlign
- uint16_t BitPerSample
- uint32_t SubChunk2ID
- uint32_t SubCHunk2Size

6.42.1 Detailed Description

Helper struct for handling the WAV file format

6.42.2 Member Data Documentation

6.42.2.1 AudioFormat

uint16_t WAV_FormatTypeDef::AudioFormat

&

6.42.2.2 BitPerSample uint16_t WAV_FormatTypeDef::BitPerSample 6.42.2.3 BlockAlign uint16_t WAV_FormatTypeDef::BlockAlign 6.42.2.4 ByteRate uint32_t WAV_FormatTypeDef::ByteRate 6.42.2.5 Chunkld uint32_t WAV_FormatTypeDef::ChunkId 6.42.2.6 FileFormat uint32_t WAV_FormatTypeDef::FileFormat & 6.42.2.7 FileSize uint32_t WAV_FormatTypeDef::FileSize & 6.42.2.8 NbrChannels uint16_t WAV_FormatTypeDef::NbrChannels &

Generated by Doxygen

&

6.42.2.9 SampleRate

uint32_t WAV_FormatTypeDef::SampleRate

6.42.2.10 SubChunk1ID

```
uint32_t WAV_FormatTypeDef::SubChunk1ID
```

8

6.42.2.11 SubChunk1Size

```
uint32_t WAV_FormatTypeDef::SubChunk1Size
```

&

6.42.2.12 SubChunk2ID

```
uint32_t WAV_FormatTypeDef::SubChunk2ID
```

&

6.42.2.13 SubCHunk2Size

```
uint32_t WAV_FormatTypeDef::SubCHunk2Size
```

&

The documentation for this struct was generated from the following file:

• src/util_wav_format.h

6.43 daisy::WavFileInfo Struct Reference

```
#include <hid_wavplayer.h>
```

Public Attributes

- WAV_FormatTypeDef raw_data
- char name [256]

6.43.1 Detailed Description

Struct containing details of Wav File.

6.43.2 Member Data Documentation

6.43.2.1 name

```
char daisy::WavFileInfo::name[256]
```

Wav filename

6.43.2.2 raw_data

```
WAV_FormatTypeDef daisy::WavFileInfo::raw_data
```

Raw wav data

The documentation for this struct was generated from the following file:

• src/hid_wavplayer.h

6.44 daisy::WavPlayer Class Reference

```
#include <hid_wavplayer.h>
```

Public Member Functions

- void Init ()
- int Open (size_t sel)
- int Close ()
- int16 t Stream ()
- void Prepare ()
- void Restart ()
- void SetLooping (bool loop)
- bool GetLooping () const
- size_t GetNumberFiles () const
- size_t GetCurrentFile () const

6.44.1 Detailed Description

Wav Player that will load .wav files from an SD Card, and then provide a method of accessing the samples with double-buffering.

6.44.2 Member Function Documentation

```
6.44.2.1 Close()

int daisy::WavPlayer::Close ( )

Closes whatever file is currently open.

Returns
```

6.44.2.2 GetCurrentFile()

```
size_t daisy::WavPlayer::GetCurrentFile ( ) const [inline]
```

Returns

currently selected file.

```
6.44.2.3 GetLooping()
```

```
bool daisy::WavPlayer::GetLooping ( ) const [inline]
```

Returns

Whether the WavPlayer is looping or not.

6.44.2.4 GetNumberFiles()

```
size_t daisy::WavPlayer::GetNumberFiles ( ) const [inline]
```

Returns

The number of files loaded by the WavPlayer

```
6.44.2.5 Init()
```

```
void daisy::WavPlayer::Init ( )
```

Initializes the WavPlayer, loading up to max_files of wav files from an SD Card.

6.44.2.6 Open()

Opens the file at index sel for reading.

Parameters

```
sel File to open
```

6.44.2.7 Prepare()

```
void daisy::WavPlayer::Prepare ( )
```

Collects buffer for playback when needed.

6.44.2.8 Restart()

```
void daisy::WavPlayer::Restart ( )
```

Resets the playback position to the beginning of the file immediately

6.44.2.9 SetLooping()

Sets whether or not the current file will repeat after completing playback.

Parameters

```
loop To loop or not to loop.
```

6.44.2.10 Stream()

```
int16_t daisy::WavPlayer::Stream ( )
```

Returns

The next sample if playing, otherwise returns 0

The documentation for this class was generated from the following file:

• src/hid_wavplayer.h

Chapter 7

File Documentation

7.1 src/daisy.h File Reference

```
#include <stdint.h>
#include "daisy_core.h"
#include "sys_system.h"
#include "per_qspi.h"
#include "per_dac.h"
#include "per_gpio.h"
#include "per_i2c.h"
#include "per_sai.h"
#include "per_tim.h"
#include "dev_leddriver.h"
#include "dev_sdram.h"
#include "dev_sr_4021.h"
#include "hid_audio.h"
#include "util_unique_id.h"
#include "per_adc.h"
#include "per_uart.h"
#include "hid_midi.h"
#include "hid_encoder.h"
#include "hid_switch.h"
#include "hid ctrl.h"
#include "hid_gatein.h"
#include "hid_parameter.h"
#include "hid_usb.h"
#include "per_sdmmc.h"
#include "per_spi.h"
#include "hid_oled_display.h"
#include "hid_wavplayer.h"
#include "hid led.h"
#include "hid_rgb_led.h"
#include "dev_sr_595.h"
```

Macros

- #define FBIPMAX 0.999985f
- #define FBIPMIN (-FBIPMAX)

128 File Documentation

```
• #define S162F_SCALE 3.0517578125e-05f
```

- #define F2S16_SCALE 32767.0f
- #define F2S24_SCALE 8388608.0f
- #define S242F SCALE 1.192092896e-07f
- #define S24SIGN 0x800000

Functions

- FORCE_INLINE float s162f (int16_t x)
- FORCE_INLINE int16_t f2s16 (float x)
- FORCE_INLINE float s242f (int32_t x)
- FORCE_INLINE int32_t f2s24 (float x)

7.1.1 Macro Definition Documentation

```
7.1.1.1 F2S16_SCALE
```

```
#define F2S16_SCALE 32767.0f
```

(2 ** 15) - 1

7.1.1.2 F2S24_SCALE

#define F2S24_SCALE 8388608.0f

2 ** 23

7.1.1.3 FBIPMAX

#define FBIPMAX 0.999985f

close to 1.0f-LSB at 16 bit

7.1.1.4 FBIPMIN

#define FBIPMIN (-FBIPMAX)

• (1 - LSB)

```
7.1.1.5 S162F_SCALE
#define S162F_SCALE 3.0517578125e-05f
1 / (2** 15)
7.1.1.6 S242F_SCALE
#define S242F_SCALE 1.192092896e-07f
1 / (2 ** 23)
7.1.1.7 S24SIGN
#define S24SIGN 0x800000
2 ** 23
7.1.2 Function Documentation
7.1.2.1 f2s16()
FORCE_INLINE int16_t f2s16 (
              float x )
& < close to 1.0f-LSB at 16 bit
< - (1 - LSB)
< close to 1.0f-LSB at 16 bit
< - (1 - LSB)
< close to 1.0f-LSB at 16 bit
< close to 1.0f-LSB at 16 bit
< (2 ** 15) - 1
7.1.2.2 f2s24()
FORCE_INLINE int32_t f2s24 (
              float x )
& < close to 1.0f-LSB at 16 bit
< - (1 - LSB)
< close to 1.0f-LSB at 16 bit
< - (1 - LSB)
< close to 1.0f-LSB at 16 bit
< close to 1.0f-LSB at 16 bit
< 2 ** 23
7.1.2.3 s162f()
FORCE_INLINE float s162f (
              int16_t x )
```

Scales float by 1/(2 \(^15\)

130 File Documentation

Parameters

```
x Number to be scaled.
```

Returns

Scaled number.

```
< 1 / (2** 15)
```

7.1.2.4 s242f()

7.2 src/daisy_core.h File Reference

```
#include <stdint.h>
#include <stdlib.h>
```

Classes

• struct dsy_gpio_pin

Macros

- #define DSY_CORE_HW_H
- #define DMA_BUFFER_MEM_SECTION __attribute__((section(".sram1_bss")))
- #define DTCM_MEM_SECTION __attribute__((section(".dtcmram_bss")))

Enumerations

```
    enum dsy_gpio_port {
        DSY_GPIOA, DSY_GPIOB, DSY_GPIOC, DSY_GPIOD,
        DSY_GPIOE, DSY_GPIOF, DSY_GPIOG, DSY_GPIOH,
        DSY_GPIOI, DSY_GPIOJ, DSY_GPIOK,
        DSY_GPIO_LAST }
```

Functions

- FORCE_INLINE float cube (float x)
- FORCE_INLINE dsy_gpio_pin dsy_pin (dsy_gpio_port port, uint8_t pin)
- FORCE_INLINE uint8_t dsy_pin_cmp (dsy_gpio_pin *a, dsy_gpio_pin *b)

7.2.1 Macro Definition Documentation

7.2.1.1 DMA_BUFFER_MEM_SECTION

```
#define DMA_BUFFER_MEM_SECTION __attribute__((section(".sram1_bss")))
```

Macro for area of memory that is configured as cacheless This should be used primarily for DMA buffers, and the like

7.2.1.2 DSY_CORE_HW_H

```
#define DSY_CORE_HW_H
```

&

7.2.1.3 DTCM_MEM_SECTION

```
#define DTCM_MEM_SECTION __attribute__((section(".dtcmram_bss")))
```

THE DTCM RAM section is also non-cached. However, is not suitable for DMA transfers. Performance is on par with internal SRAM w/ cache enabled.

7.2.2 Enumeration Type Documentation

7.2.2.1 dsy_gpio_port

```
enum dsy_gpio_port
```

Enums and a simple struct for defining a hardware pin on the MCU These correlate with the stm32 datasheet, and are used to configure the hardware.

Enumerator

DSY_GPIOA	&
DSY_GPIOB	&
DSY_GPIOC	&
DSY_GPIOD	&
Generated BSB ox GPIOE	&
DSY_GPIOF	&
DSY_GPIOG	&
DSY GPIOH	&

132 File Documentation

7.2.3 Function Documentation

```
7.2.3.1 cube()
```

```
FORCE_INLINE float cube ( float x )
```

Computes cube.

Parameters

```
x Number to be cubed
```

Returns

x ^ 3

7.2.3.2 dsy_pin()

Helper for creating pins from port/pin combos easily

7.2.3.3 dsy_pin_cmp()

Helper for testing sameness of two dsy_gpio_pins

Returns

1 if same, 0 if different

7.3 src/daisy_field.h File Reference

Hardware defines and helpers for daisy field platform.

```
#include "daisy_seed.h"
```

Classes

· struct daisy::daisy_field

Macros

```
• #define DSY FIELD BSP H
```

- #define SAMPLE RATE DSY AUDIO SAMPLE RATE
- #define SW_1_PIN 29
- #define SW_2_PIN 28
- #define SW 3 PIN 27
- #define GATE_OUT_PIN 0
- #define GATE_IN_PIN 1
- #define KB SW SR CS PIN 8
- #define KB_SW_SR_CLK_PIN 9
- #define KB_SW_SR_D1_PIN 10
- #define KB SW SR D2 PIN 11
- #define MIDI_OUT_PIN 14
- #define MIDI_IN_PIN 15
- #define MUX SEL 0 PIN 21
- #define MUX_SEL_1_PIN 20
- #define MUX_SEL_2_PIN 19
- #define MUX ADC PIN 16
- #define CV1_ADC_PIN 17
- #define CV2_ADC_PIN 18
- #define CV3_ADC_PIN 23
- #define CV4 ADC PIN 22
- #define LED_DRIVER_I2C i2c1_handle

Enumerations

```
enum { daisy::SW_2, daisy::SW_1, daisy::SW_3, daisy::SW_LAST }
enum {
    daisy::KNOB_1, daisy::KNOB_3, daisy::KNOB_5, daisy::KNOB_2,
    daisy::KNOB_4, daisy::KNOB_6, daisy::KNOB_7, daisy::KNOB_8,
    daisy::KNOB_LAST }
enum {
    CV_1, daisy::CV_2, daisy::CV_3, daisy::CV_4,
    daisy::CV_LAST }
enum {
    daisy::LED_KEY_A8, daisy::LED_KEY_A7, daisy::LED_KEY_A6, daisy::LED_KEY_A5,
    daisy::LED_KEY_A4, daisy::LED_KEY_A3, daisy::LED_KEY_A2, daisy::LED_KEY_A1,
    daisy::LED_KEY_B1, daisy::LED_KEY_B2, daisy::LED_KEY_B3, daisy::LED_KEY_B4,
    daisy::LED_KEY_B5, daisy::LED_KEY_B6, daisy::LED_KEY_B7, daisy::LED_KEY_B8,
    daisy::LED_KNOB_1, daisy::LED_KNOB_2, daisy::LED_KNOB_3, daisy::LED_KNOB_4,
    daisy::LED_SW_1, daisy::LED_SW_2, daisy::LED_LAST }
```

Functions

FORCE_INLINE void daisy::daisy_field_init (daisy_field *p)

134 File Documentation

7.3.1 Detailed Description

Hardware defines and helpers for daisy field platform.

7.3.2 Macro Definition Documentation

```
7.3.2.1 CV1_ADC_PIN
```

#define CV1_ADC_PIN 17

&

7.3.2.2 CV2_ADC_PIN

#define CV2_ADC_PIN 18

&

7.3.2.3 CV3_ADC_PIN

#define CV3_ADC_PIN 23

&

7.3.2.4 CV4_ADC_PIN

#define CV4_ADC_PIN 22

&

7.3.2.5 DSY_FIELD_BSP_H

#define DSY_FIELD_BSP_H

&

7.3.2.6 GATE_IN_PIN

#define GATE_IN_PIN 1

&

```
7.3.2.7 GATE_OUT_PIN
#define GATE_OUT_PIN 0
7.3.2.8 KB_SW_SR_CLK_PIN
#define KB_SW_SR_CLK_PIN 9
7.3.2.9 KB_SW_SR_CS_PIN
#define KB_SW_SR_CS_PIN 8
7.3.2.10 KB_SW_SR_D1_PIN
#define KB_SW_SR_D1_PIN 10
7.3.2.11 KB_SW_SR_D2_PIN
#define KB_SW_SR_D2_PIN 11
&
7.3.2.12 LED DRIVER I2C
#define LED_DRIVER_I2C i2c1_handle
&
7.3.2.13 MIDI_IN_PIN
#define MIDI_IN_PIN 15
&
7.3.2.14 MIDI_OUT_PIN
#define MIDI_OUT_PIN 14
```

136 File Documentation

```
7.3.2.15 MUX_ADC_PIN
#define MUX_ADC_PIN 16
&
7.3.2.16 MUX_SEL_0_PIN
#define MUX_SEL_0_PIN 21
7.3.2.17 MUX_SEL_1_PIN
#define MUX_SEL_1_PIN 20
7.3.2.18 MUX_SEL_2_PIN
#define MUX_SEL_2_PIN 19
7.3.2.19 SAMPLE_RATE
#define SAMPLE_RATE DSY_AUDIO_SAMPLE_RATE
7.3.2.20 SW_1_PIN
#define SW_1_PIN 29
7.3.2.21 SW_2_PIN
#define SW_2_PIN 28
7.3.2.22 SW_3_PIN
#define SW_3_PIN 27
&
7.3.3 Enumeration Type Documentation
7.3.3.1 anonymous enum
```

anonymous enum

enums for controls, etc.

Enumerator

SW_2	tactile switch
SW_1	tactile switch
SW_3	toggle
SW_LAST	&

7.3.3.2 anonymous enum

anonymous enum

All knobs connect to ADC1_INP10 via CD4051 mux

Enumerator

KNOB_1	&
KNOB_3	&
KNOB_5	&
KNOB_2	&
KNOB_4	&
KNOB_6	&
KNOB_7	&
KNOB_8	&
KNOB_LAST	&

7.3.3.3 anonymous enum

anonymous enum

Enumerator

CV_2	Connected to ADC1_INP17
CV_3	Connected to ADC1_INP15
CV_4	Connected to ADC1_INP4
CV_LAST	Connected to ADC1_INP11 &

7.3.3.4 anonymous enum

anonymous enum

138 File Documentation

Enumerator

LED_KEY_A8	&
LED_KEY_A7	&
LED_KEY_A6	&
LED_KEY_A5	&
LED_KEY_A4	&
LED_KEY_A3	&
LED_KEY_A2	&
LED_KEY_A1	&
LED_KEY_B1	&
LED_KEY_B2	&
LED_KEY_B3	&
LED_KEY_B4	&
LED_KEY_B5	&
LED_KEY_B6	&
LED_KEY_B7	&
LED_KEY_B8	&
LED_KNOB↔	&
_1	
LED_KNOB← _2	&
LED_KNOB↔	&
_3	
LED_KNOB←	&
_4	
LED_KNOB←	&
_5	
LED_KNOB↔	&
6	
LED_KNOB↔	&
_7	
LED_KNOB↔	&
_8	_
LED_SW_1	&
. == 0.4: -	_
LED_SW_2 LED_LAST	& &

7.3.4 Function Documentation

7.3.4.1 daisy_field_init()

```
FORCE_INLINE void daisy::daisy_field_init ( \label{eq:daisy_field} \mbox{daisy\_field} \ *\ p\ )
```

Initializes daisy field

Parameters

р	daisy_field struct to initialize
< &	
< &	
\ α	
< &	
< &	
< &	
< &	
- 0	
< &	
< &	
< &	
< &	
< &	
. 0	
< &	
< &	
< &	
< &	
٠ ۵	
< &	
< &	
< &	

7.4 src/daisy_patch.h File Reference

#include "daisy_seed.h"

Classes

• class daisy::DaisyPatch

Class that handles initializing all of the hardware specific to the Daisy Patch Board. Helper funtions are also in place to provide easy access to built-in controls and peripherals.

7.5 src/daisy_petal.h File Reference

```
#include "daisy_seed.h"
```

Classes

· class daisy::DaisyPetal

Helpers and hardware definitions for daisy petal.

Macros

• #define DSY_PETAL_H

7.5.1 Macro Definition Documentation

7.5.1.1 DSY_PETAL_H

```
#define DSY_PETAL_H
```

&

7.6 src/daisy_pod.h File Reference

```
#include "daisy_seed.h"
```

Classes

· class daisy::DaisyPod

Class that handles initializing all of the hardware specific to the Daisy Patch Board. Helper funtions are also in place to provide easy access to built-in controls and peripherals.

7.7 src/daisy_seed.h File Reference

```
#include "daisy.h"
```

Classes

class daisy::DaisySeed

This is the higher-level interface for the Daisy board.
All basic peripheral configuration/initialization is setup here.

7.8 src/dev_codec_ak4556.h File Reference

Driver for the AK4556 Stereo Codec.

```
#include "daisy_core.h"
```

Functions

• void codec_ak4556_init (dsy_gpio_pin reset_pin)

7.8.1 Detailed Description

Driver for the AK4556 Stereo Codec.

7.8.2 Function Documentation

```
7.8.2.1 codec_ak4556_init()
```

Resets the AK4556

Parameters

reset_pin | should be a dsy_gpio_pin that is connected to the RST pin of the AK4556

7.9 src/dev_codec_pcm3060.h File Reference

Driver for the PCM3060 Codec.

```
#include "per_i2c.h"
```

Functions

void codec_pcm3060_init (dsy_i2c_handle *hi2c)

7.9.1 Detailed Description

Driver for the PCM3060 Codec.

7.9.2 Function Documentation

7.9.2.1 codec_pcm3060_init()

Resets the PCM060

Parameters

```
*hi2c array of pins handling i2c?
```

7.10 src/dev_codec_wm8731.h File Reference

Driver for the WM8731 Codec.

```
#include <stddef.h>
#include "per_sai.h"
#include "per_i2c.h"
```

Functions

- uint8_t codec_wm8731_init (dsy_i2c_handle *hi2c, uint8_t mcu_is_master, int32_t sample_rate, uint8_←
 t bitdepth)
- uint8_t codec_wm8731_enter_bypass (dsy_i2c_handle *hi2c)
- uint8_t codec_wm8731_exit_bypass (dsy_i2c_handle *hi2c)

7.10.1 Detailed Description

Driver for the WM8731 Codec.

7.10.2 Function Documentation

7.10.2.1 codec_wm8731_enter_bypass()

Put codec into bypass mode

Parameters

```
*hi2c pins handling i2c
```

7.10.2.2 codec_wm8731_exit_bypass()

```
\label{eq:codec_wm8731_exit_bypass (} $$ dsy_i2c_handle * hi2c )
```

Take codec out of bypass mode

Parameters

```
*hi2c pins handling i2c
```

7.10.2.3 codec_wm8731_init()

Resets the WM8731

Parameters

*hi2c	array of pins handling i2c?
mcu_is_master	&
sample_rate	Sample rate to run codec at
bitdepth	Bit depth to run codec at

7.11 src/dev_codec_wm8731_frame.h File Reference

WM8731 Codec framework.

```
#include <stddef.h>
```

Classes

• struct codec_frame_t

Typedefs

• typedef void(* sa_audio_callback) (codec_frame_t *, codec_frame_t *, size_t)

7.11.1 Detailed Description

WM8731 Codec framework.

7.11.2 Typedef Documentation

```
7.11.2.1 sa_audio_callback
```

```
typedef void(* sa_audio_callback) (codec_frame_t *, codec_frame_t *, size_t)
```

&

7.12 src/dev_flash_IS25LP064A.h File Reference

IS25LP08D Commands.

Macros

- #define IS25LP064A H
- #define IS25LP064A FLASH SIZE 0x800000
- #define IS25LP064A SECTOR SIZE 0x10000
- #define IS25LP064A SUBSECTOR SIZE 0x1000
- #define IS25LP064A_PAGE_SIZE 0x100
- #define IS25LP064A DUMMY CYCLES READ QUAD 8
- #define IS25LP064A_DUMMY_CYCLES_READ 8
- #define IS25LP064A_DUMMY_CYCLES_READ_DTR 6
- #define IS25LP064A DUMMY CYCLES READ QUAD DTR 6
- #define IS25LP064A DIE ERASE MAX TIME 460000
- #define IS25LP064A_SECTOR_ERASE_MAX_TIME 1000
- #define IS25LP064A_SUBSECTOR_ERASE_MAX_TIME 400
- #define RESET ENABLE CMD 0x66
- #define RESET_MEMORY_CMD 0x99
- #define READ ID CMD 0x9E
- #define READ_ID_CMD2 0x9F
- #define MULTIPLE_IO_READ_ID_CMD 0xAF
- #define READ_SERIAL_FLASH_DISCO_PARAM_CMD 0x5A
- #define READ_CMD 0x03
- #define READ_4_BYTE_ADDR_CMD 0x13
- #define FAST READ CMD 0x0B
- #define FAST READ DTR CMD 0x0D
- #define FAST READ 4 BYTE ADDR CMD 0x0C
- #define DUAL OUT FAST READ CMD 0x3B
- #define DUAL_OUT_FAST_READ_DTR_CMD 0x3D
- #define DUAL OUT FAST READ 4 BYTE ADDR CMD 0x3C
- #define DUAL INOUT FAST READ CMD 0xBB
- #define DUAL_INOUT_FAST_READ_DTR_CMD 0xBD
- #define DUAL_INOUT_FAST_READ_4_BYTE_ADDR_CMD 0xBC
- #define QUAD_OUT_FAST_READ_CMD 0x6B
- #define QUAD_OUT_FAST_READ_DTR_CMD 0x0D
- #define QUAD OUT FAST READ 4 BYTE ADDR CMD 0x6C
- #define QUAD INOUT FAST READ CMD 0xEB
- #define QUAD INOUT FAST READ DTR CMD 0xED
- #define QUAD_INOUT_FAST_READ_4_BYTE_ADDR_CMD 0xEC
- #define WRITE ENABLE CMD 0x06
- #define WRITE_DISABLE_CMD 0x04
- #define READ STATUS REG CMD 0x05
- #define WRITE STATUS REG CMD 0x01
- #define READ_LOCK_REG_CMD 0xE8
- #define WRITE LOCK REG CMD 0xE5
- #define READ_FLAG_STATUS_REG_CMD 0x70
- #define CLEAR FLAG STATUS REG CMD 0x50
- #define READ_NONVOL_CFG_REG_CMD 0xB5
- #define WRITE_NONVOL_CFG_REG_CMD 0xB1
- #define READ_READ_PARAM_REG_CMD 0x61
- #define WRITE_READ_PARAM_REG_CMD 0xC0
- #define READ_ENHANCED_VOL_CFG_REG_CMD 0x81
- #define WRITE_ENHANCED_VOL_CFG_REG_CMD 0x85
- #define READ_EXT_ADDR_REG_CMD 0xC8
- #define WRITE_EXT_ADDR_REG_CMD 0xC5
- #define PAGE PROG CMD 0x02
- #define PAGE_PROG_4_BYTE_ADDR_CMD 0x12

- #define DUAL IN FAST PROG CMD 0xA2
- #define EXT_DUAL_IN_FAST_PROG_CMD 0xD2
- #define QUAD IN FAST PROG_CMD 0x32
- #define EXT_QUAD_IN_FAST_PROG_CMD 0x38
- #define QUAD IN FAST PROG 4 BYTE ADDR CMD 0x34
- #define SUBSECTOR ERASE CMD 0xd7
- #define SUBSECTOR ERASE QPI CMD 0x20
- #define SUBSECTOR ERASE 4 BYTE ADDR CMD 0x21
- #define SECTOR ERASE CMD 0xD8
- #define SECTOR ERASE 4 BYTE ADDR CMD 0xDC
- #define BLOCK ERASE 32K CMD 0x52
- #define DIE_ERASE_CMD 0xC4
- #define PROG ERASE RESUME CMD 0x7A
- #define PROG ERASE SUSPEND CMD 0x75
- #define READ OTP ARRAY CMD 0x4B
- #define PROG_OTP_ARRAY_CMD 0x42
- #define ENTER_4_BYTE_ADDR_MODE_CMD 0xB7
- #define EXIT 4 BYTE ADDR MODE CMD 0xE9
- #define ENTER QUAD CMD 0x35
- #define EXIT QUAD CMD 0xF5
- #define IS25LP064A SR WIP ((uint8 t)0x01)

IS25LP08D Registers.

- #define IS25LP064A SR WREN ((uint8 t)0x02)
- #define IS25LP064A SR SRWREN ((uint8 t)0x80)
- #define IS25LP064A_SR_QE ((uint8_t)0x40)
- #define IS25LP064A_NVCR_NBADDR ((uint16_t)0x0001)
- #define IS25LP064A_NVCR_SEGMENT ((uint16_t)0x0002)
- #define IS25LP064A_NVCR_DUAL ((uint16_t)0x0004)
- #define IS25LP064A_NVCR_QUAB ((uint16_t)0x0008)
- #define IS25LP064A_NVCR_RH ((uint16_t)0x0010)
- #define IS25LP064A_NVCR_DTRP ((uint16_t)0x0020)
- #define IS25LP064A_NVCR_ODS ((uint16_t)0x01C0)
- #define IS25LP064A NVCR XIP ((uint16 t)0x0E00)
- #define IS25LP064A NVCR NB DUMMY ((uint16 t)0xF000)
- #define IS25LP064A_VCR_WRAP ((uint8_t)0x03)
- #define IS25LP064A VCR XIP ((uint8 t)0x08)
- #define IS25LP064A VCR NB DUMMY ((uint8 t)0xF0)
- #define IS25LP064A EAR HIGHEST SE ((uint8 t)0x03)
- #define IS25LP064A EAR THIRD SEG ((uint8 t)0x02)
- #define IS25LP064A_EAR_SECOND_SEG ((uint8_t)0x01)
- #define IS25LP064A EAR LOWEST SEG ((uint8 t)0x00)
- #define IS25LP064A EVCR ODS ((uint8 t)0x07)
- #define IS25LP064A_EVCR_RH ((uint8_t)0x10)
- #define IS25LP064A EVCR DTRP ((uint8 t)0x20)
- #define IS25LP064A_EVCR_DUAL ((uint8_t)0x40)
- #define IS25LP064A EVCR QUAD ((uint8 t)0x80)
- #define IS25LP064A FSR NBADDR ((uint8 t)0x01)
- #define IS25LP064A FSR PRERR ((uint8 t)0x02)
- #define IS25LP064A_FSR_PGSUS ((uint8_t)0x04)
- #define IS25LP064A FSR PGERR ((uint8 t)0x10)
- #define IS25LP064A FSR ERERR ((uint8 t)0x20)
- #define IS25LP064A FSR ERSUS ((uint8 t)0x40)
- #define IS25LP064A FSR READY ((uint8 t)0x80)

7.12.1 Detailed Description

IS25LP08D Commands.

7.12.2 Macro Definition Documentation

7.12.2.1 BLOCK_ERASE_32K_CMD

 ${\tt \#define~BLOCK_ERASE_32K_CMD~0x52}$

&

7.12.2.2 CLEAR_FLAG_STATUS_REG_CMD

#define CLEAR_FLAG_STATUS_REG_CMD 0x50

&

7.12.2.3 DIE_ERASE_CMD

#define DIE_ERASE_CMD 0xC4

&

7.12.2.4 DUAL_IN_FAST_PROG_CMD

#define DUAL_IN_FAST_PROG_CMD 0xA2

&

7.12.2.5 DUAL_INOUT_FAST_READ_4_BYTE_ADDR_CMD

#define DUAL_INOUT_FAST_READ_4_BYTE_ADDR_CMD 0xBC

&

7.12.2.6 DUAL_INOUT_FAST_READ_CMD

#define DUAL_INOUT_FAST_READ_CMD 0xBB

```
7.12.2.7 DUAL_INOUT_FAST_READ_DTR_CMD
#define DUAL_INOUT_FAST_READ_DTR_CMD 0xBD
7.12.2.8 DUAL_OUT_FAST_READ_4_BYTE_ADDR_CMD
#define DUAL_OUT_FAST_READ_4_BYTE_ADDR_CMD 0x3C
7.12.2.9 DUAL_OUT_FAST_READ_CMD
#define DUAL_OUT_FAST_READ_CMD 0x3B
7.12.2.10 DUAL_OUT_FAST_READ_DTR_CMD
#define DUAL_OUT_FAST_READ_DTR_CMD 0x3D
7.12.2.11 ENTER_4_BYTE_ADDR_MODE_CMD
#define ENTER_4_BYTE_ADDR_MODE_CMD 0xB7
4-byte Address Mode Operations
7.12.2.12 ENTER QUAD CMD
#define ENTER_QUAD_CMD 0x35
Quad Operations
7.12.2.13 EXIT_4_BYTE_ADDR_MODE_CMD
#define EXIT_4_BYTE_ADDR_MODE_CMD 0xE9
&
7.12.2.14 EXIT_QUAD_CMD
```

#define EXIT_QUAD_CMD 0xF5

7.12.2.15 EXT_DUAL_IN_FAST_PROG_CMD #define EXT_DUAL_IN_FAST_PROG_CMD 0xD2 & 7.12.2.16 EXT_QUAD_IN_FAST_PROG_CMD #define EXT_QUAD_IN_FAST_PROG_CMD 0x38 7.12.2.17 FAST_READ_4_BYTE_ADDR_CMD #define FAST_READ_4_BYTE_ADDR_CMD 0x0C 7.12.2.18 FAST_READ_CMD #define FAST_READ_CMD 0x0B 7.12.2.19 FAST_READ_DTR_CMD #define FAST_READ_DTR_CMD 0x0D & 7.12.2.20 IS25LP064A DIE ERASE MAX TIME #define IS25LP064A_DIE_ERASE_MAX_TIME 460000 & 7.12.2.21 IS25LP064A_DUMMY_CYCLES_READ #define IS25LP064A_DUMMY_CYCLES_READ 8 & 7.12.2.22 IS25LP064A_DUMMY_CYCLES_READ_DTR

Generated by Doxygen

&

#define IS25LP064A_DUMMY_CYCLES_READ_DTR 6

```
7.12.2.23 IS25LP064A_DUMMY_CYCLES_READ_QUAD
#define IS25LP064A_DUMMY_CYCLES_READ_QUAD 8
7.12.2.24 IS25LP064A_DUMMY_CYCLES_READ_QUAD_DTR
#define IS25LP064A_DUMMY_CYCLES_READ_QUAD_DTR 6
7.12.2.25 IS25LP064A_EAR_HIGHEST_SE
#define IS25LP064A_EAR_HIGHEST_SE ((uint8_t)0x03)
Select the Highest 128Mb segment
7.12.2.26 IS25LP064A_EAR_LOWEST_SEG
#define IS25LP064A_EAR_LOWEST_SEG ((uint8_t)0x00)
Select the Lowest 128Mb segment (default)
7.12.2.27 IS25LP064A_EAR_SECOND_SEG
#define IS25LP064A_EAR_SECOND_SEG ((uint8_t)0x01)
Select the Second 128Mb segment
7.12.2.28 IS25LP064A EAR THIRD SEG
#define IS25LP064A_EAR_THIRD_SEG ((uint8_t)0x02)
Select the Third 128Mb segment
7.12.2.29 IS25LP064A_EVCR_DTRP
#define IS25LP064A_EVCR_DTRP ((uint8_t)0x20)
Double transfer rate protocol
7.12.2.30 IS25LP064A_EVCR_DUAL
#define IS25LP064A_EVCR_DUAL ((uint8_t)0x40)
```

Dual I/O protocol

7.12.2.31 IS25LP064A_EVCR_ODS #define IS25LP064A_EVCR_ODS ((uint8_t)0x07) Output driver strength 7.12.2.32 IS25LP064A_EVCR_QUAD #define IS25LP064A_EVCR_QUAD ((uint8_t)0x80) Quad I/O protocol 7.12.2.33 IS25LP064A_EVCR_RH #define IS25LP064A_EVCR_RH ((uint8_t)0x10) Reset/hold 7.12.2.34 IS25LP064A_FLASH_SIZE #define IS25LP064A_FLASH_SIZE 0x800000 2 * 8 MBits => 1 * 1MBytes => 1MBytes 7.12.2.35 IS25LP064A_FSR_ERERR #define IS25LP064A_FSR_ERERR ((uint8_t)0x20) Erase error 7.12.2.36 IS25LP064A_FSR_ERSUS #define IS25LP064A_FSR_ERSUS ((uint8_t)0x40) Erase operation suspended #define IS25LP064A_FSR_NBADDR ((uint8_t)0x01) 3-bytes or 4-bytes addressing

#define IS25LP064A_FSR_PGERR ((uint8_t)0x10)

7.12.2.38 IS25LP064A_FSR_PGERR

Program error

7.12.2.39 IS25LP064A_FSR_PGSUS

#define IS25LP064A_FSR_PGSUS ((uint8_t)0x04)

Program operation suspended

7.12.2.40 IS25LP064A_FSR_PRERR

#define IS25LP064A_FSR_PRERR ((uint8_t)0x02)

Protection error

#define IS25LP064A_FSR_READY ((uint8_t)0x80)

Ready or command in progress

7.12.2.42 IS25LP064A_H

#define IS25LP064A_H

&

7.12.2.43 IS25LP064A_NVCR_DTRP

#define IS25LP064A_NVCR_DTRP ((uint16_t)0x0020)

Double transfer rate protocol

7.12.2.44 IS25LP064A_NVCR_DUAL

#define IS25LP064A_NVCR_DUAL ((uint16_t)0x0004)

Dual I/O protocol

7.12.2.45 IS25LP064A_NVCR_NB_DUMMY

#define IS25LP064A_NVCR_NB_DUMMY ((uint16_t)0xF000)

Number of dummy clock cycles

#define IS25LP064A_NVCR_NBADDR ((uint16_t)0x0001)

3-bytes or 4-bytes addressing

7.12.2.47 IS25LP064A_NVCR_ODS

#define IS25LP064A_NVCR_ODS ((uint16_t)0x01C0)

Output driver strength

7.12.2.48 IS25LP064A_NVCR_QUAB

#define IS25LP064A_NVCR_QUAB ((uint16_t)0x0008)

Quad I/O protocol

7.12.2.49 IS25LP064A_NVCR_RH

#define IS25LP064A_NVCR_RH ((uint16_t)0x0010)

Reset/hold

7.12.2.50 IS25LP064A_NVCR_SEGMENT

#define IS25LP064A_NVCR_SEGMENT ((uint16_t)0x0002)

Upper or lower 128Mb segment selected by default

#define IS25LP064A_NVCR_XIP ((uint16_t)0x0E00)

XIP mode at power-on reset

#define IS25LP064A_PAGE_SIZE 0x100

2 * 262144 pages of 256 bytes

7.12.2.53 IS25LP064A_SECTOR_ERASE_MAX_TIME

#define IS25LP064A_SECTOR_ERASE_MAX_TIME 1000

&

#define IS25LP064A_SECTOR_SIZE 0x10000

2 * 1024 sectors of 64KBytes

```
7.12.2.55 IS25LP064A_SR_QE
#define IS25LP064A_SR_QE ((uint8_t)0x40)
&
7.12.2.56 IS25LP064A_SR_SRWREN
#define IS25LP064A_SR_SRWREN ((uint8_t)0x80)
Status register write enable/disable
7.12.2.57 IS25LP064A_SR_WIP
#define IS25LP064A_SR_WIP ((uint8_t)0x01)
IS25LP08D Registers.
Write in progress
7.12.2.58 IS25LP064A_SR_WREN
#define IS25LP064A_SR_WREN ((uint8_t)0x02)
Write enable latch
7.12.2.59 IS25LP064A_SUBSECTOR_ERASE_MAX_TIME
#define IS25LP064A_SUBSECTOR_ERASE_MAX_TIME 400
&
7.12.2.60 IS25LP064A_SUBSECTOR_SIZE
#define IS25LP064A_SUBSECTOR_SIZE 0x1000
2 * 16384 subsectors of 4kBytes
7.12.2.61 IS25LP064A_VCR_NB_DUMMY
#define IS25LP064A_VCR_NB_DUMMY ((uint8_t)0xF0)
```

Number of dummy clock cycles

```
7.12.2.62 IS25LP064A_VCR_WRAP
#define IS25LP064A_VCR_WRAP ((uint8_t)0x03)
Wrap
7.12.2.63 IS25LP064A_VCR_XIP
\#define IS25LP064A_VCR_XIP ((uint8_t)0x08)
XIP
7.12.2.64 MULTIPLE_IO_READ_ID_CMD
#define MULTIPLE_IO_READ_ID_CMD 0xAF
7.12.2.65 PAGE_PROG_4_BYTE_ADDR_CMD
#define PAGE_PROG_4_BYTE_ADDR_CMD 0x12
7.12.2.66 PAGE_PROG_CMD
#define PAGE_PROG_CMD 0x02
Program Operations
7.12.2.67 PROG_ERASE_RESUME_CMD
#define PROG_ERASE_RESUME_CMD 0x7A
&
7.12.2.68 PROG_ERASE_SUSPEND_CMD
#define PROG_ERASE_SUSPEND_CMD 0x75
&
7.12.2.69 PROG_OTP_ARRAY_CMD
#define PROG_OTP_ARRAY_CMD 0x42
&
```

```
7.12.2.70 QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD
#define QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD 0x34
7.12.2.71 QUAD_IN_FAST_PROG_CMD
#define QUAD_IN_FAST_PROG_CMD 0x32
7.12.2.72 QUAD_INOUT_FAST_READ_4_BYTE_ADDR_CMD
#define QUAD_INOUT_FAST_READ_4_BYTE_ADDR_CMD 0xEC
7.12.2.73 QUAD_INOUT_FAST_READ_CMD
#define QUAD_INOUT_FAST_READ_CMD 0xEB
7.12.2.74 QUAD_INOUT_FAST_READ_DTR_CMD
#define QUAD_INOUT_FAST_READ_DTR_CMD 0xED
&
7.12.2.75 QUAD_OUT_FAST_READ_4_BYTE_ADDR_CMD
#define QUAD_OUT_FAST_READ_4_BYTE_ADDR_CMD 0x6C
&
7.12.2.76 QUAD_OUT_FAST_READ_CMD
#define QUAD_OUT_FAST_READ_CMD 0x6B
&
7.12.2.77 QUAD_OUT_FAST_READ_DTR_CMD
#define QUAD_OUT_FAST_READ_DTR_CMD 0x0D
```

7.12.2.78 READ_4_BYTE_ADDR_CMD #define READ_4_BYTE_ADDR_CMD 0x13 7.12.2.79 READ_CMD #define READ_CMD 0x03 **Read Operations** 7.12.2.80 READ_ENHANCED_VOL_CFG_REG_CMD #define READ_ENHANCED_VOL_CFG_REG_CMD 0x81 7.12.2.81 READ_EXT_ADDR_REG_CMD #define READ_EXT_ADDR_REG_CMD 0xC8 7.12.2.82 READ_FLAG_STATUS_REG_CMD #define READ_FLAG_STATUS_REG_CMD 0x70 & 7.12.2.83 READ_ID_CMD #define READ_ID_CMD 0x9E **Identification Operations** 7.12.2.84 READ_ID_CMD2 #define READ_ID_CMD2 0x9F & 7.12.2.85 READ_LOCK_REG_CMD

Generated by Doxygen

&

#define READ_LOCK_REG_CMD 0xE8

```
7.12.2.86 READ_NONVOL_CFG_REG_CMD
#define READ_NONVOL_CFG_REG_CMD 0xB5
7.12.2.87 READ_OTP_ARRAY_CMD
#define READ_OTP_ARRAY_CMD 0x4B
One-Time Programmable Operations
7.12.2.88 READ_READ_PARAM_REG_CMD
#define READ_READ_PARAM_REG_CMD 0x61
7.12.2.89 READ_SERIAL_FLASH_DISCO_PARAM_CMD
#define READ_SERIAL_FLASH_DISCO_PARAM_CMD 0x5A
7.12.2.90 READ_STATUS_REG_CMD
#define READ_STATUS_REG_CMD 0x05
Register Operations
7.12.2.91 RESET ENABLE CMD
#define RESET_ENABLE_CMD 0x66
Reset Operations
7.12.2.92 RESET_MEMORY_CMD
#define RESET_MEMORY_CMD 0x99
&
```

&

7.12.2.93 SECTOR_ERASE_4_BYTE_ADDR_CMD

#define SECTOR_ERASE_4_BYTE_ADDR_CMD 0xDC

7.12.2.94 SECTOR_ERASE_CMD #define SECTOR_ERASE_CMD 0xD8 & 7.12.2.95 SUBSECTOR_ERASE_4_BYTE_ADDR_CMD #define SUBSECTOR_ERASE_4_BYTE_ADDR_CMD 0x21 7.12.2.96 SUBSECTOR_ERASE_CMD #define SUBSECTOR_ERASE_CMD 0xd7 **Erase Operations** 7.12.2.97 SUBSECTOR_ERASE_QPI_CMD #define SUBSECTOR_ERASE_QPI_CMD 0x20 7.12.2.98 WRITE_DISABLE_CMD #define WRITE_DISABLE_CMD 0x04 & 7.12.2.99 WRITE_ENABLE_CMD #define WRITE_ENABLE_CMD 0x06 Write Operations 7.12.2.100 WRITE_ENHANCED_VOL_CFG_REG_CMD #define WRITE_ENHANCED_VOL_CFG_REG_CMD 0x85 & 7.12.2.101 WRITE_EXT_ADDR_REG_CMD

Generated by Doxygen

&

#define WRITE_EXT_ADDR_REG_CMD 0xC5

7.12.2.102 WRITE_LOCK_REG_CMD

#define WRITE_LOCK_REG_CMD 0xE5

&

7.12.2.103 WRITE_NONVOL_CFG_REG_CMD

#define WRITE_NONVOL_CFG_REG_CMD 0xB1

8

7.12.2.104 WRITE_READ_PARAM_REG_CMD

#define WRITE_READ_PARAM_REG_CMD 0xC0

&

7.12.2.105 WRITE_STATUS_REG_CMD

#define WRITE_STATUS_REG_CMD 0x01

&

7.13 src/dev_flash_IS25LP080D.h File Reference

IS25LP08D Commands.

Macros

- #define IS25LP080D_FLASH_SIZE 0x100000
- #define IS25LP080D_SECTOR_SIZE 0x10000
- #define IS25LP080D_SUBSECTOR_SIZE 0x1000
- #define IS25LP080D_PAGE_SIZE 0x100
- #define IS25LP080D_DUMMY_CYCLES_READ_QUAD 8
- #define IS25LP080D_DUMMY_CYCLES_READ 8
- #define IS25LP080D_DUMMY_CYCLES_READ_DTR 6
- #define IS25LP080D_DUMMY_CYCLES_READ_QUAD_DTR 6
- #define IS25LP080D DIE ERASE MAX TIME 460000
- #define IS25LP080D_SECTOR_ERASE_MAX_TIME 1000
- #define IS25LP080D_SUBSECTOR_ERASE_MAX_TIME 400
- #define RESET_ENABLE_CMD 0x66
- #define RESET_MEMORY_CMD 0x99
- #define READ_ID_CMD 0x9E
- #define READ_ID_CMD2 0x9F
- #define MULTIPLE IO READ ID CMD 0xAF
- #define READ_SERIAL_FLASH_DISCO_PARAM_CMD 0x5A

- #define READ CMD 0x03
- #define READ_4_BYTE_ADDR_CMD 0x13
- #define FAST_READ_CMD 0x0B
- #define FAST READ DTR CMD 0x0D
- #define FAST READ 4 BYTE ADDR CMD 0x0C
- #define DUAL_OUT_FAST_READ_CMD 0x3B
- #define DUAL OUT FAST READ DTR CMD 0x3D
- #define DUAL_OUT_FAST_READ_4_BYTE_ADDR_CMD 0x3C
- #define DUAL_INOUT_FAST_READ_CMD 0xBB
- #define DUAL INOUT FAST READ DTR CMD 0xBD
- #define DUAL INOUT FAST READ 4 BYTE ADDR CMD 0xBC
- #define QUAD OUT FAST READ CMD 0x6B
- #define QUAD_OUT_FAST_READ_DTR_CMD 0x0D
- #define QUAD OUT FAST READ 4 BYTE ADDR CMD 0x6C
- #define QUAD_INOUT_FAST_READ_CMD 0xEB
- #define QUAD INOUT FAST READ DTR CMD 0xED
- #define QUAD INOUT FAST READ 4 BYTE ADDR CMD 0xEC
- #define WRITE ENABLE CMD 0x06
- #define WRITE DISABLE CMD 0x04
- #define READ_STATUS_REG_CMD 0x05
- #define WRITE_STATUS_REG_CMD 0x01
- #define READ_LOCK_REG_CMD 0xE8
- #define WRITE LOCK REG CMD 0xE5
- #define READ_FLAG_STATUS_REG_CMD 0x70
- #define CLEAR FLAG STATUS REG CMD 0x50
- #define READ_NONVOL_CFG_REG_CMD 0xB5
- #define WRITE_NONVOL_CFG_REG_CMD 0xB1
- #define READ_READ_PARAM_REG_CMD 0x61
- #define WRITE_READ_PARAM_REG_CMD 0xC0
- #define READ_ENHANCED_VOL_CFG_REG_CMD 0x81
- #define WRITE_ENHANCED_VOL_CFG_REG_CMD 0x85
- #define READ EXT ADDR REG CMD 0xC8
- #define WRITE_EXT_ADDR_REG_CMD 0xC5
- #define PAGE_PROG_CMD 0x02
- #define PAGE_PROG_4_BYTE_ADDR_CMD 0x12
- #define DUAL_IN_FAST_PROG_CMD 0xA2
- #define EXT_DUAL_IN_FAST_PROG_CMD 0xD2
- #define QUAD_IN_FAST_PROG_CMD 0x32
- #define EXT_QUAD_IN_FAST_PROG_CMD 0x38
- #define QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD 0x34
- #define SUBSECTOR ERASE CMD 0xd7
- #define SUBSECTOR_ERASE_QPI_CMD 0x20
- #define SUBSECTOR_ERASE_4_BYTE_ADDR_CMD 0x21
- #define SECTOR_ERASE_CMD 0xD8
- #define SECTOR_ERASE_4_BYTE_ADDR_CMD 0xDC
- #define BLOCK ERASE 32K CMD 0x52
- #define DIE ERASE CMD 0xC4
- #define PROG_ERASE_RESUME_CMD 0x7A
- #define PROG_ERASE_SUSPEND_CMD 0x75
- #define READ_OTP_ARRAY_CMD 0x4B
- #define PROG OTP ARRAY CMD 0x42
- #define ENTER_4_BYTE_ADDR_MODE_CMD 0xB7
- #define EXIT_4_BYTE_ADDR_MODE_CMD 0xE9
- #define ENTER_QUAD_CMD 0x35
- #define EXIT_QUAD_CMD 0xF5

- #define IS25LP080D_SR_WIP ((uint8_t)0x01)
 IS25LP08D Registers.
- #define IS25LP080D_SR_WREN ((uint8_t)0x02)
- #define IS25LP080D_SR_SRWREN ((uint8_t)0x80)
- #define IS25LP080D_SR_QE ((uint8_t)0x40)
- #define IS25LP080D NVCR NBADDR ((uint16 t)0x0001)
- #define IS25LP080D NVCR SEGMENT ((uint16 t)0x0002)
- #define IS25LP080D NVCR DUAL ((uint16 t)0x0004)
- #define IS25LP080D_NVCR_QUAB ((uint16_t)0x0008)
- #define IS25LP080D_NVCR_RH ((uint16_t)0x0010)
- #define IS25LP080D_NVCR_DTRP ((uint16_t)0x0020)
- #define IS25LP080D_NVCR_ODS ((uint16_t)0x01C0)
- #define IS25LP080D_NVCR_XIP ((uint16_t)0x0E00)
- #define IS25LP080D_NVCR_NB_DUMMY ((uint16_t)0xF000)
- #define IS25LP080D_VCR_WRAP ((uint8_t)0x03)
- #define IS25LP080D VCR XIP ((uint8 t)0x08)
- #define IS25LP080D VCR NB DUMMY ((uint8 t)0xF0)
- #define IS25LP080D_EAR_HIGHEST_SE ((uint8_t)0x03)
- #define IS25LP080D_EAR_THIRD_SEG ((uint8_t)0x02)
- #define IS25LP080D_EAR_SECOND_SEG ((uint8_t)0x01)
- #define IS25LP080D EAR LOWEST SEG ((uint8 t)0x00)
- #define IS25LP080D_EVCR_ODS ((uint8_t)0x07)
- #define IS25LP080D EVCR RH ((uint8 t)0x10)
- #define IS25LP080D_EVCR_DTRP ((uint8_t)0x20)
- #define IS25LP080D_EVCR_DUAL ((uint8_t)0x40)
- #define IS25LP080D_EVCR_QUAD ((uint8_t)0x80)
- #define IS25LP080D_FSR_NBADDR ((uint8_t)0x01)
- #define IS25LP080D FSR PRERR ((uint8 t)0x02)
- #define IS25LP080D_FSR_PGSUS ((uint8_t)0x04)
- #define IS25LP080D_FSR_PGERR ((uint8_t)0x10)
- #define IS25LP080D_FSR_ERERR ((uint8_t)0x20)
- #define IS25LP080D FSR ERSUS ((uint8 t)0x40)
- #define IS25LP080D_FSR_READY ((uint8_t)0x80)

7.13.1 Detailed Description

IS25LP08D Commands.

7.13.2 Macro Definition Documentation

7.13.2.1 BLOCK ERASE 32K CMD

#define BLOCK_ERASE_32K_CMD 0x52

7.13.2.2 CLEAR_FLAG_STATUS_REG_CMD

#define CLEAR_FLAG_STATUS_REG_CMD 0x50

&

7.13.2.3 DIE_ERASE_CMD

#define DIE_ERASE_CMD 0xC4

ጴ

7.13.2.4 DUAL_IN_FAST_PROG_CMD

#define DUAL_IN_FAST_PROG_CMD 0xA2

&

7.13.2.5 DUAL_INOUT_FAST_READ_4_BYTE_ADDR_CMD

#define DUAL_INOUT_FAST_READ_4_BYTE_ADDR_CMD 0xBC

ጴ

7.13.2.6 DUAL_INOUT_FAST_READ_CMD

#define DUAL_INOUT_FAST_READ_CMD 0xBB

&

7.13.2.7 DUAL_INOUT_FAST_READ_DTR_CMD

#define DUAL_INOUT_FAST_READ_DTR_CMD 0xBD

&

7.13.2.8 DUAL_OUT_FAST_READ_4_BYTE_ADDR_CMD

#define DUAL_OUT_FAST_READ_4_BYTE_ADDR_CMD 0x3C

&

7.13.2.9 DUAL_OUT_FAST_READ_CMD

#define DUAL_OUT_FAST_READ_CMD 0x3B

```
7.13.2.10 DUAL_OUT_FAST_READ_DTR_CMD
#define DUAL_OUT_FAST_READ_DTR_CMD 0x3D
7.13.2.11 ENTER_4_BYTE_ADDR_MODE_CMD
#define ENTER_4_BYTE_ADDR_MODE_CMD 0xB7
4-byte Address Mode Operations
7.13.2.12 ENTER_QUAD_CMD
#define ENTER_QUAD_CMD 0x35
Quad Operations
7.13.2.13 EXIT_4_BYTE_ADDR_MODE_CMD
#define EXIT_4_BYTE_ADDR_MODE_CMD 0xE9
7.13.2.14 EXIT_QUAD_CMD
#define EXIT_QUAD_CMD 0xF5
&
7.13.2.15 EXT_DUAL_IN_FAST_PROG_CMD
#define EXT_DUAL_IN_FAST_PROG_CMD 0xD2
&
7.13.2.16 EXT_QUAD_IN_FAST_PROG_CMD
#define EXT_QUAD_IN_FAST_PROG_CMD 0x38
&
7.13.2.17 FAST_READ_4_BYTE_ADDR_CMD
```

#define FAST_READ_4_BYTE_ADDR_CMD 0x0C

```
7.13.2.18 FAST_READ_CMD
#define FAST_READ_CMD 0x0B
&
7.13.2.19 FAST_READ_DTR_CMD
#define FAST_READ_DTR_CMD 0x0D
7.13.2.20 IS25LP080D_DIE_ERASE_MAX_TIME
#define IS25LP080D_DIE_ERASE_MAX_TIME 460000
&
7.13.2.21 IS25LP080D_DUMMY_CYCLES_READ
#define IS25LP080D_DUMMY_CYCLES_READ 8
7.13.2.22 IS25LP080D_DUMMY_CYCLES_READ_DTR
#define IS25LP080D_DUMMY_CYCLES_READ_DTR 6
&
7.13.2.23 IS25LP080D_DUMMY_CYCLES_READ_QUAD
#define IS25LP080D_DUMMY_CYCLES_READ_QUAD 8
&
7.13.2.24 IS25LP080D_DUMMY_CYCLES_READ_QUAD_DTR
#define IS25LP080D_DUMMY_CYCLES_READ_QUAD_DTR 6
&
7.13.2.25 IS25LP080D_EAR_HIGHEST_SE
#define IS25LP080D_EAR_HIGHEST_SE ((uint8_t)0x03)
Select the Highest 128Mb segment
```

```
7.13.2.26 IS25LP080D_EAR_LOWEST_SEG
#define IS25LP080D_EAR_LOWEST_SEG ((uint8_t)0x00)
Select the Lowest 128Mb segment (default)
7.13.2.27 IS25LP080D_EAR_SECOND_SEG
#define IS25LP080D_EAR_SECOND_SEG ((uint8_t)0x01)
Select the Second 128Mb segment
7.13.2.28 IS25LP080D_EAR_THIRD_SEG
#define IS25LP080D_EAR_THIRD_SEG ((uint8_t)0x02)
Select the Third 128Mb segment
7.13.2.29 IS25LP080D_EVCR_DTRP
#define IS25LP080D_EVCR_DTRP ((uint8_t)0x20)
Double transfer rate protocol
7.13.2.30 IS25LP080D_EVCR_DUAL
#define IS25LP080D_EVCR_DUAL ((uint8_t)0x40)
Dual I/O protocol
7.13.2.31 IS25LP080D_EVCR_ODS
#define IS25LP080D_EVCR_ODS ((uint8_t)0x07)
Output driver strength
7.13.2.32 IS25LP080D_EVCR_QUAD
#define IS25LP080D_EVCR_QUAD ((uint8_t)0x80)
Quad I/O protocol
7.13.2.33 IS25LP080D_EVCR_RH
#define IS25LP080D_EVCR_RH ((uint8_t)0x10)
```

Reset/hold

```
7.13.2.34 IS25LP080D_FLASH_SIZE
#define IS25LP080D_FLASH_SIZE 0x100000
2 * 8 \text{ MBits} => 1 * 1 \text{MBytes} => 1 \text{MBytes}
#define IS25LP080D_FSR_ERERR ((uint8_t)0x20)
Erase error
7.13.2.36 IS25LP080D_FSR_ERSUS
#define IS25LP080D_FSR_ERSUS ((uint8_t)0x40)
Erase operation suspended
#define IS25LP080D_FSR_NBADDR ((uint8_t)0x01)
3-bytes or 4-bytes addressing
7.13.2.38 IS25LP080D_FSR_PGERR
#define IS25LP080D_FSR_PGERR ((uint8_t)0x10)
Program error
#define IS25LP080D_FSR_PGSUS ((uint8_t)0x04)
Program operation suspended
#define IS25LP080D_FSR_PRERR ((uint8_t)0x02)
Protection error
#define IS25LP080D_FSR_READY ((uint8_t)0x80)
```

Ready or command in progress

7.13.2.42 IS25LP080D_NVCR_DTRP #define IS25LP080D_NVCR_DTRP ((uint16_t)0x0020) Double transfer rate protocol 7.13.2.43 IS25LP080D_NVCR_DUAL #define IS25LP080D_NVCR_DUAL ((uint16_t)0x0004) Dual I/O protocol 7.13.2.44 IS25LP080D_NVCR_NB_DUMMY #define IS25LP080D_NVCR_NB_DUMMY ((uint16_t)0xF000) Number of dummy clock cycles #define IS25LP080D_NVCR_NBADDR ((uint16_t)0x0001) 3-bytes or 4-bytes addressing 7.13.2.46 IS25LP080D_NVCR_ODS #define IS25LP080D_NVCR_ODS ((uint16_t)0x01C0) Output driver strength 7.13.2.47 IS25LP080D_NVCR_QUAB #define IS25LP080D_NVCR_QUAB ((uint16_t)0x0008) Quad I/O protocol 7.13.2.48 IS25LP080D_NVCR_RH

#define IS25LP080D_NVCR_RH ((uint16_t)0x0010)

Reset/hold

#define IS25LP080D_NVCR_SEGMENT ((uint16_t)0x0002)

Upper or lower 128Mb segment selected by default

```
#define IS25LP080D_NVCR_XIP ((uint16_t)0x0E00)
XIP mode at power-on reset
#define IS25LP080D_PAGE_SIZE 0x100
2 * 262144 pages of 256 bytes
7.13.2.52 IS25LP080D_SECTOR_ERASE_MAX_TIME
#define IS25LP080D_SECTOR_ERASE_MAX_TIME 1000
&
#define IS25LP080D_SECTOR_SIZE 0x10000
2 * 1024 sectors of 64KBytes
7.13.2.54 IS25LP080D_SR_QE
#define IS25LP080D_SR_QE ((uint8_t)0x40)
&
7.13.2.55 IS25LP080D_SR_SRWREN
#define IS25LP080D_SR_SRWREN ((uint8_t)0x80)
Status register write enable/disable
7.13.2.56 IS25LP080D_SR_WIP
#define IS25LP080D_SR_WIP ((uint8_t)0x01)
IS25LP08D Registers.
Status Register Write in progress
```

```
#define IS25LP080D_SR_WREN ((uint8_t)0x02)
Write enable latch
7.13.2.58 IS25LP080D_SUBSECTOR_ERASE_MAX_TIME
#define IS25LP080D_SUBSECTOR_ERASE_MAX_TIME 400
7.13.2.59 IS25LP080D_SUBSECTOR_SIZE
#define IS25LP080D_SUBSECTOR_SIZE 0x1000
2 * 16384 subsectors of 4kBytes
7.13.2.60 IS25LP080D_VCR_NB_DUMMY
#define IS25LP080D_VCR_NB_DUMMY ((uint8_t)0xF0)
Number of dummy clock cycles
#define IS25LP080D_VCR_WRAP ((uint8_t)0x03)
Wrap
7.13.2.62 IS25LP080D_VCR_XIP
#define IS25LP080D_VCR_XIP ((uint8_t)0x08)
XIP
7.13.2.63 MULTIPLE_IO_READ_ID_CMD
#define MULTIPLE_IO_READ_ID_CMD 0xAF
&
7.13.2.64 PAGE_PROG_4_BYTE_ADDR_CMD
#define PAGE_PROG_4_BYTE_ADDR_CMD 0x12
```

7.13.2.65 PAGE_PROG_CMD #define PAGE_PROG_CMD 0x02 **Program Operations** 7.13.2.66 PROG_ERASE_RESUME_CMD #define PROG_ERASE_RESUME_CMD 0x7A 7.13.2.67 PROG_ERASE_SUSPEND_CMD #define PROG_ERASE_SUSPEND_CMD 0x75 7.13.2.68 PROG_OTP_ARRAY_CMD #define PROG_OTP_ARRAY_CMD 0x42 7.13.2.69 QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD #define QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD 0x34 & 7.13.2.70 QUAD IN FAST_PROG_CMD #define QUAD_IN_FAST_PROG_CMD 0x32 & 7.13.2.71 QUAD_INOUT_FAST_READ_4_BYTE_ADDR_CMD #define QUAD_INOUT_FAST_READ_4_BYTE_ADDR_CMD 0xEC &

Generated by Doxygen

&

7.13.2.72 QUAD_INOUT_FAST_READ_CMD

#define QUAD_INOUT_FAST_READ_CMD 0xEB

```
7.13.2.73 QUAD_INOUT_FAST_READ_DTR_CMD
#define QUAD_INOUT_FAST_READ_DTR_CMD 0xED
&
7.13.2.74 QUAD_OUT_FAST_READ_4_BYTE_ADDR_CMD
#define QUAD_OUT_FAST_READ_4_BYTE_ADDR_CMD 0x6C
7.13.2.75 QUAD_OUT_FAST_READ_CMD
#define QUAD_OUT_FAST_READ_CMD 0x6B
7.13.2.76 QUAD_OUT_FAST_READ_DTR_CMD
#define QUAD_OUT_FAST_READ_DTR_CMD 0x0D
7.13.2.77 READ_4_BYTE_ADDR_CMD
#define READ_4_BYTE_ADDR_CMD 0x13
&
7.13.2.78 READ_CMD
#define READ_CMD 0x03
Read Operations
7.13.2.79 READ_ENHANCED_VOL_CFG_REG_CMD
#define READ_ENHANCED_VOL_CFG_REG_CMD 0x81
&
7.13.2.80 READ_EXT_ADDR_REG_CMD
#define READ_EXT_ADDR_REG_CMD 0xC8
```

7.13 src/dev_flash_IS25LP080D.h File Reference 7.13.2.81 READ_FLAG_STATUS_REG_CMD #define READ_FLAG_STATUS_REG_CMD 0x70 7.13.2.82 READ_ID_CMD #define READ_ID_CMD 0x9E Identification Operations 7.13.2.83 READ_ID_CMD2 #define READ_ID_CMD2 0x9F 7.13.2.84 READ_LOCK_REG_CMD #define READ_LOCK_REG_CMD 0xE8 7.13.2.85 READ_NONVOL_CFG_REG_CMD #define READ_NONVOL_CFG_REG_CMD 0xB5 & 7.13.2.86 READ_OTP_ARRAY_CMD #define READ_OTP_ARRAY_CMD 0x4B One-Time Programmable Operations

7.13.2.87 READ_READ_PARAM_REG_CMD

#define READ_READ_PARAM_REG_CMD 0x61

&

7.13.2.88 READ_SERIAL_FLASH_DISCO_PARAM_CMD

#define READ_SERIAL_FLASH_DISCO_PARAM_CMD 0x5A

7.13.2.89 READ_STATUS_REG_CMD

#define READ_STATUS_REG_CMD 0x05

Register Operations

7.13.2.90 RESET_ENABLE_CMD

#define RESET_ENABLE_CMD 0x66

Reset Operations

7.13.2.91 RESET_MEMORY_CMD

#define RESET_MEMORY_CMD 0x99

&

7.13.2.92 SECTOR_ERASE_4_BYTE_ADDR_CMD

#define SECTOR_ERASE_4_BYTE_ADDR_CMD 0xDC

&

7.13.2.93 SECTOR_ERASE_CMD

#define SECTOR_ERASE_CMD 0xD8

&

7.13.2.94 SUBSECTOR_ERASE_4_BYTE_ADDR_CMD

#define SUBSECTOR_ERASE_4_BYTE_ADDR_CMD 0x21

&

7.13.2.95 SUBSECTOR_ERASE_CMD

#define SUBSECTOR_ERASE_CMD 0xd7

Erase Operations

7.13.2.96 SUBSECTOR_ERASE_QPI_CMD

#define SUBSECTOR_ERASE_QPI_CMD 0x20

7.13.2.97 WRITE_DISABLE_CMD

#define WRITE_DISABLE_CMD 0x04

8

7.13.2.98 WRITE_ENABLE_CMD

#define WRITE_ENABLE_CMD 0x06

Write Operations

7.13.2.99 WRITE_ENHANCED_VOL_CFG_REG_CMD

#define WRITE_ENHANCED_VOL_CFG_REG_CMD 0x85

&

7.13.2.100 WRITE_EXT_ADDR_REG_CMD

#define WRITE_EXT_ADDR_REG_CMD 0xC5

ጴ

7.13.2.101 WRITE_LOCK_REG_CMD

#define WRITE_LOCK_REG_CMD 0xE5

&

7.13.2.102 WRITE_NONVOL_CFG_REG_CMD

#define WRITE_NONVOL_CFG_REG_CMD 0xB1

&

7.13.2.103 WRITE_READ_PARAM_REG_CMD

#define WRITE_READ_PARAM_REG_CMD 0xC0

&

7.13.2.104 WRITE_STATUS_REG_CMD

#define WRITE_STATUS_REG_CMD 0x01

&

7.14 src/dev_leddriver.h File Reference

Device driver for PCA9685 16-channel 12-bit PWM generator.

```
#include <stdint.h>
#include "per_i2c.h"
```

Classes

· struct color

Macros

- #define SA_LED_DRIVER_H
- #define DSY_LED_DRIVER_MAX_DRIVERS 8

Enumerations

enum {
 LED_COLOR_RED, LED_COLOR_GREEN, LED_COLOR_BLUE, LED_COLOR_WHITE,
 LED_COLOR_PURPLE, LED_COLOR_CYAN, LED_COLOR_GOLD, LED_COLOR_OFF,
 LED_COLOR_LAST }

Functions

- void dsy_led_driver_init (dsy_i2c_handle *dsy_i2c, uint8_t *addr, uint8_t addr_cnt)
- void dsy_led_driver_update ()
- void dsy_led_driver_set_led (uint8_t idx, float bright)
- color * dsy_led_driver_color_by_name (uint8_t name)

7.14.1 Detailed Description

Device driver for PCA9685 16-channel 12-bit PWM generator.

7.14.2 Macro Definition Documentation

7.14.2.1 DSY_LED_DRIVER_MAX_DRIVERS

```
#define DSY_LED_DRIVER_MAX_DRIVERS 8
```

Maximum number of drivers

7.14.2.2 SA_LED_DRIVER_H

```
#define SA_LED_DRIVER_H
```

ጲ

7.14.3 Enumeration Type Documentation

7.14.3.1 anonymous enum

anonymous enum

Different Led colors

Enumerator

LED_COLOR_RED	&
LED_COLOR_GREEN	&
LED_COLOR_BLUE	&
LED_COLOR_WHITE	&
LED_COLOR_PURPLE	&
LED_COLOR_CYAN	&
LED_COLOR_GOLD	&
LED_COLOR_OFF	&
LED_COLOR_LAST	&

7.14.4 Function Documentation

7.14.4.1 dsy_led_driver_color_by_name()

Passing in one of the preset colors will return a pointer to a color struct

Parameters

name	Preset color

7.14.4.2 dsy_led_driver_init()

Initializes the LED Driver(s) on the specified I2C Bus

Parameters

*dsy_i2c	should be any dsy_i2c_handle with pins and speed configured.
addr	is either a pointer to 1 device address, or an array of addresses for multiple devices
addr_cnt	is the number of addresses passed in (use '1' for a single device)

7.14.4.3 dsy_led_driver_set_led()

sets the LED at the index to the specified brightness (0-1) Index is sequential so device 0 will have idx 0-15, while device 1 will have idx 16-31, etc.

Parameters

idx	Index
bright	Brightness

7.14.4.4 dsy_led_driver_update()

```
void dsy_led_driver_update ( )
```

Updates the LED Driver with the values set using the set function Currently only updates one driver at a time due to the time it takes to update all of the devices. This can likely be set up to use DMA so that the function doesn't block for so long.

7.15 src/dev_sdram.h File Reference

```
#include <stdint.h>
#include "daisy_core.h"
```

Classes

• struct dsy_sdram_handle

Macros

- #define RAM AS4C16M16SA H
- #define DSY_SDRAM_DATA __attribute__((section(".sdram_data")))
- #define DSY_SDRAM_BSS __attribute__((section(".sdram_bss")))

Enumerations

- enum { DSY_SDRAM_OK, DSY_SDRAM_ERR }
- enum dsy_sdram_state { DSY_SDRAM_STATE_ENABLE, DSY_SDRAM_STATE_DISABLE, DSY_SDR → AM STATE LAST }
- enum dsy_sdram_pin { DSY_SDRAM_PIN_SDNWE, DSY_SDRAM_PIN_LAST }

Functions

uint8_t dsy_sdram_init (dsy_sdram_handle *dsy_hsdram)

7.15.1 Macro Definition Documentation

```
7.15.1.1 DSY_SDRAM_BSS
#define DSY_SDRAM_BSS __attribute__((section(".sdram_bss")))
Variables placed here will not be initialized.
Usage
E.g. int DSY_SDRAM_BSS uninitialized_var;

7.15.1.2 DSY_SDRAM_DATA
#define DSY_SDRAM_DATA __attribute__((section(".sdram_data")))
Usage:
E.g. int DSY_SDRAM_DATA initialized_var = 1;

7.15.1.3 RAM_AS4C16M16SA_H
#define RAM_AS4C16M16SA_H
```

SDRAM for 32MB AS4C16M16SA (and 64MB equivalent). Thanks to whoever this awesome person is: http-://main.lv/writeup/stm32f4_sdram_configuration.md The Init function is basically a copy and paste. He has references to timing, etc. RAM is configured at 100MHz (fastest possible on the MCU). To use these the .sdram_data/_bss sections must be configured correctly in the LINKER SCRIPT. using BSS is advised for most things, since the DATA section must also fit in flash in order to be initialized. Data section init not properly set up, as SDRAM is not initialized until after startup code.&

7.15.2 Enumeration Type Documentation

7.15.2.1 anonymous enum

anonymous enum

Enumerator

DSY_SDRAM_OK	&
DSY_SDRAM_ERR	&

7.15.2.2 dsy_sdram_pin

enum dsy_sdram_pin

This is PH5 on Daisy

Enumerator

DSY_SDRAM_PIN_SDNWE	&
DSY_SDRAM_PIN_LAST	&

7.15.2.3 dsy_sdram_state

enum dsy_sdram_state

Determines whether chip is initialized, and activated.

Enumerator

DSY_SDRAM_STATE_ENABLE	&
DSY_SDRAM_STATE_DISABLE	&
DSY_SDRAM_STATE_LAST	&

7.15.3 Function Documentation

7.15.3.1 dsy_sdram_init()

Initializes the SDRAM peripheral

7.16 src/dev_sr_4021.h File Reference

Device driver for the CD4021. Bit-banged serial shift input.

```
#include "per_gpio.h"
```

Classes

• struct dsy_sr_4021_handle

Macros

- #define DEV_SR_4021_H
- #define SR 4021 MAX PARALLEL 2
- #define SR_4021_MAX_DAISYCHAIN 1

Enumerations

```
    enum {
        DSY_SR_4021_PIN_CS, DSY_SR_4021_PIN_CLK, DSY_SR_4021_PIN_DATA, DSY_SR_4021_PIN_D →
        ATA2,
        DSY_SR_4021_PIN_LAST }
```

Functions

- void dsy_sr_4021_init (dsy_sr_4021_handle *sr)
- void dsy_sr_4021_update (dsy_sr_4021_handle *sr)
- uint8_t dsy_sr_4021_state (dsy_sr_4021_handle *sr, uint8_t idx)

7.16.1 Detailed Description

Device driver for the CD4021. Bit-banged serial shift input.

7.16.2 Macro Definition Documentation

7.16.2.1 DEV_SR_4021_H

```
#define DEV_SR_4021_H
```

&

7.16.2.2 SR_4021_MAX_DAISYCHAIN

```
#define SR_4021_MAX_DAISYCHAIN 1
```

fixed maximum for daisychained use

7.16.2.3 SR_4021_MAX_PARALLEL

```
#define SR_4021_MAX_PARALLEL 2
```

Fixed maximums for parallel/daisychained use These could be expanded, but haven't been tested beyond this

7.16.3 Enumeration Type Documentation

7.16.3.1 anonymous enum

```
anonymous enum
```

Pins that need to be configured to use. DATA2 only needs to be set if num_parallel is > 1

Enumerator

DSY_SR_4021_PIN_CS	CS Pin
DSY_SR_4021_PIN_CLK	CLK Pin
DSY_SR_4021_PIN_DATA	DATA pin
DSY_SR_4021_PIN_DATA2	DATA2 Pin, optional
DSY_SR_4021_PIN_LAST	Enum Last

7.16.4 Function Documentation

7.16.4.1 dsy_sr_4021_init()

```
void dsy_sr_4021_init ( \label{eq:dsy_sr_4021_handle} \ *\ sr\ )
```

Initialize CD4021 with settings from sr_4021_handle

Parameters

```
sr handle to initialize
```

7.16.4.2 dsy_sr_4021_state()

Returns the state of a pin at a given index.

Parameters

*,	sr	Handle containing desired pin
ic	lx	Pin index

7.16.4.3 dsy_sr_4021_update()

Fills internal states with CD4021 data states.

Parameters

```
*sr Handle to update
```

7.17 src/dev_sr_595.h File Reference

```
#include "daisy_core.h"
#include "per_gpio.h"
```

Classes

• class ShiftRegister595

Device Driver for 8-bit shift register. CD74HC595 - 8-bit serial to parallel output shift.

Variables

• const size_t kMaxSr595DaisyChain = 16

7.17.1 Variable Documentation

7.17.1.1 kMaxSr595DaisyChain

```
const size_t kMaxSr595DaisyChain = 16
```

Maximum Number of chained devices Connect device's QH' pin to the next chips serial input

7.18 src/fatfs.h File Reference

fatfs support.

```
#include "ff.h"
#include "ff_gen_drv.h"
#include "util_sd_diskio.h"
```

Macros

• #define __fatfs_H

Functions

• void dsy_fatfs_init (void)

Variables

- uint8_t retSD
- char SDPath [4]
- FATFS SDFatFS
- FIL SDFile

7.18.1 Detailed Description

fatfs support.

7.18.2 Macro Definition Documentation

```
7.18.2.1 __fatfs_H
#define ___fatfs_H
7.18.3 Function Documentation
7.18.3.1 dsy_fatfs_init()
void dsy_fatfs_init (
            void )
&
7.18.4 Variable Documentation
7.18.4.1 retSD
uint8_t retSD
&
7.18.4.2 SDFatFS
FATES SDFatES
7.18.4.3 SDFile
FIL SDFile
&
7.18.4.4 SDPath
char SDPath[4]
```

&

7.19 src/ffconf.h File Reference

```
#include "util_bsp_sd_diskio.h"
#include <stdlib.h>
```

Macros

- #define FFCONF 68300
- #define _FS_READONLY 0
- #define _FS_MINIMIZE 0
- #define _USE_STRFUNC 2
- #define _USE_FIND 0
- #define _USE_MKFS 1
- #define _USE_FASTSEEK 1
- #define USE EXPAND 0
- #define USE CHMOD 0
- #define _USE_LABEL 0
- #define _USE_FORWARD 0
- #define _CODE_PAGE 850
- #define USE LFN 1
- #define _MAX_LFN 255
- #define _LFN_UNICODE 0
- #define _STRF_ENCODE 3
- #define _FS_RPATH 0
- #define _VOLUMES 1
- #define _STR_VOLUME_ID 0
- #define _VOLUME_STRS
- #define _MULTI_PARTITION 0
- #define _MIN_SS 512
- #define _MAX_SS 512
- #define _USE_TRIM 0
- #define _FS_NOFSINFO 0
- #define _FS_TINY 0
- #define _FS_EXFAT 0
- #define _FS_NORTC 0
- #define _NORTC_MON 6
- #define _NORTC_MDAY 4
- #define _NORTC_YEAR 2015
- #define _FS_LOCK 2
- #define _FS_REENTRANT 0
- #define _FS_TIMEOUT 1000
- #define _SYNC_t osSemaphoreId
- #define ff_malloc malloc
- #define ff_free free

7.19.1 Detailed Description

Further fatfs support.

7.19.2 Macro Definition Documentation

7.19.2.1 _CODE_PAGE

#define _CODE_PAGE 850

This option specifies the OEM code page to be used on the target system. / Incorrect setting of the code page can cause a file open failure. // 1 - ASCII (No extended character. Non-LFN cfg. only) / 437 - U.S. / 720 - Arabic / 737 - Greek / 771 - KBL / 775 - Baltic / 850 - Latin 1 / 852 - Latin 2 / 855 - Cyrillic / 857 - Turkish / 860 - Portuguese / 861 - Icelandic / 862 - Hebrew / 863 - Canadian French / 864 - Arabic / 865 - Nordic / 866 - Russian / 869 - Greek 2 / 932 - Japanese (DBCS) / 936 - Simplified Chinese (DBCS) / 949 - Korean (DBCS) / 950 - Traditional Chinese (DBCS)

7.19.2.2 _FFCONF

#define _FFCONF 68300

FatFs - Generic FAT file system module R0.12c (C)ChaN, 2017

Attention

© Copyright (c) 2019 STMicroelectronics. All rights reserved.

This software component is licensed by ST under Ultimate Liberty license SLA0044, the "License"; You may not use this file except in compliance with the License. You may obtain a copy of the License at: www.st.com/SLA0044← Revision ID

7.19.2.3 _FS_EXFAT

#define _FS_EXFAT 0

This option switches support of exFAT file system. (0:Disable or 1:Enable) / When enable exFAT, also LFN needs to be enabled. ($_$ USE $_$ LFN >= 1) / Note that enabling exFAT discards C89 compatibility.

7.19.2.4 _FS_LOCK

#define _FS_LOCK 2

0:Disable or >=1:Enable The option _FS_LOCK switches file lock function to control duplicated file open / and illegal operation to open objects. This option must be 0 when _FS_READONLY / is 1. // 0: Disable file lock function. To avoid volume corruption, application program / should avoid illegal open, remove and rename to the open objects. / >0: Enable file lock function. The value defines how many files/sub-directories / can be opened simultaneously under file lock control. Note that the file / lock control is independent of re-entrancy.

7.19.2.5 _FS_MINIMIZE

```
#define _FS_MINIMIZE 0
```

0 to 3 This option defines minimization level to remove some basic API functions. // 0: All basic functions are enabled. / 1: f_stat(), f_getfree(), f_unlink(), f_mkdir(), f_truncate() and f_rename() / are removed. / 2: f_opendir(), f_readdir() and f_closedir() are removed in addition to 1. / 3: f_lseek() function is removed in addition to 2.

7.19.2.6 _FS_NOFSINFO

```
#define _FS_NOFSINFO 0
```

0,1,2 or 3 If you need to know correct free space on the FAT32 volume, set bit 0 of this / option, and f_getfree() function at first time after volume mount will force / a full FAT scan. Bit 1 controls the use of last allocated cluster number. // bit0=0: Use free cluster count in the FSINFO if available. / bit0=1: Do not trust free cluster count in the FSINFO. / bit1=0: Use last allocated cluster number in the FSINFO if available. / bit1=1: Do not trust last allocated cluster number in the FSINFO.

7.19.2.7 _FS_NORTC

```
#define _FS_NORTC 0
```

&

7.19.2.8 _FS_READONLY

```
#define _FS_READONLY 0
```

0:Read/Write or 1:Read only This option switches read-only configuration. (0:Read/Write or 1:Read-only) / Read-only configuration removes writing API functions, f_write(), f_sync(), / f_unlink(), f_mkdir(), f_chmod(), f_rename(), f_truncate(), f_getfree() / and optional writing functions as well.

7.19.2.9 _FS_REENTRANT

```
#define _FS_REENTRANT 0
```

0:Disable or 1:Enable

7.19.2.10 _FS_RPATH

```
#define _FS_RPATH 0
```

0 to 2 This option configures support of relative path. // 0: Disable relative path and remove related functions. / 1: Enable relative path. f_chdir() and f_chdrive() are available. / 2: f_getcwd() function is available in addition to 1.

7.19.2.11 _FS_TIMEOUT

#define _FS_TIMEOUT 1000

Timeout period in unit of time ticks

7.19.2.12 _FS_TINY

#define _FS_TINY 0

0:Normal or 1:Tiny This option switches tiny buffer configuration. (0:Normal or 1:Tiny) / At the tiny configuration, size of file object (FIL) is reduced _MAX_SS bytes. / Instead of private sector buffer eliminated from the file object, common sector / buffer in the file system object (FATFS) is used for the file data transfer.

7.19.2.13 _LFN_UNICODE

#define _LFN_UNICODE 0

0:ANSI/OEM or 1:Unicode This option switches character encoding on the API. (0:ANSI/OEM or 1:UTF-16) / To use Unicode string for the path name, enable LFN and set _LFN_UNICODE = 1. / This option also affects behavior of string I/O functions.

7.19.2.14 MAX_LFN

#define _MAX_LFN 255

Maximum LFN length to handle (12 to 255) The _USE_LFN switches the support of long file name (LFN). // 0: Disable support of LFN. _MAX_LFN has no effect. / 1: Enable LFN with static working buffer on the BSS. Always NOT thread-safe. / 2: Enable LFN with dynamic working buffer on the STACK. / 3: Enable LFN with dynamic working buffer on the HEAP. // To enable the LFN, Unicode handling functions (option/unicode.c) must be added / to the project. The working buffer occupies (_MAX_LFN + 1) * 2 bytes and / additional 608 bytes at exFAT enabled. _MAX_LFN can be in range from 12 to 255. / It should be set 255 to support full featured LFN operations. / When use stack for the working buffer, take care on stack overflow. When use heap / memory for the working buffer, memory management functions, ff_memalloc() and / ff_memfree(), must be added to the project.

7.19.2.15 _MAX_SS

#define _MAX_SS 512

512, 1024, 2048 or 4096 These options configure the range of sector size to be supported. (512, 1024, / 2048 or 4096) Always set both 512 for most systems, all type of memory cards and / harddisk. But a larger value may be required for on-board flash memory and some / type of optical media. When _MAX_SS is larger than _MIN_SS, FatFs is configured / to variable sector size and GET_SECTOR_SIZE command must be implemented to the / disk ioctl() function.

7.19.2.16 _MIN_SS

#define _MIN_SS 512

512, 1024, 2048 or 4096

7.19.2.17 _MULTI_PARTITION

```
#define _MULTI_PARTITION 0
```

0:Single partition, 1:Multiple partition This option switches support of multi-partition on a physical drive. / By default (0), each logical drive number is bound to the same physical drive / number and only an FAT volume found on the physical drive will be mounted. / When multi-partition is enabled (1), each logical drive number can be bound to / arbitrary physical drive and partition listed in the VolToPart[]. Also f fdisk() / function will be available.

7.19.2.18 NORTC_MDAY

```
#define _NORTC_MDAY 4
```

&

7.19.2.19 NORTC_MON

```
#define _NORTC_MON 6
```

&

7.19.2.20 _NORTC_YEAR

```
#define _NORTC_YEAR 2015
```

The option _FS_NORTC switches timestamp function. If the system does not have / any RTC function or valid timestamp is not needed, set _FS_NORTC = 1 to disable / the timestamp function. All objects modified by FatFs will have a fixed timestamp / defined by _NORTC_MON, _NORTC_MDAY and _NORTC_YEAR in local time. / To enable timestamp function (_FS_NORTC = 0), get_fattime() function need to be / added to the project to get current time form real-time clock. _NORTC_MON, / _NORTC_MDAY and _NORTC_YEAR have no effect. / These options have no effect at read-only configuration (_FS_READONLY = 1).

7.19.2.21 _STR_VOLUME_ID

```
#define _STR_VOLUME_ID 0
```

0:Use only 0-9 for drive ID, 1:Use strings for drive ID

7.19.2.22 STRF_ENCODE

```
#define _STRF_ENCODE 3
```

When $_$ LFN $_$ UNICODE == 1, this option selects the character encoding ON THE FILE to / be read/written via string I/O functions, f $_$ gets(), f $_$ putc(), f $_$ puts and f $_$ printf(). // 0: ANSI/OEM / 1: UTF-16LE / 2: UTF-16BE / 3: UTF-8 // This option has no effect when $_$ LFN $_$ UNICODE == 0.

```
7.19.2.23 _SYNC_t
```

```
#define _SYNC_t osSemaphoreId
```

The option _FS_REENTRANT switches the re-entrancy (thread safe) of the FatFs / module itself. Note that regardless of this option, file access to different / volume is always re-entrant and volume control functions, f_mount(), f_mkfs() / and f_fdisk() function, are always not re-entrant. Only file/directory access / to the same volume is under control of this function. // 0: Disable re-entrancy. _FS_TIMEOUT and _SYNC_t have no effect. / 1: Enable re-entrancy. Also user provided synchronization handlers, / ff_req_grant(), ff_rel_grant(), ff_del_syncobj() and ff_cre_syncobj() / function, must be added to the project. Samples are available in / option/syscall.c. // The _FS _ _TIMEOUT defines timeout period in unit of time tick. / The _SYNC_t defines O/S dependent sync object type. e.g. HANDLE, ID, OS_EVENT*, / SemaphoreHandle_t and etc.. A header file for O/S definitions needs to be / included somewhere in the scope of ff.h.

7.19.2.24 _USE_CHMOD

```
#define _USE_CHMOD 0
```

This option switches attribute manipulation functions, $f_chmod()$ and $f_utime()$. / (0:Disable or 1:Enable) Also $_F \leftarrow S_READONLY$ needs to be 0 to enable this option.

7.19.2.25 USE EXPAND

```
#define _USE_EXPAND 0
```

This option switches f_expand function. (0:Disable or 1:Enable)

7.19.2.26 _USE_FASTSEEK

```
#define _USE_FASTSEEK 1
```

This option switches fast seek feature. (0:Disable or 1:Enable)

7.19.2.27 _USE_FIND

```
#define _USE_FIND 0
```

This option switches filtered directory read functions, f_findfirst() and / f_findnext(). (0:Disable, 1:Enable 2:Enable with matching altname[] too)

7.19.2.28 _USE_FORWARD

```
#define _USE_FORWARD 0
```

This option switches f_forward() function. (0:Disable or 1:Enable)

```
7.19.2.29 _USE_LABEL

#define _USE_LABEL 0

This option switches volume label functions, f_getlabel() and f_setlabel(). / (0:Disable or 1:Enable)

7.19.2.30 _USE_LFN

#define _USE_LFN 1

0 to 3

7.19.2.31 _USE_MKFS

#define _USE_MKFS 1

This option switches f_mkfs() function. (0:Disable or 1:Enable)

7.19.2.32 _USE_STRFUNC

#define _USE_STRFUNC 2
```

0:Disable or 1-2:Enable This option switches string functions, f_gets(), f_putc(), f_puts() and / f_printf(). // 0: Disable string functions. / 1: Enable without LF-CRLF conversion. / 2: Enable with LF-CRLF conversion.

```
7.19.2.33    _USE_TRIM
#define _USE_TRIM 0
```

This option switches support of ATA-TRIM. (0:Disable or 1:Enable) / To enable Trim function, also CTRL_TRIM command should be implemented to the / disk_ioctl() function.

```
7.19.2.34 _VOLUME_STRS

#define _VOLUME_STRS

Value:

"RAM", "NAND", "CF", "SD1", "SD2", "USB1", "USB2", \
"USB3"
```

_STR_VOLUME_ID switches string support of volume ID. / When _STR_VOLUME_ID is set to 1, also pre-defined strings can be used as drive / number in the path name. _VOLUME_STRS defines the drive ID strings for each / logical drives. Number of items must be equal to _VOLUMES. Valid characters for / the drive ID strings are: A-Z and 0-9.

```
7.19.2.35 _VOLUMES
```

```
#define _VOLUMES 1
```

Number of volumes (logical drives) to be used.

```
7.19.2.36 ff_free
```

```
#define ff_free free
```

define the ff_malloc ff_free macros as standard malloc free

```
7.19.2.37 ff malloc
```

```
#define ff_malloc malloc
```

define the ff_malloc ff_free macros as standard malloc free

7.20 src/hid_audio.h File Reference

Audio Driver

Configures Audio Device and provides callback for signal processing. Many of the hard-coded values here will change (increase), and/or be replaced by configurable options

includ

```
#include <stddef.h>
#include <stdint.h>
#include "per_sai.h"
#include "per_i2c.h"
```

Classes

• struct dsy_audio_handle

Macros

- #define DSY_AUDIO_H
- #define DSY_AUDIO_BLOCK_SIZE_MAX 128
- #define DSY_AUDIO_CHANNELS_MAX 2
- #define DSY_AUDIO_SAMPLE_RATE 48014.0f

Typedefs

typedef void(* dsy_audio_mc_callback) (float **, float **, size_t)

Enumerations

enum { DSY_AUDIO_INTERNAL, DSY_AUDIO_EXTERNAL, DSY_AUDIO_LAST }

Functions

- void dsy_audio_init (dsy_audio_handle *handle)
- void dsy_audio_set_callback (uint8_t intext, dsy_audio_callback cb)
- void dsy_audio_set_mc_callback (dsy_audio_mc_callback cb)
- void dsy_audio_set_blocksize (uint8_t intext, size_t blocksize)
- void dsy audio start (uint8 t intext)
- void dsy_audio_stop (uint8_t intext)
- void dsy_audio_enter_bypass (uint8_t intext)
- void dsy_audio_exit_bypass (uint8_t intext)
- void dsy_audio_passthru (float *in, float *out, size_t size)
- void dsy_audio_silence (float *in, float *out, size_t size)

7.20.1 Detailed Description

Audio Driver

Configures Audio Device and provides callback for signal processing. Many of the hard-coded values here will change (increase), and/or be replaced by configurable options

7.20.2 Macro Definition Documentation

7.20.2.1 DSY_AUDIO_BLOCK_SIZE_MAX

```
#define DSY_AUDIO_BLOCK_SIZE_MAX 128
```

Defines for generic maximums While 'Audio Channels Max' is set to 2, this is per-SAI 4x4 Audio I/O is possible using the dsy_audio_mc_callback Hard-coded samplerate is calculated from original clock tree. The new clock tree has less than 0.01% error for all supported sampleratesMax block size

7.20.2.2 DSY_AUDIO_CHANNELS_MAX

```
#define DSY_AUDIO_CHANNELS_MAX 2
```

Max number of audio channels

7.20.2.3 DSY_AUDIO_H

#define DSY_AUDIO_H

&

7.20.2.4 DSY_AUDIO_SAMPLE_RATE

```
#define DSY_AUDIO_SAMPLE_RATE 48014.0f
```

Default sample rate

7.20.3 Typedef Documentation

7.20.3.1 dsy_audio_mc_callback

```
typedef void(* dsy_audio_mc_callback) (float **, float **, size_t)
```

These are user-defineable callbacks that are called when audio data is ready to be received/transmitted. This function is called at samplerate/blocksize (e.g. 1kHz when Function to define for using a single Stereo device for I/Oaudio is packed as: { LEFT | RIGHT | LEFT | RIGHT } typical example:

```
void AudioCallback(float *in, float *out, size_t size)
{
    for (size_t i = 0; i < size; i+=2)
{
    out[i] = in[i]; // Left
    out[i+1] = in[i+1]; // Right
}</pre>
```

/ typedef void (dsy audio callback)(float, float, size t);

/** Defaults to 4 channels, and is fixed for now. (still works for stereo, but will still fill buffers) */ // /** audio is packed as: */ // /** { LEFT | LEFT + 1 | . . . | LEFT + SIZE | RIGHT | RIGHT + 1 | . . . | RIGHT + SIZE } */ // /** typical example:

```
void AudioCallback(float **in, float **out, size_t size)
{
  */
```

7.20.4 Enumeration Type Documentation

7.20.4.1 anonymous enum

anonymous enum

Internally, there are two separate 'audio blocks' that can be configured together or separately

Enumerator

DSY_AUDIO_INTERNAL	&
DSY_AUDIO_EXTERNAL	&
DSY_AUDIO_LAST	&

7.20.5 Function Documentation

7.20.5.1 dsy_audio_enter_bypass()

If the device supports hardware bypass, enter that mode.**Only minimally tested with WM8731 codec.**

7.20.5.2 dsy_audio_exit_bypass()

If the device supports hardware bypass, exit that mode.**Only minimally tested with WM8731 codec.**

7.20.5.3 dsy_audio_init()

Initializes the Audio Engine using configurations set to the sai_handlei2c_handles can be set to NULL if not needed.

7.20.5.4 dsy_audio_passthru()

```
void dsy_audio_passthru (
          float * in,
           float * out,
           size_t size )
```

A few useful stereo-interleaved callbacks Passes the input to the output

7.20.5.5 dsy_audio_set_blocksize()

Sets the number of samples (per-channel) to be handled in a single audio frame.

7.20.5.6 dsy_audio_set_callback()

Sets the user defined, interleaving callback to be called when audio data is ready.

intext is a specifier for DSY_AUDIO_INT/EXT (which audio peripheral to use).

When using this, each 'audio block' can have completely independent callbacks.

7.20.5.7 dsy_audio_set_mc_callback()

```
void dsy_audio_set_mc_callback ( {\tt dsy\_audio\_mc\_callback}\ cb\ )
```

Sets the user defined, non-interleaving callback to be called when audio data is ready. This will always use both DSY_AUDIO_INT and DSY_AUDIO_EXT blocks together. To ensure clean audio you'll want to make sure the two SAIs are set to the same samplerate

7.20.5.8 dsy_audio_silence()

sets outputs to 0 without stopping the Audio Engine.

7.20.5.9 dsy_audio_start()

Starts Audio Engine, callbacks will begin getting called. When using with dsy_audio_mc_callback (for 4 channels), this function should be called for both audio blocks

7.20.5.10 dsy_audio_stop()

Stops transmitting/receiving audio on the specified audio block.

7.21 src/hid ctrl.h File Reference

```
#include <stdint.h>
```

Classes

· class daisy::AnalogControl

Hardware Interface for control inputs Primarily designed for ADC input controls such as potentiometers, and control voltage.

7.22 src/hid_encoder.h File Reference

```
#include "daisy_core.h"
#include "per_gpio.h"
#include "hid_switch.h"
```

Classes

· class daisy::Encoder

Generic Class for handling Quadrature Encoders
Inspired/influenced by Mutable Instruments (pichenettes) Encoder classes.

7.23 src/hid_gatein.h File Reference

```
#include "per_gpio.h"
```

Classes

· class daisy::GateIn

Generic Class for handling gate inputs through GPIO.

7.24 src/hid_led.h File Reference

```
#include "daisy_core.h"
#include "per_gpio.h"
```

Classes

· class daisy::Led

LED Class providing simple Software PWM ability, etc Eventually this will work with hardware PWM, and external LED Driver devices as well.

7.25 src/hid_midi.h File Reference

```
#include <stdint.h>
#include <stdlib.h>
#include "per_uart.h"
#include "util_ringbuffer.h"
```

Classes

- struct daisy::NoteOnEvent
- · struct daisy::ControlChangeEvent
- struct daisy::MidiEvent
- · class daisy::MidiHandler

Simple MIDI Handler

Parses bytes from an input into valid MidiEvents.

The MidiEvents fill a FIFO queue that the user can pop messages from.

Enumerations

enum daisy::MidiMessageType {
 daisy::NoteOff, daisy::NoteOn, daisy::PolyphonicKeyPressure, daisy::ControlChange,
 daisy::ProgramChange, daisy::ChannelPressure, daisy::PitchBend, daisy::MessageLast }

7.25.1 Enumeration Type Documentation

7.25.1.1 MidiMessageType

```
enum daisy::MidiMessageType
```

Parsed from the Status Byte, these are the common Midi Messages that can be handled. At this time only 3-byte messages are correctly parsed into MidiEvents.

Enumerator

NoteOff	&
NoteOn	&
PolyphonicKeyPressure	&
ControlChange	&
ProgramChange	&
ChannelPressure	&
PitchBend	&
MessageLast	&

7.26 src/hid_oled_display.h File Reference

```
#include <stdlib.h>
#include <stdint.h>
#include "util_oled_fonts.h"
#include "daisy_core.h"
```

Classes

· class daisy::OledDisplay

Macros

- #define DSY_OLED_DISPLAY_H
- #define SSD1309_HEIGHT 64
- #define SSD1309_WIDTH 128

7.26.1 Macro Definition Documentation

```
7.26.1.1 DSY_OLED_DISPLAY_H
```

```
#define DSY_OLED_DISPLAY_H
```

Macro

7.26.1.2 SSD1309_HEIGHT

```
#define SSD1309_HEIGHT 64
```

SSD1309 height in pixels

7.26.1.3 SSD1309_WIDTH

```
#define SSD1309_WIDTH 128
```

SSD1309 width in pixels

7.27 src/hid_parameter.h File Reference

```
#include <stdint.h>
#include "hid_ctrl.h"
```

Classes

· class daisy::Parameter

7.28 src/hid_rgb_led.h File Reference

```
#include "hid_led.h"
#include "util_color.h"
```

Classes

· class daisy::RgbLed

7.29 src/hid_switch.h File Reference

```
#include "daisy_core.h"
#include "per_gpio.h"
```

Classes

· class daisy::Switch

7.30 src/hid_usb.h File Reference

```
#include <stdint.h>
#include <stdlib.h>
```

Classes

• class daisy::UsbHandle

Interface for initializing and using the USB Peripherals on the daisy.

7.31 src/hid_wavplayer.h File Reference

```
#include "daisy_core.h"
#include "util_wav_format.h"
```

Classes

- struct daisy::WavFileInfo
- · class daisy::WavPlayer

Macros

- #define DSY_WAVPLAYER_H
- #define WAV_FILENAME_MAX 256

7.31.1 Macro Definition Documentation

```
7.31.1.1 DSY_WAVPLAYER_H
```

```
#define DSY_WAVPLAYER_H
```

Macro

7.31.1.2 WAV_FILENAME_MAX

```
#define WAV_FILENAME_MAX 256
```

Maximum LFN (set to same in FatFs (ffconf.h)

7.32 src/per_adc.h File Reference

```
#include <stdint.h>
#include <stdlib.h>
#include "daisy_core.h"
#include "per_gpio.h"
```

Classes

- struct daisy::AdcChannelConfig
- class daisy::AdcHandle

Macros

- #define DSY_ADC_H
- #define DSY_ADC_MAX_CHANNELS 14

7.32.1 Macro Definition Documentation

7.32.1.1 DSY_ADC_H

#define DSY_ADC_H

Macro

7.32.1.2 DSY_ADC_MAX_CHANNELS

#define DSY_ADC_MAX_CHANNELS 14

Maximum number of ADC channels

7.33 src/per_dac.h File Reference

```
#include "daisy_core.h"
```

Classes

• struct dsy_dac_handle

Enumerations

- enum dsy_dac_mode { DSY_DAC_MODE_POLLING, DSY_DAC_MODE_LAST }
- enum dsy_dac_bitdepth { DSY_DAC_BITS_8, DSY_DAC_BITS_12, DSY_DAC_BITS_LAST }
- enum dsy_dac_channel { DSY_DAC_CHN1, DSY_DAC_CHN2, DSY_DAC_CHN_LAST, DSY_DAC_CH
 N_BOTH }

Functions

- void dsy_dac_init (dsy_dac_handle *dsy_hdac, dsy_dac_channel channel)
- void dsy_dac_start (dsy_dac_channel channel)
- void dsy_dac_write (dsy_dac_channel channel, uint16_t val)

7.33.1 Enumeration Type Documentation

7.33.1.1 dsy_dac_bitdepth

enum dsy_dac_bitdepth

Sets the bit depth of the DAC output This can be set independently for each channel.

Enumerator

DSY_DAC_BITS_8	&
DSY_DAC_BITS_12	&
DSY_DAC_BITS_LAST	&

7.33.1.2 dsy_dac_channel

```
enum dsy_dac_channel
```

Sets which channel(s) are initialized with the settings chosen.

Enumerator

DSY DAC CHN1	&
DSY_DAC_CHN2	&
DSY_DAC_CHN_LAST	&
DSY_DAC_CHN_BOTH	&

7.33.1.3 dsy_dac_mode

```
enum dsy_dac_mode
```

Driver for the built in DAC on the STM32 The STM32 has 2 Channels of independently configurable DACs, with up to 12-bit resolution. Currently only Polling is supported.

Enumerator

DSY_DAC_MODE_POLLING	Polling mode
DSY_DAC_MODE_LAST	3

7.33.2 Function Documentation

7.33.2.1 dsy_dac_init()

Initializes the specified channel(s) of the DAC

Parameters

*dsy_hdac	Dac to initialize
channel	Channels to init

7.33.2.2 dsy_dac_start()

Turns on the DAC and turns on any internal timer if necessary.

Parameters

channel	Channel to start

7.33.2.3 dsy_dac_write()

Sets the specified channel of the dac to the value (within bitdepth) resolution. When set to 8-bit, val should be 0-255 When set to 12-bit, val should be 0-4095

Parameters

channel	Channel to write to
val	Value to write

7.34 src/per_gpio.h File Reference

```
#include "daisy_core.h"
```

Classes

• struct dsy_gpio

Enumerations

- enum dsy_gpio_mode {
 DSY_GPIO_MODE_INPUT, DSY_GPIO_MODE_OUTPUT_PP, DSY_GPIO_MODE_OUTPUT_OD, DSY
 _GPIO_MODE_ANALOG,
 DSY_GPIO_MODE_LAST }
- enum dsy_gpio_pull { DSY_GPIO_NOPULL, DSY_GPIO_PULLUP, DSY_GPIO_PULLDOWN }

Functions

- void dsy_gpio_init (dsy_gpio *p)
- void dsy_gpio_deinit (dsy_gpio *p)
- uint8_t dsy_gpio_read (dsy_gpio *p)
- void dsy_gpio_write (dsy_gpio *p, uint8_t state)
- void dsy_gpio_toggle (dsy_gpio *p)

7.34.1 Detailed Description

General Purpose IO driver

7.34.2 Enumeration Type Documentation

7.34.2.1 dsy_gpio_mode

enum dsy_gpio_mode

Sets the mode of the GPIO

Enumerator

DSY_GPIO_MODE_INPUT	&
DSY_GPIO_MODE_OUTPUT_PP	Push-Pull
DSY_GPIO_MODE_OUTPUT_OD	Open-Drain
DSY_GPIO_MODE_ANALOG	&
DSY_GPIO_MODE_LAST	&

7.34.2.2 dsy_gpio_pull

enum dsy_gpio_pull

Configures whether an internal Pull up or Pull down resistor is used

Enumerator

DSY_GPIO_NOPULL	&
DSY_GPIO_PULLUP	&
DSY_GPIO_PULLDOWN	&

7.34.3 Function Documentation

7.34.3.1 dsy_gpio_deinit()

Deinitializes the gpio pin

Parameters

```
*p Pin pointer
```

7.34.3.2 dsy_gpio_init()

Initializes the gpio with the settings configured.

Parameters

*p Pin pointer

7.34.3.3 dsy_gpio_read()

Reads the state of the gpio pin

Parameters

*p Pin pointer

Returns

1 if the pin is HIGH, and 0 if the pin is LOW

7.34.3.4 dsy_gpio_toggle()

Toggles the state of the pin so that it is not at the same state as it was previously.

Parameters

```
*p Pin pointer
```

7.34.3.5 dsy_gpio_write()

Writes the state to the gpio pin Pin will be set to 3v3 when state is 1, and 0V when state is 0

Parameters

*p	Pin pointer
state	State to write

7.35 src/per_i2c.h File Reference

```
#include "daisy_core.h"
```

Classes

• struct dsy_i2c_handle

Macros

• #define DSY_I2C_H

Enumerations

- enum dsy_i2c_periph { DSY_I2C_PERIPH_1, DSY_I2C_PERIPH_2, DSY_I2C_PERIPH_3, DSY_I2C_PE
 RIPH_4 }
- enum dsy_i2c_pin { DSY_I2C_PIN_SCL, DSY_I2C_PIN_SDA, DSY_I2C_PIN_LAST }
- enum dsy_i2c_speed { DSY_I2C_SPEED_100KHZ, DSY_I2C_SPEED_400KHZ, DSY_I2C_SPEED_1MHZ, DSY_I2C_SPEED_LAST }

Functions

• void dsy_i2c_init (dsy_i2c_handle *dsy_hi2c)

7.35.1 Macro Definition Documentation

7.35.1.1 DSY_I2C_H

#define DSY_I2C_H

Macro

7.35.2 Enumeration Type Documentation

7.35.2.1 dsy_i2c_periph

enum dsy_i2c_periph

Driver for controlling I2C devices Specifices the internal peripheral to use (these are mapped to different pins on the hardware).

Enumerator

DSY_I2C_PERIPH←	&
_1	
DSY_I2C_PERIPH ←	&
_2	
DSY_I2C_PERIPH←	&
_3	
DSY_I2C_PERIPH ↔	&
_4	

7.35.2.2 dsy_i2c_pin

```
enum dsy_i2c_pin
```

List of pins associated with the peripheral. These must be set in the handle's pin_config.

Enumerator

DSY_I2C_PIN_SCL	&
DSY_I2C_PIN_SDA	&
DSY_I2C_PIN_LAST	&

7.35.2.3 dsy_i2c_speed

```
enum dsy_i2c_speed
```

Rate at which the clock/data will be sent/received. The device being used will have maximum speeds. 1MHZ Mode is currently 886kHz**

Enumerator

DSY_I2C_SPEED_100KHZ	&
DSY_I2C_SPEED_400KHZ	&
DSY_I2C_SPEED_1MHZ	&
DSY_I2C_SPEED_LAST	&

7.35.3 Function Documentation

7.35.3.1 dsy_i2c_init()

Initializes an I2C peripheral with the data given from the handle.

Parameters

*dsy_hi2c	Required to initialize.
-----------	-------------------------

7.36 src/per_qspi.h File Reference

```
#include <stdint.h>
#include "daisy_core.h"
```

Classes

· struct dsy_qspi_handle

Macros

- #define DSY QSPI
- #define DSY MEMORY OK ((uint32 t)0x00)
- #define DSY MEMORY ERROR ((uint32 t)0x01)
- #define DSY QSPI TEXT
- #define DSY_QSPI_DATA
- #define DSY_QSPI_BSS

Enumerations

- enum dsy_qspi_pin {
 DSY_QSPI_PIN_IO0, DSY_QSPI_PIN_IO1, DSY_QSPI_PIN_IO2, DSY_QSPI_PIN_IO3,
 DSY_QSPI_PIN_CLK, DSY_QSPI_PIN_NCS, DSY_QSPI_PIN_LAST }
- enum dsy_qspi_mode { DSY_QSPI_MODE_DSY_MEMORY_MAPPED, DSY_QSPI_MODE_INDIRECT_ \hookleftarrow POLLING, DSY_QSPI_MODE_LAST }
- enum dsy_qspi_device { DSY_QSPI_DEVICE_IS25LP080D, DSY_QSPI_DEVICE_IS25LP064A, DSY_Q
 SPI_DEVICE_LAST }

Functions

- int dsy_qspi_init (dsy_qspi_handle *hqspi)
- int dsy_qspi_deinit ()
- int dsy_qspi_writepage (uint32_t adr, uint32_t sz, uint8_t *buf)
- int dsy_qspi_write (uint32_t address, uint32_t size, uint8_t *buffer)
- int dsy_qspi_erase (uint32_t start_adr, uint32_t end_adr)
- int dsy_qspi_erasesector (uint32_t addr)

7.36.1 Macro Definition Documentation

7.36.1.1 DSY_MEMORY_ERROR

```
#define DSY_MEMORY_ERROR ((uint32_t)0x01)
```

&

```
7.36.1.2 DSY_MEMORY_OK

#define DSY_MEMORY_OK ((uint32_t)0x00)
&

7.36.1.3 DSY_QSPI

#define DSY_QSPI
Macro

7.36.1.4 DSY_QSPI_BSS

#define DSY_QSPI_BSS

Value:
__attribute__((section(\
__r.gspiflash_bss")))
```

used for reading memory in memory_mapped mode.

```
7.36.1.5 DSY_QSPI_DATA
```

```
#define DSY_QSPI_DATA
```

Value:

```
__attribute__((section(\
".qspiflash_data")))
```

used for reading memory in memory mapped mode.

```
7.36.1.6 DSY_QSPI_TEXT
```

```
#define DSY_QSPI_TEXT
```

Value:

```
__attribute__((section(\
    ".qspiflash_text")))
```

used for reading memory in memory_mapped mode.

7.36.2 Enumeration Type Documentation

```
7.36.2.1 dsy_qspi_device
```

```
enum dsy_qspi_device
```

Flash Devices supported. (Both of these are more-or-less the same, just different sizes).

Enumerator

DSY_QSPI_DEVICE_IS25LP080D	&
DSY_QSPI_DEVICE_IS25LP064A	&
DSY_QSPI_DEVICE_LAST	&

7.36.2.2 dsy_qspi_mode

 $\verb"enum dsy_qspi_mode"$

Modes of operation. Memory Mapped mode: QSPI configured so that the QSPI can be read from starting address 0x90000000. Writing is not possible in this mode.

Indirect Polling mode: Device driver enabled. Read/Write possible via dsy_qspi_* functions

Enumerator

DSY_QSPI_MODE_DSY_MEMORY_MAPPED	&
DSY_QSPI_MODE_INDIRECT_POLLING	&
DSY_QSPI_MODE_LAST	&

7.36.2.3 dsy_qspi_pin

enum dsy_qspi_pin

Driver for QSPI peripheral to interface with external flash memory. Currently supported QSPI Devices: IS25LP080DList of Pins used in QSPI (passed in during Init)

Enumerator

DSY_QSPI_PIN_IO0	&
DSY_QSPI_PIN_IO1	&
DSY_QSPI_PIN_IO2	&
DSY_QSPI_PIN_IO3	&
DSY_QSPI_PIN_CLK	&
DSY_QSPI_PIN_NCS	&
DSY_QSPI_PIN_LAST	&

7.36.3 Function Documentation

7.36.3.1 dsy_qspi_deinit()

```
int dsy_qspi_deinit ( )
```

Deinitializes the peripheral This should be called before reinitializing QSPI in a different mode.

Returns

DSY_MEMORY_OK or DSY_MEMORY_ERROR

7.36.3.2 dsy_qspi_erase()

Erases the area specified on the chip. Erasures will happen by 4K, 32K or 64K increments. Smallest erase possible is 4kB at a time. (on IS25LP*)

Parameters

start_adr	Address to begin erasing from
end_adr	Address to stop erasing at

Returns

DSY_MEMORY_OK or DSY_MEMORY_ERROR

7.36.3.3 dsy_qspi_erasesector()

Erases a single sector of the chip. TODO: Document the size of this function.

Parameters

addr	Address of sector to erase
------	----------------------------

Returns

DSY_MEMORY_OK or DSY_MEMORY_ERROR

7.36.3.4 dsy_qspi_init()

Initializes QSPI peripheral, and Resets, and prepares memory for access.

Parameters

hqspi should be populated with the mode, device and pin_config before calling this function.

Returns

```
DSY_MEMORY_OK or DSY_MEMORY_ERROR
```

7.36.3.5 dsy_qspi_write()

Writes data in buffer to to the QSPI. Starting at address to address+size

Parameters

address	Address to write to
size	Buffer size
buffer	Buffer to write

Returns

```
DSY_MEMORY_OK or DSY_MEMORY_ERROR
```

7.36.3.6 dsy_qspi_writepage()

Writes a single page to to the specified address on the QSPI chip. For IS25LP* page size is 256 bytes.

Parameters

adr	Address to write to
SZ	Buff size
buf	Buffer to write

Returns

DSY_MEMORY_OK or DSY_MEMORY_ERROR

7.37 src/per_sai.h File Reference

```
#include "daisy_core.h"
```

Classes

• struct dsy_sai_handle

Enumerations

- enum dsy_audio_sai {
 DSY_AUDIO_INIT_SAI1, DSY_AUDIO_INIT_SAI2, DSY_AUDIO_INIT_BOTH, DSY_AUDIO_INIT_NONE,
 DSY_AUDIO_INIT_LAST }
- enum dsy_audio_bitdepth { DSY_AUDIO_BITDEPTH_16, DSY_AUDIO_BITDEPTH_24, DSY_AUDIO_BI

 TDEPTH_LAST }
- enum dsy_audio_sync { DSY_AUDIO_SYNC_MASTER, DSY_AUDIO_SYNC_SLAVE, DSY_AUDIO_SY NC_LAST }
- enum dsy_audio_dir { DSY_AUDIO_RX, DSY_AUDIO_TX }
- enum dsy_sai_pin {

DSY_SAI_PIN_MCLK, DSY_SAI_PIN_FS, DSY_SAI_PIN_SCK, DSY_SAI_PIN_SIN, DSY_SAI_PIN_SOUT, DSY_SAI_PIN_LAST }

DST_SAI_FIN_SOUT, DST_SAI_FIN

enum dsy_audio_device {
 DSY_AUDIO_NONE, DSY_AUDIO_DEVICE_PCM3060, DSY_AUDIO_DEVICE_WM8731, DSY_AUDIO_
 DEVICE_AK4556,
 DSY_AUDIO_DEVICE_LAST }

enum { DSY_SAI_1, DSY_SAI_2, DSY_SAI_LAST }

Functions

- void dsy_sai_init (dsy_audio_sai init, dsy_audio_samplerate sr[2], dsy_audio_bitdepth bitdepth[2], dsy_\iff audio sync sync config[2], dsy gpio pin *sai1 pin list, dsy gpio pin *sai2 pin list)
- void dsy_sai_init_from_handle (dsy_sai_handle *hsai)

7.37.1 Enumeration Type Documentation

7.37.1.1 anonymous enum

anonymous enum

Index for the several arrays in the sai handle struct below.

Enumerator

DSY_SAI_1	&
DSY_SAI_2	&
DSY_SAI_LAST	&

7.37.1.2 dsy_audio_bitdepth

 $\verb"enum dsy_audio_bitdepth"$

Specifies the bitdepth of the hardware connected to the SAI peripheral

Enumerator

DSY_AUDIO_BITDEPTH_16	&
DSY_AUDIO_BITDEPTH_24	&
DSY_AUDIO_BITDEPTH_LAST	&

7.37.1.3 dsy_audio_device

enum dsy_audio_device

List of devices with built in support. Devices not listed here, will need to have initialization done externally.

Enumerator

DSY_AUDIO_NONE	For unsupported, or custom devices.
DSY_AUDIO_DEVICE_PCM3060	&
DSY_AUDIO_DEVICE_WM8731	&
DSY_AUDIO_DEVICE_AK4556	&
DSY_AUDIO_DEVICE_LAST	&

7.37.1.4 dsy_audio_dir

enum dsy_audio_dir

Each SAI has two datalines, they can independently be configured as inputs or outputs.

Enumerator

DSY_AUDIO_RX	&
DSY_AUDIO_TX	&

7.37.1.5 dsy_audio_sai

enum dsy_audio_sai

Driver for the SAI peripheral Supports SAI1 and SAI2 with several configuration options selects which SAI (or both/none) to initialize

Enumerator

DSY_AUDIO_INIT_SAI1	&
DSY_AUDIO_INIT_SAI2	&
DSY_AUDIO_INIT_BOTH	&
DSY_AUDIO_INIT_NONE	&
DSY_AUDIO_INIT_LAST	&

7.37.1.6 dsy_audio_samplerate

enum dsy_audio_samplerate

Currently Sample Rates are not correctly supported. All audio is currently run at 48kHz

Enumerator

DSY_AUDIO_SAMPLERATE_32K	&
DSY_AUDIO_SAMPLERATE_48K	&
DSY_AUDIO_SAMPLERATE_96K	&
DSY_AUDIO_SAMPLERATE_LAST	&

7.37.1.7 dsy_audio_sync

enum dsy_audio_sync

Setting for each SAI that sets whether the processor is generating the MCLK signal or not.

Enumerator

DSY_AUDIO_SYNC_MASTER	No Crystal
DSY_AUDIO_SYNC_SLAVE	Crystal
DSY_AUDIO_SYNC_LAST	&

7.37.1.8 dsy_sai_pin

```
enum dsy_sai_pin
```

List of the pins that need to be initialized SIN/SOUT is a bit misleading, and should be turned into A/B since it is possible to configure two inputs or two outputs on a single SAI.

Enumerator

DSY_SAI_PIN_MCLK	&
DSY_SAI_PIN_FS	&
DSY_SAI_PIN_SCK	&
DSY_SAI_PIN_SIN	&
DSY_SAI_PIN_SOUT	&
DSY_SAI_PIN_LAST	&

7.37.2 Function Documentation

7.37.2.1 dsy_sai_init()

Intializes the SAI peripheral(s) with the specified settings. Pinlists should be arrays of DSY_SAI_PIN_LAST elements

Parameters

init	&
sr[]	Sample rate per chan: 0, 1
bitdepth[]	Bitdepth per chan: 0, 1
sync_config[]	& sync config per chan: 0, 1
*sai1_pin_list	&
*sai2_pin_list	&

7.37.2.2 dsy_sai_init_from_handle()

Uses the data within *hsai to initialize the peripheral(s)

Parameters

hsai &

7.38 src/per_sdmmc.h File Reference

```
#include <stdint.h>
```

Classes

- struct daisy::SdmmcHandlerInit
- class daisy::SdmmcHandler

Macros

- #define DSY SDMMC H
- #define DSY_SD_OK 0
- #define DSY_SD_ERROR 1

Enumerations

- enum daisy::SdmmcMode { daisy::SDMMC_MODE_FATFS }
- enum daisy::SdmmcBitWidth { daisy::SDMMC_BITS_1, daisy::SDMMC_BITS_4 }
- enum daisy::SdmmcSpeed { daisy::SDMMC_SPEED_400KHZ, daisy::SDMMC_SPEED_12MHZ }

7.38.1 Macro Definition Documentation

```
7.38.1.1 DSY_SD_ERROR
```

#define DSY_SD_ERROR 1

ERROR return

7.38.1.2 DSY_SD_OK

#define DSY_SD_OK 0

OK return

7.38.1.3 DSY_SDMMC_H

#define DSY_SDMMC_H

macro

7.38.2 Enumeration Type Documentation

7.38.2.1 SdmmcBitWidth

enum daisy::SdmmcBitWidth

Sets whether 4-bit mode or 1-bit mode is used for the SDMMC

Enumerator

SDMMC_BITS↔	&
_1	
SDMMC_BITS↔	&
4	

7.38.2.2 SdmmcMode

enum daisy::SdmmcMode

Operating Mode. Currently only FatFS is supported.

Enumerator

SDMMC_MODE_FATFS &

7.38.2.3 SdmmcSpeed

enum daisy::SdmmcSpeed

Sets the desired clock speed of the SD card bus. Initialization is always done at or below 400kHz, and then the user speed is set.

Enumerator

SDMMC_SPEED_400KHZ	
SDMMC SPEED 12MHZ &	

Generated by Doxygen

7.39 src/per_spi.h File Reference

```
#include "daisy_core.h"
```

Classes

• class daisy::SpiHandle

Enumerations

- enum daisy::SpiPeriph { daisy::SPI_PERIPH_1, daisy::SPI_PERIPH_3, daisy::SPI_PERIPH_6 }
- enum daisy::SpiPin { daisy::SPI_PIN_CS, daisy::SPI_PIN_SCK, daisy::SPI_PIN_MOSI, daisy::SPI_PIN_← MISO }

7.39.1 Enumeration Type Documentation

7.39.1.1 SpiPeriph

enum daisy::SpiPeriph

SPI peripheral enum

Enumerator

SPI_PERIPH↔	SPI peripheral 1
_1	
SPI_PERIPH↔	SPI peripheral 3
_3	
SPI_PERIPH↔	SPI peripheral 3
_6	

7.39.1.2 SpiPin

enum daisy::SpiPin

SPI pins

Enumerator

SPI_PIN_CS	CS pin
SPI_PIN_SCK	SCK pin
SPI_PIN_MOSI	MOSI pin
SPI_PIN_MISO	MISO pin

7.40 src/per_tim.h File Reference

```
#include <stdint.h>
```

Functions

```
• void dsy_tim_init ()
```

- void dsy_tim_start ()
- uint32_t dsy_tim_get_tick ()
- void dsy_tim_delay_tick (uint32_t cnt)
- uint32_t dsy_tim_get_ms ()
- void dsy_tim_delay_ms (uint32_t cnt)
- uint32_t dsy_tim_get_us ()
- void dsy_tim_delay_us (uint32_t cnt)

7.40.1 Function Documentation

7.40.1.1 dsy_tim_delay_ms()

blocking delay of cnt milliseconds.

Parameters

```
cnt Delay time in ms
```

7.40.1.2 dsy_tim_delay_tick()

blocking delay of cnt timer ticks.

Parameters

cnt Number of ticks

7.40.1.3 dsy_tim_delay_us()

blocking delay of cnt microseconds.

Parameters

```
cnt Delay time in us
```

7.40.1.4 dsy_tim_get_ms()

```
uint32_t dsy_tim_get_ms ( )
```

These functions are converted to use milliseconds as their time base.

Returns

the number of milliseconds through the timer period.

7.40.1.5 dsy_tim_get_tick()

```
uint32_t dsy_tim_get_tick ( )
```

These functions are specific to the actual clock ticks at the timer frequency which is currently fixed at 200MHz

Returns

a number 0x00000000-0xffffffff of the current tick

7.40.1.6 dsy_tim_get_us()

```
uint32_t dsy_tim_get_us ( )
```

These functions are converted to use microseconds as their time base.

Returns

the number of microseconds through the timer period.

```
7.40.1.7 dsy_tim_init()
```

void dsy_tim_init ()

General purpose timer for delays and general timing. initializes the TIM2 peripheral with maximum counter autoreload, and no prescalers.

```
7.40.1.8 dsy_tim_start()
void dsy_tim_start ( )
```

Starts the timer ticking.

7.41 src/per_uart.h File Reference

```
#include "daisy_core.h"
```

Classes

• class daisy::UartHandler

Macros

• #define DSY_UART_H

Variables

• const size_t daisy::kUartMaxBufferSize = 32

7.41.1 Macro Definition Documentation

```
7.41.1.1 DSY_UART_H
#define DSY_UART_H
macro
```

7.41.2 Variable Documentation

7.41.2.1 kUartMaxBufferSize

```
const size_t daisy::kUartMaxBufferSize = 32
```

Maximum Queue buffer size

7.42 src/sys_dma.h File Reference

Functions

void dsy_dma_init (void)

7.42.1 Function Documentation

7.42.1.1 dsy_dma_init()

```
void dsy_dma_init (
     void )
```

Initializes the Direct Memory Access Peripheral used by many internal elements of libdaisy. Initializes the DMA (specifically for the modules used within the library)

7.43 src/sys_system.h File Reference

```
#include <stdint.h>
```

Functions

- void dsy system init ()
- void dsy_system_jumpto (uint32_t addr)
- void dsy_system_jumptoqspi ()
- uint32_t dsy_system_getnow ()
- void dsy_system_delay (uint32_t delay_ms)

7.43.1 Detailed Description

Low level System Configuration

7.43.2 Function Documentation

7.43.2.1 dsy_system_delay()

Blocking Delay that uses the SysTick (1ms callback) to wait.

Parameters

```
delay_ms | Time to delay in ms
```

7.43.2.2 dsy_system_getnow()

```
uint32_t dsy_system_getnow ( )
```

Returns

a uint32_t value of milliseconds since the SysTick started Note! This is a HAL_GetTick()

7.43.2.3 dsy_system_init()

```
void dsy_system_init ( )
```

Initializes Clock tree, MPU, and internal memories voltage regulators. This function *must* be called at the beginning of any program using libdaisy Higher level daisy_files call this through the DaisySeed object.

7.43.2.4 dsy_system_jumpto()

```
void dsy_system_jumpto ( \mbox{uint32\_t } \mbox{\it addr} \mbox{\it )}
```

Jump to an address within the internal memory

This may not work correctly, and may not be very useful with the single sector of memory on the stm32h750**

Parameters

```
addr Address to jump to
```

7.43.2.5 dsy_system_jumptoqspi()

```
void dsy_system_jumptoqspi ( )
```

Jumps to the first address of the external flash chip (0x9000000) If there is no code there, the chip will likely fall through to the while() loop TODO: Documentation/Loader for using external flash coming soon.

7.44 src/usbd_cdc_if.h File Reference

```
: Header for usbd_cdc_if.c file.
#include "usbd_cdc.h"
```

Typedefs

• typedef void(* CDC_ReceiveCallback) (uint8_t *buf, uint32_t *size)

Functions

- void CDC_Set_Rx_Callback_FS (CDC_ReceiveCallback cb)
- uint8_t CDC_Transmit_FS (uint8_t *Buf, uint16_t Len)
- uint8_t CDC_Transmit_HS (uint8_t *Buf, uint16_t Len)

Variables

- USBD_CDC_ltfTypeDef USBD_Interface_fops_FS
- USBD_CDC_ItfTypeDef USBD_Interface_fops_HS

7.44.1 Detailed Description

: Header for usbd_cdc_if.c file.

Version

: v1.0_Cube

Attention

© Copyright (c) 2019 STMicroelectronics. All rights reserved.

This software component is licensed by ST under Ultimate Liberty license SLA0044, the "License"; You may not use this file except in compliance with the License. You may obtain a copy of the License at: www.st.com/SLA0044

7.45 src/usbd_conf.h File Reference

```
: Header for usbd_conf.c file.
```

```
#include <stdio.h>
#include <stdlib.h>
#include <string.h>
#include "stm32h7xx.h"
#include "stm32h7xx_hal.h"
```

Macros

- #define USBD_MAX_NUM_INTERFACES 1U
- #define USBD MAX NUM CONFIGURATION 1U
- #define USBD_MAX_STR_DESC_SIZ 512U
- #define USBD_SUPPORT_USER_STRING 0U
- #define USBD_DEBUG_LEVEL 3U
- #define USBD LPM ENABLED 0U
- #define USBD SELF POWERED 1U
- #define DEVICE_FS 0
- #define DEVICE HS 1
- #define USBD_malloc malloc
- #define USBD free free
- #define USBD_memset memset
- #define USBD_memcpy memcpy
- #define USBD Delay HAL Delay
- #define USBD_UsrLog(...)
- #define USBD ErrLog(...)
- #define USBD_DbgLog(...)

7.45.1 Detailed Description

: Header for usbd_conf.c file.

Version

: v1.0_Cube

Attention

© Copyright (c) 2019 STMicroelectronics. All rights reserved.

This software component is licensed by ST under Ultimate Liberty license SLA0044, the "License"; You may not use this file except in compliance with the License. You may obtain a copy of the License at: www.st.com/SLA0044

7.46 src/usbd_desc.h File Reference

```
: Header for usbd_conf.c file.
#include "usbd_def.h"
```

Macros

- #define DEVICE_ID1 (UID_BASE)
- #define DEVICE_ID2 (UID_BASE + 0x4)
- #define DEVICE_ID3 (UID_BASE + 0x8)
- #define USB_SIZ_STRING_SERIAL 0x1A

Variables

- USBD_DescriptorsTypeDef HS_Desc
- USBD DescriptorsTypeDef FS Desc

7.46.1 Detailed Description

: Header for usbd_conf.c file.

Version

: v1.0_Cube

Attention

© Copyright (c) 2019 STMicroelectronics. All rights reserved.

This software component is licensed by ST under Ultimate Liberty license SLA0044, the "License"; You may not use this file except in compliance with the License. You may obtain a copy of the License at: www.st.com/SLA0044

7.47 src/util_bsp_sd_diskio.h File Reference

#include <stdint.h>

Classes

struct DSY_SD_CardInfoTypeDef

Macros

- #define DSY BSP SD DISKIO H
- #define BSP_SD_CardInfo DSY_SD_CardInfoTypeDef
- #define MSD_OK ((uint8_t)0x00)
- #define MSD ERROR ((uint8 t)0x01)
- #define MSD_ERROR_SD_NOT_PRESENT ((uint8_t)0x02)
- #define SD TRANSFER OK ((uint8 t)0x00)
- #define SD_TRANSFER_BUSY ((uint8_t)0x01)
- #define SD PRESENT ((uint8 t)0x01)
- #define SD_NOT_PRESENT ((uint8_t)0x00)
- #define SD_DATATIMEOUT ((uint32_t)100000000)

Functions

- uint8_t BSP_SD_Init (void)
- uint8_t BSP_SD_ITConfig (void)
- uint8_t BSP_SD_ReadBlocks (uint32_t *pData, uint32_t ReadAddr, uint32_t NumOfBlocks, uint32_t Timeout)
- uint8 t BSP SD WriteBlocks (uint32 t *pData, uint32 t WriteAddr, uint32 t NumOfBlocks, uint32 t Timeout)
- uint8_t BSP_SD_ReadBlocks_DMA (uint32_t *pData, uint32_t ReadAddr, uint32_t NumOfBlocks)
- uint8_t BSP_SD_WriteBlocks_DMA (uint32_t *pData, uint32_t WriteAddr, uint32_t NumOfBlocks)
- uint8_t BSP_SD_Erase (uint32_t StartAddr, uint32_t EndAddr)
- uint8_t BSP_SD_GetCardState (void)
- void BSP_SD_GetCardInfo (DSY_SD_CardInfoTypeDef *CardInfo)
- uint8_t BSP_SD_IsDetected (void)
- · void BSP SD AbortCallback (void)
- · void BSP SD WriteCpltCallback (void)
- · void BSP_SD_ReadCpltCallback (void)

7.47.1 Macro Definition Documentation

7.47.1.1 BSP_SD_CardInfo

#define BSP_SD_CardInfo DSY_SD_CardInfoTypeDef

&

7.47.1.2 DSY_BSP_SD_DISKIO_H

#define DSY_BSP_SD_DISKIO_H

&

```
7.47.1.3 MSD_ERROR
#define MSD_ERROR ((uint8_t)0x01)
7.47.1.4 MSD_ERROR_SD_NOT_PRESENT
\#define MSD_ERROR_SD_NOT_PRESENT ((uint8_t)0x02)
7.47.1.5 MSD_OK
#define MSD_OK ((uint8_t)0x00)
7.47.1.6 SD_DATATIMEOUT
#define SD_DATATIMEOUT ((uint32_t)100000000)
7.47.1.7 SD_NOT_PRESENT
#define SD_NOT_PRESENT ((uint8_t)0x00)
&
7.47.1.8 SD_PRESENT
#define SD_PRESENT ((uint8_t)0x01)
&
7.47.1.9 SD_TRANSFER_BUSY
#define SD_TRANSFER_BUSY ((uint8_t)0x01)
&
7.47.1.10 SD_TRANSFER_OK
#define SD_TRANSFER_OK ((uint8_t)0x00)
```

&

7.47.2 Function Documentation

7.47.2.1 BSP_SD_AbortCallback()

These functions can be modified in case the current settings (e.g. DMA stream) need to be changed for specific application needs /n

Abort the callback

7.47.2.2 BSP_SD_Erase()

Erase a section of memory

Parameters

StartAddr	Address to start erasing at
EndAddr	Address to stop erasing at

Returns

card state, ERROR, etc.

7.47.2.3 BSP_SD_GetCardInfo()

Parameters

Parameters

CardInfo &

```
7.47.2.4 BSP_SD_GetCardState()
```

Returns

card state, ERROR, etc.

7.47.2.5 BSP_SD_Init()

Returns

card state, ERROR, etc.

7.47.2.6 BSP_SD_IsDetected()

Returns

Is card detected

7.47.2.7 BSP_SD_ITConfig()

Returns

card state, ERROR, etc.

7.47.2.8 BSP_SD_ReadBlocks()

Parameters

*pData	&
ReadAddr	Address to read from
NumOfBlocks	Number of blocks to be read
Timeout	Timeout len in ms

Returns

OK ERROR, etc.

7.47.2.9 BSP_SD_ReadBlocks_DMA()

No timeout

Parameters

*pData	&
ReadAddr	Address to read from
NumOfBlocks	Number of blocks to be read

Returns

card state, ERROR, etc.

7.47.2.10 BSP_SD_ReadCpltCallback()

Write complete callback

7.47.2.11 BSP_SD_WriteBlocks()

Parameters

*pData	&
WriteAddr	Address to write to
NumOfBlocks	Number of blocks to be written
Timeout	Timeout len in ms

Returns

card state, ERROR, etc.

7.47.2.12 BSP_SD_WriteBlocks_DMA()

No timeout

Parameters

*pData	&
WriteAddr	Address to write to
NumOfBlocks	Number of blocks to be read

Returns

card state, ERROR, etc.

7.47.2.13 BSP_SD_WriteCpltCallback()

Read complete callback

7.48 src/util_color.h File Reference

#include <stdint.h>

Classes

· class daisy::Color

Macros

• #define DSY_COLOR_H

7.48.1 Macro Definition Documentation

7.48.1.1 DSY_COLOR_H

```
#define DSY_COLOR_H
```

I'd like for it to be easy and not Color::PresetColor::Foo-There's no way to change a color once its been created (without unintuitively reiniting it).

7.49 src/util_hal_map.h File Reference

```
#include "stm32h7xx_hal.h"
#include "daisy_core.h"
#include "per_i2c.h"
```

Functions

- GPIO_TypeDef * dsy_hal_map_get_port (dsy_gpio_pin *p)
- uint16_t dsy_hal_map_get_pin (dsy_gpio_pin *p)
- I2C_HandleTypeDef * dsy_hal_map_get_i2c (dsy_i2c_handle *p)

Variables

- I2C_HandleTypeDef hi2c1
- I2C HandleTypeDef hi2c2
- I2C_HandleTypeDef hi2c3
- I2C_HandleTypeDef hi2c4

7.49.1 Function Documentation

7.49.1.1 dsy_hal_map_get_i2c()

Parameters

```
*p dsy_i2c_handle to get
```

Returns

The I2C_HandleTypeDef for the given *p

7.49.1.2 dsy_hal_map_get_pin()

Parameters

```
*p Pin pin to get
```

Returns

HAL GPIO Pin as used in the HAL from a dsy_gpio_pin input.

7.49.1.3 dsy_hal_map_get_port()

Parameters

*p Pin pin to get

Returns

HAL GPIO_TypeDef as used in the HAL from a dsy_gpio_pin input.

7.49.2 Variable Documentation

7.49.2.1 hi2c1

```
I2C_HandleTypeDef hi2c1
```

global structs, and helper functions for interfacing with the stm32 HAL library while it remains a dependancy. This file should only be included from source files (c/cpp) Including it from a header within libdaisy would expose the entire HAL to the users. This should be an option for users, but should not be required externs of HAL handles...

7.49.2.2 hi2c2

I2C_HandleTypeDef hi2c2

externs of HAL handles...

7.49.2.3 hi2c3

I2C_HandleTypeDef hi2c3

externs of HAL handles...

7.49.2.4 hi2c4

I2C_HandleTypeDef hi2c4

externs of HAL handles...

7.50 src/util_ringbuffer.h File Reference

```
#include <algorithm>
```

Classes

- class daisy::RingBuffer< T, size >
- class daisy::RingBuffer< T, 0 >

7.51 src/util_unique_id.h File Reference

```
#include "daisy_core.h"
```

Functions

void dsy_get_unique_id (uint32_t *w0, uint32_t *w1, uint32_t *w2)

7.51.1 Function Documentation

7.51.1.1 dsy_get_unique_id()

Returns 96-bit Unique ID of the MCU

Author

shensley

Date

May 2020 fills the three pointer arguments with the unique ID of the MCU.

Parameters

*w0	First pointer
*w1	Second pointer
*w2	Third pointer

7.52 src/util_wav_format.h File Reference

```
#include <stdint.h>
```

Classes

struct WAV_FormatTypeDef

Index

CODE DAGE	#{h 400
_CODE_PAGE	ffconf.h, 192
ffconf.h, 188	_USE_FASTSEEK
_FFCONF	ffconf.h, 192
ffconf.h, 188	_USE_FIND
_FS_EXFAT	ffconf.h, 192
ffconf.h, 188	_USE_FORWARD
_FS_LOCK	ffconf.h, 192
ffconf.h, 188	_USE_LABEL
_FS_MINIMIZE	ffconf.h, 192
ffconf.h, 188	_USE_LFN
_FS_NOFSINFO	ffconf.h, 193
ffconf.h, 189	_USE_MKFS
_FS_NORTC	ffconf.h, 193
ffconf.h, 189	_USE_STRFUNC
_FS_READONLY	ffconf.h, 193
ffconf.h, 189	_USE_TRIM
_FS_REENTRANT	ffconf.h, 193
ffconf.h, 189	_VOLUMES
_FS_RPATH	ffconf.h, 193
ffconf.h, 189	_VOLUME_STRS
_FS_TIMEOUT	ffconf.h, 193
ffconf.h, 189	fatfs_H
FS TINY	fatfs.h, 185
ffconf.h, 190	\sim AnalogControl
_LFN_UNICODE	daisy::AnalogControl, 40
ffconf.h, 190	\sim DaisyPatch
MAX LFN	daisy::DaisyPatch, 49
ffconf.h, 190	\sim DaisyPetal
MAX SS	daisy::DaisyPetal, 55
ffconf.h, 190	\sim GateIn
_MIN_SS	daisy::GateIn, 84
ffconf.h, 190	\sim Parameter
_MULTI_PARTITION	daisy::Parameter, 97
ffconf.h, 190	
_NORTC_MDAY	a_direction
	dsy_sai_handle, 75
ffconf.h, 191	adc
_NORTC_MON	daisy::DaisySeed, 68
ffconf.h, 191	AnalogControl
_NORTC_YEAR	daisy::AnalogControl, 40
ffconf.h, 191	AsControlChange
_STRF_ENCODE	daisy::MidiEvent, 87
ffconf.h, 191	AsNoteOn
_STR_VOLUME_ID	daisy::MidiEvent, 87
ffconf.h, 191	audio_handle
_SYNC_t	daisy::DaisySeed, 68
ffconf.h, 191	AudioBlockSize
_USE_CHMOD	daisy::DaisyPatch, 49
ffconf.h, 192	daisy::DaisyPetal, 56
_USE_EXPAND	daisy::DaisyPod, 62

244 INDEX

AudioCallbackRate	BlockingTransmit
daisy::DaisyPatch, 49	daisy::SpiHandle, 110
daisy::DaisyPetal, 56	Blue
daisy::DaisyPod, 62	daisy::Color, 44
AudioFormat	blue
WAV_FormatTypeDef, 120	color, 43
AudioSampleRate	button1
daisy::DaisyPatch, 50	daisy::DaisyPod, 64
daisy::DaisyPetal, 56	button2
daisy::DaisyPod, 62	daisy::DaisyPod, 64
daisy::DaisySeed, 66	buttons
daily Bailey Boods, 00	daisy::DaisyPod, 65
b_direction	ByteRate
dsy_sai_handle, 75	WAV_FormatTypeDef, 121
BLOCK_ERASE_32K_CMD	WW_i omanypobol, iEi
dev_flash_IS25LP064A.h, 147	CDC_ReceiveCallback
dev flash IS25LP080D.h, 162	USBD_CDC_IF_Exported_Types, 11
BSP_SD_AbortCallback	CDC_Set_Rx_Callback_FS
util_bsp_sd_diskio.h, 235	USBD_CDC_IF_Exported_FunctionsPrototype, 14
BSP_SD_CardInfo	CDC_Transmit_FS
util_bsp_sd_diskio.h, 233	USBD_CDC_IF_Exported_FunctionsPrototype, 14
BSP_SD_Erase	CDC Transmit HS
util_bsp_sd_diskio.h, 235	USBD_CDC_IF_Exported_FunctionsPrototype, 14
BSP_SD_GetCardInfo	CLEAR_FLAG_STATUS_REG_CMD
util_bsp_sd_diskio.h, 235	dev_flash_IS25LP064A.h, 147
BSP_SD_GetCardState	dev_flash_IS25LP080D.h, 162
util_bsp_sd_diskio.h, 235	CV1_ADC_PIN
BSP_SD_ITConfig	daisy_field.h, 134
util_bsp_sd_diskio.h, 236	CV2_ADC_PIN
BSP_SD_Init	daisy_field.h, 134
util_bsp_sd_diskio.h, 236	CV3_ADC_PIN
BSP_SD_IsDetected	daisy_field.h, 134
util_bsp_sd_diskio.h, 236	CV4_ADC_PIN
BSP_SD_ReadBlocks	daisy_field.h, 134
util_bsp_sd_diskio.h, 236	capacity
BSP_SD_ReadBlocks_DMA	daisy::RingBuffer, 100
util_bsp_sd_diskio.h, 237	daisy::RingBuffer $<$ T, 0 $>$, 104
BSP_SD_ReadCpltCallback	CardSpeed
util_bsp_sd_diskio.h, 237	DSY_SD_CardInfoTypeDef, 77
BSP_SD_WriteBlocks	CardType
util_bsp_sd_diskio.h, 237	DSY_SD_CardInfoTypeDef, 77
BSP_SD_WriteBlocks_DMA	CardVersion
util_bsp_sd_diskio.h, 238	DSY_SD_CardInfoTypeDef, 78
BSP_SD_WriteCpltCallback	ChangeAudioCallback
util_bsp_sd_diskio.h, 238	daisy::DaisyPatch, 50
BitPerSample	daisy::DaisyPetal, 56
WAV_FormatTypeDef, 120	daisy::DaisyPod, 62
bitdepth	channel
daisy::SdmmcHandlerInit, 107	daisy::ControlChangeEvent, 46
dsy_dac_handle, 71	daisy::MidiEvent, 87
dsy_sai_handle, 75	daisy::NoteOnEvent, 91
block_size	CheckError
dsy_audio_handle, 70	daisy::UartHandler, 115
BlockAlign	Chunkld
WAV_FormatTypeDef, 121	WAV_FormatTypeDef, 121
BlockNbr	Class
DSY_SD_CardInfoTypeDef, 77	DSY_SD_CardInfoTypeDef, 78
BlockSize	ClearLeds
DSY_SD_CardInfoTypeDef, 77	daisy::DaisyPetal, 56

INDEX 245

daisy::DaisyPod, 63	per_adc.h, 204
clk	DSY_AUDIO_BLOCK_SIZE_MAX
dsy_sr_4021_handle, 80	hid audio.h, 195
Close	DSY_AUDIO_CHANNELS_MAX
daisy::WavPlayer, 123	hid_audio.h, 195
codec_ak4556_init	DSY_AUDIO_SAMPLE_RATE
dev_codec_ak4556.h, 141	hid_audio.h, 195
codec_frame_t, 41	DSY_AUDIO_H
I, 42	hid_audio.h, 195
r, 42	DSY_BSP_SD_DISKIO_H
codec_pcm3060_init dev_codec_pcm3060.h, 142	util_bsp_sd_diskio.h, 233 DSY_COLOR_H
codec_wm8731_enter_bypass	util_color.h, 239
dev_codec_wm8731.h, 143	DSY CORE HW H
codec_wm8731_exit_bypass	daisy_core.h, 131
dev_codec_wm8731.h, 143	DSY FIELD BSP H
codec_wm8731_init	daisy_field.h, 134
dev_codec_wm8731.h, 143	DSY_I2C_H
color, 42	per_i2c.h, 210
blue, 43	DSY_LED_DRIVER_MAX_DRIVERS
green, 43	dev_leddriver.h, 176
red, 43 Configure	DSY_MEMORY_ERROR
daisy::DaisySeed, 67	per_qspi.h, 212
control number	DSY_MEMORY_OK
daisy::ControlChangeEvent, 46	per_qspi.h, 212
controls	DSY_OLED_DISPLAY_H
daisy::DaisyPatch, 52	hid_oled_display.h, 201 DSY PETAL H
cs	daisy_petal.h, 140
dsy_sr_4021_handle, 80	DSY_QSPI_BSS
Ctrl	per_qspi.h, 213
daisy::DaisyPatch, 49	DSY_QSPI_DATA
cube	per_qspi.h, 213
daisy_core.h, 132 Curve	DSY_QSPI_TEXT
daisy::Parameter, 96	per_qspi.h, 213
CVS	DSY_QSPI
daisy::daisy_field, 47	per_qspi.h, 213
· · · · , · · · · · , · · · · · · · · · · · · · · · · · · ·	DSY_SD_CardInfoTypeDef, 77
DEV_SR_4021_H	BlockNbr, 77
dev_sr_4021.h, 181	BlockSize, 77 CardSpeed, 77
DEVICE_FS	CardType, 77
USBD_CONF_Exported_Defines, 17 DEVICE HS	CardVersion, 78
USBD_CONF_Exported_Defines, 17	Class, 78
DEVICE ID1	LogBlockNbr, 78
USBD_DESC_Exported_Constants, 24	LogBlockSize, 78
DEVICE ID2	RelCardAdd, 78
USBD_DESC_Exported_Constants, 24	DSY_SD_ERROR
DEVICE_ID3	per_sdmmc.h, 222
USBD_DESC_Exported_Constants, 24	DSY_SD_OK
DIE_ERASE_CMD	per_sdmmc.h, 222
dev_flash_IS25LP064A.h, 147	DSY_SDMMC_H
dev_flash_IS25LP080D.h, 163	per_sdmmc.h, 222
DMA_BUFFER_MEM_SECTION	DSY_SDRAM_BSS
daisy_core.h, 131	dev_sdram.h, 179 DSY_SDRAM_DATA
DSY_ADC_MAX_CHANNELS per_adc.h, 204	dev_sdram.h, 179
DSY ADC H	DSY UART H

246 INDEX

per_uart.h, 227	daisy::AnalogControl, 39
DSY_WAVPLAYER_H	\sim AnalogControl, 40
hid_wavplayer.h, 203	AnalogControl, 40
DTCM_MEM_SECTION	Init, 40
daisy_core.h, 131	InitBipolarCv, 41
DUAL_IN_FAST_PROG_CMD	Process, 41
dev_flash_IS25LP064A.h, 147	Value, 41
dev_flash_IS25LP080D.h, 163	daisy::Color, 43
DUAL_INOUT_FAST_READ_4_BYTE_ADDR_CMD	Blue, 44
dev_flash_IS25LP064A.h, 147	Green, 44
dev_flash_IS25LP080D.h, 163	Init, 44, 45
DUAL_INOUT_FAST_READ_CMD	PresetColor, 44
dev_flash_IS25LP064A.h, 147	Red, 45
dev_flash_IS25LP080D.h, 163	daisy::ControlChangeEvent, 45
DUAL_INOUT_FAST_READ_DTR_CMD	channel, 46
dev_flash_IS25LP064A.h, 147	control_number, 46
dev_flash_IS25LP080D.h, 163	value, 46
DUAL_OUT_FAST_READ_4_BYTE_ADDR_CMD	daisy::DaisyPatch, 48
dev_flash_IS25LP064A.h, 148	~DaisyPatch, 49
dev_flash_IS25LP080D.h, 163	AudioBlockSize, 49
DUAL_OUT_FAST_READ_CMD	AudioCallbackRate, 49 AudioSampleRate, 50
dev_flash_IS25LP064A.h, 148	ChangeAudioCallback, 50
dev_flash_IS25LP080D.h, 163	controls, 52
DUAL_OUT_FAST_READ_DTR_CMD dev_flash_IS25LP064A.h, 148	Ctrl, 49
dev_flash_IS25LP080D.h, 163	DaisyPatch, 49
dac_handle	DebounceControls, 50
daisy::DaisySeed, 68	DelayMs, 50
daisy.h	display, 52
F2S16_SCALE, 128	DisplayControls, 50
F2S24 SCALE, 128	encoder, 52
f2s16, 129	gate_input, 52
f2s24, 129	gate_output, 52
FBIPMAX, 128	GateInput, 49
FBIPMIN, 128	GetCtrlValue, 51
S162F_SCALE, 128	Init, 51
s162f, 129	midi, <u>52</u>
S242F_SCALE, 129	seed, 53
s242f, 130	SetAudioBlockSize, 51
S24SIGN, 129	StartAdc, 51
daisy::AdcChannelConfig, 33	StartAudio, 51
InitMux, 34	UpdateAnalogControls, 52
InitSingle, 34	daisy::DaisyPetal, 53
mux_channels_, 35	∼DaisyPetal, 55
mux_pin_, 35	AudioBlockSize, 56
MuxPin, 33	AudioCallbackRate, 56
pin_, 35	AudioSampleRate, 56
daisy::AdcHandle, 35	ChangeAudioCallback, 56
Get, 36	ClearLeds, 56
GetFloat, 37	DaisyPetal, 55
GetMux, 37	DebounceControls, 56
GetMuxFloat, 37	DelayMs, 57
GetMuxPtr, 38	encoder, 59
GetPtr, 38	expression, 59
Init, 38	footswitch_led, 59
OverSampling, 36	FootswitchLed, 54
Start, 39	GetExpression, 57
Stop, 39	GetKnobValue, 57

Init, 57	StartAudio, 68
Knob, 54	usb_handle, 69
knob, 60	daisy::Encoder, 81
ring_led, 60	Debounce, 81
RingLed, 55	FallingEdge, 82
seed, 60	Increment, 82
SetAudioBlockSize, 57	Init, 82
SetFootswitchLed, 58	Pressed, 82
SetRingLed, 58	RisingEdge, 82
StartAdc, 58	TimeHeldMs, 82
StartAudio, 59	daisy::GateIn, 84
Sw, 55	\sim GateIn, 84
switches, 60	GateIn, 84
UpdateAnalogControls, 59	Init, 84
UpdateLeds, 59	Trig, 85
daisy::DaisyPod, 60	daisy::Led, 85
AudioBlockSize, 62	Init, 85
AudioCallbackRate, 62	Set, 86
AudioSampleRate, 62	Update, 86
button1, 64	daisy::MidiEvent, 86
button2, 64	AsControlChange, 87
buttons, 65	AsNoteOn, 87
ChangeAudioCallback, 62	channel, 87
ClearLeds, 63	data, 87
DebounceControls, 63	type, 87
DelayMs, 63	daisy::MidiHandler, 88
encoder, 65	HasEvents, 89
GetKnobValue, 63	Init, 89
Init, 63	Listen, 90
Knob, 61	MidiInputMode, 88
knob1, 65	MidiOutputMode, 89
knob2, 65	Parse, 90
knobs, 65	PopEvent, 90
led1, 65	StartReceive, 90
led2, 65	daisy::NoteOnEvent, 91
seed, 65	channel, 91
SetAudioBlockSize, 63	note, 91
StartAudia 64	velocity, 91
StartAudio, 64	daisy::OledDisplay, 91
Sw, 62	DrawPixel, 92
UpdateAnalogControls, 64	Fill, 94
UpdateLeds, 64	Init, 94
daisy::DaisySeed, 66	Pins, 92
adc, 68	SetCursor, 94
audio_handle, 68	Update, 95
AudioSampleRate, 66	WriteChar, 95
Configure, 67	WriteString, 95
dac_handle, 68	daisy::Parameter, 96
GetPin, 67	\sim Parameter, 97
i2c1_handle, 68	Curve, 96
i2c2_handle, 68	Init, 97
Init, 67	Parameter, 97
qspi_handle, 69	Process, 97
sai_handle, 69	Value, 98
sdram_handle, 69	daisy::RgbLed, 98
SetAudioBlockSize, 67	Init, 98
SetLed, 67	Set, 99
SetTestPoint, 67	SetColor, 99

Update, 99	daisy::WavFileInfo, 122
daisy::RingBuffer	name, 122
capacity, 100	raw_data, 123
Flush, 100	daisy::WavPlayer, 123
ImmediateRead, 100, 101	Close, 123
Init, 101	GetCurrentFile, 124
Overwrite, 101, 102	GetLooping, 124
Read, 102	GetNumberFiles, 124
readable, 102	Init, 124
Swallow, 102	Open, 124
writable, 103	Prepare, 125
Write, 103	Restart, 125
daisy::RingBuffer< T, 0 >, 103	SetLooping, 125
capacity, 104	Stream, 125
Flush, 104	daisy::daisy_field, 46
ImmediateRead, 104	cvs, 47
Init, 105	gate_in, 47
Overwrite, 105	gate_out, 47
Read, 105	keyboard_sr, 47
readable, 105	knobs, 47
writable, 106	seed, 47
Write, 106	switches, 47
daisy::RingBuffer< T, size >, 100	daisy_core.h
daisy::SdmmcHandler, 106	cube, 132
Init, 107	DMA_BUFFER_MEM_SECTION, 131
daisy::SdmmcHandlerInit, 107	DSY_CORE_HW_H, 131
bitdepth, 107	DTCM_MEM_SECTION, 131
speed, 107	dsy_gpio_port, 131
daisy::SpiHandle, 110	dsy_pin, 132
BlockingTransmit, 110	dsy_pin_cmp, 132
Init, 110	daisy_field.h
daisy::Switch, 110	CV1_ADC_PIN, 134
Debounce, 112	CV2_ADC_PIN, 134
•	
FallingEdge, 112	CV3_ADC_PIN, 134
	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134
FallingEdge, 112	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138
FallingEdge, 112 Init, 112, 113 Polarity, 111	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D1_PIN, 135 LED_DRIVER_I2C, 135
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114 CheckError, 115	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D2_PIN, 135
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114 CheckError, 115 FlushRx, 115	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D1_PIN, 135 LED_DRIVER_I2C, 135
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114 CheckError, 115 FlushRx, 115 Init, 115	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D2_PIN, 135 LED_DRIVER_I2C, 135 MIDI_IN_PIN, 135
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114 CheckError, 115 FlushRx, 115 Init, 115 PollReceive, 115	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D2_PIN, 135 LED_DRIVER_I2C, 135 MIDI_IN_PIN, 135 MIDI_OUT_PIN, 135
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114 CheckError, 115 FlushRx, 115 Init, 115 PollReceive, 115 PollTx, 116	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D2_PIN, 135 LED_DRIVER_I2C, 135 MIDI_IN_PIN, 135 MIDI_OUT_PIN, 135 MUX_ADC_PIN, 135
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114 CheckError, 115 FlushRx, 115 Init, 115 PollReceive, 115 PollTx, 116 PopRx, 116	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D2_PIN, 135 LED_DRIVER_I2C, 135 MIDI_IN_PIN, 135 MIDI_OUT_PIN, 135 MUX_ADC_PIN, 135 MUX_SEL_0_PIN, 136
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114 CheckError, 115 FlushRx, 115 Init, 115 PollReceive, 115 PollTx, 116 PopRx, 116 Readable, 116	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D2_PIN, 135 LED_DRIVER_I2C, 135 MIDI_IN_PIN, 135 MIDI_OUT_PIN, 135 MUX_ADC_PIN, 135 MUX_SEL_0_PIN, 136 MUX_SEL_1_PIN, 136
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114 CheckError, 115 FlushRx, 115 Init, 115 PollReceive, 115 PollTx, 116 PopRx, 116 Readable, 116 RxActive, 116	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D2_PIN, 135 LED_DRIVER_I2C, 135 MIDI_IN_PIN, 135 MIDI_OUT_PIN, 135 MUX_ADC_PIN, 135 MUX_SEL_0_PIN, 136 MUX_SEL_2_PIN, 136
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114 CheckError, 115 FlushRx, 115 Init, 115 PollReceive, 115 PollTx, 116 PopRx, 116 Readable, 116 RxActive, 116 StartRx, 117	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D2_PIN, 135 LED_DRIVER_I2C, 135 MIDI_IN_PIN, 135 MIDI_OUT_PIN, 135 MUX_ADC_PIN, 135 MUX_SEL_0_PIN, 136 MUX_SEL_1_PIN, 136 SAMPLE_RATE, 136
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114 CheckError, 115 FlushRx, 115 Init, 115 PollReceive, 115 PollTx, 116 PopRx, 116 Readable, 116 RxActive, 116 StartRx, 117 daisy::UsbHandle, 117 Init, 118 ReceiveCallback, 118	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D2_PIN, 135 LED_DRIVER_I2C, 135 MIDI_IN_PIN, 135 MIDI_OUT_PIN, 135 MUX_ADC_PIN, 135 MUX_SEL_0_PIN, 136 MUX_SEL_1_PIN, 136 SAMPLE_RATE, 136 SW_1_PIN, 136 SW_2_PIN, 136 SW_3_PIN, 136
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114 CheckError, 115 FlushRx, 115 Init, 115 PollReceive, 115 PollTx, 116 PopRx, 116 Readable, 116 RxActive, 116 StartRx, 117 daisy::UsbHandle, 117 Init, 118	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D2_PIN, 135 LED_DRIVER_I2C, 135 MIDI_IN_PIN, 135 MIDI_OUT_PIN, 135 MIDI_OUT_PIN, 135 MUX_ADC_PIN, 135 MUX_SEL_0_PIN, 136 MUX_SEL_1_PIN, 136 SAMPLE_RATE, 136 SW_1_PIN, 136
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114 CheckError, 115 FlushRx, 115 Init, 115 PollReceive, 115 PollTx, 116 PopRx, 116 Readable, 116 RxActive, 116 StartRx, 117 daisy::UsbHandle, 117 Init, 118 ReceiveCallback, 118	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D2_PIN, 135 LED_DRIVER_I2C, 135 MIDI_IN_PIN, 135 MIDI_OUT_PIN, 135 MUX_ADC_PIN, 135 MUX_SEL_0_PIN, 136 MUX_SEL_1_PIN, 136 SAMPLE_RATE, 136 SW_1_PIN, 136 SW_2_PIN, 136 SW_3_PIN, 136
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114 CheckError, 115 FlushRx, 115 Init, 115 PollReceive, 115 PollTx, 116 PopRx, 116 Readable, 116 RxActive, 116 StartRx, 117 daisy::UsbHandle, 117 Init, 118 ReceiveCallback, 118 SetReceiveCallback, 119	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D2_PIN, 135 LED_DRIVER_I2C, 135 MIDI_IN_PIN, 135 MIDI_OUT_PIN, 135 MUX_ADC_PIN, 135 MUX_SEL_0_PIN, 136 MUX_SEL_1_PIN, 136 SAMPLE_RATE, 136 SW_1_PIN, 136 SW_2_PIN, 136 SW_3_PIN, 136 daisy_field_init
FallingEdge, 112 Init, 112, 113 Polarity, 111 Pressed, 113 Pull, 111 RisingEdge, 113 TimeHeldMs, 114 Type, 112 daisy::UartHandler, 114 CheckError, 115 FlushRx, 115 Init, 115 PollReceive, 115 PollTx, 116 PopRx, 116 Readable, 116 RxActive, 116 StartRx, 117 daisy::UsbHandle, 117 Init, 118 ReceiveCallback, 118 SetReceiveCallback, 119 TransmitExternal, 119	CV3_ADC_PIN, 134 CV4_ADC_PIN, 134 DSY_FIELD_BSP_H, 134 daisy_field_init, 138 GATE_IN_PIN, 134 GATE_OUT_PIN, 134 KB_SW_SR_CLK_PIN, 135 KB_SW_SR_CS_PIN, 135 KB_SW_SR_D1_PIN, 135 KB_SW_SR_D2_PIN, 135 LED_DRIVER_I2C, 135 MIDI_IN_PIN, 135 MIDI_OUT_PIN, 135 MUX_ADC_PIN, 135 MUX_SEL_0_PIN, 136 MUX_SEL_1_PIN, 136 MUX_SEL_2_PIN, 136 SAMPLE_RATE, 136 SW_1_PIN, 136 SW_2_PIN, 136 SW_3_PIN, 136 daisy_field_init daisy_field.h, 138

DaisyPatch	IS25LP064A_DUMMY_CYCLES_READ_QUAD↔
daisy::DaisyPatch, 49	_DTR, 150
DaisyPetal	IS25LP064A_DUMMY_CYCLES_READ_QUAD,
daisy::DaisyPetal, 55	149
data	IS25LP064A_DUMMY_CYCLES_READ, 149
daisy::MidiEvent, 87	IS25LP064A_EAR_HIGHEST_SE, 150
dsy_sr_4021_handle, 80	IS25LP064A_EAR_LOWEST_SEG, 150
FontDef, 83	IS25LP064A_EAR_SECOND_SEG, 150
Debounce	IS25LP064A_EAR_THIRD_SEG, 150
daisy::Encoder, 81	IS25LP064A_EVCR_DTRP, 150
daisy::Switch, 112	IS25LP064A_EVCR_DUAL, 150
DebounceControls	IS25LP064A_EVCR_ODS, 150
daisy::DaisyPatch, 50	IS25LP064A_EVCR_QUAD, 151
daisy::DaisyPetal, 56	IS25LP064A_EVCR_RH, 151
daisy::DaisyPod, 63	IS25LP064A_FLASH_SIZE, 151
DelayMs	IS25LP064A_FSR_ERERR, 151
daisy::DaisyPatch, 50	IS25LP064A_FSR_ERSUS, 151
daisy::DaisyPetal, 57	IS25LP064A_FSR_NBADDR, 151
daisy::DaisyPod, 63	IS25LP064A_FSR_PGERR, 151
dev0_i2c	IS25LP064A_FSR_PGSUS, 151
dsy_audio_handle, 70	IS25LP064A_FSR_PRERR, 152
dev1_i2c	IS25LP064A_FSR_READY, 152
dsy_audio_handle, 70	IS25LP064A_NVCR_DTRP, 152
dev_codec_ak4556.h	IS25LP064A_NVCR_DUAL, 152
codec_ak4556_init, 141	IS25LP064A_NVCR_NB_DUMMY, 152
dev_codec_pcm3060.h	IS25LP064A_NVCR_NBADDR, 152
codec_pcm3060_init, 142	IS25LP064A_NVCR_ODS, 152
dev_codec_wm8731.h	IS25LP064A_NVCR_QUAB, 153
codec_wm8731_enter_bypass, 143	IS25LP064A_NVCR_RH, 153
codec_wm8731_exit_bypass, 143	IS25LP064A_NVCR_SEGMENT, 153
codec_wm8731_init, 143	IS25LP064A_NVCR_XIP, 153
dev_codec_wm8731_frame.h	IS25LP064A_PAGE_SIZE, 153
sa_audio_callback, 144	IS25LP064A_SECTOR_ERASE_MAX_TIME, 153
dev_flash_IS25LP064A.h	IS25LP064A_SECTOR_SIZE, 153
BLOCK_ERASE_32K_CMD, 147	IS25LP064A_SR_QE, 153
CLEAR_FLAG_STATUS_REG_CMD, 147	IS25LP064A_SR_SRWREN, 154
DIE_ERASE_CMD, 147	IS25LP064A_SR_WIP, 154
DUAL_IN_FAST_PROG_CMD, 147	IS25LP064A_SR_WREN, 154
DUAL_INOUT_FAST_READ_4_BYTE_ADDR_← CMD, 147	IS25LP064A_SUBSECTOR_ERASE_MAX_TIME, 154
DUAL_INOUT_FAST_READ_CMD, 147	IS25LP064A_SUBSECTOR_SIZE, 154
DUAL INOUT FAST READ DTR CMD, 147	IS25LP064A_VCR_NB_DUMMY, 154
DUAL_OUT_FAST_READ_4_BYTE_ADDR_C↔	IS25LP064A VCR WRAP, 154
MD, 148	IS25LP064A VCR XIP, 155
DUAL_OUT_FAST_READ_CMD, 148	IS25LP064A_H, 152
DUAL_OUT_FAST_READ_DTR_CMD, 148	MULTIPLE_IO_READ_ID_CMD, 155
ENTER_4_BYTE_ADDR_MODE_CMD, 148	PAGE_PROG_4_BYTE_ADDR_CMD, 155
ENTER_QUAD_CMD, 148	PAGE_PROG_CMD, 155
EXIT_4_BYTE_ADDR_MODE_CMD, 148	PROG_ERASE_RESUME_CMD, 155
EXIT_QUAD_CMD, 148	PROG_ERASE_SUSPEND_CMD, 155
EXT_DUAL_IN_FAST_PROG_CMD, 148	PROG_OTP_ARRAY_CMD, 155
EXT_QUAD_IN_FAST_PROG_CMD, 149	QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD,
FAST_READ_4_BYTE_ADDR_CMD, 149	155
FAST_READ_CMD, 149	QUAD_IN_FAST_PROG_CMD, 156
FAST_READ_DTR_CMD, 149	QUAD_INOUT_FAST_READ_4_BYTE_ADDR_
IS25LP064A_DIE_ERASE_MAX_TIME, 149	CMD, 156
IS25LP064A_DUMMY_CYCLES_READ_DTR,	QUAD_INOUT_FAST_READ_CMD, 156
149	QUAD_INOUT_FAST_READ_DTR_CMD, 156

QUAD_OUT_FAST_READ_4_BYTE_ADDR_C \leftarrow IS25LP080D_DUMMY_CYCLES_RE MD, 156	AD_DTR,
QUAD_OUT_FAST_READ_CMD, 156	AD QUAD⇔
QUAD_OUT_FAST_READ_DTR_CMD, 156DTR, 165	_
READ_4_BYTE_ADDR_CMD, 156 IS25LP080D_DUMMY_CYCLES_RE	AD_QUAD,
READ CMD, 157 165	
READ_ENHANCED_VOL_CFG_REG_CMD, 157 IS25LP080D_DUMMY_CYCLES_RE	AD, 165
READ_EXT_ADDR_REG_CMD, 157 IS25LP080D_EAR_HIGHEST_SE, 1	65
READ_FLAG_STATUS_REG_CMD, 157 IS25LP080D_EAR_LOWEST_SEG,	165
READ_ID_CMD2, 157 IS25LP080D_EAR_SECOND_SEG,	
READ_ID_CMD, 157 IS25LP080D_EAR_THIRD_SEG, 16	6
READ_LOCK_REG_CMD, 157 IS25LP080D_EVCR_DTRP, 166	
READ_NONVOL_CFG_REG_CMD, 157 IS25LP080D_EVCR_DUAL, 166	
READ_OTP_ARRAY_CMD, 158 IS25LP080D_EVCR_ODS, 166	
READ_READ_PARAM_REG_CMD, 158 IS25LP080D_EVCR_QUAD, 166	
READ_SERIAL_FLASH_DISCO_PARAM_CMD, IS25LP080D_EVCR_RH, 166	
158 IS25LP080D_FLASH_SIZE, 166	
READ_STATUS_REG_CMD, 158 IS25LP080D_FSR_ERERR, 167	
RESET_ENABLE_CMD, 158 IS25LP080D_FSR_ERSUS, 167	
RESET_MEMORY_CMD, 158 IS25LP080D_FSR_NBADDR, 167	
SECTOR_ERASE_4_BYTE_ADDR_CMD, 158 IS25LP080D_FSR_PGERR, 167	
SECTOR_ERASE_CMD, 158 IS25LP080D_FSR_PGSUS, 167	
SUBSECTOR_ERASE_4_BYTE_ADDR_CMD, IS25LP080D_FSR_PRERR, 167	
159 IS25LP080D_FSR_READY, 167	
SUBSECTOR_ERASE_CMD, 159 SUBSECTOR_ERASE_CMD, 159 SUBSECTOR_ERASE_CMD, 159 IS25LP080D_NVCR_DUAL, 168	
SUBSECTOR_ERASE_QPT_CIVID, 159	68
WRITE_DISABLE_CIVID, 159	00
WRITE_ENABLE_CMD, 159 IS25I P080D_NVCR_ODS_168	
WRITE_ENHANCED_VOL_CFG_REG_CMD, 159 IS25I P080D_NVCR_OLIAB_168	
WRITE_EXT_ADDR_REG_CMD, 159 IS25I P080D_NVCB_RH_168	
WRITE_LOCK_REG_CMD, 159	8
WRITE_NONVOL_CFG_REG_CMD, 160 IS25LP080D_NVCR_XIP_168	
WRITE_READ_PARAM_REG_CMD, 160 IS25I P080D_PAGE_SIZE_169	
WRITE_STATUS_REG_CMD, 160 IS25LP080D_SECTOR_EBASE_MA	X TIME, 169
dev_flash_IS25LP080D.h IS25LP080D SECTOR SIZE, 169	_
BLOCK_ERASE_32K_CMD, 162 IS25LP080D_SR_QE, 169	
CLEAR_FLAG_STATUS_REG_CMD, 162 IS25LP080D_SR_SRWREN, 169	
DIE_ERASE_CMD, 163 IS25LP080D_SR_WIP, 169	
DUAL_IN_FAST_PROG_CMD, 163 IS25LP080D_SR_WREN, 169	
DUAL_INOUT_FAST_READ_4_BYTE_ADDR_← IS25LP080D_SUBSECTOR_ERASE	_MAX_TIME,
CMD, 163	
DUAL_INOUT_FAST_READ_CMD, 163 DUAL_INOUT_FAST_READ_DTR_CMD, 163 IS25LP080D_SUBSECTOR_SIZE, 1	
DUAL CUT FACT DEAD 1 DIVITE ADDR 0	0
DUAL_OUT_FAST_READ_4_BYTE_ADDR_C MD, 163 IS25LP080D_VCR_WRAP, 170	
DUAL CUT FACT BEAD CARD 100	
DUAL_OUT_FAST_READ_CMD, 163 DUAL_OUT_FAST_READ_DTR_CMD, 163 MULTIPLE_IO_READ_ID_CMD, 170 PAGE_PROG_4_RYTE_ADDR_CMI	
TAGE_THOG_T_BTTE_ABBIT_OMI	D, 170
7.7d2_1.1d4_0m2, 170	
	7.1
	ADDD CMD
	NDDK_CMD,
EXT_QUAD_IN_FAST_PROG_CMD, 164 171 FAST_READ_4_BYTE_ADDR_CMD, 164 QUAD_IN_FAST_PROG_CMD, 171	
I AOI NEAD 4 DITE ADDIT OND, 104 QUAD IN FAST PROG (MID. 1/1	
	LE VUUD
FAST_READ_CMD, 164 QUAD_INOUT_FAST_READ_4_BYT	ΓE_ADDR_←

	QUAD_INOUT_FAST_READ_DTR_CMD, 171	device
	QUAD_OUT_FAST_READ_4_BYTE_ADDR_C← MD, 172	dsy_qspi_handle, 74 dsy_sai_handle, 76
	QUAD_OUT_FAST_READ_CMD, 172	display
	QUAD OUT FAST READ DTR CMD, 172	daisy::DaisyPatch, 52
	READ_4_BYTE_ADDR_CMD, 172	DisplayControls
	READ CMD, 172	daisy::DaisyPatch, 50
	READ_ENHANCED_VOL_CFG_REG_CMD, 172	DrawPixel
	READ_EXT_ADDR_REG_CMD, 172	daisy::OledDisplay, 92
	READ_FLAG_STATUS_REG_CMD, 172	dsy_audio_bitdepth
	READ_ID_CMD2, 173	per_sai.h, 218
	READ_ID_CMD, 173	dsy_audio_device
	READ_LOCK_REG_CMD, 173	per_sai.h, 218
	READ_NONVOL_CFG_REG_CMD, 173	dsy_audio_dir
	READ_OTP_ARRAY_CMD, 173	per_sai.h, 218
	READ_READ_PARAM_REG_CMD, 173	dsy_audio_enter_bypass
	READ_SERIAL_FLASH_DISCO_PARAM_CMD,	hid_audio.h, 197
	173	dsy_audio_exit_bypass
	READ_STATUS_REG_CMD, 173	hid_audio.h, 197
	RESET_ENABLE_CMD, 174	dsy_audio_handle, 69
	RESET_MEMORY_CMD, 174	block_size, 70
	SECTOR_ERASE_4_BYTE_ADDR_CMD, 174	dev0_i2c, 70
	SECTOR_ERASE_CMD, 174	dev1_i2c, 70
	SUBSECTOR_ERASE_4_BYTE_ADDR_CMD,	sai, 70
	SUBSECTOR_ERASE_CMD, 174	dsy_audio_init hid_audio.h, 197
	SUBSECTOR_ERASE_CMD, 174 SUBSECTOR ERASE QPI CMD, 174	dsy_audio_mc_callback
	WRITE_DISABLE_CMD, 174	hid_audio.h, 196
	WRITE_ENABLE_CMD, 175	dsy_audio_passthru
	WRITE_ENHANCED_VOL_CFG_REG_CMD, 175	hid_audio.h, 197
	WRITE_EXT_ADDR_REG_CMD, 175	dsy_audio_sai
	WRITE_LOCK_REG_CMD, 175	per_sai.h, 219
	WRITE_NONVOL_CFG_REG_CMD, 175	dsy_audio_samplerate
	WRITE READ PARAM REG CMD, 175	per_sai.h, 219
	WRITE_STATUS_REG_CMD, 175	dsy_audio_set_blocksize
dev_	_leddriver.h	hid_audio.h, 197
	DSY_LED_DRIVER_MAX_DRIVERS, 176	dsy_audio_set_callback
	dsy_led_driver_color_by_name, 177	hid_audio.h, 197
	dsy_led_driver_init, 177	dsy_audio_set_mc_callback
	dsy_led_driver_set_led, 178	hid_audio.h, 198
	dsy_led_driver_update, 178	dsy_audio_silence
	SA_LED_DRIVER_H, 176	hid_audio.h, 198
dev_	_sdram.h	dsy_audio_start
	DSY_SDRAM_BSS, 179	hid_audio.h, 198
	DSY_SDRAM_DATA, 179	dsy_audio_stop
	dsy_sdram_init, 180	hid_audio.h, 198
	dsy_sdram_pin, 180	dsy_audio_sync
	dsy_sdram_state, 180	per_sai.h, 219
	RAM_AS4C16M16SA_H, 179	dsy_dac_bitdepth
dev_	_sr_4021.h	per_dac.h, 204
	DEV_SR_4021_H, 181	dsy_dac_channel
	dsy_sr_4021_init, 182	per_dac.h, 205
	dsy_sr_4021_state, 184	dsy_dac_handle, 70
	dsy_sr_4021_update, 184	bitdepth, 71
	SR_4021_MAX_DAISYCHAIN, 182 SR_4021_MAX_PARALLEL, 182	mode, 71
dov	sr_4021_MAX_PARALLEL, 162 sr_595.h	pin_config, 71 dsy_dac_init
uev_	si_595.fi kMaxSr595DaisyChain, 185	per_dac.h, 205
	Minarologopaloy Orlani, 100	poi_uao.ii, 200

dsy_dac_mode	dev_leddriver.h, 178
per_dac.h, 205	dsy_led_driver_update
dsy_dac_start	dev_leddriver.h, 178
per_dac.h, 206	dsy_pin
dsy_dac_write	daisy_core.h, 132
per_dac.h, 206	dsy_pin_cmp
dsy_dma_init	daisy_core.h, 132
sys_dma.h, 228	dsy_qspi_deinit
dsy_fatfs_init	per_qspi.h, 214
fatfs.h, 186	dsy_qspi_device
dsy_get_unique_id	per_qspi.h, 213
util_unique_id.h, 241	dsy_qspi_erase
dsy_gpio, 71	per_qspi.h, 215
mode, 72	dsy_qspi_erasesector
pin, 72 pull, 72	per_qspi.h, 215 dsy_qspi_handle, 74
dsy_gpio_deinit	device, 74
per_gpio.h, 208	mode, 74
dsy_gpio_init	pin_config, 74
per_gpio.h, 208	dsy_qspi_init
dsy_gpio_mode	per_qspi.h, 215
per_gpio.h, 207	dsy_qspi_mode
dsy_gpio_pin, 72	per_qspi.h, 214
pin, 72	dsy_qspi_pin
port, 73	per_qspi.h, 214
dsy_gpio_port	dsy_qspi_write
daisy_core.h, 131	per_qspi.h, 216
dsy_gpio_pull	dsy_qspi_writepage
per_gpio.h, 207	per_qspi.h, 216
dsy_gpio_read	dsy_sai_handle, 75
per_gpio.h, 208	a_direction, 75
dsy_gpio_toggle	b_direction, 75
per_gpio.h, 209	bitdepth, 75
dsy_gpio_write	device, 76
per_gpio.h, 209	init, 76
dsy_hal_map_get_i2c	sai1_pin_config, 76
util_hal_map.h, 239	sai2_pin_config, 76
dsy_hal_map_get_pin	samplerate, 76
util_hal_map.h, 240	sync_config, 76
dsy_hal_map_get_port	dsy_sai_init
util_hal_map.h, 240	per_sai.h, 220
dsy_i2c_handle, 73	dsy_sai_init_from_handle
periph, 73	per_sai.h, 220
pin_config, 73	dsy_sai_pin
speed, 73	per_sai.h, 219
dsy_i2c_init	dsy_sdram_handle, 78
per_i2c.h, 211	pin_config, 79
dsy_i2c_periph	state, 79
per_i2c.h, 210	dsy_sdram_init
dsy_i2c_pin	dev_sdram.h, 180
per_i2c.h, 210	dsy_sdram_pin
dsy_i2c_speed	dev_sdram.h, 180
per_i2c.h, 211	dsy_sdram_state
dsy_led_driver_color_by_name	dev_sdram.h, 180
dev_leddriver.h, 177	dsy_sr_4021_handle, 79
dsy_led_driver_init	clk, 80
dev_leddriver.h, 177	cs, 80
dsy_led_driver_set_led	data, 80

num daisychained, 80	expression
num_parallel, 80	daisy::DaisyPetal, 59
pin config, 80	daisyDaisyr ctai, 50
states, 80	F2S16_SCALE
dsy_sr_4021_init	daisy.h, 128
dev_sr_4021.h, 182	F2S24_SCALE
dsy_sr_4021_state	daisy.h, 128
dev_sr_4021.h, 184	f2s16
dsy_sr_4021_update	daisy.h, 129
dev sr 4021.h, 184	f2s24
dsy_system_delay	daisy.h, 129
sys_system.h, 228	FAST_READ_4_BYTE_ADDR_CMD
dsy_system_getnow	dev_flash_IS25LP064A.h, 149
sys_system.h, 229	dev_flash_IS25LP080D.h, 164
dsy_system_init	FAST_READ_CMD
sys system.h, 229	dev_flash_IS25LP064A.h, 149
dsy_system_jumpto	dev_flash_IS25LP080D.h, 164
sys_system.h, 229	FAST_READ_DTR_CMD
dsy_system_jumptoqspi	dev_flash_IS25LP064A.h, 149
sys_system.h, 229	dev_flash_IS25LP080D.h, 165
dsy_tim_delay_ms	FBIPMAX
per_tim.h, 225	daisy.h, 128
dsy_tim_delay_tick	FBIPMIN
per tim.h, 225	daisy.h, 128
dsy_tim_delay_us	FS_Desc
per_tim.h, 225	USBD_DESC_Exported_Variables, 28
dsy_tim_get_ms	FallingEdge
per_tim.h, 226	daisy::Encoder, 82
dsy_tim_get_tick	daisy::Switch, 112
per_tim.h, 226	fatfs.h
dsy_tim_get_us	fatfs_H, 185
per_tim.h, 226	dsy_fatfs_init, 186
dsy_tim_init	retSD, 186
per tim.h, 226	SDFatFS, 186
dsy_tim_start	SDFile, 186
per_tim.h, 227	SDPath, 186
, –	ff_free
ENTER_4_BYTE_ADDR_MODE_CMD	ffconf.h, 194
dev_flash_IS25LP064A.h, 148	ff_malloc
dev_flash_IS25LP080D.h, 164	ffconf.h, 194
ENTER_QUAD_CMD	ffconf.h
dev_flash_IS25LP064A.h, 148	_CODE_PAGE, 188
dev_flash_IS25LP080D.h, 164	_FFCONF, 188
EXIT_4_BYTE_ADDR_MODE_CMD	_FS_EXFAT, 188
dev_flash_IS25LP064A.h, 148	_FS_LOCK, 188
dev_flash_IS25LP080D.h, 164	_FS_MINIMIZE, 188
EXIT_QUAD_CMD	_FS_NOFSINFO, 189
dev_flash_IS25LP064A.h, 148	_FS_NORTC, 189
dev_flash_IS25LP080D.h, 164	_FS_READONLY, 189
EXT_DUAL_IN_FAST_PROG_CMD	_FS_REENTRANT, 189
dev_flash_IS25LP064A.h, 148	_FS_RPATH, 189
dev_flash_IS25LP080D.h, 164	_FS_TIMEOUT, 189
EXT_QUAD_IN_FAST_PROG_CMD	_FS_TINY, 190
dev_flash_IS25LP064A.h, 149	_LFN_UNICODE, 190
dev_flash_IS25LP080D.h, 164	_MAX_LFN, 190
encoder	_MAX_SS, 190
daisy::DaisyPatch, 52	_MIN_SS, 190
daisy::DaisyPetal, 59	_MULTI_PARTITION, 190
daisy::DaisyPod, 65	_NORTC_MDAY, 191

_NORTC_MON, 191	Get
_NORTC_YEAR, 191	daisy::AdcHandle, 36
_STRF_ENCODE, 191	GetCtrlValue
_STR_VOLUME_ID, 191	daisy::DaisyPatch, 51
_SYNC_t, 191	GetCurrentFile
_USE_CHMOD, 192	daisy::WavPlayer, 124
_USE_EXPAND, 192	GetExpression
_USE_FASTSEEK, 192	daisy::DaisyPetal, 57
_USE_FIND, 192	GetFloat
_USE_FORWARD, 192	daisy::AdcHandle, 37
_USE_LABEL, 192	GetKnobValue
_USE_LFN, 193	daisy::DaisyPetal, 57
_USE_MKFS, 193	daisy::DaisyPod, 63
_USE_STRFUNC, 193	GetLooping
USE TRIM, 193	daisy::WavPlayer, 124
VOLUMES, 193	GetMux
_VOLUME_STRS, 193	daisy::AdcHandle, 37
ff free, 194	GetMuxFloat
ff malloc, 194	daisy::AdcHandle, 37
FileFormat	GetMuxPtr
WAV_FormatTypeDef, 121	daisy::AdcHandle, 38
FileSize	GetNumberFiles
WAV_FormatTypeDef, 121	daisy::WavPlayer, 124
Fill	GetPin
daisy::OledDisplay, 94	daisy::DaisySeed, 67
Flush	GetPtr
daisy::RingBuffer, 100	daisy::AdcHandle, 38
daisy::RingBuffer< T, 0 >, 104	Green
FlushRx	daisy::Color, 44
Tidom ix	
daisy::UartHandler, 115	areen
daisy::UartHandler, 115 FontDef, 83	green color, 43
FontDef, 83	green color, 43
FontDef, 83 data, 83	•
FontDef, 83 data, 83 FontHeight, 83	color, 43
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83	color, 43 HS_Desc
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontHeight	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontHeight FontDef, 83	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontDef, 83 FontWidth	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontDef, 83 FontWidth FontDef, 83	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontDef, 83 FontWidth FontDef, 83 footswitch_led	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54 GATE_IN_PIN	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4 util_hal_map.h, 241
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54 GATE_IN_PIN daisy_field.h, 134	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4 util_hal_map.h, 241 hid_audio.h
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontWidth, 83 FontWidth FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54 GATE_IN_PIN daisy_field.h, 134 GATE_OUT_PIN daisy_field.h, 134	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4 util_hal_map.h, 241 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 195
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54 GATE_IN_PIN daisy_field.h, 134 GATE_OUT_PIN	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4 util_hal_map.h, 241 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 195 DSY_AUDIO_CHANNELS_MAX, 195
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontWidth, 83 FontWidth FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54 GATE_IN_PIN daisy_field.h, 134 GATE_OUT_PIN daisy_field.h, 134 gate_in	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4 util_hal_map.h, 241 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 195 DSY_AUDIO_CHANNELS_MAX, 195 DSY_AUDIO_SAMPLE_RATE, 195
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54 GATE_IN_PIN daisy_field.h, 134 GATE_OUT_PIN daisy_field.h, 134 gate_in daisy::daisy_field, 47 gate_input	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4 util_hal_map.h, 241 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 195 DSY_AUDIO_CHANNELS_MAX, 195 DSY_AUDIO_SAMPLE_RATE, 195 DSY_AUDIO_H, 195 dsy_audio_enter_bypass, 197
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontWidth, 83 FontWidth FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54 GATE_IN_PIN daisy_field.h, 134 GATE_OUT_PIN daisy_field.h, 134 gate_in daisy::daisy_field, 47 gate_input daisy::DaisyPatch, 52	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4 util_hal_map.h, 241 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 195 DSY_AUDIO_CHANNELS_MAX, 195 DSY_AUDIO_SAMPLE_RATE, 195 DSY_AUDIO_H, 195 dsy_audio_enter_bypass, 197 dsy_audio_exit_bypass, 197
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontWidth, 83 FontWidth FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54 GATE_IN_PIN daisy_field.h, 134 GATE_OUT_PIN daisy_field.h, 134 gate_in daisy::daisy_field, 47 gate_input daisy::DaisyPatch, 52 gate_out	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4 util_hal_map.h, 241 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 195 DSY_AUDIO_CHANNELS_MAX, 195 DSY_AUDIO_SAMPLE_RATE, 195 DSY_AUDIO_H, 195 dsy_audio_enter_bypass, 197 dsy_audio_init, 197
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontWidth FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54 GATE_IN_PIN daisy_field.h, 134 GATE_OUT_PIN daisy_field.h, 134 gate_in daisy::DaisyPatch, 52 gate_out daisy::daisy_field, 47	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4 util_hal_map.h, 241 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 195 DSY_AUDIO_CHANNELS_MAX, 195 DSY_AUDIO_SAMPLE_RATE, 195 DSY_AUDIO_H, 195 dsy_audio_exit_bypass, 197 dsy_audio_init, 197 dsy_audio_mc_callback, 196
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontWidth, 83 FontWidth FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54 GATE_IN_PIN daisy_field.h, 134 GATE_OUT_PIN daisy_field.h, 134 gate_in daisy::daisy_field, 47 gate_input daisy::DaisyPatch, 52 gate_out	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4 util_hal_map.h, 241 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 195 DSY_AUDIO_CHANNELS_MAX, 195 DSY_AUDIO_SAMPLE_RATE, 195 DSY_AUDIO_H, 195 dsy_audio_enter_bypass, 197 dsy_audio_init, 197 dsy_audio_passthru, 197
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontWidth FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54 GATE_IN_PIN daisy_field.h, 134 GATE_OUT_PIN daisy_field.h, 134 gate_in daisy::DaisyPatch, 52 gate_out daisy::daisy_field, 47 gate_output	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4 util_hal_map.h, 241 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 195 DSY_AUDIO_CHANNELS_MAX, 195 DSY_AUDIO_SAMPLE_RATE, 195 DSY_AUDIO_H, 195 dsy_audio_exit_bypass, 197 dsy_audio_init, 197 dsy_audio_mc_callback, 196
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontWidth FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54 GATE_IN_PIN daisy_field.h, 134 GATE_OUT_PIN daisy_field.h, 134 gate_in daisy::daisy_field, 47 gate_input daisy::DaisyPatch, 52 gate_out daisy::daisy_field, 47 gate_output daisy::DaisyPatch, 52	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4 util_hal_map.h, 241 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 195 DSY_AUDIO_CHANNELS_MAX, 195 DSY_AUDIO_SAMPLE_RATE, 195 DSY_AUDIO_H, 195 dsy_audio_enter_bypass, 197 dsy_audio_exit_bypass, 197 dsy_audio_mc_callback, 196 dsy_audio_set_blocksize, 197 dsy_audio_set_callback, 197
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontWidth FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54 GATE_IN_PIN daisy_field.h, 134 GATE_OUT_PIN daisy_field.h, 134 gate_in daisy::daisy_field, 47 gate_input daisy::DaisyPatch, 52 gate_out daisy::DaisyPatch, 52 GateIn	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4 util_hal_map.h, 241 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 195 DSY_AUDIO_CHANNELS_MAX, 195 DSY_AUDIO_SAMPLE_RATE, 195 DSY_AUDIO_H, 195 dsy_audio_enter_bypass, 197 dsy_audio_exit_bypass, 197 dsy_audio_passthru, 197 dsy_audio_set_blocksize, 197 dsy_audio_set_callback, 196 dsy_audio_set_callback, 197 dsy_audio_set_mc_callback, 197 dsy_audio_set_mc_callback, 198
FontDef, 83 data, 83 FontHeight, 83 FontWidth, 83 FontWidth FontDef, 83 FontWidth FontDef, 83 footswitch_led daisy::DaisyPetal, 59 FootswitchLed daisy::DaisyPetal, 54 GATE_IN_PIN daisy_field.h, 134 GATE_OUT_PIN daisy_field.h, 134 gate_in daisy::daisy_field, 47 gate_input daisy::DaisyPatch, 52 gate_out daisy::DaisyPatch, 52 GateIn daisy::GateIn, 84	color, 43 HS_Desc USBD_DESC_Exported_Variables, 28 HasEvents daisy::MidiHandler, 89 hi2c1 util_hal_map.h, 240 hi2c2 util_hal_map.h, 240 hi2c3 util_hal_map.h, 241 hi2c4 util_hal_map.h, 241 hid_audio.h DSY_AUDIO_BLOCK_SIZE_MAX, 195 DSY_AUDIO_CHANNELS_MAX, 195 DSY_AUDIO_SAMPLE_RATE, 195 DSY_AUDIO_H, 195 dsy_audio_enter_bypass, 197 dsy_audio_exit_bypass, 197 dsy_audio_mc_callback, 196 dsy_audio_set_blocksize, 197 dsy_audio_set_callback, 197

dsy_audio_stop, 198	IS25LP064A_NVCR_DTRP
hid_midi.h	dev_flash_IS25LP064A.h, 152
MidiMessageType, 200	IS25LP064A_NVCR_DUAL
hid_oled_display.h	dev_flash_IS25LP064A.h, 152
DSY_OLED_DISPLAY_H, 201	IS25LP064A_NVCR_NB_DUMMY
SSD1309 HEIGHT, 201	dev_flash_IS25LP064A.h, 152
SSD1309_WIDTH, 201	IS25LP064A_NVCR_NBADDR
hid_wavplayer.h	dev flash IS25LP064A.h, 152
DSY_WAVPLAYER_H, 203	IS25LP064A NVCR ODS
WAV_FILENAME_MAX, 203	dev flash IS25LP064A.h, 152
	IS25LP064A_NVCR_QUAB
i2c1_handle	dev_flash_IS25LP064A.h, 153
daisy::DaisySeed, 68	IS25LP064A_NVCR_RH
i2c2_handle	
daisy::DaisySeed, 68	dev_flash_IS25LP064A.h, 153
IS25LP064A_DIE_ERASE_MAX_TIME	IS25LP064A_NVCR_SEGMENT
dev flash IS25LP064A.h, 149	dev_flash_IS25LP064A.h, 153
IS25LP064A_DUMMY_CYCLES_READ_DTR	IS25LP064A_NVCR_XIP
dev_flash_IS25LP064A.h, 149	dev_flash_IS25LP064A.h, 153
IS25LP064A_DUMMY_CYCLES_READ_QUAD_DTR	IS25LP064A_PAGE_SIZE
dev flash IS25LP064A.h, 150	dev_flash_IS25LP064A.h, 153
IS25LP064A_DUMMY_CYCLES_READ_QUAD	IS25LP064A_SECTOR_ERASE_MAX_TIME
dev flash IS25LP064A.h, 149	dev_flash_IS25LP064A.h, 153
IS25LP064A DUMMY CYCLES READ	IS25LP064A_SECTOR_SIZE
dev flash IS25LP064A.h, 149	dev_flash_IS25LP064A.h, 153
IS25LP064A_EAR_HIGHEST_SE	IS25LP064A_SR_QE
dev_flash_IS25LP064A.h, 150	dev_flash_IS25LP064A.h, 153
IS25LP064A_EAR_LOWEST_SEG	IS25LP064A_SR_SRWREN
	dev_flash_IS25LP064A.h, 154
dev_flash_IS25LP064A.h, 150	IS25LP064A_SR_WIP
IS25LP064A_EAR_SECOND_SEG	dev_flash_IS25LP064A.h, 154
dev_flash_IS25LP064A.h, 150	IS25LP064A_SR_WREN
IS25LP064A_EAR_THIRD_SEG	dev_flash_IS25LP064A.h, 154
dev_flash_IS25LP064A.h, 150	IS25LP064A_SUBSECTOR_ERASE_MAX_TIME
IS25LP064A_EVCR_DTRP	dev_flash_IS25LP064A.h, 154
dev_flash_IS25LP064A.h, 150	IS25LP064A_SUBSECTOR_SIZE
IS25LP064A_EVCR_DUAL	dev flash IS25LP064A.h, 154
dev_flash_IS25LP064A.h, 150	
IS25LP064A_EVCR_ODS	IS25LP064A_VCR_NB_DUMMY
dev_flash_IS25LP064A.h, 150	dev_flash_IS25LP064A.h, 154 IS25LP064A VCR WRAP
IS25LP064A_EVCR_QUAD	
dev_flash_IS25LP064A.h, 151	dev_flash_IS25LP064A.h, 154
IS25LP064A_EVCR_RH	IS25LP064A_VCR_XIP
dev_flash_IS25LP064A.h, 151	dev_flash_IS25LP064A.h, 155
IS25LP064A_FLASH_SIZE	IS25LP064A_H
dev_flash_IS25LP064A.h, 151	dev_flash_IS25LP064A.h, 152
IS25LP064A_FSR_ERERR	IS25LP080D_DIE_ERASE_MAX_TIME
dev_flash_IS25LP064A.h, 151	dev_flash_IS25LP080D.h, 165
IS25LP064A_FSR_ERSUS	IS25LP080D_DUMMY_CYCLES_READ_DTR
dev_flash_IS25LP064A.h, 151	dev_flash_IS25LP080D.h, 165
IS25LP064A_FSR_NBADDR	IS25LP080D_DUMMY_CYCLES_READ_QUAD_DTR
dev_flash_IS25LP064A.h, 151	dev_flash_IS25LP080D.h, 165
IS25LP064A_FSR_PGERR	IS25LP080D_DUMMY_CYCLES_READ_QUAD
dev_flash_IS25LP064A.h, 151	dev_flash_IS25LP080D.h, 165
IS25LP064A_FSR_PGSUS	IS25LP080D_DUMMY_CYCLES_READ
dev_flash_IS25LP064A.h, 151	dev_flash_IS25LP080D.h, 165
IS25LP064A_FSR_PRERR	IS25LP080D_EAR_HIGHEST_SE
dev_flash_IS25LP064A.h, 152	dev_flash_IS25LP080D.h, 165
IS25LP064A_FSR_READY	IS25LP080D_EAR_LOWEST_SEG
dev_flash_IS25LP064A.h, 152	dev_flash_IS25LP080D.h, 165
GOV_HOSH_HOZOLI OUTA.H, TOE	00V_110311_1020E1 000D.11, 100

IS25LP080D_EAR_SECOND_SEG	IS25LP080D_SR_WIP
dev_flash_IS25LP080D.h, 166	dev_flash_IS25LP080D.h, 169
IS25LP080D_EAR_THIRD_SEG	IS25LP080D_SR_WREN
dev_flash_IS25LP080D.h, 166	dev_flash_IS25LP080D.h, 169
IS25LP080D_EVCR_DTRP	IS25LP080D_SUBSECTOR_ERASE_MAX_TIME
dev_flash_IS25LP080D.h, 166	dev_flash_IS25LP080D.h, 170
IS25LP080D_EVCR_DUAL	IS25LP080D_SUBSECTOR_SIZE
dev_flash_IS25LP080D.h, 166	dev_flash_IS25LP080D.h, 170
IS25LP080D_EVCR_ODS	IS25LP080D_VCR_NB_DUMMY
dev_flash_IS25LP080D.h, 166	dev_flash_IS25LP080D.h, 170
IS25LP080D_EVCR_QUAD	IS25LP080D_VCR_WRAP
dev_flash_IS25LP080D.h, 166	dev_flash_IS25LP080D.h, 170
IS25LP080D_EVCR_RH	IS25LP080D_VCR_XIP
dev_flash_IS25LP080D.h, 166	dev_flash_IS25LP080D.h, 170
IS25LP080D_FLASH_SIZE	ImmediateRead
dev_flash_IS25LP080D.h, 166	daisy::RingBuffer, 100, 101
IS25LP080D FSR ERERR	daisy::RingBuffer $<$ T, 0 $>$, 104
dev_flash_IS25LP080D.h, 167	Increment
IS25LP080D_FSR_ERSUS	daisy::Encoder, 82
dev_flash_IS25LP080D.h, 167	Init
IS25LP080D FSR NBADDR	daisy::AdcHandle, 38
dev_flash_IS25LP080D.h, 167	daisy::AnalogControl, 40
IS25LP080D FSR PGERR	daisy::Color, 44, 45
dev_flash_IS25LP080D.h, 167	daisy::DaisyPatch, 51
IS25LP080D_FSR_PGSUS	daisy::DaisyPetal, 57
dev_flash_IS25LP080D.h, 167	daisy::DaisyPod, 63
	daisy::DaisySeed, 67
IS25LP080D_FSR_PRERR	daisy::Encoder, 82
dev_flash_IS25LP080D.h, 167	daisy::GateIn, 84
IS25LP080D_FSR_READY	daisy::Led, 85
dev_flash_IS25LP080D.h, 167	daisy::MidiHandler, 89
IS25LP080D_NVCR_DTRP	daisy::OledDisplay, 94
dev_flash_IS25LP080D.h, 167	daisy::Parameter, 97
IS25LP080D_NVCR_DUAL	daisy::RgbLed, 98
dev_flash_IS25LP080D.h, 168	daisy::RingBuffer, 101
IS25LP080D_NVCR_NB_DUMMY	daisy::RingBuffer< T, 0 >, 105
dev_flash_IS25LP080D.h, 168	daisy::SdmmcHandler, 107
IS25LP080D_NVCR_NBADDR	daisy::SpiHandle, 110
dev_flash_IS25LP080D.h, 168	daisy::Switch, 112, 113
IS25LP080D_NVCR_ODS	daisy::UartHandler, 115
dev_flash_IS25LP080D.h, 168	daisy::UsbHandle, 118
IS25LP080D_NVCR_QUAB	daisy::WavPlayer, 124
dev_flash_IS25LP080D.h, 168	ShiftRegister595, 109
IS25LP080D_NVCR_RH	init
dev_flash_IS25LP080D.h, 168	dsy_sai_handle, 76
IS25LP080D_NVCR_SEGMENT	InitBipolarCv
dev_flash_IS25LP080D.h, 168	daisy::AnalogControl, 41
IS25LP080D_NVCR_XIP	InitMux
dev_flash_IS25LP080D.h, 168	daisy::AdcChannelConfig, 34
IS25LP080D_PAGE_SIZE	InitSingle
dev_flash_IS25LP080D.h, 169	daisy::AdcChannelConfig, 34
IS25LP080D_SECTOR_ERASE_MAX_TIME	dately tage that more of mig, or
dev_flash_IS25LP080D.h, 169	KB_SW_SR_CLK_PIN
IS25LP080D_SECTOR_SIZE	daisy_field.h, 135
dev_flash_IS25LP080D.h, 169	KB_SW_SR_CS_PIN
IS25LP080D_SR_QE	daisy_field.h, 135
dev_flash_IS25LP080D.h, 169	KB_SW_SR_D1_PIN
IS25LP080D_SR_SRWREN	daisy_field.h, 135
dev_flash_IS25LP080D.h, 169	KB_SW_SR_D2_PIN

daisy_field.h, 135	daisy::MidiHandler, 88
kMaxSr595DaisyChain	MidiMessageType
dev_sr_595.h, 185	hid_midi.h, 200
kUartMaxBufferSize	MidiOutputMode
per_uart.h, 227	daisy::MidiHandler, 89
keyboard_sr	mode
daisy::daisy_field, 47	dsy_dac_handle, 71
Knob	dsy_gpio, 72
daisy::DaisyPetal, 54	dsy_qspi_handle, 74
daisy::DaisyPod, 61	mux_channels_
knob	daisy::AdcChannelConfig, 35
daisy::DaisyPetal, 60	mux_pin_
knob1	daisy::AdcChannelConfig, 35
daisy::DaisyPod, 65	MuxPin
knob2	daisy::AdcChannelConfig, 33
daisy::DaisyPod, 65	dately in the entire in the en
	name
knobs	daisy::WavFileInfo, 122
daisy::DaisyPod, 65	
daisy::daisy_field, 47	NbrChannels
	WAV_FormatTypeDef, 121
	note
codec_frame_t, 42	daisy::NoteOnEvent, 91
LED DRIVER I2C	num daisychained
daisy field.h, 135	dsy_sr_4021_handle, 80
led1	num_parallel
daisy::DaisyPod, 65	
	dsy_sr_4021_handle, 80
led2	0.00
daisy::DaisyPod, 65	Open
Listen	daisy::WavPlayer, 124
daisy::MidiHandler, 90	OverSampling
LogBlockNbr	daisy::AdcHandle, 36
DSY_SD_CardInfoTypeDef, 78	Overwrite
LogBlockSize	daisy::RingBuffer, 101, 102
DSY SD CardInfoTypeDef, 78	daisy::RingBuffer< T, 0 >, 105
201_02_0didiiii01yp0201,70	auto, g_a c , c > ,
MIDI IN PIN	PAGE_PROG_4_BYTE_ADDR_CMD
	dev_flash_IS25LP064A.h, 155
daisy_field.h, 135	
MIDI_OUT_PIN	dev_flash_IS25LP080D.h, 170
daisy_field.h, 135	PAGE_PROG_CMD
MSD_ERROR_SD_NOT_PRESENT	dev_flash_IS25LP064A.h, 155
util_bsp_sd_diskio.h, 234	dev_flash_IS25LP080D.h, 170
MSD_ERROR	PROG_ERASE_RESUME_CMD
util_bsp_sd_diskio.h, 233	dev flash IS25LP064A.h, 155
MSD_OK	dev flash IS25LP080D.h, 171
util_bsp_sd_diskio.h, 234	PROG_ERASE_SUSPEND_CMD
_ •	dev_flash_IS25LP064A.h, 155
MULTIPLE_IO_READ_ID_CMD	
dev_flash_IS25LP064A.h, 155	dev_flash_IS25LP080D.h, 171
dev_flash_IS25LP080D.h, 170	PROG_OTP_ARRAY_CMD
MUX_ADC_PIN	dev_flash_IS25LP064A.h, 155
daisy_field.h, 135	dev_flash_IS25LP080D.h, 171
MUX_SEL_0_PIN	Parameter
daisy_field.h, 136	daisy::Parameter, 97
MUX_SEL_1_PIN	Parse
daisy_field.h, 136	daisy::MidiHandler, 90
MUX_SEL_2_PIN	per_adc.h
daisy_field.h, 136	DSY_ADC_MAX_CHANNELS, 204
midi	DSY_ADC_H, 204
daisy::DaisyPatch, 52	per_dac.h
MidiInputMode	dsy_dac_bitdepth, 204

dsy_dac_channel, 205	dsy_tim_delay_us, 225
dsy_dac_init, 205	dsy_tim_get_ms, 226
dsy_dac_mode, 205	dsy_tim_get_tick, 226
dsy_dac_start, 206	dsy_tim_get_us, 226
dsy dac write, 206	dsy_tim_init, 226
per_gpio.h	dsy_tim_start, 227
dsy_gpio_deinit, 208	per_uart.h
dsy_gpio_init, 208	DSY UART H, 227
dsy_gpio_mode, 207	kUartMaxBufferSize, 227
dsy_gpio_pull, 207	periph
dsy_gpio_read, 208	dsy_i2c_handle, 73
· — · · —	pin
dsy_gpio_toggle, 209	dsy_gpio, 72
dsy_gpio_write, 209	dsy_gpio_pin, 72
per_i2c.h	pin_
DSY_I2C_H, 210	• —
dsy_i2c_init, 211	daisy::AdcChannelConfig, 35
dsy_i2c_periph, 210	pin_config
dsy_i2c_pin, 210	dsy_dac_handle, 71
dsy_i2c_speed, 211	dsy_i2c_handle, 73
per_qspi.h	dsy_qspi_handle, 74
DSY_MEMORY_ERROR, 212	dsy_sdram_handle, 79
DSY_MEMORY_OK, 212	dsy_sr_4021_handle, 80
DSY_QSPI_BSS, 213	Pins
DSY_QSPI_DATA, 213	daisy::OledDisplay, 92
DSY_QSPI_TEXT, 213	ShiftRegister595, 108
DSY_QSPI, 213	Polarity
dsy_qspi_deinit, 214	daisy::Switch, 111
dsy_qspi_device, 213	PollReceive
dsy_qspi_erase, 215	daisy::UartHandler, 115
dsy_qspi_erasesector, 215	PollTx
dsy_qspi_init, 215	daisy::UartHandler, 116
dsy_qspi_mode, 214	PopEvent
dsy_qspi_niode, 214	daisy::MidiHandler, 90
	PopRx
dsy_qspi_write, 216	daisy::UartHandler, 116
dsy_qspi_writepage, 216	port
per_sai.h	dsy_gpio_pin, 73
dsy_audio_bitdepth, 218	Prepare
dsy_audio_device, 218	daisy::WavPlayer, 125
dsy_audio_dir, 218	PresetColor
dsy_audio_sai, 219	daisy::Color, 44
dsy_audio_samplerate, 219	Pressed
dsy_audio_sync, 219	daisy::Encoder, 82
dsy_sai_init, <mark>220</mark>	daisy::Switch, 113
dsy_sai_init_from_handle, 220	Process
dsy_sai_pin, 219	daisy::AnalogControl, 41
per_sdmmc.h	daisy::Parameter, 97
DSY_SD_ERROR, 222	Pull
DSY_SD_OK, 222	
DSY_SDMMC_H, 222	daisy::Switch, 111
SdmmcBitWidth, 223	pull
SdmmcMode, 223	dsy_gpio, 72
SdmmcSpeed, 223	QUAD_IN_FAST_PROG_4_BYTE_ADDR_CMD
per_spi.h	dev_flash_IS25LP064A.h, 155
SpiPeriph, 224	dev_flash_IS25LP080D.h, 171
SpiPin, 224	QUAD_IN_FAST_PROG_CMD
per_tim.h	dev_flash_IS25LP064A.h, 156
• —	
dsy_tim_delay_ms, 225	dev_flash_IS25LP080D.h, 171
dsy_tim_delay_tick, 225	QUAD_INOUT_FAST_READ_4_BYTE_ADDR_CMD

dev_flash_IS25LP064A.h, 156	dev_flash_IS25LP080D.h, 173
dev_flash_IS25LP080D.h, 171	READ_STATUS_REG_CMD
QUAD_INOUT_FAST_READ_CMD	dev_flash_IS25LP064A.h, 158
dev_flash_IS25LP064A.h, 156	dev_flash_IS25LP080D.h, 173
dev_flash_IS25LP080D.h, 171	RESET_ENABLE_CMD
QUAD_INOUT_FAST_READ_DTR_CMD	dev_flash_IS25LP064A.h, 158
dev_flash_IS25LP064A.h, 156	dev_flash_IS25LP080D.h, 174
dev_flash_IS25LP080D.h, 171	RESET_MEMORY_CMD
QUAD_OUT_FAST_READ_4_BYTE_ADDR_CMD	dev_flash_IS25LP064A.h, 158
dev_flash_IS25LP064A.h, 156	dev_flash_IS25LP080D.h, 174
dev_flash_IS25LP080D.h, 172	raw_data
QUAD_OUT_FAST_READ_CMD	daisy::WavFileInfo, 123
dev_flash_IS25LP064A.h, 156	Read
dev_flash_IS25LP080D.h, 172	daisy::RingBuffer, 102
QUAD_OUT_FAST_READ_DTR_CMD	daisy::RingBuffer $<$ T, 0 $>$, 105
dev_flash_IS25LP064A.h, 156	Readable
dev_flash_IS25LP080D.h, 172	daisy::UartHandler, 116
qspi_handle	readable
daisy::DaisySeed, 69	daisy::RingBuffer, 102
	daisy::RingBuffer< T, 0 >, 105
r	ReceiveCallback
codec_frame_t, 42	daisy::UsbHandle, 118
RAM_AS4C16M16SA_H	Red
dev_sdram.h, 179	daisy::Color, 45
READ_4_BYTE_ADDR_CMD	
dev_flash_IS25LP064A.h, 156	red
dev_flash_IS25LP080D.h, 172	color, 43
READ_CMD	RelCardAdd
	DSY_SD_CardInfoTypeDef, 78
dev_flash_IS25LP064A.h, 157	Restart
dev_flash_IS25LP080D.h, 172	daisy::WavPlayer, 125
READ_ENHANCED_VOL_CFG_REG_CMD	retSD
dev_flash_IS25LP064A.h, 157	fatfs.h, 186
dev_flash_IS25LP080D.h, 172	ring_led
READ_EXT_ADDR_REG_CMD	daisy::DaisyPetal, 60
dev_flash_IS25LP064A.h, 157	RingLed
dev_flash_IS25LP080D.h, 172	_
READ_FLAG_STATUS_REG_CMD	daisy::DaisyPetal, 55
dev_flash_IS25LP064A.h, 157	RisingEdge
dev_flash_IS25LP080D.h, 172	daisy::Encoder, 82
	daisy::Switch, 113
READ_ID_CMD2	RxActive
dev_flash_IS25LP064A.h, 157	daisy::UartHandler, 116
dev_flash_IS25LP080D.h, 173	
READ_ID_CMD	S162F_SCALE
dev_flash_IS25LP064A.h, 157	daisy.h, 128
dev_flash_IS25LP080D.h, 173	s162f
READ_LOCK_REG_CMD	daisy.h, 129
dev_flash_IS25LP064A.h, 157	S242F_SCALE
dev flash IS25LP080D.h, 173	daisy.h, 129
READ_NONVOL_CFG_REG_CMD	s242f
dev_flash_IS25LP064A.h, 157	daisy.h, 130
dev flash IS25LP080D.h, 173	S24SIGN
READ_OTP_ARRAY_CMD	daisy.h, 129
dev_flash_IS25LP064A.h, 158	SA_LED_DRIVER_H
dev_flash_IS25LP080D.h, 173	dev_leddriver.h, 176
READ_READ_PARAM_REG_CMD	SAMPLE_RATE
dev_flash_IS25LP064A.h, 158	daisy_field.h, 136
dev_flash_IS25LP080D.h, 173	SD_DATATIMEOUT
READ_SERIAL_FLASH_DISCO_PARAM_CMD	util_bsp_sd_diskio.h, 234
dev_flash_IS25LP064A.h, 158	SD_NOT_PRESENT

util_bsp_sd_diskio.h, 234	per_sdmmc.h, 223
SD_PRESENT	SdmmcMode
util_bsp_sd_diskio.h, 234	per_sdmmc.h, 223
SD_TRANSFER_BUSY	SdmmcSpeed
util_bsp_sd_diskio.h, 234	per_sdmmc.h, 223
SD_TRANSFER_OK	sdram_handle
util_bsp_sd_diskio.h, 234	daisy::DaisySeed, 69
SDFatFS	seed
fatfs.h, 186	daisy::DaisyPatch, 53
SDFile	daisy::DaisyPetal, 60
fatfs.h, 186	daisy::DaisyPod, 65
SDPath	daisy::daisy_field, 47
fatfs.h, 186	Set
SECTOR_ERASE_4_BYTE_ADDR_CMD	daisy::Led, 86
dev_flash_IS25LP064A.h, 158	daisy::RgbLed, 99
dev_flash_IS25LP080D.h, 174	ShiftRegister595, 109
SECTOR_ERASE_CMD	SetAudioBlockSize
dev_flash_IS25LP064A.h, 158	daisy::DaisyPatch, 51
dev_flash_IS25LP080D.h, 174	daisy::DaisyPetal, 57
SR_4021_MAX_DAISYCHAIN	daisy::DaisyPod, 63
dev sr 4021.h, 182	daisy::DaisySeed, 67
SR_4021_MAX_PARALLEL	SetColor
dev_sr_4021.h, 182	daisy::RgbLed, 99
SSD1309 HEIGHT	SetCursor
hid_oled_display.h, 201	daisy::OledDisplay, 94
SSD1309 WIDTH	SetFootswitchLed
hid_oled_display.h, 201	daisy::DaisyPetal, 58
STM32_USB_OTG_DEVICE_LIBRARY, 30	SetLed
SUBSECTOR_ERASE_4_BYTE_ADDR_CMD	daisy::DaisySeed, 67
dev_flash_IS25LP064A.h, 159	SetLooping
dev flash IS25LP080D.h, 174	daisy::WavPlayer, 125
SUBSECTOR ERASE CMD	SetReceiveCallback
dev_flash_IS25LP064A.h, 159	daisy::UsbHandle, 119
dev flash IS25LP080D.h, 174	SetRingLed
SUBSECTOR ERASE QPI CMD	daisy::DaisyPetal, 58
dev flash IS25LP064A.h, 159	SetTestPoint
dev flash IS25LP080D.h, 174	daisy::DaisySeed, 67
SW 1 PIN	ShiftRegister595, 108
daisy field.h, 136	Init, 109
SW 2 PIN	Pins, 108
daisy field.h, 136	Set, 109
SW 3 PIN	Write, 109
daisy_field.h, 136	speed
sa audio callback	daisy::SdmmcHandlerInit, 107
dev_codec_wm8731_frame.h, 144	dsy_i2c_handle, 73
sai	SpiPeriph
dsy_audio_handle, 70	per_spi.h, 224
sai1_pin_config	SpiPin
dsy_sai_handle, 76	per_spi.h, 224
sai2_pin_config	src/daisy.h, 127
dsy_sai_handle, 76	src/daisy_core.h, 130
sai handle	src/daisy_field.h, 132
daisy::DaisySeed, 69	src/daisy_patch.h, 139
SampleRate	src/daisy_petal.h, 140
WAV_FormatTypeDef, 121	src/daisy_pod.h, 140
samplerate	src/daisy_seed.h, 140
dsy_sai_handle, 76	src/dev_codec_ak4556.h, 141
SdmmcBitWidth	src/dev_codec_pcm3060.h, 141
	,,,

src/dev_codec_wm8731.h, 142	state
src/dev_codec_wm8731_frame.h, 144	dsy_sdram_handle, 79
src/dev_flash_IS25LP064A.h, 144	states
src/dev_flash_IS25LP080D.h, 160	dsy_sr_4021_handle, 80
src/dev_leddriver.h, 176	Stop
src/dev_sdram.h, 178	daisy::AdcHandle, 39
src/dev_sr_4021.h, 181	Stream
src/dev_sr_595.h, 184	daisy::WavPlayer, 125
src/fatfs.h, 185	SubCHunk2Size
src/ffconf.h, 187	WAV_FormatTypeDef, 122
src/hid_audio.h, 194	SubChunk1ID
src/hid_ctrl.h, 198	WAV_FormatTypeDef, 121
src/hid_encoder.h, 199	SubChunk1Size
	WAV_FormatTypeDef, 122
src/hid_gatein.h, 199	SubChunk2ID
src/hid_led.h, 199	WAV_FormatTypeDef, 122
src/hid_midi.h, 200	Sw
src/hid_oled_display.h, 201	daisy::DaisyPetal, 55
src/hid_parameter.h, 201	•
src/hid_rgb_led.h, 202	daisy::DaisyPod, 62
src/hid_switch.h, 202	Swallow
src/hid_usb.h, 202	daisy::RingBuffer, 102
src/hid_wavplayer.h, 202	switches
src/per_adc.h, 203	daisy::DaisyPetal, 60
src/per_dac.h, 204	daisy::daisy_field, 47
src/per_gpio.h, 206	sync_config
src/per_i2c.h, 209	dsy_sai_handle, 76
src/per_qspi.h, 212	sys_dma.h
src/per_sai.h, 217	dsy_dma_init, 228
src/per_sdmmc.h, 222	sys_system.h
src/per_spi.h, 224	dsy_system_delay, 228
src/per_tim.h, 225	dsy_system_getnow, 229
src/per_uart.h, 227	dsy_system_init, 229
src/sys_dma.h, 228	dsy_system_jumpto, 229
src/sys_uma.n, 228	dsy_system_jumptoqspi, 229
. — .	
src/usbd_cdc_if.h, 230	TimeHeldMs
src/usbd_conf.h, 231	daisy::Encoder, 82
src/usbd_desc.h, 232	daisy::Switch, 114
src/util_bsp_sd_diskio.h, 232	TransmitExternal
src/util_color.h, 238	daisy::UsbHandle, 119
src/util_hal_map.h, 239	TransmitInternal
src/util_ringbuffer.h, 241	daisy::UsbHandle, 119
src/util_unique_id.h, 241	Trig
src/util_wav_format.h, 242	daisy::GateIn, 85
Start	Туре
daisy::AdcHandle, 39	daisy::Switch, 112
StartAdc	type
daisy::DaisyPatch, 51	daisy::MidiEvent, 87
daisy::DaisyPetal, 58	dalojvidi Evorit, ev
daisy::DaisyPod, 64	USB_SIZ_STRING_SERIAL
StartAudio	USBD_DESC_Exported_Constants, 24
daisy::DaisyPatch, 51	USBD_CDC_IF_Exported_Defines, 10
daisy::DaisyPetal, 59	USBD_CDC_IF_Exported_FunctionsPrototype, 14
daisy::DaisyPod, 64	CDC_Set_Rx_Callback_FS, 14
daisy::DaisySeed, 68	CDC_Transmit_FS, 14
StartReceive	CDC_Transmit_HS, 14
daisy::MidiHandler, 90	USBD_CDC_IF_Exported_Macros, 12
StartRx	USBD_CDC_IF_Exported_Types, 11
daisy::UartHandler, 117	CDC_ReceiveCallback, 11
uaisyuai (Hanulei, 117	ODO_NECEIVECAIIDACK, 11

USBD_CDC_IF_Exported_Variables, 13	USBD_MAX_STR_DESC_SIZ
USBD_Interface_fops_FS, 13	USBD_CONF_Exported_Defines, 18
USBD_Interface_fops_HS, 13	USBD_OTG_DRIVER, 31
USBD_CDC_IF, 9	USBD_SELF_POWERED
USBD_CONF_Exported_Defines, 17	USBD_CONF_Exported_Defines, 18
DEVICE_FS, 17	USBD_SUPPORT_USER_STRING
DEVICE_HS, 17	USBD_CONF_Exported_Defines, 18
USBD_DEBUG_LEVEL, 17	USBD_UsrLog
USBD_LPM_ENABLED, 17	USBD_CONF_Exported_Macros, 20
USBD_MAX_NUM_CONFIGURATION, 18	USBD_free
USBD_MAX_NUM_INTERFACES, 18	USBD_CONF_Exported_Macros, 20
USBD_MAX_STR_DESC_SIZ, 18	USBD_malloc
USBD_SELF_POWERED, 18	USBD_CONF_Exported_Macros, 20
USBD_SUPPORT_USER_STRING, 18	USBD_memcpy
USBD_CONF_Exported_FunctionsPrototype, 22	USBD_CONF_Exported_Macros, 20
USBD_CONF_Exported_Macros, 19	USBD_memset
USBD_DbgLog, 19	USBD_CONF_Exported_Macros, 20
USBD_Delay, 19	Update
USBD_ErrLog, 19	daisy::Led, 86
USBD_UsrLog, 20	daisy::OledDisplay, 95
USBD_free, 20	daisy::RgbLed, 99
USBD_malloc, 20	UpdateAnalogControls
USBD_memcpy, 20	daisy::DaisyPatch, 52
USBD_memset, 20	daisy::DaisyPetal, 59
USBD_CONF_Exported_Types, 21	daisy::DaisyPod, 64
USBD_CONF_Exported_Variables, 16	UpdateLeds
USBD_CONF, 15	daisy::DaisyPetal, 59
USBD_DEBUG_LEVEL	daisy::DaisyPod, 64
USBD_CONF_Exported_Defines, 17	usb_handle
USBD_DESC_Exported_Constants, 24	daisy::DaisySeed, 69
DEVICE_ID1, 24	UsbPeriph
DEVICE_ID2, 24	daisy::UsbHandle, 118
DEVICE_ID3, 24	util_bsp_sd_diskio.h
USB_SIZ_STRING_SERIAL, 24	BSP_SD_AbortCallback, 235
USBD_DESC_Exported_Defines, 25	BSP_SD_CardInfo, 233
USBD_DESC_Exported_FunctionsPrototype, 29	BSP_SD_Erase, 235
USBD_DESC_Exported_Macros, 27	BSP_SD_GetCardInfo, 235
USBD_DESC_Exported_TypesDefinitions, 26	BSP_SD_GetCardState, 235
USBD_DESC_Exported_Variables, 28	BSP_SD_ITConfig, 236
FS_Desc, 28	BSP_SD_Init, 236
HS_Desc, 28	BSP_SD_IsDetected, 236
USBD_DESC, 23	BSP_SD_ReadBlocks, 236
USBD_DbgLog	BSP_SD_ReadBlocks_DMA, 237
USBD_CONF_Exported_Macros, 19	BSP_SD_ReadCpltCallback, 237
USBD_Delay	BSP_SD_WriteBlocks, 237
USBD_CONF_Exported_Macros, 19	BSP_SD_WriteBlocks_DMA, 238
USBD_ErrLog	BSP_SD_WriteCpltCallback, 238
USBD_CONF_Exported_Macros, 19	DSY_BSP_SD_DISKIO_H, 233
USBD_Interface_fops_FS	MSD_ERROR_SD_NOT_PRESENT, 234
USBD_CDC_IF_Exported_Variables, 13	MSD_ERROR, 233
USBD_Interface_fops_HS	MSD_OK, 234
USBD_CDC_IF_Exported_Variables, 13	SD_DATATIMEOUT, 234
USBD_LPM_ENABLED	SD_NOT_PRESENT, 234
USBD_CONF_Exported_Defines, 17	SD_PRESENT, 234
USBD_MAX_NUM_CONFIGURATION	SD_TRANSFER_BUSY, 234
USBD_CONF_Exported_Defines, 18	SD_TRANSFER_OK, 234
USBD_MAX_NUM_INTERFACES	util_color.h
USBD_CONF_Exported_Defines, 18	DSY_COLOR_H, 239

util_hal_map.h dsy_hal_map_get_i2c, 239 dsy_hal_map_get_pin, 240 dsy_hal_map_get_port, 240 hi2c1, 240 hi2c2, 240 hi2c3, 241	writable daisy::RingBuffer, 103 daisy::RingBuffer < T, 0 >, 106 Write daisy::RingBuffer, 103 daisy::RingBuffer < T, 0 >, 106 ShiftRegister595, 109
hi2c4, 241 util_unique_id.h dsy_get_unique_id, 241	WriteChar daisy::OledDisplay, 95 WriteString
Value	daisy::OledDisplay, 95
daisy::AnalogControl, 41 daisy::Parameter, 98	
value	
daisy::ControlChangeEvent, 46	
velocity	
daisy::NoteOnEvent, 91	
WAV_FILENAME_MAX	
hid_wavplayer.h, 203	
WAV_FormatTypeDef, 120	
AudioFormat, 120	
BitPerSample, 120	
BlockAlign, 121	
ByteRate, 121	
Chunkld, 121	
FileFormat, 121	
FileSize, 121	
NbrChannels, 121	
SampleRate, 121	
SubCHunk2Size, 122	
SubChunk1ID, 121	
SubChunk1Size, 122	
SubChunk2ID, 122	
WRITE_DISABLE_CMD	
dev_flash_IS25LP064A.h, 159	
dev_flash_IS25LP080D.h, 174	
WRITE_ENABLE_CMD	
dev_flash_IS25LP064A.h, 159	
dev_flash_IS25LP080D.h, 175	
WRITE_ENHANCED_VOL_CFG_REG_CMD	
dev_flash_IS25LP064A.h, 159 dev_flash_IS25LP080D.h, 175	
WRITE_EXT_ADDR_REG_CMD	
dev_flash_IS25LP064A.h, 159	
dev_flash_IS25LP004A.ft, 139 dev_flash_IS25LP080D.h, 175	
WRITE LOCK REG CMD	
dev_flash_IS25LP064A.h, 159	
dev flash IS25LP080D.h, 175	
WRITE_NONVOL_CFG_REG_CMD	
dev flash IS25LP064A.h, 160	
dev_flash_IS25LP080D.h, 175	
WRITE_READ_PARAM_REG_CMD	
dev_flash_IS25LP064A.h, 160	
dev_flash_IS25LP080D.h, 175	
WRITE_STATUS_REG_CMD	
dev_flash_IS25LP064A.h, 160	
dev_flash_IS25LP080D.h, 175	
<u> </u>	