DaisySP

Contents

adenv	7
Envelope Segments	7
init	7
process	8
trigger	8
Mutators	8
SetTime	8
SetCurve	
SetMin	
SetMax	
Accessors	_
GetCurrentSegment	
IsRunning	
Example	
Zampo	
compressor	12
init	12
process	12
setters	13
set_ratio	13
set_threshold	13
set_attack	13
set_release	13
Example	13
crossfade	17
Curve Options	17

init	17
process	18
Setters	18
set_pos	18
set_curve	18
Getters	18
get_pos	18
get_curve	18
Example	19
deblock	21
init	
process	
Example	
decimator	23
init	23
process	23
Mutators	23
set_downsample_factor	23
set_bitcrush_factor	23
set_bits_to_crush	23
Accessors	24
get_downsample_factor	24
get_bitcrush_factor	24
Example	24
delayline	27
init	
reset	
set_delay	
write	
read	
Example	
core dsp	31
Generic Defines	
fast helpers	
fmax/fmin	31

	fclamp .																													31
	fastpower	r and	d fa	str	00	t																								31
	mtof																													32
Filte	rs																													32
	fonepole																													32
	median																													32
Quid	ck Effects																													32
	Soft Satu	rate																												32
Exa	mple																													33
line																														34
	init																													34
	process																													34
	start		•								٠																			34
Exa	mple				٠						٠	٠									٠									34
metro																														37
	init																													37
	process																													37
	reset																													37
Sett																														37
0011	set_freq																													37
Gett	ters																													37
Got	get_freq																													37
Exa	mple																													38
			•		•		•				•				•		•	•	•	·		•		•		•	•		•	
nlfilt																														40
	init																													40
	process																													40
sette	ers																													40
	set_coeff	icier	nts																											40
	individual	l set	ters	s fo	r e	eac	ch	СО	ef	fici	er	ıts.																		41
Exa	mple																													41
oscillat	tor																													44
	eforms .																													44
vvav	init																													44
	set_freq																													45
	set_neq		•		•	•	•	•	•	•	•	•	•	•	•	•	•		 •	•	•	•	•	•	•	•	•	•	•	45

	set_waveform	 	 	 	 	 	 			45
	process	 	 	 	 	 	 			45
E	Example	 	 	 	 	 	 			45
nha	noor .									48
pha	init									48
										48
	process									48
	Setters									_
,	set_freq									48
(Getters									49
_	get_freq									49
Ė	Example	 	 	 	 	 	 	٠	•	49
pitc	chshift									51
•	Example	 	 	 	 	 	 			51
	- F									
pluc	ck									53
N	Mode	 	 	 	 	 	 			53
	init	 	 	 	 	 	 			53
	process	 	 	 	 	 	 			54
N	Mutators	 	 	 	 	 	 			54
	set_amp	 	 	 	 	 	 			54
	set_freq	 	 	 	 	 	 			54
	set_decay	 	 	 	 	 	 			54
	set_damp	 	 	 	 	 	 			54
	set_mode	 	 	 	 	 	 			54
A	Accessors									55
	get_amp	 	 	 	 	 	 			55
	get_freq	 	 	 	 	 	 			55
	get_decay									55
	get_damp									55
	get_mode									55
Е	Example						 			55
	·									
port	t									58
	init	 	 	 	 	 	 			58
	process	 	 	 	 	 	 			58
5	Setters	 	 	 	 	 	 			58
	set_htime	 	 	 	 	 	 			58

Gette	ers																59
	get_htime .																59
Exar	nple																59
reverbs	С																61
	init																61
	process																61
	set_feedabck	ί.										 					61
	set_lpfreq .																61
Exar	nple					-											61
svf																	63
	init																63
	process																63
Sette	ers																63
	set_freq																63
	set_res																63
	set_drive																64
Filter	Outputs																64
Lowp	oass Filter																64
High	pass Filter .																64
Band	dpass Filter .																64
Note	h Filter																64
Peak	Filter																64
Exar	nple																64
tone																	67
	init																67
	process																67
Sette	ers																67
	set_freq																67
Gette	ers																67
	get_freq																67
Exar	nple					-											67
whitenc	oise																70
	init																70
	set_amp																70
	nrocess																70

Example																			_	^
- xamne																				О
	-																			

adenv

Author: shensley

Trigger-able envelope with adjustable min/max, and independent per-segment time control.

TODO:

- · Add Cycling
- · Implement Curve (its only linear for now).
- · Maybe make this an ADsr_ that has AD/AR/Asr_ modes.

Envelope Segments

Distinct stages that the phase of the envelope can be located in.

- IDLE = located at phase location 0, and not currently running
- ATTACK = First segment of envelope where phase moves from MIN value to MAX value
- DECAY = Second segment of envelope where phase moves from MAX to MIN value
- LAST = The final segment of the envelope (currently decay)

enum

```
{
    ADENV_SEG_IDLE,
    ADENV_SEG_ATTACK,
    ADENV_SEG_DECAY,
    ADENV_SEG_LAST,
};
```

init

Initializes the ad envelope

float sample_rate - sample rate of the audio engine being run.

Defaults

- · current segment = idle
- · curve = linear
- phase = 0
- min = 0

```
• max = 1
void Init(float sample_rate);
```

process

processes the current sample of the envelope. Returns the current envelope value. This should be called once per sample period.

```
float Process();
```

trigger

Starts or retriggers the envelope.

```
inline void Trigger() { trigger = 1; }
```

Mutators

SetTime

Sets the length of time (in seconds) for a specific segment.

```
inline void SetTime(uint8 t seg, float time)
```

SetCurve

Sets the amount of curve applied. A positive value will create a log Input range: -100 to 100. (or more)

```
inline void SetCurve(float scalar) { curve_scalar_ = scalar; }
```

SetMin

Sets the minimum value of the envelope output Input range: -FLTmax_, to FLTmax_

```
inline void SetMin(float min) { min_ = min; }
```

SetMax

Sets the maximum value of the envelope output Input range: -FLTmax_, to FLTmax_

```
inline void SetMax(float max) { max_ = max; }
```

Accessors

GetCurrentSegment

Returns the segment of the envelope that the phase is currently located in.

```
inline uint8_t GetCurrentSegment() { return current_segment_; }
```

IsRunning

Returns true if the envelope is currently in any stage apart from idle.

```
inline bool IsRunning() const
```

```
#include "daisysp.h"
#include "daisy seed.h"
// Shortening long macro for sample rate
#ifndef SAMPLE RATE
#define SAMPLE RATE DSY AUDIO SAMPLE RATE
#endif
// Interleaved audio definitions
#define LEFT (i)
#define RIGHT (i+1)
using namespace daisysp;
static daisy_handle seed;
static adenv env;
static oscillator osc;
static metro tick;
static void audioCallback(float *in, float *out, size_t size)
{
    float osc_out, env_out;
    for (size_t i = 0; i < size; i += 2)</pre>
```

```
{
        // When the metro ticks, trigger the envelope to start.
        if (tick.process())
        {
            env.trigger();
        }
        // Use envelope to control the amplitude of the oscillator.
        env out = env.process();
        osc.set amp(env out);
        osc_out = osc.process();
        out[LEFT] = osc_out;
        out[RIGHT] = osc_out;
    }
}
int main(void)
{
    // initialize seed hardware and daisysp modules
    daisy seed init(&seed);
    env.init(SAMPLE_RATE);
    osc.init(SAMPLE_RATE);
    // Set up metro to pulse every second
    tick.init(1.0f, SAMPLE RATE);
    // set adenv parameters
    env.set_time(ADENV_SEG_ATTACK, 0.15);
    env.set_time(ADENV_SEG_DECAY, 0.35);
    env.set_min(0.0);
    env.set max(0.25);
    env.set_curve_scalar(0); // linear
    // Set parameters for oscillator
    osc.set waveform(osc.WAVE TRI);
    osc.set_freq(220);
    osc.set_amp(0.25);
```

```
// define callback
dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);

// start callback
dsy_audio_start(DSY_AUDIO_INTERNAL);

while(1) {}
}
```

compressor

influenced by compressor in soundpipe (from faust).

Modifications made to do:

- Less calculations during each process loop (coefficients recalculated on parameter change).
- · C++-ified
- · added sidechain support

TODO:

- · With fixed controls this is relatively quick, but changing controls now costs a lot more
- · Still pretty expensive
- · Add soft/hard knee settings
- Maybe make stereo possible? (needing two for stereo is a bit silly, and their gain shouldn't be totally unique.

by: shensley

init

Initializes compressor

samplerate - rate at which samples will be produced by the audio engine.

```
void init(float samplerate);
```

process

compresses the audio input signal, either keyed by itself, or a secondary input.

in - audio input signal (to be compressed)

(optional) key - audio input that will be used to side-chain the compressor.

```
float process(float &in, float &key);
float process(float &in);
```

setters

```
set_ratio
```

amount of gain reduction applied to compressed signals

```
Expects 1.0 -> 40. (untested with values < 1.0)
```

```
void set_ratio(const float &ratio)
```

set_threshold

threshold in dB at which compression will be applied

```
Expects 0.0 -> -80.
```

```
void set_threshold(const float &thresh)
```

set_attack

envelope time for onset of compression for signals above the threshold.

```
Expects 0.001 -> 10
```

```
void set_attack(const float &atk)
```

set_release

envelope time for release of compression as input signal falls below threshold.

```
Expects 0.001 -> 10
```

```
void set_release(const float &rel)
```

internals from faust struct

```
#include "daisysp.h"
#include "daisy_seed.h"

// Shortening long macro for sample rate
#ifndef SAMPLE_RATE
```

```
#define SAMPLE_RATE DSY_AUDIO_SAMPLE_RATE
#endif
// Interleaved audio definitions
#define LEFT (i)
#define RIGHT (i+1)
using namespace daisysp;
static daisy handle seed;
static compressor comp;
// Helper Modules
static adenv env;
static oscillator osc_a, osc_b;
static metro tick;
static void audioCallback(float *in, float *out, size_t size)
{
    float osc_a_out, osc_b_out, env_out, sig_out;
    for (size t i = 0; i < size; i += 2)</pre>
    {
        // When the metro ticks:
        // trigger the envelope to start
        if (tick.process())
        {
            env.trigger();
        }
        // Use envelope to control the amplitude of the oscillator.
        env out = env.process();
        osc_a.set_amp(env_out);
        osc_a_out = osc_a.process();
        osc_b_out = osc_b.process();
        // Compress the steady tone with the enveloped tone.
        sig_out = comp.process(osc_b_out, osc_a_out);
```

```
// Output
        out[LEFT] = sig out; // compressed
        out[RIGHT] = osc_a_out; // key signal
    }
}
int main(void)
{
    // initialize seed hardware and daisysp modules
    daisy seed init(&seed);
    comp.init(SAMPLE_RATE);
    env.init(SAMPLE_RATE);
    osc_a.init(SAMPLE_RATE);
    osc_b.init(SAMPLE_RATE);
    // Set up metro to pulse every second
    tick.init(1.0f, SAMPLE RATE);
    // set compressor parameters
    comp.set_threshold(-64.0f);
    comp.set_ratio(2.0f);
    comp.set_attack(0.005f);
    comp.set_release(0.1250);
    // set adenv parameters
    env.set_time(ADENV_SEG_ATTACK, 0.001);
    env.set_time(ADENV_SEG_DECAY, 0.50);
    env.set min(0.0);
    env.set_max(0.25);
    env.set_curve_scalar(0); // linear
    // Set parameters for oscillator
    osc_a.set_waveform(oscillator::WAVE_TRI);
    osc_a.set_freq(110);
    osc_a.set_amp(0.25);
    osc b.set waveform(oscillator::WAVE TRI);
    osc_b.set_freq(220);
    osc_b.set_amp(0.25);
```

```
// define callback
dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);

// start callback
dsy_audio_start(DSY_AUDIO_INTERNAL);

while(1) {}
}
```

crossfade

Performs a crossfade between two signals

Original author: Paul Batchelor

Ported from Soundpipe by Andrew Ikenberry added curve option for constant power, etc.

TODO:

- · implement exponential curve process
- · implement logarithmic curve process

Curve Options

Curve applied to the crossfade

```
• LIN = linear
```

- CPOW = constant power
- LOG = logarithmic
- EXP exponential
- LAST = end of enum (used for array indexing)

```
enum
{
      CROSSFADE_LIN,
      CROSSFADE_CPOW,
      CROSSFADE_LOG,
      CROSSFADE_EXP,
      CROSSFADE_LAST,
};
```

init

Initializes crossfade module

Defaults

- current position = .5
- curve = linear

```
inline void init(int curve)
```

```
inline void init()
process
processes crossfade and returns single sample
         float process(float &in1, float &in2);
Setters
set_pos
Sets position of crossfade between two input signals
Input range: 0 to 1
         inline void set_pos(float pos) { pos_ = pos; }
set_curve
Sets current curve applied to crossfade
Expected input: See Curve Options
         inline void set_curve(uint8_t curve) { curve_ = curve; }
Getters
get_pos
Returns current position
         inline float get_pos(float pos) { return pos_; }
get_curve
Returns current curve
         inline uint8_t get_curve(uint8_t curve) { return curve_; }
```

```
#include "daisysp.h"
#include "daisy_seed.h"
using namespace daisysp;
static daisy_handle seed;
static crossfade cfade;
static oscillator osc_sine, osc_saw, lfo;
static void audioCallback(float *in, float *out, size_t size)
{
    float saw, sine, pos, output;
    for (size_t i = 0; i < size; i += 2)</pre>
        sine = osc_sine.process();
        saw = osc_saw.process();
        // lfo output = -1 to 1
        pos = lfo.process();
        // scale signal between 0 and 1
        pos = (pos + 1) / 2;
        cfade.set_pos(pos);
        output = cfade.process(sine, saw);
        // left out
        out[i] = output;
        // right out
        out[i+1] = output;
    }
}
int main(void)
```

```
{
   // initialize seed hardware and daisysp modules
   daisy seed init(&seed);
   // set params for crossfade object
   cfade.init();
   cfade.set curve(CROSSFADE LIN);
   // set parameters for sine oscillator object
   osc sine.init(DSY AUDIO SAMPLE RATE);
   osc_sine.set_waveform(oscillator::WAVE_SIN);
   osc_sine.set_freq(100);
   osc_sine.set_amp(0.25);
   // set parameters for sawtooth oscillator object
   osc_saw.init(DSY_AUDIO_SAMPLE_RATE);
   osc saw.set waveform(oscillator::WAVE POLYBLEP SAW);
   osc saw.set freq(100);
   osc_saw.set_amp(0.25);
   // set parameters for triangle lfo oscillator object
   lfo.init(DSY_AUDIO_SAMPLE_RATE);
   lfo.set_waveform(oscillator::WAVE_TRI);
   lfo.set_freq(.25);
   lfo.set_amp(1);
   // define callback
   dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
   // start callback
   dsy_audio_start(DSY_AUDIO_INTERNAL);
   while(1) {}
}
```

dcblock

```
Removes DC component of a signal
```

```
init
```

```
Initializes dcblock module
```

```
void init(float sample_rate);
```

process

performs dcblock process

```
float process(float in);
```

```
#include "daisysp.h"
#include "daisy_seed.h"

using namespace daisysp;

static daisy_handle seed;
static dcblock block;
static oscillator osc_sine;

static void audioCallback(float *in, float *out, size_t size)
{
    float output;
    for (size_t i = 0; i < size; i += 2)
    {
        output = osc_sine.process();

        // add dc to signal
        output += 1;

        // remove dc from signal</pre>
```

```
output = block.process(output);
        // left out
        out[i] = output;
        // right out
        out[i+1] = output;
    }
}
int main(void)
{
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    block.init(DSY_AUDIO_SAMPLE_RATE);
    // set parameters for sine oscillator object
    osc_sine.init(DSY_AUDIO_SAMPLE_RATE);
    osc_sine.set_waveform(oscillator::WAVE_SIN);
    osc_sine.set_freq(100);
    osc_sine.set_amp(0.25);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
}
```

decimator

Performs downsampling and bitcrush effects

init

Initializes downsample module

```
void init();
```

process

Applies downsample and bitcrush effects to input signal. Returns one sample. This should be called once per sample period.

```
float process(float input);
```

Mutators

set_downsample_factor

Sets amount of downsample Input range:

```
inline void set_downsample_factor(float downsample_factor)
```

set_bitcrush_factor

Sets amount of bitcrushing Input range:

```
inline void set_bitcrush_factor(float bitcrush_factor)
```

set_bits_to_crush

Sets the exact number of bits to crush

0-16 bits

```
inline void set_bits_to_crush(const uint8_t &bits)
```

Accessors

```
get\_downsample\_factor
```

```
Returns current setting of downsample
```

```
inline float get_downsample_factor() { return downsample_factor_; }
```

get_bitcrush_factor

Returns current setting of bitcrush

```
inline float get_bitcrush_factor() { return bitcrush_factor_; }
```

```
#include "daisysp.h"
#include "daisy seed.h"
// Shortening long macro for sample rate
#ifndef SAMPLE RATE
#define SAMPLE RATE DSY AUDIO SAMPLE RATE
#endif
// Interleaved audio definitions
#define LEFT (i)
#define RIGHT (i+1)
using namespace daisysp;
static daisy_handle seed;
static oscillator osc;
static decimator decim;
static phasor phs;
static void audioCallback(float *in, float *out, size_t size)
{
    float osc_out, decimated_out;
    float downsample_amt;
```

```
for (size_t i = 0; i < size; i += 2)</pre>
        // Generate a pure sine wave
        osc_out = osc.process();
        // Modulate downsample amount via phasor
        downsample_amt = phs.process();
        decim.set downsample factor(downsample amt);
        // downsample and bitcrush
        decimated out = decim.process(osc out);
        // outputs
        out[LEFT] = decimated_out;
        out[RIGHT] = decimated_out;
    }
}
int main(void)
{
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    osc.init(SAMPLE_RATE);
    phs.init(SAMPLE_RATE, 0.5f);
    decim.init();
    // Set parameters for oscillator
    osc.set waveform(osc.WAVE SIN);
    osc.set freq(220);
    osc.set_amp(0.25);
    // Set downsampling, and bit crushing values.
    decim.set_downsample_factor(0.4f);
    decim.set_bits_to_crush(8);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy audio start(DSY AUDIO INTERNAL);
    while(1) {}
```

}

delayline

```
Simple Delay line.
November 2019
Converted to Template December 2019
declaration example: (1 second of floats)
delayline<float, SAMPLE_RATE> del;
By: shensley
init
initializes the delay line by clearing the values within, and setting delay to 1 sample.
     void init()
reset
clears buffer, sets write ptr to 0, and delay to 1 sample.
     void reset() {
set_delay
sets the delay time in samples
If a float is passed in, a fractional component will be calculated for interpolating the delay
line.
     inline void set_delay(size_t delay)
     inline void set_delay(float delay)
write
writes the sample of type T to the delay line, and advances the write ptr
     inline void write(const T sample)
```

read

returns the next sample of type T in the delay line, interpolated if necessary.

```
inline const T read() const
```

```
#include "daisysp.h"
#include "daisy_seed.h"
// Shortening long macro for sample rate
#ifndef SAMPLE RATE
#define SAMPLE_RATE DSY_AUDIO_SAMPLE_RATE
#endif
// Interleaved audio definitions
#define LEFT (i)
#define RIGHT (i+1)
// Set max delay time to 0.75 of samplerate.
#define MAX_DELAY static_cast<size_t>(SAMPLE_RATE * 0.75f)
using namespace daisysp;
static daisy_handle seed;
// Helper Modules
static adenv env;
static oscillator osc;
static metro tick;
// Declare a delayline of MAX_DELAY number of floats.
static delayline<float, MAX_DELAY> del;
static void audioCallback(float *in, float *out, size t size)
{
    float osc_out, env_out, feedback, del_out, sig_out;
```

```
for (size_t i = 0; i < size; i += 2)</pre>
        // When the metro ticks:
        // trigger the envelope to start, and change freq of oscillator.
        if (tick.process())
            float freq = rand() % 200;
            osc.set_freq(freq + 100.0f);
            env.trigger();
        }
        // Use envelope to control the amplitude of the oscillator.
        env out = env.process();
        osc.set_amp(env_out);
        osc_out = osc.process();
        // Read from delay line
        del_out = del.read();
        // Calculate output and feedback
        sig_out = del_out + osc_out;
        feedback = (del_out * 0.75f) + osc_out;
        // Write to the delay
        del.write(feedback);
        // Output
        out[LEFT] = sig_out;
        out[RIGHT] = sig_out;
    }
}
int main(void)
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    env.init(SAMPLE RATE);
    osc.init(SAMPLE_RATE);
    del.init();
```

```
// Set up metro to pulse every second
tick.init(1.0f, SAMPLE_RATE);
// set adenv parameters
env.set_time(ADENV_SEG_ATTACK, 0.001);
env.set_time(ADENV_SEG_DECAY, 0.50);
env.set_min(0.0);
env.set max(0.25);
env.set_curve_scalar(0); // linear
// Set parameters for oscillator
osc.set_waveform(osc.WAVE_TRI);
osc.set_freq(220);
osc.set_amp(0.25);
// Set Delay time to 0.75 seconds
del.set_delay(SAMPLE_RATE * 0.75f);
// define callback
dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
// start callback
dsy_audio_start(DSY_AUDIO_INTERNAL);
while(1) {}
```

}

core dsp

helper defines, functions for use in/with daisysp modules.

Generic Defines

```
For now just PIs
```

```
#define PI_F 3.1415927410125732421875f
#define TWOPI_F (2.0f * PI_F)
#define HALFPI_F (PI_F * 0.5f)
```

fast helpers

fmax/fmin

efficient floating point min/max

c/o stephen mccaul

```
inline float fmax(float a, float b)
inline float fmin(float a, float b)
```

fclamp

quick fp clamp

```
inline float fclamp(float in, float min, float max)
```

fastpower and fastroot

From Musicdsp.org "Fast power and root estimates for 32bit floats)

Original code by Stefan Stenzel

These are approximations

```
inline float fastpower(float f, int n)
inline float fastroot(float f, int n)
```

mtof

```
Midi to frequency helper
inline float mtof(float m)
{
    return powf(2, (m - 69.0f) / 12.0f) * 440.0f;
}
```

Filters

fonepole

one pole lpf

out is passed by reference, and must be retained between calls to properly filter the signal coeff can be calculated:

```
coeff = 1.0 / (time * samplerate); where time is in seconds
inline void fonepole(float &out, float in, float coeff)
```

median

Simple 3-point median filter

c/o stephen mccaul

```
template <typename T>
T median(T a, T b, T c)
```

Quick Effects

Soft Saturate

Based on soft saturate from:

musicdsp.org

Bram de Jong (2002-01-17)

This still needs to be tested/fixed. Definitely does some weird stuff

```
described as:
x < a:
    f(x) = x

x > a:
    f(x) = a + (x-a)/(1+((x-a)/(1-a))^2)

x > 1:
    f(x) = (a + 1)/2

inline float soft_saturate(float in, float thresh)
```

Example

No example Provided

line

creates a line segment signal

init

Initializes line module.

```
void init(float sample_rate);
```

process

Processes line segment. Returns one sample.

value of finished will be updated to a 1, upon completion of the line's trajectory.

```
float process(uint8_t *finished);
```

start

Begin creation of line.

Arguments:

- · start beginning value
- · end ending value
- · dur duration in seconds of line segment

```
void start(float start, float end, float dur);
```

```
#include "daisysp.h"
#include "daisy_seed.h"

using namespace daisysp;

static daisy_handle seed;
static line line_seg;
static oscillator osc_sine;
```

```
uint8_t finished;
static void audioCallback(float *in, float *out, size_t size)
{
    float sine, freq;
    for (size_t i = 0; i < size; i += 2)</pre>
    {
        if (finished)
        {
            // start creating a line segment from 100 to 500 in 1 seconds
            line_seg.start(100, 500, 1);
        }
        freq = line_seg.process(&finished);
        osc sine.set freq(freq);
        sine = osc_sine.process();
        // left out
        out[i] = sine;
        // right out
        out[i+1] = sine;
    }
}
int main(void)
{
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    // initialize line module
    line_seg.init(DSY_AUDIO_SAMPLE_RATE);
    finished = 1;
    // set parameters for sine oscillator object
    osc sine.init(DSY AUDIO SAMPLE RATE);
    osc_sine.set_waveform(oscillator::WAVE_SIN);
    osc_sine.set_freq(100);
```

```
osc_sine.set_amp(0.25);

// define callback
dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);

// start callback
dsy_audio_start(DSY_AUDIO_INTERNAL);

while(1) {}
}
```

metro

Creates a clock signal at a specific frequency.

init

Initializes metro module.

Arguments: - freq: frequency at which new clock signals will be generated Input Range: - sample_rate: sample rate of audio engine Input range:

```
void init(float freq, float sample_rate);
```

process

checks current state of metro object and updates state if necesary.

```
uint8_t process();
```

reset

resets phase to 0

```
inline void reset() { phs_ = 0.0f; }
```

Setters

set_freq

Sets frequency at which metro module will run at.

```
void set_freq(float freq);
```

Getters

get_freq

Returns current value for frequency.

```
inline float get_freq() { return freq_; }
```

```
#include "daisysp.h"
#include "daisy_seed.h"
using namespace daisysp;
static daisy_handle seed;
static metro clock;
static oscillator osc_sine;
static void audioCallback(float *in, float *out, size_t size)
{
    float sine, freq;
    uint8_t tic;
    for (size_t i = 0; i < size; i += 2)</pre>
        tic = clock.process();
        if (tic)
            freq = rand() \% 500;
            osc_sine.set_freq(freq);
        }
        sine = osc_sine.process();
        // left out
        out[i] = sine;
        // right out
        out[i+1] = sine;
    }
}
int main(void)
{
    // initialize seed hardware and daisysp modules
```

```
daisy_seed_init(&seed);

// initialize metro object at 2 hz
clock.init(2, DSY_AUDIO_SAMPLE_RATE);

// set parameters for sine oscillator object
osc_sine.init(DSY_AUDIO_SAMPLE_RATE);
osc_sine.set_waveform(oscillator::WAVE_SIN);
osc_sine.set_freq(100);
osc_sine.set_amp(0.25);

// define callback
dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
// start callback
dsy_audio_start(DSY_AUDIO_INTERNAL);
while(1) {}
}
```

nlfilt

port by: stephen hensley, December 2019

Non-linear filter.

The four 5-coefficients: a, b, d, C, and L are used to configure different filter types.

Structure for Dobson/Fitch nonlinear filter

Revised Formula from Risto Holopainen 12 Mar 2004

$$Y{n} = tanh(a Y{n-1} + b Y{n-2} + d Y^2{n-L} + X{n} - C)$$

Though traditional filter types can be made, the effect will always respond differently to different input.

This Source is a heavily modified version of the original source from Csound.

TODO:

· make this work on a single sample instead of just on blocks at a time.

init

Initializes the nlfilt object.

```
void init();
```

process

Process the array pointed to by *in and updates the output to *out;

This works on a block of audio at once, the size of which is set with the size.

```
void process_block(float *in, float *out, size_t size);
```

setters

set coefficients

inputs these are the five coefficients for the filter.

```
inline void set_coefficients(float a, float b, float d, float C, float L)
```

individual setters for each coefficients.

```
inline void set_a(float a) { a_ = a; }
inline void set_b(float b) { b_ = b; }
inline void set_d(float d) { d_ = d; }
inline void set_C(float C) { C_ = C; }
inline void set_L(float L) { L_ = L; }
```

```
#include "daisysp.h"
#include "daisy_seed.h"
// Shortening long macro for sample rate
#ifndef SAMPLE RATE
#define SAMPLE RATE DSY AUDIO SAMPLE RATE
#endif
// Interleaved audio definitions
#define LEFT (i)
#define RIGHT (i+1)
using namespace daisysp;
static daisy_handle seed;
// Helper Modules
static adenv env;
static oscillator osc;
static metro tick;
static nlfilt filt;
static void audioCallback(float *in, float *out, size_t size)
{
```

```
// This can be accommodated easily with an extra loop at the end.
    // We use size/2 since we only need to process mono
    float dry[size/2];
    float wet[size/2];
    float env out;
    // loop through mono process
    for (size_t i = 0; i < size/2; i++)</pre>
    {
        // When the metro ticks:
        // trigger the envelope to start, and change freq of oscillator.
        if (tick.process())
        {
            float freq = rand() % 150;
            osc.set_freq(freq + 25.0f);
            env.trigger();
        // Use envelope to control the amplitude of the oscillator.
        env_out = env.process();
        osc.set_amp(env_out);
        dry[i] = osc.process();
    // nonlinear filter
    filt.process_block(dry, wet, size/2);
    // Now write wet signal to both outputs.
    for (size t i = 0; i < size; i+=2)</pre>
    {
        out[LEFT] = wet[i/2];
        out[RIGHT] = wet[i/2];
    }
}
int main(void)
{
    // initialize seed hardware and daisysp modules
    daisy seed init(&seed);
    env.init(SAMPLE_RATE);
    osc.init(SAMPLE_RATE);
```

// The nlfilt object currently only works on blocks of audio at a time.

```
// Set up metro to pulse every 3 seconds
    tick.init(0.333f, SAMPLE_RATE);
    // set adenv parameters
    env.set_time(ADENV_SEG_ATTACK, 1.50);
    env.set_time(ADENV_SEG_DECAY, 1.50);
    env.set_min(0.0);
    env.set max(0.25);
    env.set_curve_scalar(0); // linear
    // Set parameters for oscillator
    osc.set_waveform(osc.WAVE_POLYBLEP_SAW);
    // Set coefficients for non-linear filter.
    filt.set_coefficients(0.7f, -0.2f, 0.95f, 0.24f, 1000.0f);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
}
```

oscillator

```
Synthesis of several waveforms, including polyBLEP bandlimited waveforms.
example:
daisysp::oscillator osc;
init()
{
    osc.init(SAMPLE_RATE);
    osc.set_frequency(440);
    osc.set_amp(0.25);
    osc.set_waveform(WAVE_TRI);
}
callback(float *in, float *out, size_t size)
{
    for (size_t i = 0; i < size; i+=2)
    {
        out[i] = out[i+1] = osc.process();
    }
}</pre>
```

Waveforms

Choices for output waveforms, POLYBLEP are appropriately labeled. Others are naive forms.

```
enum
{
    WAVE_SIN,
    WAVE_TRI,
    WAVE_SAW,
    WAVE_RAMP,
    WAVE_SQUARE,
    WAVE_POLYBLEP_TRI,
    WAVE_POLYBLEP_SAW,
    WAVE_POLYBLEP_SQUARE,
    WAVE_LAST,
```

};

init

Initializes the oscillator

float samplerate - sample rate of the audio engine being run, and the frequency that the process function will be called.

set_freq

Changes the frequency of the oscillator, and recalculates phase increment.

```
inline void set freq(const float f)
```

set_amp

Sets the amplitude of the waveform.

```
inline void set_amp(const float a) { amp = a; }
```

set_waveform

Sets the waveform to be synthesized by the process() function.

```
inline void set_waveform(const uint8_t wf) { waveform = wf < WAVE_LAST ?</pre>
```

process

Processes the waveform to be generated, returning one sample. This should be called once per sample period.

```
float process();
```

```
#include "daisysp.h"
#include "daisy_seed.h"
```

```
using namespace daisysp;
static daisy_handle seed;
static oscillator osc;
static void audioCallback(float *in, float *out, size_t size)
{
    float sig;
    for (size_t i = 0; i < size; i += 2)</pre>
    {
        sig = osc.process();
        // left out
        out[i] = sig;
        // right out
        out[i+1] = sig;
    }
}
int main(void)
{
    // initialize seed hardware and oscillator daisysp module
    daisy seed init(&seed);
    osc.init(DSY AUDIO SAMPLE RATE);
    // Set parameters for oscillator
    osc.set_waveform(osc.WAVE_SIN);
    osc.set freq(440);
    osc.set_amp(0.5);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
```

```
while(1) {}
}
```

phasor

Generates a normalized signal moving from 0-1 at the specified frequency.

TODO:

I'd like to make the following things easily configurable:

- · Selecting which channels should be initialized/included in the sequence conversion.
- Setup a similar start function for an external mux, but that seems outside the scope of this file.

init

Initializes the phasor module

sample rate, and freq are in Hz

initial phase is in radians

Additional init functions have defaults when arg is not specified:

```
• phs = 0.0f
```

```
• freq = 1.0f
```

```
inline void init(float sample_rate, float freq, float initial_phase)
inline void init(float sample_rate, float freq)
inline void init(float sample_rate)
```

process

processes phasor and returns current value

```
float process();
```

Setters

set_freq

Sets frequency of the phasor in Hz

```
void set freq(float freq);
```

Getters

get_freq

Returns current frequency value in Hz

```
inline float get_freq() { return freq_; }
```

```
#include "daisysp.h"
#include "daisy seed.h"
using namespace daisysp;
static daisy_handle seed;
static phasor ramp;
static oscillator osc_sine;
static void audioCallback(float *in, float *out, size_t size)
    float sine, freq;
    for (size_t i = 0; i < size; i += 2)</pre>
        // generate phasor value (0-1), and scale it between 0 and 300
        freq = ramp.process()*300;
        osc_sine.set_freq(freq);
        sine = osc_sine.process();
        // left out
        out[i] = sine;
        // right out
        out[i+1] = sine;
    }
}
```

```
int main(void)
{
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    // initialize phasor module
    ramp.init(DSY_AUDIO_SAMPLE_RATE, 1, 0);
    // set parameters for sine oscillator object
    osc_sine.init(DSY_AUDIO_SAMPLE_RATE);
    osc_sine.set_waveform(oscillator::WAVE_SIN);
    osc_sine.set_freq(100);
    osc_sine.set_amp(0.25);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
}
```

pitchshift

From ucsd.edu "Pitch Shifting" t = 1 - ((s f) / R) where: s is the size of the delay f is the frequency of the Ifo r is the samplerate solving for t = 12.0 f = (12 - 1) 48000 / SHIFT_BUFFER_SIZE; Shift can be 30-100 ms lets just start with 50 for now. 0.050 * SR = 2400 samples (at 48kHz) First process delay mod/crossfade Handle Delay Writing Modulate Delay Lines Ifo stuff pitch stuff

```
// Example that takes the mono input from channel 1 (left input),
// and pitchshifts it up 1 octave.
// The left output will be pitchshifteed, while the right output
// stays will be the unshifted left input.
#include "daisysp.h"
#include "daisy seed.h"
// Defines for Interleaved Audio
#define LEFT (i)
#define RIGHT (i+1)
using namespace daisysp;
daisy handle seed;
pitchshifter ps;
static void audioCallback(float *in, float *out, size_t size)
{
    float shifted, unshifted;
    for (size t i = 0; i < size; i += 2)</pre>
    {
        unshifted = in[LEFT];
        shifted = ps.process(unshifted);
        out[LEFT] = shifted;
        out[RIGHT] = unshifted;
    }
```

```
int main(void)
{
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);

ps.init(DSY_AUDIO_SAMPLE_RATE);
    // set transposition 1 octave up (12 semitones)
    ps.set_transposition(12.0f);

    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);

    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);

while(1) {}
}
```

pluck

Produces a naturally decaying plucked string or drum sound based on the Karplus-Strong algorithms.

This code has been extracted from the Csound opcode "pluck" It has been modified to work as a Daisy Soundpipe module.

Original Author(s): Barry Vercoe, John ffitch

Year: 1991

Location: OOps/ugens4.c

Mode

The method of natural decay that the algorithm will use.

- RECURSIVE: 1st order recursive filter, with coefs .5.
- · WEIGHTED_AVERAGE: weighted averaging.

```
enum
{
    PLUCK_MODE_RECURSIVE,
    PLUCK_MODE_WEIGHTED_AVERAGE,
};
```

init

Initializes the Pluck module.

Arguments:

- sample_rate: Sample rate of the audio engine being run.
- · buf: buffer used as an impulse when triggering the pluck algorithm
- · npt: number of elementes in buf.
- · mode: Sets the mode of the algorithm.

```
void init (float sample_rate, float *buf, int32_t npt, int32_t mode);
```

process

Processes the waveform to be generated, returning one sample. This should be called once per sample period.

```
float process (float &trig);
```

Mutators

set_amp

Sets the amplitude of the output signal.

```
Input range: 0-1?
```

```
inline void set_amp(float amp) { amp_ = amp; }
```

set_freq

Sets the frequency of the output signal in Hz.

Input range: Any positive value

```
inline void set_freq(float freq) { freq_ = freq; }
```

set_decay

Sets the time it takes for a triggered note to end in seconds.

```
Input range: 0-1
```

```
inline void set_decay(float decay) { decay_ = decay; }
```

set_damp

Sets the dampening factor applied by the filter (based on PLUCK_MODE)

```
Input range: 0-1
```

```
inline void set_damp(float damp) { damp_ = damp; }
```

set_mode

Sets the mode of the algorithm.

```
inline void set_mode(int32_t mode) { mode_ = mode; }
Accessors
get_amp
Returns the current value for amp.
         inline float get_amp() { return amp_; }
get_freq
Returns the current value for freq.
         inline float get_freq() { return freq_; }
get_decay
Returns the current value for decay.
         inline float get decay() { return decay ; }
get_damp
Returns the current value for damp.
         inline float get_damp() { return damp_; }
get_mode
Returns the current value for mode.
         inline int32_t get_mode() { return mode_; }
Example
#include "daisysp.h"
#include "daisy_seed.h"
#include <algorithm>
// Shortening long macro for sample rate
```

```
#ifndef SAMPLE_RATE
#define SAMPLE RATE DSY AUDIO SAMPLE RATE
#endif
// Interleaved audio definitions
#define LEFT (i)
#define RIGHT (i+1)
using namespace daisysp;
static daisy_handle seed;
// Helper Modules
static metro tick;
static pluck plk;
// MIDI note numbers for a major triad
const float arpeggio[3] = { 48.0f, 52.0f, 55.0f };
uint8_t arp_idx;
static void audioCallback(float *in, float *out, size_t size)
    float sig_out, freq, trig;
    for (size_t i = 0; i < size; i += 2)</pre>
        // When the metro ticks:
        // advance the arpeggio, and trigger the pluck.
        trig = 0.0f;
        if (tick.process())
        {
            freq = mtof(arpeggio[arp_idx]); // convert midi nn to frequency.
            arp_idx = (arp_idx + 1) % 3; // advance the arpeggio, wrapping at the
            plk.set_freq(freq);
            trig = 1.0f;
        sig_out = plk.process(trig);
        // Output
        out[LEFT] = sig_out;
```

```
out[RIGHT] = sig_out;
   }
}
int main(void)
{
    float init_buff[256]; // buffer for pluck impulse
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    // Set up metro to pulse every second
    tick.init(1.0f, SAMPLE_RATE);
    // Set up pluck algo
    plk.init(SAMPLE_RATE, init_buff, 256, PLUCK_MODE_RECURSIVE);
    plk.set_decay(0.95f);
    plk.set_damp(0.9f);
    plk.set_amp(0.3f);
    arp_idx = 0;
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
}
```

port

Applies portamento to an input signal. At each new step value, the input is low-pass filtered to move towards that value at a rate determined by ihtim. ihtim is the half-time of the function (in seconds), during which the curve will traverse half the distance towards the new value, then half as much again, etc., theoretically never reaching its asymptote.

This code has been ported from Soundpipe to DaisySP by Paul Batchelor.

The Soundpipe module was extracted from the Csound opcode "portk".

Original Author(s): Robbin Whittle, John ffitch

Year: 1995, 1998

Location: Opcodes/biquad.c

init

Initializes port module

Arguments:

- · sample_rate: sample rate of audio engine
- · htime: half-time of the function, in seconds.

```
void init(float sample_rate, float htime);
```

process

Applies portamento to input signal and returns processed signal.

```
float process(float in);
```

Setters

set_htime

Sets htime

```
inline void set_htime(float htime) { htime_ = htime; }
```

Getters

```
get_htime
```

returns current value of htime

```
inline float get_htime() { return htime_; }
```

```
#include "daisysp.h"
#include "daisy_seed.h"
using namespace daisysp;
static daisy_handle seed;
static port slew;
static metro clock;
static oscillator osc_sine;
float freq;
static void audioCallback(float *in, float *out, size_t size)
    float sine, slewed_freq;
    uint8_t tic;
    for (size_t i = 0; i < size; i += 2)</pre>
        tic = clock.process();
        if (tic)
        {
            freq = rand() \% 500;
        }
        slewed_freq = slew.process(freq);
        osc_sine.set_freq(slewed_freq);
        sine = osc_sine.process();
```

```
// left out
        out[i] = sine;
        // right out
        out[i+1] = sine;
    }
}
int main(void)
{
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    // set params for port object
    slew.init(DSY_AUDIO_SAMPLE_RATE, .09);
    clock.init(1, DSY_AUDIO_SAMPLE_RATE);
    // set parameters for sine oscillator object
    osc_sine.init(DSY_AUDIO_SAMPLE_RATE);
    osc_sine.set_waveform(oscillator::WAVE_SIN);
    osc_sine.set_freq(100);
    osc_sine.set_amp(0.25);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
}
```

reverbsc

```
Stereo Reverb
Ported from soundpipe
example:
daisysp/modules/examples/ex_reverbsc
init
Initializes the reverb module, and sets the samplerate at which the process function will be
called.
     int init(float samplerate);
process
process the input through the reverb, and updates values of out1, and out2 with the new
processed signal.
     int process(const float &in1, const float &in2, float *out1, float *out2);
set feedabck
controls the reverb time. reverb tail becomes infinite when set to 1.0
range: 0.0 to 1.0
     inline void set_feedback(const float &fb) { _feedback = fb; }
```

set_lpfreq

controls the internal dampening filter's cutoff frequency.

```
range: 0.0 to samplerate / 2
```

```
inline void set_lpfreq(const float &freq) { _lpfreq = freq; }
```

```
#include "daisysp.h"
```

```
#include "daisy_seed.h"
using namespace daisysp;
static daisy_handle seed;
reverbsc verb;
static void audioCallback(float *in, float *out, size_t size)
    for (size_t i = 0; i < size; i += 2)</pre>
    {
        verb.process(in[i], in[i+1], &out[i], &out[i+1]);
}
int main(void)
    // initialize seed hardware and whitenoise daisysp module
    daisy_seed_init(&seed);
    verb.init(DSY_AUDIO_SAMPLE_RATE);
    verb.set_feedback(0.85f);
    verb.set_lpfreq(18000.0f);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
}
```

svf

```
Double Sampled, Stable State Variable Filter
```

Credit to Andrew Simper from musicdsp.org

This is his "State Variable Filter (Double Sampled, Stable)"

Additional thanks to Laurent de Soras for stability limit, and Stefan Diedrichsen for the correct notch output

Ported by: Stephen Hensley

example: daisysp/examples/svf/

init

Initializes the filter

float samplerate - sample rate of the audio engine being run, and the frequency that the process function will be called.

```
void init(float samplerate);
```

process

Process the input signal, updating all of the outputs.

```
void process(float in);
```

Setters

set_freq

sets the frequency of the cutoff frequency.

f must be between 0.0 and samplerate / 2

```
void set_freq(float f);
```

set res

sets the resonance of the filter.

Must be between 0.0 and 1.0 to ensure stability.

```
void set_res(float r);
```

set_drive

sets the drive of the filter, affecting the response of the resonance of the filter.

```
inline void set_drive(float d) { _drive = d; }
```

Filter Outputs

Lowpass Filter

```
inline float low() { return _out_low; }
```

Highpass Filter

```
inline float high() { return _out_high; }
```

Bandpass Filter

```
inline float band() { return _out_band; }
```

Notch Filter

```
inline float notch() { return _out_notch; }
```

Peak Filter

```
inline float peak() { return _out_peak; }
```

```
#include "daisysp.h"
#include "daisy_seed.h"
using namespace daisy;
using namespace daisysp;
```

```
static daisy_handle seed;
oscillator osc;
svf filt;
static void audioCallback(float *in, float *out, size_t size)
    float sig;
    for (size t i = 0; i < size; i += 2)</pre>
    {
        sig = osc.process();
        filt.process(sig);
        // left out
        out[i] = filt.low();
        // right out
        out[i + 1] = filt.high();
    }
}
int main(void)
{
    // initialize seed hardware and suf daisysp module
    daisy_seed_init(&seed);
    // Initialize Oscillator, and set parameters.
    osc.init(DSY_AUDIO_SAMPLE_RATE);
    osc.set_waveform(osc.WAVE_POLYBLEP_SAW);
    osc.set_freq(250.0);
    osc.set_amp(0.5);
    // Initialize Filter, and set parameters.
    filt.init(DSY_AUDIO_SAMPLE_RATE);
    filt.set_freq(500.0);
    filt.set res(0.85);
    filt.set_drive(0.8);
```

```
// define callback
dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
dsy_adc_start();

// start callback
dsy_audio_start(DSY_AUDIO_INTERNAL);
while(1) {}
}
```

tone

A first-order recursive low-pass filter with variable frequency response.

init

Initializes the tone module.

sample_rate - The sample rate of the audio engine being run.

```
void init(float sample_rate);
```

process

Processes one sample through the filter and returns one sample.

in - input signal

```
float process(float &in);
```

Setters

set_freq

Sets the cutoff frequency or half-way point of the filter.

Arguments

· freq - frequency value in Hz. Range: Any positive value.

```
inline void set_freq(float &freq)
```

Getters

get_freq

Returns the current value for the cutoff frequency or half-way point of the filter.

```
inline float get_freq() { return freq_; }
```

```
#include "daisysp.h"
```

```
#include "daisy_seed.h"
using namespace daisysp;
static daisy_handle seed;
static tone flt;
static oscillator osc, lfo;
static void audioCallback(float *in, float *out, size_t size)
    float saw, freq, output;
    for (size_t i = 0; i < size; i += 2)</pre>
    {
        freq = 2500 + (lfo.process()*2500);
        saw = osc.process();
        flt.set freq(freq);
        output = flt.process(saw);
        // left out
        out[i] = output;
        // right out
        out[i+1] = output;
    }
}
int main(void)
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    // initialize tone object
    flt.init(DSY_AUDIO_SAMPLE_RATE);
    // set parameters for sine oscillator object
    lfo.init(DSY_AUDIO_SAMPLE_RATE);
    lfo.set_waveform(oscillator::WAVE_TRI);
```

```
lfo.set_amp(1);
lfo.set_freq(.4);

// set parameters for sine oscillator object
osc.init(DSY_AUDIO_SAMPLE_RATE);
osc.set_waveform(oscillator::WAVE_POLYBLEP_SAW);
osc.set_freq(100);
osc.set_amp(0.25);

// define callback
dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);

// start callback
dsy_audio_start(DSY_AUDIO_INTERNAL);
while(1) {}
}
```

whitenoise

fast white noise generator I think this came from musicdsp.org at some point

init

Initializes the whitenoise object

```
void init()
```

set_amp

sets the amplitude of the noise output

```
inline void set_amp(float a) { amp = a; }
```

process

returns a new sample of noise in the range of -amp to amp

```
inline float process()
```

```
#include "daisysp.h"
#include "daisy_seed.h"

using namespace daisysp;

static daisy_handle seed;
static whitenoise nse;

static void audioCallback(float *in, float *out, size_t size)
{
    float sig;

    for (size_t i = 0; i < size; i += 2)
        {
        sig = nse.process();
    }
}</pre>
```

```
// left out
        out[i] = sig;
        // right out
        out[i + 1] = sig;
    }
}
int main(void)
{
    // initialize seed hardware and whitenoise daisysp module
    daisy_seed_init(&seed);
    nse.init();
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
}
```