DaisySP

Contents

adenv													6
	Envelope Segments												6
	init												6
	process												6
	trigger												7
Mut	ators												7
	setsegment_time_												7
	setcurve_scalar												7
	set_min												7
	set_max												7
$Acc\epsilon$	essors												7
	current_segment .												7
	is_running												7
Exai	mple												8
compre	essor												10
	init												10
	process												10
sette	ers												10
	set_ratio												10
	$set_threshold \dots$												11
	set_attack												11
	set_release												11
Exai	mple												11
crossfa													14
Curv	ve Options	 •											14
	init												14
	process												14
Sette	ers												15
	set_pos												15
	set_curve												15
Gett	ers												15
	get nos												15

get_curve	
Example	. 10
dcblock	18
init	. 18
process	. 18
Example	. 18
decimator	20
init	. 20
process	
Mutators	
set downsample factor	
set_bitcrush_factor	
set bits to crush	
Accessors	
get_downsample_factor	
get_bitcrush_factor	
Example	
Example	. 21
delayline	23
init	. 23
reset	. 23
set_delay	. 23
write	. 23
read	. 23
Example	. 24
core dsp	27
Generic Defines	. 27
fast helpers	
fmax/fmin	
fclamp	
fastpower and fastroot	
mtof	
Filters	
fonepole	
median	_
Quick Effects	
Soft Saturate	
Example	
Example	. 29
line	30
init	
process	. 30

	start	30
	Example	30
me		32
		32
	1	32
		32
		32
	= 1	32
		32
	$\circ = 1$	32
	Example	32
nlfi	14	35
11111		3 5
		35
	1	
		35
	_	35
		35
	Example	36
റടറ	illator	39
		39
		39
		40
		40
		40
	r	40
	Example	40
റടറ	illator	42
		42
		42
		43
	= 1	43
	_ I	43
	-	43
	r	43
	Example	45
pha	sor	44
r		44
		44
	r	44
		44
		44
		44
	get_freq	44

	Example																											45
pit	chshift Example				 •														•				•			•		47 47
nlı	ıck																											49
Ρ	Mode																											49
	init																											49
	process																											49
	Mutators																											49
	set amp.																											49
	set_amp.																											50
	set_freq .																											50
	set_decay																											50
	set_damp set_mode																											50
	Accessors																											50
																												50
	get_amp.																											50
	get_freq .																											50
	get_decay get_damp																											51
	0 = 1																											51
	get_mode																											51
	Example	•	 •	•	 •	•	•	•	•	•		•	•	٠	•	•	•	•	•	•	•	•	•	•	•	•	•	91
po	rt																											53
Р	init																											53
	process																											53
	Setters																											53
	set htime																											53
	Getters																											53
	get_htime																											53
	Example																											54
	Example	•	 •	•	 •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	01
re	verbsc																											56
	init																											56
	process																											56
	set_feedab																											56
	set lpfreq																											56
	Example																											56
	. r																											
\mathbf{sv}	f																											58
	$init \dots$																											58
	process																											58
	Setters																											58
	$\operatorname{set_freq}$.																											58
	set_res .																											58
	set_drive																											58

	Filter Outputs																59
	Lowpass Filter																59
	Highpass Filter																59
	Bandpass Filter																59
	Notch Filter																59
	Peak Filter																59
	Example																59
to	ne																61
	init																61
	process																61
	Setters																61
	set_freq .																61
	Getters																61
	get_freq .																61
	Example																61
wł	nitenoise																64
	$init \dots$																64
	set_amp .																64
	process																64
	Evample																64

adenv

Author: shensley

Trigger-able envelope with adjustable min/max, and independent per-segment time control.

TODO:

- Add Cycling
- Implement Curve (its only linear for now).
- Maybe make this an ADsr_ that has AD/AR/Asr_ modes.

Envelope Segments

Distinct stages that the phase of the envelope can be located in.

- IDLE = located at phase location 0, and not currently running
- DECAY = Second segment of envelope where phase moves from MAX to MIN value
- LAST = The final segment of the envelope (currently decay)

```
enum {
          ADENV_SEG_IDLE,
          ADENV_SEG_ATTACK,
          ADENV_SEG_DECAY,
          ADENV_SEG_LAST,
};
```

init

Initializes the ad envelope

float sample_rate - sample rate of the audio engine being run.

Defaults

```
    current segment = idle
    curve = linear
    phase = 0
    min = 0
    max = 1
```

```
void init(float sample rate);
```

process

processes the current sample of the envelope. Returns the current envelope value. This should be called once per sample period.

```
float process();
trigger
Starts or retriggers the envelope.
        inline void trigger() {trigger_ = 1; }
Mutators
setsegment_time_
Sets the length of time(secondsVERIFYTHIS) for a specific segment.
        inline void set_time(uint8_t seg, float time)
setcurve\_scalar\_
Sets the amount of curve applied. Input range: -1 to 1. - At -1, curve = full
logarithmic - At 1, curve = full exponential - At 0, curve = linear
        inline void set_curve_scalar(float scalar) { curve_scalar_ = scalar; }
set\_min
Sets the minimum value of the envelope output Input range: -FLTmax_, to
FLTmax
        inline void set_min(float min) {min_ = min; }
set\_max
Sets the maximum value of the envelope output Input range: -FLTmax , to
FLTmax
        inline void set_max(float max) {max_ = max; }
Accessors
current_segment
Returns the segment of the envelope that the phase is currently located in.
        inline uint8_t get_current_segment() { return current_segment_; }
is_running
Returns true if the envelope is currently in any stage apart from idle.
        inline bool is_running() const { return current_segment_ != ADENV_SEG_IDLE; }
```

```
#include "daisysp.h"
#include "daisy_seed.h"
// Shortening long macro for sample rate
#ifndef SAMPLE_RATE
#define SAMPLE_RATE DSY_AUDIO_SAMPLE_RATE
#endif
// Interleaved audio definitions
#define LEFT (i)
#define RIGHT (i+1)
using namespace daisysp;
static daisy_handle seed;
static adenv env;
static oscillator osc;
static metro tick;
static void audioCallback(float *in, float *out, size_t size)
    float osc_out, env_out;
    for (size_t i = 0; i < size; i += 2)</pre>
        // When the metro ticks, trigger the envelope to start.
        if (tick.process())
        {
            env.trigger();
        // Use envelope to control the amplitude of the oscillator.
        env_out = env.process();
        osc.set_amp(env_out);
        osc_out = osc.process();
        out[LEFT] = osc_out;
        out[RIGHT] = osc_out;
   }
}
int main(void)
    // initialize seed hardware and daisysp modules
```

```
daisy_seed_init(&seed);
env.init(SAMPLE_RATE);
osc.init(SAMPLE_RATE);
// Set up metro to pulse every second
tick.init(1.0f, SAMPLE_RATE);
// set adenv parameters
env.set_time(ADENV_SEG_ATTACK, 0.15);
env.set_time(ADENV_SEG_DECAY, 0.35);
env.set_min(0.0);
env.set_max(0.25);
env.set_curve_scalar(0); // linear
// Set parameters for oscillator
osc.set_waveform(osc.WAVE_TRI);
osc.set_freq(220);
osc.set_amp(0.25);
// define callback
dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
// start callback
dsy_audio_start(DSY_AUDIO_INTERNAL);
while(1) {}
```

}

compressor

influenced by compressor in soundpipe (from faust).

Modifications made to do:

- Less calculations during each process loop (coefficients recalculated on parameter change).
- C++-ified
- added sidechain support

TODO:

- With fixed controls this is relatively quick, but changing controls now costs a lot more
- Still pretty expensive
- Add soft/hard knee settings
- Maybe make stereo possible? (needing two for stereo is a bit silly, and their gain shouldn't be totally unique.

by: shensley

init

```
Initializes compressor
```

samplerate - rate at which samples will be produced by the audio engine.

```
void init(float samplerate);
```

process

```
compresses the audio input signal, either keyed by itself, or a secondary input.
```

```
in - audio input signal (to be compressed)
```

(optional) key - audio input that will be used to side-chain the compressor.

```
float process(float &in, float &key);
float process(float &in);
```

setters

set_ratio

amount of gain reduction applied to compressed signals

```
Expects 1.0 \rightarrow 40. (untested with values < 1.0)
```

```
void set_ratio(const float &ratio)
```

```
set\_threshold
threshold in dB at which compression will be applied
Expects 0.0 -> -80.
    void set_threshold(const float &thresh)
set\_attack
envelope time for onset of compression for signals above the threshold.
Expects 0.001 -> 10
    void set_attack(const float &atk)
set\_release
envelope time for release of compression as input signal falls below threshold.
Expects 0.001 -> 10
    void set_release(const float &rel)
Example
#include "daisysp.h"
#include "daisy_seed.h"
// Shortening long macro for sample rate
#ifndef SAMPLE_RATE
#define SAMPLE_RATE DSY_AUDIO_SAMPLE_RATE
#endif
// Interleaved audio definitions
#define LEFT (i)
#define RIGHT (i+1)
using namespace daisysp;
static daisy_handle seed;
static compressor comp;
// Helper Modules
static adenv env;
static oscillator osc_a, osc_b;
```

static metro tick;

```
static void audioCallback(float *in, float *out, size_t size)
{
    float osc_a_out, osc_b_out, env_out, sig_out;
    for (size_t i = 0; i < size; i += 2)</pre>
        // When the metro ticks:
        // trigger the envelope to start
        if (tick.process())
            env.trigger();
        }
        // Use envelope to control the amplitude of the oscillator.
        env out = env.process();
        osc_a.set_amp(env_out);
        osc_a_out = osc_a.process();
        osc_b_out = osc_b.process();
        // Compress the steady tone with the enveloped tone.
        sig_out = comp.process(osc_b_out, osc_a_out);
        // Output
        out[LEFT] = sig_out; // compressed
        out[RIGHT] = osc_a_out; // key signal
    }
}
int main(void)
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    comp.init(SAMPLE_RATE);
    env.init(SAMPLE_RATE);
    osc a.init(SAMPLE RATE);
    osc_b.init(SAMPLE_RATE);
    // Set up metro to pulse every second
    tick.init(1.0f, SAMPLE_RATE);
    // set compressor parameters
    comp.set_threshold(-64.0f);
    comp.set_ratio(2.0f);
    comp.set_attack(0.005f);
    comp.set_release(0.1250);
    // set adenv parameters
    env.set_time(ADENV_SEG_ATTACK, 0.001);
```

```
env.set_time(ADENV_SEG_DECAY, 0.50);
    env.set_min(0.0);
    env.set_max(0.25);
    env.set_curve_scalar(0); // linear
    // Set parameters for oscillator
    osc_a.set_waveform(oscillator::WAVE_TRI);
    osc_a.set_freq(110);
    osc_a.set_amp(0.25);
    osc_b.set_waveform(oscillator::WAVE_TRI);
    osc_b.set_freq(220);
    osc_b.set_amp(0.25);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
}
```

crossfade

Performs a crossfade between two signals

Original author: Paul Batchelor

Ported from Soundpipe by Andrew Ikenberry added curve option for constant power, etc.

TODO:

- implement exponential curve process
- implement logarithmic curve process

Curve Options

Curve applied to the crossfade

```
LIN = linear
CPOW = constant power
LOG = logarithmic
EXP exponential
LAST = end of enum (used for array indexing)
enum
CROSSFADE_LIN,
        CROSSFADE_CPOW,
        CROSSFADE_LOG,
        CROSSFADE_LAST,
        };
```

init

Initializes crossfade module

Defaults

```
current position = .5curve = linearinline void init()
```

process

processes crossfade and returns single sample

```
float process(float &in1, float &in2);
```

```
Setters
set\_pos
Sets position of crossfade between two input signals
Input range: 0 to 1
        inline void set_pos(float pos) { pos_ = pos; }
set_curve
Sets current curve applied to crossfade
Expected input: See Curve Options
        inline void set_curve(uint8_t curve) { curve_ = curve; }
Getters
get_pos
Returns current position
        inline float get_pos(float pos) { return pos_; }
get_curve
Returns current curve
        inline uint8_t get_curve(uint8_t curve) { return curve_; }
Example
#include "daisysp.h"
#include "daisy_seed.h"
using namespace daisysp;
static daisy_handle seed;
static crossfade cfade;
static oscillator osc_sine, osc_saw, lfo;
static void audioCallback(float *in, float *out, size_t size)
    float saw, sine, pos, output;
    for (size_t i = 0; i < size; i += 2)</pre>
        sine = osc_sine.process();
        saw = osc_saw.process();
```

```
// lfo output = -1 to 1
        pos = lfo.process();
        // scale signal between 0 and 1
        pos = (pos + 1) / 2;
        cfade.set_pos(pos);
        output = cfade.process(sine, saw);
        // left out
        out[i] = output;
        // right out
        out[i+1] = output;
   }
}
int main(void)
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    // set params for crossfade object
    cfade.init();
    cfade.set_curve(CROSSFADE_LIN);
    // set parameters for sine oscillator object
    osc_sine.init(DSY_AUDIO_SAMPLE_RATE);
    osc_sine.set_waveform(oscillator::WAVE_SIN);
    osc sine.set freq(100);
    osc_sine.set_amp(0.25);
    // set parameters for sawtooth oscillator object
    osc_saw.init(DSY_AUDIO_SAMPLE_RATE);
    osc_saw.set_waveform(oscillator::WAVE_POLYBLEP_SAW);
    osc_saw.set_freq(100);
    osc_saw.set_amp(0.25);
    // set parameters for triangle lfo oscillator object
    lfo.init(DSY_AUDIO_SAMPLE_RATE);
    lfo.set_waveform(oscillator::WAVE_TRI);
    lfo.set_freq(.25);
    lfo.set_amp(1);
    // define callback
```

```
dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);

// start callback
dsy_audio_start(DSY_AUDIO_INTERNAL);

while(1) {}
}
```

dcblock

```
Removes DC component of a signal
init
Initializes dcblock module
        void init(float sample_rate);
process
performs deblock process
        float process(float in);
Example
#include "daisysp.h"
#include "daisy_seed.h"
using namespace daisysp;
static daisy_handle seed;
static dcblock block;
static oscillator osc_sine;
static void audioCallback(float *in, float *out, size_t size)
    float output;
    for (size_t i = 0; i < size; i += 2)</pre>
        output = osc_sine.process();
        // add dc to signal
        output += 1;
        // remove dc from signal
        output = block.process(output);
        // left out
        out[i] = output;
        // right out
        out[i+1] = output;
    }
}
```

```
int main(void)
{
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    block.init(DSY_AUDIO_SAMPLE_RATE);
    // set parameters for sine oscillator object
    osc_sine.init(DSY_AUDIO_SAMPLE_RATE);
    osc_sine.set_waveform(oscillator::WAVE_SIN);
    osc_sine.set_freq(100);
    osc_sine.set_amp(0.25);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
}
```

decimator

Performs downsampling and bitcrush effects

```
init
```

```
Initializes downsample module
```

```
void init();
```

process

Applies downsample and bitcrush effects to input signal. Returns one sample. This should be called once per sample period.

```
float process(float input);
```

Mutators

```
set_downsample_factor
```

Sets amount of downsample Input range:

```
inline void set_downsample_factor(float downsample_factor)
```

$set_bitcrush_factor$

Sets amount of bitcrushing Input range:

```
inline void set_bitcrush_factor(float bitcrush_factor)
```

$set_bits_to_crush$

Sets the exact number of bits to crush

0-16 bits

```
inline void set_bits_to_crush(const uint8_t &bits)
```

Accessors

```
get\_downsample\_factor
```

Returns current setting of downsample

```
inline float get_downsample_factor() { return downsample_factor_; }
```

get_bitcrush_factor

Returns current setting of bitcrush

```
inline float get_bitcrush_factor() { return bitcrush_factor_; }
```

```
#include "daisysp.h"
#include "daisy_seed.h"
// Shortening long macro for sample rate
#ifndef SAMPLE_RATE
#define SAMPLE_RATE DSY_AUDIO_SAMPLE_RATE
#endif
// Interleaved audio definitions
#define LEFT (i)
#define RIGHT (i+1)
using namespace daisysp;
static daisy_handle seed;
static oscillator osc;
static decimator decim;
static phasor phs;
static void audioCallback(float *in, float *out, size_t size)
    float osc_out, decimated_out;
    float downsample amt;
    for (size_t i = 0; i < size; i += 2)</pre>
    {
        // Generate a pure sine wave
        osc_out = osc.process();
        // Modulate downsample amount via phasor
        downsample_amt = phs.process();
        decim.set_downsample_factor(downsample_amt);
        // downsample and bitcrush
        decimated_out = decim.process(osc_out);
        // outputs
        out[LEFT] = decimated_out;
        out[RIGHT] = decimated_out;
    }
}
int main(void)
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    osc.init(SAMPLE_RATE);
```

```
phs.init(SAMPLE_RATE, 0.5f);
decim.init();

// Set parameters for oscillator
osc.set_waveform(osc.WAVE_SIN);
osc.set_freq(220);
osc.set_amp(0.25);
// Set downsampling, and bit crushing values.
decim.set_downsample_factor(0.4f);
decim.set_bits_to_crush(8);

// define callback
dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
// start callback
dsy_audio_start(DSY_AUDIO_INTERNAL);
while(1) {}
}
```

delayline

```
Simple Delay line.
November 2019
Converted to Template December 2019
declaration example: (1 second of floats)
delayline<float, SAMPLE_RATE> del;
By: shensley
init
initializes the delay line by clearing the values within, and setting delay to 1
sample.
    void init()
reset
clears buffer, sets write ptr to 0, and delay to 1 sample.
    void reset() {
set_delay
sets the delay time in samples
If a float is passed in, a fractional component will be calculated for interpolating
the delay line.
    inline void set_delay(size_t delay)
    inline void set_delay(float delay)
write
writes the sample of type T to the delay line, and advances the write ptr
    inline void write(const T sample)
read
returns the next sample of type T in the delay line, interpolated if necessary.
    inline const T read() const
```

```
#include "daisysp.h"
#include "daisy_seed.h"
// Shortening long macro for sample rate
#ifndef SAMPLE RATE
#define SAMPLE_RATE DSY_AUDIO_SAMPLE_RATE
#endif
// Interleaved audio definitions
#define LEFT (i)
#define RIGHT (i+1)
// Set max delay time to 0.75 of samplerate.
#define MAX_DELAY static_cast<size_t>(SAMPLE_RATE * 0.75f)
using namespace daisysp;
static daisy_handle seed;
// Helper Modules
static adenv env;
static oscillator osc;
static metro tick;
// Declare a delayline of {\it MAX\_DELAY} number of floats.
static delayline<float, MAX_DELAY> del;
static void audioCallback(float *in, float *out, size_t size)
    float osc_out, env_out, feedback, del_out, sig_out;
    for (size_t i = 0; i < size; i += 2)</pre>
    {
        // When the metro ticks:
        // trigger the envelope to start, and change freq of oscillator.
        if (tick.process())
            float freq = rand() % 200;
            osc.set_freq(freq + 100.0f);
            env.trigger();
        // Use envelope to control the amplitude of the oscillator.
        env_out = env.process();
```

```
osc.set_amp(env_out);
        osc_out = osc.process();
        // Read from delay line
        del_out = del.read();
        // Calculate output and feedback
        sig_out = del_out + osc_out;
        feedback = (del_out * 0.75f) + osc_out;
        // Write to the delay
        del.write(feedback);
        // Output
        out[LEFT] = sig out;
        out[RIGHT] = sig_out;
}
int main(void)
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    env.init(SAMPLE_RATE);
    osc.init(SAMPLE_RATE);
    del.init();
    // Set up metro to pulse every second
   tick.init(1.0f, SAMPLE_RATE);
    // set adenv parameters
    env.set_time(ADENV_SEG_ATTACK, 0.001);
    env.set_time(ADENV_SEG_DECAY, 0.50);
    env.set min(0.0);
    env.set_{max}(0.25);
    env.set_curve_scalar(0); // linear
    // Set parameters for oscillator
    osc.set_waveform(osc.WAVE_TRI);
    osc.set_freq(220);
    osc.set_amp(0.25);
    // Set Delay time to 0.75 seconds
    del.set_delay(SAMPLE_RATE * 0.75f);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
```

```
// start callback
dsy_audio_start(DSY_AUDIO_INTERNAL);
while(1) {}
}
```

core dsp

helper defines, functions for use in/with daisysp modules.

Generic Defines

```
For now just PIs
#define PI_F 3.1415927410125732421875f
#define TWOPI_F (2.0f * PI_F)
#define HALFPI_F (PI_F * 0.5f)
fast helpers
fmax/fmin
efficient floating point min/max
c/o stephen mccaul
inline float fmax(float a, float b)
inline float fmin(float a, float b)
fclamp
quick fp clamp
inline float fclamp(float in, float min, float max)
fastpower and fastroot
From Musicdsp.org "Fast power and root estimates for 32bit floats)
Original code by Stefan Stenzel
These are approximations
inline float fastpower(float f, int n)
inline float fastroot(float f, int n)
mtof
Midi to frequency helper
inline float mtof(float m)
    return powf(2, (m - 69.0f) / 12.0f) * 440.0f;
}
```

Filters

fonepole

```
one pole lpf
out is passed by reference, and must be retained between calls to properly filter
the signal
coeff can be calculated:
coeff = 1.0 / (time * samplerate); where time is in seconds
inline void fonepole(float &out, float in, float coeff)
median
Simple 3-point median filter
```

Quick Effects

c/o stephen mccaul

template <typename T>
T median(T a, T b, T c)

Soft Saturate

Based on soft saturate from:

musicdsp.org

Bram de Jong (2002-01-17)

This still needs to be tested/fixed. Definitely does some weird stuff

```
described as:
```

```
x < a:
    f(x) = x
x > a:
    f(x) = a + (x-a)/(1+((x-a)/(1-a))^2)
x > 1:
    f(x) = (a + 1)/2
inline float soft_saturate(float in, float thresh)
```

Example

No example Provided dsy_pstream.h Ported from Csound - October 2019

(c) Richard Dobson August 2001 NB pvoc routines based on CARL distribution(Mark Dolson). This file is licensed according to the terms of the GNU LGPL.

Definitions from Csound: pvsanal pvsfread pvsynth pvsadsyn pvscross pvsmaska = (overloaded, – should probably just pvsset(&src, &dest))

More or less for starting purposes we really only need pvsanal, and pvsynth to get started

Example

No example Provided

line

creates a line segment signal

init

Initializes line module.

```
void init(float sample_rate);
```

process

Processes line segment. Returns one sample.

value of finished will be updated to a 1, upon completion of the line's trajectory.

```
float process(uint8_t *finished);
```

start

Begin creation of line.

Arguments:

- start beginning value
- end ending value
- dur duration in seconds of line segment

```
void start(float start, float end, float dur);
```

```
#include "daisysp.h"
#include "daisy_seed.h"

using namespace daisysp;

static daisy_handle seed;
static line line_seg;
static oscillator osc_sine;

uint8_t finished;

static void audioCallback(float *in, float *out, size_t size)
{
    float sine, freq;
    for (size_t i = 0; i < size; i += 2)
    {
        if (finished)</pre>
```

```
{
            // start creating a line segment from 100 to 500 in 1 seconds
            line_seg.start(100, 500, 1);
        }
        freq = line_seg.process(&finished);
        osc_sine.set_freq(freq);
        sine = osc_sine.process();
        // left out
        out[i] = sine;
        // right out
        out[i+1] = sine;
    }
}
int main(void)
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    // initialize line module
    line_seg.init(DSY_AUDIO_SAMPLE_RATE);
    finished = 1;
    // set parameters for sine oscillator object
    osc_sine.init(DSY_AUDIO_SAMPLE_RATE);
    osc_sine.set_waveform(oscillator::WAVE_SIN);
    osc_sine.set_freq(100);
    osc_sine.set_amp(0.25);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
}
```

metro

Creates a clock signal at a specific frequency.

init

Initializes metro module.

Arguments: - freq: frequency at which new clock signals will be generated Input Range: - sample_rate: sample rate of audio engine Input range:

```
void init(float freq, float sample_rate);
```

process

checks current state of metro object and updates state if necesary.

```
uint8_t process();
```

reset

```
resets phase to 0
```

```
inline void reset() { phs_ = 0.0f; }
```

Setters

set_freq

Sets frequency at which metro module will run at.

```
void set_freq(float freq);
```

Getters

get_freq

Returns current value for frequency.

```
inline float get_freq() { return freq_; }
```

```
#include "daisysp.h"
#include "daisy_seed.h"

using namespace daisysp;

static daisy_handle seed;
static metro clock;
```

```
static oscillator osc_sine;
static void audioCallback(float *in, float *out, size_t size)
    float sine, freq;
    uint8_t tic;
   for (size_t i = 0; i < size; i += 2)</pre>
        tic = clock.process();
        if (tic)
        {
            freq = rand() % 500;
            osc_sine.set_freq(freq);
        sine = osc_sine.process();
        // left out
        out[i] = sine;
        // right out
        out[i+1] = sine;
   }
}
int main(void)
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    // initialize metro object at 2 hz
    clock.init(2, DSY_AUDIO_SAMPLE_RATE);
    // set parameters for sine oscillator object
    osc_sine.init(DSY_AUDIO_SAMPLE_RATE);
    osc_sine.set_waveform(oscillator::WAVE_SIN);
    osc_sine.set_freq(100);
    osc_sine.set_amp(0.25);
    // define callback
   dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
   while(1) {}
```

}

nlfilt

port by: stephen hensley, December 2019

Non-linear filter.

The four 5-coefficients: a, b, d, C, and L are used to configure different filter types.

Structure for Dobson/Fitch nonlinear filter

Revised Formula from Risto Holopainen 12 Mar 2004

```
Y{n} = tanh(a Y{n-1} + b Y{n-2} + d Y^2{n-L} + X{n} - C)
```

Though traditional filter types can be made, the effect will always respond differently to different input.

This Source is a heavily modified version of the original source from Csound.

TODO:

• make this work on a single sample instead of just on blocks at a time.

init

Initializes the nlfilt object.

```
void init();
```

process

Process the array pointed to by *in and updates the output to *out;

This works on a block of audio at once, the size of which is set with the size.

```
void process_block(float *in, float *out, size_t size);
```

setters

$set_coefficients$

inputs these are the five coefficients for the filter.

```
inline void set_coefficients(float a, float b, float d, float C, float L)
```

individual setters for each coefficients.

```
inline void set_a(float a) { a_ = a; }
inline void set_b(float b) { b_ = b; }
inline void set_d(float d) { d_ = d; }
inline void set_C(float C) { C_ = C; }
```

```
inline void set_L(float L) { L_ = L; }
```

```
#include "daisysp.h"
#include "daisy_seed.h"
// Shortening long macro for sample rate
#ifndef SAMPLE RATE
#define SAMPLE_RATE DSY_AUDIO_SAMPLE_RATE
#endif
// Interleaved audio definitions
#define LEFT (i)
#define RIGHT (i+1)
using namespace daisysp;
static daisy_handle seed;
// Helper Modules
static adenv env;
static oscillator osc;
static metro tick;
static nlfilt filt;
static void audioCallback(float *in, float *out, size_t size)
   // The nlfilt object currently only works on blocks of audio at a time.
    // This can be accommodated easily with an extra loop at the end.
   // We use size/2 since we only need to process mono
   float dry[size/2];
   float wet[size/2];
   float env_out;
    // loop through mono process
    for (size_t i = 0; i < size/2; i++)</pre>
        // When the metro ticks:
        // trigger the envelope to start, and change freq of oscillator.
        if (tick.process())
        {
            float freq = rand() % 150;
            osc.set_freq(freq + 25.0f);
            env.trigger();
```

```
// Use envelope to control the amplitude of the oscillator.
        env_out = env.process();
        osc.set_amp(env_out);
        dry[i] = osc.process();
    }
    // nonlinear filter
    filt.process_block(dry, wet, size/2);
    // Now write wet signal to both outputs.
    for (size_t i = 0; i < size; i+=2)</pre>
    {
        out[LEFT] = wet[i/2];
        out[RIGHT] = wet[i/2];
    }
}
int main(void)
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    env.init(SAMPLE_RATE);
    osc.init(SAMPLE_RATE);
    // Set up metro to pulse every 3 seconds
   tick.init(0.333f, SAMPLE_RATE);
    // set adenv parameters
    env.set_time(ADENV_SEG_ATTACK, 1.50);
    env.set_time(ADENV_SEG_DECAY, 1.50);
    env.set_min(0.0);
    env.set_max(0.25);
    env.set_curve_scalar(0); // linear
    // Set parameters for oscillator
    osc.set_waveform(osc.WAVE_POLYBLEP_SAW);
    // Set coefficients for non-linear filter.
    filt.set_coefficients(0.7f, -0.2f, 0.95f, 0.24f, 1000.0f);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
```

}

oscillator

```
Synthesis of several waveforms, including polyBLEP bandlimited waveforms.
example:
daisysp::oscillator osc;
init()
{
    osc.init(SAMPLE_RATE);
    osc.set_frequency(440);
    osc.set_amp(0.25);
    osc.set_waveform(WAVE_TRI);
}
callback(float *in, float *out, size_t size)
{
    for (size_t i = 0; i < size; i+=2)
    {
        out[i] = out[i+1] = osc.process();
    }
}</pre>
```

Waveforms

Choices for output waveforms, POLYBLEP are appropriately labeled. Others are naive forms.

```
enum
{
    WAVE_SIN,
    WAVE_TRI,
    WAVE_SAW,
    WAVE_RAMP,
    WAVE_SQUARE,
    WAVE_POLYBLEP_TRI,
    WAVE_POLYBLEP_SAW,
    WAVE_POLYBLEP_SQUARE,
    WAVE_LAST,
};
```

init

Initializes the oscillator

float samplerate - sample rate of the audio engine being run, and the frequency that the process function will be called.

Defaults: - freq = 100 Hz - amp = 0.5 - waveform = sine wave.

```
void init(float samplerate)
```

set_freq

Changes the frequency of the oscillator, and recalculates phase increment.

```
inline void set_freq(const float f)
```

set_amp

Sets the amplitude of the waveform.

```
inline void set_amp(const float a) { amp = a; }
```

set waveform

Sets the waveform to be synthesized by the process() function.

```
inline void set_waveform(const uint8_t wf) { waveform = wf < WAVE_LAST ? wf : WAVE_S</pre>
```

process

Processes the waveform to be generated, returning one sample. This should be called once per sample period.

```
float process();
```

```
#include "daisysp.h"
#include "daisy_seed.h"

using namespace daisysp;

static daisy_handle seed;
static oscillator osc;

static void audioCallback(float *in, float *out, size_t size)
{
    float sig;
    for (size_t i = 0; i < size; i += 2)
    {
        sig = osc.process();

        // left out
        out[i] = sig;

        // right out</pre>
```

```
out[i+1] = sig;
   }
}
int main(void)
    // initialize seed hardware and oscillator daisysp module
    daisy_seed_init(&seed);
    osc.init(DSY_AUDIO_SAMPLE_RATE);
    // Set parameters for oscillator
    osc.set_waveform(osc.WAVE_SIN);
    osc.set_freq(440);
    osc.set_amp(0.5);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
}
```

oscillator

```
Synthesis of several waveforms, including polyBLEP bandlimited waveforms.
example:
daisysp::oscillator osc;
init()
{
    osc.init(SAMPLE_RATE);
    osc.set_frequency(440);
    osc.set_amp(0.25);
    osc.set_waveform(WAVE_TRI);
}
callback(float *in, float *out, size_t size)
{
    for (size_t i = 0; i < size; i+=2)
    {
        out[i] = out[i+1] = osc.process();
    }
}</pre>
```

Waveforms

Choices for output waveforms, POLYBLEP are appropriately labeled. Others are naive forms.

```
enum
{
    WAVE_SIN,
    WAVE_TRI,
    WAVE_SAW,
    WAVE_RAMP,
    WAVE_SQUARE,
    WAVE_POLYBLEP_TRI,
    WAVE_POLYBLEP_SAW,
    WAVE_POLYBLEP_SQUARE,
    WAVE_LAST,
};
```

init

Initializes the oscillator

float samplerate - sample rate of the audio engine being run, and the frequency that the process function will be called.

Defaults: - freq = 100 Hz - amp = 0.5 - waveform = sine wave.

```
void init(float samplerate)
```

set_freq

Changes the frequency of the oscillator, and recalculates phase increment.

```
inline void set_freq(const float f)
```

set_amp

Sets the amplitude of the waveform.

```
inline void set_amp(const float a) { amp = a; }
```

set_waveform

Sets the waveform to be synthesized by the process() function.

```
inline void set_waveform(const uint8_t wf) { waveform = wf < WAVE_LAST ? wf : WAVE_S</pre>
```

process

Processes the waveform to be generated, returning one sample. This should be called once per sample period.

```
float process();
```

Example

No example Provided

phasor

Generates a normalized signal moving from 0-1 at the specified frequency.

TODO:

I'd like to make the following things easily configurable:

- Selecting which channels should be initialized/included in the sequence conversion.
- Setup a similar start function for an external mux, but that seems outside the scope of this file.

init

```
Initializes the phasor module
sample rate, and freq are in Hz
initial phase is in radians
```

Additional init functions have defaults when arg is not specified:

```
    phs = 0.0f
    freq = 1.0f
    inline void init(float sample_rate, float freq, float initial_phase)
    inline void init(float sample_rate, float freq)
    inline void init(float sample_rate)

process
processes phasor and returns current value
```

Setters

```
set_freq
```

Sets frequency of the phasor in Hz

float process();

```
void set_freq(float freq);
```

Getters

get_freq

Returns current frequency value in Hz

```
inline float get_freq() { return freq_; }
```

```
#include "daisysp.h"
#include "daisy_seed.h"
using namespace daisysp;
static daisy_handle seed;
static phasor ramp;
static oscillator osc_sine;
static void audioCallback(float *in, float *out, size_t size)
{
    float sine, freq;
    for (size_t i = 0; i < size; i += 2)</pre>
        // generate phasor value (0-1), and scale it between 0 and 300
        freq = ramp.process()*300;
        osc_sine.set_freq(freq);
        sine = osc_sine.process();
        // left out
        out[i] = sine;
        // right out
        out[i+1] = sine;
    }
}
int main(void)
   // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    // initialize phasor module
   ramp.init(DSY_AUDIO_SAMPLE_RATE, 1, 0);
    // set parameters for sine oscillator object
    osc_sine.init(DSY_AUDIO_SAMPLE_RATE);
    osc_sine.set_waveform(oscillator::WAVE_SIN);
    osc_sine.set_freq(100);
    osc_sine.set_amp(0.25);
    // define callback
```

```
dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);

// start callback
dsy_audio_start(DSY_AUDIO_INTERNAL);

while(1) {}
}
```

pitchshift

From ucsd.edu "Pitch Shifting" t = 1 - ((s f) / R) where: s is the size of the delay f is the frequency of the lfo r is the samplerate solving for $t=12.0\,f=(12-1)$ 48000 / SHIFT_BUFFER_SIZE; Shift can be 30-100 ms lets just start with 50 for now. 0.050 * SR = 2400 samples (at 48kHz)

```
// Example that takes the mono input from channel 1 (left input),
// and pitchshifts it up 1 octave.
// The left output will be pitchshifteed, while the right output
// stays will be the unshifted left input.
#include "daisysp.h"
#include "daisy_seed.h"
// Defines for Interleaved Audio
#define LEFT (i)
#define RIGHT (i+1)
using namespace daisysp;
daisy_handle seed;
pitchshifter ps;
static void audioCallback(float *in, float *out, size_t size)
    float shifted, unshifted;
   for (size_t i = 0; i < size; i += 2)</pre>
        unshifted = in[LEFT];
        shifted = ps.process(unshifted);
        out[LEFT] = shifted;
        out[RIGHT] = unshifted;
    }
}
int main(void)
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
   ps.init(DSY_AUDIO_SAMPLE_RATE);
    // set transposition 1 octave up (12 semitones)
```

```
ps.set_transposition(12.0f);

// define callback
dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);

// start callback
dsy_audio_start(DSY_AUDIO_INTERNAL);

while(1) {}
}
```

pluck

Produces a naturally decaying plucked string or drum sound based on the Karplus-Strong algorithms.

This code has been extracted from the Csound opcode "pluck" It has been modified to work as a Daisy Soundpipe module.

Original Author(s): Barry Vercoe, John ffitch

Year: 1991

Location: OOps/ugens4.c

Mode

The method of natural decay that the algorithm will use.

- RECURSIVE: 1st order recursive filter, with coefs .5.
- WEIGHTED_AVERAGE: weighted averaging.

```
enum
{
    PLUCK_MODE_RECURSIVE,
    PLUCK_MODE_WEIGHTED_AVERAGE,
};
```

init

Initializes the Pluck module.

Arguments:

- sample_rate: Sample rate of the audio engine being run.
- buf: buffer used as an impulse when triggering the pluck algorithm
- npt: number of elementes in buf.
- mode: Sets the mode of the algorithm.

```
void init (float sample_rate, float *buf, int32_t npt, int32_t mode);
```

process

Processes the waveform to be generated, returning one sample. This should be called once per sample period.

```
float process (float &trig);
```

Mutators

set_amp

Sets the amplitude of the output signal.

```
Input range: 0-1?
        inline void set_amp(float amp) { amp_ = amp; }
set_freq
Sets the frequency of the output signal in Hz.
Input range: Any positive value
        inline void set_freq(float freq) { freq_ = freq; }
set_decay
Sets the time it takes for a triggered note to end in seconds.
Input range: 0-1
        inline void set_decay(float decay) { decay_ = decay; }
set\_damp
Sets the dampening factor applied by the filter (based on PLUCK_MODE)
Input range: 0-1
         inline void set_damp(float damp) { damp_ = damp; }
set\_mode
Sets the mode of the algorithm.
         inline void set_mode(int32_t mode) { mode_ = mode; }
Accessors
get_amp
Returns the current value for amp.
         inline float get_amp() { return amp_; }
get\_freq
Returns the current value for freq.
        inline float get_freq() { return freq_; }
get decay
Returns the current value for decay.
         inline float get_decay() { return decay_; }
```

```
get\_damp
Returns the current value for damp.
        inline float get_damp() { return damp_; }
get\_mode
Returns the current value for mode.
        inline int32_t get_mode() { return mode_; }
Example
#include "daisysp.h"
#include "daisy_seed.h"
#include <algorithm>
// Shortening long macro for sample rate
#ifndef SAMPLE_RATE
#define SAMPLE_RATE DSY_AUDIO_SAMPLE_RATE
// Interleaved audio definitions
#define LEFT (i)
#define RIGHT (i+1)
using namespace daisysp;
static daisy_handle seed;
// Helper Modules
static metro tick;
static pluck plk;
// MIDI note numbers for a major triad
const float arpeggio[3] = { 48.0f, 52.0f, 55.0f };
uint8_t arp_idx;
static void audioCallback(float *in, float *out, size_t size)
    float sig_out, freq, trig;
    for (size_t i = 0; i < size; i += 2)</pre>
    {
        // When the metro ticks:
        // advance the arpeggio, and trigger the pluck.
```

```
trig = 0.0f;
        if (tick.process())
        {
            freq = mtof(arpeggio[arp_idx]); // convert midi nn to frequency.
            arp_idx = (arp_idx + 1) % 3; // advance the arpeggio, wrapping at the end.
            plk.set_freq(freq);
            trig = 1.0f;
        sig_out = plk.process(trig);
        // Output
        out[LEFT] = sig_out;
        out[RIGHT] = sig_out;
    }
}
int main(void)
{
    float init_buff[256]; // buffer for pluck impulse
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    // Set up metro to pulse every second
    tick.init(1.0f, SAMPLE_RATE);
    // Set up pluck algo
    plk.init(SAMPLE_RATE, init_buff, 256, PLUCK_MODE_RECURSIVE);
    plk.set_decay(0.95f);
    plk.set_damp(0.9f);
    plk.set_amp(0.3f);
    arp idx = 0;
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
}
```

port

Applies portamento to an input signal. At each new step value, the input is low-pass filtered to move towards that value at a rate determined by ihtim. ihtim is the "half-time" of the function (in seconds), during which the curve will traverse half the distance towards the new value, then half as much again, etc., theoretically never reaching its asymptote.

This code has been ported from Soundpipe to DaisySP by Paul Batchelor.

The Soundpipe module was extracted from the Csound opcode "portk".

Original Author(s): Robbin Whittle, John ffitch

Year: 1995, 1998

Location: Opcodes/biquad.c

init

Initializes port module

Arguments:

- sample_rate: sample rate of audio engine
- htime: half-time of the function, in seconds.

```
void init(float sample_rate, float htime);
```

process

Applies portamento to input signal and returns processed signal.

```
float process(float in);
```

Setters

set_htime

Sets htime

```
inline void set htime(float htime) { htime = htime; }
```

Getters

get_htime

returns current value of htime

```
inline float get_htime() { return htime_; }
```

```
#include "daisysp.h"
#include "daisy_seed.h"
using namespace daisysp;
static daisy_handle seed;
static port slew;
static metro clock;
static oscillator osc_sine;
float freq;
static void audioCallback(float *in, float *out, size_t size)
{
    float sine, slewed_freq;
    uint8_t tic;
    for (size_t i = 0; i < size; i += 2)</pre>
    {
        tic = clock.process();
        if (tic)
            freq = rand() % 500;
        slewed_freq = slew.process(freq);
        osc_sine.set_freq(slewed_freq);
        sine = osc_sine.process();
        // left out
        out[i] = sine;
        // right out
        out[i+1] = sine;
    }
}
int main(void)
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    // set params for port object
```

```
slew.init(DSY_AUDIO_SAMPLE_RATE, .09);

clock.init(1, DSY_AUDIO_SAMPLE_RATE);

// set parameters for sine oscillator object

osc_sine.init(DSY_AUDIO_SAMPLE_RATE);
osc_sine.set_waveform(oscillator::WAVE_SIN);
osc_sine.set_freq(100);
osc_sine.set_amp(0.25);

// define callback
dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);

// start callback
dsy_audio_start(DSY_AUDIO_INTERNAL);
while(1) {}
}
```

reverbsc

```
Stereo Reverb
Ported from soundpipe
example:
daisysp/modules/examples/ex_reverbsc
init
Initializes the reverb module, and sets the samplerate at which the process
function will be called.
    int init(float samplerate);
process
process the input through the reverb, and updates values of out1, and out2 with
the new processed signal.
    int process(const float &in1, const float &in2, float *out1, float *out2);
set\_feedabck
controls the reverb time. reverb tail becomes infinite when set to 1.0
range: 0.0 to 1.0
    inline void set_feedback(const float &fb) { _feedback = fb; }
set_lpfreq
controls the internal dampening filter's cutoff frequency.
range: 0.0 to samplerate / 2
    inline void set_lpfreq(const float &freq) { _lpfreq = freq; }
Example
#include "daisysp.h"
#include "daisy_seed.h"
using namespace daisysp;
static daisy_handle seed;
reverbsc verb;
```

```
static void audioCallback(float *in, float *out, size_t size)
{
    for (size_t i = 0; i < size; i += 2)</pre>
        verb.process(in[i], in[i+1], &out[i], &out[i+1]);
    }
}
int main(void)
{
    //\ initialize\ seed\ hardware\ and\ white noise\ daisysp\ module
    daisy_seed_init(&seed);
    verb.init(DSY_AUDIO_SAMPLE_RATE);
    verb.set_feedback(0.85f);
    verb.set_lpfreq(18000.0f);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
}
```

svf

```
Double Sampled, Stable State Variable Filter
Credit to Andrew Simper from musicdsp.org
This is his "State Variable Filter (Double Sampled, Stable)"
Additional thanks to Laurent de Soras for stability limit, and Stefan Diedrichsen
for the correct notch output
Ported by: Stephen Hensley
example: daisysp/examples/svf/
init
Initializes the filter
float samplerate - sample rate of the audio engine being run, and the frequency
that the process function will be called.
             void init(float samplerate);
process
Process the input signal, updating all of the outputs.
             void process(float in);
Setters
set_freq
sets the frequency of the cutoff frequency.
f must be between 0.0 and samplerate / 2
             void set_freq(float f);
set_res
sets the resonance of the filter.
Must be between 0.0 and 1.0 to ensure stability.
             void set_res(float r);
set_drive
sets the drive of the filter, affecting the response of the resonance of the filter..
              inline void set_drive(float d) { _drive = d; }
```

```
Filter Outputs
Lowpass Filter
            inline float low() { return _out_low; }
Highpass Filter
            inline float high() { return _out_high; }
Bandpass Filter
            inline float band() { return _out_band; }
Notch Filter
            inline float notch() { return _out_notch; }
Peak Filter
            inline float peak() { return _out_peak; }
Example
#include "daisysp.h"
#include "daisy_seed.h"
using namespace daisy;
using namespace daisysp;
static daisy_handle seed;
oscillator osc;
svf filt;
static void audioCallback(float *in, float *out, size_t size)
    float sig;
    for (size_t i = 0; i < size; i += 2)</pre>
        sig = osc.process();
        filt.process(sig);
        // left out
```

```
out[i] = filt.low();
        // right out
        out[i + 1] = filt.high();
    }
}
int main(void)
    // initialize seed hardware and suf daisysp module
    daisy_seed_init(&seed);
    // Initialize Oscillator, and set parameters.
    osc.init(DSY_AUDIO_SAMPLE_RATE);
    osc.set_waveform(osc.WAVE_POLYBLEP_SAW);
    osc.set_freq(250.0);
    osc.set_amp(0.5);
    // Initialize Filter, and set parameters.
    filt.init(DSY_AUDIO_SAMPLE_RATE);
    filt.set_freq(500.0);
    filt.set_res(0.85);
    filt.set_drive(0.8);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    dsy_adc_start();
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
    while(1) {}
}
```

tone

A first-order recursive low-pass filter with variable frequency response.

init

Initializes the tone module.

sample_rate - The sample rate of the audio engine being run.

```
void init(float sample_rate);
```

process

Processes one sample through the filter and returns one sample.

in - input signal

```
float process(float &in);
```

Setters

set_freq

Sets the cutoff frequency or half-way point of the filter.

Arguments

• freq - frequency value in Hz. Range: Any positive value.

```
inline void set_freq(float &freq)
```

Getters

get_freq

Returns the current value for the cutoff frequency or half-way point of the filter.

```
inline float get_freq() { return freq_; }
```

```
#include "daisysp.h"
#include "daisy_seed.h"

using namespace daisysp;

static daisy_handle seed;
static tone flt;
static oscillator osc, lfo;
```

```
static void audioCallback(float *in, float *out, size_t size)
{
   float saw, freq, output;
    for (size_t i = 0; i < size; i += 2)</pre>
        freq = 2500 + (lfo.process()*2500);
        saw = osc.process();
        flt.set_freq(freq);
        output = flt.process(saw);
        // left out
        out[i] = output;
        // right out
        out[i+1] = output;
   }
}
int main(void)
    // initialize seed hardware and daisysp modules
    daisy_seed_init(&seed);
    // initialize tone object
    flt.init(DSY_AUDIO_SAMPLE_RATE);
    // set parameters for sine oscillator object
   lfo.init(DSY_AUDIO_SAMPLE_RATE);
   lfo.set_waveform(oscillator::WAVE_TRI);
   lfo.set_amp(1);
   lfo.set_freq(.4);
    // set parameters for sine oscillator object
    osc.init(DSY_AUDIO_SAMPLE_RATE);
    osc.set_waveform(oscillator::WAVE_POLYBLEP_SAW);
    osc.set_freq(100);
    osc.set_amp(0.25);
    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);
    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);
   while(1) {}
```

}

whitenoise

fast white noise generator I think this came from musicdsp.org at some point

init

```
Initializes the whitenoise object
```

```
void init()
```

set_amp

sets the amplitude of the noise output

```
inline void set_amp(float a) { amp = a; }
```

process

returns a new sample of noise in the range of -amp to amp

```
inline float process()
```

```
#include "daisysp.h"
#include "daisy_seed.h"

using namespace daisysp;

static daisy_handle seed;
static whitenoise nse;

static void audioCallback(float *in, float *out, size_t size)
{
    float sig;
    for (size_t i = 0; i < size; i += 2)
        {
        sig = nse.process();
        // left out
        out[i] = sig;
        // right out
        out[i + 1] = sig;
    }
}</pre>
```

```
int main(void)
{
    // initialize seed hardware and whitenoise daisysp module
    daisy_seed_init(&seed);
    nse.init();

    // define callback
    dsy_audio_set_callback(DSY_AUDIO_INTERNAL, audioCallback);

    // start callback
    dsy_audio_start(DSY_AUDIO_INTERNAL);

    while(1) {}
}
```