DaisySP

Contents

adenv	5
Envelope Segments	5
$\mathrm{init} \ldots \ldots$	5
process	5
trigger	6
Setters	6
set segment time	6
set curve scalar	6
set min	6
set max	6
Getters	6
current_segment	6
compressor	7
init	7
process	7
setters	7
	7
	8
set_attack	8
	8
set_release	0
crossfade	9
Curve Options	9
init	9
process	9
Setters	10
set_pos	10
set curve	10
Getters	10
get pos	10
get_curve	10
dcblock	11

	init
	process
	•
decima	tor 12
	init
	process
Sette	rs
	set_downsample_factor
	set_bitcrush_factor
	set bits to crush
Gett	
acu	get_downsample_factor
	0 = 1 =
	get_bitcrush_factor
delayliı	ne 13
aciaj ili	init
	reset
	= v
	write
	read
line	15
me	
	init
	process
	start
metro	16
metro	
Q	process
Sette	rs
	set_freq
Gett	
	get_freq
1014	1.
nlfilt	17
	init
	process
sette	rs
	set_coefficients
	individual setters for each coefficients
:11	
oscillat	
Wave	eforms
	init
	set_freq
	set_amp
	set waveform

	$\operatorname{process}$																											20
phasor																												21
1	init																											21
	process																											21
Sette	ers																											21
Section	set freq.																											21
Gett																												21
Gen																												21
	get_freq .		٠.	•	٠	•	•	•	•	•	•	•	 •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	21
pluck																												22
Mod	e																											22
Mod	init																											22
																												22
Mart	process																											22
Muta	ators																											
	set_amp.																											22
	set_freq .																											23
	set_decay																											23
	set_mode			•						•			 •															23
Acce	ssors			•									 •															23
	${\rm get_amp}$.																											23
	get_freq .																											23
	get_decay																											23
	get_mode																											23
\mathbf{port}																												24
	init			•	•			•					 •						•			•						24
	$\operatorname{process}$																											24
Sette	ers																											24
	set_htime																											24
Gett	ers																											24
	get_htime																											24
																												~-
reverbs																												25
	init																											25
	process	_																										25
	set_feedab																											25
	set_lpfreq			•				•					 •			•			•						•	•		25
\mathbf{svf}																												26
541	init																											26
	process																		•	•	•	•	•	•	•	•	•	26
Sotte	-																								•	•	•	$\frac{20}{26}$
Selle	ers																•								•	•	•	26
	set_freq .																							•	•	•	•	-
	set_res .		٠.	•	•	•		•	•	•	•	•	 •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	26 26

Filter Outputs																27
Lowpass Filter																27
Highpass Filter																27
Bandpass Filter																27
Notch Filter																27
Peak Filter																27

adenv

Author: shensley

Trigger-able envelope with adjustable min/max, and independent per-segment time control.

TODO:

- Add Cycling
- Implement Curve (its only linear for now).
- Maybe make this an AD_sr that has AD/AR/A_sr modes.

Envelope Segments

Distinct stages that the phase of the envelope can be located in.

- IDLE = located at phase location 0, and not currently running
- DECAY = Second segment of envelope where phase moves from MAX to MIN value
- LAST = The final segment of the envelope (currently decay)

```
enum {
          ADENV_SEG_IDLE,
          ADENV_SEG_ATTACK,
          ADENV_SEG_DECAY,
          ADENV_SEG_LAST,
};
```

init

Initializes the ad envelope

float sample_rate - sample rate of the audio engine being run.

Defaults

```
current segment = idle
curve = linear
phase = 0
min = 0
max = 1
```

```
void init(float sample rate);
```

process

processes the current sample of the envelope. Returns the current envelope value. This should be called once per sample period.

```
float process();
trigger
Starts or retriggers the envelope.
        inline void trigger() {_trigger = 1; }
Setters
set_segment_time
Sets the length of time(secondsVERIFYTHIS) for a specific segment.
        inline void set_time(uint8_t seg, float time)
set\_curve\_scalar
Sets the amount of curve applied. Input range: -1 to 1. - At -1, curve = full
logarithmic - At 1, curve = full exponential - At 0, curve = linear
        inline void set_curve_scalar(float scalar) { _curve_scalar = scalar; }
set\_min
Sets the minimum value of the envelope output Input range: -FLT_MAX, to
FLT\_MAX
        inline void set_min(float min) {_min = min; }
set\_max
Sets the maximum value of the envelope output Input range: -FLT MAX, to
FLT\_MAX
        inline void set_max(float max) {_max = max; }
Getters
current_segment
Returns the segment of the envelope that the phase is currently located in.
        inline void current_segment();
```

compressor

influenced by compressor in soundpipe (from faust).

Modifications made to do:

- Less calculations during each process loop (coefficients recalculated on parameter change).
- C++-ified
- added sidechain support

TODO:

- With fixed controls this is relatively quick, but changing controls now costs a lot more
- Still pretty expensive
- Add soft/hard knee settings
- Maybe make stereo possible? (needing two for stereo is a bit silly, and their gain shouldn't be totally unique.

by: shensley

init

```
Initializes compressor
```

samplerate - rate at which samples will be produced by the audio engine.

```
void init(float samplerate);
```

process

```
compresses the audio input signal, either keyed by itself, or a secondary input.
```

```
in - audio input signal (to be compressed)
```

(optional) key - audio input that will be used to side-chain the compressor.

```
float process(float &in, float &key);
float process(float &in);
```

setters

set_ratio

amount of gain reduction applied to compressed signals

```
Expects 1.0 \rightarrow 40. (untested with values < 1.0)
```

```
void set_ratio(const float &ratio)
```

```
set_threshold
threshold in dB at which compression will be applied
Expects 0.0 -> -80.
    void set_threshold(const float &thresh)

set_attack
envelope time for onset of compression for signals above the threshold.
Expects 0.001 -> 10
    void set_attack(const float &atk)

set_release
envelope time for release of compression as input signal falls below threshold.
Expects 0.001 -> 10
```

void set_release(const float &rel)

crossfade

Performs a crossfade between two signals

Original author: Paul Batchelor

Ported from Soundpipe by Andrew Ikenberry added curve option for constant power, etc.

TODO:

- implement exponential curve process
- implement logarithmic curve process

Curve Options

Curve applied to the crossfade

init

Initializes crossfade module

Defaults

```
current position = .5curve = linearinline void init()
```

process

processes crossfade and returns single sample

```
float process(float &in1, float &in2);
```

inline uint8_t get_curve(uint8_t curve) { return curve_; }

dcblock

```
Removes DC component of a signal

init

Initializes dcblock module

void init(float sample_rate);

process

performs dcblock process

float process(float in);
```

decimator

Performs downsampling and bitcrush effects

```
init
```

```
Initializes downsample module
```

```
void init();
```

process

Applies downsample and bitcrush effects to input signal. Returns one sample. This should be called once per sample period.

```
float process(float input);
```

Setters

```
set\_downsample\_factor
```

Sets amount of downsample Input range:

```
inline void set_downsample_factor (float downsample_factor)
```

set_bitcrush_factor

Sets amount of bitcrushing Input range:

```
inline void set_bitcrush_factor (float bitcrush_factor)
```

$set_bits_to_crush$

Sets the exact number of bits to crush

0-16 bits

```
inline void set_bits_to_crush(const uint8_t &bits)
```

Getters

```
get\_downsample\_factor
```

Returns current setting of downsample

```
inline float get_downsample_factor () { return _downsample_factor; }
```

$get_bitcrush_factor$

Returns current setting of bitcrush

```
inline float get_bitcrush_factor () { return _bitcrush_factor; }
```

delayline

```
Simple Delay line.
November 2019
Converted to Template December 2019
declaration example: (1 second of floats)
delayline<float, SAMPLE_RATE> del;
By: shensley
init
initializes the delay line by clearing the values within, and setting delay to 1
sample.
    void init()
reset
clears buffer, sets write ptr to 0, and delay to 1 sample.
    void reset() {
set_delay
sets the delay time in samples
If a float is passed in, a fractional component will be calculated for interpolating
the delay line.
    inline void set_delay(size_t delay)
    inline void set_delay(float delay)
write
writes the sample of type T to the delay line, and advances the write ptr
    inline void write(const T sample)
read
returns the next sample of type T in the delay line, interpolated if necessary.
    inline const T read() const
```

dsy_pstream.h Ported from Csound - October 2019

(c) Richard Dobson August 2001 NB pvoc routines based on CARL distribution(Mark Dolson). This file is licensed according to the terms of the GNU LGPL.

Definitions from Csound: pvsanal pvsfread pvsynth pvsadsyn pvscross pvsmaska = (overloaded, – should probably just pvsset(&src, &dest))

More or less for starting purposes we really only need pvsanal, and pvsynth to get started

line

creates a line segment signal

init

Initializes line module.

```
void init(float sample_rate);
```

process

Processes line segment. Returns one sample.

value of finished will be updated to a 1, upon completion of the line's trajectory.

```
float process(uint8_t *finished);
```

start

Begin creation of line.

Arguments:

- start beginning value
- $\bullet\,$ end $\bullet\,$ ending value
- dur duration in seconds of line segment

```
void start(float start, float end, float dur);
```

metro

Creates a clock signal at a specific frequency.

init

Initializes metro module.

Arguments: - freq: frequency at which new clock signals will be generated Input Range: - sample_rate: sample rate of audio engine Input range:

```
void init(float freq, float sample_rate);
```

process

checks current state of metro object and updates state if necesary.

```
uint8_t process();
```

Setters

set_freq

Sets frequency at which metro module will run at.

```
void set_freq(float freq);
```

Getters

get_freq

Returns current value for frequency.

```
inline float get_freq() { return freq_; }
```

nlfilt

port by: stephen hensley, December 2019

Non-linear filter.

The four 5-coefficients: a, b, d, C, and L are used to configure different filter types.

Structure for Dobson/Fitch nonlinear filter

Revised Formula from Risto Holopainen 12 Mar 2004

```
Y{n} = tanh(a Y{n-1} + b Y{n-2} + d Y^2{n-L} + X{n} - C)
```

Though traditional filter types can be made, the effect will always respond differently to different input.

This Source is a heavily modified version of the original source from Csound.

TODO:

• make this work on a single sample instead of just on blocks at a time.

init

Initializes the nlfilt object.

```
void init();
```

process

Process the array pointed to by *in and updates the output to *out;

This works on a block of audio at once, the size of which is set with the size.

```
void process_block(float *in, float *out, size_t size);
```

setters

$set_coefficients$

inputs these are the five coefficients for the filter.

```
inline void set_coefficients(float a, float b, float d, float C, float L)
```

individual setters for each coefficients.

```
inline void set_a(float a) { a_ = a; }
inline void set_b(float b) { b_ = b; }
inline void set_d(float d) { d_ = d; }
inline void set_C(float C) { C_ = C; }
```

inline void set_L(float L) { $L_ = L; }$

oscillator

```
Synthesis of several waveforms, including polyBLEP bandlimited waveforms.
example:
daisysp::oscillator osc;
init()
{
    osc.init(SAMPLE_RATE);
    osc.set_frequency(440);
    osc.set_amp(0.25);
    osc.set_waveform(WAVE_TRI);
}
callback(float *in, float *out, size_t size)
{
    for (size_t i = 0; i < size; i+=2)
    {
        out[i] = out[i+1] = osc.process();
    }
}</pre>
```

Waveforms

Choices for output waveforms, POLYBLEP are appropriately labeled. Others are naive forms.

```
enum
{
    WAVE_SIN,
    WAVE_TRI,
    WAVE_SAW,
    WAVE_RAMP,
    WAVE_SQUARE,
    WAVE_POLYBLEP_TRI,
    WAVE_POLYBLEP_SAW,
    WAVE_POLYBLEP_SQUARE,
    WAVE_LAST,
};
```

init

Initializes the oscillator

float samplerate - sample rate of the audio engine being run, and the frequency that the process function will be called.

Defaults: - freq = 100 Hz - amp = 0.5 - waveform = sine wave.

```
void init(float samplerate)
```

set_freq

Changes the frequency of the oscillator, and recalculates phase increment.

```
inline void set_freq(const float f)
```

set_amp

Sets the amplitude of the waveform.

```
inline void set_amp(const float a) { amp = a; }
```

$set_waveform$

Sets the waveform to be synthesized by the process() function.

```
inline void set_waveform(const uint8_t wf) { waveform = wf < WAVE_LAST ? wf : WAVE_S</pre>
```

process

Processes the waveform to be generated, returning one sample. This should be called once per sample period.

```
float process();
```

phasor

Generates a normalized signal moving from 0-1 at the specified frequency.

TODO:

I'd like to make the following things easily configurable:

- Selecting which channels should be initialized/included in the sequence conversion.
- Setup a similar start function for an external mux, but that seems outside the scope of this file.

init

```
Initializes the phasor module
sample rate, and freq are in Hz
initial phase is in radians
```

Additional init functions have defaults when arg is not specified:

```
    phs = 0.0f
    freq = 1.0f
    inline void init(float sample_rate, float freq, float initial_phase)
    inline void init(float sample_rate, float freq)
    inline void init(float sample_rate)

process
processes phasor and returns current value
float process();
```

Setters

```
set_freq
```

Sets frequency of the phasor in Hz

```
void set_freq(float freq);
```

Getters

get_freq

Returns current frequency value in Hz

```
inline float get_freq() { return freq_; }
```

pluck

Produces a naturally decaying plucked string or drum sound based on the Karplus-Strong algorithms.

This code has been extracted from the Csound opcode "pluck" It has been modified to work as a Daisy Soundpipe module.

Original Author(s): Barry Vercoe, John ffitch

Year: 1991

Location: OOps/ugens4.c

Mode

The method of natural decay that the algorithm will use.

- RECURSIVE: 1st order recursive filter, with coefs .5.
- WEIGHTED_AVERAGE: weighted averaging.

```
enum
{
    PLUCK_MODE_RECURSIVE,
    PLUCK_MODE_WEIGHTED_AVERAGE,
};
```

init

Initializes the Pluck module.

Arguments:

- sample_rate: Sample rate of the audio engine being run.
- buf: buffer used as an impulse when triggering the pluck algorithm
- npt: number of elementes in buf.
- mode: Sets the mode of the algorithm.

```
void init (float sample_rate, float *buf, int32_t npt, int32_t mode);
```

process

Processes the waveform to be generated, returning one sample. This should be called once per sample period.

```
float process (float &trig);
```

Mutators

set_amp

Sets the amplitude of the output signal.

```
Input range: 0-1?
        inline void set_amp(float amp) { amp_ = amp; }
set\_freq
Sets the frequency of the output signal in Hz.
Input range: Any positive value
        inline void set_freq(float freq) { freq_ = freq; }
set_decay
Sets the time it takes for a triggered note to end in seconds.
Input range: Any positive value
        inline void set_decay(float decay) { decay_ = decay; }
set\_mode
Sets the mode of the algorithm.
        inline void set_mode(int32_t mode) { mode_ = mode; }
Accessors
get_amp
Returns the current value for amp.
        inline float get_amp() { return amp_; }
get_freq
Returns the current value for freq.
        inline float get_freq() { return freq_; }
get_decay
Returns the current value for decay.
        inline float get_decay() { return decay_; }
get\_mode
Returns the current value for mode.
        inline int32_t get_mode() { return mode_; }
```

port

Applies portamento to an input signal. At each new step value, the input is low-pass filtered to move towards that value at a rate determined by ihtim. ihtim is the "half-time" of the function (in seconds), during which the curve will traverse half the distance towards the new value, then half as much again, etc., theoretically never reaching its asymptote.

This code has been ported from Soundpipe to DaisySP by Paul Batchelor.

The Soundpipe module was extracted from the Csound opcode "portk".

Original Author(s): Robbin Whittle, John ffitch

Year: 1995, 1998

Location: Opcodes/biquad.c

init

Initializes port module

Arguments:

- sample_rate: sample rate of audio engine
- htime: half-time of the function, in seconds.

```
void init(float sample_rate, float htime);
```

process

Applies portamento to input signal and returns processed signal.

```
float process(float in);
```

Setters

set_htime

Sets htime

```
inline void set htime(float htime) { htime = htime; }
```

Getters

get_htime

returns current value of htime

```
inline float get_htime() { return htime_; }
```

reverbsc

```
Stereo Reverb
Ported from soundpipe
example:
daisysp/modules/examples/ex_reverbsc
init
Initializes the reverb module, and sets the samplerate at which the process
function will be called.
    int init(float samplerate);
process
process the input through the reverb, and updates values of out1, and out2 with
the new processed signal.
    int process(const float &in1, const float &in2, float *out1, float *out2);
set\_feedabck
controls the reverb time. reverb tail becomes infinite when set to 1.0
range: 0.0 to 1.0
    inline void set_feedback(const float &fb) { _feedback = fb; }
set_lpfreq
controls the internal dampening filter's cutoff frequency.
range: 0.0 to samplerate / 2
    inline void set_lpfreq(const float &freq) { _lpfreq = freq; }
```

svf

```
Double Sampled, Stable State Variable Filter
Credit to Andrew Simper from musicdsp.org
This is his "State Variable Filter (Double Sampled, Stable)"
Additional thanks to Laurent de Soras for stability limit, and Stefan Diedrichsen
for the correct notch output
Ported by: Stephen Hensley
example: daisysp/examples/svf/
init
Initializes the filter
float samplerate - sample rate of the audio engine being run, and the frequency
that the process function will be called.
             void init(float samplerate);
process
Process the input signal, updating all of the outputs.
             void process(float in);
Setters
set_freq
sets the frequency of the cutoff frequency.
f must be between 0.0 and samplerate / 2
             void set_freq(float f);
set_res
sets the resonance of the filter.
Must be between 0.0 and 1.0 to ensure stability.
             void set_res(float r);
set_drive
sets the drive of the filter, affecting the response of the resonance of the filter..
              inline void set_drive(float d) { _drive = d; }
```

Lowpass Filter inline float low() { return _out_low; } Highpass Filter inline float high() { return _out_high; }

Bandpass Filter

Filter Outputs

```
inline float band() { return _out_band; }
```

Notch Filter

```
inline float notch() { return _out_notch; }
```

Peak Filter

```
inline float peak() { return _out_peak; }
```