

# CS-E5360 Systems of Systems

**Practical Session** 

Asad Javed PhD Researcher Computer Science Avleen Malhi Postdoctoral Researcher Computer Science

#### Agenda

- Introduction
- O-MI/O-DF Reference Implementation
- How to run O-MI node
- Live demos
- (Scripts and Slides are available at: <u>https://github.com/AaltoAsia/SoS-Scripts</u>)

#### Introduction




- This session will address the practical aspects of using IoT technology to deliver smart city solutions.
- Goal of the session:
  - Install O-MI Node reference implementation
  - Use an IoT device to send sensor values to your Node
  - Make a data subscription to send value from your Node to our Node
- We will have live visualization of all the data coming to our O-MI Node



## O-MI/O-DF Reference Implementation

- Open source implementation developed at Aalto University
  - Available at: <a href="https://github.com/AaltoAsia/O-MI">https://github.com/AaltoAsia/O-MI</a>
- Enable fast deployment of IoT node






#### How to run O-MI node?

- Dependency Java JDK 1.8
- Run pre-compiled node:
  - Download the latest release version and unpack it. Available at: <a href="https://github.com/AaltoAsia/O-MI/releases">https://github.com/AaltoAsia/O-MI/releases</a>
    - For Windows: Use "o-mi-node-1.0.9.zip" (Don't use deep directory structure)
    - For MAC/Linux: Use "o-mi-node-1.0.9.tgz"
  - 2. To allow **write** requests from other machines you need to modify file "<Extracted folder>/conf/application.conf".
    - Change the setting "allowRequestTypesForAll", add "write" to the list, such that the result looks like this:
    - allowRequestTypesForAll = ["read", "cancel", "call", "write"]
  - 3. For Windows: Go to the <Extracted folder>/bin and click on o-mi-node.bat

    For NAC /Linux: cd <Extracted folder>/bin and run " / o mi node"
    - For MAC/Linux: cd <Extracted folder>/bin and run "./ o-mi-node"
  - 4. The server can now be accessed with URL <a href="http://localhost:8080/">http://localhost:8080/</a>



### Case Study: Smart Home





### **Smart Home Scenario Description**

- Smart Home equipped with
  - Temperature and Humidity sensor (SHT-20)
  - CO2 sensor (S-100)
- Wrapper to publish smart home data to O-MI node
  - Read sensor value
  - Translate it to O-DF
  - Put it in O-MI Write request
  - Send with HTTP POST request
- Developer can test the system using web-client
- <u>Data consumer</u> (Monitoring unit) might be interested in these sensor values for analyzing the required object values. It can subscribe to the objects of interest



#### Hardware and Sensors Provided

- ESP8266 WiFi development modules
- SHT20 Temperature and humidity sensor
- S-100 CO2 sensor

Live Demo

Implementation Using ESP8266



#### **Download Scripts**

- Connect to our WiFi "TP-LINK\_C5E618"
- Open new termial and download the provided scripts from https://github.com/AaltoAsia/SoS-Scripts




## **ESP8266 Arduino Configuration**

- The ESP8266 is a very low-cost Wi-Fi microchip with full TCP/IP stack and microcontroller capability.
- Arduino is an open-source electronics platform based on easy-touse hardware and software.
  - Install latest Arduino IDE from https://www.arduino.cc/en/main/software
  - Start Arduino and open Preferences window.
  - Enter https://arduino.esp8266.com/stable/package\_esp8266com\_index.json into Additional Board Manager URLs field.
  - Open Boards Manager from Tools > Board menu and install esp8266 platform
  - For MAC machine, download and install the driver "CH34x\_Install\_V1.5.pkg" from <a href="https://github.com/adrianmihalko/ch340g-ch34g-ch34x-mac-os-x-driver">https://github.com/adrianmihalko/ch340g-ch34g-ch34x-mac-os-x-driver</a>

Restart the Arduino IDE



## CO<sub>2</sub> Sensor (Model: S-100)



- Connect jumper cables:
  - Sensor TX -> ESP RX
  - Sensor GND -> ESP GND
  - Sensor 5V -> ESP 5V



## Interfacing CO2 Sensor with ESP8266

- 1. Connect ESP chip with your laptop USB port.
- 2. Start Arduino IDE and select the following board from Tools -> Board
  - LOLIN (WEMOS) D1 R2 and Mini
- 3. Select port using Tools -> Port
- 4. cd <....>/SoS-Scripts/CO2\_test (for opening test scripts for CO2 sensor)
- 5. Open create\_odf tab in Arduino and change <id> of the Object to something unique and change the url to your O-MI Node (<a href="http://yourlP:8080/">http://yourlP:8080/</a>)
- 6. Note: Disconnect the RX of ESP8266 while uploading the code.
- 7. Press Upload button



- 8. Connect RX of ESP8266 again after uploading is done.
- 9. If it fails you might have wrong port or too high upload speed
- 10. View the output through Tools -> Serial Monitor

Select baud rate as 38400

# Temperature and Humidity Sensor (Model: SHT-20)



**#?** \*?


+ GND \* ?

\*? \*3v3

\*? \* SDC

\*? \* SDA

- Connect jumper cables:
  - Sensor SDA -> ESP SDA (D2)
  - Sensor SDC -> ESP SDL (D1)
  - Sensor GND -> ESP GND
  - Sensor 3.3V -> ESP 3V3





#### SHT20 Sensor

- Download the library for SHT20 from <a href="https://github.com/DFRobot/DFRobot\_SHT20">https://github.com/DFRobot/DFRobot\_SHT20</a> into the 'libraries' folder of your Arduino installation directory (<....>/Documents/Arduino/libraries).
- cd <....>/SoS-Scripts/temp\_humi\_test (go to our scripts directory)
- Open create\_odf tab in Arduino and change <id> of the Object to something unique and change the url to your O-MI Node (<a href="http://yourlP:8080/">http://yourlP:8080/</a>)
- Press Upload button
- Tools -> Serial Monitor
  - Select baud rate as 115200

# Create a subscription for our visualization Node



- Go to <a href="http://localhost:8080/">http://localhost:8080/</a> and go to "O-MI Test Client WebApp"
- 2. Check that your data have been received correctly with a Read request, after that, continue with subscription:
- 3. Select "Objects" from the O-DF tree
- 4. Select "Subscription" request
- Open "Optional parameters"
- 6. Put address of the visualization node (<a href="http://192.168.1.20:8080/">http://192.168.1.20:8080/</a>) to "callback" field
- Press "Send" and see if your value shows on the visualization (after it changes next time)

