# Manual for 3-DOF Helicopter Lab

Rita Laezza\*

Department of Electrical Engineering, Chalmers University of Technology November, 2022

<sup>\*</sup>Adapted from [1]

### 1 Introduction

During the Linear Control Systems Design (SSY285) course, you have learned to design optimal control strategies for linear time-invariant (LTI) systems. In this lab, these skills will be put to the test on a real experimental setup of a helicopter with 3 Degrees of Freedom (DOF), designed by Quanser. The 3-DOF Helicopter model that is used in this laboratory is analogous to a tandem rotor helicopter such as the Boeing HC-1B Chinook shown in Figure 1.




Figure 1: Boeing HC-1B Chinook. Source: [2]

This lab manual provides the necessary background information related to the equipment, a list of preparation exercises to be completed before the session (Sections 1-4) and a number of tasks which should be carried out at the lab (Section 5). You are expected to read the entire document and to successfully complete all of the non-optional preparation exercises before your lab session.

The purpose of the lab is for you to familiarize yourself with useful computer software for model analysis and control design. First, you should linearize a given nonlinear model, by hand and/or using tools from Simulink. The resulting linearized model should then be validated, by comparing it to the nonlinear model. Finally, based on the linear model you should perform control design, using Linear Quadratic (LQ) optimization principles to control the process elevation axis, travel axis and travel axis speed.

## 1.1 Equipment

The 3-DOF Helicopter plant is depicted in Figure 2. Two DC motors are mounted at the two ends of a rectangular frame and drive two propellers. The motors' axes are parallel and the thrust vector is normal to the frame. The helicopter frame is suspended from in instrumented joint mounted at the end of a long arm and is free to pitch about its center. The arm is installed on an additional 2-DOF instrumented joint which allows the helicopter body to move in elevation and yaw directions. The other end of the arm carries a counterweight such that the effective mass of the helicopter is light enough for it to be lifted using the thrust from the motors [2].



Figure 2: 3-DOF Helicopter equipment. Source: [2]

A positive voltage applied to the front motor causes a positive pitch while a positive voltage applied to the back motor causes a negative pitch. A positive voltage to either motor also causes an elevation of the body (i.e., pitch of the arm). If the body pitches, the thrust vectors result in a travel of the body (i.e., yaw of the arm) as well. The vertical base is equipped with an eight-contact slip ring. Electrical signals to and from the arm and helicopter are channeled through the slip ring to eliminate tangled wires, reduce friction, and allow for unlimited and unhindered travel [2].

### 1.2 Model




Figure 3: Schematics of 3-DOF Helicopter, indicating elevation, pitch and travel axes.

Figure 3 depicts the layout of the helicopter device. The three angular position states we will use for our model are the elevation  $(\varepsilon)$ , pitch  $(\rho)$  and travel  $(\lambda)$  angles. The input voltage for the front and back motor will be denoted by  $V_f$  and  $V_b$ , respectively. A positive voltage implies air being blown downwards creating an upwards lift. A simplified nonlinear model of the process is given by the following input-affine system:

$$\dot{x} = f(x) + g(x)u \tag{1}$$

where

$$x = \left[\varepsilon, \rho, \lambda, \dot{\varepsilon}, \dot{\rho}, \dot{\lambda}\right]^{T} \tag{2}$$

$$u = \left[V_f, V_b\right]^T \tag{3}$$

The function f(x) is defined as

$$f(x) = \begin{bmatrix} \dot{\varepsilon} \\ \dot{\rho} \\ \dot{\lambda} \\ p_1 \cos \varepsilon + p_2 \sin \varepsilon + p_3 \dot{\varepsilon} \\ p_5 \cos \rho + p_6 \sin \rho + p_7 \dot{\rho} \\ p_9 \dot{\lambda} \end{bmatrix}$$
(4)

and g(x) is defined as

$$g(x) = \begin{bmatrix} 0 & 0 \\ 0 & 0 \\ 0 & 0 \\ p_4 \cos \rho & p_4 \cos \rho \\ p_8 & -p_8 \\ p_{10} \sin \rho & p_{10} \sin \rho \end{bmatrix}$$
 (5)

Table 1: Modelling parameters

Parameter	Value	Description
$\overline{M_f}$	0.71~kg	Mass of front propeller assembly
$M_b$	$0.71 \ kg$	Mass of back propeller assembly
$M_c$	$1.69 \ kg$	Mass of the counterweight
$L_d$	0.05 m	The length of pendulum for elevation axis
$L_c$	0.44 m	Distance from pivot point to counterweight
$L_a$	0.62 m	Distance from pivot point to helicopter body
$L_e$	0.02 m	The length of pendulum for pitch axis
$L_h$	$0.18 \ m$	The distance from the pitch axis to motor
g	$9.81 \ m/s^2$	Gravitational acceleration
$K_m$	$0.12 \ N/V$	Propeller force-thrust constant
$J_arepsilon$	$0.86 \ kg \cdot m^2$	Moment of inertia about the elevation axis
$J_{ ho}$	$0.044 \ kg \cdot m^2$	Moment of inertia about the pitch axis
$J_{\lambda}$	$0.82 \ kg \cdot m^2$	Moment of inertia about the travel axis
$\eta_arepsilon$	$0.001 \ kg \cdot m^2/s$	Coefficient of viscous friction, elevation axis
$\eta_ ho$	$0.001 \ kg \cdot m^2/s$	Coefficient of viscous friction, pitch axis
$\eta_{\lambda}$	$0.005 \ kg \cdot m^2/s$	Coefficient of viscous friction, travel axis

Finally, the weights p are defined as

$$p_{1} = \left[ -(M_{f} + M_{b})gL_{a} + M_{c}gL_{c} \right] / J_{\varepsilon} \qquad p_{2} = \left[ -(M_{f} + M_{b})g(L_{d} + L_{e}) + M_{c}gL_{d} \right] / J_{\varepsilon}$$

$$p_{3} = -\eta_{\varepsilon} / J_{\varepsilon} \qquad p_{4} = K_{m}L_{a} / J_{\varepsilon}$$

$$p_{5} = (-M_{f} + M_{b})gL_{h} / J_{\rho} \qquad p_{6} = -(M_{f} + M_{b})gL_{e} / J_{\rho}$$

$$p_{7} = -\eta_{\rho} / J_{\rho} \qquad p_{8} = K_{m}L_{h} / J_{\rho}$$

$$p_{9} = -\eta_{\lambda} / J_{\lambda} \qquad p_{10} = -K_{m}L_{a} / J_{\lambda} \qquad (6)$$

and Table 1 lists the physical quantities used to compute the weights in equation (6), together with a description of the parameters.

**Remark 1.** All exercises related to this laboratory are carried out in continuous time.

### 1.3 LTI State-Space Model

As this course focuses on linear control methods, the system will have to be linearized in order to perform control design. The standard form for a dynamic model, suitable for simulation and controller design, is the state-space form

$$\dot{x}(t) = A_{\delta}x(t) + B_{\delta}u(t) 
y(t) = C_{\delta}x(t) + D_{\delta}u(t)$$
(7)

where x(t) is the state, u(t) is the control input,  $A_{\delta}$ ,  $B_{\delta}$ ,  $C_{\delta}$ , and  $D_{\delta}$  are state-space matrices. For a 3-DOF Helicopter, the linear states are

$$x(t) = [\delta \varepsilon(t) \ \delta \rho(t) \ \delta \lambda(t) \ \delta \dot{\varepsilon}(t) \ \delta \dot{\rho}(t) \ \delta \dot{\lambda}(t)]^{T}, \tag{8}$$

where  $\delta$  refers to small variable changes around the operating point. According to equations (1)-(6) the system state equations are given by

$$\frac{\mathrm{d}\varepsilon(t)}{\mathrm{d}t} = \dot{\varepsilon}(t) = h_1(t)$$

$$\frac{\mathrm{d}\rho(t)}{\mathrm{d}t} = \dot{\rho}(t) = h_2(t)$$

$$\frac{\mathrm{d}\lambda(t)}{\mathrm{d}t} = \dot{\lambda}(t) = h_3(t)$$

$$\frac{\mathrm{d}\dot{\varepsilon}(t)}{\mathrm{d}t} = h_4(t)$$

$$\frac{\mathrm{d}\dot{\rho}(t)}{\mathrm{d}t} = h_5(t)$$

$$\frac{\mathrm{d}\dot{\lambda}(t)}{\mathrm{d}t} = h_6(t)$$
(9)

The control inputs are

$$u(t) = [\delta V_f(t) \ \delta V_b(t)]^T = [u_1(t) \ u_2(t)]^T.$$
(10)

We would like to linearize the system at the origin, that is to set the initial condition as:  $x_0 = [0 \ 0 \ 0 \ 0 \ 0]^T$ . For the inputs  $u_0 = [V_{f0}, V_{b0}]$ , it is reasonable to assume that the front and back voltages are equal, i.e.  $V_{f0} = V_{b0}$ . To find  $V_{f0}$ , simply solve  $f(x_0) + g(x_0)u_0 = 0$  for  $u_0$ . After determining the operating point, linearization results in matrices  $A_{\delta}$  and  $B_{\delta}$  as

$$A_{\delta} = \begin{bmatrix} \frac{\partial h_{1}}{\partial x_{1}} & \cdots & \frac{\partial h_{1}}{\partial x_{n}} \\ \vdots & \ddots & \vdots \\ \frac{\partial h_{n}}{\partial x_{1}} & \cdots & \frac{\partial h_{n}}{\partial x_{n}} \end{bmatrix} \Big|_{(\varepsilon = \rho = \lambda = \dot{\varepsilon} = \dot{\rho} = \dot{\lambda} = 0, u_{0})}$$

$$B_{\delta} = \begin{bmatrix} \frac{\partial h_{1}}{\partial u_{1}} & \cdots & \frac{\partial h_{1}}{\partial u_{n}} \\ \vdots & \ddots & \vdots \\ \frac{\partial h_{n}}{\partial u_{1}} & \cdots & \frac{\partial h_{n}}{\partial u_{n}} \end{bmatrix} \Big|_{(\varepsilon = \rho = \lambda = \dot{\varepsilon} = \dot{\rho} = \dot{\lambda} = 0, u_{0})}$$

$$(11)$$

Only angles can be sensed by encoders, and not angular rates. Hence, the states  $x_1(t)$ ,  $x_2(t)$  and  $x_3(t)$  are measured and the outputs of the 3-DOF Helicopter are obtained as


$$y(t) = [\delta \varepsilon(t) \ \delta \rho(t) \ \delta \lambda(t)]^T = [x_1(t) \ x_2(t) \ x_3(t)]^T. \tag{12}$$

giving the following matrices, since the control input does not influence the measurement:

$$C_{\delta} = \begin{bmatrix} 1 & 0 & 0 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 & 0 & 0 \\ 0 & 0 & 1 & 0 & 0 & 0 \end{bmatrix}, \quad D_{\delta} = \begin{bmatrix} 0 & 0 \\ 0 & 0 \\ 0 & 0 \end{bmatrix}. \tag{13}$$

**Exercise 1 (optional)** Linearize the nonlinear model defined in (1)-(6), around the operating point. You can use generalized series expansions of the trigonometric functions (for small angles). Find the numerical values for the matrices  $A_{\delta}$  and  $B_{\delta}$ , using the parameter values from Table 1.

#### Answer



Exercise 2 A Simulink model describing the nonlinear system is available on the course home page, in  $nlmodel_3D.mdl$ . Instead of computing the linearized system by hand, it is possible to use the **Model Linearizer** app which is part of the **Simulink Control Design** add-on. Use this Simulink tool to obtain a linearized model. In the LINEAR ANALYSIS tab, the point around which the system is linearized can be set to "Model Initial Condition" [3]. Make sure to compute  $V_{f0}$  and  $V_{b0}$  in the  $nl_parameters_3D.m$  script and run it before running the simulation. Load the resulting  $(A_{\delta}, B_{\delta}, C_{\delta}, D_{\delta})$  matrices into the same script.

### 1.4 Elevation and Travel Tracking Errors

In this laboratory, you will control the elevation and travel of the helicopter. Note that the pitch will indirectly be controlled in order to move the helicopter around the travel axis. To this end, one can define the appropriate reference tracking errors. Let us augment the LTI model from equation (7) with two integral states:

$$x_e(t) \equiv \begin{bmatrix} x(t) \\ z_{\varepsilon}(t) \\ z_{\lambda}(t) \end{bmatrix}$$
 (14)

with,

$$z_{\varepsilon}(t) = \int \left(\delta \varepsilon(t) - \delta \varepsilon_{ref}(t)\right) dt \tag{15}$$

$$z_{\lambda}(t) = \int (\delta \lambda(t) - \delta \lambda_{ref}(t)) dt$$
 (16)

where  $\delta \varepsilon_{ref}(t)$  and  $\delta \lambda_{ref}(t)$  are the reference signals. Note that these integral states correspond to the cumulative error of the elevation and travel angles with respect to their desired references.

**Exercise 3 (optional)** Expand the linear model with the above elevation tracking error and find the numerical values for the augmented system as (A, B, C, D). Include this augmented system in nl\_parameters\_3D.m. Note that when augmenting the linearized system with two new states then  $C \in \mathbb{R}^{2\times 8}$ .

Answer

# 2 Open-Loop System Analysis

Exercise 4 It is important to investigate how well the linear model represents the nonlinear
one. Simulate both models in open loop using an all zero initial state and constant input $u_0$
Implement the linearized model in nlmodel_3D.mdl, without changing the nonlinear system
Analyze the output, what happens to the various states? Compare the results, how do the
linear and nonlinear models' reactions differ?

Answer	
1 Stability	
ability of a state space model can be analyzed based on the eigenvalues of the matrix $A$ .	
<b>Exercise 5 (optional)</b> Are the linearized $(A_{\delta}, B_{\delta}, C_{\delta}, D_{\delta})$ and augmented $(A, B, C, S)$ stems asymptotically stable? Does the inclusion of extra integral states change the stabil operty? Are they input-output stable? Find the transmission zeros of the systems. When you conclude from the zeros? <b>Answer</b>	ity

# 2.2 Observability

If by only measuring the output y(t) and input u(t), the states of the system can be deduced at any time in final time, the system is called observable. Observability can be checked by different alternatives, such as by checking the rank of the observability matrix or by means of the PBH (Popov-Belevich-Hautus) test.

**Exercise 6 (optional)** Determine the observability matrix and check if the system is observable using Kalman's rank test. Check both systems, i.e.  $(A_{\delta}, B_{\delta}, C_{\delta}, D_{\delta})$  and (A, B, C, D). Does the inclusion of additional integral states change the observability property?

Answer

Exercise 7 (optional) Check observability by means of the PBH test.  Answer
2.3 Controllability
If the control input, $u(t)$ , of a system can take the state vector, $x(t)$ from any non-zero initial state to the origin in finite time, the LTI system is said to be (full state) controllable. When checking controllability there are different possible approaches, namely by checking the rank of the controllability matrix or by means of the PBH test.
Exercise 8 (optional) Find the controllability matrix and check if the system is control lable using Kalman's rank test. Check both systems, i.e. $(A_{\delta}, B_{\delta}, C_{\delta}, D_{\delta})$ and $(A, B, C, D)$ Does the inclusion of additional integral states change the controllability?  Answer
Exercise 9 (optional) Check controllability by means of the PBH test.  Answer
· - /

### 3 Feedback Control




Figure 4: A feedback control system with state feedback. The controller uses the system state x and the reference input r to command the process through its input u. We model disturbances via the additive input d. Source: [4]

Consider the system defined in (7). A feedback control loop is to be designed to drive the helicopter to follow a given time varying reference signal r(t). For a linear feedback law (without disturbances d), the input can be written as:

$$u(t) = -Kx(t) + K_r r(t), \tag{17}$$

For this control input, illustrated in Figure 4, the closed-loop state-space equation becomes:

$$\dot{x}(t) = A_{\delta}x(t) + B_{\delta}(-Kx(t) + K_r r(t)) = (A_{\delta} - B_{\delta}K)x(t) + B_{\delta}K_r r(t) \tag{18}$$

The state feedback gain K can be obtained in different ways, for example by pole placement design or by linear quadratic optimization (see Section 3.1).

Note that  $K_r$  does not affect the stability of the system (determined by eigenvalues of  $A_{\delta} - B_{\delta}K$ ) but it does affect the steady-state solution. Since the equilibrium point  $(\dot{x}(t) = 0)$  and steady state output  $y_e(t)$  for the closed loop system (for  $D_{\delta} = 0$ ) are given by:

$$x_e = -(A_\delta - B_\delta K)^{-1} B_\delta K_r r$$

$$y_e = C_p x_e$$
(19)

where  $C_p$  is the matrix selecting which states are to be controlled, and the value of  $K_r$  should be chosen such that the output equals the desired reference  $y_e = r$ . In other words, such that the stationary gain from r to x is the identity matrix I. Therefore,  $K_r$  can be computed as:

$$K_r = -(C_p(A_\delta - B_\delta K)^{-1}B_\delta)^{-1}$$
(20)

## 3.1 Linear Quadratic Regulator (LQR)

A stationary LQR can be used to find the feedback control gain K, which minimizes the following quadratic cost, with respect to a control input u(t):

$$J = \frac{1}{2} \int_0^\infty \left( x(t)^T Q_x x(t) + u(t)^T Q_u u(t) \right) dt.$$
 (21)

where  $Q_x$  and  $Q_u$  are penalty weightings,  $Q_x \in \mathbb{R}^{n \times n}$ ,  $Q_u \in \mathbb{R}^{2 \times 2}$ , where n is the number of states. By solving the Control Algebraic Riccati Equation (CARE) offline we may find the solution of  $\min_{u(t)} J$ . Based on the solution matrix of the Riccati equation, K can be obtained.

### 3.2 LQR with Integral Action

An alternative way to achieve reference tracking, is to augment the system with integral states z, as in Section 1.4, which allow the computation of the cumulative tracking error<sup>1</sup>,  $\int (y-r)dt$ . If for example we would like an integral action at the plant outputs, then the augmented system (for  $D_{\delta} = 0$ ) is given by:

$$\begin{bmatrix} \dot{x}(t) \\ \dot{z}(t) \end{bmatrix} = \underbrace{\begin{bmatrix} A_{\delta} & 0 \\ C_I & 0 \end{bmatrix}}_{A} \begin{bmatrix} x(t) \\ z(t) \end{bmatrix} + \underbrace{\begin{bmatrix} B_{\delta} \\ 0 \end{bmatrix}}_{B} u(t) + \begin{bmatrix} K_r \\ -I \end{bmatrix} r(t)$$
 (22)

$$y(t) = \underbrace{\begin{bmatrix} C_I & 0 \end{bmatrix}}_{C} \begin{bmatrix} x(t) \\ z(t) \end{bmatrix}$$
 (23)

where  $C_I$  selects the system states needed to compute the new integral states. With this formulation, the result is a dynamic controller which gets rid of the steady state error by means of tracking error integration (consequently  $K_r$  is not needed and can be set to zero). Therefore the control policy becomes:

$$u(t) = -K \begin{bmatrix} x(t) \\ z(t) \end{bmatrix} = -[K_P \ K_I] \begin{bmatrix} x(t) \\ z(t) \end{bmatrix}$$
 (24)

where K is the feedback gain, which can be decomposed into proportional  $K_P$  and integral  $K_I$  gains. The resulting equilibirum point for the system (for D = 0) is then:

$$x_e = -(A - BK)^{-1}B(K_r r - K z_e)$$

$$y_e = Cx_e$$
(25)

Note that  $z_e$  is not specified. Since the equilibrium point is given by  $\dot{x} = 0$ , this automatically implies that  $\dot{z} = y - r = 0$ , at equilibrium, i.e. the output equals the reference.

Exercise 10 Design a feedback controller for the linearized system  $(A_{\delta}, B_{\delta}, C_p)$  in order to achieve elevation and travel angle tracking, based on LQ principles. In the nl\_parameters\_3D.m script, compute K based on LQ optimization and then obtain  $K_r$ . In nlmodel\_3D.slx, implement also the closed loop system from Figure 4, while still keeping the previous open-loop implementations of the linearized and nonlinear models.

Exercise 11 (optional) Design an LQR controller with integral action for the system augmented system (A, B, C), in the nl\_parameters\_3D.m script. Implement the LQR closed loop in nlmodel\_3D.mdl, while keeping previous implementations.

<sup>&</sup>lt;sup>1</sup>Depending on how the tracking error is defined, i.e.  $\pm (y-r)$ , the signs in equation (22) change.

# 4 Closed-Loop Simulation

In this section you will use the Simulink model to simulate the closed-loop behaviour of designed controllers.

Exercise 12 Simulate your controllers from Exercise 10 and 11 (optional) on both
the linear and nonlinear system. Make sure to add $u_0$ to the control input of the nonlinear
model such it rests at steady state. Use reference steps on $\varepsilon$ and $\lambda$ separately and pay specific
attention to their outputs. Remember that your state space model uses radians. Comment on
your results.
Answer

Answer		

## 5 Laboratory Session

If you have successfully completed the preparatory exercises above, you should be ready for controlling the physical system. Bring your version of the nl\_parameters\_3D.m script with a loaded version of the linearized model. Be prepared to present your results and explain your conclusions.

#### 5.1 Introduction

In order to start the lab, log into the PC at your station, with your CID and password. Download from the Canvas page the Helicopter lab files. Unzip the 3DOFHelilab file into a folder on your Desktop. In this part of the laboratory you will examine how regulation of the helicopter's elevation works based on the linearized model defined in linnlsys.m. For all tasks, you are required to specify four matrices:  $K \in \mathbb{R}^{2 \times n}$ , where n is the number of states,  $K_I \in \mathbb{R}^{2 \times 2}$ ,  $K_r \in \mathbb{R}^{2 \times 2}$  and  $V_K \in \mathbb{R}^2_+$ , which represent the proportional gain matrix, integral gain matrix and voltage bias respectively. The latter is simply a constant voltage added to the motors, which may also be a scalar since at equilibrium the voltage for both motors should be equal. This matrices are defined in the lab\_init.m script, which must be modified. Save these matrices in each task, so that you can easily go back to previous controllers.

In Sections 5.3 and 5.4 you will be working on elevation and travel angle control, respectively, while in Section 5.5 you will move to travel speed control. In order to execute the files for both these experiments the procedure is the same, for the *initial* run:

- 1. Open the correct Simulink file.
- 3. Click on "Connect to Target" , within the **Simulation** menu in Simulink.
- 4. Click on "Run" , after you have called the lab assistant to verify your solution.

Every time a change is made in the lab\_init.m script, it must be executed before you run the simulation again, i.e. before you press "Run".

Remark 2. You only need to build the code once. If the build is unsuccessful, make sure that the correct compiler is selected in MATLAB. In the Command Window execute the following command: mex -setup. The result should state: "MEX configured to use 'Microsoft Visual C++ 2013 Professional (C)' for C language compilation". If something else is printed, execute the appropriate suggested command to change to the correct compiler.

## 5.2 Warnings

It is very important that you at all times are ready to physically intervene in case the process and the controller turns out to be unstable. There is also an emergency stop button which will cut power to the motors when pressed, please use this option or the stop button in Simulink at any sign of trouble. Before you run the first controller on the real system, call the laboratory assistant.

When running your controllers, always start with the helicopter at its lowest elevation. Furthermore make sure to start at zero travel and pitch angles. Note that for the latter, one person should gently hold up one of the propellers, otherwise the helicopter will start sideways.

When stopping your controllers, make sure to soften the fall by reaching out and grabbing the helicopter with your hand.

In these first experiments, you will use lab\_elev\_travel.mdl to control the process. Make sure to follow the procedure explained in Section 5.1 and respect the warnings in Section 5.2.

Task 1 (Feedback control) Fill in all the blank matrices and run the script. You should set  $K_I$  and  $V_K$  to zero for this task and keep  $Q_u$  fixed at diag([0.1 0.1]) for all tasks. In

this section, the system has two outputs, $\varepsilon$ and $\lambda$ . Also compute $K_r$ using equation (20). First increase the weight on $\varepsilon$ just enough to get the helicopter to lift off. Then find the weights on $\rho$ and $\lambda$ needed to keep the travel movement to a minimum.					
Task 2 (LQ parameter tuning) Start with a conservative weight for $\varepsilon$ , progressive choose a higher weight and record your results, keep the rest of the weights fixed. For example, the start of the weights fixed is a second or conservative weight and record your results, keep the rest of the weights fixed.					
attempt record the weight, steady state elevation and steady state control signal.					
In the previous task, the steady state error is never completely eliminated. We will try to add a base voltage $V_K$ to the control signal. This means that without any regulator control action.					
the propellers should deliver enough thrust for the helicopter to be close to zero elevation, and					
then the controller will just need to steer the helicopter in this region.  Task 3 (Estimating the required base voltage) Using the data from the previous task					
make a linear or second order approximation of the control signal, i.e. voltage to the motors, to the steady state elevation. Extrapolate your results and determine the control signal needed to					
reach zero elevation. Run the process with the added base voltage $V_K$ and record its behaviour					
Task 4 (Feedback control of elevation, with added base voltage) Now try exchanging					
the constant elevation reference for a square wave which alternates between $-10^{\circ}$ and $10^{\circ}$ , inside "Desired Angle from Program" block. Is the steady state error eliminated, and why?					

As you should have noticed, the helicopter steers very close to zero elevation, but it does not work as well for the square wave reference.

We will keep the base voltage and use integration to remove the small steady state error. In the lab\_init.m file, just after the linearized system has been loaded, extend the A and B (not C) matrices to include an integral state for the elevation tracking error, as in equation (15). Do not forget to also extend  $Q_x$ . The resulting K matrix should be split into proportional integrative parts as follows:

```
K = lqr(A,B,Q_x,Q_u);
K_I = [K(:,7) zeros(2,1)];
K = K(:,1:6);
```

Task 5 (Selecting an appropriate feedforward term) What is a reasonable choice for  $K_r$  now that we are using LQR with integral action? Discuss among yourselves and present your hypothesis to the lab assistant.

Task 6 (LQR control of elevation, with added base voltage) Start out with the same weights for the states as in the previous task, run the system and iterate the values of the integral state weight. Use the same square wave as before. What values for  $Q_x$  give good results? Keep a plot of the best result.

Even though you get good results in the previous task, those results are only good around the region close to zero elevation.

Task 7 (Robustness for larger set point changes) With your preferred settings from the previous task, try a square wave which alternates between  $-15^{\circ}$  and  $15^{\circ}$  instead. How do your results look now? Keep a plot of the result.

We will now remove the base voltage, i.e. Set $V_K$ to zero, and try to control the system using only the regulator.  Task 8 (LQR control of elevation, without base voltage) Go back to the smaller square wave and try different settings for the weighting matrices. Once you've found good settings, compare your best result with the plot from Task 6. With the same settings, test your controller for the larger square wave and compare your result with the plot from Task 7.
your controller for the larger square wave and compare your result with the plot from Task 7.
Task 9 (Robustness) You will now try adding a disturbance to the system and supply the smaller square wave as reference. Apply the physical weight supplied by the laboratory assistant to the system. Use the controller from Task 8 and see how it reacts to the disturbance. Save a plot of the result. Next, use the feedback controller with added base voltage from Task 4 and compare the results.
5.4 Travel Angle Control (approx. 0.5 hours)
You will now attempt to control the position of the helicopter around the travel axis, still using the lab_elev_travel.mdl file to test your controllers. Make sure to follow the procedure explained in Section 5.1 and respect the warnings from Section 5.2.  For travel control, there is really no use for a base voltage as the steady state input is independent of the travel angle. We will consider the same controllers as in Section 5.3. Use the weighting matrices and code from <b>Task 8</b> . This means that you will have integral action for the elevation but only proportional control for the travel angle $\lambda$ .
Task 10 (LQ control of travel angle) Apply a constant elevation reference and a square wave reference of amplitude $\pm 10^{\circ}$ for $\lambda$ . Try out different settings for the weights related to $\lambda$ and $\rho$ , let the weights related to elevation stay as they are. Can you find any good settings? Is there a steady state error?

Task 14 (LQR control of travel speed, with integral action) Add integral action is
$\lambda$ , how does the system perform now? Change the reference speed.
Task 15 (Varying travel reference speed) Using your preferred settings from the prevous task, apply a square wave to the speed reference such that the $\dot{\lambda}$ reference switches between say 15°/s and 30°/s.
Task 16 (Varying both reference travel speed and elevation) Using the same reference for North the previous teels add a green ways to the arrivage. Let the green ways
ence for $\lambda$ as in the previous task, add a square wave to the $\varepsilon$ reference. Let the square wave have amplitude 10°. Observe the system behaviour, are you satisfied with its performance?
References
References

- [1] O Wigström, 3-DOF Helicopter Laboratory Session, Chalmers University of Technology, Göteborg, Sweden, 2014.
- [2] J Apkarian, M Lévis, C Fulford *LABORATORY GUIDE: 3 DOF Helicopter Experiment* for MATLAB / Simulink ® Users, Quanser, 2012.
- [3] https://se.mathworks.com/help/slcontrol/ug/linearize-simulink-model.html
- [4] K J Åström, R Murray Feedback Systems: An Introduction for Scientists and Engineers