
DietPi SSH access on Windows machine:

download putty.exe or install putty Application on windows
 http://www.putty.org/
 https://www.chiark.greenend.org.uk/~sgtatham/putty/latest.html


2. find out the Board IP address:

From GUI: dietpi.local and check under system settings the IP address or from router find out the IPaddress.



3. Open puttye.exe /putty application on windows and login with board IP address. Type the board IP address on putty and open.

(For example shows IP address 192.168.0.72, you have to enter your board IP address)



```
P192168.0.72 - PUTTY
login as: root
root@192.168.0.72's password:
```

Login as :root

Password : dietpi

On successful login reach to the root@DietPi~#

Now you can type the basic commands as suggested by Support Isusb , Isusb -t , aplay -I , cat /proc/asound/card1/stream0 , fdisk -I , mount