
CENTRAL PROCESSING UNIT


- Introduction
- General Register Organization
- Stack Organization
- Instruction Formats
- Addressing Modes
- Reduced Instruction Set Computer

MAJOR COMPONENTS OF CPU

- Storage Components Registers Flags
- Execution (Processing) Components
 Arithmetic Logic Unit(ALU)
 Arithmetic calculations, Logical computations, Shifts/Rotates
- Transfer Components
 Bus
- Control Components
 Control Unit



Stack, accumulator and general purpose register organization.



Code Sequence Example for C=A+B


Stack	Accumulator	Register (register-memory)	Register (load-store)
Push A	Load A	Load R1,A	Load R1,A
Push B	Add B	Add R3,R1,B	Load R2,B
Add	Store C	Store R3,C	Add R3,R1,R2
Pop C	Secret in Rock of Afford	na kiza pokilej kio "Tojakina ka	Store R3,C

REGISTERS

- In Basic Computer, there is only one general purpose register, the Accumulator (AC)
- In modern CPUs, there are many general purpose registers
- It is advantageous to have many registers
 - Transfer between registers within the processor are relatively fast
 - Going "off the processor" to access memory is much slower

How many registers will be the best?

GENERAL REGISTER ORGANIZATION



OPERATION OF CONTROL UNIT

The control unit

Directs the information flow through ALU by

- Selecting various Components in the system
- Selecting the Function of ALU

Example: $R1 \leftarrow R2 + R3$

[1] MUX A selector (SELA): BUS A \leftarrow R2

[2] MUX B selector (SELB): BUS B \leftarrow R3

[3] ALU operation selector (OPR): ALU to ADD

[4] Decoder destination selector (SELD): R1 ← Out Bus

Control Word

3	3	3	5
SELA	SELB	SELD	OPR

Encoding of register selection fields

```
Binary

Code SELA SELB SELD

000 Input Input None

001 R1 R1 R1

010 R2 R2 R2

011 R3 R3 R3

100 R4 R4 R4

101 R5 R5 R5
```

110 R6 R6 R6

111 D7 D7 D7

ALU CONTROL

Encoding of ALU operations

OPR	
	<u>eration Symbol</u>
00000	Transfer A TSFA
00001	Increment A INCA
00010	ADD A + B ADD
00101	Subtract A - B SUB
00110	Decrement ADECA
01000	AND A and BAND
01010	OR A and B OR
01100	XOR A and BXOR
01110	Complement A COMA
10000	Shift right A SHRA
11000	Shift left A SHLA

Examples of ALU Microoperations


Microoperation	SELA SELB SELD OPR Control Word
R1 🛭 R2 – R3	R2 R3 R1 SUB 010 011 001 00101
R4 🛭 R4 🖺 R5	R4 R5 R4 OR 100 101 100 01010
R6 🛭 R6 + 1	R6 - R6 INCA 110 000 110 00001
R7 🛭 R1 R1	- R7 TSFA 001 000 111 00000
Output 🛭 R2	R2 - None TSFA 010 000 000 00000
Output I Input	Input - None TSFA 000 000 000 00000
R4 🛭 shl R4	R4 - R4 SHLA 100 000 100 11000
R5 🛭 0 R5	R5 R5 XOR 101 101 101 01100

REGISTER STACK ORGANIZATION

Stack

- Very useful feature for nested subroutines, nested interrupt services
- Also efficient for arithmetic expression evaluation
- Storage which can be accessed in LIFO
- Pointer: SP
- Only PUSH and POP operations are applicable

Register Stack



Push, Pop operations

```
/* Initially, SP = 0, EMPTY = 1, FULL = 0 */
```

PUSH

POP

SP \square SP + 1 DR \square M[SP] M[SP] \square DR SP \square 1) If (SP = 0) then (FULL \square 1) If (SP = 0) then (EMPTY \square 1)

EMPTY 0


FULL Ø 0

Stack grows

In this direction

MEMORY STACK ORGANIZATION

Memory with Program, Data, and Stack Segments



- A portion of memory is used as a stack with a processor register as a stack pointer

-PUSH: $SP \leftarrow SP - 1$

 $M[SP] \leftarrow DR$

- POP: DR \leftarrow M[SP]

 $SP \leftarrow SP + 1$

- Most computers do not provide hardware to check stack overflow (full stack) or underflow (empty stack) → must be done in software

REVERSE POLISH NOTATION

- Arithmetic Expressions: A + B
 - A + B Infix notation
 - + A B Prefix or Polish notation
 - A B + Postfix or reverse Polish notation
 - The reverse Polish notation is very suitable for stack manipulation
- Evaluation of Arithmetic Expressions

Any arithmetic expression can be expressed in parenthesis-free Polish notation, including reverse Polish notation

$$(3*4)+(5*6) \Rightarrow 34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

$$34*56*+$$

PROCESSOR ORGANIZATION

- In general, most processors are organized in one of 3 ways
 - Single register (Accumulator) organization
 - » Basic Computer is a good example
 - » Accumulator is the only general purpose register
 - General register organization
 - » Used by most modern computer processors
 - » Any of the registers can be used as the source or destination for computer operations
 - Stack organization
 - » All operations are done using the hardware stack
 - » For example, an OR instruction will pop the two top elements from the stack, do a logical OR on them, and push the result on the stack

INSTRUCTION FORMAT

Instruction Fields

OP-code field - specifies the operation to be performed

Address field - designates memory address(es) or a processor register(s)

Mode field - determines how the address field is to be interpreted (to get effective address or the operand)

- The number of address fields in the instruction format depends on the internal organization of CPU
- The three most common CPU organizations: Single accumulator organization:

ADD X /*
$$AC \leftarrow AC + M[X] */$$

General register organization:

ADD R1, R2, R3 /* R1
$$\leftarrow$$
 R2 + R3 */

ADD R1, R2 /* R1 \leftarrow R1 + R2 */

MOV R1, R2 /* R1 \leftarrow R2 */

ADD R1, X /* R1
$$\leftarrow$$
 R1 + M[X] */

Stack organization:

THREE, AND TWO-ADDRESS INSTRUCTIONS

Three-Address Instructions

```
Program to evaluate X = (A + B) * (C + D):

ADD R1, A, B /* R1 \( \text{M} \text{M[A]} + \text{M[B]} */

ADD R2, C, D /* R2 \( \text{M} \text{M[C]} + \text{M[D]} */

MUL X, R1, R2 /* M[X] \( \text{R1} \text{R1} * R2 */
```

- Results in short programs
- Instruction becomes long (many bits)
- Two-Address Instructions

Program to evaluate X = (A + B) * (C + D):

```
MOV R1, A /* R1 \( M[A] \) */
ADD R1, B /* R1 \( R1 + M[A] \) */
MOV R2, C /* R2 \( M[C] \) */
ADD R2, D /* R2 \( R2 + M[D] \) */
MUL R1, R2 /* R1 \( R1 + R2 \) */
```

ONE, AND ZERO-ADDRESS INSTRUCTIONS

- One-Address Instructions
 - Use an implied AC register for all data manipulation
 - Program to evaluate X = (A + B) * (C + D):

- Zero-Address Instructions
 - Can be found in a stack-organized computer
 - Program to evaluate X = (A + B) * (C + D):

```
PUSH A /* TOS \( \text{A} \) A /* TOS \( \text{A} \) A /* TOS \( \text{A} \) B /* ADD /* TOS \( \text{A} \) (A + B) */
PUSH C /* TOS \( \text{C} \) C */
PUSH D /* TOS \( \text{C} \) C + D) */
ADD /* TOS \( \text{C} \) (C + D) */
MUL /* TOS \( \text{C} \) (C + D) * (A + B) */
POP X /* M[X] \( \text{A} \) TOS */
```

ADDRESSING MODES

- Addressing Modes
 - * Specifies a rule for interpreting or modifying the address field of the instruction (before the operand is actually referenced)
 - * Variety of addressing modes
 - to give programming flexibility to the user
 - to use the bits in the address field of the instruction efficiently

Implied Mode

Address of the operands are specified implicitly in the definition of the instruction

- No need to specify address in the instruction
- EA = AC, or EA = Stack[SP]
- Examples from Basic Computer CLA, CME, INP
- Immediate Mode

Instead of specifying the address of the operand, operand itself is specified

- No need to specify address in the instruction
- However, operand itself needs to be specified
- Sometimes, require more bits than the address
- Fast to acquire an operand

Register Mode

Address specified in the instruction is the register address

- Designated operand need to be in a register
- Shorter address than the memory address
- Saving address field in the instruction
- Faster to acquire an operand than the memory addressing
- EA = IR(R) (IR(R): Register field of IR)

· Register Indirect Mode

Instruction specifies a register which contains the memory address of the operand

- Saving instruction bits since register address is shorter than the memory address
- Slower to acquire an operand than both the register addressing or memory addressing
- EA = [IR(R)]([x]: Content of x)
- Autoincrement or Autodecrement Mode
- When the address in the register is used to access memory, the value in the register is incremented or decremented by 1 automatically

Direct Address Mode

Instruction specifies the memory address which can be used directly to access the memory

- Faster than the other memory addressing modes
- Too many bits are needed to specify the address for a large physical memory space
- EA = IR(addr) (IR(addr): address field of IR)

Indirect Addressing Mode

The address field of an instruction specifies the address of a memory location that contains the address of the operand

- When the abbreviated address is used large physical memory can be addressed with a relatively small number of bits
 - Slow to acquire an operand because of an additional memory access
 - EA = M[IR(address)]

Relative Addressing Modes

The Address fields of an instruction specifies the part of the address (abbreviated address) which can be used along with a designated register to calculate the address of the operand

- Address field of the instruction is short
- Large physical memory can be accessed with a small number of address bits
 - EA = f(IR(address), R), R is sometimes implied

3 different Relative Addressing Modes depending on R;

- * PC Relative Addressing Mode (R = PC)
 - EA = PC + IR(address)
- * Indexed Addressing Mode (R = IX, where IX: Index Register)
 - EA = IX + IR(address)
- * Base Register Addressing Mode

(R = BAR, where BAR: Base Address Register)

- EA = BAR + IR(address)

ADDRESSING MODES - EXAMPLES -

PC = 200

R1 = 400

XR = 100

AC

Addres	s Memory	
200	Load to AC Mode	
201	Address = 500	
202	Next instruction	
399	450	
400	700	
500	800	
600	900	
702	325	
800	300	

Addressing	Effective		Content
Mode	Address		of AC
Direct address 50	0 /* ΔC ← (500) */	800	

Immediate operand $-/*AC \leftarrow 500 */ 500$

Indirect address 800 /* AC \leftarrow ((500)) */ 300

Relative address 702 /* AC \leftarrow (PC+500) */ 325

Indexed address 600 /* AC \leftarrow (RX+500) */ 900

Register $-/*AC \leftarrow R1 */ 400$

Register indirect 400 /* AC \leftarrow (R1) */ 700

Autoincrement 400 /* AC \leftarrow (R1)+ */ 700

Autodecrement 399 /* AC \leftarrow -(R) */ 450

DATA TRANSFER INSTRUCTIONS

Typical Data Transfer Instructions

Name	Mnemonic
Load Store Move Exchange Input Output Push Pop	LD ST MOV E XCH IN OUT PUSH POP

Data Transfer Instructions with Different Addressing Modes

Mode	Assembly Convention	Register Transfer
Direct address LD		
Indirect address		
Relative address	LD \$ADR AC 🛭 M[I	PC + ADR]
Immediate operand	LD #NBR A	C 🛮 NBR
Index addressing	LD ADR(X) AC 🛭	M[ADR + XR]
Register LD R1	AC 🛭 R1	
	LD (R1) AC 🛭 M[I	
Autoincrement LD	(R1)+ AC M[R1],	R1 🛮 R1 + 1
Autodecrement	LD -(R1) R1	
	• •	

DATA MANIPULATION INSTRUCTIONS

Three Basic Types: Arithmetic instructions

Logical and bit manipulation instructions

Shift instructions

Arithmetic Instructions

Name	Mnemonic
Increment	INC
Decrement	DEC
Add	ADD
Subtract	SUB
Multiply	MUL
Divide	DIV
Add with Carry	ADDC
Subtract with Borrow	SUBB

· Logical and Bratefanipulationi)Instructions

Name	Mnemonic
Clear CLR	
Complement CC)M
AND AND	
OROR	
Exclusive-OR	XOR
Clear carry CL	RC
Set carry SETC	
Complement ca	rry COMC
Enable interrupt	
Disable interrup	

Shift Instructions


Name	Mnemonic
Logical shift right	
Logical shift left SH	L
Arithmetic shift rigl	nt SHRA
Arithmetic shift left	
Rotate right ROR	
Rotate left ROL	
Rotate right thru ca	arry RORC
Rotate left thru car	

FLAG, PROCESSOR STATUS WORD


- In Basic Computer, the processor had several (status) flags 1 bit value that indicated various information about the processor's state – E, FGI, FGO, I, IEN, R
- In some processors, flags like these are often combined into a register

 the processor status register (PSR); sometimes called a processor status word (PSW)
- Common flags in PSW are
 - C (Carry): Set to 1 if the carry out of the ALU is 1
 - S (Sign): The MSB bit of the ALU's output
 - Z (Zero): Set to 1 if the ALU's output is all 0's
 - V (Overflow): Set to 1 if there is an overflow

Status Flag Circuit



PROGRAM CONTROL INSTRUCTIONS



+1
In-Line Sequencing (Next instruction is fetched from the next adjacent location in the memory)

Address from other source; Current Instruction, Stack, etc; Branch, Conditional Branch, Subroutine, etc

Program Control Instructions

Name	Mnemonic
Branch	BR
Jump	JMP
Skip	SKP
Call	CALL
Return	RTN
Compare(by –)	CMP
Compare(by –) Test(by AND)	TST

^{*} CMP and TST instructions do not retain their results of operations (– and AND, respectively). They only set or clear certain Flags.

CONDITIONAL BRANCH INSTRUCTIONS

```
Mnemonic Branch condition
                                Tested condition
  BZ Branch if zero Z = 1
  BNZ Branch if not zero Z = 0
  BC Branch if carry C = 1
  BNC Branch if no carry C = 0
  BP Branch if plus S = 0
        Branch if minus S = 1
  BM
  BV Branch if overflow V = 1
  BNV Branch if no overflow V = 0
     Unsigned compare conditions (A - B)
  BHI
        Branch if higher A > B
  BHE Branch if higher or equal A \ge B
  BLO Branch if lower A < B
  BLOE Branch if lower or equal A \leq B
  BE Branch if equal A = B
  BNE Branch if not equal A ≠ B
     Signed compare conditions (A - B)
  BGT Branch if greater than A > B
  BGE Branch if greater or equal A \ge B
  BLT
        Branch if less than A < B
  BLE Branch if less or equal A \le B
  BE Branch if equal A = B
  BNE Branch if not equal A \neq B
```

SUBROUTINE CALL AND RETURN

· Subroutine Call

Call subroutine

Jump to subroutine

Branch to subroutine

Branch and save return address

- Two Most Important Operations are Implied;
 - * Branch to the beginning of the Subroutine
 - Same as the Branch or Conditional Branch
 - * Save the Return Address to get the address of the location in the Calling Program upon exit from the Subroutine
- Locations for storing Return Address
 - Fixed Location in the subroutine (Memory)
 - Fixed Location in memory
 - · In a processor Register
 - · In memory stack
 - most efficient way

CALL

 $SP \leftarrow SP - 1$

 $M[SP] \leftarrow PC$

PC ← EA

RTN

 $PC \leftarrow M[SP]$

 $SP \leftarrow SP + 1$

PROGRAM INTERRUPT

Types of Interrupts

External interrupts

External Interrupts initiated from the outside of CPU and Memory

- I/O Device → Data transfer request or Data transfer complete
- Timing Device → Timeout
- Power Failure
- Operator

Internal interrupts (traps)

Internal Interrupts are caused by the currently running program

- Register, Stack Overflow
- Divide by zero
- OP-code Violation
- Protection Violation

Software Interrupts

Both External and Internal Interrupts are initiated by the computer HW. Software Interrupts are initiated by the executing an instruction.

- Supervisor Call → Switching from a user mode to the supervisor mode
 - → Allows to execute a certain class of operations which are not allowed in the user mode

INTERRUPT PROCEDURE

Interrupt Procedure and Subroutine Call

- The interrupt is usually initiated by an internal or an external signal rather than from the execution of an instruction (except for the software interrupt)
- The address of the interrupt service program is determined by the hardware rather than from the address field of an instruction
- An interrupt procedure usually stores all the information necessary to define the state of CPU rather than storing only the PC.

The state of the CPU is determined from;


Content of the PC

RISC: Historical Background

IBM System/360, 1964

- The real beginning of modern computer architecture
- Distinction between Architecture and Implementation
- Architecture: The abstract structure of a computer an assembly-language programmer

seen by



- Continuing growth in semiconductor memory and microprogramming
 - ⇒ A much richer and complicated instruction sets
 - ⇒ CISC(Complex Instruction Set Computer)

ARGUMENTS ADVANCED AT THAT TIME

- Richer instruction sets would simplify compilers
- Richer instruction sets would alleviate the software crisis
 - move as much functions to the hardware as possible
- Richer instruction sets would improve architecture quality

ARCHITECTURE DESIGN PRINCIPLES - IN 70's -

- Large microprograms would add little or nothing to the cost of the machine
 - ← Rapid growth of memory technology
 - ⇒ Large General Purpose Instruction Set
- Microprogram is much faster than the machine instructions
 - ← Microprogram memory is much faster than main memory
 - ⇒ Moving the software functions into microprogram for the high performance machines
- Execution speed is proportional to the program size
 - ← Architectural techniques that led to small program
 - ⇒ High performance instruction set
- Number of registers in CPU has limitations
 - ← Very costly
 - ⇒ Difficult to utilize them efficiently

COMPARISONS OF EXECUTION MODELS

 $A \leftarrow B + C$ Data: 32-bit

Register-to-register

8	4	16		
Load	rB	В		
Load	rC	С		
Add	rA	rB	rC	
Store	rA	A		

I = 104b; D = 96b; M = 200b

Memory-to-register

8	16
Load	В
Add	С
Store	Α

I = 72b; D = 96b; M = 168b

Memory-to-memory

8	16	16	16
Add	В	С	A

I = 56b; D = 96b; M = 152b

FOUR MODERN ARCHITECTURES IN 70's

	IBM 370/168	DEC VAX-11/780	Xerox Dorado	Intel iAPX-432
Year	1973	1978	1978	1982
# of instrs.	208	303	270	222
Control mem. size	420 Kb	480 Kb	136 Kb	420 Kb
Instr. size (bits)	16-48	16-456	8-24	6-321
Technology	ECL MSI	TTLMSI	ECLMSI	NMOS VLSI
Execution model	reg-mem mem-mem reg-reg	reg-mem mem-mem reg-reg	stack	stack mem-mem
Cache size	64 Kb	64 Kb	64 Kb	64 Kb

COMPLEX INSTRUCTION SET COMPUTER

- These computers with many instructions and addressing modes came to be known as Complex Instruction Set Computers (CISC)
- One goal for CISC machines was to have a machine language instruction to match each high-level language statement type

VARIABLE LENGTH INSTRUCTIONS

- The large number of instructions and addressing modes led CISC machines to have variable length instruction formats
- The large number of instructions means a greater number of bits to specify them
- In order to manage this large number of opcodes efficiently, they were encoded with different lengths:
 - More frequently used instructions were encoded using short opcodes.
 - Less frequently used ones were assigned longer opcodes.
- Also, multiple operand instructions could specify different addressing modes for each operand
 - For example,
 - » Operand 1 could be a directly addressed register,
 - » Operand 2 could be an indirectly addressed memory location,
 - » Operand 3 (the destination) could be an indirectly addressed register.
- All of this led to the need to have different length instructions in different situations, depending on the opcode and operands used

VARIABLE LENGTH INSTRUCTIONS

- For example, an instruction that only specifies register operands may only be two bytes in length
 - One byte to specify the instruction and addressing mode
 - One byte to specify the source and destination registers.
- An instruction that specifies memory addresses for operands may need five bytes
 - One byte to specify the instruction and addressing mode
 - Two bytes to specify each memory address
 - » Maybe more if there's a large amount of memory.
- Variable length instructions greatly complicate the fetch and decode problem for a processor
- The circuitry to recognize the various instructions and to properly fetch the required number of bytes for operands is very complex

COMPLEX INSTRUCTION SET COMPUTER

- Another characteristic of CISC computers is that they have instructions that act directly on memory addresses
 - For example, ADD L1, L2, L3 that takes the contents of M[L1] adds it to the contents of M[L2] and stores the result in location M[L3]
- An instruction like this takes three memory access cycles to execute
- That makes for a potentially very long instruction execution cycle

- The problems with CISC computers are
 - The complexity of the design may slow down the processor,
 - The complexity of the design may result in costly errors in the processor design and implementation,
 - Many of the instructions and addressing modes are used rarely, if ever

SUMMARY: CRITICISMS ON CISC

High Performance General Purpose Instructions

- Complex Instruction
 - → Format, Length, Addressing Modes
- → Complicated instruction cycle control due to the complex decoding HW and decoding process
 - Multiple memory cycle instructions
 - → Operations on memory data
 - → Multiple memory accesses/instruction
 - Microprogrammed control is necessity
 - → Microprogram control storage takes substantial portion of CPU chip area
 - → Semantic Gap is large between machine instruction and microinstruction
- General purpose instruction set includes all the features required by individually different applications
- → When any one application is running, all the features by the other applications are extra burden to the application

required

REDUCED INSTRUCTION SET COMPUTERS

- In the late '70s and early '80s there was a reaction to the shortcomings of the CISC style of processors
- Reduced Instruction Set Computers (RISC) were proposed as an alternative
- The underlying idea behind RISC processors is to simplify the instruction set and reduce instruction execution time
- RISC processors often feature:
 - Few instructions
 - Few addressing modes
 - Only load and store instructions access memory
 - All other operations are done using on-processor registers
 - Fixed length instructions
 - Single cycle execution of instructions
 - The control unit is hardwired, not microprogrammed

REDUCED INSTRUCTION SET COMPUTERS

- Since all but the load and store instructions use only registers for operands, only a few addressing modes are needed
- By having all instructions the same length, reading them in is easy and fast
- The fetch and decode stages are simple, looking much more like Mano's Basic Computer than a CISC machine
- The instruction and address formats are designed to be easy to decode
- Unlike the variable length CISC instructions, the opcode and register fields of RISC instructions can be decoded simultaneously
- The control logic of a RISC processor is designed to be simple and fast
- The control logic is simple because of the small number of instructions and the simple addressing modes
- The control logic is hardwired, rather than microprogrammed, because hardwired control is faster

REGISTERS

- By simplifying the instructions and addressing modes, there is space available on the chip or board of a RISC CPU for more circuits than with a CISC processor
- This extra capacity is used to
 - Pipeline instruction execution to speed up instruction execution
 - Add a large number of registers to the CPU

PIPELINING

- A very important feature of many RISC processors is the ability to execute an instruction each clock cycle
- This may seem nonsensical, since it takes at least once clock cycle each to fetch, decode and execute an instruction.
- It is however possible, because of a technique known as pipelining
 - We'll study this in detail later
- Pipelining is the use of the processor to work on different phases of multiple instructions in parallel

PIPELINING

- For instance, at one time, a pipelined processor may be
 - Executing instruction i_t
 - Decoding instruction i_{t+1}
 - Fetching instruction i_{+2} from memory
- So, if we're running three instructions at once, and it takes an average instruction three cycles to run, the CPU is executing an average of an instruction a clock cycle
- As we'll see when we cover it in depth, there are complications
 - For example, what happens to the pipeline when the processor branches
- However, pipelined execution is an integral part of all modern processors, and plays an important role

REGISTERS

- By having a large number of general purpose registers, a processor can minimize the number of times it needs to access memory to load or store a value
- This results in a significant speed up, since memory accesses are much slower than register accesses
- Register accesses are fast, since they just use the bus on the CPU itself, and any transfer can be done in one clock cycle
- To go off-processor to memory requires using the much slower memory (or system) bus
- It may take many clock cycles to read or write to memory across the memory bus
 - The memory bus hardware is usually slower than the processor
 - There may even be competition for access to the memory bus by other devices in the computer (e.g. disk drives)
- So, for this reason alone, a RISC processor may have an advantage over a comparable CISC processor, since it only needs to access memory
 - for its instructions, and
 - occasionally to load or store a memory value

CHARACTERISTICS OF RISC

- RISC Characteristics
 - Relatively few instructions
 - Relatively few addressing modes
 - Memory access limited to load and store instructions
 - All operations done within the registers of the CPU
 - Fixed-length, easily decoded instruction format
 - Single-cycle instruction format
- · Advantages of Risc than microprogrammed control
 - VLSI Realization
 - Computing Speed
 - Design Costs and Reliability
 - High Level Language Support

ADVANTAGES OF RISC

VLSI Realization

Control area is considerably reduced

Example:

RISC I: 6%

RISC II: 10%

MC68020: 68%

general CISCs: ~50%

- ⇒ RISC chips allow a large number of registers on the chip
 - Enhancement of performance and HLL support
 - Higher regularization factor and lower VLSI design cost

The GaAs VLSI chip realization is possible

- Computing Speed
 - Simpler, smaller control unit ⇒ faster
 - Simpler instruction set; addressing modes; instruction format
 - ⇒ faster decoding
 - Register operation ⇒ faster than memory operation
 - Register window ⇒ enhances the overall speed of execution
 - Identical instruction length, One cycle instruction execution ⇒ suitable for pipelining ⇒ faster

ADVANTAGES OF RISC

- Design Costs and Reliability
 - Shorter time to design
 - ⇒ reduction in the overall design cost and reduces the problem that the end product will be obsolete by the time the design is completed
 - Simpler, smaller control unit
 - ⇒ higher reliability
 - Simple instruction format (of fixed length)
- · High Level Language Supporty management
 - A single choice of instruction
 - ⇒ shorter, simpler compiler
 - A large number of CPU registers
 - ⇒ more efficient code
 - Register window
 - ⇒ Direct support of HLL
 - Reduced burden on compiler writer