JUNO-Di Model: Date: May 1, 2009 Version: 1.00

1. Data Reception

Parameters marked with "*" in this document can be viewed by using "JUNO-Di Editor."

■Channel Voice Messages

Not received in Performance mode when the RCV MIDI (Receive MIDI) parameter (PERFORM/ MIDI) is OFF.

Note off

Status 2nd byte 3rd byte kkH 8nH vvH 00H 9nH kkH n = MIDI channel number:

0H - FH (ch 1 - 16) kk = note number: 00H - 7FH (0 - 127) vv = note off velocity: 00H - 7FH (0 - 127)

Not received when the ENV MODE (Envelope MODE) parameter (PATCH/CONTROL SW or RHYTHM/COMMON+CONTROL) is NO-SUS.

Note on

<u>Status</u>	2nd byte	3rd byte
9nH	kkH	vvH
n = MIDI channel number:		0H - FH (ch.1 - 16)
kk = note number:		00H - 7FH (0 - 127)
vv = note on velocity:		01H - 7FH (1 - 127)

Polyphonic Key Pressure

Status	2nd byte	3rd byte
AnH	kkH	vvH
n = MIDI channel number:		0H - FH (ch.1 - 16)
kk = note number:		00H - 7FH (0 - 127)
vv = Polyphonic Key Pressure:		00H - 7FH (0 - 127)

Not received in Performance mode when the RCV POLY PRESS (Receive Polyphonic Key Pressure) parameter (PERFORM/MIDI) is OFF.

●Control Change

- If the corresponding Controller number is selected for the PATCH MATRIX CONTROL SOURCE $1, 2, 3 \ or \ 4 \ parameter \ (PATCH/MATRIX \ CONTROL), the \ corresponding \ effect \ will \ occur.$
- If a Controller number that corresponds to the SYSTEM CTRL SRC 1, 2, 3 or 4 parameter (SYSTEM/COMMON) is selected, the specified effect will apply if PATCH MATRIX CONTROL SOURCE 1, 2, 3 or 4 parameter (PATCH/MATRIX CONTROL) is set to SYS-CTRL1, SYS-CTRL2, SYS-CTRL3 or SYS-CTRL4.

OBank Select (Controller number 0, 32)

<u>Status</u>	2nd byte	3rd byte
BnH	00H	mmH
BnH	20H	IIH
MIDL		OU 511/

0H - FH (ch.1 - 16)

mm, II = Bank number: 00 00H - 7F 7FH (bank.1 - bank.16384)

- Not received in Performance mode when the RCV BS (Receive Bank Select) (PERFORM/MIDI) is OFF
- The Performances, Patches, and Rhythms corresponding to each Bank Select are as follows.

BANK MSB	SELECT LSB	PROGRAM NUMBER	GROUP	NUMBER
000		001 - 128	GM Patch	001 - 256
063		001 - 128	GM Patch	001 - 256
085	000	001 - 064	User Performance	001 - 064
	064	001 - 064	Preset Performance	001 - 064
086	000	001 - 008	User Rhythm	001 - 008
	064	001 - 020	Preset Rhythm	001 - 020
087	000	001 - 128	User Patch	001 - 128
	064	001 - 128	Preset Patch	001 - 128
	065	001 - 128	Preset Patch	001 - 128
	:		:	
	072	001 - 058	Preset Patch	
120		001 - 057	GM Rhythm	001 - 009
121	000 -	001 - 128	GM Patch	001 - 256

OModulation (Controller number 1)

Status	2nd byte	3rd byte
BnH	01H	vvH
n = MIDI channel number:		0H - FH (ch.1 - 16)
vv = Modulation depth:		00H - 7FH (0 - 127)

Not received in Performance mode when the RCV MOD (Receive Modulation) parameter (PERFORM/MIDI) is OFF.

OBreath type (Controller number 2)

Status 3rd byte n = MIDI channel number: 0H - FH (ch.1 - 16) 00H - 7FH (0 - 127) vv = Control value:

OFoot type (Controller number 4) 2nd byte 3rd byte 04H vvH

n = MIDI channel number: 0H - FH (ch.1 - 16) vv = Control value: 00H - 7FH (0 - 127)

OPortamento Time (Controller number 5)

Status 2nd byte 05H vvH n = MIDI channel number: 0H - FH (ch.1 - 16)

00H - 7FH (0 - 127)

* In Performance mode, the PORTAMENTO TIME parameter (PERFORM/ALL PARAMETER) will

OData Entry (Controller number 6, 38)

<u>Status</u>	2nd byte	3rd byte	
BnH	06H	mmH	
BnH	26H	IIH	
n = MIDI channel number: 0H - FH (ch.1 - 16)			

mm, II = the value of the parameter specified by RPN/NRPN

mm = MSB, II = LSB

OVolume (Controller number 7)

<u>Status</u>	2nd byte	3rd byte
BnH	07H	vvH
n = MIDI channel number:		0H - FH (ch.1 - 16)
vv = Volume:		00H - 7FH (0 - 127)

- Not received in Performance mode when the RCV VOLUME (Receive Volume) parameter (PERFORM/MIDI) is OFF.
- In Performance mode, the LEVEL parameter (PERFORM/ALL PARAMETERS) (on the JUNO-Di. the Part Level parameter (PART EDIT)) will change.

OPanpot (Controller number 10)

2nd byte

n = MIDI channel number: 0H - FH (ch.1 - 16)

00H - 40H - 7FH (Left - Center - Right). vv = Panpot:

- * Not received in Performance mode when the RCV PAN (Receive PAN) parameter (PERFORM/
- In Performance mode, the PAN parameter (PERFORM/ALL PARAMETERS) will change.

OExpression (Controller number 11)

2nd byte Status 3rd byte 0BH vvH n = MIDI channel number:

0H - FH (ch.1 - 16) vv = Expression: 00H - 7FH (0 - 127)

- Not received when RCV EXP (Receive Expression) parameter (PATCH/CONTROL SW or RHYTHM/COMMON+CONTROL) is OFF
- * Not received in Performance mode when RCV EXP (Receive Expression) parameter (PERFORM/ MIDI) is OFF.

OHold 1 (Controller number 64)

2nd byte Status 3rd byte 40H vvH 0H - FH (ch.1 - 16) n = MIDI channel number:

vv = Control value: 00H - 7FH (0 - 127) 0-63 = OFF, 64-127 = ON

- Not received when RCV HOLD-1 (Receive Hold-1) parameter (PATCH/CONTROL SW or RHYTHM/COMMON+CONTROL) is OFF.
- Not received in Performance mode when RCV HOLD-1 (Receive Hold-1) parameter (PERFORM/ MIDI) is OFF.
- * When the REDAMPER parameter (PATCH/CONTROL SW) is turned ON, 128 discrete steps are recognized for the value.

OPortamento (Controller number 65)

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Control value: 00H - 7FH (0 - 127) 0 - 63 = OFF, 64 - 127 = ON

* In Performance mode, the PORTAMENTO SW parameter (PERFORM/ALL PARAMETERS) will change

OSostenuto (Controller number 66)

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Control value: 00H - 7FH (0 - 127) 0 - 63 = OFF, 64 - 127 = ON

OSoft (Controller number 67)

 Status
 2nd byte
 3rd byte

 BnH
 43H
 vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Control value: 00H - 7FH (0 - 127) 0 - 63 = OFF, 64 - 127 = ON

OLegato Foot Switch (Controller number 68)

 Status
 2nd byte
 3rd byte

 BnH
 44H
 vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Control value: 00H - 7FH (0 - 127) 0 - 63 = OFF, 64 - 127 = ON

* In Performance mode, the LEGATO parameter (PERFORM/ALL PARAMETERS) will change.

OHold-2 (Controller number 69)

 Status
 2nd byte
 3rd byte

 BnH
 45H
 vvH

 n = MIDI channel number:
 0H - FH (ch.1 - 16)

 v = Control value:
 00H - 7FH (0 - 127)

* A hold movement isn't done.

OResonance (Controller number 71)

 Status
 2nd byte
 3rd byte

 BnH
 47H
 vvH

n = MIDI channel number: OH - FH (ch.1 - 16)

vv= Resonance value (relative change): 00H - 40H - 7FH (-64 - 0 - +63),

 In Performance mode, the OFFSET RES (Resonance) parameter (PERFORM/ALL PARAMETERS) will change.

ORelease Time (Controller number 72)

 Status
 2nd byte
 3rd byte

 BnH
 48H
 vvH

 n = MIDI channel number:
 0H - FH (ch.1 - 16)

vv = Release Time value (relative change): 00H - 40H - 7FH (-64 - 0 - +63),

* In Performance mode, the OFFSET REL (Release) parameter (PERFORM/ALL PARAMETERS) will

OAttack time (Controller number 73)

 Status
 2nd byte
 3rd byte

 BnH
 49H
 vvH

 n = MIDI channel number:
 0H - FH (ch.1 - 16)

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Attack time value (relative change): 00H - 40H - 7FH (-64 - 0 - +63),

 In Performance mode, the OFFSET ATK (Attack) parameter (PERFORM/ALL PARAMETERS) will change.

OCutoff (Controller number 74)

 Status
 2nd byte
 3rd byte

 BnH
 4AH
 vvH

 n = MIDI channel number:
 0H - FH (c

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Cutoff value (relative change): 00H - 40H - 7FH (-64 - 0 - +63)

* In Performance mode, the OFFSET COF (Cutoff) parameter (PERFORM/ALL PARAMETERS) will change.

ODecay Time (Controller number 75)

 Status
 2nd byte
 3rd byte

 BnH
 48H
 vvH

 n = MIDI channel number:
 0H - FH (r

n = MIDI channel number: 0H - FH (ch.1 - 16) vv = Decay Time value (relative change): 00H - 40H - 7FH (-64 - 0 - +63)

* In Performance mode, the OFFSET DCY (Decay) parameter (PERFORM/ALL PARAMETERS) will

OVibrato Rate (Controller number 76)

 Status
 2nd byte
 3rd byte

 BnH
 4CH
 vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Vibrato Rate value (relative change): 00H - 40H - 7FH (-64 - 0 - +63)

* In Performance mode, the VIBRATO RATE parameter (PERFORM/ALL PARAMETERS) will change.

OVibrato Depth (Controller number 77)

 Status
 2nd byte
 3rd byte

 BnH
 4DH
 vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Vibrato Depth Value (relative change): 00H - 40H - 7FH (-64 - 0 - +63)

 In Performance mode, the VIBRATO DEPTH parameter (PERFORM/ALL PARAMETERS) will change.

OVibrato Delay (Controller number 78)

 Status
 2nd byte
 3rd byte

 BnH
 4EH
 vvH

 n = MIDI channel number:
 0H - FH (ch.1 - 16)

vv = Vibrato Delay value (relative change): 00H - 40H - 7FH (-64 - 0 - +63)

 In Performance mode, the VIBRATO DELAY parameter (PERFORM/ALL PARAMETERS) will change.

OGeneral Purpose Controller 5 (Controller number 80)

 Status
 2nd byte
 3rd byte

 BnH
 50H
 vvH

 n = MIDI channel number:
 0H - FH (ch.1 - 16)

 vv = Control value:
 00H - 7FH (0 - 127)

* The LEVEL parameter (PATCH/TVA) of Tone 1 will change.

OGeneral Purpose Controller 6 (Controller number 81)

 Status
 2nd byte
 3rd byte

 BnH
 51H
 vvH

 n = MIDI channel number:
 0H - FH (ch.1 - 16)

 vv = Control value:
 00H - 7FH (0 - 127)

* The LEVEL parameter (PATCH/TVA) of Tone 2 will change.

OGeneral Purpose Controller 7 (Controller number 82)

 Status
 2nd byte
 3rd byte

 BnH
 52H
 vvH

 n = MIDI channel number:
 0H - FH (ch.1 - 16)

 vv = Control value:
 00H - 7FH (0 - 127)

* The LEVEL parameter (PATCH/TVA) of Tone 3 will change.

OGeneral Purpose Controller 8 (Controller number 83)

 Status
 2nd byte
 3rd byte

 BnH
 53H
 vvH

 n = MIDI channel number:
 0H - FH (ch.1 - 16)

 vv = Control value:
 00H - 7FH (0 - 127)

 * $\;$ The LEVEL parameter (PATCH/TVA) of Tone 4 will change.

OPortamento control (Controller number 84)

 Status
 2nd byte
 3rd byte

 BnH
 54H
 kkH

n = MIDI channel number: 0H - FH (ch.1 - 16) kk = source note number: 00H - 7FH (0 - 127)

- A Note-on received immediately after a Portamento Control message will change continuously in pitch, starting from the pitch of the Source Note Number.
- * If a voice is already sounding for a note number identical to the Source Note Number, this voice will continue sounding (i.e., legato) and will, when the next Note-on is received, smoothly change to the pitch of that Note-on.
- * The rate of the pitch change caused by Portamento Control is determined by the Portamento Time value.

OEffect 1 (Reverb Send Level) (Controller number 91)

 Status
 2nd byte
 3rd byte

 BnH
 5BH
 vvH

n = MIDI channel number: 0H - FH (ch.1 - 16) vv = Reverb Send Level: 00H - 7FH (0 - 127)

 In Performance mode, the REVERB (Reverb Send Level) parameter (PERFORM/MIXER) will change.

OEffect 3 (Chorus Send Level) (Controller number 93)

 Status
 2nd byte
 3rd byte

 RnH
 5DH
 vvH

n = MIDI channel number: 0H - FH (ch.1 - 16) vv = Chorus Send Level: 00H - 7FH (0 - 127)

* In Performance mode, the CHORUS (Chorus Send Level) parameter (PERFORM/MIXER) will change

ORPN MSB/LSB (Controller number 100, 101)

 Status
 2nd byte
 3rd byte

 BnH
 65H
 mmH

 BnH
 64H
 IIH

 n = MIDI channel number: 0H - FH (ch.1 - 16)
 III

 $\label{eq:mm} mm = upper \ byte \ (MSB) \ of \ parameter \ number \ specified \ by \ RPN$ $II = lower \ byte \ (LSB) \ of \ parameter \ number \ specified \ by \ RPN$

<<< RPN >>>

Control Changes include RPN (Registered Parameter Numbers), which are extended.

When using RPNs, first RPN (Controller numbers 100 and 101; they can be sent in any order) should be sent in order to select the parameter, then Data Entry (Controller numbers 6 and 38) should be sent to set the value. Once RPN messages are received, Data Entry messages that is received at the same MIDI channel after that are recognized as changing toward the value of the RPN messages. In order not to make any mistakes, transmitting RPN Null is recommended after setting parameters you need.

This device receives the following RPNs.

RPN Data entry

MSB, LSB MSB, LSB Notes

00H, 00H mmH, IIH Pitch Bend Sensitivity

mm: 00H - 18H (0 - 24 semitones) II: ignored (processed as 00H)

Up to 2 octave can be specified in semitone steps.

* In Performance mode, the PB RANGE (Pitch Bend Range) parameter (PERFORM/ALL

PARAMETERS) will change.

00H, 02H

00H, 01H mmH, IIH Channel Fine Tuning

mm, II: 20 00H - 40 00H - 60 00H

(-4096 x 100 / 8192 - 0 - +4096 x 100 / 8192 cent)

 $^*\quad \text{In Performance mode, the TUNE FINE parameter (PERFORM/ALL PARAMETERS) will change.}$

Channel Coarse Tuning

mm: 10H - 40H - 70H (-48 - 0 - +48 semitones)

II: ignored (processed as 00H)

* In Performance mode, the TUNE COARSE parameter (PERFORM/ALL PARAMETERS) will change.

00H, 05H mmH, IIH Modulation Depth Range mm, II: 00 00H - 00 06H (0 - 16384 x 600 / 16384 cent)

* Not received in Patch mode.

7FH, 7FH ---, --- RPN null

mmH, IIH

RPN and NRPN will be set as "unspecified." Once this

setting has been made, subsequent * The sai

Parameter values that were previously set will not

change. mm, ll: ignored

●Program Change

<u>Status</u> <u>2nd byte</u> CnH ppH

 Not received in Performance mode when the RCV PC (Receive Program Change) parameter (PERFORM/MIDI) is OFF.

OChannel Pressure

 Status
 2nd byte

 DnH
 vvH

n = MIDI channel number: 0H - FH (ch.1 - 16) vv = Channel Pressure: 00H - 7FH (0 - 127)

 Not received in Performance mode when the RCV CH PRESS (Receive Channel Pressure) parameter (PERFORM/MIDI) is OFF.

Pitch Bend Change

 Status
 2nd byte
 3rd byte

 EnH
 IIH
 mmH

 n = MIDI channel number:
 0H - FH (ch.1 - 16)

mm, II = Pitch Bend value: 00 00H - 40 00H - 7F 7FH (-8192 - 0 - +8191)

* Not received when the RCV BENDER (Receive Bender) parameter (PATCH/CONTROL SW) is OFF.

* Not received in Performance mode when the RCV PB (Receive Pitch Bend) parameter

■Channel Mode Messages

 Not received in Performance mode when the RCV MIDI (Receive MIDI) parameter (PERFORM/ MIDI) is OFF.

•All Sounds Off (Controller number 120)

 Status
 2nd byte
 3rd byte

 BnH
 78H
 00H

 n = MIDL channel number 0H - FH (ch 1 - 16)
 00H

 When this message is received, all notes currently sounding on the corresponding channel will be turned off.

● Reset All Controllers (Controller number 121)

 Status
 2nd byte
 3rd byte

 BnH
 79H
 00H

 n = MIDI channel number: 0H - FH (ch.1 - 16)
 0H

* When this message is received, the following controllers will be set to their reset values.

 Controller
 Reset value

 Pitch Bend Change
 +/-0 (center)

 Polyphonic Key Pressure
 0 (off)

 Channel Pressure
 0 (off)

 Modulation
 0 (off)

 Breath Type
 0 (min)

 Expression
 127 (max)

However the controller will be at minimum.

Hold 1 0 (off)
Sostenuto 0 (off)

RPN unset; previously set data will not change NRPN unset; previously set data will not change

•All Notes Off (Controller number 123)

 Status
 2nd byte
 3rd byte

 BnH
 7BH
 00H

 n = MIDI channel number: 0H - FH (ch.1 - 16)
 0H

* When All Notes Off is received, all notes on the corresponding channel will be turned off. However, if Hold 1 or Sostenuto is ON, the sound will be continued until these are turned off.

●OMNI OFF (Controller number 124)

 Status
 2nd byte
 3rd byte

 BnH
 7CH
 00H

 n = MIDI channel number: 0H - FH (ch.1 - 16)
 0H

* The same processing will be carried out as when All Notes Off is received.

●OMNI ON (Controller number 125)

Status 2nd byte 3rd byte 7DH

n = MIDI channel number: 0H - FH (ch.1 - 16)

The same processing will be carried out as when All Notes Off is received. OMNI ON will not be

●MONO (Controller number 126)

2nd byte BnH 7EH mmH n = MIDI channel number: 0H - FH (ch.1 - 16) mm = mono number: 00H - 10H (0 - 16)

- * The same processing will be carried out as when All Notes Off is received.
- * In Performance mode, the MONO/POLY parameter (PERFORM/ALL PARAMETERS) will change.

●POLY (Controller number 127)

2nd byte n = MIDI channel number: 0H - FH (ch.1 - 16)

- * The same processing will be carried out as when All Notes Off is received.
- In Performance mode, the MONO/POLY parameter (PERFORM/ALL PARAMETERS) will change.

■System Realtime Message

Timing Clock

Status

F8H

* Received by the JUNO-Di if the Sync Mode parameter (SYSTEM/MIDI) is set to SLAVE.

●Start

Status

* Received by the JUNO-Di if the Sync Mode parameter (SYSTEM/MIDI) is set to SLAVE.

●Continue

Status FBH

* Received by the JUNO-Di if the Sync Mode parameter (SYSTEM/MIDI) is set to SLAVE.

Stop

Status FCH

* Received by the JUNO-Di if the Sync Mode parameter (SYSTEM/MIDI) is set to SLAVE.

Active Sensing

* When Active Sensing is received, the unit will begin monitoring the intervals of all further messages. While monitoring, if the interval between messages exceeds 420 ms, the same processing will be carried out as when All Sounds Off, All Notes Off and Reset All Controllers are received, and message interval monitoring will be halted.

■System Exclusive Message

Data byte iiH. ddH. ..

System Exclusive Message status

ii = ID number: an ID number (manufacturer ID) to indicate the manufacturer whose

Exclusive message this is. Roland's manufacturer ID is 41H.

ID numbers 7EH and 7FH are extensions of the MIDI standard; Universal Non-realtime Messages (7EH) and Universal Realtime Messages (7FH).

dd,...,ee = data: 00H - 7FH (0 - 127) EOX (End Of Exclusive) F7H:

Of the System Exclusive messages received by this device, the Universal Non-realtime messages and the Universal Realtime messages and the Data Request (RQ1) messages and the Data Set (DT1) messages will be set automatically.

●Universal Non-realtime System Exclusive Messages

Oldentity Request Message

Status Data byte Status 7EH, dev, 06H, 01H

Byte Explanation FOH Exclusive status

7EH ID number (Universal Non-realtime Message)

Device ID (dev: 10H, 7FH) dev 06H Sub ID#1 (General Information) 01H Sub ID#2 (Identity Request) F7H EOX (End Of Exclusive)

* When this message is received, Identity Reply message (p. 9) will be transmitted.

OGM1 System On

Status Data byte Status FOH 7EH, 7FH, 09H, 01H F7H

Byte Explanation F0H Exclusive status

ID number (Universal Non-realtime Message) 7EH

7FH Device ID (Broadcast)

Sub ID#1 (General MIDI Message) 09H Sub ID#2 (General MIDI 1 On) F7H EOX (End Of Exclusive)

* When this messages is received, this instrument will turn to the Performance mode.

OGM2 System On

Status Data byte Status 7EH 7FH 09H 03H

Byte Explanation FOH Exclusive status

7EH ID number (Universal Non-realtime Message)

Device ID (Broadcast) 09H Sub ID#1 (General MIDI Message) 03H Sub ID#2 (General MIDI 2 On) EOX (End Of Exclusive)

* When this messages is received, this instrument will turn to the Performance mode.

○GM System Off

Status Data byte Status F0H 7EH, 7F, 09H, 02H F7H

Byte Explanation Exclusive status

ID number (Universal Non-realtime Message) 7EH

7FH Device ID (Broadcast)

09H Sub ID#1 (General MIDI Message) Sub ID#2 (General MIDI Off) 02H EOX (End Of Exclusive)

* When this messages is received, this instrument will return to the Performance mode.

●Universal Realtime System Exclusive Messages

OMaster Volume

<u>Status</u>	<u>Data byte</u>	Status
F0H	7FH, 7FH, 04H, 01H, IIH, mmH	F7H

Byte Explanation FOH Exclusive status

7FH ID number (universal realtime message)
7FH Device ID (Broadcast)

 7FH
 Device ID (Broadcast)

 04H
 Sub ID#1 (Device Control)

 01H
 Sub ID#2 (Master Volume)

 IIH
 Master Volume lower byte

 mmH
 Master Volume upper byte

 F7H
 EOX (End of Exclusive)

- * The lower byte (IIH) of Master Volume will be handled as 00H.
- * The MASTER LEVEL parameter (SYSTEM/COMMON) will change.

OMaster Fine Tuning

Status	Data byte	<u>Status</u>
F0H	7FH, 7FH, 04H, 03H, IIH, mmH	F7H

ByteExplanationFOHExclusive status

7FH ID number (universal realtime message)
7FH Device ID (Broadcast)
04H Sub ID#1 (Device Control)
03H Sub ID#2 (Master Fine Tuning)
IIH Master Fine Tuning LSB
mmH Master Fine Tuning MSB
F7H EOX (End Of Exclusive)

mm, II: 00 00H - 40 00H - 7F 7FH (-100 - 0 - +99.9 [cents])

OMaster Coarse Tuning

<u>Status</u>	Data byte	<u>Status</u>
F0H	7FH, 7FH, 04H, 04H, IIH, mmH	F7

ByteExplanationF0HExclusive status

7FH ID number (universal realtime message)

 7FH
 Device ID (Broadcast)

 04H
 Sub ID#1 (Device Control)

 04H
 Sub ID#2 (Master Coarse Tuning)

 IIH
 Master Coarse Tuning LSB

 mmH
 Master Coarse Tuning MSB

 F7H
 EOX (End Of Exclusive)

IIH: ignored (processed as 00H)

mmH: 28H - 40H - 58H (-24 - 0 - +24 [semitones])

Global Parameter Control

* Not received in Patch mode.

OReverb Parameters

01H ppH

vvH

<u>Status</u>	<u>Data byte</u>	<u>Status</u>
F0H	7FH, 7FH, 04H, 05H, 01H, 01H,	F7H
	01H, 01H, 01H, ppH, vvH	
<u>Byte</u>	Explanation	
F0H	Exclusive status	
7FH	ID number (universal realtime message)	
7FH	Device ID (Broadcast)	
04H	Sub ID#1 (Device Control)	
05H	Sub ID#2 (Global Parameter Control)	
01H	Slot path length	
01H	Parameter ID width	
01H	Value width	
01H	Slot path MSB	

Slot path LSB (Effect 0101: Reverb)

Parameter to be controlled.

Value for the parameter.

	pp=0	Reverb Type
	vv = 00H	Small Room
	vv = 01H	Medium Room
	vv = 02H	Large Room
	vv = 03H	Medium Hall
	vv = 04H	Large Hall
	vv = 08H	Plate
	pp=1	Reverb Time
	vv = 00H - 7FH	0 - 127
7H	EOX (End Of Exclus	sive)

OChorus Parameters

<u>Status</u>	<u>Data byte</u>	<u>Status</u>
F0H	7FH, 7FH, 04H, 05H, 01H, 01H,	F7H

01H, 01H, 02H, ppH, vvH

<u>Byte</u> <u>Explanation</u> FOH Exclusive status

7FH ID number (universal realtime message)

 7FH
 Device ID (Broadcast)

 04H
 Sub ID#1 (Device Control)

 05H
 Sub ID#2 (Global Parameter Control)

01H Slot path length 01H Parameter ID width 01H Value width 01H Slot path MSB

02H Slot path LSB (Effect 0102: Chorus)
ppH Parameter to be controlled.
vvH Value for the parameter.

pp=0 Chorus Type vv=0 Chorus1 Chorus2 vv=1 Chorus3 vv=2 Chorus4 vv=3 vv=4FR Chorus vv=5 Flanger Mod Rate pp=1 vv= 00H - 7FH 0 - 127 Mod Depth pp=2 yy = 00H - 7FH0 - 127 pp=3 Feedback vv = 00H - 7FH Send To Reverb pp=4 vv = 00H - 7FH 0 - 127

F7H EOX (End Of Exclusive)

OChannel Pressure

<u>Status</u>	<u>Data byte</u>	<u>Status</u>
F0H	7FH, 7FH, 09H, 01H, 0nH, ppH, rrH	F7H

Byte Explanation
F0H Exclusive status

7FH ID number (universal realtime message)

7FH Device ID (Broadcast)

 09H
 Sub ID#1 (Controller Destination Setting)

 01H
 Sub ID#2 (Channel Pressure)

 0nH
 MIDI Channel (00 - 0F)

ppH Controlled parameter rrH Controlled range

0=qq

rr = 28H - 58H -24 - +24 [semitones] pp=1 Filter Cutoff Control rr = 00H - 7FH-9600 - +9450 [cents] Amplitude Control pp=2 rr = 00H - 7FH 0 - 200% LFO Pitch Depth pp=3 rr = 00H - 7FH 0 - 600 [cents] pp=4 LFO Filter Depth rr = 00H - 7FH0 - 2400 [cents] LFO Amplitude Depth pp=5

0 - 100%

Pitch Control

F7H EOX (End Of Exclusive)

rr = 00H - 7FH

The MASTER TUNE parameter (SYSTEM/COMMON) (on the JUNO-Di, the Master Tune parameter (SYSTEM/SOUND)) will change.

^{*} The MASTER KEY SHIFT parameter (SYSTEM/COMMON) will change.

OController

Status Status 7FH, 7FH, 09H, 03H, 0nH, ccH, ppH, rrH Byte Explanation

FOH **Exclusive status** 7FH

ID number (universal realtime message)

7FH Sub ID#1 (Controller Destination Setting)

09H Sub ID#2 (Control Change) 03H 0nH MIDI Channel (00 - 0F)

ccH Controller number (01 - 1F, 40 - 5F)

ррН Controlled parameter rrH

Controlled range

Pitch Control pp=0 rr = 28H - 58H -24 - +24 [semitones] Filter Cutoff Control rr = 00H - 7FH -9600 - +9450 [cents] pp=2 Amplitude Control rr = 00H - 7FH 0 - 200% pp=3 LFO Pitch Depth rr = 00H - 7FH 0 - 600 [cents] LFO Filter Depth pp=4 rr = 00H - 7FH 0 - 2400 [cents]

pp=5 LFO Amplitude Depth rr = 00H - 7FH 0 - 100%

EOX (End Of Exclusive)

OScale/Octave Tuning Adjust

F7H

F7H

Status

FOH

Data byte Status Status 7EH, 7FH, 08H, 08H, ffH, ggH, hhH, ssH... F0H

Byte Explanation

7EH ID number (Universal Non-realtime Message)

7FH Device ID (Broadcast) Sub ID#1 (MIDI Tuning Standard) 08H

08H Sub ID#2 (scale/octave tuning 1-byte form)

ffH Channel/Option byte 1 bits 0 to 1 = channel 15 to 16 bit 2 to 6 = Undefined ggH Channel byte 2

bits 0 to 6 = channel 8 to 14

bits 0 to 6 = channel 1 to 7

ssH 12 byte tuning offset of 12 semitones from C to B

00H = -64 [cents]

40H = 0 [cents] (equal temperament) 7FH = +63 [cents]

7FH, 7FH, 0AH, 01H, 0nH, kkH, nnH, vvH

Status

F7H

EOX (End Of Exclusive)

Data byte

OKey-based Instrument Controllers

Byte	Explanation		
F0H	Exclusive status		
7FH	ID number (universal realtime message)		
7FH	Device ID (Broadcast)		
0AH	Sub ID#1 (Key-Based In	nstrument Control)	
01H	Sub ID#2 (Controller)		
0nH	MIDI Channel (00 - 0FI	H)	
kkH	Key Number		
nnH	Control Number		
vvH	Value		
	nn=07H Level		
	vv = 00H - 7FH	0 - 200% (Relative)	
	nn=0AH	Pan	
	vv = 00H - 7FH	Left - Right (Absolute)	
	nn=5BH	Reverb Send	
	vv = 00H - 7FH	0 - 127 (Absolute)	

Chorus Send

0 - 127 (Absolute)

F7 EOX (End Of Exclusive)

nn=5D

vv = 00H - 7FH

Data Transmission

This instrument can use exclusive messages to exchange many varieties of internal settings with

The model ID of the exclusive messages used by this instrument is 00H 00H 3AH.

OData Request 1 (RQ1)

This message requests the other device to transmit data. The address and size indicate the type and amount of data that is requested.

When a Data Request message is received, if the device is in a state in which it is able to transmit data, and if the address and size are appropriate, the requested data is transmitted as a Data Set 1 (DT1) message. If the conditions are not met, nothing is transmitted.

<u>Status</u>	Data byte	Status
F0H	41H, dev, 00H, 00H, 3AH, 11H, aaH, bbH, ccH,	F7H

ddH, ssH, ttH, uuH, vvH, sum

<u>Byte</u> Remarks Exclusive status 41H ID number (Roland) device ID (dev: 10H 7FH) dev 00H model ID #1 (JUNO-Di) 00H model ID #2 (JUNO-Di) зан model ID #3 (JUNO-Di) 11H command ID (RO1) address MSB aaH hhH address address ddH address LSB ssH size MSB ttΗ size uuH size checksum sum EOX (End Of Exclusive) F7H

- * The size of data that can be transmitted at one time is fixed for each type of data. And data requests must be made with a fixed starting address and size. Refer to the address and size given in "Parameter Address Map" (p. 10).
- * For the checksum, refer to p. 24.

^{*} This parameter affects drum instruments only.

OData set 1 (DT1)

Status

FOH 41H, dev, 00H, 00H, 3AH, 12H, aaH, bbH, F7 ccH, ddH, eeH, ... ffH, sum

Byte Explanation
FOH Exclusive status

 Byte
 Explanation

 F0H
 Exclusive status

 41H
 ID number (Roland)

 dev
 Device ID (dev: 10H, 7FH)

 00H
 Model ID #1 (JUNO-Di)

 00H
 Model ID #2 (JUNO-Di)

 3AH
 Model ID #3 (JUNO-Di)

 12H
 Command ID (DT1)

Data byte

aaH Address MSB: upper byte of the starting address of the data to be

sent

bbH Address: upper middle byte of the starting address of the

data to be sent

Status

Status

ccH Address: lower middle byte of the starting address of the data

to be sent

ddH Address LSB: lower byte of the starting address of the data to be

sent.

eeH Data: the actual data to be sent. Multiple bytes of data are transmitted in order starting from the address.

F7H EOX (End Of Exclusive)

- * The amount of data that can be transmitted at one time depends on the type of data, and data will be transmitted from the specified starting address and size. Refer to the address and size given in "Parameter Address Map" (p. 10).
- Data larger than 256 bytes will be divided into packets of 256 bytes or less, and each packet will be sent at an interval of about 20 ms.
- * Regarding the checksum, please refer to p. 24.

Data byte

Status

Status	<u>Data byte</u>			Status			
F0H	41H, dev, 42H, 12H, a	aH, bbH, ccH,		F7H			
	ddH, eeH, sum						
<u>Byte</u>	<u>Explanation</u>						
F0H	Exclusive status						
41H	ID number (Roland)						
dev	Device ID (dev: 10H, 7	7FH)					
42H	Model ID (GS)						
12H	Command ID (DT1)						
aaH	Address MSB:	upper byte	of th	e starting	address	of	the
		transmitted da	ata				
bbH	Address:	middle byte	of th	ne starting	address	of	the
		transmitted da	ata				
ссН	Address LSB:	lower byte of t	the star	ting address	of the tra	nsmi	tted
		data					
ddH	Data:	the actual dat	a to be	transmitted	. Multiple	byte	es of
		data are transr	mitted s	starting from	the addre	ess.	
:	:						
eeH	Data						
sum	Checksum						
F7H	EOX (End Of Exclusive	<u>e</u>)					
		•					

- * The amount of data that can be transmitted at one time depends on the type of data, and data will be transmitted from the specified starting address and size. Refer to the address and size given in "Parameter Address Map" (p. 10).
- Data larger than 256 bytes will be divided into packets of 256 bytes or less, and each packet will be sent at an interval of about 20 ms.
- * Regarding the checksum, please refer to p. 24.

2. Data Transmission

■Channel Voice Messages

Note off

Status 2nd byte 3rd byte 8nH kkH vvH

n = MIDI channel number: 0H - FH (ch.1 - 16) kk = note number: 00H - 7FH (0 - 127) 00H - 7FH (0 - 127) vv = note off velocity:

Note on

Status 3rd byte 2nd byte kkH 9nH vvH 0H - FH (ch.1 - 16) n = MIDI channel number:

kk = note number 00H - 7FH (0 - 127) vv = note on velocity: 01H - 7FH (1 - 127)

Control Change

By selecting a controller number that corresponds to the setting of parameters of controllers, the JUNO-Di can transmit any control change message.

OBank Select (Controller number 0, 32)

2nd byte BnH 00H mmH BnH 20H IIH

n = MIDI channel number: 0H - FH (ch.1 - 16)

mm, II = Bank number: 00 00H - 7F 7FH (bank.1 - bank.16384)

These messages are transmitted when Patch, Rhythm Set or Performance is selected.

OModulation (Controller number 1)

2nd byte Status 3rd byte 01H

n = MIDI channel number: 0H - FH (ch 1 - 16) vv = Modulation depth: 00H - 7FH (0 - 127)

OBreath type (Controller number 2)

2nd byte 3rd byte BnH 02H vvH

n = MIDI channel number: 0H - FH (ch.1 - 16) vv = Control value: 00H - 7FH (0 - 127)

OPortamento Time (Controller number 5)

2nd byte Status

n = MIDI channel number: 0H - FH (ch.1 - 16) 00H - 7FH (0 - 127) vv = Portamento Time:

OData Entry (Controller number 6, 38)

Status 2nd byte 3rd byte 06H BnH mmH 26H n = MIDI channel number: 0H - FH (ch.1 - 16)

mm, II = the value of the parameter specified by RPN/NRPN

mm = MSB, II = LSB

OVolume (Controller number 7)

2nd byte 3rd byte

n = MIDI channel number: 0H - FH (ch.1 - 16) 00H - 7FH (0 - 127) vv = Volume:

OPanpot (Controller number 10)

Status 2nd byte 3rd byte 0AH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Panpot: 00H - 40H - 7FH (Left - Center - Right),

OExpression (Controller number 11)

Status 2nd byte 3rd byte OBH

0H - FH (ch 1 - 16) n = MIDI channel number: 00H - 7FH (0 - 127)

OHold 1 (Controller number 64)

Status 3rd byte

n = MIDI channel number: 0H - FH (ch.1 - 16)

00H - 7FH (0 - 127) 0-63 = OFF, 64-127 = ON vv = Control value:

* If the HOLD PEDAL Assign parameter is set to HOLD and the Continuous Hold parameter (SYSTEM/HOLD PEDAL) is set to OFF on the JUNO-Di, only 00H (OFF) or 7FH (ON) can be transmitted as the value of the control.

OPortamento (Controller number 65)

Status 2nd byte 3rd byte RnH **11H**

0H - FH (ch.1 - 16) n = MIDI channel number:

vv = Control value: 00H - 7FH (0 - 127) 0 - 63 = OFF, 64 - 127 = ON

OResonance (Controller number 71)

Status 2nd byte 3rd byte RnH 47H vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv= Resonance value (relative change): 00H - 40H - 7FH (-64 - 0 - +63)

ORelease Time (Controller number 72)

Status 2nd byte 3rd byte 48H

n = MIDI channel number: 0H - FH (ch 1 - 16)

vv = Release Time value (relative change): 00H - 40H - 7FH (-64 - 0 - +63)

OAttack time (Controller number 73)

2nd byte 3rd byte 49H vvH 0H - FH (ch.1 - 16) n = MIDI channel number:

vv = Attack time value (relative change): 00H - 40H - 7FH (-64 - 0 - +63)

OCutoff (Controller number 74)

<u>Status</u> 2nd byte 3rd byte

n = MIDI channel number: 0H - FH (ch.1 - 16) 00H - 40H - 7FH (-64 - 0 - +63) vv = Cutoff value (relative change):

OGeneral Purpose Controller 5 (Controller number 80)

2nd byte 3rd byte 50H

n = MIDI channel number: 0H - FH (ch.1 - 16) vv = Control value: 00H - 7FH (0 - 127)

OGeneral Purpose Controller 6 (Controller number 81)

Status 2nd byte 3rd byte 51H

n = MIDI channel number: 0H - FH (ch.1 - 16) 00H - 7FH (0 - 127) vv = Control value:

OGeneral Purpose Controller 7 (Controller number 82)

2nd byte 3rd byte Status BnH 52H vvH

n = MIDI channel number: 0H - FH (ch.1 - 16) vv = Control value: 00H - 7FH (0 - 127)

OGeneral Purpose Controller 8 (Controller number 83)

2nd byte 3rd byte BnH 53H vvH

n = MIDI channel number: 0H - FH (ch.1 - 16) vv = Control value: 00H - 7FH (0 - 127)

OPortamento control (Controller number 84)

2nd byte Status

0H - FH (ch.1 - 16) n = MIDI channel number: 00H - 7FH (0 - 127) kk = source note number:

Program Change

Status 2nd byte ррН

n = MIDI channel number: 0H - FH (ch.1 - 16) 00H - 7FH (prog.1 - prog.128)

* These messages are transmitted when Patch, Rhythm Set or Performance is selected.

●Channel Pressure

2nd byte Status DnH vvH

n = MIDI channel number: 0H - FH (ch 1 - 16) vv = Channel Pressure: 00H - 7FH (0 - 127)

Pitch Bend Change

Status 2nd byte 3rd byte EnH mmH n = MIDI channel number: 0H - FH (ch.1 - 16)

mm, II = Pitch Bend value: 00 00H - 40 00H - 7F 7FH (-8192 - 0 - +8191)

■Channel Mode Messages

●MONO (Controller number 126)

2nd byte 3rd byte Status BnH

n = MIDI channel number: 0H - FH (ch.1 - 16) mm = mono number: 00H - 10H (0 - 16)

●POLY (Controller number 127)

Status 2nd byte 3rd byte BnH 7FH 00H n = MIDI channel number: 0H - FH (ch.1 - 16)

■System Realtime Messages

Active Sensing

<u>Status</u>

* This message is transmitted at intervals of approximately 250 msec.

■System Exclusive Messages

Universal Non-realtime System Exclusive Message" and Data Set 1 (DT1) are the only System Exclusive messages transmitted by the JUNO-Di.

●Universal Non-realtime System Exclusive Message

Oldentity Reply Message (JUNO-Di)

Receiving Identity Request Message (p. 4), the JUNO-Di send this message.

<u>Status</u> Data byte 7EH, dev, 06H, 02H, 41H, 3AH, 02H, F7H

00H, 00H, 00H, 03H, 00H, 00H

Byte Explanation Exclusive status

7EH ID number (Universal Non-realtime Message)

10H Device ID (dev: 10H) Sub ID#1 (General Information) 06H 02H Sub ID#2 (Identity Reply) 41H ID number (Roland) 3AH 02H Device family code 00H 00H Device family number code 00H 03H 00H 00H Software revision level EOX (End of Exclusive)

Data Transmission

OData set 1 (DT1)

Status Data byte Status F0H 41H, dev, 00H, 00H, 3AH, 12H, aaH, bbH, F7H

ccH, ddH, eeH, ... ffH, sum

Byte Explanation F0H Exclusive status 41H ID number (Roland) Device ID (dev: 10H, 7FH) 00H Model ID #1 (JUNO-Di) 00H Model ID #2 (JUNO-Di) Model ID #3 (JUNO-Di) 3AH 12H Command ID (DT1)

Address MSB upper byte of the starting address of the data to be

sent

Address: upper middle byte of the starting address of the bbH

data to be sent

ссН Address: lower middle byte of the starting address of the data

Address LSB: lower byte of the starting address of the data to be ddH

sent.

eeH Data: the actual data to be sent. Multiple bytes of data are

transmitted in order starting from the address.

ffH Data sum Checksum F7H EOX (End Of Exclusive)

- * The amount of data that can be transmitted at one time depends on the type of data, and data will be transmitted from the specified starting address and size. Refer to the address and size given in "Parameter Address Map" (p. 10).
- * Data larger than 256 bytes will be divided into packets of 256 bytes or less, and each packet will be sent at an interval of about 20 ms.

3. Parameter Address Map

- * Transmission of "#" marked address is divided to some packets. For example, ABH in hexadecimal notation will be divided to 0AH and 0BH, and is sent/received in this order.
- * "<*>" marked address or parameters are ignored when the JUNO-Di received them.

3.1 JUNO-Di (ModelID = 00H 00H 3AH)

Start Address	Description
01 00 00 00	Setup
02 00 00 00	System
OF 00 00 00	(for editor)
10 00 00 00 11 00 00 00 11 20 00 00	Temporary Performance Temporary Patch/Rhythm (Performance Mode Part 1) Temporary Patch/Rhythm (Performance Mode Part 2)
14 60 00 00 1E 00 00 00 1E 11 00 00 1E 13 00 00 1E 14 00 00 1F 00 00 00 1F 20 00 00	Temporary Patch/Rhythm (Performance Mode Part 16) Temporary Rhythm Pattern Temporary Arpeggio Temporary Rhythm Group Temporary Chord Memory Temporary Patch/Rhythm (Patch Mode Part 1) Temporary Patch/Rhythm (Patch Mode Part 2)
20 00 00 00 20 01 00 00 : 20 3F 00 00	User Performance (01) User Performance (02) User Performance (64)
30 00 00 00 30 01 00 00 : 30 7F 00 00	User Patch (001) User Patch (002) User Patch (128)
40 00 00 00 40 10 00 00 40 70 00 00	User Rhythm Set (001) User Rhythm Set (002) User Rhythm Set (008)

* System

+		÷
Offset Address	Description	
00 00 00	System Common System Controller	

* Temporary Patch/Rhythm

Offset		í
Address	Description	İ
00 00 00	Temporary Patch	l

* Performance

Offset Address	Description
00 06 00 00 08 00 00 0A 00	Performance Common MFX1 Performance Common Chorus Performance Common Reverb
00 11 00	Performance MIDI (Channel 2)
00 1F 00 00 20 00 00 21 00	
00 2F 00 00 50 00 00 51 00	Performance Part (Part 16) Performance Zone (Channel 1) Performance Zone (Channel 2)
00 5F 00	Performance Zone (Channel 16)

* Patch

Offset Address	Description
00 00 00 00 02 00 00 04 00 00 06 00 00 10 00 00 20 00 00 24 00 00 26 00	Patch Common MFX Patch Common MFX Patch Common Chorus Patch Common Reverb Patch TMT (Tone Mix Table) Patch Tone (Tone 1) Patch Tone (Tone 2) Patch Tone (Tone 3) Patch Tone (Tone 3) Patch Tone (Tone 4)

* Rhythm

İ	Offset Address	Description
	00 00 00 00 02 00 00 04 00 00 06 00 00 10 00 00 12 00 :	Rhythm Common Rhythm Common MFX Rhythm Common Chorus Rhythm Common Reverb Rhythm Tone (Key # 21) Rhythm Tone (Key # 22) Rhythm Tone (Key # 108)

* Arpeggio (Rhythm Pattern)

Offset Address	Description	
00 00 00 00 10 00 00 11 00 :	Arpeggio Common Arpeggio Pattern (Note 1) Arpeggio Pattern (Note 2)	

00 1F 00 | Arpeggio Pattern (Note 16)

* Rhythm Group

Offset Address	Description	ĺ
00 00 00	Rhythm Group	l

* Chord Memory

Offset	
Address	Description
00 00 00 00 10 00 00 11 00 : 00 1B 00	Chord Memory Common Chord Memory Pattern (key 1) Chord Memory Pattern (key 2) Chord Memory Pattern (key 12)

* Setup

Offset Address		Description	
00 00	+ 0000 0aaa	Sound Mode	(0 - 4
	 +	PATCH, PERFO	RM, GM1, GM2, GS
00 01 00 02	Oaaa aaaa	Performance Bank Select MSB (CC# Performance Bank Select LSB (CC#	32) (0 - 12
00 03	0aaa aaaa	Performance Program Number (PC)	(0 - 12
00 04 00 05	Oaaa aaaa Oaaa aaaa	Kbd Patch Bank Select MSB (CC# 0) Kbd Patch Bank Select LSB (CC# 32	(0 - 12° (0 - 12°
00 06	Oaaa aaaa	Kbd Patch Program Number (PC)	(0 - 12)
00 07 00 08	Oaaa aaaa Oaaa aaaa	Rhy Patch Bank Select MSB (CC# 0) Rhy Patch Bank Select LSB (CC# 32 Rhy Patch Program Number (PC)) (0 - 12
00 09	0aaa aaaa +	+	
00 0A	0000 000a	MFX1 Switch	(0 - BYPASS, O
00 OB	0000 000a	MFX2 Switch	(0 - BYPASS, O (0 -
00 OC	0000 000a	MFX3 Switch	(0 - BYPASS, O
00 0D	0000 000a	Chorus Switch	BYPASS, 0: (0 - OFF, 0: (0 -
00 OE	0000 000a	Reverb Switch	(0 - OFF, 0
00 OF 00 10	0000 000a 0000 000a	(reserve) <*> (reserve) <*>	
00 10	0000 000a	(reserve) <*>	
00 12	0000 aaaa	Transpose Value	(59 - 7
00 13	0000 0aaa	Octave Shift	(61 - 6 -3 - +
00 14	 + 0000 0aaa	D Beam Select	(0 -
00 15	0000 00aa	OFF, (reserv) (reserve) <*>	, SOLO-SYN, ASG
00 16 00 17	0000 000a 0aaa aaaa	(reserve) <*> (reserve) <*> Arp/Ptn Grid	(0 -
00 17		04_, 08 16	_, 08L, 08H, 08 , 16L, 16H, 16
00 18	Oaaa aaaa	Arp/Ptn Duration 30, 40, 50	60 70 80 9
00 19	0000 000-		100, 120, FU (0 -
	0000 000a	Arpeggio Switch	(U - OFF, O
00 1A 00 1B	Oaaa aaaa Oaaa aaaa	(reserve) <*> Arpeggio Style	(0 - 12 1 - 12
00 1C	Oaaa aaaa	Arpeggio Motif	(0 - 1
		UP/L, UP/H, dn/_, Ud/L,	UP/_, dn/L, dn/ Ud/H, Ud/_, rn/
00 1D	0000 0aaa	Arpeggio Octave Range	rn/_, PHRAS (61 - 6 -3 - +
00 1E	0000 000a	Arpeggio Hold	(0 -
00 1F	Oaaa aaaa	Arpeggio Accent Rate	OFF, 0:
00 20	Oaaa aaaa	Arpeggio Velocity	(0 - 12 REAL, 1 - 12
00 21	0000 000a	Rhythm Pattern Sw	OFF, O
00 22 00 23	0aaa aaaa 0000 aaaa	(reserve) <*>	022, 0
	0000 bbbb	Rhythm Pattern Style	(0 - 25 1 - 25
00 25 00 26	0000 000a 0aaa aaaa	(reserve) <*> Rhythm Pattern Group Number	
00 26	Oaaa aaaa	Rhythm Pattern Group Number	(0 - 2 1 - 2 (0 - 10
00 27	Oaaa aaaa	Rnythm Pattern Accent Rate Rhythm Pattern Velocity	(1 - 12
00 29	0000 000a	Chord Switch	(0 - OFF, O
00 2A 00 2B	0aaa aaaa 00aa aaaa	(reserve) <*> Chord Form	
		· · · - · · · ·	(0 - 1
00 2C 00 2D	0000 000a	(reserve) <*>	
00 2E	0000 000a	(reserve) <*> (reserve) <*>	
00 2F 00 30	0000 000a 0aaa aaaa	(reserve) <*> (reserve) <*>	
00 30	0aaa aaaa + 0000 000a	(reserve) <-> Rolled Chord	(0 -
00 31	0000 000a		OFF, O: (0 -
			DOWN, ALTERNATI
00 33	00aa aaaa	Arpeggio Step	AUTO, 1 - 3
00 00 00 34	Total Size	<u></u>	

* System Common

Of	fset Address		Description	
#	00 00	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Master Tune	(24 - 2024) -100.0 - 100.0 [cent]
	00 04	00aa aaaa	Master Key Shift	(40 - 88) -24 - +24
	00 05 00 06	0aaa aaaa 0000 000a	Master Level Scale Tune Switch	(0 - 127) (0 - 1) OFF ON

00 07	0000 000a	Patch Remain	(0 - 1) OFF, ON
00 08	0000 000a	Mix/Parallel <*>	, PARALLEL
00 09	000a aaaa	Performance Control Channel	(0 - 16) 1 - 16, OFF
00 0A	0000 aaaa	Kbd Patch Rx/Tx Channel	(0 - 15) 1 - 16
00 OB	0000 aaaa	(reserve) <*>	
00 OC	Oaaa aaaa	Patch Scale Tune for C	(0 - 127) -64 - +63
00 0D	Oaaa aaaa	Patch Scale Tune for C#	(0 - 127) -64 - +63
00 0E	Oaaa aaaa	Patch Scale Tune for D	(0 - 127) -64 - +63
00 OF	Oaaa aaaa	Patch Scale Tune for D#	(0 - 127) -64 - +63
00 10	Oaaa aaaa	Patch Scale Tune for E	(0 - 127) -64 - +63
00 11	Oaaa aaaa	Patch Scale Tune for F	(0 - 127) -64 - +63
00 12	Oaaa aaaa	Patch Scale Tune for F#	(0 - 127) -64 - +63
00 13	Oaaa aaaa	Patch Scale Tune for G	(0 - 127) -64 - +63
00 14	Oaaa aaaa	Patch Scale Tune for G#	(0 - 127) -64 - +63
00 15	Oaaa aaaa	Patch Scale Tune for A	(0 - 127) -64 - +63
00 16	Oaaa aaaa	Patch Scale Tune for A#	(0 - 127) -64 - +63
00 17	Oaaa aaaa	Patch Scale Tune for B	(0 - 127) -64 - +63
00 18		System Control 1 Source OFF, CC01 - CC31	(0 - 97) , CC33 - CC95,
00 19	Oaaa aaaa	System Control 2 Source OFF, CC01 - CC31	
00 1A	Oaaa aaaa	System Control 3 Source OFF, CC01 - CC31	
00 1B		System Control 4 Source OFF, CC01 - CC31	BEND, AFT
00 1C		Receive Program Change	(0 - 1) OFF, ON
00 1D	0000 000a	Receive Bank Select	(0 - 1) OFF, ON
00 00 00 1E	Total Size		

* System Controller

Offset Address		Description
00 00	0000 000a	Transmit Program Change (0 - 1)
00 01	0000 000a	OFF, ON Transmit Bank Select (0 - 1)
00 02	Oaaa aaaa	OPF, ON Keyboard Velocity (0 - 127)
00 03	0000 00aa	REAL, 1 - 127 Keyboard Velocity Curve (0 - 2)
00 04	0aaa aaaa	LIGHT, MEDIUM, HEAVY (reserve) <*>
00 05	0000 0aaa	Hold Pedal Polarity (0 - 1)
00 06	0000 000a	STANDARD, REVERSE Continuous Hold Pedal (0 - 1) OFF, ON
		Pedal Assign MODULATION, PORTA-TIME, VOLUME, BALANCE, PAN, EXPERSSION, HOLD, PORTAMENTO, SOSTENUTO, SOFT, RESONANCE, RELEASE-TIME, ATTACK-TIME, CUTOFF, DECAY-TIME, LFO-RATE, LFO-DEPTH, LFO-BLAY, CHO-SEND-LEVEL, REV-SEND-LEVEL, AFTERTOUCH, START/STOP, TAP-TEMPO, PROG-UP, PROG-DOWN, FAV-UP, FAV-DOWN
		(reserve) <*>
	0000 aaaa 0aaa aaaa	Beam Sens (1 - 10) Beam Assign MODULATION, PORTA-TIME, VOLUME, BALANCE, PAN, PORTAMENTO, SOSTENUTO, SOFT, RESONANCE, RELEASE-TIME, ATTACK-TIME, CUTOFF, DECAY-TIME, LFO-RATE, LFO-DEPTH, LFO-DELAY, CHO-SEND-LEVEL, REV-SEND-LEVEL, AFTERTOUCH, BEND-UP, BEND-DOWN,
00 OB	Oaaa aaaa	START/STOP Beam Range Lower
	0000 aaaa 0aaa aaaa 0aaa aaaa	Beam Range Upper (0 - 127) (reserve) <*> (reserve) <*> (reserve) <*>
		(reserve) <*> (reserve) <*>
00 12	Daaa aaaa	(reserve) <*> (reserve) <*>
	+	ļ
00 15	0aaa aaaa 0aaa aaaa	(reserve) <*> (reserve) <*>
00 17 00 18 00 19	0aaa aaaa 0000 00aa 0aaa aaaa 0000 aaaa	<pre>(reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*></pre>
00 1A 00 1B 00 1C 00 1D 00 1E 00 1F 00 20 00 21 00 23 00 24 00 25 00 26 00 27 00 28 00 29	0 aaa aaaa 0 aaa aaaa 0 aaa aaaa 0 aaa aaaa 0 aaa aaaa 0 aaa aaaa 0 aaa aaaa 0 aaa aaaa 0 aaa aaaa 0 aaa aaaa 0 aaa aaaa 0 aaa aaaa 0 aaa aaaa 0 aaa aaaa 0 aaa aaaa 0 aaa aaaa 0 aaa aaaa	reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*> reserve <*/> rese

00 2C	Oaaa aaaa	(reserve) <*>	
00 2D	Oaaa aaaa	(reserve) <*>	
00 2E	Oaaa aaaa	(reserve) <*>	
00 2F	Oaaa aaaa	(reserve) <*>	
00 30	Oaaa aaaa	(reserve) <*>	
00 31	Oaaa aaaa	(reserve) <*>	
00 32	Oaaa aaaa	(reserve) <*>	
00 33	Oaaa aaaa	(reserve) <*>	
00 34	Oaaa aaaa	(reserve) <*>	
00 35	Oaaa aaaa	(reserve) <*>	
00 36	Oaaa aaaa	(reserve) <*>	
00 37	Oaaa aaaa	(reserve) <*>	
00 38	Oaaa aaaa	(reserve) <*>	
00 39	Oaaa aaaa	(reserve) <*>	
00 3A	Oaaa aaaa	(reserve) <*>	
00 3B	Oaaa aaaa	(reserve) <*>	
00 3C	Oaaa aaaa	(reserve) <*>	
00 3D	Oaaa aaaa	(reserve) <*>	
00 3E	Oaaa aaaa	(reserve) <*>	
00 3F	Oaaa aaaa	(reserve) <*>	
00 40	Oaaa aaaa	(reserve) <*>	
00 41	Oaaa aaaa	(reserve) <*>	
00 42	Oaaa aaaa	(reserve) <*>	
00 43	Oaaa aaaa	(reserve) <*>	
00 44	Oaaa aaaa	(reserve) <*>	
00 45	Oaaa aaaa	(reserve) <*>	
00 46	Oaaa aaaa	(reserve) <*>	
00 47	Oaaa aaaa	(reserve) <*>	
00 48	Oaaa aaaa	(reserve) <*>	
00 49	Oaaa aaaa	(reserve) <*>	
00 4A	Oaaa aaaa	(reserve) <*>	
00 4B	Oaaa aaaa	(reserve) <*>	
	+	+	
00 4C	0000 000a	(reserve) <*>	
00 4D	0000 000a	(reserve) <*>	
	·		
00 00 00 4E	Total Size		
+			-

* Performance Common

+ Offset			
Offset Address		Description	
00 00	0aaa aaaa	Performance Name 1	(32 - 127)
00 01	Oaaa aaaa	Performance Name 2	32 - 127 [ASCII] (32 - 127)
00 02	Oaaa aaaa	Performance Name 3	32 - 127 [ASCII]
00 02	Oaaa aaaa		32 - 127 [ASCII]
		Performance Name 4	32 - 127 [ASCII]
00 04	Oaaa aaaa	Performance Name 5	32 - 127 [ASCII]
00 05	Oaaa aaaa	Performance Name 6	(32 - 127) 32 - 127 [ASCII]
00 06	Oaaa aaaa	Performance Name 7	(32 - 127) 32 - 127 [ASCII]
00 07	Oaaa aaaa	Performance Name 8	(32 - 127) 32 - 127 [ASCII]
00 08	Oaaa aaaa	Performance Name 9	(32 - 127)
00 09	Oaaa aaaa	Performance Name 1	32 - 127 [ASCII] 0 (32 - 127)
00 0A	Oaaa aaaa	Performance Name 1	32 - 127 [ASCII] 1 (32 - 127)
00 OB	Oaaa aaaa	Performance Name 1	
			32 - 127 [ASCII]
00 OC	00aa aaaa	Solo Part Select	(0 - 16)
00 OD	000a aaaa	MFX1 Control Chann	OFF, 1 - 16 (0 - 16) 1 - 16, OFF
00 OE	0000 000a	(reserve) <*>	1 - 16, OFF
00 OF	0000 000a	(reserve) <*>	
00 10	Oaaa aaaa	Voice Reserve 1	(0 - 64) 0 - 63, FULL
00 11	Oaaa aaaa	Voice Reserve 2	0 - 63, FULL (0 - 64)
00 12	Oaaa aaaa	Voice Reserve 3	0 - 63, FULL (0 - 64)
00 13	Oaaa aaaa	Voice Reserve 4	0 - 63, FULL (0 - 64)
00 14	Oaaa aaaa	Voice Reserve 5	0 - 63, FULL (0 - 64)
00 15	Oaaa aaaa	Voice Reserve 6	0 - 63, FULL (0 - 64)
00 16	Oaaa aaaa	Voice Reserve 7	0 - 63, FULL (0 - 64)
00 10	Oaaa aaaa	Voice Reserve 8	0 - 63, FULL (0 - 64)
			0 - 64) 0 - 63, FULL (0 - 64)
00 18	Oaaa aaaa	Voice Reserve 9	0 - 64) 0 - 63, FULL (0 - 64)
00 19	Oaaa aaaa	Voice Reserve 10	0 - 63, FULL
00 1A	Oaaa aaaa	Voice Reserve 11	(0 - 64) 0 - 63, FULL (0 - 64)
00 1B	Oaaa aaaa	Voice Reserve 12	(0 - 64) 0 - 63, FULL
00 1C	Oaaa aaaa	Voice Reserve 13	0 - 63, FULL (0 - 64) 0 - 63, FULL
00 1D	Oaaa aaaa	Voice Reserve 14	(0 = 64)
00 1E	Oaaa aaaa	Voice Reserve 15	0 - 63, FULL (0 - 64)
00 1F	Oaaa aaaa	Voice Reserve 16	0 - 63, FULL (0 - 64)
00 20	Oaaa aaaa	(reserve) <*>	0 - 63, FULL
00 21 00 22	Oaaa aaaa Oaaa aaaa	(reserve) <*> (reserve) <*>	
00 23	Oaaa aaaa	(reserve) <*>	
00 24 00 25	Oaaa aaaa Oaaa aaaa	(reserve) <*> (reserve) <*>	
00 26	Oaaa aaaa	(reserve) <*>	
00 27 00 28	Oaaa aaaa Oaaa aaaa	(reserve) <*> (reserve) <*>	
00 29	Oaaa aaaa	(reserve) <*>	
00 2A	Oaaa aaaa	(reserve) <*>	
00 2B 00 2C	Oaaa aaaa	(reserve) <*> (reserve) <*>	
00 2C 00 2D	Oaaa aaaa Oaaa aaaa	(reserve) <*> (reserve) <*>	
00 2E	Oaaa aaaa	(reserve) <*>	
00 2F	Oaaa aaaa	(reserve) <*>	
00 30	00aa aaaa	MFX1 Source	(0 - 16)
00 31	00aa aaaa	MFX2 Source	(0 - 16)
00 32	00aa aaaa	MFX3 Source	PERFORM, 1 - 16 (0 - 16)
00 33	00aa aaaa		PERFORM, 1 - 16 (0 - 16)
00 33	00aa aaaa		PERFORM, 1 - 16
00 34	uuaa aaaa	Reverb Source	(0 - 16) PERFORM, 1 - 16
00 35	00aa aaaa	MFX2 Control Chann	el (0 - 16)
00 36	00aa aaaa	MFX3 Control Chann	1 - 16, OFF (0 - 16) 1 - 16, OFF
			1 - 16, OFF

00 37	0000 aaaa	MFX Structure	(0 - 15) 1 - 16
00 00 00 38	Total Size		

* Performance Common MFX

	dress	:	Description	
	00 00 00 01 00 02 00 03 00 04	0aaa aaaa 0aaa aaaa 0aaa aaaa 0aaa aaaa 0000 00aa	MFX Type MFX Dry Send Level MFX Chorus Send Level MFX Reverb Send Level MFX Output Assign <*>	(0 - 79 (0 - 127 (0 - 127 (0 - 127 A,,,
	00 05	Oaaa aaaa	MFX Control 1 Source	CC01 - CC31, CC33 - CC95 BEND, AFT, SYS1 - SYS4
	00 06	Oaaa aaaa	MFX Control 1 Sens	BEND, AFT, SYS1 - SYS4 (1 - 127
	00 07	Oaaa aaaa	MEX Control 2 Source	(1 - 127 -63 - +63 (0 - 101
			OFF,	CC01 - CC31, CC33 - CC95 BEND, AFT, SYS1 - SYS4
	00 08	Oaaa aaaa	MFX Control 2 Sens MFX Control 3 Source	(1 - 127 -63 - +63
	00 03	Vaaa aaaa	OFF,	CC01 - CC31, CC33 - CC95 BEND, AFT, SYS1 - SYS4 (1 - 127 BEND, AFT, SYS1 - SYS4 (1 - 127 -63 - +63
	00 0A	Oaaa aaaa	MFX Control 3 Sens	(1 - 127 -63 - +63
	00 OB	Oaaa aaaa	MFX Control 4 Source OFF,	CC01 - CC31, CC33 - CC95 BEND, AFT, SYS1 - SYS4
	00 OC	Oaaa aaaa	MFX Control 4 Sens	BEND, AFT, SYS1 - SYS4 (1 - 127 -63 - +63
	00 0D	 000a aaaa	 + MFX Control Assign 1	
	00 OE	000a aaaa	MFX Control Assign 2	(0 - 16 OFF, 1 - 16 (0 - 16
	00 OF		MFX Control Assign 3	OFF, 1 - 16 (0 - 16
	00 10	000a aaaa	MFX Control Assign 4	OFF, 1 - 16 (0 - 16 OFF, 1 - 16 (0 - 16 OFF, 1 - 16
*	00 11	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 1	
	00 15	0000 aaaa 0000 bbbb 0000 cccc		(12768 - 52768 -20000 - +20000
#	00 19	0000 dddd 0000 aaaa 0000 bbbb 0000 cccc	MFX Parameter 2	(12768 - 52768 -20000 - +20000
		0000 dddd	MFX Parameter 3	(12768 - 52768 -20000 - +20000
#	00 1D	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 4	(12768 - 52768 -20000 - +20000
#	00 21	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 5	
#	00 25	0000 aaaa 0000 bbbb 0000 cccc		(12768 - 52768 -20000 - +20000
#	00 29	0000 dddd 0000 aaaa 0000 bbbb 0000 cccc	MFX Parameter 6	(12768 - 52768 -20000 - +20000
ŧ	00 2D	0000 dddd 0000 aaaa 0000 bbbb	MFX Parameter 7	(12768 - 52768 -20000 - +20000
#	00 31	0000 cccc 0000 dddd 0000 aaaa 0000 bbbb	MFX Parameter 8	(12768 - 52768 -20000 - +20000
ŧ	00 35	0000 cccc 0000 dddd 0000 aaaa	MFX Parameter 9	(12768 - 52768 -20000 - +20000
	00.20	0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 10	(12768 - 52768 -20000 - +20000
#	00 39	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 11	(12768 - 52768 -20000 - +20000
#	00 3D	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 12	(12768 - 52768 -20000 - +20000
#	00 41	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 13	-20000 - +20000 (12768 - 52768 -20000 - +20000
#	00 45	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 14	
ŧ	00 49	0000 aaaa 0000 bbbb 0000 cccc		(12768 - 52768 -20000 - +20000
ŧ	00 4D	0000 aaaa 0000 bbbb 0000 cccc	MFX Parameter 15	(12768 - 52768 -20000 - +20000
#	00 51	0000 dddd 0000 aaaa 0000 bbbb 0000 cccc	MFX Parameter 16	(12768 - 52768 -20000 - +20000
ŧ	00 55	0000 ccc 0000 dddd 0000 aaaa 0000 bbbb	MFX Parameter 17	(12768 - 52768 -20000 - +20000
	00 59	0000 cccc	MFX Parameter 18	(12768 - 52768 -20000 - +20000

	0000 dddd	MFX Parameter 19	(12768 - 52768) -20000 - +20000
# 00 5D	0000 bbbb	MFX Parameter 20	
# 00 61	0000 bbbb 0000 cccc	MFX Parameter 21	(12768 - 52768)
# 00 65	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 22	-20000 - +20000 (12768 - 52768)
# 00 69	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 23	-20000 - +20000 (12768 - 52768)
# 00 6D	0000 bbbb 0000 cccc	MFX Parameter 24	-20000 - +20000 (12768 - 52768)
# 00 71	0000 aaaa 0000 bbbb 0000 cccc	MFX Parameter 25	-20000 - +20000
# 00 75	0000 aaaa 0000 bbbb 0000 cccc		(12768 - 52768) -20000 - +20000
# 00 79	0000 aaaa 0000 bbbb 0000 cccc	MFX Parameter 26	(12768 - 52768) -20000 - +20000
# 00 7D	0000 dddd 0000 aaaa 0000 bbbb	MFX Parameter 27	(12768 - 52768) -20000 - +20000
# 01 01		MFX Parameter 28	(12768 - 52768) -20000 - +20000
# 01 05	0000 cccc 0000 dddd 0000 aaaa	MFX Parameter 29	(12768 - 52768) -20000 - +20000
# 01 09	0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 30	(12768 - 52768) -20000 - +20000
	0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 31	(12768 - 52768) -20000 - +20000
# 01 0D	0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 32	-20000 - +20000
	Total Size		

* Performance Common Chorus

	set Address		Description	
	00 00 00 01	0000 aaaa 0aaa aaaa 0000 00aa	Chorus Type Chorus Level Chorus Output Assign <*>	(0 - 3 (0 - 127
	00 03		Chorus Output Select	(0 - 2 MAIN, REV, MAIN+REV
#		0000 aaaa 0000 bbbb		
#	00 08	0000 aaaa 0000 bbbb		(12768 - 52768 -20000 - +20000
‡	00 OC	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 3	(12768 - 52768
#	00 10	0000 bbbb	Chorus Parameter 4	-20000 - +20000 (12768 - 52768
#	00 14	0000 aaaa 0000 bbbb		(12768 - 52768
#	00 18	0000 aaaa 0000 bbbb 0000 cccc	Chorus Parameter 6	(12768 - 52768
#	00 1C	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 7	-20000 - +20000 (12768 - 52768
#	00 20	0000 aaaa 0000 bbbb 0000 cccc	Chorus Parameter 8	-20000 - +20000 (12768 - 52768
#	00 24	0000 bbbb	Chorus Parameter 9	-20000 - +20000 (12768 - 52768
#	00 28	0000 aaaa 0000 bbbb 0000 cccc	Chorus Parameter 10	-20000 - +20000 (12768 - 52768
#	00 2C	0000 aaaa 0000 bbbb 0000 cccc	Chorus Parameter 11	-20000 - +20000 (12768 - 52768
#	00 30			-20000 - +20000

		0000 cccc 0000 dddd	Chorus Parameter 12	(12768 - 52768) -20000 - +20000
#	00 34	0000 bbbb 0000 cccc	Chorus Parameter 13	(12768 - 52768) -20000 - +20000
#	00 38	0000 bbbb 0000 cccc	Chorus Parameter 14	(12768 - 52768) -20000 - +20000
#	00 3C	0000 bbbb 0000 cccc	Chorus Parameter 15	(12768 - 52768)
#	00 40	0000 bbbb 0000 cccc	Chorus Parameter 16	-20000 - +20000 (12768 - 52768)
#	00 44	0000 bbbb 0000 cccc	Chorus Parameter 17	-20000 - +20000 (12768 - 52768)
#	00 48	0000 bbbb 0000 cccc	Chorus Parameter 18	-20000 - +20000 (12768 - 52768)
#	00 4C	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 19	-20000 - +20000 (12768 - 52768)
#	00 50	0000 bbbb 0000 cccc	Chorus Parameter 20	-20000 - +20000 (12768 - 52768)
00 00	00 54	Total Size		-20000 - +20000

* Performance Common Reverb

	fset	Common H		
	Address		Description	
	00 00 00 01 00 02	0000 aaaa 0aaa aaaa 0000 00aa	Reverb Type Reverb Level Reverb Output Assign <*>	(0 - 5) (0 - 127) A,,
#	00 03	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 1	(12768 - 52768) -20000 - +20000
#	00 07	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 2	(12768 - 52768) -20000 - +20000
#	00 OB	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 3	(12768 - 52768) -20000 - +20000
#	00 OF	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 4	(12768 - 52768) -20000 - +20000
#	00 13	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 5	(12768 - 52768)
#	00 17	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 6	-20000 - +20000 (12768 - 52768)
#	00 1B	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 7	-20000 - +20000 (12768 - 52768)
#	00 1F	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 8	-20000 - +20000 (12768 - 52768) -20000 - +20000
#	00 23	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 9	-20000 - +20000 (12768 - 52768) -20000 - +20000
#	00 27	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 10	-20000 - +20000 (12768 - 52768) -20000 - +20000
#	00 2B	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 11	-20000 - +20000 (12768 - 52768) -20000 - +20000
#	00 2F	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 12	
#	00 33	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 13	(12768 - 52768) -20000 - +20000
#	00 37	0000 dddd 0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 14	(12768 - 52768) -20000 - +20000 (12768 - 52768)
#	00 3B	0000 dddd 0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 15	-20000 - +20000
#	00 3F	0000 aaaa 0000 bbbb 0000 cccc		(12768 - 52768) -20000 - +20000
#	00 43	0000 dddd 0000 aaaa 0000 bbbb 0000 cccc	Reverb Parameter 16	(12768 - 52768) -20000 - +20000

0000 aaaa	Reverb Parameter 17	(12768 - 52768) -20000 - +20000
0000 cccc 0000 dddd	Reverb Parameter 18	(12768 - 52768) -20000 - +20000
0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 19	(12768 - 52768)
0000 bbbb 0000 cccc		-20000 - +20000
	Reverb Parameter 20	(12768 - 52768) -20000 - +20000
B	7 0000 aaaa 0000 bbbb 0000 cccc 0000 dddd B 0000 aaaa 0000 bbbb 0000 cccc 0000 dddd F 0000 aaaaa 0000 bbbb 0000 cccc 0000 dddd	0000 bbbb 0000 cccc 0000 dddd Reverb Parameter 18 B 0000 aaaa 0000 bbbb 0000 cccc 0000 dddd Reverb Parameter 19 F 0000 aaaa 0000 bbbb 0000 cccc 0000 dddd Reverb Parameter 20

* Performance MIDI

Offset Address		Description	
00 00	0000 000a	Receive Program Change	(0 - 1) OFF, ON
00 01	0000 000a	Receive Bank Select	(0 - 1) OFF, ON
00 02	0000 000a	Receive Bender	(0 - 1)
00 03	0000 000a	Receive Polyphonic Key Pressure	OFF, ON (0 - 1)
00 04	0000 000a	Receive Channel Pressure	OFF, ON (0 - 1)
00 05	0000 000a	Receive Modulation	OFF, ON (0 - 1)
00 06	0000 000a	Receive Volume	OFF, ON (0 - 1)
00 07	0000 000a	Receive Pan	OFF, ON (0 - 1)
00 08	0000 000a	Receive Expression	OFF, ON (0 - 1)
00 09	0000 000a	Receive Hold-1	OFF, ON (0 - 1) OFF, ON
00 0A	0000 000a	Phase Lock	(0 - 1)
00 OB	0000 0aaa	Velocity Curve Type	OFF, ON (0 - 4) OFF, 1 - 4
00 00 00 0C	Total Size		

* Performance Part

Offset Address		Description	
00 00	0000 aaaa	Receive Channel	(0 - 15) 1 - 16
00 01	0000 000a	Receive Switch	(0 - 1)
00 02	0000 0000	(reserve) <*>	OFF, ON (1 - 0)
00 03	0000 0000	(reserve) <*>	(1 - 0)
00 04 00 05 00 06	Oaaa aaaa Oaaa aaaa Oaaa aaaa	Patch Bank Select MSB (CC# 0) Patch Bank Select LSB (CC# 32) Patch Program Number (PC)	(0 - 127) (0 - 127) (0 - 127)
00 07 00 08	Oaaa aaaa	Part Level (CC# 7) Part Pan (CC# 10)	(0 - 127) (0 - 127) L64 - 63R
00 09	Oaaa aaaa	Part Coarse Tune (RPN# 2)	(16 - 112)
00 0A	Oaaa aaaa	Part Fine Tune (RPN# 1)	-48 - +48 (14 - 114) -50 - +50
00 OB	0000 00aa	Part Mono/Poly (MONO ON/POLY ON)	(0 - 2) ONO, POLY, PATCH
00 OC	0000 00aa	Part Legato Switch (CC# 68)	OFF, ON, PATCH
00 0D	000a aaaa	Part Pitch Bend Range (RPN# 0)	(0 - 25) 0 - 24, PATCH
00 OE	0000 00aa	Part Portamento Switch (CC# 65)	(0 - 2) OFF, ON, PATCH
# 00 OF	0000 aaaa 0000 bbbb	Part Portamento Time (CC# 5)	(0 - 128)
00 11	Oaaa aaaa	Part Cutoff Offset (CC# 74)	0 - 127, PATCH (0 - 127)
00 12	Oaaa aaaa	Part Resonance Offset (CC# 71)	-64 - +63 (0 - 127)
00 13	Oaaa aaaa	Part Attack Time Offset (CC# 73)	-64 - +63 (0 - 127)
00 14	Oaaa aaaa		-64 - +63
00 15	0000 0aaa	Part Octave Shift	(61 - 67)
00 16	Oaaa aaaa	Part Velocity Sens Offset	-3 - +3 (1 - 127) -63 - +63
00 17 00 18 00 19 00 1A 00 1B	0aaa aaaa 0aaa aaaa 0aaa aaaa 0aaa aaaa 0000 000a	<pre>(reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> Mute Switch</pre>	(0 - 1) OFF, MUTE
00 1C 00 1D 00 1E 00 1F	0aaa aaaa 0aaa aaaa 0aaa aaaa 0000 aaaa	Part Dry Send Level Part Chorus Send Level (CC# 93) Part Reverb Send Level (CC# 91) Part Output Assign MFX,	
		1, 2,,	-,,, PATCH
00 20	0000 00aa	Part Output MFX Select	(0 - 2) MFX1, MFX2, MFX3
00 21	Oaaa aaaa	Part Decay Time Offset (CC# 75)	(0 - 127) -64 - +63
00 22	Oaaa aaaa	Part Vibrato Rate (CC# 76)	(0 - 127)
00 23	Oaaa aaaa	Part Vibrato Depth (CC# 77)	-64 - +63 (0 - 127) -64 - +63 (0 - 127)
00 24	Oaaa aaaa	Part Vibrato Delay (CC# 78)	-64 - +63
00 25	Oaaa aaaa	Part Scale Tune for C	(0 - 127)
00 26	Oaaa aaaa	Part Scale Tune for C#	(0 - 127) -64 - +63 (0 - 127) -64 - +63
00 27	Oaaa aaaa	Part Scale Tune for D	-64 - +63 (0 - 127) -64 - +63
00 28	Oaaa aaaa	Part Scale Tune for D#	(0 - 127) -64 - +63

00 29	Oaaa aaaa	Part Scale Tune for E	(0 - 127)
			-64 - +63
00 2A	Oaaa aaaa	Part Scale Tune for F	(0 - 127)
00 2B	Oaaa aaaa	Part Scale Tune for F#	(0 - 127)
	İ		-64 - +63
00 2C	Oaaa aaaa	Part Scale Tune for G	(0 - 127)
			-64 - +63
00 2D	Oaaa aaaa	Part Scale Tune for G#	(0 - 127)
			-64 - +63
00 2E	Oaaa aaaa	Part Scale Tune for A	(0 - 127)
00 2F		Part Scale Tune for A#	-64 - +63 (0 - 127)
00 ZF	Oaaa aaaa	Part Scale Tune for A#	-64 - +63
00 30	Oaaa aaaa	Part Scale Tune for B	(0 - 127)
00 30	Vada adaa	rait scare rane for b	-64 - +63
	. 		
00 00 00 31	Total Size		

* Performance Zone

+			
Offset Address		Description	
00 00	0000 0aaa	Zone Octave Shift	(61 - 67) -3 - +3
00 01	0000 000a	Zone Switch	(0 - 1) OFF, ON
00 02	0000 000a	(reserve) <*>	OFF, ON
# 00 03	0000 aaaa 0000 bbbb	(reserve) <*>	
# 00 05 # 00 06	0aaa aaaa 0000 aaaa	(reserve) <*>	
# 00 08	0000 bbbb 0000 aaaa 0000 bbbb	(reserve) <*>	
# 00 0A	0000 aaaa 0000 bbbb	(reserve) <*>	
00 OC	Oaaa aaaa	Keyboard Range Lower	(0 - 127) C-1 - UPPER
00 0D	Oaaa aaaa	Keyboard Range Upper	(0 - 127) LOWER - G9
00 0E 00 0F 00 10 00 11 00 12 00 13 00 14 00 15 00 16 00 17 00 18	0000 000a 0000 000a	(reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*> (reserve) <*/ (reserve) <*/ (reserve) <*/ (reserve) <*/ (reserve) <*/ (reserve) <*/ (reserve) <*/ (reserve) <*/ (r	
00 00 00 1B	Total Size		

* Arpeggio Common

+			
Offset Address		Description	
# 00 00	0000 aaaa 0000 bbbb	End Step	(1 - 32)
00 02	Oaaa aaaa	Arpeggio Name 1	(32 - 127)
00 03	Oaaa aaaa	Arpeggio Name 2	(32 - 127)
00 04	Oaaa aaaa	Arpeggio Name 3	(32 - 127)
00 05	Oaaa aaaa	Arpeggio Name 4	(32 - 127)
00 06	Oaaa aaaa	Arpeggio Name 5	(32 - 127)
00 07	Oaaa aaaa	Arpeggio Name 6	(32 - 127)
00 08	Oaaa aaaa	Arpeggio Name 7	(32 - 127)
00 09	Oaaa aaaa	Arpeggio Name 8	(32 - 127)
A0 00	Oaaa aaaa	Arpeggio Name 9	(32 - 127)
00 OB	Oaaa aaaa	Arpeggio Name 10	(32 - 127)
00 0C	Oaaa aaaa	Arpeggio Name 11	(32 - 127)
00 0D	Oaaa aaaa	Arpeggio Name 12	(32 - 127)
00 0E	Oaaa aaaa	Arpeggio Name 13	(32 - 127)
00 OF	Oaaa aaaa	Arpeggio Name 14	(32 - 127)
00 10	Oaaa aaaa	Arpeggio Name 15	(32 - 127)
00 11	Oaaa aaaa	Arpeggio Name 16	(32 - 127)
00 00 00 12	Total Size		

* Arpeggio Pattern

Off	Offset Address		Description		
#	00 00	0000 aaaa 0000 bbbb	Original Note	(0 - 128)	
#	00 02	0000 aaaa 0000 bbbb	Step1 Data	(0 - 128)	
#	00 04	0000 aaaa 0000 bbbb	Step2 Data	(0 - 128)	
#	00 06	0000 aaaa	_		
#	00 08	0000 bbbb 0000 aaaa	Step3 Data	(0 - 128)	
#	00 OA	0000 bbbb 0000 aaaa	Step4 Data	(0 - 128)	
		0000 bbbb	Step5 Data	(0 - 128)	
#	00 OC	0000 aaaa 0000 bbbb	Step6 Data	(0 - 128)	
#	00 OE	0000 aaaa 0000 bbbb	Step7 Data	(0 - 128)	
#	00 10	0000 aaaa	_		
#	00 12	0000 bbbb 0000 aaaa	Step8 Data	(0 - 128)	
#	00 14	0000 bbbb 0000 aaaa	Step9 Data	(0 - 128)	
		0000 bbbb	Step10 Data	(0 - 128)	
#	00 16	0000 aaaa 0000 bbbb	Step11 Data	(0 - 128)	

#	00 18	0000 aaaa		1
		0000 bbbb	Step12 Data	(0 - 128)
#	00 1A	0000 aaaa		
		0000 bbbb	Step13 Data	(0 - 128)
#	00 1C	0000 aaaa		
		0000 bbbb	Step14 Data	(0 - 128)
#	00 1E	0000 aaaa		
		0000 bbbb	Step15 Data	(0 - 128)
#	00 20	0000 aaaa		
	00.00	0000 bbbb	Step16 Data	(0 - 128)
#	00 22	0000 aaaa	a. 15 p.:	(0 100)
#	00.04	0000 bbbb	Step17 Data	(0 - 128)
#	00 24	0000 aaaa 0000 bbbb	Step18 Data	(0 - 128)
#	00 26	0000 BBBB	Stepis Data	(0 - 128)
#	00 26	0000 aaaa	Step19 Data	(0 - 128)
#	00 28	0000 bbbb	Step19 Data	(0 - 128)
1"	00 20	0000 dddd 0000 bbbb	Step20 Data	(0 - 128)
#	00 2A	0000 bbbb	Scepzo Daca	(0 120)
"	00 211	0000 bbbb	Step21 Data	(0 - 128)
#	00 2C	0000 aaaa		(* ===,
"		0000 bbbb	Step22 Data	(0 - 128)
#	00 2E	0000 aaaa		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
İ		0000 bbbb	Step23 Data	(0 - 128)
#	00 30	0000 aaaa		
		0000 bbbb	Step24 Data	(0 - 128)
#	00 32	0000 aaaa		
		0000 bbbb	Step25 Data	(0 - 128)
#	00 34	0000 aaaa		
		0000 bbbb	Step26 Data	(0 - 128)
#	00 36	0000 aaaa	G1 07 P 1	(0 100)
	00 00	0000 bbbb	Step27 Data	(0 - 128)
#	00 38	0000 aaaa 0000 bbbb	Step28 Data	(0 - 128)
#	00 3A	0000 bbbb	эсерго раса	(0 - 128)
"	00 JA	0000 aaaa	Step29 Data	(0 - 128)
#	00 3C	0000 bbbb	эсергэ васа	(0 - 128)
	00 00	0000 dddd 0000 bbbb	Step30 Data	(0 - 128)
#	00 3E	0000 aaaa		(0 120)
l "		0000 bbbb	Step31 Data	(0 - 128)
#	00 40	0000 aaaa		/
İ		0000 bbbb	Step32 Data	(0 - 128)
00	00 00 42	Total Size		!

* Rhythm Group

Offse	et Address		Description	
	00 00		Rhythm Group Name 1	(32 - 127
	00 01	Oaaa aaaa	Rhythm Group Name 2	(32 - 127
	00 02	Oaaa aaaa	Rhythm Group Name 3	(32 - 127
	00 03	Oaaa aaaa	Rhythm Group Name 4	(32 - 127
	00 04	Oaaa aaaa	Rhythm Group Name 5	(32 - 127
	00 05	Oaaa aaaa	Rhythm Group Name 6	(32 - 127
	00 06	Oaaa aaaa	Rhythm Group Name 7	(32 - 127
	00 07	Oaaa aaaa	Rhythm Group Name 8	(32 - 127
	00 08	Oaaa aaaa	Rhythm Group Name 9	(32 - 127
	00 09	Oaaa aaaa	Rhythm Group Name 10	(32 - 127
	00 OA	Oaaa aaaa	Rhythm Group Name 11	(32 - 127
	00 OB	Oaaa aaaa	Rhythm Group Name 12	(32 - 127
	00 OC	Oaaa aaaa	Rhythm Group Name 13	(32 - 127
	00 OD	Oaaa aaaa	Rhythm Group Name 14	(32 - 127
	00 OE			(30 100
	00 OE	Oaaa aaaa	Rhythm Group Name 15	(32 - 127
	00 OF	Oaaa aaaa	Rhythm Group Name 16	(32 - 127
	00 10	Oaaa aaaa	Recommended Rhythm Bank Select MSB	(0 - 127 (0 - 127
	00 11 00 12	0aaa aaaa 0aaa aaaa	Recommended Rhythm Bank Select MSB Recommended Rhythm Bank Select LSB Recommended Rhythm Program Number	(0 - 127 (0 - 127
	00 13	0aaa aaaa	(reserve) <*>	
	00 14 00 15	Oaaa aaaa	(reserve) <*> Pad 1 Velocity	(1 - 127
	00 15 00 16 00 17	0000 000a	(reserve) <*> (reserve) <*> Pad 1 Velocity (reserve) <*>	(1 - 12/
	00 17	0000 aaaa	Dad 1 Dhythm Dattown Number	(0 - 255
	00 19	Oaaa aaaa	Pad 1 Rhythm Pattern Number (reserve) <*> (reserve) <*>	(0 - 255
	00 1A	Oaaa aaaa	(reserve) <*> Pad 2 Velocity	(1 - 127
	00 1B 00 1C	0aaa aaaa 0000 000a	(reserve) <*>	(1 - 127
	00 1D	0000 aaaa 0000 bbbb	Pad 2 Rhythm Pattern Number	(0 - 255
	00 1F 00 20	Oaaa aaaa	(reserve) <*>	(0 255
	00 20	Oaaa aaaa Oaaa aaaa	(reserve) <*> Pad 3 Velocity	(1 - 127
	00 21 00 22 00 23	0aaa aaaa 0000 000a	(reserve) <*>	(1 12)
	00 23	0000 aaaa	Pad 3 Rhythm Pattern Number	(0 - 255
	00 25	Oaaa aaaa	Pad 3 Rhythm Pattern Number (reserve) <*>	(
	00 26 00 27	Oaaa aaaa Oaaa aaaa	(reserve) <*> Pad 4 Velocity	(1 - 127
	00 28	0aaa aaaa 0000 000a	Pad 4 Velocity (reserve) <*>	,
	00 29	0000 aaaa 0000 bbbb	Pad 4 Rhythm Pattern Number	(0 - 255
	00 2B 00 2C	Oaaa aaaa	(reserve) <*> (reserve) <*>	
	00 2D	Oaaa aaaa Oaaa aaaa	Pad 5 Velocity	(1 - 127
	00 2E 00 2F	0000 000a 0000 aaaa	(reserve) <*>	
	i	0000 aaaa	Pad 5 Rhythm Pattern Number	(0 - 255
	00 31 00 32 00 33	Oaaa aaaa	(reserve) <*> (reserve) <*>	
	00 32	Oaaa aaaa Oaaa aaaa	Pad 6 Velocity	(1 - 127
	00 34 00 35	0000 000a 0000 aaaa	(reserve) <*>	
		l nnnn bbbb	Pad 6 Rhythm Pattern Number	(0 - 255
	00 37 00 38	Oaaa aaaa Oaaa aaaa	(reserve) <*> (reserve) <*>	
	00 39	0aaa aaaa 0000 000a	Pad 7 Velocity	(1 - 127
	00 39 00 3A 00 3B	0000 000a 0000 aaaa	(reserve) <*>	
		0000 bbbb	Pad 7 Rhythm Pattern Number	(0 - 255
	00 3D 00 3E 00 3F	Oaaa aaaa	(reserve) <*> (reserve) <*>	
	00 3F	Oaaa aaaa Oaaa aaaa	Pad 8 Velocity	(1 - 127
	00 40 00 41	0000 000a 0000 aaaa	(reserve) <*>	
		0000 bbbb	Pad 8 Rhythm Pattern Number	(0 - 255
			(recerve) <*>	
	00 43 00 44	0aaa aaaa 0aaa aaaa	(reserve) <*> (reserve) <*> Pad 9 Velocity (reserve) <*>	

	#	00 47			
-					(0 - 255)
		00 49	Vaaa aaaa	(reserve) <*>	
- 1		00 4A	Oaaa aaaa	(reserve) <*> Pad 10 Velocity	(1 - 127)
- 1		00 40	0000 0005	(reserve) <*>	(1 - 12/)
	#	00 4C		(reserve) (">	
- 1	"	00 12		Pad 10 Rhythm Pattern Number	(0 - 255)
ı		00 4F		(reserve) <*>	(,
- 1		00 50	Oaaa aaaa	(reserve) <*>	
- 1		00 51	Oaaa aaaa	Pad 11 Velocity	(1 - 127)
i		00 52	0000 000a	(reserve) <*>	
- 1	#	00 53			
					(0 - 255)
				(reserve) <*>	
- 1		00 56	Oaaa aaaa	(reserve) <*> Pad 12 Velocity	
- !		00 57	Uaaa aaaa	Pad 12 Velocity	(1 - 127)
	#	00 58	0000 000a	(reserve) <*>	
	#	00 59	0000 aaaa	Pad 12 Rhythm Pattern Number	(0 255)
- 1		00 EB		(reserve) <*>	(0 - 255)
- 1				(reserve) <*>	
- 1					(1 - 127)
ı				(reserve) <*>	(/
- 1	#	00 5F	0000 aaaa		
- 1			0000 bbbb	Pad 13 Rhythm Pattern Number	(0 - 255)
İ		00 61	Oaaa aaaa	(reserve) <*>	
		00 62	Oaaa aaaa	(reserve) <*>	
ı		00 63	Oaaa aaaa	Pad 14 Velocity	(1 - 127)
- 1		00 64	00000 000a	(reserve) <*>	
	#	00 65			(0 055)
H		00 67		Pad 14 Rhythm Pattern Number (reserve) <*>	(0 - 255)
- 1				(reserve) <*>	
				Pad 15 Velocity	(1 - 127)
ı				(reserve) <*>	(1 12/)
- 1		00 6B		(1000170)	
				Pad 15 Rhythm Pattern Number	(0 - 255)
i		00 6D		(reserve) <*>	
- 1		00 6E	Oaaa aaaa	(reserve) <*>	
					(1 - 127)
		00 70	0000 000a	(reserve) <*>	
	#	00 71	0000 aaaa		
-			0000 pppp	Pad 16 Rhythm Pattern Number	(0 - 255)
	00 00	00 73	Total Size		
-!	00 00	00 /3	TOCAL SIZE		

* Chord Memory Common

)ffset Address	 	Description	
00 00	Oaaa aaaa	Chord Name 1	(32 - 127)
00 01	Oaaa aaaa	Chord Name 2	(32 - 127)
00 02	Oaaa aaaa	Chord Name 3	(32 - 127)
00 03	Oaaa aaaa	Chord Name 4	(32 - 127)
00 04	Oaaa aaaa	Chord Name 5	(32 - 127)
00 05	Oaaa aaaa	Chord Name 6	(32 - 127)
00 06	Oaaa aaaa	Chord Name 7	(32 - 127)
00 07	Oaaa aaaa	Chord Name 8	(32 - 127)
00 08	Oaaa aaaa	Chord Name 9	(32 - 127)
00 09	Oaaa aaaa	Chord Name 10	(32 - 127)
00 OA	Oaaa aaaa	Chord Name 11	(32 - 127)
00 OB	Oaaa aaaa	Chord Name 12	(32 - 127)
00 OC	Oaaa aaaa	Chord Name 13	(32 - 127)
00 0D	Oaaa aaaa	Chord Name 14	(32 - 127)
00 OE	Oaaa aaaa	Chord Name 15	(32 - 127)
00 OF	Oaaa aaaa	Chord Name 16	(32 - 127)
00 10	0000 000a	(reserve) <*>	

* Chord Memory Pattern

fset			
Address		Description	
00 00	Oaaa aaaa	Chord Pattern Assign 1	(20 - 108 OFF, A0 - C8
00 01	Oaaa aaaa	Chord Pattern Assign 2	(20 - 108 OFF, A0 - C8
00 02	Oaaa aaaa	Chord Pattern Assign 3	(20 - 108 OFF, A0 - C8
00 03	Oaaa aaaa	Chord Pattern Assign 4	(20 - 108 OFF, A0 - C8
00 04	Oaaa aaaa	Chord Pattern Assign 5	(20 - 108 OFF, A0 - C8
00 05	Oaaa aaaa	Chord Pattern Assign 6 Chord Pattern Assign 7	(20 - 108 OFF, A0 - C8
00 06	Oaaa aaaa	Chord Pattern Assign / Chord Pattern Assign 8	(20 - 108 OFF, A0 - C8 (20 - 108
00 07	vaaa dddd	Chord Factern Assign 8	OFF, A0 - C8

* Patch Common

Offset Address		Description	
00 00	Oaaa aaaa	Patch Name 1	(32 - 127)
00 01	Oaaa aaaa	Patch Name 2	32 - 127 [ASCII] (32 - 127)
00 02	Oaaa aaaa	Patch Name 3	32 - 127 [ASCII] (32 - 127)
00 03	Oaaa aaaa	Patch Name 4	32 - 127 [ASCII] (32 - 127)
00 04	Oaaa aaaa	Patch Name 5	32 - 127 [ASCII] (32 - 127)
00 05	Oaaa aaaa	Patch Name 6	32 - 127 [ASCII] (32 - 127)
00 06	Oaaa aaaa	Patch Name 7	32 - 127 [ASCII] (32 - 127)
00 07	Oaaa aaaa	Patch Name 8	32 - 127 [ASCII] (32 - 127)
00 08	Oaaa aaaa	Patch Name 9	32 - 127 [ASCII] (32 - 127)

00 09 00 0A			
nn na	Oaaa aaaa	Patch Name 10	32 - 127 [ASCII] (32 - 127) 32 - 127 [ASCII]
UU UA	Oaaa aaaa	Patch Name 11	(32 - 127 32 - 127 [ASCII]
00 OB	Oaaa aaaa	Patch Name 12	(32 - 127) 32 - 127 [ASCII]
00 OC	Oaaa aaaa	Patch Category	(0 - 127)
00 0D	0000 000a	(reserve)	
00 OE 00 OF	Oaaa aaaa Oaaa aaaa	Patch Level Patch Pan	(0 - 127) (0 - 127) L64 - 63R (0 - 1)
00 10	0000 000a	Patch Priority	L64 - 63R
00 10	Oaaa aaaa	Patch Coarse Tune	LAST, LOUDEST
00 11	Oaaa aaaa	Patch Fine Tune	(16 - 112) -48 - +48
00 12	0000 0aaa	Octave Shift	-48 - +48 (14 - 114) -50 - +50 (61 - 67) -3 - +3 (0 - 3)
00 13	0000 0aaa	Stretch Tune Depth	-3 - +3
00 14	Oaaa aaaa	Analog Feel	(0 - 3) OFF, 1 - 3 (0 - 127)
00 16	0000 000a	Mono/Poly	(0 - 1)
00 17	0000 000a	Legato Switch	MONO, POLY (0 - 1)
00 18	0000 000a	Legato Retrigger	(0 - 1) OFF, ON (0 - 1) OFF, ON (0 - 1) OFF, ON (0 - 1)
00 19	0000 000a	Portamento Switch	(0 - 1)
00 1A	0000 000a	Portamento Mode	OFF, ON (0 - 1)
00 1B	0000 000a	Portamento Type	(0 - 1)
00 1C	0000 000a	Portamento Start	RATE, TIME (0 - 1)
00 1D	Oaaa aaaa	Portamento Time	PITCH, NOTE (0 - 127)
00 1E 00 1F	0000 000a 0000 aaaa	(reserve)	
00 21	0000 bbbb 0000 000a	(reserve)	
00 22	Oaaa aaaa	Cutoff Offset	(1 - 127
00 22	Oaaa aaaa	Resonance Offset	(1 - 127 -63 - +63 (1 - 127 -63 - +63 (1 - 127 -63 - +63 (1 - 127 -63 - +63
00 23	Oaaa aaaa	Attack Time Offset	-63 - +63
			-63 - +63
00 25	Oaaa aaaa	Release Time Offset	(1 - 127) -63 - +63 (1 - 127) -63 - +63
00 26	Oaaa aaaa	Velocity Sens Offset	(1 - 127) -63 - +63
00 27	0000 aaaa	Patch Output Assign	MFX, A,,,, TONE
		1, 2,,	TONE
00 28	0000 000a	TMT Control Switch	(0 - 1 OFF, ON (0 - 48) (0 - 48)
00 29 00 2A	00aa aaaa 00aa aaaa	Pitch Bend Range Up Pitch Bend Range Down	(0 - 48)
00 2A 00 2B		Matrix Control 1 Source	(0 - 48)
00 2C	00aa aaaa	Matrix Control 1 Destination OFF, PIT-L PAN-LFO: PT' TV	PCH, CUT, RES, LEV, PAN, DRY, CHO, REV, PIT-LFO1, FO2, TVF-LFO1, TVF-LFO2, FO1, TVA-LFO2, PAN-LFO1, 2, LFO1-RATE, LFO2-RATE, T-ATK, PIT-DCY, PIT-REL, F-ATK, TVF-DCY, TVF-REL, TVF-R
00 2D	Oaaa aaaa	TMT, FXM, Matrix Control 1 Sens 1	A-ATK, TVA-DCY, TVA-REL MFX1, MFX2, MFX3, MFX4 (1 - 127)
00 2E	00aa aaaa	PAN-LFO: PI' TV	PCH, CUT, RES, LEV, PAN DRY, CHO, REV, PIT-LF01 FO2, TVF-LF01, TVF-LF02
00 2F	Oaaa aaaa	Matrix Control 1 Sens 2	(1 - 127) -63 - +63
00 2F 00 30	0aaa aaaa 00aa aaaa	Matrix Control 1 Destination OFF, in Pirt-Li TVA-Li PAN-LPC PI' TV.	(1 - 127) -63 - +63 -67 - +63 -68 - +63 -68 - +63 -68 - +63 -69 -
		Matrix Control 1 Destinati OFF, PIT-Li TVA-LFO: PAN-LFO: TV. TV. TV. TMT, FXM, Matrix Control 1 Sens 3	(1 - 127) -63 - 68 -60 - 30 -6
00 30	00aa aaaa	Matrix Control 1 Destinati OFF.: PIT-Li TVA-Li PAN-LFO: PI TV. TWT, FXM, Matrix Control 1 Destinati OFF.: TVA-Li PAN-LFO: PAN-LFO: TVA-LI PAN-LFO: TV	(1 - 127) -63 - 63 -60 - 30 -6
00 30	00aa aaaa 00aa aaaa	Matrix Control 1 Destinati OFF.: PIT-Li TVA-Li PAN-LFO: PI TV. TWT, FXM, Matrix Control 1 Destinati OFF.: TVA-Li PAN-LFO: PAN-LFO: TVA-LI PAN-LFO: TV	(1 - 127) -63 - 463 OPCH, CUT, RES, LEV, PAN DRY, CHO, REV, PTT-LFO1 OPC, TVF-LFO1, TVF-LFO2 FO1, TVA-LFO2, PAN-LFO1, TVF-LFO2 FO1, TVA-LFO2, PAN-LFO1, TVF-LFO2 F-ATK, TVF-DCY, TVF-REL A-ATK, TVA-DCY, TVA-REL A-ATK, TVA-DCY, TVA-REL DRY, CHO, BEV, PTT-LFO1 DRY, CHO, BEV, PTT-LFO1 DRY, CHO, BEV, PTT-LFO1 DRY, CHO, BEV, PTT-LFO1 DRY, CHO, BEV, PTT-LFO1 DRY, CHO, BEV, PTT-LFO1 DRY, CHO, BEV, PTT-LFO1 DRY, CHO, BEV, PTT-LFO1 DRY, CHO, BEV, PTT-LFO1 DRY, CHO, BEV, PTT-LFO1 DRY, CHO, BEV, PTT-LFO1 DRY, CHO, A-APK, TVA-DCY, TVF-REL ATK, TVF-DCY, PTT-REL P-ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, TVF-REL ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, PTT-REL ATK, TVF-DCY, TVF-REL ATK, TVF-DCY, TVF-REL ATK, TVF-DCY, TVF-REL ATK, TVF-DCY, TVF-REL ATK, TVF-DCY, TVF-REL ATK, TVF-DCY, TVF-REL ATK, TVF-DCY, TVF-REL ATK, TVF-ACY, TVF
00 30 00 31 00 32	Oaaa aaaa Ooaa aaaa Ooaa aaaa	Matrix Control 1 Destinati OFF.: PIT-LI TVA-LI TVA-LI PAN-LFO PI TVI TWT TWT TWT TWT TWT TWT TWT TWT TWT TW	(1 - 127) -63 - 63 -60 -60 -60 -60 -60 -60 -60 -60 -60 -60
00 30 00 31 00 32 00 33 00 34	Oaaa aaaa Oaaa aaaa Oaaa aaaa	Matrix Control 1 Destination (OFF.) PIT-LI TVA-LI PAN-LFO PI TVI TWT TWT TWT TWT TWT TWT TWT TWT TWT TW	(1 - 127) -63 - 63 DPCH, CUT, RES, LEV, PAN DRY, CHO, REV, PIT-LFO1 OC2, TVF-LFO1, TVF-LFO2 CO1, TVF-LFO2, PAN-LFO1,
00 31 00 32 00 33	Oaaa aaaa Oaaa aaaa Oaaa aaaa	Matrix Control 1 Destination of F	(1 - 127) -63 - 63 -60 -60 -60 -60 -60 -60 -60 -60 -60 -60

		TVA-LF01, TVA-LF02, PAN-LF01, PAN-LF02, LF01-RATE, LF02-RATE, PIT-ATK, PIT-DCY, PIT-REL,
		TVF-ATK, TVF-DCY, TVF-REL,
00 38	Oaaa aaaa	TVA-ATK, TVA-DCY, TVA-REL, TVA-TX, MFX2, MFX3, MFX3, MFX4 Matrix Control 2 Sens 2 (1 - 127) Matrix Control 2 Destination 3 (6 - 33 - 463) OFF, PCH, CUT, RES, LEV, PAN, DRY, CHO, REV, PLT-LFO1, PLT-CALL, TVA-LFO2, PAN-LFO1, PAN-LFO2, LFO1-RATE, LFO2-RATE, DPM-MAY DETT-MENT DETT-MENT,
00 39	00aa aaaa	Matrix Control 2 Destination 3 (0 - 33) OFF, PCH, CUT, RES, LEV, PAN,
		DRY, CHO, REV, PIT-LF01, PIT-LF02, TVF-LF01, TVF-LF02,
		TVF-ATK, TVF-DCY, TVF-REL,
00 3A	Oaaa aaaa	Matrix Control 2 Sens 3 (1 - 127) -63 - +63
00 3B	00aa aaaa	TVA-ATK, TVA-DCY, TVA-REI, TVA-ATK, TVA-DCY, TVA-REI, MATRIX CONTROL 2 Sens 3 (1 - 127) Matrix Control 2 Destination 4 (0 - 33) OFF, PCH, CUT, RES, LEV, PAN, DRY, CHO, REV, PIT-LFO1, PIT-LFO2, TVP-LFO1, TVP-LFO2, TVA-LFO1 TVA-LFO2, ATRIC, PAN-LFO2 TVA-LFO2, PAN-LFO1 PAN-LFO2, LFO2-RATE, PAN-LFO2 LFO2-RATE,
		PIT-LF02, TVF-LF01, TVF-LF02, TVA-LF01, TVA-LF02, PAN-LF01,
		TVF-ATK, TVF-DCY, TVF-REL, TVA-ATK, TVA-DCY, TVA-REL, TMT, FXM, MFX1, MFX2, MFX3, MFX4
00 3C	Oaaa aaaa	TWA-ATK, TVA-DI, TVA-REL, TMT, FXM, MFX1, MFX2, MFX3, MFX4 Matrix Control 2 Sens 4 (1 - 127) -63 - +63
00 3D	Oaaa aaaa	Matrix Control 3 Source (0 - 109) OFF, CC01 - CC31, CC33 - CC95, BEND, AFT, SYS1 - SYS4, VELOCITY,
		KEYFOLLOW, TEMPO, LF01, LF02,
00 3E	00aa aaaa	Matrix Control 3 Destination 1 UT, RES, LEV, PAN, OVERNO, DESTINATION 1 (0 - 33) OFF, PCH, CUT, RES, LEV, PAN, DRY, CHO, REV, PIT-LFO1, PIT-LFO2, TVP-LFO1, TVP-LFO2, TVP-LFO1, TVA-LFO1,
		PIT-LF02, TVF-LF01, TVF-LF02, TVA-LF01, TVA-LF02, PAN-LF01,
		PAN-LFO2, LFO1-RATE, LFO2-RATE, PIT-ATK, PIT-DCY, PIT-REL, TVF-ATK, TVF-DCY, TVF-REL, TVA-ATK, TVA-DCY, TVA-REL,
		TVA-ATK, TVA-DCY, TVA-REL, TMT, FXM, MFX1, MFX2, MFX3, MFX4
00 3F 00 40	0aaa aaaa 00aa aaaa	Matrix Control 3 Sens 1 (1 - 127) -63 - +63 Matrix Control 3 Destination 2 (0 - 33)
		TVA-ATK, TVA-DCY, TVA-REL, TMT, FXM, MFX1, MFX2, MFX3, MFX4 Matrix Control 3 Sens 1 (1 - 127) Matrix Control 3 Destination 2 (0 - 33) OFF, PCH, CUT, RES, LEV, PAM, DRY, CHO, REV, PTT-LFO1, PTT-LFO2, TVP-LFO1, TVP-LFO2, TVA-LFO1, TVA-LFO2, PAN-LFO1, PAN-LFO2, LFO1-RATE, LFO2-RATE, DTT-MFK PTT-NFV PTT-BFE,
		TYA-LFO2, TVF-LFO1, TVF-LFO2, TVA-LFO1, TVA-LFO2, PAN-LFO1, PAN-LFO2, LFO1-RATE, LFO2-RATE,
		TVF-ATK, TVF-DCY, TVF-REL,
00 41	Oaaa aaaa	TMT, FXM, MFX1, MFX2, MFX3, MFX4 Matrix Control 3 Sens 2 (1 - 127)
00 42	00aa aaaa	TVA-ATK, TVA-DCY, TVA-REL, TMT, FXM, MFX1, MFX2, MFX3, MFX4 Matrix Control 3 Sens 2 (1 - 127) Matrix Control 3 Destination 3 (0 - 33) OFF, PCH, CUT, RES, LEV, PAM, DRY, CHO, REV, PTT-LFO1, PTT-LFO2, TVP-LFO1, TVP-LFO2, TVA-LFO1, TVA-LFO2, PAN-LFO1, PAN-LFO2, LFO1-RATE, LFO2-RATE, DTT-MFK PTT-NFV PTT-BFE,
		DRY, CHO, REV, PIT-LF01, PIT-LF02, TVF-LF01, TVF-LF02,
		TVF-ATK, TVF-DCY, TVF-REL,
00 43	Oaaa aaaa	TVA-ATK, TVA-DCY, TVA-REL, TMT, FXM, MFX1, MFX2, MFX3, MFX4 Matrix Control 3 Sens 3 (-6 - 127) Matrix Control 3 Destination 4 (0 - 33) OFF, PCH, CUT, RES, LEV, PAN, DRY, CHO, REV, PIT-LFO1, PIT-LFO2, TVF-LFO1, TVF-LFO2, TVA-LFO1, TVA-LFO2, PAN-LFO1, PAN-LFO2, LFO1-RATE, LFO2-RATE.
00 44	00aa aaaa	Matrix Control 3 Destination 4 (0 - 33) OFF, PCH, CUT, RES, LEV, PAN, DBV CHO REV PIT-LEO1
		PIT-LF02, TVF-LF01, TVF-LF02, TVA-LF01, TVA-LF01, TVA-LF02, PAN-LF01,
		PAN-LFO2, LFO1-RATE, LFO2-RATE, PIT-ATK, PIT-DCY, PIT-REL, TVF-ATK, TVF-DCY, TVF-REL,
00 45	Oaaa aaaa	PAN-LFO2, LFO1-RATE, LFO2-RATE, PITA-ATK, PIT-DCY, PIT-REL, PTA-ATK, TVF-DCY, PIT-REL, TVF-ATK, TVF-DCY, TVF-REL, TVF-ATK, TVF-DCY, TVA-REL, TMT, FXM, MFX1, MFX2, MFX3, MFX4 Matrix Control 3 Sens 4 (1 - 127) -63 - +63
00 46	Oaaa aaaa	Matrix Control 4 Source
00 47	00aa aaaa	KEYFOLLOW, TEMPO, LFO1, LFO2,
00 4/	Junu aaad	Matrix Control 4 Destination 1 (0 - 33) OFP, PCH, CUT, RES, LEV, PAN, DRY, CHO, REV, PIT-LFO1, PIT-LFO2, TVF-LFO1, TVF-LFO2, TVA-LFO1, TVA-LFO2, PAN-LFO1, PAN-LFO2, LFO1-RATE, LFO2-RATE.
		PIT-LF02, TVF-LF01, TVF-LF02, TVA-LF01, TVA-LF02, PAN-LF01, PAN-LF02, LF01-RATE, LF02-RATE,
		PIT-ATK, PIT-DCY, PIT-REL, TVF-ATK, TVF-DCY, TVF-REL,
00 48	Oaaa aaaa	TWA-ATK, TVA-DCY, TVA-REL, TMT, FXM, MFX1, MFX2, MFX3, MFX4 Matrix Control 4 Sens 1 (1 - 127)
00 49	00aa aaaa	PAN-LFO2, LFO1-RATE, LFO2-RATE, PTT-ATK, PTT-DCY, PTT-REL, TVF-ATK, TVF-DCY, PTT-REL, TVF-ATK, TVF-DCY, TVF-REL, TWA-ATK, TVA-DCY, TVA-REL, TMT, FXM, MFX1, MFX2, MFX3, MFX4 Matrix Control 4 Sens 1 (1 - 127) -63 - +63 Matrix Control 4 Destination 2 (0 - 33) OFF, PCH, CUT, RES, LEV, PAN, DRY, CHO, REV, PIT-LFO1, PAN-LFO1, TVF-LFO2, TVA-LFO1, TVF-LFO2, TVA-LFO1, TVA-LFO2, PAN-LFO1, PAN-LFO2, LFO1-RATE, LFO2-RATE,
		DFF, FCH, CUT, RES, LEV, PAN, DRY, CHO, REV, PIT-LF01, PIT-LF02, TVF-LF01, TVF-LF02
		TVA-LFO1, TVA-LFO2, PAN-LFO1, PAN-LFO2, LFO1-RATE, LFO2-RATE, PAT-ATK PIT-DCV PIT-REI.
		TVF-ATK, TVF-DCY, TVF-REL, TVA-ATK, TVA-DCY, TVA-REL,
00 4A	Oaaa aaaa	PAN-LFO2, LFO1-RATE, LFO2-RATE, PTT-ATK, PIT-DCY, PIT-REL, TVF-ATK, TVF-DCY, PTT-REL, TVF-ATK, TVF-DCY, TVF-REL, TWA-ATK, TVA-DCY, TVA-REL, TMT, FXM, MFX1, MFX2, MFX3, MFX4 Matrix Control 4 Sens 2 (1 - 127) -63 - +63 Matrix Control 4 Destination 3 (0 - 33) OFF, PCH, CUT, RES, LEV, PAN, DRY, CHO, REV, PIT-LFO1, PAN-LFO1, TVF-LFO2, TVA-LFO1, TVF-LFO2, PAN-LFO1, PAN-LFO2, LFO1-RATE, LFO2-RATE,
00 4B	00aa aaaa	Matrix Control 4 Destination 3 (0 - 33) OFF, PCH, CUT, RES, LEV, PAN,
		DKY, CHO, REV, PIT-LFO1, PIT-LFO2, TVF-LFO1, TVF-LFO2, TVA-LFO1, TVA-LFO2, PAN-LFO1,
		PAN-LFO2, LFO1-RATE, LFO2-RATE, PIT-ATK, PIT-DCY, PIT-REL, TVP-ATK, TVP-DCY, TVP-REL
		TVA-ATK, TVA-DCY, TVF-REL, TVA-ATK, TVA-DCY, TVA-REL, TMT, FXM, MFX1, MFX2, MFX3, MFX4
00 4C	0aaa aaaa 00aa aaaa	PAN-LFO2, LFO1-RATE, LFO2-RATE, PTT-ATK, PIT-DCY, PIT-REL, TVF-ATK, TVF-DCY, PTT-REL, TVF-ATK, TVF-DCY, TVF-REL, TWA-ATK, TVA-DCY, TVA-REL, TMT, FXM, MFX1, MFX2, MFX3, MFX4 Matrix Control 4 Sens 3 (1 - 127) -63 - +63 Matrix Control 4 Destination 4 (0 - 33) OFF, PCH, CUT, RES, LEV, PAN, DRY, CHO, REV, PIT-LFO1, PAN-LFO1, TVF-LFO1, TVF-LFO2, TVA-LFO1, TVF-LFO2, PAN-LFO1, PAN-LFO2, LFO1-RATE, LFO2-RATE,
		OFF, PCH, CUT, RES, LEV, PAN, DRY, CHO, REV, PIT-LF01,
		PIT-LFO2, TVF-LFO1, TVF-LFO2, TVA-LFO1, TVA-LFO2, PAN-LFO1, PAN-LFO2, LFO1-RATE, LFO2-RATE,
		PIT-ATK, PIT-DCY, PIT-REL, TVF-ATK, TVF-DCY, TVF-REL,
00 4E	Oaaa aaaa	TVA-ATK, TVA-DCY, TVA-REL, TMT, FXM, MFX1, MFX2, MFX3, MFX4 Matrix Control 4 Sens 4 (1 - 127) -63 - +63
		-63 - +63

00 4F	0000 000a	Part Modulation Switch	(0 - 1) OFF, ON
00 00 00 50	Total Size		

* Patch Common MFX

Offse A	ddress		Description	
	00 00	Oaaa aaaa	MFX Type MFX Dry Send Level MFX Chorus Send Level MFX Reverb Send Level MFX Output Assign <*>	(0 - 79 (0 - 127
	00 01 00 02	Oaaa aaaa	MFX Dry Send Level	(0 - 127 (0 - 127
	00 03	Oaaa aaaa	MFX Reverb Send Level	(0 - 127 (0 - 127
	00 04	0000 00aa	MFX Output Assign <*>	A,,,
	00 05	0aaa aaaa	MFX Control 1 Source OFF,	
	00 06	Oaaa aaaa	MFX Control 1 Sens	BEND, AFT, SYS1 - SYS4 (1 - 127
	00 07	Oaaa aaaa	MFX Control 2 Source OFF,	(0 - 10) CC01 - CC31, CC33 - 100) BEND, AFT, SYS1 - SYS4 (1 - 127 -63 - +63 (0 - 10) CC01 - CC31, CC33 - CC95 BEND, AFT, SYS1 - SYS4 (1 - 127 -63 - +63 (0 - 10)
	00 08	Oaaa aaaa	MFX Control 2 Sens	BEND, AFT, SYS1 - SYS4 (1 - 127
	00 09	Oaaa aaaa		
	00 OA	Oaaa aaaa	MFX Control 3 Sens	CC01 - CC31, CC33 - CC95 BEND, AFT, SYS1 - SYS4 (1 - 127
	00 OB	Oaaa aaaa	MFX Control 4 Source	-63 - +63 (0 - 101
	00 OC	Oaaa aaaa	OFF, MFX Control 4 Sens	(1 - 127 -63 - +63 (0 - 101 CC01 - CC31, CC33 - CC95 BEND, AFT, SYS1 - SYS4 (1 - 127 -63 - +63
		 +		
	00 0D		MFX Control Assign 1	(0 - 16 OFF, 1 - 16
	00 OE	000a aaaa	MFX Control Assign 2	OFF, 1 - 16 (0 - 16 OFF, 1 - 16
	00 OF 00 10	000a aaaa	MFX Control Assign 3 MFX Control Assign 4	(0 - 16 OFF, 1 - 16 (0 - 16
;	00 10	0000 aaaa	insign 4	OFF, 1 - 16
	-, 11	0000 dada 0000 bbbb 0000 cccc	MFX Parameter 1	(12768 - 52768 -20000 - +20000
‡	00 15	0000 aaaa		-20000 - +20000
		0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 2	/12760 52760
‡	00 19	0000 dddd 0000 aaaa	rarameter 2	(12768 - 52768 -20000 - +20000
		0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 3	(12768 - 52768
‡	00 1D		rrr rarameter 3	-20000 - +20000
	00 ID	0000 aaaa 0000 bbbb 0000 cccc		
		0000 dddd	MFX Parameter 4	(12768 - 52768 -20000 - +20000
ŧ	00 21	0000 aaaa 0000 bbbb		
		0000 dddd	MFX Parameter 5	(12768 - 52768 -20000 - +20000
ŧ	00 25	0000 aaaa 0000 bbbb		-20000 - +20000
		0000 cccc	MFX Parameter 6	(12768 - 52769
;	00 29	0000 aaaa		(12768 - 52768 -20000 - +20000
		0000 bbbb 0000 cccc		
	00.0=	0000 dddd	MFX Parameter 7	(12768 - 52768 -20000 - +20000
ŧ	00 2D	0000 aaaa 0000 bbbb		
		0000 cccc 0000 dddd	MFX Parameter 8	(12768 - 52768 -20000 - +20000
ŧ	00 31	0000 aaaa 0000 bbbb		-20000 - +20000
		0000 dddd	MFX Parameter 9	(12768 - 52768
ŧ	00 35	0000 aaaa		(12768 - 52768 -20000 - +20000
		0000 bbbb 0000 cccc		
	00	0000 dddd	MFX Parameter 10	(12768 - 52768 -20000 - +20000
ŧ	00 39	0000 aaaa 0000 bbbb		
		0000 cccc 0000 dddd	MFX Parameter 11	(12768 - 52768 -20000 - +20000
ŧ	00 3D	0000 aaaa 0000 bbbb		-20000 - +20000
		0000 cccc	MFX Parameter 12	(12768 - 52769
‡	00 41	0000 aaaa		(12768 - 52768 -20000 - +20000
		0000 bbbb 0000 cccc		
		İ	MFX Parameter 13	(12768 - 52768 -20000 - +20000
ŧ	00 45	0000 aaaa 0000 bbbb		
		0000 cccc 0000 dddd	MFX Parameter 14	(12768 - 52768 -20000 - +20000
ŧ	00 49	0000 aaaa 0000 bbbb		_3000
		0000 cccc	MFX Parameter 15	(12768 - 52768 -20000 - +20000
;	00 4D	0000 aaaa		-20000 - +20000
		0000 bbbb 0000 cccc		,,,,,,,
	00 ==	0000 dddd	MFX Parameter 16	(12768 - 52768 -20000 - +20000
ŧ	00 51	0000 aaaa 0000 bbbb		
		0000 cccc 0000 dddd	MFX Parameter 17	(12768 - 52768 -20000 - +20000
‡	00 55	0000 aaaa		-20000 - +20000
		0000 bbbb	MPV Davameter 10	(10760
:	00 59		MFX Parameter 18	(12768 - 52768 -20000 - +20000
	00 00	0000 aaaa 0000 bbbb 0000 cccc		

		0000 dddd	MFX Parameter 19	(12768 - 52768) -20000 - +20000
#		0000 aaaa 0000 bbbb 0000 cccc	MFX Parameter 20	(12768 - 52768) -20000 - +20000
#	00 61	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 21	(12768 - 52768)
#	00 65	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 22	-20000 - +20000 (12768 - 52768)
#	00 69	0000 bbbb 0000 cccc	MFX Parameter 23	-20000 - +20000 (12768 - 52768)
#	00 6D	0000 aaaa 0000 bbbb	MFX Parameter 24	-20000 - +20000 (12768 - 52768)
#	00 71	0000 aaaa 0000 bbbb 0000 cccc		-20000 - +20000
#	00 75	0000 aaaa 0000 bbbb 0000 cccc	MFX Parameter 25	(12768 - 52768) -20000 - +20000
#	00 79	0000 dddd 0000 aaaa 0000 bbbb 0000 cccc	MFX Parameter 26	(12768 - 52768) -20000 - +20000
#	00 7D	0000 dddd 0000 aaaa 0000 bbbb	MFX Parameter 27	(12768 - 52768) -20000 - +20000
#	01 01	0000 cccc 0000 dddd 0000 aaaa 0000 bbbb	MFX Parameter 28	(12768 - 52768) -20000 - +20000
#	01 05	0000 cccc 0000 dddd 0000 aaaa	MFX Parameter 29	(12768 - 52768) -20000 - +20000
_	01.00		MFX Parameter 30	(12768 - 52768) -20000 - +20000
#	01 09	0000 bbbb 0000 cccc	MFX Parameter 31	(12768 - 52768) -20000 - +20000
#	01 0D	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 32	(12768 - 52768) -20000 - +20000

* Patch Common Chorus

Offset Address		Description	
00 00 00 01 00 02	0000 aaaa 0aaa aaaa 0000 00aa	Chorus Type Chorus Level Chorus Output Assign <*>	(0 - 3) (0 - 127)
00 03	0000 00aa	Chorus Output Select	MAIN, REV, MAIN+REV
# 00 04	I nonn bbbb	Chorus Parameter 1	(12768 - 52768)
# 00 08	0000 aaaa	Chorus Parameter 2	(12768 - 52768) -20000 - +20000
# 00 OC	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 3	
# 00 10	0000 aaaa 0000 bbbb		(12768 - 52768)
# 00 14	0000 aaaa 0000 bbbb	Chorus Parameter 5	(12768 - 52768)
# 00 18	0000 aaaa	Chorus Parameter 6	-20000 - +20000 (12768 - 52768) -20000 - +20000
# 00 1C	0000 aaaa 0000 bbbb		(12768 - 52768)
# 00 20	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 8	-20000 - +20000 (12768 - 52768)
# 00 24	0000 aaaa 0000 bbbb	Chorus Parameter 9	-20000 - +20000 (12768 - 52768)
# 00 28	0000 aaaa 0000 bbbb	Chorus Parameter 10	-20000 - +20000 (12768 - 52768)
# 00 2C	0000 aaaa 0000 bbbb	Chorus Parameter 11	-20000 - +20000
# 00 30	0000 dddd 0000 aaaa 0000 bbbb		-20000 - +20000

		0000 cccc 0000 dddd	Chorus Parameter 12	(12768 - 52768) -20000 - +20000
#	00 34	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 13	(12768 - 52768) -20000 - +20000
#	00 38	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 14	(12768 - 52768) -20000 - +20000
#	00 3C	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 15	(12768 - 52768)
#	00 40	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 16	-20000 - +20000 (12768 - 52768)
#	00 44	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 17	-20000 - +20000 (12768 - 52768)
#	00 48	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 18	-20000 - +20000 (12768 - 52768)
#	00 4C	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd		-20000 - +20000 (12768 - 52768)
#	00 50	0000 aaaa 0000 bbbb 0000 cccc	Chorus Parameter 19	-20000 - +20000
		0000 dddd	Chorus Parameter 20	(12768 - 52768) -20000 - +20000
00	00 00 54	Total Size		

* Patch Common Reverb

1	Offset Address		Description	
	00 00 00 01	0000 aaaa 0aaa aaaa	Reverb Type Reverb Level Reverb Output Assign <*>	(0 - 5) (0 - 127)
	00 02	0000 00aa	Reverb Output Assign <*>	
#	00 03	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 1	(12768 - 52768) -20000 - +20000
#	00 07	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 2	(12768 - 52768) -20000 - +20000
#	00 0B	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 3	(12768 - 52768) -20000 - +20000
#	00 OF	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 4	(12768 - 52768) -20000 - +20000
#	00 13	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 5	(12768 - 52768) -20000 - +20000
#	00 17	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 6	(12768 - 52768) -20000 - +20000
#	00 1B	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 7	(12768 - 52768) -20000 - +20000
#	00 1F	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 8	(12768 - 52768) -20000 - +20000
#	00 23	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 9	
#	00 27	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 10	(12768 - 52768) -20000 - +20000
#	00 2B	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 11	(12768 - 52768) -20000 - +20000
#	00 2F	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 12	(12768 - 52768) -20000 - +20000
#	00 33	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 13	(12768 - 52768) -20000 - +20000
#	00 37	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 14	(12768 - 52768) -20000 - +20000
#	00 3B	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 15	-20000 - +20000 (12768 - 52768) -20000 - +20000
#	00 3F	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 16	-20000 - +20000 (12768 - 52768) -20000 - +20000
#	00 43	0000 aaaa 0000 bbbb 0000 cccc		-20000 - +20000

				Reverb Parameter 17	(12768 - 52768) -20000 - +20000
#	00	47	0000 aaaa 0000 bbbb 0000 cccc		
			0000 dddd	Reverb Parameter 18	(12768 - 52768) -20000 - +20000
#	00	4B	0000 aaaa 0000 bbbb 0000 ccc		
			0000 dddd	Reverb Parameter 19	(12768 - 52768) -20000 - +20000
#	00	4F	0000 aaaa 0000 bbbb		
			0000 dddd	Reverb Parameter 20	(12768 - 52768) -20000 - +20000
-	00 00 00	53	Total Size		

* Patch TMT (Tone Mix Table)

Offset Address		Description	
00 00	0000 aaaa	Structure Type 1 & 2	(0 - 9)
00 01	0000 00aa	Booster 1 & 2	(0 - 9) 1 - 10 (0 - 3)
00 02	0000 aaaa	0, +6, +12, Structure Type 3 & 4	(0 - 9)
00 03	0000 00aa	Booster 3 & 4 0, +6, +12,	1 - 10 (0 - 3) +18 [dB]
00 04	0000 00aa	TMT Velocity Control OFF, ON, RANDO	(0 - 3)
00 05	0000 000a	TMT1 Tone Switch	(0 - 1)
00 06	Oaaa aaaa	TMT1 Keyboard Range Lower	(0 - 1) OFF, ON (0 - 127)
00 07	Oaaa aaaa	C-1 TMT1 Keyboard Range Upper	- UPPER (0 - 127)
00 08 00 09 00 0A	Oaaa aaaa Oaaa aaaa Oaaa aaaa	TMT1 Keyboard Fade Width Lower TMT1 Keyboard Fade Width Upper TMT1 Velocity Range Lower	WER - G9 (0 - 127) (0 - 127) (1 - 127)
00 OB	Oaaa aaaa	TMT1 Velocity Pance Unner	- UPPER (1 - 127)
00 0C 00 0D	Oaaa aaaa Oaaa aaaa	TMT1 Velocity Fade Width Lower TMT1 Velocity Fade Width Upper	ER - 127 (0 - 127 (0 - 127
00 OE	0000 000a	TMT2 Tone Switch	(0 - 1)
00 OF	Oaaa aaaa	TMT2 Keyboard Range Lower	(0 - 1) OFF, ON (0 - 127)
00 10	Oaaa aaaa	C-1	- UPPER
00 11 00 12 00 13	Oaaa aaaa Oaaa aaaa Oaaa aaaa	TMT2 Keyboard Fade Width Lower TMT2 Keyboard Fade Width Upper TMT2 Velocity Range Lower	WER - G9 (0 - 127) (0 - 127) (1 - 127)
00 13	Oaaa aaaa	TMT2 Velocity Range Upper	- UPPER (1 - 127)
00 15 00 16	Oaaa aaaa Oaaa aaaa	LOW: TMT2 Velocity Fade Width Lower TMT2 Velocity Fade Width Upper	ER - 127 (0 - 127) (0 - 127)
00 17	 0000 000a	TMT3 Tone Switch	(0 - 1)
00 18	0aaa aaaa	TMT3 Keyboard Range Lower	OFF, ON (0 - 127)
00 19	Oaaa aaaa	C-1	- UPPER (0 - 127)
00 1A 00 1B 00 1C	0aaa aaaa 0aaa aaaa 0aaa aaaa	LOW TMT3 Keyboard Fade Width Lower	WER - G9 (0 - 127 (0 - 127 (1 - 127 - UPPER
00 1D	Oaaa aaaa	TMT3 Velocity Range Upper	(1 - 127)
00 1E 00 1F	Oaaa aaaa Oaaa aaaa	TMT3 Velocity Fade Width Lower	ER - 127 (0 - 127 (0 - 127
00 20	0000 000a	L	(0 - 1)
00 21	Oaaa aaaa	TMT4 Keyboard Range Lower	(0 - 1) OFF, ON (0 - 127)
00 22	Oaaa aaaa	C-1 TMT4 Keyboard Range Upper	- UPPER (0 - 127)
00 23 00 24 00 25	Oaaa aaaa Oaaa aaaa Oaaa aaaa	LOI TMT4 Keyboard Fade Width Lower TMT4 Keyboard Fade Width Upper TMT4 Velocity Range Lower	WER - G9 (0 - 127) (0 - 127) (1 - 127)
00 26	Oaaa aaaa		- UPPER
00 27 00 28	Oaaa aaaa Oaaa aaaa	TMT4 Velocity Range Upper LOW. TMT4 Velocity Fade Width Lower TMT4 Velocity Fade Width Upper	EK - 127 (0 - 127) (0 - 127)
00 00 00 29	Total Size		

* Patch Tone

+		
Offset Address		Description
00 00 00 01	Oaaa aaaa Oaaa aaaa	Tone Level (0 - 127) Tone Coarse Tune (16 - 112) -48 - 48
00 02	Oaaa aaaa	Tone Fine Tune (14 - 114)
00 03	000a aaaa	Tone Random Pitch Depth (0 - 30) (10
00 04	Oaaa aaaa	Tone Pan (0 - 127) L64 - 63R
00 05	000a aaaa	Tone Pan Keyfollow (54 - 74)
00 06 00 07	00aa aaaa 0aaa aaaa	Tone Random Pan Depth (0 - 63) Tone Alternate Pan Depth (1 - 127) L63 - 63R
00 08	0000 000a	Tone Env Mode (0 - 1) NO-SUS, SUSTAIN
00 09	0000 00aa	Tone Delay Mode (0 - 3) NORMAL, HOLD, KEY-OFF-NORMAL, KEY-OFF-DECAY
# 00 0A	0000 aaaa 0000 bbbb	Tone Delay Time (0 - 149) 0 - 127, MUSICAL-NOTES
00 0C 00 0D 00 0E 00 0F 00 10 00 11	0aaa aaaa 0aaa aaaa 0aaa aaaa 0aaa aaaa 0aaa aaaa 0000 aaaa	Tone Dry Send Level (MFX) (0 - 127) Tone Chorus Send Level (MFX) (0 - 127) Tone Reverb Send Level (MFX) (0 - 127) Tone Chorus Send Level (non MFX) (0 - 127) Tone Reverb Send Level (non MFX) (0 - 127) Tone Reverb Send Level (non MFX) (0 - 127) Tone Output Assign (0 - 12)

			MF	X, A,,
		 		X, A,,,, ,,,
	00 12	0000 000a	Tone Receive Bender	(0 - 1) OFF, ON
	00 13	0000 000a	Tone Receive Expression	OFF, ON (0 - 1) OFF, ON (0 - 1)
	00 14	0000 000a	Tone Receive Hold-1	OFF, ON (0 - 1)
	00 15	0000 000a		CONTINUOUS, KEY-ON
				(0 - 1) OFF, ON
	00 17	0000 00aa	Tone Control 1 Switch 1	(0 - 2) OFF, ON, REVERSE
	00 18	0000 00aa	Tone Control 1 Switch 2	(0 - 2) OFF, ON, REVERSE
	00 19	0000 00aa	Tone Control 1 Switch 3	(0 - 2) OFF, ON, REVERSE
	00 1A 00 1B	0000 00aa	Tone Control 1 Switch 4 Tone Control 2 Switch 1	(0 - 2) OFF, ON, REVERSE (0 - 2)
	00 1B	0000 00aa	Tone Control 2 Switch 2	OFF, ON, REVERSE (0 - 2)
	00 1C	0000 00aa	Tone Control 2 Switch 3	OFF, ON, REVERSE (0 - 2)
	00 1E	0000 00aa	Tone Control 2 Switch 4	OFF, ON, REVERSE (0 - 2)
	00 1F	0000 00aa	Tone Control 3 Switch 1	OFF, ON, REVERSE (0 - 2)
	00 20	0000 00aa	Tone Control 3 Switch 2	OFF, ON, REVERSE (0 - 2)
	00 21	0000 00aa	Tone Control 3 Switch 3	OFF, ON, REVERSE (0 - 2)
	00 22	0000 00aa	Tone Control 3 Switch 4	OFF, ON, REVERSE (0 - 2)
	00 23	0000 00aa	Tone Control 4 Switch 1	OFF, ON, REVERSE (0 - 2)
	00 24	0000 00aa	Tone Control 4 Switch 2	OFF, ON, REVERSE (0 - 2)
	00 25	0000 00aa	Tone Control 4 Switch 3	OFF, ON, REVERSE (0 - 2) OFF, ON, REVERSE
	00 26	0000 00aa	Tone Control 4 Switch 4	OFF, ON, REVERSE (0 - 2) OFF, ON, REVERSE
	00 27	 0000 00aa	(reserve) <*>	OFF, ON, REVERSE
#	00 27	0000 00aa	(
		0000 bbbb 0000 cccc		
		0000 dddd	(reserve) <*>	
#	00 2C	0000 aaaa 0000 bbbb		
		0000 cccc 0000 dddd	Wave Number L (Mono)	(0 - 16384) OFF, 1 - 16384
#	00 30	0000 aaaa		OFF, 1 - 16384
		0000 bbbb 0000 cccc	Wasse Numbers D	(0. 16304)
	00 34	0000 dddd 0000 00aa	Wave Number R Wave Gain	OFF, 1 - 16384 (0 - 3)
	00 35	0000 000a		-6, 0, +6, +12 [dB]
	00 36	0000 00aa	Wave FXM Color	(0 - 1) OFF, ON (0 - 3)
	00 37	000a aaaa	Wave FXM Depth	(0 - 3) 1 - 4 (0 - 16)
	00 38	0000 000a	Wave Tempo Sync	(0 - 16) (0 - 1) OFF, ON (44 - 84)
	00 39	00aa aaaa	Wave Pitch Keyfollow	-200 - +200
	00 3A	000a aaaa	Pitch Env Depth	(52 - 76) -12 - +12
	00 3B	Oaaa aaaa	Pitch Env Velocity Sens	(52 - 76) -12 - +12 (1 - 127) -63 - +63
	00 3C	Oaaa aaaa	Pitch Env Time 1 Velocity Sens	(1 - 127) -63 - +63
	00 3D	Oaaa aaaa	Pitch Env Time 4 Velocity Sens	-63 - +63
	00 3E	000a aaaa	Pitch Env Time Keyfollow	(54 - 74) -100 - +100 (0 - 127)
	00 3F 00 40	Oaaa aaaa Oaaa aaaa	Pitch Env Time 1 Pitch Env Time 2	(0 - 127)
	00 41 00 42	Oaaa aaaa Oaaa aaaa	Pitch Env Time 3 Pitch Env Time 4	(0 - 127) (0 - 127)
	00 43	Oaaa aaaa	Pitch Env Level 0	(1 - 127) -63 - +63
	00 44	Oaaa aaaa Oaaa aaaa	Pitch Env Level 1 Pitch Env Level 2	(1 - 127) -63 - +63 (1 - 127)
	00 45	Oaaa aaaa		-63 - +63
	00 47	Oaaa aaaa	Pitch Env Level 4	(1 - 127) -63 - +63 (1 - 127)
		 		-63 - +63
	00 48		OFF, LPF,	(0 - 6) BPF, HPF, PKG, LPF2,
	00 49 00 4A	0aaa aaaa 00aa aaaa	TVF Cutoff Frequency TVF Cutoff Keyfollow	LPF3 (0 - 127) (44 - 84)
	00 4A	0000 0aaa		-200 - +200
	00 4C	Oaaa aaaa		(0 - 7) FIXED, 1 - 7 (1 - 127)
	00 4D	Oaaa aaaa	TVF Resonance	-63 - +63 (0 - 127) (1 - 127)
	00 4E	Oaaa aaaa	TVF Resonance Velocity Sens	(1 - 127) -63 - +63
	00 4F	Oaaa aaaa	TVF Env Depth	-63 - +63 (1 - 127) -63 - +63
	00 50	0000 0aaa	TVF Env Velocity Curve	(0 - 7) FIXED, 1 - 7 (1 - 127)
	00 51 00 52	Oaaa aaaa Oaaa aaaa	TVF Env Velocity Sens	(1 - 127) -63 - +63 (1 - 127) -63 - +63
	00 52	Oaaa aaaa Oaaa aaaa		(1 - 127) -63 - +63
	00 53	000a aaaa		(1 - 127) -63 - +63 (54 - 74)
	00 74	Oaaa aaaa	TVF Env Time Reylollow TVF Env Time 1	-100 - +100 (0 - 127) (0 - 127)
	00 55	Oaaa aaaa	TVF Env Time 2 TVF Env Time 3	(0 - 127) (0 - 127)
	00 55 00 56 00 57	Oaaa aaaa	mum m m' 4	(0 127)
	00 56 00 57 00 58 00 59		TVF Env Time 4 TVF Env Level 0	(0 - 127)
	00 56 00 57 00 58 00 59 00 5A 00 5B	0aaa aaaa 0aaa aaaa	TVF Env Level 0	(0 - 127) (0 - 127) (0 - 127) (0 - 127) (0 - 127) (0 - 127)
	00 56 00 57 00 58 00 59 00 5A 00 5B 00 5C	0aaa aaaa 0aaa aaaa 0aaa aaaa 0aaa aaaa	TVF Env Level 0 TVF Env Level 1 TVF Env Level 2 TVF Env Level 3 TVF Env Level 4	(0 - 127) (0 - 127) (0 - 127) (0 - 127)
	00 56 00 57 00 58 00 59 00 5A 00 5B 00 5C 00 5D	0aaa aaaa 0aaa aaaa 0aaa aaaa 0aaa aaaa 0aaa aaaa	TVF Env Level 0 TVF Env Level 1 TVF Env Level 2 TVF Env Level 3 TVF Env Level 4	(0 - 127) (0 - 127) (0 - 127) (0 - 127)
	00 56 00 57 00 58 00 59 00 5A 00 5B 00 5C 00 5D	0aaa aaaa 0aaa aaaa 0aaa aaaa 0aaa aaaa 0aaa aaaa 0aaa aaaa 0aaa aaaa	TVF Env Level 0 TVF Env Level 1 TVF Env Level 2 TVF Env Level 3 TVF Env Level 4	(0 - 127) (0 - 127) (0 - 127) (0 - 127)

	I	LOWER, UPPER, LOWER&UPPER, ALL
00 6	1 0000 0aaa	TVA Level Velocity Curve (0 - 7)
00 6	2 Oaaa aaaa	TVA Level Velocity Sens (1 - 127) -63 - +63 TVA Env Time 1 Velocity Sens (1 - 127)
00 6	0aaa aaaa	TVA Env Time 1 Velocity Sens (1 - 127) -63 - +63
00 6	1 Oaaa aaaa	TVA Env Time 4 Velocity Sens (1 - 127) TVA Env Time 4 Velocity Sens (1 - 127) -63 - 63 TVA Env Time Keyfollow (54 - 74)
00 6	000a aaaa	TVA Env Time Keyfollow (54 - 74)
00 6 00 6 00 6	7 Oaaa aaaa 8 Oaaa aaaa	-100 - ±100 TVA Env Time 1 (0 - 127) TVA Env Time 2 (0 - 127) TVA Env Time 3 (0 - 127) TVA Env Time 4 (0 - 127)
00 6 00 6	A Oaaa aaaa B Oaaa aaaa	TVA Env Level 1 (0 - 127) TVA Env Level 2 (0 - 127)
00 61	0000 aaaa	LF01 Waveform (0 - 12)
		SIN, TRI, SAW-UP, SAW-DW, SQR, RND, BEND-UP, BEND-DW, TRP, S&H, CHS, VSIN, STEP
# 00 61	0000 aaaa 0000 bbbb	LFO1 Rate (0 - 149) 0 - 127, MUSICAL-NOTES
00 7	0000 0aaa	T TO 1 OFF
00 7: 00 7:	2 Oaaa aaaa	LFO1 Offset (0 - 4) -100, -50, 0, +50, +100 LFO1 Rate Detune (0 - 127) LFO1 Delay Time (0 - 127)
00 7		LFO1 Delay Time Keyfollow (54 - 74) -100 - +100 LFO1 Fade Mode (0 - 3)
00 7	0aaa aaaa	ON-IN, ON-OUT, OFF-IN, OFF-OUT LFO1 Fade Time (0 - 127)
00 7	0000 000a	LEO1 Vey Trigger (0 - 1)
00 7		OFF, ON LF01 Pitch Depth (1 - 127) -63 - +63
00 7		LF01 TVF Depth (1 - 127) -63 - +63
00 7		LF01 TVA Depth (1 - 127) -63 - +63
00 7		LFO1 TVA Depth (1 - 127) LFO1 Pan Depth (1 - 127) -63 - +63 LFO2 Manufacture (1 - 127)
00 71	3 0000 aaaa	LFO2 Waveform SIN, TRI, SAW-UP, SAW-UP, SQR, RND, BEND-UP, BEND-DW, TRP, SAW CHS, VSIN, STEP
# 00 70	0000 aaaa 0000 bbbb	LFO2 Rate (0 - 149) 0 - 127, MUSICAL-NOTES
00 7	0000 0aaa	
00 71 01 0	Oaaa aaaa	LFO2 Offset
01 0:		-100 - +100 LFO2 Fade Mode (0 - 3)
01 0		ON-IN, ON-OUT, OFF-IN, OFF-OUT LFO2 Fade Time (0 - 127)
01 0		LF02 Key Trigger (0 - 1) OFF, ON
01 0		OFF, ON LFO2 Pitch Depth (1 - 127) -63 - 63 LFO2 TVF Depth (1 - 127)
01 0		LFO2 TVF Depth (1 - 127) LFO2 TVA Depth (1 - 127) LFO3 TVA Depth (1 - 127) -63 - +63
01 0		LFO2 Pan Depth (1 - 127)
		LFO2 Pan Depth (1 - 127) -63 - +63
01 0 01 0		LFO Step Type (0 - 1) LFO Step1 (28 - 100) -36 - +36
01 0	3 Oaaa aaaa	LFO Step2 (28 - 100)
01 00	Oaaa aaaa	-36 - +36 LFO Step3 (28 - 10)
01 0	Oaaa aaaa	-36 - +36 (28 - 100) -36 - +36
01 0	3 Oaaa aaaa	LFO Step5 (28 - 100)
01 0	P Oaaa aaaa	-36 - +36 LFO Step6 (28 - 100)
01 1	Oaaa aaaa	-36 - +36 LFO Step7 (28 - 100) -36 - +36
01 1	l Oaaa aaaa	LFO Step8 (28 - 100)
01 1:	2 Oaaa aaaa	LFO Step9 -36 - +36 (28 - 100)
01 1	0aaa aaaa	-36 - +36 (28 - 100) -36 - +36
01 1	1 Oaaa aaaa	LFO Step11 (28 - 100)
01 1	0aaa aaaa	-36 - +36 LFO Step12 (28 - 100) -36 - +36
01 1	0aaa aaaa	LFO Step13 (28 - 100) -36 - +36
01 1	7 Oaaa aaaa	LFO Step14 (28 - 100)
01 1	Oaaa aaaa	-36 - +36 (28 - 100) -36 - +36
01 1	9 0aaa aaaa	LFO Step16
00 00 01 1	A Total Size	

* Rhythm Common	*
-----------------	---

Offset Address		Description	
00 00	Oaaa aaaa	Rhythm Name 1	(32 - 127)
00 01	Oaaa aaaa	Rhythm Name 2	32 - 127 [ASCII] (32 - 127)
00 02	Oaaa aaaa	Rhythm Name 3	32 - 127 [ASCII] (32 - 127)
00 03	Oaaa aaaa	Rhythm Name 4	32 - 127 [ASCII] (32 - 127)
00 04	Oaaa aaaa	Rhythm Name 5	32 - 127 [ASCII] (32 - 127)
00 05	Oaaa aaaa	Rhythm Name 6	32 - 127 [ASCII] (32 - 127)
00 06	Oaaa aaaa	Rhythm Name 7	32 - 127 [ASCII] (32 - 127)
00 07	Oaaa aaaa	Rhythm Name 8	32 - 127 [ASCII] (32 - 127)
00 08	Oaaa aaaa	Rhythm Name 9	32 - 127 [ASCII] (32 - 127)
00 09	Oaaa aaaa	Rhythm Name 10	32 - 127 [ASCII] (32 - 127)
00 0A	Oaaa aaaa	Rhythm Name 11	32 - 127 [ASCII] (32 - 127)
00 OB	Oaaa aaaa	Rhythm Name 12	32 - 127 [ASCII] (32 - 127)
		, + -	32 - 127 [ASCII]
00 OC	0aaa aaaa	Rhythm Level	(0 - 127)

# 00 0D 00 0E 00 10	0000 000a 0000 aaaa 0000 bbbb 0000 000a	(reserve) (reserve) (reserve)
00 11	0000 aaaa	Rhythm Output Assign (0 - 13) MFX, A,,,,, TONE
00 00 00 12	Total Size	

* Rhythm Common MFX

	Address		Description	
		Oaaa aaaa		(0 - 79) (0 - 127) (0 - 127) (0 - 127)
	00 05	Oaaa aaaa	MFX Control 1 Source OFF,	(0 - 101) CC01 - CC31, CC33 - CC95, BEND, AFT, SYS1 - SYS4
	00 06	Oaaa aaaa	MFX Control 1 Sens	BEND, AFT, SYS1 - SYS4 (1 - 127) -63 - +63
	00 07	Oaaa aaaa	MFX Control 2 Source	(0 - 101)
	00 08	Oaaa aaaa	MFX Control 2 Sens	CC01 - CC31, CC33 - CC95, BEND, AFT, SYS1 - SYS4 (1 - 127)
	00 09	Oaaa aaaa	MFX Control 3 Source	-63 - +63 (0 - 101)
	00 OA	Oaaa aaaa	MFX Control 3 Sens	CC01 - CC31, CC33 - CC95, BEND, AFT, SYS1 - SYS4 (1 - 127) -63 - +63
	00 OB		MFX Control 4 Source	-63 - +63 (0 - 101)
	00 OC		OFF, MFX Control 4 Sens	CC01 - CC31, CC33 - CC95, BEND, AFT, SYS1 - SYS4 (1 - 127) -63 - +63
	00 OD		MFX Control Assign 1 MFX Control Assign 2	OFF, 1 - 16
	00 OF		MFX Control Assign 3	(0 - 16) OFF, 1 - 16 (0 - 16) OFF, 1 - 16 (0 - 16) OFF, 1 - 16 OFF, 1 - 16
	00 10		MFX Control Assign 4	OFF, 1 - 16 (0 - 16)
#	00 11	0000 aaaa 0000 bbbb 0000 cccc	MFX Parameter 1	
#	00 15	0000 aaaa 0000 bbbb	MFX Parameter 2	(12768 - 52768) -20000 - +20000 (12768 - 52768)
#	00 19	0000 aaaa 0000 bbbb 0000 cccc		-20000 - +20000
#	00 1D	0000 aaaa 0000 bbbb 0000 cccc	MFX Parameter 3	(12768 - 52768) -20000 - +20000
#	00 21	0000 dddd 0000 aaaa 0000 bbbb	MFX Parameter 4	(12768 - 52768) -20000 - +20000
#	00 25	0000 cccc 0000 dddd 0000 aaaa 0000 bbbb	MFX Parameter 5	(12768 - 52768) -20000 - +20000
#	00 29	0000 cccc 0000 dddd 0000 aaaa 0000 bbbb	MFX Parameter 6	(12768 - 52768) -20000 - +20000
#	00 2D	0000 cccc	MFX Parameter 7	(12768 - 52768) -20000 - +20000
		0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 8	(12768 - 52768) -20000 - +20000
#	00 31	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 9	(12768 - 52768) -20000 - +20000
#	00 35	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 10	(12768 - 52768)
#	00 39	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 11	-20000 - +20000 (12768 - 52768)
#	00 3D	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 12	-20000 - +20000 (12768 - 52768) -20000 - +20000
#	00 41	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 13	-20000 - +20000 (12768 - 52768) -20000 - +20000
#	00 45	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 14	(12768 - 52768)
#	00 49	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 15	-20000 - +20000 (12768 - 52768) -20000 - +20000
#	00 4D	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 16	(12768 - 52768)
#	00 51	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 17	-20000 - +20000 (12768 - 52768)
#	00 55	0000 aaaa		-20000 - +20000

		0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 18	(12768 - 52768) -20000 - +20000
#	00 59	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 19	(12768 - 52768)
#	00 5D	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 20	-20000 - +20000 (12768 - 52768)
#	00 61	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 21	-20000 - +20000 (12768 - 52768)
#	00 65	0000 aaaa 0000 bbbb 0000 cccc		-20000 - +20000
#	00 69	0000 dddd 0000 aaaa 0000 bbbb 0000 cccc	MFX Parameter 22	(12768 - 52768) -20000 - +20000
#	00 6D	0000 dddd 0000 aaaa 0000 bbbb	MFX Parameter 23	(12768 - 52768) -20000 - +20000
#	00 71	0000 aaaa	MFX Parameter 24	(12768 - 52768) -20000 - +20000
#	00 75	0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 25	(12768 - 52768) -20000 - +20000
		0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 26	(12768 - 52768) -20000 - +20000
#	00 79	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 27	(12768 - 52768) -20000 - +20000
#	00 7D	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 28	(12768 - 52768)
#	01 01	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	MFX Parameter 29	-20000 - +20000 (12768 - 52768)
#	01 05	0000 aaaa 0000 bbbb 0000 cccc		-20000 - +20000
#	01 09	0000 dddd 0000 aaaa 0000 bbbb 0000 cccc	MFX Parameter 30	(12768 - 52768) -20000 - +20000
#	01 0D	0000 dddd 0000 aaaa 0000 bbbb	MFX Parameter 31	(12768 - 52768) -20000 - +20000
			MFX Parameter 32	(12768 - 52768) -20000 - +20000

* Rhythm Common Chorus

Offset Address		Description	
00 00 00 01 00 02	0000 aaaa 0aaa aaaa 0000 00aa	Chorus Type Chorus Level Chorus Output Assign <*>	(0 - 3) (0 - 127)
00 03	0000 00aa	Chorus Output Select	MAIN, REV, MAIN+REV
	0000 aaaa 0000 bbbb	Chorus Parameter 1	(12768 - 52768)
# 00 08	0000 bbbb 0000 cccc	Chorus Parameter 2	-20000 - +20000 (12768 - 52768)
# 00 0C	0000 bbbb 0000 cccc	Chorus Parameter 3	-20000 - +20000 (12768 - 52768)
# 00 10	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 4	(12768 - 52768) -20000 - +20000 (12768 - 52768)
# 00 14	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 5	-20000 - +20000 (12768 - 52768)
# 00 18	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 6	-20000 - +20000 (12768 - 52768)
# 00 1C	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 7	-20000 - +20000 (12768 - 52768)
# 00 20	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 8	-20000 - +20000 (12768 - 52768)
# 00 24	0000 aaaa 0000 bbbb 0000 cccc	Chorus Parameter 9	-20000 - +20000 (12768 - 52768)
# 00 28	0000 aaaa 0000 bbbb 0000 cccc		-20000 - +20000
	0000 dddd	Chorus Parameter 10	(12768 - 52768) -20000 - +20000

#	00 2C	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 11	(12768 - 52768)
#	00 30	0000 bbbb 0000 cccc	Chorus Parameter 12	-20000 - +20000 (12768 - 52768)
#	00 34	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Chorus Parameter 13	-20000 - +20000 (12768 - 52768)
#	00 38	0000 bbbb 0000 cccc	Chorus Parameter 14	-20000 - +20000 (12768 - 52768)
#	00 3C	0000 bbbb 0000 cccc	Chorus Parameter 15	-20000 - +20000 (12768 - 52768)
#	00 40	0000 bbbb 0000 cccc	Chorus Parameter 16	-20000 - +20000 (12768 - 52768)
#	00 44	0000 bbbb 0000 cccc	Chorus Parameter 17	-20000 - +20000 (12768 - 52768)
#	00 48	0000 aaaa 0000 bbbb 0000 cccc	Chorus Parameter 18	-20000 - +20000 (12768 - 52768)
#	00 4C	0000 aaaa 0000 bbbb 0000 cccc	Chorus Parameter 19	-20000 - +20000
#	00 50	0000 aaaa 0000 bbbb 0000 cccc		(12768 - 52768) -20000 - +20000
		0000 dddd	Chorus Parameter 20	(12768 - 52768) -20000 - +20000
0.0	00 00 54	Total Size		

* Rhythm Common Reverb

Off	set Address		Description	
	00 00 00 01 00 02		Reverb Type Reverb Level Reverb Output Assign <*>	(0 - 5) (0 - 127) A,,
#	00 03	0000 aaaa 0000 bbbb 0000 cccc	Reverb Parameter 1	(12768 - 52768) -20000 - +20000
#	00 07	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 2	(12768 - 52768) -20000 - +20000
#	00 OB	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 3	(12768 - 52768) -20000 - +20000
#	00 OF	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 4	(12768 - 52768) -20000 - +20000
#	00 13	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 5	-20000 - +20000 (12768 - 52768) -20000 - +20000
#	00 17	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 6	(12768 - 52768)
#	00 1B	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 7	-20000 - +20000 (12768 - 52768) -20000 - +20000
#	00 1F	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 8	-20000 - +20000 (12768 - 52768) -20000 - +20000
#	00 23	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 9	-20000 - +20000 (12768 - 52768)
#	00 27	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 10	-20000 - +20000 (12768 - 52768) -20000 - +20000
#	00 2B	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 11	
#	00 2F	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 12	(12768 - 52768) -20000 - +20000 (12768 - 52768)
#	00 33	0000 dddd 0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 13	-20000 - +20000
#	00 37	0000 dddd 0000 aaaa 0000 bbbb 0000 cccc 0000 dddd		(12768 - 52768) -20000 - +20000
#	00 3B	0000 aaaa 0000 bbbb 0000 cccc	Reverb Parameter 14	(12768 - 52768) -20000 - +20000
#	00 3F	0000 dddd 0000 aaaa	Reverb Parameter 15	(12768 - 52768) -20000 - +20000

		Total Size		
#	00 4F	0000 aaaa 0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 20	(12768 - 52768) -20000 - +20000
		0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 19	(12768 - 52768) -20000 - +20000
	00 4B	0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 18	(12768 - 52768) -20000 - +20000
	00 47	0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 17	(12768 - 52768) -20000 - +20000
ŧ	00 43	0000 bbbb 0000 cccc 0000 dddd	Reverb Parameter 16	(12768 - 52768) -20000 - +20000

* Rhythm Tone

* Rhythm Tone	e	
Offset	 	
Address	 +	Description
00 00	Oaaa aaaa	Tone Name 1 (32 - 127) 32 - 127 [ASCII]
00 01	Oaaa aaaa	Tone Name 2 (32 - 127)
00 02	Oaaa aaaa	32 - 127 [ASCII] Tone Name 3 (32 - 127)
00 03	Oaaa aaaa	32 - 127 [ASCII] Tone Name 4 (32 - 127)
		32 - 127 [ASCII]
00 04	Oaaa aaaa	Tone Name 5 (32 - 127) 32 - 127 [ASCII]
00 05	Oaaa aaaa	Tone Name 6 (32 - 127) 32 - 127 [ASCII]
00 06	Oaaa aaaa	Tone Name 7 (32 - 127) 32 - 127 [ASCII]
00 07	Oaaa aaaa	Tone Name 8 (32 - 127)
00 08	Oaaa aaaa	32 - 127 [ASCII] Tone Name 9 (32 - 127)
00 09	Oaaa aaaa	32 - 127 [ASCII] Tone Name 10 (32 - 127)
00 0A	Oaaa aaaa	32 - 127 [ASCII] Tone Name 11 (32 - 127)
		32 - 127 [ASCII]
00 OB	Oaaa aaaa	Tone Name 12 (32 - 127) 32 - 127 [ASCII]
00 OC	0000 000a	Assign Type (0 - 1)
		MULTI, SINGLE
00 02	ood ddd	OFF, 1 - 31
00 OE	Oaaa aaaa	Tone Level
00 OF	Oaaa aaaa	
00 10	Oaaa aaaa	Tone Fine Tune (14 - 114)
00 11	000a aaaa	Tone Random Pitch Depth (0 - 30)
		Tone Random Pitch Depth (0 - 30) 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 20, 30, 40, 50, 60, 70, 80, 90, 100, 200, 300, 400, 500, 600, 700, 800, 900, 1000, 1100, 1200, 1200
		90, 100, 200, 300, 400, 500, 600, 700, 800, 900, 1000, 1100,
00 12		
i	Oaaa aaaa	Tone Pan (0 - 127) L64 - 63R
00 13 00 14	00aa aaaa 0aaa aaaa	Tone Random Pan Depth (0 - 63) Tone Alternate Pan Depth (1 - 127)
00 15		Tone Alternate Pan Depth (1 - 127) L63 - 63R Tone Env Mode (0 - 1)
00 13	0000 0000	NO-SUS, SUSTAIN
00 16	Oaaa aaaa	Tone Dry Send Level (0 - 127) Tone Chorus Send Level (0 - 127)
00 18	Oaaa aaaa Oaaa aaaa Oaaa aaaa	Tone Reverb Send Level (0 - 127)
00 19 00 1A	Oaaa aaaa Oaaa aaaa	Tone Chorus Send Level (non MFX) (0 - 127) Tone Reverb Send Level (non MFX) (0 - 127)
00 1B	0000 aaaa	Tone Output Assign (0 - 12)
		Tone Reverb Send Level (non MFX) (0 - 127) Tone Output Assign MFX, A,,,,,,,,
00 1C	00aa aaaa	Tone Pitch Bend Range
00 1D	0000 000a	Tone Receive Expression (0 - 1) OFF, ON
00 1E	0000 000a	OFF, ON Tone Receive Hold-1 (0 - 1) OFF, ON
00 1F	0000 000a	OFF, ON Tone Receive Pan Mode (0 - 1) CONTINUOUS, KEY-ON
00 20	0000 00aa	WMT Velocity Control (0 - 2) OFF, ON, RANDOM
00 21	0000 000a	WMT1 Wave Switch (0 - 1)
00 22	0000 00aa	WMT1 Wave Switch (0 - 1) OFF, ON (reserve) <*>
		(IEBELVE) 1 P
# 00 23	0000 aaaa 0000 bbbb	
	0000 cccc 0000 dddd	(reserve) <*>
# 00 27	0000 aaaa	
" 00 27	0000 bbbb	
i	0000 cccc 0000 dddd	WMT1 Wave Number L (Mono) (0 - 16384) OFF, 1 - 16384
# 00 2B	0000 aaaa	OFF, 1 - 16384
	0000 bbbb 0000 cccc	
	0000 dddd	WMT1 Wave Number R (0 - 16384) OFF, 1 - 16384
00 2F	0000 00aa	WMT1 Wave Gain (0 - 3)
00 30	0000 000a	-6, 0, +6, +12 [dB] WMT1 Wave FXM Switch (0 - 1)
00 31	0000 00aa	OFF, ON (0 - 3) 1 - 4
00 32	000a aaaa	WMT1 Wave FXM Depth (0 - 16)
00 32	000a aaaa 0000 000a	WMT1 Warre Tempo Sync (0 = 1)
00 34	Oaaa aaaa	OFF, ON WMT1 Wave Coarse Tune (16 - 112)
00 35	Oaaa aaaa	WMT1 Wave Codise Tune (10 - 112) -48 - 48 WMT1 Wave Fine Tune (14 - 114) -50 - +50
		-50 - +50
00 36	Oaaa aaaa	WMT1 Wave Pan (0 - 127) L64 - 63R
	0000 000a	WMT1 Wave Random Pan Switch (0 - 1)
00 37		OFF, ON
00 37	0000 00aa	OFF, ON (0 - 2) WMT1 Wave Alternate Pan Switch (0 - 2) OFF, ON, REVERSE

	00 39 00 3A	Oaaa aaaa Oaaa aaaa	WMT1 Wave Level (0 - 127) WMT1 Velocity Range Lower (1 - 127)
	00 3B	Oaaa aaaa	1 - UPPER WMT1 Velocity Range Upper (1 - 127) LOWER - 127
	00 3C 00 3D 00 3E	Oaaa aaaa Oaaa aaaa	WMT1 Velocity Fade Width Lower (0 - 127) WMT1 Velocity Fade Width Upper (0 - 127)
	00 3E	0000 000a 0000 00aa	WMT2 Wave Switch (0 - 1) OFF, ON (reserve) <*>
#	00 40	0000 aaaa	
		0000 bbbb 0000 cccc 0000 dddd	(reserve) <*>
#	00 44	0000 aaaa	(reserve)
		0000 bbbb 0000 cccc 0000 dddd	WMT2 Wave Number L (Mono) (0 - 16384)
#	00 48	0000 aaaa	OFF, 1 - 16384
		0000 bbbb 0000 cccc	
	00 4C	0000 dddd 0000 00aa	WMT2 Wave Number R (0 - 16384) OFF, 1 - 16384 WMT2 Wave Gain (0 - 3)
	00 4D	0000 000a	-6, 0, +6, +12 [dB] WMT2 Wave FXM Switch (0 - 1)
	00 4E	0000 00aa	OFF, ON WMT2 Wave FXM Color (0 - 3) 1 - 4
	00 4F 00 50	000a aaaa 0000 000a	
	00 51	Oaaa aaaa	WHTZ Wave Fxm Deptn
	00 52	Oaaa aaaa	-48 - +48 WMT2 Wave Fine Tune (14 - 114)
	00 53	Oaaa aaaa	-50 - +50 WMT2 Wave Pan
	00 54	0000 000a	WMT2 Wave Random Pan Switch (0 - 1) OFF, ON
	00 55	0000 00aa	OFF, ON, REVERSE
	00 56 00 57	Oaaa aaaa Oaaa aaaa	WMT2 Wave Level (0 - 127) WMT2 Velocity Range Lower (1 - 127) 1 - UPPER
	00 58	Oaaa aaaa	WMT2 Velocity Range Upper (1 - 127)
	00 59 00 5A 00 5B	0aaa aaaa 0aaa aaaa 0000 000a	WMT2 Velocity Fade Width Lower (0 - 127) WMT2 Velocity Fade Width Upper (0 - 127) WMT3 Wave Switch (0 - 1)
	00 5E	0000 000a	(0 - 1) (reserve) <*>
#	00 5D	0000 aaaa	
		0000 bbbb 0000 cccc 0000 dddd	(reserve) <*>
#	00 61	0000 dddd	(reserve) <->
		0000 bbbb 0000 cccc	
#	00 65	0000 dddd 0000 aaaa	WMT3 Wave Number L (Mono) (0 - 16384) OFF, 1 - 16384
"	00 03	0000 bbbb 0000 cccc	
		0000 dddd	WMT3 Wave Number R (0 - 16384) OFF, 1 - 16384
	00 69 00 6A	0000 00aa 0000 000a	WMT3 Wave Gain
	00 6B	0000 00aa	OFF, ON (0 - 3) WMT3 Wave FXM Color (0 - 3) 1 - 4
	00 6C 00 6D	000a aaaa 0000 000a	1 - 4 WMT3 Wave FXM Depth (0 - 16) WMT3 Wave Tempo Sync (0 - 1)
	00 6E	Oaaa aaaa	OFF. ON
	00 6F	Oaaa aaaa	WMT3 Wave Coarse Tune (16 - 112) -48 - +48 WMT3 Wave Fine Tune (14 - 114)
	00 70	Oaaa aaaa	WMT3 Wave Pan (0 - 127) L64 - 63R
	00 71	0000 000a	WMT3 Wave Random Pan Switch (0 - 1) OFF, ON
	00 72 00 73	0000 00aa 0aaa aaaa	OFF, ON, REVERSE
	00 74	Oaaa aaaa	WMT3 Velocity Range Lower (1 - 127)
	00 75	Oaaa aaaa	WMT3 Velocity Range Upper (1 - 127)
	00 76 00 77 00 78	Oaaa aaaa Oaaa aaaa OOOO OOOa	WMT3 Velocity Fade Width Lower
	00 79	0000 00aa	(reserve) <*>
#	00 7A	0000 aaaa 0000 bbbb	
		0000 cccc 0000 dddd	(reserve) <*>
#	00 7E	0000 aaaa	
		0000 bbbb 0000 cccc 0000 dddd	WMT4 Wave Number L (Mono) (0 - 16384)
#	01 02	0000 aaaa	WMT4 Wave Number L (Mono) (0 - 16384) OFF, 1 - 16384
		0000 bbbb 0000 cccc 0000 dddd	WMT4 Wave Number R (0 - 16384)
	01 06	0000 00aa	OFF, 1 - 16384
	01 07	0000 000a	-6, 0, +6, +12 [dB]
	01 08	0000 00aa	WMT4 Wave FXM Color (0 - 3) WMT4 Wave FXM Color 1, (0 - 3)
	01 09 01 0A	000a aaaa 0000 000a	WMT4 Wave FXM Depth (0 - 16)
	01 OB	Oaaa aaaa	WHT4 Wave Coarse Tune (16 - 112) -48 - 448 WHT4 Wave Fine Tune (14 - 114)
	01 OC	Oaaa aaaa	WMT4 Wave Fine Tune (14 - 114) -50 - +50
	01 0D 01 0E	0aaa aaaa 0000 000a	WMT4 Wave Pan
	01 OE	0000 000a	WMT4 Wave Random Pan Switch (0 - 1) OFF, ON WMT4 Wave Alternate Pan Switch (0 - 2)
	01 10	Oaaa aaaa	WMT4 Wave Level OFF, ON, REVERSE (0 - 127)
	01 11 01 12	Oaaa aaaa Oaaa aaaa	1 - UPPER
	01 13		WMT4 Velocity Range Upper (1 - 127) LOWER - 127 WMT4 Velocity Fade Width Lower (0 - 127)

01 14 0	Daaa aaaa	WMT4 Velocity Fade Width Upper	(0 - 127)
		Pitch Env Depth	(52 - 76) -12 - +12
01 16	Daaa aaaa		
01 17	Daaa aaaa	Pitch Env Time 1 Velocity Sens	-63 - +63 (1 - 127) -63 - +63
01 18	Daaa aaaa	Pitch Env Time 4 Velocity Sens	(1 - 127)
01 19 0	Daaa aaaa	Pitch Env Time 1	-63 - +63 (0 - 127)
01 1A I (Daaa aaaa İ	Pitch Env Time 2	(0 - 127)
01 1B 0 01 1C 0	Daaa aaaa	Pitch Env Time 3 Pitch Env Time 4	(0 - 127)
01 1D 0	Daaa aaaa	Pitch Env Level 0	(0 - 127) (1 - 127)
1		Pitch Env Level 1	(1 - 127) -63 - +63 (1 - 127)
		Pitch Env Level 2	-63 - +63 (1 - 127)
		Pitch Env Level 3	-63 - +63 (1 - 127)
1			-63 - +63 (1 - 127)
i i	i	Pitch Env Level 4	-63 - +63
		TVF Filter Type	(0 - 6)
01 22 0	JUJU Udda	TVF Filter Type OFF, LPF, BPF,	HPF, PKG, LPF2,
01 22 /			
01 23 0 01 24 0	Daad ddda DOOO Oaaa	TVF Cutoff Frequency TVF Cutoff Velocity Curve	(0 - 127) (0 - 7)
"" " '		TVF Cutoff Velocity Curve TVF Cutoff Velocity Sens	FIXED, 1 - 7
01 25 0	Daaa aaaa	TVF Cutoff Velocity Sens	(1 - 127) -63 - +63
01 26	Daaa aaaa	TVF Resonance	(0 - 127)
01 27 (Daaa aaaa	TVF Resonance Velocity Sens	(1 - 127) -63 - +63
01 28 (Daaa aaaa	TVF Env Depth	(1 - 127) -63 - +63
01 29 0	0000 0aaa	TVF Env Velocity Curve Type	(0 - 7) FIXED, 1 - 7
01 2A (Daaa aaaa	TVF Env Velocity Sens	(1 - 127)
01 2B (Daaa aaaa	TVF Env Time 1 Velocity Sens	(1 - 127)
01 2C	Daaa aaaa	TVF Env Depth TVF Env Velocity Curve Type TVF Env Velocity Sens TVF Env Time 1 Velocity Sens TVF Env Time 4 Velocity Sens TVF Env Time 4	(1 - 127)
01 2D (Daaa aaaa	TVF Env Time 1	-63 - +63 (0 - 127) (0 - 127) (0 - 127)
01 2E (01 2F (Daaa aaaa	TVF Env Time 2 TVF Env Time 3 TVF Env Time 4	(0 - 127)
01 2F (Daaa aaaa	TVF Env Time 3	(0 - 127)
01 30 (Daaa aaaa	TVF Env Time 4	(0 - 127) (0 - 127)
01 31 0 01 32 0	Daaa aaaa	TVF Env Level 0 TVF Env Level 1 TVF Env Level 2	(0 - 127)
01 33	Daaa aaaa	TVF Env Level 2	(0 - 127)
01 34 0	Daaa aaaa	TVF Env Level 3 TVF Env Level 4	(0 - 127)
01 35 (Daaa aaaa	TVF Env Level 4	(0 - 127)
01 36 (0000 0aaa	TVA Level Velocity Curve TVA Level Velocity Sens	(0 - 7) FIXED, 1 - 7
			(1 - 127) -63 - +63
		TVA Env Time 1 Velocity Sens	-63 - +63
01 39 (Daaa aaaa	TVA Env Time 4 Velocity Sens	(1 - 127) -63 - +63 (0 - 127)
01 3A (Daaa aaaa	TVA Env Time 1	(0 - 127)
01 3B	Daaa aaaa	TVA Env Time 2 TVA Env Time 3	(0 - 127)
01 3C (Daaa aaaa	TVA Env Time 3 TVA Env Time 4	(0 - 127)
			(0 - 127) (0 - 127)
01 35 0	Daaa aaaa	TVA Env Level 1	(0 - 127)
01 40	Daaa aaaa	TVA Env Level 2 TVA Env Level 3	(0 - 127)
01 41 (+ 0000 000a	One Shot Mode	(0 - 1)
			(0 - 1) OFF, ON (0 - 127)
i i		Relative Level	-64 - +63
00 00 01 43			
+			

4. Supplementary Material

■Decimal and Hexadecimal Table

(An "H" is appended to the end of numbers in hexadecimal notation.)

In MIDI documentation, data values and addresses/sizes of Exclusive messages, etc. are expressed as hexadecimal values for each 7 hits

The following table shows how these correspond to decimal numbers.

D	H	D	Н	D	Н	D	Н
0	00H	32	20H	64	40H	96	60H
1	01H	33	21H	65	41H	97	61H
2	02H	34	22H	66	42H	98	62H
3	03H	35	23H	67	43H	99	63H
4	04H	36	24H	68	44H	100	64H
5	05H	37	25H	69	45H	101	65H
6 7	06H	38	26H	70	46H	102	66H
	07H	39	27H	71 72	47H	103	67H
8 9	08H 09H	40 41	28H 29H	73	48H 49H	104 105	68H 69H
10	0AH	41	29H 2AH	74	49H 4AH	105	6AH
11	0BH	43	2BH	75	4BH	107	6BH
12	0CH	44	2CH	76	4CH	108	6CH
13	0 DH	45	2DH	77	4DH	109	6DH
14	0EH	46	2EH	78	4EH	110	6EH
15	0FH	47	2FH	79	4FH	111	6FH
16	10H	48	30H	80	50H	112	70H
17	11H	49	31H	81	51H	113	71H
18	12H	50	32H	82	52H	114	72H
19	13H	51	33H	83	53H	115	73H
20	14H	52	34H	84	54H	116	74H
21	15H	53	35H	85	55H	117	75н
22	16H	54	36H	86	56H	118	76H
23	17H	55	37H	87	57H	119	77H
24	18H	56	38H	88	58H	120	78H
25	19H	57	39H	89	59H	121	79H
26	1AH	58	3AH	90	5AH	122	7AH
27	1BH	59	3BH	91	5BH	123	7BH
28	1CH	60	3CH	92	5CH	124	7CH
29	1DH	61	3 DH	93	5DH	125	7DH
30	1EH	62	3EH	94	5EH	126	7EH
31	1FH	63	3FH	95	5FH	127	7FH

D: decimal

H: hexadecimal

- Decimal values such as MIDI channel, bank select, and program change are listed as one greater than the values given in the above table.
- A 7-bit byte can express data in the range of 128 steps. For data where greater precision is required, we must use two or more bytes. For example, two hexadecimal numbers as bbH expressing two 7-bit bytes would indicate a value of as x 128+bb.
- In the case of values which have a +/- sign, 00H = -64, 40H = +/-0, and 7FH = +63, so that the decimal expression would be 64 less than the value given in the above chart. In the case of two types, 00 00H = -8192, 40 00H = +/-0, and 7F 7FH = +8191. For example, if aa bbH were expressed as decimal, this would be aa bbH 40 00H = aa x 128+bb 64 x 128.
- * Data marked "Use nibbled data" is expressed in hexadecimal in 4-bit units. A value expressed as a 2-byte nibble 0a 0bH has the value of a x 16+b.

<Example1> What is the decimal expression of 5AH?

From the preceding table, 5AH = 90

<Example2> What is the decimal expression of the value 12 34H given as hexadecimal for each 7 bits?

From the preceding table, since 12H = 18 and 34H = 52 $18 \times 128 + 52 = 2356$

<Example3> What is the decimal expression of the nibbled value 0A 03 09 0D?

From the preceding table, since 0AH = 10, 03H = 3, 09H = 9, 0DH = 13 $((10\times16+3)\times16+9)\times16+13=41885$

<Example4> What is the nibbled expression of the decimal value 1258?

16)	1258		
16)	78		10
16)	4		14
		0		4

Since from the preceding table, 0 = 00H, 4 = 04H, 14 = 0EH, 10 = 0AH, the result is: $00.04 \times 0E \times 0AH$.

■Examples of Actual MIDI Messages

<Example1> 92 3E 5F

9n is the Note-on status, and n is the MIDI channel number. Since 2H = 2, 3EH = 62, and 5FH = 95, this is a Note-on message with MIDI CH = 3, note number 62 (note name is D4), and velocity 95.

<Example2> CE 49

CnH is the Program Change status, and n is the MIDI channel number. Since EH = 14 and 49H = 73, this is a Program Change message with MIDI CH = 15, program number 74.

<Example3> EA 00 28

EnH is the Pitch Bend Change status, and n is the MIDI channel number. The 2nd byte (00H=0) is the LSB and the 3rd byte (28H=40) is the MSB, but Pitch Bend Value is a signed number in which $40\ 00H\ (=64\times12+80=8192)$ is 0, so this Pitch Bend Value is

28 00H - 40 00H = 40 x 12+80 - (64 x 12+80) = 5120 - 8192 = -3072

If the Pitch Bend Sensitivity is set to 2 semitones, -8192 (00 00H) will cause the pitch to change - 200 cents, so in this case -200 x (-3072) \div (-8192) = -75 cents of Pitch Bend is being applied to MIDI change | 11

<Example4> B3 64 00 65 00 06 0C 26 00 64 7F 65 7F

BnH is the Control Change status, and n is the MIDI channel number. For Control Changes, the 2nd byte is the control number, and the 3rd byte is the value. In a case in which two or more messages consecutive messages have the same status, MIDI has a provision called "running status" which allows the status byte of the second and following messages to be omitted. Thus, the above messages have the following meaning.

B3	64 00	MIDI ch.4, lower byte of RPN parameter number:	00H
(B3)	65 00	(MIDI ch.4) upper byte of RPN parameter number:	00H
(B3)	06 0C	(MIDI ch.4) upper byte of parameter value:	0CH
(B3)	26 00	(MIDI ch.4) lower byte of parameter value:	00H
(B3)	64 7F	(MIDI ch.4) lower byte of RPN parameter number:	7FH
(B3)	65 7F	(MIDI ch.4) upper byte of RPN parameter number:	7FH

In other words, the above messages specify a value of 0C 00H for RPN parameter number 00 00H on MIDI channel 4, and then set the RPN parameter number to 7F 7FH.

RPN parameter number 00 00H is Pitch Bend Sensitivity, and the MSB of the value indicates semitone units, so a value of 0CH = 12 sets the maximum pitch bend range to \pm 12 semitones (1 octave). (On GS sound generators the LSB of Pitch Bend Sensitivity is ignored, but the LSB should be transmitted anyway (with a value of 0) so that operation will be correct on any device.)

Once the parameter number has been specified for RPN or NRPN, all Data Entry messages transmitted on that same channel will be valid, so after the desired value has been transmitted, it is a good idea to set the parameter number to 7F 7FH to prevent accidents. This is the reason for the (B3) 64 7F (B3) 65 7F at the end.

It is not desirable for performance data (such as Standard MIDI File data) to contain many events with running status as given in <Example 4>. This is because if playback is halted during the song and then rewound or fast-forwarded, the sequencer may not be able to transmit the correct status, and the sound generator will then misinterpret the data. Take care to give each event its own status.

It is also necessary that the RPN or NRPN parameter number setting and the value setting be done in the proper order. On some sequencers, events occurring in the same (or consecutive) clock may be transmitted in an order different than the order in which they were received. For this reason it is a good idea to slightly skew the time of each event (about 1 tick for TPQN = 96, and about 5 ticks for TPQN = 480).

* TPQN: Ticks Per Quarter Note

■Example of an Exclusive Message and Calculating a Checksum

Roland Exclusive messages (RQ1, DT1) are transmitted with a checksum at the end (before F7) to make sure that the message was correctly received. The value of the checksum is determined by the address and data (or size) of the transmitted Exclusive message.

●How to calculate the checksum

(hexadecimal numbers are indicated by "H")

The checksum is a value derived by adding the address, size, and checksum itself and inverting the lower 7 bits.

Here's an example of how the checksum is calculated. We will assume that in the Exclusive message we are transmitting, the address is aabbccddH and the data or size is eeffH.

aa + bb + cc + dd + ee + ff = sum $sum \div 128 = quotient ... remainder$ 128 - remainder = checksum

<Example> Setting CHORUS TYPE of PERFORMANCE COMMON to DELAY (DT1)

According to the "Parameter Address Map" (p. 10), the start address of Temporary Performance is 10 00 00 00H, the offset address of CHORUS at PERFORMANCE COMMON is 04 00H, and the address of CHORUS TYPE is 00 00H. Therefore the address of CHORUS TYPE of PERFORMANCE COMMON is:

DELAY has the value of 02H.

So the system exclusive message should be sent is;

F0	41	10	00 00 3A	12	10 00 04 00	02	??	F7
(1)	(2)	(3)	(4)	(5)	address	data	checksum	(6)
<i>(</i> -) =				(a) ID ((a) B	(- =\
(1) E	xclusive	Status	5	(2) ID (F	Roland)		(3) Device ID	(17)
(4) N	lodel ID	(JUNC)-Di)	(5) Con	nmand ID (DT1)	(6) End of Exc	lusive

Then calculate the checksum.

10H + 00H + 04H + 00H + 02H = 16 + 0 + 4 + 0 + 2 = 22 (sum) 22 (sum) \div 128 = 0 (quotient) ... 22 (remainder) checksum = 128 - 22 (remainder) = 106 = 6AH

This means that F0 41 10 00 00 3A 12 10 00 04 00 02 6A F7 is the message should be sent.

■The Scale Tune Feature (address: 40 1x 40)

The scale tune feature allows you to finely adjust the individual pitch of the notes from C through B. Though the settings are made while working with one octave, the fine adjustments will affect all octaves. By making the appropriate Scale Tune settings, you can obtain a complete variety of tuning methods other than equal temperament. As examples, three possible types of scale setting are explained below.

* The scale tune value received by the part 1 is used in Patch mode.

OEqual Temperament

This method of tuning divides the octave into 12 equal parts. It is currently the most widely used form of tuning, especially in occidental music. On the JUNO-Di, the default settings for the Scale Tune feature produce equal temperament.

OJust Temperament (Tonic of C)

The principal triads resound much more beautifully than with equal temperament, but this benefit can only be obtained in one key. If transposed, the chords tend to become ambiguous. The example given involves settings for a key in which C is the keynote.

OArabian Scale

By altering the setting for Scale Tune, you can obtain a variety of other tunings suited for ethnic music. For example, the settings introduced below will set the unit to use the Arabian Scale.

Example Settings

Note name	Equal Temperament	Just Temperament (Key-tone C)	Arabian Scale
C	0	0	-6
C#	0	-8	+45
D	0	+4	-2
Eb	0	+16	-12
E	0	-14	-51
F	0	-2	-8
F#	0	-10	+43
G	0	+2	-4
G#	0	+14	+47
Α	0	-16	0
Bb	0	+14	-10
В	0	-12	-49

The values in the table are given in cents. Convert these values to hexadecimal, and transmit them as Exclusive data.

For example, to set the tune (C-B) of the Part 1 Arabian Scale, send the following data:

F0 41 10 42 12 40 11 40 3A 6D 3E 34 0D 38 6B 3C 6F 40 36 0F 76 F7

■ASCII Code Table

Patch Name and Performance Name, etc., of MIDI data are described the ASCII code in the table below.

+	+ н	Char	+	Н Н	Char	+	H	Char
32	+ 20н	SP	1 64	 40н	@	1 96	+ 60н	· · · · · ·
33	21H	1	65	41H	Ā	97	61H	al
34	22H	"	66	42H	В	98	62H	b
35	23Н	#	67	43H	l c l	99	63H	c
36	24H	\$	68	44H	D	100	64H	d
37	25H	8	69	45H	E	101	65H	e
38	26H	&	70	46H	F	102	66H	e f
39	27H	`	71	47H	G	103	67H	g
40	28H	(72	48H	Н	104	68H	h
41	29H)	73	49H	I	105	69H	i
42	2AH	*	74	4AH	J	106	6AH	i j
43	2BH	+	75	4BH	K	107	6BH	k
44	2CH	,	76	4CH	L	108	6CH	1
45	2DH	-	77	4DH	M	109	6DH	m
46	2EH		78	4EH	N	110	6EH	n
47	2FH	/ /	79	4FH	0	111	6FH	0
48	30H	0	80	50H	P	112	70H	p
49	31H	1	81	51H	Q	113	71H	q
50	32H	2	82	52H	R	114	72H	r
51	33H	3	83	53H	S	115	73H	s
52	34H	4	84	54H	T	116	74H	t
53	35H	5	85	55H	U	117	75H	u
54	36H	6	86	56H	V	118	76H	∨
55	37H	7	87	57H	W	119	77H	w
56	38H	8	88	58H	X	120	78H	x
57	39H	9	89	59H	Y	121	79H	У
58	3AH	:	90	5AH	Z	122	7AH	z
59	3BH	;	91	5BH]]	123	7BH	{
60	3CH	<	92	5CH	\ \	124	7CH	
61	3 DH	=	93	5DH]	125	7DH	}
62	3EH	>	94	5EH	1 ^		+	++
63	3FH	?	95	5FH	_			

D: decimal

H: hexadecimal

* "SP" is space.