

Chapter 2

Instructions: Language of the Computer



9 Communicating with People

Byte/Halfword Operations

- MIPS byte/halfword load/store are common for string processing
- 1b \$t0, 0(\$sp) //load with sign extension
 - Load rs+offset address into rt
 - Sign extend to 32 bits in rt

• Sb \$t0, 0(\$sp)

– Store just rightmost byte \$t0=

00000000000000000000110000000

\$sp

1111111111111111111111111110000000



Byte/Halfword Operations



- 1bu \$t0, 0(\$sp) //load without sign extension
 - Load rs+offset address into rt
 - Sign bit is not extended in rt

\$sp

\$t0=?

000000000000000000000110000000

000000000000000000000010000000

No store byte unsigned instruction (Sbu)





Other similar instruction

- 1h rt, offset(rs) ; load half word
 - Load rs+offset address into rt
 - Sign extend to 32 bits in rt
- 1hu rt, offset(rs) ;load half word unsigned
- sh rt, offset(rs); store halfword
 - Store just rightmost halfword
- No store halfword unsigned instruction



32-bit Constants



- Most constants are small (16 bit range is -2^{16} ~ 2^{16} -1)
- Sometimes we need 32-bit constant, but a instruction can't have 32-bit constant (no space for op code)
- => combine ui and ori instruction to achieve this
- lui rt, constant
 - Copies 16-bit constant to left 16 bits of rt
 - Clears right 16 bits of rt to 0

Question: Steps to set \$s0 to 4,000,000

4000000₁₀=0000 0000 0011 1101 0000 1001 0000 0000₂

lui \$s0, 61

0000 0000 0011 1101 0000 0000 0000 0000

ori \$s0,\$s0,2304

0000 0000 0000 0000 0000 1001 0000 0000

Finally, \$s0 =

0000 0000 0011 1101 0000 1001 0000 0000



A to t

Branch Addressing (for beq, bne)

- Branch instructions specify
 - Opcode, two registers, target address
- Most branch targets are near branch
 - Forward or backward

- Addr. Inst.
- 8 (01000) beq \$t0 \$t1
- 12(01100) ...
- 16(10000)
- 20(10100)

- PC-relative addressing
 - Address is always a multiple of 4 => offset/4 is stored in the instruction
 - Target address = PC + (Address × 4)
 - PC is already incremented by 4

ор	rs	Address (=Offset/4)	
6 bits	5 bits	16 bits	
If the abo	ove <mark>beq</mark> go	to address 2	20 when \$s0==\$t1, =? 2
000100	01000	01001	0000 0000 0000 0010



Example



- Suppose \$s0=\$t1,
- (1) find target address of beq instruction
- (2) the next instruction to be executed

```
Addr. Inst.
4(00100) beq $s0 $t1 2
8(01000) Inst1.....
12(01100) Inst2....
16(10000) Inst3....
20(10100) Inst4....
```


- Target address= 8+ 2*4=16
- Next instruction to be executed: inst3



成功方學

Jump Addressing

- Jump (j and jal) targets could be anywhere in text segment
 - Need larger address space
 - Encode full address in instruction



- (Pseudo)Direct jump addressing
 - Target address = $PC_{31...28}$: (address × 4)
 - 5. Pseudodirect addressing

 op Address Memory

 PC Word





• Assume $PC=40000000_{16}$, what is the target address of the jump instruction?

000010 00 0000000 0000010 0000001 26 bits

Address in the instruction= 0x0000201


Target Address= $PC[31:28]+0021_{16}*4= 0x40000804$






Target Addressing Example

- Loop code from earlier example (assume PC[31:28]=0000), what is the value of (1) and (2)
 - Assume Loop at location 80000







Branching Far Away

- If branch target is too far to encode with 16-bit offset, assembler insert an unconditional jump to the branch target, and inverts the condition so that the branch decides whether to skip the jump.
- Example

j can jump farer than beq





Summary: Instruction format

• R-format: add, and, or ...

• I-format: beq, bneq, addi, ...

• J-format: j, jal

Name			Fie	lds	Comments		
Field size	6 bits	5 bits	5 bits	5 bits 5 bits 6 bits			All MIPS instructions are 32 bits long
R-format	ор	rs	rt	rd shamt funct			Arithmetic instruction format
I-format	ор	rs	rt	address/immediate			Transfer, branch, imm. format
J-format	ор		ta	rget addres	SS		Jump instruction format




成め方字

Summary: Addressing Mode


 Immediate addressing: operand is a constant within the instruction (e.g. addi)

addi
$$$s1, $s0, 1 # s1 = s0+1$$
 op rs rt Immediate

Register addressing: operand is a register (e.g. add,



 Base or displacement addressing: operand is at the memory location (e.g. lw, sw)




17




Summary: Addressing Mode (2)

 PC-relative addressing: branch address is the sum of PC and constant (e.g. beq)



 (Pseudo)direct addressing: jump address is 26 bit of instruction + PC (e.g. j)





Decoding MIPS instruction

	op(31:26)								
28–26	0(000)	1(001)	2(010)	3(011)	4(100)	5(101)	6(110)	7(111)	
31–29									
0(000)	R-format	Bltz/gez	jump	jump & link	branch eq	branch ne	blez	bgtz	
1(001)	add immediate	addiu	set less than imm.	set less than imm. unsigned	andi	ori	xori	load upper immediate	
2(010)	TLB	F1Pt							
3(011)									
4(100)	load byte	load half	1w1	load word	load byte unsigned	load half unsigned	lwr		
5(101)	store byte	store half	swl	store word			swr		
6(110)	load linked word	1wc1							
7(111)	store cond. word	swc1							


op(31:26)=010000 (TLB), rs(25:21)								
23–21	0(000)	1(001)	2(010)	3(011)	4(100)	5(101)	6(110)	7(111)
25–24								
0(00)	mfc0		cfc0		mtc0		ctc0	
1(01)								
2(10)								
3(11)								

	op(31:26)=000000 (R-format), funct(5:0)									
2-0	0(000)	1(001)	2(010)	3(011)	4(100)	5(101)	6(110)	7(111)		
5–3										
0(000)	shift left logical		shift right logical	sra	sllv		srlv	srav		
1(001)	jump register	jalr			syscall	break				
2(010)	mfhi	mthi	mflo	mtlo						
3(011)	mult	multu	div	divu						
4(100)	add	addu	subtract	subu	and	or	xor	not or (nor)		
5(101)			set l.t.	set l.t. unsigned						
6(110)		1								



Decoding Machine Code

What's the assembly code represent?
 00af8020 (hex)



add \$s0 \$a1 \$t7



Assembler Pseudoinstructions



- Most assembler instructions represent machine instructions one-to-one
- However: some useful instructions may be missing
 - Can be achieved using by other instructions
- Pseudoinstructions: figments of the assembler's imagination

```
move $t0, $t1 \rightarrow add $t0, $zero, $t1 blt $t0, $t1, L \rightarrow slt $at, $t0, $t1 bne $at, $zero, L
```

- \$at (register 1) is reserved for assembler





More pseudoinstructions in MIPS

- blt (branch less than), bgt (branch greater than), ble (branch less than and equal to), bge (branch great than and equal to)
- neg: changes the mathematical sign of the number
- not: bitwise logical negation
- li: loads an immediate value into a register

• sge (set greater than and equal to), sgt (set great than). See references for more details



Exercise



- What is the range of addresses for conditional branches in MIPS (K=1024)?
- 1. Address between 0 and 64K -1
- 2. Address between 0 and 256K -1
- 3. Address up to about 32K before the branch to about 32K after
- 4. Addresses up to about 128K before the branch to about 128K after

ор	rs	rt	constant or address
6 bits	5 bits	5 bits	16 bits

Answer: 4 $2^{16}*4=2^{18}$ = about -128K ~ 128K



成功方學

Exercise -2

- What is the range of addresses for jump and jump and link in MIPS (K=1024)?
 - 1. Address between 0 and 64M -1
 - 2. Address between 0 and 256M -1
 - 3. Address up to about 32M before the branch to about 32M after
 - 4. Addresses up to about 128M before the branch to about 128M after
 - 5. Anywhere within a block of 64M addresses where the PC supplies the upper 6 bits
 - 6. Anywhere within a block of 256M addresses where the PC supplies the upper 4bits

000010	00 0000000 00000010 00000001
6 bits	26 bits

Answer: $2^{26}*4=2^{28}=256MB$. The answer is 6




C Sort Example



- Illustrates use of assembly instructions for a C bubble sort function
- Swap procedure (leaf)
 void swap(int v[], int k)
 {
 int temp;
 temp = v[k];
 v[k] = v[k+1];
 v[k+1] = temp;
 remp;
 remp;

Translate Swap procedure assuming v in \$a0, k in \$a1, temp in \$t0





The Procedure Swap

```
void swap(int v[], int k)
                            v in $a0,
  int temp;
                            k in $a1,
  temp = v[k];
                           temp in $t0
 v[k] = v[k+1];
 v[k+1] = temp;
swap: s11 $t1, sa1, 2 # st1 = k * 4 (k is in $a1)
      add $t1, $a0, $t1 # <math>$t1 = v+(k*4)
                        # (address of v[k])
      lw $t0, 0($t1)  # $t0 (temp) = v[k]
      1w $t2, 4($t1) # $t2 = v[k+1]
      sw t2, 0(t1) # v[k] = t2 (v[k+1])
      sw $t0, 4($t1) # v[k+1] = $t0 (temp)
                        # return to calling routine
      jr $ra
```



The Sort Procedure in C

```
    Non-leaf (calls swap)

       void sort (int v[], int n)
          int i, j;
for1tst \longrightarrow for (i = 0; i < n; i += 1) {
for 2tst \longrightarrow for (j = i - 1;
                   j >= 0 \& v[j] > v[j + 1];
                   i -= 1) {
               swap(v,j);
```

Translate sort procedure assuming v in \$a0, n in \$a1, i in \$s0, j in \$s1





The Sort Procedure

SW SW SW SW	\$ra, 16(\$sp)	# S # S # S # S	save \$ save \$ save \$ save \$ save \$	\$ra (\$s3 (\$s2 (\$s1 (\$s0 (on on on on	stack stack stack stack stack	for	5	registers
	7	# p	proced	dure	bo	dy			
1w 1w 1w 1w	\$s1, 4(\$sp) \$s2, 8(\$sp) \$s3,12(\$sp) \$ra,16(\$sp)	# r # r # r	restor restor restor restor	re \$5 re \$5 re \$5	s1 s2 s3 ra	from s from s from s from s from s k poir	tack tack tack tack		
jr	\$ra	# r	eturr	1 to	ca	lling	rout	ine	2





The Procedure Body

		move	\$s2,	\$a0	#	save \$a0 into \$s2
		move	\$s3,	\$a1	#	save \$a1 into \$s3
		move	\$s0,	\$zero	#	i = 0
for	1tst:	slt	\$t0,	\$s0, \$s3	#	$t0 = 0 \text{ if } s0 \ge s3 (i \ge n)$
		beq	\$t0,	<pre>\$zero, exit1</pre>	#	go to exit1 if $s0 \ge s3$ (i $\ge n$)
		addi	\$s1,	\$s0, -1	#	j = i - 1
for	2tst:	slti	\$t0,	\$s1, 0	#	\$t0 = 1 if \$s1 < 0 (j < 0)
		bne	\$t0,	<pre>\$zero, exit2</pre>	#	go to exit2 if \$s1 < 0 (j < 0)
		s11	\$t1,	\$s1, 2	#	\$t1 = j * 4
		add	\$t2,	\$s2, \$t1	#	t2 = v + (j * 4)
		٦w	\$t3,	0(\$t2)	#	t3 = v[j]
		٦w	\$t4,	4(\$t2)	#	t4 = v[j + 1]
		slt	\$t0,	\$t4, \$t3	#	$t0 = 0 \text{ if } t4 \ge t3$
		beq	\$t0,	<pre>\$zero, exit2</pre>	#	go to exit2 if \$t4 ≥ \$t3
		move	\$a0,	\$s2	#	1st param of swap is v (old \$a0)
		move	\$a1,	\$s1	#	2nd param of swap is j
		jal	swap		#	call swap procedure
		addi	\$s1,	\$s1, -1	#	j -= 1
		j	for2t	tst	#	jump to test of inner loop
exi	t2:				#	i += 1
		j	for1t	tst	#	jump to test of outer loop

Move params

Outer loop

Inner loop

Pass params & call

Inner loop


Outer loop





Effect of Compiler Optimization

Compiled with gcc for Pentium 4 under Linux



Instruction count and CPI are not good performance indicators in isolation



Fallacies


- Powerful instruction ⇒ higher performance
 - Fewer instructions required
 - But complex instructions are hard to implement
 - May slow down all instructions, including simple ones
 - Compilers are good at making fast code from simple instructions
- Use assembly code for high performance
 - But modern compilers are better at dealing with modern processors
 - More lines of code ⇒ more errors and less productivity



Fallacies



- Backward compatibility ⇒ instruction set doesn't change
 - But they do accrete more instructions





Pitfalls



 Sequential words are not at sequential addresses=>increment by 4, not by 1!

\$s3	Base address of A
\$s2	h
\$s1 [g
\$s0	

$$g = h + A[8];$$

g in \$\$1, h in \$\$2, base address of A in \$\$3

••••

A[8]

Compiled MIPS code:


- Index 8 requires offset of 32
 - 4 bytes per word

X + 32

2.19 Concluding Remarks

Concluding Remarks

- Design principles
 - 1. Simplicity favors regularity
 - 2. Smaller is faster
 - 3. Make the common case fast
 - 4. Good design demands good compromises
- Layers of software/hardware
 - Compiler, assembler, hardware
- MIPS: typical of RISC ISAs
 - c.f. x86





Exercise





Backup slides

