

# BREEZELITE GLOBAL - OFFICIAL OPERATING MANUAL

## Model: BreezeLite BLD-Curl Master

### OPERATING INSTRUCTIONS

#### ALCI SAFETY TEST (BEFORE EVERY USE):

1. Plug into a standard outlet. Press the TEST button; the RESET button should pop out.
2. Press RESET to reactivate the unit. Do not use if the test fails.

#### DRYING STEPS:

1. Attach diffuser before powering on.
2. Use Low heat and Low speed. Place curls in the diffuser and lift toward the scalp.

### MAINTENANCE & STORAGE

1. Unplug the unit and allow it to cool completely before cleaning.
2. Use a soft brush to remove dust and lint from the rear intake filter monthly. Blocked airflow causes overheating and potential fire hazard.
3. DO NOT WRAP THE POWER CORD AROUND THE DRYER. Store the cord loosely coiled to prevent internal wire breakage and sparking.

### LIMITED THREE (3) MONTH WARRANTY

BreezeLite Global warrants this product against defects in workmanship and materials for a period of three (3) months from the original date of purchase. This warranty only covers defects in workmanship and materials. The warranty does not include damage due to abuse or misuse, any commercial use, or accidents.

### WHAT IS NOT COVERED

- Normal wear and tear.
- Damage caused by misuse, abuse, or failure to follow instructions.
- Damage caused by wrapping the power cord around the unit.
- Use with a voltage converter or improper electrical current.
- Damage resulting from immersion in water.
- Physical damage to the diffuser attachment prongs or mounting ring.

### LIMITATIONS

The warranty stated above is the only warranty applicable to this product. Other expressed or implied warranties are hereby disclaimed. The manufacturer shall not be liable for incidental or consequential damages resulting from the use of this product. Any implied warranty of merchantability or fitness for a particular purpose is limited to the duration of this warranty.

### HOW TO FILE A CLAIM

For warranty service, contact BreezeLite Global Support. PHYSICAL SHIPPING IS NOT REQUIRED.

Email: support@breezeliteglobal.com | Provide: Model #, Receipt Photo, and Video of defect.