


Fundamentals of Electronics

ECE 101



# The Transistor


Amplification and switching

Transistor

- Key characteristic:

- The transistor is a three-terminal device with the feature that the current through two terminals can be controlled by small changes we make in the current or voltage at the third terminal.
- This control feature allows us to amplify small ac signals or to switch the device from an *on* state to an *off* state and back.
- These two operations, amplification and switching, are the basis of a host of electronic functions.
- This forms the basis for both bipolar junction transistors (BJT) and field effect transistors (FET).





# The transistor action - 1



$$V_i = I \times \underline{r} \quad V_o = I \times \underline{R}$$
$$V_i < \underline{V_o} \quad (\text{amplification})$$

Active mode  
 $J_1 \rightarrow f.b. \quad R_{es} = 0$   
 $J_2 \rightarrow \gamma.b. \quad R_{es} = \infty$

# The transistor action - 2







- If an ac source is added to the control voltage
  - We can achieve large variations in  $i_D$  by making small changes in  $V_G$
  - For example if  $V_G$  changes by value of 0.25V,  $V_d$  varies about its dc 2V.
  - Thus the amplification of the ac signal is  $2/0.25 = 8$ .
  - we can switch from the bottom of the load line to almost the top by appropriate changes in  $V_G$ .

For BJTs, this kind of control is achieved by current control.

# Field Effect Transistors

The idea

## Junction Field Effect Transistor: JFETs




Gate control

$$v_d = \frac{I}{neA}$$




# MOSFET (Metal–Oxide–Semiconductor Field-Effect Transistor)

MOSFET





(b)


Different regimes as  $V_D$  is varied.





# Field Effect Transistors




## Characteristics



Different regimes as  $V_D$  is varied.




Pinch-off



# MOSFET (Metal–Oxide–Semiconductor Field-Effect Transistor)

N-Channel MOSFETs use electron flow as the charge carrier. P-Channel MOSFETs use hole flow as the charge carrier, which has less mobility than electron flow.

## Symbols




4-terminal

Simplified

Simplified

n-channel MOSFET






4-terminal

Simplified

Simplified

p-channel MOSFET

# MOSFET Band Diagram





N-channel MOSFET



Most transistors operate by controlling the height of an energy barrier with an applied voltage.

Note: that there is a potential energy barrier that separates electrons in the source from electrons in the drain.


## Application of a positive voltage




# MOSFET Characteristics




# MOSFET Circuits



Common gate amplifier



N-Channel



CS stage with resistive load

**Thank you**