



Embedded Systems Advanced Nano-Degree Embedded Software Design

Automotive Door Control System Design

Static Design

Ahmad Aladdin Tohamy

tuhami.10.8@gmail.com July Cohort 2022


Table of Contents

Static Design Analysis	2
ECU 1	2
Layered Architecture	2
ECU 1 Components	2
ECU 1 Modules	2
APIs	3
Folder Structure	9
ECU 2	10
Layered Architecture	10
ECU 2 Components	10
ECU 2 Modules	10
APIs	11
Folder Structure	18

Static Design Analysis

1. ECU 1

• Layered Architecture



• ECU 1 Components

- 1) Door Sensor 2) Light Switch
- 3) Speed Sensor

• ECU 1 Modules

MCAL Layer	HAL Layer
1) General Purpose Input Output Module	1) Light Switch Module
2) Analog-to-Digital Converter	2) Speed Sensor Module
3) Controller Area Network Module	3) Door Sensor Module
4) Port Module	
5) System Control Module	
Servi	ce Layer
1) Operating System	2) Basic Communication Module

• APIs

Port Module:

Function Nan	ne:	void PORT_Init (const Port	<pre>void PORT_Init (const Port_ConfigType * Port_ConfigArray)</pre>	
Arguments:	Input:	Name : Port_ConfigArray		
			Type : Pointer to Port_ConfigType Port_ConfigType is an unsigned char	
		Range: Array size is hardware dependant as each element represents a pin Each element range is hardware dependant as well. We may assume 0-15 (the number of possible functionalities) as an example for illustration.		
		Macros: which represent each pin possible functionalities according to data sheet For ex: PAO_DIO, PA1_GPT, PA2_ADC, PA3_CAN_TX, etc		
		Description : Specifies each pin configuration		
	Output:	None		
Return: None				
Synchronous	: Yes	Reentrant: Yes		
Description:		This function sets Initializes each Pin with its desired functionality		

SysCtrl Module:

Function Nam	ne:	void SysCtrl_MicrocontrollerInit (void)	
Arguments:	Input:	Macros from SysCtrl_Configure.h header file	
		Range : each configuration Macro has a range which is data sheet dependant	
		Description : Specifies Microcontroller clock configuration	
	Output:	None	
Return:		None	
Synchronous:		Yes	
Reentrant:		Yes	
Description:		This function Initializes necessary configurations for Microcontroller such as system clock , peripherals configurations	

General Purpose Input Output Module:

Function Nam	e:	GPIO_LevelType GPIO_ReadChannel (GPIO_ChannelType ChannelId);
Arguments:	Input:	Name : ChannelId
		Type: GPIO_ChannelType (An enum of microcontroller GPIO channels)
		Range : 0-Number of GPIO Channels (Hardware dependant)
		Variable / Macro : Macro
		Description : Indicates which GPIO channel to read from
	Output:	Name: -
		Type: GPIO_LevelType (An enum representing High/Low levels)
		Range : 0-1
		Variable / Macro : Variable
		Description : Indicates GPIO channel current level
Return:		GPIO_LevelType
Synchronous:		Yes
Reentrant:		No
Description:		This function receives input level from specified Pin Used typedefs GPIO_ChannelType : Specifies which channel to read from GPIO_LevelType : Specifies channel level (High/Low)

ADC Module:

Function Nam	e:	void ADC_Init(void);
Arguments:	Input:	Macros from ADC_Configure.h header file
		Range : each configuration Macro has a range which is data sheet dependant
		Description : Specifies ADC configurations
	Output:	None
Return:		None
Synchronous:		Yes
Reentrant:		Yes
Description:		This function Initializes necessary configurations for Analog-to-Digital Converter Module

Function Name: u8 ADC_StartConv		u8 ADC_StartConver	rsion(ADC_ChannelType ChannelId);	
Arguments:	Input:	Name : ChannelId		
		Type : ADC_Channel	Type : ADC_ChannelType	
		Range : 0-Number o	f ADC channels (HW Dependant)	
		Variable/Macro : Ma	acro	
		Description : Indica	tes which ADC channel to read from	
	Output:	Name : -		
		Type: unsigned char (u8)		
		Range: 0-255		
		Variable/Macro : Variable		
		Description : Converted Digital Data		
Return: u8				
Synchronous: Yes			Reentrant: No	
This function rec		This function receiv	res input level from specified Pin	
Description: Used ty		Used typedefs		
ADC_Channel		ADC_ChannelType:	Specifies which channel to read signal from	
TIDO		3_01.011.011.) po :		

CAN Module:

Function Nam	e:	void CAN1_Init(void);	
Arguments:	Input:	t: Name : -	
		Type:-	
		Range : each configuration has a different range	
	Variable / Macro : Macros		
		Description : CAN1 Module Configurations	
	Output:	None	
Return:		None	
Synchronous:		Yes	
Reentrant:		Yes	
Description:		This function Initializes necessary configurations for CAN Module	

Function Name	e:	void CAN1_TransmitMessage(void);
Arguments:	nents: Input: Passed by writing over TxMailBox	
		Type : unsigned char
		Range: 0-255
		Variable / Macro : Variable
		Description : Message content
	Output:	None
Return:		None
Synchronous:		Yes
Reentrant:		No
Description:		This function Transmits a message to CAN Transceiver

Light Switch Module:

Function Name:		LightSwitch_StateType LightSwitch_getState(void);
Arguments:	nts : Input: None	
	Output:	Name:-
		Type: LightSwitch_StateType (High/Low)
	Range: 0-1	
		Variable / Macro : Variable
		Description : Light Switch Current state
Return:		LightSwitch_StateType
Synchronous:		Yes
Reentrant:		Yes
Description:		This function gets the current light switch state Used Typedefs LightSwitch_StateType : Specifies switch level (ON/OFF)


Speed Sensor Module:

Function Name:		u32 SpeedSens_getSpeed(void);
Arguments:	Input:	None
	Output:	Name:-
		Type: unsigned integer
		Range: 0-4294967295
		Variable / Macro : Variable
		Description : Speed Sensor Current value
Return:		u32
Synchronous:		Yes
Reentrant:		No
Description:		This function gets the digital form of a speed sensor

Door Sensor Module:


Function Nam	e:	DoorSens_StateType DoorSens_getState(void);
Arguments:	Input:	None
	Output:	Name:-
		Type : DoorSens_StateType (Open/Closed)
		Range: 0-1
		Variable / Macro : Variable
		Description : Door Current state
Return:		DoorSens_StateType
Synchronous:		Yes
Reentrant:		No
Description:		This function gets the current light switch state Used Typedefs DoorSens_StateType : Specifies Door state (Open/Closed)

• Folder Structure



2. ECU 2

• Layered Architecture



• ECU 2 Components

1)Right Light

- 2) Left Light
- 3) Buzzer

• ECU 2 Modules

MCAL Layer	HAL Layer
1) General Purpose Input Output Module	1) Lights Module
2) General Purpose Timers Module	2) Buzzer Module
3) Controller Area Network Module	
5) Port Module	
6) System Control Module	
Service	e Layer
1) Operating System	
2) Basic Communication Module	

APIs

There are many common API between ECU1 and ECU2 such as:

Port Module: void PORT_Init (const u8 PinConfig)

SysCtrl Module: void SysCtrl_MicrocontrollerInit (void)

General Purpose Input Output Module:

GPIO_LevelType GPIO_ReadChannel (GPIO_ChannelType ChannelId);

CAN Module: void CAN1_Init(void)

General Purpose Timers Module:

Function Name:		void GPT_Init (Gpt_ConfigType * GPT_ConfigArray)	
Arguments:	Input:	Name: GPT_ConfigArray	
		Type : Array of Gpt_ConfigType Gpt_ConfigType is a structure which represents each pin name and configurations	
		Range : Array size is hardware dependant as each element represents a GPT channel .	
		Macros: which represent each channel configurations	
		Description : Specifies each GPT channel configuration	
	Output:	None	
Return:		Void	
Synchronous:		Yes	
Reentrant:		No	
		This function initializes the microcontroller timer with desired configurations	
Description:		<u>Used typedefs</u>	
		Gpt_ConfigType : Contains configurations associated with timers such as (Channel Id , Channel Mode , Channel Tick Frequency , etc)	

Function Name:		void GPT_StartTimer(Gpt_ChannelType Channel, Gpt_ValueType Counts);	
Arguments:	Input:	Name : Channel	
		Type: Gpt_ChannelType	
		Range: 0-Number of GPT Channels (HW dependant)	
		Variable / Macro: Macro	
		Description : Specifies which GPT channel to start	
	Input:	Name: Ticks	
		Type : Gpt_ValueType (unsigned integer)	
		Range: 0-4294967295	
		Variable / Macro : Variable	
		Description : Specifies the number of ticks desired	
	Output:	None	
Return:		Void	
Synchronous:		Yes	
Reentrant:		No	
Description:		This function starts the specified timer with desired number of ticks <u>Used typedefs</u> Gpt_ChannelType : Contains all the channel IDs Gpt_ValueType : unsigned integer	

Function Name:		void GPT_StopTimer(Gpt_ChannelType Channel);	
Arguments:	Input:	Name : Channel	
		Type: Gpt_ChannelType	
		Range: 0-Number of GPT Channels (HW dependant)	
		Variable / Macro: Macro	
		Description : Specifies which GPT channel to stop	
	Output:	None	
Return:		Void	
Synchronous:		Yes	
Reentrant:		No	
		This function stops the specified timer with	
Description:		<u>Used typedefs</u>	
		Gpt_ChannelType : Contains all the channel IDs	

Function Name:		void GPT_nSecondsDelay (Gpt_ChannelType Channel, Gpt_ValueType TimeInSec);	
Arguments:	Input:	Name : Channel	
		Type : Gpt_ChannelType	
		Range: 0-Number of GPT Channels (HW dependant)	
		Variable / Macro: Macro	
		Description : Specifies which GPT channel to start	
	Input:	Name: TimeInSec	
		Type : Gpt_ValueType (unsigned integer)	
		Range: 0-4294967295	
		Variable / Macro : Variable	
		Description : Specifies the number of ticks desired	
	Output:	None	
Return:		Void	
Synchronous:		Yes	
Reentrant:		No	
		This function is a busy wait implementation for the desired number of seconds	
Description:		Used typedefs	
		Gpt_ChannelType : Contains all the channel IDs	

General Purpose Input Output Module:

Function Nam	e:	void GPIO_WriteChannel (GPIO_ChannelType ChannelId, GPIO_LevelType Level)	
Arguments:	Input:	Name : ChannelId	
		Type : GPIO_ChannelType	
		Range: 0-Number of GPIO Channels (HW dependant)	
		Variable / Macro: Macro	
		Description : Specifies which GPIO channel to write over	
	Input	Name: Level	
		Type: GPIO_LevelType (High/Low)	
		Range: 0-1	
		Variable / Macro : Variable	
		Description : Sets GPIO Channel level	
Return:		None	
Synchronous:		Yes	
Reentrant:		Yes	
Description:		This function sets specified Output Pin value as desired <u>Used typedefs</u> GPIO_ChannelType : Specifies which channel to write over GPIO_LevelType : Specifies desired level (High/Low)	

CAN Module:

Function Name:		u8 CAN1_ReceiveMessage(void);
Arguments:	Input:	None
	Output:	Name:-
		Type: unsigned char (u8)
		Range: 0-255
		Variable/Macro : Variable
		Description : Received Data
Return:		u8
Synchronous:		Yes
Reentrant:		No
Description:		This function Receives a message from CAN Transceiver

Buzzer Module:

Function Name: void Buzz_SetBuzzerON(void);		id);	
Arguments:	Input:	None	
	Output:	None	
Return: None		None	
Synchronous: Yes			Reentrant: No
Description: This function Turns the buzzer on		zer on	

Function Name: void Buzz_SetBuzzerOFF(void);		oid);	
Arguments:	Input:	None	
	Output:	None	
Return: None		None	
Synchronous: Yes			Reentrant: No
Description: This function Turns the buzzer off		zer off	

Lights Module:

Function Name:		void Lights_SetLightsON(void);
Arguments:	Input:	None
	Output:	None
Return:		None
Synchronous:		Yes
Reentrant:		No
Description:		This function Turns the Lights on

Function Name:		void Lights_SetLightsOFF(void);
Arguments:	Input:	None
	Output:	None
Return:		None
Synchronous:		Yes
Reentrant:		No
Description:		This function Turns the Lights Off

• Folder Structure

