Building an Arithmetic Machine

SIGN UP FOR OR CANCEL


2nd chance exam reservation.

Today's lecture

- The Arithmetic Machine
 - Programmable hardware
 - Instruction Set Architectures (ISA)
 - Instructions & Registers
 - Assembly Language
 - Machine Language

Building an "arithmetic machine"

- With an ALU and a register file, we can build a calculator
 - Here are the essential parts.



Building a computer processor.

- The key feature that distinguishes a computer processor from other digital systems is programmability.
- A processor is a hardware system controlled by software



- An Instruction Set Architecture (ISA) describes the interface between the software and the hardware.
 - Specifies what operations are available
 - Specifies the effects of each operation

A MIPS ISA processor

- Different processor families (x86, PowerPC, ARM, MIPS, ...) use their own instruction set architectures.
- The processor we'll build will execute a subset of the MIPS ISA
 - Of course, the concepts are not MIPS-specific
 - MIPS is just convenient because it is real, yet simple
- The MIPS ISA is widely used. Primarily in embedded systems:
 - Various routers from Cisco
 - Game machines like the Nintendo 64 and Sony Playstation 2








Programming and CPUs

Programs written in a high-level language like <u>C++</u> must be <u>compiled</u> to produce an executable program.

The result is a CPU-specific machine

- The result is a CPU-specific machine language program. This can be loaded into memory and executed by the processor.
- Machine language serves as the interface between hardware and software.



High-level languages vs. machine language

- High-level languages are designed for human usage:
 - Useful programming constructs (for loops, if/else)
 - Functions for code abstraction; variables for naming data
 - Safety features: type checking, garbage collection
 - Portable across platforms
- Machine language is designed for efficient hardware implementation
 - Consists of very simple statements, called instructions
 - Data is named by where it is being stored
 - Loops, if/e(se implemented by branch and jump instructions)
 - Little error checking provided; no portability

Assembly Language & Instructions

Machine language is a binary representation of instructions

100116

- Assembly language is a human-readable version
- There is an (almost) one-to-one correspondence between assembly and machine languages; we'll see the relation later.
- Instructions consist of:
 - Operation code (opcode): names the operation to perform
 - Operands: names the data to operate on
- Example:



MIPS: register-to-register, "three address" code

- MIPS uses three-address instructions for arithmetic.
 - Each ALU instruction contains a destination and two sources.
- MIPS is a register-to-register architecture.
 - For arithmetic instructions, the destination and sources must all be registers (or constants).
 - Special instructions move values between the register file and memory.
- For example, an addition (a = b + c) might look like:


operation operands
$$$6 = register #6$$

ADD $$17, $6, 15
destination sources


 $$3$

MIPS register file

- MIPS processors have 32 registers, each of which holds a 32-bit value.
 - Register specifiers (addresses) are 5 bits long.
 - The data inputs and outputs are 32-bits wide.
- Register 0 is special
 - It is always read as the value 0.
 - Writes to it are ignored.
- Two naming conventions for registers:
 - By number: \$0,..., \$17,..., \$31 ◆
 - By name: \$zero,..., \$s1,..., \$ra ← qssen bly/so



A 32 x 32b Register File



Basic arithmetic and logic operations

MIPS provides basic integer arithmetic operations:

add sub mul* div*

And logical operations:

and or nor xor not

Remember that these all require three register operands; for example:

```
add $14, $18, $3 # $14 = $18 + $3
mul $22, $22, $11 # $22 = $22 x $11
```

Note: a full MIPS ISA reference can be found in Appendix A (linked from website)

* We won't implement these in our implementation

Larger expressions

 More complex arithmetic expressions may require multiple operations at the instruction level.

- Temporary registers may be necessary, since each MIPS instruction can access only two source registers and one destination.
 - We could have re-used \$1, \$3 instead of introducing \$5, \$6.
 - But be careful not to modify registers that are needed again later.

Immediate operands

- So far, the instructions expect register operands. How do you get data into registers in the first place?
 - Some instructions allow you to specify a <u>signed constant</u>, or "immediate" value, for the second source instead of a register.
 - For example, here is the immediate add instruction, addi:

Immediate operands can be used in conjunction with the \$zero register to write constants into registers:

A more complete example

• What if we wanted to compute the following?

$$1 + 2 + 3 + 4$$

A more complete example iclicker.

• What if we wanted to compute the following?

$$1 + 2 + 3 + 4$$

```
III
       Ι
                                ΙI
addi $1, 1, 2
                         addi $1, $0, 1
                                                addi $1, $0, 1
                                                addi $2, $0, 2
addi $2, 3, 4
                         addi $1, $1, 2
add $1, $1, $2
                         addi $1, $1, 3
                                                addi $3, $0, 3
                         addi $1, $1, 4
                                                addi $4, $0, 4
                                                add $1, $1, $2
                                                add $3, $3, $4
           A: none of the above
                                                add $1, $1, $3
           B: I and II
           C: I and III
           D: II and III
           E: all of the above
```

To be continued elsewhere...

- We will write code some assembly code (add.s)
- Execute code in MIPS simulator called SPIM
- Tour of MIPS reference documents
 - Appendix A
 - MIPS Green Sheet